

1990 Mazda 323 4-Wheel Drive Workshop Manual Supplement

FOREWORD

This is a supplement to the workshop manual(s) shown below. This supplement describes service procedures of new or modified mechanical and/or electrical systems. For service procedures and important safety notices not contained in this supplement, please refer to the previous workshop manual.

Workshop Manual:
Form No.1195-10-89E

All information in this supplement was the latest available at the time of printing, all alterations related to modifications will be notified by Service Bulletin.

Mazda Motor Corporation
HIROSHIMA, JAPAN

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

| Title | Section |
|--|---------|
| General Information | GI |
| Pre-Delivery Inspection and Scheduled Maintenance Services | A |
| Engine | B |
| Lubrication System | D |
| Cooling System | E |
| Fuel and Emission Control System | F |
| Engine Electrical System | G |
| Clutch | H |
| Manual Transaxle and Transfer | J3 |
| Automatic Transaxle and Transfer | K2 |
| Propeller Shaft | L |
| Front and Rear Axles | M |
| Steering System | N |
| Braking System | P |
| Wheels and Tires | Q |
| Suspension | R |
| Body | S |
| Body Electrical System | T |
| Heater and Air Conditioner Systems | U |
| Technical Data | TD |
| Special Tools | ST |
| Parts Index | PI |
| Wiring Diagram (Form No. 5145-10-89G) | Z |

© 1989 Mazda Motor Corporation
PRINTED IN JAPAN, SEP., '89 (N)
1213-10-89I

VEHICLE IDENTIFICATION NUMBERS (VIN)

JM1 BG227 * L0 100001 ~
JM1 BG228 * L0 100001 ~

GENERAL INFORMATION

| | |
|--|--------------|
| IMPORTANT INFORMATION | GI- 2 |
| BASIC ASSUMPTIONS | GI- 2 |
| SAFETY RISK | GI- 2 |
| POSSIBLE LOSS OF WARRANTY | GI- 2 |
| WARNING ON LUBRICANTS AND GREASES | GI- 2 |
| HOW TO USE THIS MANUAL | GI- 3 |
| PREPARATION | GI- 3 |
| REPAIR PROCEDURE | GI- 3 |
| SYMBOLS | GI- 4 |
| NOTES, CAUTIONS, AND WARNINGS | GI- 4 |
| FUNDAMENTAL PROCEDURES | GI- 4 |
| PROTECTION OF THE VEHICLE | GI- 4 |
| A WORD ABOUT SAFETY | GI- 5 |
| PREPARATION OF TOOLS AND MEASURING EQUIPMENT | GI- 5 |
| SPECIAL TOOLS | GI- 5 |
| REMOVAL OF PARTS | GI- 5 |
| DISASSEMBLY | GI- 5 |
| REASSEMBLY | GI- 6 |
| ADJUSTMENTS | GI- 7 |
| RUBBER PARTS AND TUBING | GI- 7 |
| JACK AND SAFETY STAND POSITIONS | GI- 8 |
| VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS | GI- 8 |
| TOWING | GI- 9 |
| IDENTIFICATION NUMBER LOCATIONS | GI-10 |
| UNITS | GI-10 |
| ABBREVIATIONS | GI-10 |
| CAUTION | GI-11 |
| INSTALLATION OF A MOBILE TWO-WAY RADIO SYSTEM | GI-11 |
| REMOVAL OF IGNITION KEY ON AUTOMATIC TRANSAXLE MODEL | GI-11 |
| ELECTRICAL TROUBLESHOOTING TOOLS | GI-12 |
| CAUTION WITH ELECTRICAL PARTS | GI-13 |

IMPORTANT INFORMATION**BASIC ASSUMPTIONS**

This workshop manual assumes that you have certain special tools that are necessary for the safe and efficient performance of service operations on Mazda vehicles and that you know how to use them properly. It also assumes that you are familiar with automobile systems and basic service and repair procedures. You should not attempt to use this manual unless these assumptions are correct and you understand the consequences described below.

SAFETY RISK

This manual contains certain notes, warnings, and other precautionary information that you should carefully read and follow to reduce the risk of personal injury to yourself or others and the risk of improper service that may damage the vehicle or render it unsafe. If there is no such information in regard to any specific service method, this does not mean there is no possibility that personal safety or vehicle safety will be jeopardized by the use of incorrect methods or tools.

POSSIBLE LOSS OF WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

WARNING ON LUBRICANTS AND GREASES

Avoid all prolonged and repeated contact with mineral oils, especially used oils. Used oils contaminated during service (e.g., engine sump oils) are more irritating and more likely to cause serious effects, including skin cancer, in the event of gross and prolonged skin contact.

Wash skin thoroughly after work involving oil.

Protective hand cleaners may be of value provided they can be removed from the skin with water. Do not use gasoline, paraffin, or other solvents to remove oil from the skin.

Lubricants and greases may be slightly irritating to the eyes.

Repeated or prolonged skin contact should be avoided by wearing protective clothing if necessary. Particular care should be taken with used oils and greases containing lead. Do not allow work clothing to be contaminated with oil. Dry clean or launder such clothing at regular intervals.



9MUGIX-002

HOW TO USE THIS MANUAL

PREPARATION

PREPARATION points out the needed **Special Service Tool (SST)** for the service operation that it proceeds. Gather all necessary **SST** before beginning work.

Example:


| MANUAL STEERING | | SST NUMBER | USAGE |
|---|----------------------------|---|----------------------------|
| PREPARATION SST 49 0118 850C Puller, ball joint  | For removal of tie-rod end | 49 0118 850C Puller, ball joint  | For removal of tie-rod end |
| | | SST NAME | SST ILLUSTRATION |

9MUGIX-033

REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and visual parts inspections. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

Example:



SHOWS EXPENDABLE PARTS (Callout to part 9)

SHOWS APPLICATION POINT OF OIL, ETC. (Callout to part 10)

SHOWS RELATED PAGE FOR SERVICE (Callout to part 1)

SHOWS TIGHTENING TORQUE SPECIFICATION *2 (Callout to part 20)

SHOWS TIGHTENING TORQUE UNIT (Callout to part 20)

SHOWS VISUAL INSPECTION INFORMATION (Callout to part 16)







| | |
|--------------------------------|--|
| 1. Bolt | 16. Bearing inner race |
| 2. Lock plate | Removal..... page M-22 |
| 3. Bearing cup | Inspect for damage or rough rotation |
| 4. Adjusting screw | Installation..... page M-24 |
| 5. Bearing outer race | 17. Spacer |
| 6. Locknut | 18. Drive pinion |
| 7. Washer | Removal..... page M-21 |
| 8. Companion flange | Inspect splines and teeth for wear or damage |
| Removal..... page M-21 | Adjustment of height..... page M-22 |
| Inspect splines..... page M-21 | Adjustment..... page M-24 |

*1: The numbering (ex. ①) shows service procedure.

*2: Units shown in N·m (m·kg, ft·lb) unless otherwise specified.

SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.

| Symbol | Meaning | Kind |
|--|------------------------------------|---|
|  | Apply oil | New engine oil or gear oil as appropriate |
|  | Apply brake fluid | Only brake fluid |
|  | Apply automatic transmission fluid | Only ATF |
|  | Apply grease | Appropriate grease |
|  | Apply sealant | Appropriate sealant |
|  | Apply petroleum jelly | Appropriate petroleum jelly |

05UGIX-005


Note

- When special oil or grease is needed, this is shown in the illustration.

NOTES, CAUTIONS, AND WARNINGS

As you read through the procedures, you will come across NOTES, CAUTIONS, and WARNINGS. Each one is there for a specific purpose. **NOTES** give you **added information** that will help you to complete a particular procedure. **CAUTIONS** are given to prevent you from making an error that could **damage the vehicle**. **WARNINGS** remind you to be especially careful in those areas where carelessness can cause **personal injury**. The following list contains some general WARNINGS you should follow when you work on a vehicle.


9MUGIX-036



9MUGIX-037

FUNDAMENTAL PROCEDURES**PROTECTION OF THE VEHICLE**

Always be sure to cover fenders, seats, and floor areas before starting work.




9MUGIX-003

A WORD ABOUT SAFETY

The following precautions must be followed when jacking up the vehicle.

1. Block the wheels.
2. Use only the specified jacking positions.
3. Support the vehicle with safety stands.


Start the engine only after making certain the engine compartment is clear of tools and people.



9MUGIX-038

PREPARATION OF TOOLS AND MEASURING EQUIPMENT


Be sure that all necessary tools and measuring equipment are available before starting any work.



47U0GX-005

SPECIAL TOOLS


Use special tools when they are required.



47U0GX-006

REMOVAL OF PARTS


While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair.



9MUGIX-039

DISASSEMBLY


If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



9MUGIX-040

1. Inspection of parts

When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.




9MUGIX-041

2. Arrangement of parts

All disassembled parts should be carefully arranged for re-assembly.


Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



47U0GX-010

3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.



9MUGIX-004

REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts. Refer to STANDARD BOLT AND NUT TIGHTENING TORQUE in Section TD for tightening torques not mentioned in the main text.

If removed, these parts should be replaced with new ones:


- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:

1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.




9MUGIX-042



67U0GX-002

ADJUSTMENTS

Use suitable gauges and/or testers when making adjustments.



9MUGIX-005

RUBBER PARTS AND TUBING


Prevent gasoline or oil from getting on rubber parts or tubing.

JACK AND SAFETY STAND POSITIONS

FRONT END

Jack position:


At the front crossmember



03UGIX-007

Safety stand positions:

On both sides of the body frame




03UGIX-008

REAR END

Jack position:

At the center of the rear crossmember (2WD)


At the rear differential (4WD)



03UGIX-801

Safety stand positions:

On both sides of the body frame




03UGIX-010

VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

FRONT END

Frame

Side sills




9MUGIX-010

REAR END

Frame


Side sills




9MUGIX-011

TOWING


TOWING



WHEEL DOLLIES



03UGIX-002



Proper towing equipment is necessary to prevent damage to the vehicle.

Laws and regulations applicable to vehicles in tow must always be observed.

As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.


With either automatic or manual transaxle:

1. Set the ignition switch in the ACC position;
2. Place the selector lever or shift lever in N (Neutral);
3. Release the parking brake.


Caution

- **Do not tow the vehicle backward with driving wheels on the ground. This may cause internal damage to the transaxles.**
- **Do not use the hook loops under the front and rear of the vehicle for towing purposes. These hook loops are designed ONLY for transport tie-down. If tie-down hook loops are used for towing, the front/rear bumper will be damaged.**

TIE-DOWN HOOKS — FRONT




TIE-DOWN HOOKS — REAR




IDENTIFICATION NUMBER LOCATIONS


VEHICLE IDENTIFICATION NUMBER (VIN)



AUTOMATIC TRANSAXLE MODEL AND NUMBER



ENGINE MODEL AND NUMBER



9MUGIX-015

UNITS

| | |
|---|--------------------------------|
| Nm (m·kg or cm·kg, ft·lb or in·lb)..... | Torque |
| rpm..... | Revolutions per minute |
| A..... | Ampere(s) |
| V..... | Volt(s) |
| Ω | Ohm(s) (resistance) |
| kPa (kg/cm ² , psi)..... | Pressure (usually positive) |
| mmHg (inHg)..... | Pressure (usually negative) |
| W..... | Watt |
| liters (US qt, Imp qt).... | Volume |
| mm (in)..... | Length |

89U0GX-006

ABBREVIATIONS

| | |
|-----------|------------------------------|
| ABDC..... | After bottom dead center |
| A/C..... | Air conditioner |
| ACC..... | Accessories |
| ATX..... | Automatic transaxle |
| ATDC..... | After top dead center |
| ATF..... | Automatic transmission fluid |
| BAC..... | Bypass air control |
| BBDC..... | Before bottom dead center |
| BTDC..... | Before top dead center |
| CPU..... | Central processing unit |

| | |
|------------|--|
| EC-AT..... | Electronically-controlled automatic transmission |
| ECU..... | Engine control unit |
| EGL..... | Electronic gasoline injection |
| E/L..... | Electrical load |
| EX..... | Exhaust |
| IC..... | Integrated circuit |
| IGN..... | Ignition |
| IN..... | Intake |
| INT..... | Intermittent |
| ISC..... | Idle speed control |
| LH..... | Left hand |
| M..... | Motor |
| MIL..... | Malfunction indicator lamp |
| MTX..... | Manual transaxle |
| OD..... | Overdrive |
| OFF..... | Switch off |
| ON..... | Switch on |
| PCV..... | Positive crankcase ventilation |
| PRC..... | Pressure regulator control |
| P/S..... | Power steering |
| P/W..... | Power window |
| RH..... | Right hand |
| SST..... | Special service tool |
| ST..... | Start |
| SW..... | Switch |
| TDC..... | Top dead center |
| 4WD..... | 4-wheel drive |

03UGIX-802


CAUTION

INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM


If a mobile two-way radio system is installed improperly or if a high-powered type is used, the EGI system and other systems may be affected.

When the vehicle is to be equipped with a mobile two-way radio, observe the following precautions:

1. Install the antenna at the farthest point from control units.
2. Install the antenna feeder as far as possible from the control unit harnesses (**at least 30 cm [11.8 in]**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered mobile two-way radio system.




05UGIX-013




03UGIX-005

REMOVAL OF IGNITION KEY ON AUTOMATIC TRANSAXLE MODEL


The selector lever must be in P (PARK) to turn the ignition key to the OFF position. If the switch seems to be off but the key cannot be removed, the switch may still be in the ACC position, or the selector lever may not be in P (PARK). Shift the selector lever to P (PARK), and turn the ignition key to the LOCK position. The key should now be free for removal.




9MUGIX-019




9MUGIX-020



9MUGIX-021



05UGIX-021



9MUGIX-045

ELECTRICAL TROUBLESHOOTING TOOLS

Test Light

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

Caution

- When checking the control unit, never use a bulb over 3.4W.

Jumper Wire

The jumper wire is used for testing by shorting across switch terminals and ground connections.

Caution

- Do not connect a jumper wire from the power source line to a body ground; this may cause burning or other damage to harnesses or electronic components.

Voltmeter

The DC voltmeter is used to measure of circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.

Diagnosis Connector

Insert the probe into the service hole when connecting a jumper wire to the diagnosis connector.

Caution


- Do not insert the jumper wire probe into the diagnosis connector terminal, which may damage the terminal.

Ohmmeter

The ohmmeter is used to measure the resistance between two points in a circuit and also to check for continuity and diagnosis of short circuits.

Caution

- Do not attempt to connect the ohmmeter to any circuit to which voltage is applied; this may burn or otherwise damage the ohmmeter.




9MUGIX-022

CAUTION WITH ELECTRICAL PARTS

Battery Cable

Before disconnecting connectors or replacing electrical parts, disconnect the negative battery cable.




9MUGIX-023

Connectors

Removal of connector

Never pull on the wiring harness when disconnecting connectors.


Connectors can be removed by pressing or pulling the lock lever as shown.



9MUGIX-024

Locking of connector


When locking connectors, make sure to listen for a click that will indicate they are securely locked.




9MUGIX-025

Inspection

1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wire harness side.



03UGIX-011




05UGIX-028

- Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wire harness side.

Caution


- Use fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.



9MUGIX-027

Terminals Inspection

Pull lightly on individual wires to check that they are secured in the terminal.



9MUGIX-028

Replacement of terminals



Use the appropriate tools to remove the terminal as shown. When installing the terminal, be sure to insert it until it locks securely.

< Female >

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.

< Male >


Same as the female type.




9MUGIX-030

Sensors, Switches, and Relays


Handle sensors, switches, and relays carefully. Do not drop them or strike them against other parts.



9MUGIX-031



9MUGIX-032



9MUGIX-029

Fuse Replacement

1. When replacing a fuse, be sure to replace it with one of specified capacity.
If a fuse again fails after it has been replaced, the circuit probably has a short circuit and the wiring should be checked.
2. Be sure the negative battery terminal is disconnected before replacing a main fuse (80A).
3. When replacing a pullout fuse, use the fuse puller supplied in the fuse box cover.

**Wiring Harness
Wiring color codes**

Two-color wires are indicated by a two-color code symbol. The first letter indicates the base color of the wire and the second the color of the stripe.

| CODE | COLOR | CODE | COLOR |
|------|-------------|------|--------|
| B | Black | O | Orange |
| BR | Brown | P | Pink |
| G | Green | R | Red |
| GY | Gray | V | Violet |
| L | Blue | W | White |
| LB | Light Blue | Y | Yellow |
| LG | Light Green | — | — |



PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE SERVICES

PRE-DELIVERY INSPECTION A- 2
PRE-DELIVERY INSPECTION TABLE **A- 2**
SCHEDULED MAINTENANCE SERVICES A- 3
SCHEDULE 1
(NORMAL DRIVING CONDITION)..... **A- 3**
SCHEDULE 2
(UNIQUE DRIVING CONDITION) **A- 6**

9MU0AX-001

PRE-DELIVERY INSPECTION

PRE-DELIVERY INSPECTION TABLE

EXTERIOR

INSPECT and **ADJUST**, if necessary, the following items to the specifications:

- Glass, exterior bright metal and paint for damage
- Wheel lug nuts
 - 88—118 N·m (9—12 m·kg, 65—87 ft·lb)
- Tire pressures (Refer to section Q)
- All weatherstrips for damage or detachment
- Operation of hood release and lock
- Operation of trunk lid, back door, and fuel lid opener
- Door operation and alignment
- Headlight aiming

INSTALL the following parts:

- Wheel caps or rings (if equipped)
- Outside rear view mirror(s)

UNDER HOOD—ENGINE OFF

INSPECT and **ADJUST**, if necessary, the following items to the specifications:

- Fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Engine oil level
- Power steering fluid level
- Brake and clutch master cylinder fluid level
- Windshield washer reservoir fluid level
- Radiator coolant level and specific gravity

| Protection °C (°F) | Specific gravity at 20°C (68°F) |
|--------------------|---------------------------------|
| -16 (3) | 1.054 |
| -26 (-15) | 1.066 |
| -40 (-40) | 1.078 |

- Tightness of water hose clamps (including heater hoses)
- Tightness of battery terminals
- Manual transaxle oil level
- Drive belt tensions
- Accelerator cable and its linkage for free movement

CLEAN spark plugs

INTERIOR

INSTALL the following parts:

- Rubber stopper for inside rear view mirror
- Fuse for accessories

CHECK the operations of the following items:

- Seat controls (sliding and reclining) and head restraint
- Folding rear seat
- Door locks including childproof door locks (if equipped)
- Seat belts and warning system
- Ignition switch and steering lock
- Inhibitor switch (ATX only)
- Starter interlock switch (clutch pedal, MTX only)
- All lights including warning and indicator lights
- Sound warning system
- Horn, wipers and washers (front and rear, if equipped)

- Audio system (if equipped)
- Cigarette lighter and clock
- Heater, defroster and air conditioner at various mode selection (if equipped)

CHECK the following items:

- Presence of spare fuse
- Upholstery and interior finish

CHECK and **ADJUST**, if necessary, the following items:

- Operation and fit of windows
- Pedal height and free play of brake and clutch pedal

| | Pedal height mm (in) | Free play mm (in) |
|--------------|--------------------------------------|--------------------|
| Clutch pedal | 196—204 (7.72—8.03) (with carpet) | 5—13 (0.197—0.512) |
| Brake pedal | 193—196 (7.60—7.72) | 4—7 (0.16—0.28) |

- Parking brake
 - 5—7 notches/98 N (10 kg, 22lb)

UNDER HOOD—ENGINE RUNNING AT OPERATING TEMPERATURE

CHECK the following items:

- Automatic transaxle fluid level
- Initial ignition timing (with TEN terminal of diagnosis connector grounded)
 - 5 ± 1° BTDC: BP SOHC
- Idle speed (ATX: P range, MTX: Neutral)
 - 750 ± 50 rpm: (With parking brake applied)

ON HOIST

CHECK the following items:

- Underside fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Tires for cuts or bruises
- Steering linkage, suspension, exhaust system and all underside hardware for looseness or damage

ROAD TEST

CHECK the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of meters and gauge
- Squeaks, rattles or unusual noise
- Engine general performance
- Emergency locking retractors
- Cruise control system (if equipped)

AFTER ROAD TEST

REMOVE seat and floor mat protective covers

CHECK for necessary owner information materials, tools and spare tire in vehicle

SCHEDULED MAINTENANCE SERVICES

Follow Schedule 1 (Normal Driving Condition) if the vehicle is mainly operated where none of the following conditions apply.
Follow Schedule 2 (Unique Driving Condition) if any of the conditions below apply:

- Repeated short-distance driving.
- Driving in dusty conditions.
- Driving with extended use of brakes.
- Driving in areas where using road salt or other corrosive materials are used.
- Driving on rough and/or muddy roads.
- Extended periods of idling and/or low-speed operation.
- Driving for prolonged periods in cold temperatures and/or extremely humid climates.

Schedule 1 (Normal Driving Conditions)

| MAINTENANCE OPERATION | MAINTENANCE INTERVALS | Number of months or miles (kilometers), whichever comes first | | | | | | | | Service data and inspection points | Page | | | | | | |
|----------------------------------|-----------------------|---|-----|----|-----------------|----|------|----|------|---|--------|-----|--------------|---------|----------------------|------------------------|-------|
| | | Months | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | | | 60 | | | | | |
| | | × 1,000 miles | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | | | 60 | | | | | |
| | | × 1,000 km | 12 | 24 | 36 | 48 | 60 | 72 | 84 | | | 96 | | | | | |
| Drive belts | | | | | I | | | | I | <ul style="list-style-type: none"> • Cracks or damage • Tension | B1-5* | | | | | | |
| Engine oil | | R | R | R | R | R | R | R | R | <ul style="list-style-type: none"> • Oil pan capacity: All BP 3.6 liters (3.8 US qt, 3.2 Imp qt) | D-5* | | | | | | |
| Oil filter | | R | R | R | R | R | R | R | R | <ul style="list-style-type: none"> • Oil filter capacity: 0.17 liter (0.18 US qt, 0.15 Imp qt) | D-5* | | | | | | |
| Engine timing belt* ¹ | | Replace every 60,000 miles (96,000 km) | | | | | | | | — | B1-12* | | | | | | |
| Air cleaner element | | | | | R | | | | R | — | F-71* | | | | | | |
| Spark plugs | | | | | R | | | | R | <ul style="list-style-type: none"> • Plug gap: 1.0—1.1mm (0.039—0.043 in) • Recommended spark plugs <table border="1"> <thead> <tr> <th>Engine</th> <th>NGK</th> <th>Nippon Denso</th> </tr> </thead> <tbody> <tr> <td>BP SOHC</td> <td>BKR5E-11 BKR6E-11</td> <td>K16PR-U11 K20PR-U11</td> </tr> </tbody> </table> | Engine | NGK | Nippon Denso | BP SOHC | BKR5E-11 BKR6E-11 | K16PR-U11 K20PR-U11 | G-18* |
| Engine | NGK | Nippon Denso | | | | | | | | | | | | | | | |
| BP SOHC | BKR5E-11 BKR6E-11 | K16PR-U11 K20PR-U11 | | | | | | | | | | | | | | | |
| Cooling system | | | | | I | | | | I | <ul style="list-style-type: none"> • Hoses for cracks or wear • Coolant level | E-5* | | | | | | |
| Engine coolant | | | | | R | | | | R | <ul style="list-style-type: none"> • Coolant capacity: 5.0 liters (5.3 US qt, 4.4 Imp qt)..... MTX 6.0 liters (6.3 US qt, 5.3 Imp qt) ATX | E-6* | | | | | | |
| Fuel filter | | | | | | | | | R | — | F-107* | | | | | | |
| Idle speed | | | | | A* ² | | | | A | <ul style="list-style-type: none"> • ATX: P range, MTX: Neutral 750 ± 50 rpm (With parking brake applied) | F-71* | | | | | | |
| Fuel lines | | | | | I* ³ | | | | I | <ul style="list-style-type: none"> • Fittings, connections, and components for leaks | F-9 | | | | | | |

* Indicates page to be referred to on 323 Workshop Manual (1195-10-89E)

A-4 Schedule 1 (Normal Driving Conditions) (Cont'd)

| MAINTENANCE OPERATION | MAINTENANCE INTERVALS | Number of months or miles (kilometers), whichever comes first | | | | | | | | Service data and inspection points | Page | |
|--------------------------------------|-----------------------|---|-------------------------------------|----|------|----|------|----|------|------------------------------------|---|--------------------------------------|
| | | Months | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | | | 60 |
| | | × 1,000 miles | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | | | 60 |
| | | × 1,000 km | 12 | 24 | 36 | 48 | 60 | 72 | 84 | | | 96 |
| Brake lines, hoses and connections | | | | | | I | | | | I | <ul style="list-style-type: none"> • Proper attachment and connections | — |
| Clutch pedal | | | | | | I | | | | I | <ul style="list-style-type: none"> • Operation • Pedal height (with carpet): 196—204mm (7.72—8.03 in) • Free play: 5—13mm (0.197—0.512 in) | H-5 |
| Disc brake | | | | | | I | | | | I | <ul style="list-style-type: none"> • Caliper operation • Disc plate thickness: Minimum.... Front 20mm (0.79 in) Rear 7.0mm (0.28 in) • Pad thickness: Minimum.... Front 2.0mm (0.08 in) Rear 1.0mm (0.04 in) | P-20* P-25* P-18* P-25* |
| Steering operation and linkage | | | | | | I | | | | I | <ul style="list-style-type: none"> • Operation and looseness • Fluid leakage or oozing • Free play.... 0—30mm (0—1.18 in) | N-18* N-8* |
| Front suspension ball joints | | | | | | I | | | | I | <ul style="list-style-type: none"> • Damage, looseness, and grease leakage | — |
| Driveshaft dust boots | | | | | | I | | | | I | <ul style="list-style-type: none"> • Cracking and damage | M-7 |
| Bolts and nuts on chassis and body | | | | | | T | | | | T | <ul style="list-style-type: none"> • Retighten all loose nuts and bolts | — |
| Exhaust system heat shield | | | | | | I | | | | I | <ul style="list-style-type: none"> • Insulation clearance | F-15 |
| Air conditioner system (if equipped) | | Refrigerant | Inspect refrigerant amount annually | | | | | | | | — | U-34* |
| | | Compressor | Inspect operation annually | | | | | | | | — | U-38* |
| Rear differential oil | | | | | | | | | | R | <ul style="list-style-type: none"> • Oil capacity: 0.5 liter (0.53 US qt, 0.44 Imp qt) | M-17 |
| Transfer oil | | | | | | | | | | R | <ul style="list-style-type: none"> • Oil capacity: 0.65 liter (0.69 US qt, 0.57 Imp qt) | J3-12 K2-136 |

* Indicates page to be referred to on 323 Workshop Manual (1195-10-89E)

Note

I Inspect, and if necessary correct, clean, or replace

A.... Adjust

R.... Replace or change

T.... Tighten

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.

As for * marked items in this maintenance chart, note the following points:

- *1 Replacement of the timing belt is required every 60,000 miles (96,000 km). Failure to replace the timing belt may result in damage to the engine.
- *2 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
- *3 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule 2 (Unique Driving Conditions)

| MAINTENANCE OPERATION | MAINTENANCE INTERVALS | Number of months or miles (kilometers), whichever comes first | | | | | | | | | | | | Service data and inspection points | Page | | | | | | |
|------------------------------------|-----------------------|---|---|-----------------|----|----|-----------------|----|----|-----------------|----|----|----|---|--------------------------------------|-----|--------------|---------|----------------------|------------------------|-------|
| | | Months | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | | | 60 | | | | | |
| | | × 1,000 miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | | | 60 | | | | | |
| | | × 1,000 km | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | | | 96 | | | | | |
| Drive belts | | | | | | | I | | | | | | I | <ul style="list-style-type: none"> Cracks or damage Tension | B1-5* | | | | | | |
| Engine oil | | R | R | R | R | R | R | R | R | R | R | R | R | <ul style="list-style-type: none"> Oil pan capacity: All BP 3.6 liters (3.8 US qt, 3.2 Imp qt) | D-5* | | | | | | |
| Oil filter | | R | R | R | R | R | R | R | R | R | R | R | R | <ul style="list-style-type: none"> Oil filter capacity: 0.17 liter (0.18 US qt, 0.15 Imp qt) | D-5* | | | | | | |
| Engine timing belt* ¹ | | Replace every 60,000 miles (96,000 km) | | | | | | | | | | | | — | B1-12* | | | | | | |
| Air cleaner element | | | | I* ² | | | R | | | I* ² | | | R | — | F-71* | | | | | | |
| Spark plugs | | | | | | | R | | | | | | R | <ul style="list-style-type: none"> Plug gap: 1.0—1.1mm (0.039—0.043 in) Recommended spark plugs <table border="1"> <tr> <td>Engine</td> <td>NGK</td> <td>Nippon Denso</td> </tr> <tr> <td>BP SOHC</td> <td>BKR5E-11 BKR6E-11</td> <td>K16PR-U11 K20PR-U11</td> </tr> </table> | Engine | NGK | Nippon Denso | BP SOHC | BKR5E-11 BKR6E-11 | K16PR-U11 K20PR-U11 | G-18* |
| Engine | NGK | Nippon Denso | | | | | | | | | | | | | | | | | | | |
| BP SOHC | BKR5E-11 BKR6E-11 | K16PR-U11 K20PR-U11 | | | | | | | | | | | | | | | | | | | |
| Cooling system | | | | | | | I | | | | | | I | <ul style="list-style-type: none"> Hoses for cracks or wear Coolant level | E-5* | | | | | | |
| Engine coolant | | | | | | | R | | | | | | R | <ul style="list-style-type: none"> Coolant capacity: 5.0 liters (5.3 US qt, 4.4 Imp qt)..... MTX 6.0 liters (6.3 US qt, 5.3 Imp qt) ATX | E-6* | | | | | | |
| Idle speed | | | | | | | A* ² | | | | | | A | <ul style="list-style-type: none"> ATX: P range, MTX: Neutral 750 ± 50 rpm (With parking brake applied) | F-71* | | | | | | |
| Fuel filter | | | | | | | | | | | | | R | — | F-107* | | | | | | |
| Fuel lines | | | | | | | I* ³ | | | | | | I | <ul style="list-style-type: none"> Fittings, connections, and components for leaks | F-9 | | | | | | |
| Brake lines, hoses and connections | | | | | | | I | | | | | | I | <ul style="list-style-type: none"> Proper attachment and connections | — | | | | | | |
| Clutch pedal | | | | | | | | | | | | | I | <ul style="list-style-type: none"> Operation Pedal height (with carpet): 196—204mm (7.72—8.03 in) Free play 5—13mm (0.197—0.512 in) | H-5 | | | | | | |
| Disc brake | | | | I | | | | I | | | | | I | <ul style="list-style-type: none"> Caliper operation Disc plate thickness: Minimum Front.... 20mm (0.79 in) Rear..... 7.0mm (0.28 in) Pad thickness: Minimum Front.... 2.0mm (0.08 in) Rear..... 1.0mm (0.04 in) | P-20* P-25* P-18* P-25* | | | | | | |

* Indicates page to be referred to on 323 Workshop Manual (1195-10-89E)

Schedule 2 (Unique Driving Conditions) (Cont'd)

| MAINTENANCE OPERATION | MAINTENANCE INTERVALS | Number of months or miles (kilometers), whichever comes first | | | | | | | | | | | | | Service data and inspection points | Page | | |
|--------------------------------------|-----------------------|---|-------------------------------------|----|----|----|----|----|----|----|----|----|----|----|------------------------------------|--|---|-----------------|
| | | Months | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | | | | |
| | | × 1,000 miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | | | | |
| | | × 1,000 km | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | 96 | | | | |
| Steering operation and linkage | | | | | | | | I | | | | | | | I | <ul style="list-style-type: none"> • Operation and looseness • Fluid leakage or oozing • Free play.... 0—30mm (0—1.18 in) | N-18* N-8* | |
| Front suspension ball joint | | | | | | | | I | | | | | | | I | <ul style="list-style-type: none"> • Damage looseness and grease leakage | — | |
| Driveshaft dust boots | | | | | | | | I | | | | | | | I | <ul style="list-style-type: none"> • Cracking and damage | M-7 | |
| Bolts and nuts on chassis and body | | | | | T | | | T | | | T | | | | T | <ul style="list-style-type: none"> • Retighten all loose nuts and bolts | — | |
| Exhaust system heat shield | | | | | | | | I | | | | | | | I | <ul style="list-style-type: none"> • Insulator clearance | F-15 | |
| Air conditioner system (if equipped) | | Refrigerant | Inspect refrigerant amount annually | | | | | | | | | | | | | — | U-34* | |
| | | Compressor | Inspect operation annually | | | | | | | | | | | | | — | U-38* | |
| Rear differential oil | | | | | | | | | | | | | | | | R | <ul style="list-style-type: none"> • Oil capacity 0.5 liter (0.53 US qt, 0.44 Imp qt) | M-17 |
| Transfer oil | | | | | | | | | R | | | | | | | R | <ul style="list-style-type: none"> • Oil capacity 0.65 liter (0.69 US qt, 0.57 Imp qt) | J3-12 K2-136 |

* Indicates page to be referred to on 323 Workshop Manual (1195-10-89E)

Note

I.... Inspect, and if necessary correct, clean, or replace

A.... Adjust

R.... Replace or change

T.... Tighten

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.

As for * marked items in this maintenance chart, note the following points:

*1 Replacement of the timing belt is required every 60,000 miles (96,000 km). Failure to replace the timing belt may result in damage to the engine.

*2 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.

*3 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

ENGINE (SOHC)

INDEX..... B- 2


FEATURES

OUTLINE..... B- 3
 OUTLINE OF CONSTRUCTION B- 3
 SPECIFICATIONS..... B- 3
 INTERCHANGEABILITY..... B- 4
 FLYWHEEL B- 5

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. B- 6
REMOVAL B- 6
 PROCEDURE B- 6
INSTALLATION..... B-14
 PROCEDURE B-14

INDEX



DEFLECTION AT (98 N, 10 kg, 22 lb) mm (in)

| DRIVE BELT | NEW | USED |
|----------------|---------------------|----------------------|
| ALTERNATOR | 8.0—9.0 (0.31—0.35) | 9.0—10.0 (0.35—0.39) |
| P/S, P/S + A/C | 8.0—9.0 (0.31—0.35) | 9.0—10.0 (0.35—0.39) |

COMPRESSION kPa (kg/cm², psi)-rpm

| | BP SOHC |
|----------|-----------------------|
| STANDARD | 1,197 (12.2, 173)-300 |
| MINIMUM | 834 (8.5, 121)-300 |

N-m (m-kg, ft-lb)

03U0BX-802

1. Engine

Removal page B- 6

Installation..... page B-14

OUTLINE

OUTLINE OF CONSTRUCTION

The BP SOHC engine for the 4WD model is the same as for the 2WD model, except that the flywheel is shaped differently.

03U0BX-803

SPECIFICATIONS

| Item | | Engine | BP SOHC |
|---------------------------------|---------|------------------------------------|---------------------------|
| Type | | | Gasoline, 4-cycle |
| Cylinder arrangement and number | | | In-line, 4 cylinders |
| Combustion chamber | | | Pentroof |
| Valve system | | | OHC, belt-driven |
| Displacement | | cc (cu in) | 1,839 (112.2) |
| Bore and stroke | | mm (in) | 83.0 x 85.0 (3.27 x 3.35) |
| Compression ratio | | | 8.9 |
| Compression pressure | | kPa (kg/cm ² , psi)-rpm | 1,197 (12.2, 173)-300 |
| Valve timing | IN | Open BTDC | 2° |
| | | Close ABDC | 50° |
| | EX | Open BBDC | 55° |
| | | Close ATDC | 8° |
| Valve clearance | mm (in) | IN | 0: Maintenance-free |
| | | EX | 0: Maintenance-free |
| Idle speed ^{*1*2} | rpm | MTX | 750 ± 50 |
| | | ATX | 750 ± 50 |
| Ignition timing ^{*2} | | BTDC | 5° ± 1° |
| Firing order | | | 1-3-4-2 |

03U0BX-804

*1...With parking brake applied. (Canada)

*2...TEN terminal of diagnosis connector grounded.

INTERCHANGEABILITY

The following chart shows interchangeability of the main parts of the BP SOHC engine for the 4WD model and the 2WD model.



Symbols: ○ Interchangeable

X Not interchangeable



| Part name | | Interchangeability | Remark | |
|----------------------------|----------------------------------|--------------------|-------------------------|--|
| Cylinder block related | Cylinder head | ○ | | |
| | Camshaft oil seal | ○ | | |
| | Cylinder head bolt | ○ | | |
| | Cylinder head gasket | ○ | | |
| | Cylinder head cover | ○ | | |
| | Cylinder head cover gasket | ○ | | |
| | Cylinder block | ○ | | |
| | Main bearing cap | ○ | | |
| | Main bearing support plate | ○ | | |
| | Oil pan | ○ | | |
| | Timing belt cover | ○ | | |
| | Front oil seal | ○ | | |
| | Rear oil seal | ○ | | |
| | Crankshaft related | Crankshaft | ○ | |
| Main bearing | | ○ | | |
| Thrust bearing | | ○ | | |
| Connecting rod and cap | | ○ | | |
| Connecting rod bearing | | ○ | | |
| Piston | | ○ | | |
| Piston pin | | ○ | | |
| Piston ring | | ○ | | |
| Crankshaft pulley | | ○ | | |
| Rear cover | | ○ | | |
| Flywheel | | X | Shape different | |
| Flywheel bolt | | ○ | | |
| Timing belt related | Timing belt | ○ | | |
| | Timing belt crank pulley | ○ | | |
| | Camshaft pulley | ○ | | |
| | Timing belt tensioner and spring | ○ | | |
| Valve related | Camshaft | ○ | | |
| | Rocker arm | ○ | | |
| | Rocker arm shaft | ○ | | |
| | HLA | ○ | | |
| | Valve | Intake | ○ | |
| | | Exhaust | ○ | |
| | Valve spring and seat | Intake | ○ | |
| | | Exhaust | ○ | |
| Valve guide | ○ | | | |
| Valve seal | ○ | | | |
| Lubrication system related | Oil pump | ○ | | |
| | Oil pump gasket | ○ | | |
| | Oil strainer | ○ | | |
| | Oil strainer gasket | ○ | | |
| | Oil jet | ○ | | |
| | Oil filter | ○ | | |
| Cooling system related | Water pump | ○ | | |
| | Thermostat | ○ | | |
| | Radiator | X | Specification different | |
| | Cooling fan | X | Specification different | |

FLYWHEEL

4WD MODEL



2WD MODEL



03U0BX-806

The flywheel is shaped differently to accommodate the redesigned clutch disc and clutch cover.

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with Workshop Manual (1195-10-89E).

Engine

- Removal
- Installation

03U0BX-807

REMOVAL


Warning

- Release the fuel pressure.

PROCEDURE

1. Disconnect the negative battery cable.
2. Drain the engine coolant and transaxle oil.
3. Remove in the order shown in the figure, referring to **Removal Note**.

Step 1



03U0BX-808

- | | |
|---|---------------------------------------|
| 1. Undercover | 12. Oil cooler hose (ATX) |
| 2. Side cover | 13. Radiator bracket |
| 3. Resonance chamber and air cleaner assembly | 14. Radiator and cooling fan assembly |
| 4. Battery bracket and battery | 15. P/S and/or A/C drive belt |
| 5. Battery carrier and battery duct | 16. P/S oil pump and bracket |
| 6. Accelerator cable | Removal Note..... page B-7 |
| 7. Radiator hose | 17. A/C compressor |
| 8. Coolant reservoir hose | Removal Note..... page B-7 |
| 9. Cooling fan connector | 18. Crossmember |
| 10. Radiator switch connector (ATX) | 19. A/C compressor bracket |
| 11. A/C cut switch connector (ATX) | 20. Coolant reservoir |


REMOVAL

Removal note P/S oil pump


Caution

- Do not damage the hoses.

1. Remove the P/S oil pump with the hoses still connected.
2. Position the pump away from the engine and affix it with wire.



05U0BX-074



05U0BX-075

A/C compressor


Caution

- Do not damage the hoses.

1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and affix it with wire.


Step 2

1. Disconnect the harness connectors shown in the figure.



Step 3

1. Disconnect the hoses shown in the figure.



03U0BX-810

- 1. Brake vacuum hose
- 2. Fuel hose

Removal Note..... page B-8

- 3. Vacuum hose (Purge control)
- 4. Vacuum hose (Cruise control)
- 5. Heater hose

Removal Note..... page B-8

Removal note Fuel hose

Warning

- Keep sparks and open flame away from the fuel area.

Caution

- Cover the hose with a rag because fuel will spray out when disconnecting.
- Plug the disconnected hoses to avoid fuel leakage.


1. Disconnect the fuel hoses.

Heater hose


Caution

- Do not lose the heater hose joint O-rings and spacer when removed.

1. Depress the heater hose retainer and remove the heater hose.




05U0BX-078



03U0BX-845


Step 4



03U0BX-811

- 1. Speedometer cable
- 2. Select and shift cable (MTX)
- 3. Shift control cable (ATX)
- 4. Front exhaust pipe
- 5. Stabilizer

- 6. Tie-rod end
Removal Note..... page B- 9
- 7. Driveshaft
Removal Note..... page B-10
- 8. Propeller shaft
Removal Note..... page L- 5



03U0BX-812


Removal note
Tie-rod end

- 1. Remove the cotter pin and loosen the nut until it is flush with the end of the ball joint stud.


Caution

- **Do not reuse the cotter pin.**


- 2. Separate the ball joint from the knuckle arm with the **SST**.




93E0B2-025



03U0BX-846



03U0BX-847



03U0BX-813

Driveshaft

1. Remove the joint shaft.

2. Remove the lower arm ball joint clinch bolt.

Caution

- Do not damage the ball joint dust boots.


3. Pry the lower arm downward to separate it from the knuckle.

Caution

- Do not damage the oil seal.

4. Separate the driveshaft from the transaxle.


Step 5



*ATX ONLY

03U0BX-814


- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Exhaust manifold insulator 2. Exhaust manifold and gasket 3. Water inlet pipe and gasket 4. Engine mount member Removal Note..... page B-11 5. No.2 engine mount rubber and bracket | <ul style="list-style-type: none"> 6. Clutch release cylinder (MTX) Removal Note..... page B-12 7. Dynamic damper 8. No.3 engine mount rubber 9. No.4 engine mount rubber and bracket 10. Engine and transaxle assembly Removal Note..... page B-12 |
|--|--|



03U0BX-815

**Removal note
Engine mount member**


- 1. Suspend the engine with a chain hoist.



2. Remove the No.1 and No.2 engine mount nuts.
3. Remove the engine mount member bolts and nuts and the engine mount member.

Caution

- Be careful that the engine does not fall when removing the member.




Clutch release cylinder (MTX)

1. Remove the release cylinder pipe bracket from the transaxle.
2. Position the release cylinder with the hose connected away from the transaxle for easier removal.

Caution

- Do not damage the pipe and hose.



Engine and transaxle assembly


Caution

- Do not damage any components in the engine compartment.

1. Lift the engine and transaxle assembly out as a unit.

Step 6

Separate the engine and transaxle in the order shown in the figure.



03U0BX-019

- 1. Intake manifold bracket
- 2. Center differential lock motor
- 3. Starter and bracket
- 4. Throttle cable (ATX)
- 5. Torque converter nuts (ATX)
- 6. Transaxle mounting bolts
- 7. Transaxle

Removal Note page J3-99

INSTALLATION


PROCEDURE

Tighten all bolts and nuts to the specified torques.

Step 1

1. Join the engine and transaxle.

Torque Specifications




Step 2


Warning

- Be sure the vehicle is securely supported on safety stands.

Torque Specifications



03U0BX-821




03U0BX-822

Engine and transaxle assembly


1. Suspend the engine and transaxle assembly.

Caution


- Do not damage any components in the engine compartment.




03U0BX-823




03U0BX-824



03U0BX-825



03U0BX-826



03U0BX-827

Engine mount, clutch release cylinder (MTX) and engine mount member

1. Install the No.3 engine mount rubber; then loosely tighten the bolt and nuts.

2. Install the No.4 engine mount rubber and bracket assembly; then loosely tighten the bolts and nuts.

3. Install the clutch release cylinder and pipe bracket assembly. (MTX)

Tightening torque:

- Ⓐ 16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)
- Ⓑ 6.9—9.8 N·m (70—100 cm·kg, 61—87 in·lb)

4. No.2 engine mount rubber and bracket assembly.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

5. Align the engine mount member to the No.1 and No.2 engine mount bolts; then loosely tighten the nuts.

6. Install the engine mount member bolt and nuts; then tighten them.


Tightening torque:

64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)


7. Tighten the No.1 and No.2 engine mount nuts.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



03U0BX-828



03U0BX-829

8. Tighten bolts (B) in two or three steps in the order shown.

Tightening torque:
43—61 N·m (4.4—6.2 m·kg, 32—43 ft·lb)

9. Tighten nuts (A).

Tightening torque:
67—93 N·m (6.8—9.5 m·kg, 49—69 ft·lb)

10. Tighten the No.3 engine mount nuts (A).

Tightening torque:
74—103 N·m (7.5—10.5 m·kg, 54—76 ft·lb)

11. Tighten nut (B).


Tightening torque:
67—93 N·m (6.8—9.5 m·kg, 49—69 ft·lb)

12. Install the dynamic damper.


Tightening torque:
55—80 N·m (5.6—8.2 m·kg, 41—59 ft·lb)

13. Remove a chain hoist.

Step 3 Torque Specifications



03U0BX-830



03U0BX-831

Propeller shaft

1. Install the propeller shaft. (Refer to page L-5.)

Driveshaft

1. Apply grease to the end of the driveshaft.


Caution

- When installing the driveshaft, be careful not to damage the oil seal.
- After installation, pull the front hub outward to confirm that the driveshaft is securely held by the clip.

2. Install the driveshaft and a new clip.
3. Install the lower arm ball joint to the knuckle and tighten the clinch bolt.

Tightening torque:

43—59 N·m (4.4—6.0 m·kg, 31—43 ft·lb)




03U0B2-832

4. Install the joint shaft.
5. Tighten the bolts in the order shown.

Tightening torque:

42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)



93E0B2-061


Tie-rod end

1. Install the tie-rod end to the knuckle.

Tightening torque:

42—57 N·m (4.3—5.8 m·kg, 31—42 ft·lb)

2. Install a new cotter pin.



03U0BX-848


Stabilizer

1. Install and adjust the stabilizer.


Dimension A: 17—19mm (0.67—0.75 in)

Tightening torque:

16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)



93E0B2-078



03U0BX-844

Exhaust pipe

1. Install the exhaust pipe and a new gasket; then loosely tighten the locknuts (A).
2. Loosely tighten the bracket nuts (B).
3. Tighten the locknuts (A).


Tightening torque:

31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)

4. Tighten the bracket nuts (B).

Tightening torque:


21—27 N·m (2.1—2.8 m·kg, 15—20 ft·lb)



03U0BX-833

Select and shift cable (MTX)

1. Install the select cable and the spring pin.
2. Install the shift cable and the spring pin.




03U0BX-834

Shift control cable (ATX)

1. Install the shift control cable and the spring pin.

Tightening torque:

6.9—11 N·m (70—110 cm·kg, 61—95 in·lb)



03U0BX-835

Speedometer cable


1. Connect the speedometer cable.

Step 4

1. Connect the hoses shown in the figure.

Caution


- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.



03U0BX-836


Step 5

1. Connect the harness connectors shown in the figure.




03U0BX-837

Step 6 Torque Specifications



03U0BX-838




03U0BX-839

Crossmember

1. Install the crossmember.

Tightening torque:

93—107 N-m (9.5—11.9 m-kg, 69—79 ft-lb)




03U0B1-193

A/C compressor

1. Install the A/C compressor.

Tightening torque:

24—35 N-m (2.4—3.6 m-kg, 17—26 ft-lb)



03U0BX-840

P/S oil pump and bracket


1. Install the P/S oil pump and bracket.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

Drive belt

1. Install the P/S and/or A/C drive belt.
2. Adjust the drive belt deflections.



03U0BX-841


Radiator and cooling fan assembly

1. Install the radiator and cooling fan assembly.

Tightening torque:

7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)


2. Connect the cooling fan connector.
3. Connect the radiator switch connector. (ATX)
4. Connect the A/C cut switch connector. (ATX)
5. Connect the oil cooler hose. (ATX)
6. Connect the coolant reservoir hose.
7. Connect the upper and lower radiator hoses.



03U0BX-842

Caution

- Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.




03U0BX-849

Accelerator cable

1. Install the accelerator cable.
2. Adjust the cable deflection by turning nuts A.

Deflection: 1—3mm (0.04—0.12 in)



03U0B1-198

Battery duct, battery carrier, and battery

1. Install the battery duct.
2. Install the battery carrier.


Tightening torque:

19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

3. Install the battery and the battery bracket.

Tightening torque:

2.9—5.9 N·m (30—60 cm·kg, 26—52 in·lb)



03U0B1-199

Air cleaner assembly

1. Install the air cleaner assembly.

Tightening torque:

- Ⓐ 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)
- Ⓑ 7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)

2. Connect the airflow sensor connector.

Resonance chamber

1. Install the resonance chamber.

Tightening torque:

- 7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)

Undercover and side cover

1. Install the undercover and side cover.

Steps after installation

1. If the engine oil was drained, fill with the specified amount and type of engine oil.
2. Fill the radiator with the specified amount and type of engine coolant.
3. Fill the transaxle with the specified amount and type of transaxle oil. (Refer to pages J3-12, K2-134.)
4. Connect the negative battery cable.
5. Start the engine and check the following:
 - (1) Engine oil, transaxle oil, and engine coolant leakage.
 - (2) Ignition timing, idle speed.
 - (3) Operation of emission control system.
6. Perform a road test.
7. Recheck the engine oil and engine coolant levels.

03U0BX-843



COOLING SYSTEM

OUTLINE..... E- 2
OUTLINE OF CONSTRUCTION..... E- 2
SPECIFICATIONS E- 2
RADIATOR AND COOLING FAN..... E- 3

03U0EX-801

OUTLINE

OUTLINE OF CONSTRUCTION

The cooling system in the 4WD model 323 is basically the same as in the 2WD model 323. The radiator and cooling fan specifications are different, however.

03U0EX-802

SPECIFICATIONS

| Item | | Engine | BP SOHC | | |
|------------------|----------------------------|--------------------------------|--|----------------|---|
| | | | MTX | ATX | |
| Cooling system | | | Water-cooled, forced circulation | | |
| Coolant capacity | | liters (US qt, Imp qt) | 5.0 (5.3, 4.4) | 6.0 (6.3, 5.3) | |
| Water pump | Type | | Centrifugal | | |
| | Water seal | | Unified mechanical seal | | |
| Thermostat | Type | | Wax, two-stage | | |
| | Opening temperature | °C (°F) | Main: 86.5—89.5 (188—193) Sub : 83.5—86.5 (182—188) | | |
| | Full-open temperature | °C (°F) | 100 (212) | | |
| | Full-open lift | mm (in) | Main: 8.0 (0.31) min. Sub : 1.5 (0.05) min. | | |
| Radiator | Type | | Corrugated fin | | |
| | Cap valve-opening pressure | kPa (kg/cm ² , psi) | 74—103 (0.75—1.05, 11—15) | | |
| Cooling fan | Type | | Electric | | |
| | Blade | Outer diameter | mm (in) | 320 (12.6) | 340 (13.4) |
| | | Number | | 4 | 5 |
| | Motor | Current | A | 6.6 ± 1 | Hi : 13.3 + 10% max. Low: 8.8 + 10% max. |

03U0EX-803


RADIATOR AND COOLING FAN

The radiator and cooling fan specifications are revised.

Specifications

| | | 4WD model | | 2WD model | |
|---------------------------|----------------------------------|--------------|---|------------|---|
| | | MTX | ATX | MTX | ATX |
| Radiator | | | | | |
| Core size | mm (in) | | | | |
| | Width | 648 (25.51) | 647 (25.47) | ← | ← |
| | Height | 400 (15.75) | 390 (15.35) | ← | ← |
| | Depth | 16 (0.63) | 25 (0.98) | 16 (0.63) | 25 (0.98) |
| Fin pitch | mm (in) | 1.25 (0.049) | 1.3 (0.051) | ← | ← |
| Heat dissipation capacity | kcal/h | 38,500 | 43,800 | 38,800 | 43,800 |
| Transaxle oil cooler | Type | — | Double tube | — | Laminated |
| | Heat dissipation capacity kcal/h | — | 1,650 | — | 1,700 |
| Cooling fan | | | | | |
| Number of blades | | 4 | 5 | 4 | ← |
| Outer diameter | mm (in) | 320 (12.6) | 340 (13.4) | 320 (12.6) | ← |
| Capacity | W-V | 80-12 | 160-12 | 80-12 | 160-12 |
| Current | A | 6.6 ± 1 | Hi : 13.3+10% max. Low: 8.8+10% max. | 6.6 ± 1 | Hi : 13.3+10% max. Low: 8.8+10% max. |

03U0EX-804



()

(

(

FUEL AND EMISSION CONTROL SYSTEMS

INDEX F- 2


FEATURES

OUTLINE F- 3
 OUTLINE OF CONSTRUCTION F- 3
 SPECIFICATIONS F- 3
 SYSTEM DIAGRAM F- 4
 WIRING DIAGRAM F- 5
FUEL SYSTEM F- 6
 OUTLINE F- 6
 FUEL TANK AND TRANSFER PUMP F- 7
A/C CUT-OFF SYSTEM F- 9

SERVICE

SUPPLEMENTAL SERVICE INFORMATION .. F- 9
FUEL SYSTEM F- 9
 PRECAUTION F- 9
 FUEL TANK F-10
TRANSFER PUMP CONTROL SYSTEM F-11
 SYSTEM OPERATION F-11
 4x4 CONTROL UNIT
 (FUEL PUMP CONTROL UNIT) F-12
 TRANSFER PUMP SWITCH F-13
 TRANSFER PUMP F-13
EXHAUST SYSTEM F-15
 COMPONENTS F-15

INDEX



03U0FX-802

- 1. Fuel tank
Removal / Inspection /
Installation page F-10
- 2. 4x4 control unit (Fuel pump control unit)
Inspection page F-12
Replacement..... page F-12
- 3. Transfer pump switch
Removal / Installation page F-13
Inspection page F-13

- 4. Transfer pump
Inspection page F-13
Replacement..... page F-13
- 5. Exhaust system components
Removal / Inspection /
Installation page F-15

OUTLINE

OUTLINE OF CONSTRUCTION

The fuel and emission control system of the 1990 323 4WD is basically the same as that of the 1990 323 2WD, however, the fuel tank is designed with separate right and left sections due to the installation of the propeller shaft for the 4-wheel-drive system and the transfer pump is equipped to pump the fuel from the left to the right (fuel pump side) section of the fuel tank.

A water thermostat is equipped for A/C cut-off system.

03U0FX-803

SPECIFICATIONS


| Item | | Engine | BP SOHC | |
|---------------------------------------|---|-------------------------------------|------------------------------|---------------|
| Idle speed* ¹ | | rpm | 750 ± 50 | |
| Ignition timing* ² | | BTDC | 5 ± 1° | |
| Fuel pump | | | | |
| Maximum output pressure | | kPa (kg/cm ² , psi) | 441—589 (4.5—6.0, 64—85) | |
| Transfer pump | | | | |
| Maximum output pressure | | kPa (kg/cm ² , psi) | More than 39 (0.4, 5.7) | |
| Fuel filter | | | | |
| Type | Low-pressure side | | Nylon element | |
| | High-pressure side | | Paper element | |
| Pressure regulator | | | | |
| Regulating pressure | | kPa (kg/cm ² , psi) | 264—314 (2.7—3.2, 38.3—45.5) | |
| Injector | | | | |
| Type | | High-ohmic | | |
| Type of drive | | Electric | | |
| Resistance | | Ω | 12—16 | |
| Idle speed control (ISC) valve | | | | |
| Type | | Rotary | | |
| Resistance | | Ω | 11—13 | |
| Solenoid valve (Purge control) | | | | |
| Resistance | | Ω | 23—27 | |
| Water thermostat | | | | |
| Resistance | kΩ | -20°C (-4°F) | 14.6—17.8 | |
| | | 20°C (68°F) | 2.21—2.69 | |
| | | 40°C (104°F) | 1.0—1.3 | |
| | | 80°C (176°F) | 0.29—0.35 | |
| Airflow meter | | | | |
| Resistance | Ω | E2 ↔ Vs | Fully closed | 200—600 |
| | | | Fully open | 20—1,200 |
| | E2 ↔ THAA (Intake air thermosensor) | Ω | -20°C (-4°F) | 13,600—18,400 |
| | | | 20°C (68°F) | 2,210—2,690 |
| | | | 60°C (140°F) | 493—667 |
| | E1 ↔ Fc | Ω | Fully closed | ∞ |
| Fully open | | | 0 | |
| Fuel tank | | | | |
| Capacity | | liters (US gal, Imp gal) | 60 (15.8, 13.2) | |
| Air cleaner | | | | |
| Element type | | Oil permeated | | |
| Fuel | | | | |
| Specification | | Unleaded regular (RON 91 or higher) | | |


03U0FX-804

*¹ With parking brake applied (Canada).

*² TEN terminal of diagnosis connector grounded.

The  mark indicates newly equipped parts.






*1: CANADA (DRL: DAYTIME RUNNING LIGHT)

FUEL SYSTEM


OUTLINE



03U0FX-807

The fuel system consists of the fuel tank, the transfer pump, the fuel pump, the fuel filters, the pressure regulator, the delivery pipe, the injectors, and the 4x4 control unit (fuel pump control unit).

FUEL TANK AND TRANSFER PUMP




03U0FX-808

The fuel tank is designed with a separate right and left section due to the installation of the propeller shaft for the 4-wheel-drive system.


A transfer pump is used to pump the fuel from the left to the right (fuel pump) side. The transfer pump is installed in the fuel tank, and is controlled by the transfer pump switch and the fuel pump control unit (included in the 4x4 control unit).

Transfer Pump Control


FUEL IN LEFT TANK



NO FUEL IN LEFT TANK



DELAY TIMER FUNCTION



03U0FX-809

Fuel in left tank

The transfer pump switch is OFF, and the transistor within the fuel pump control unit is ON. As a result, current flows to the coil, the switch is switched ON, and the transfer pump is activated.

No fuel in left tank

The transfer pump switch is ON, and the transistor within the fuel pump control unit is OFF. As a result, the current to the coil is interrupted, the switch is switched OFF, and the transfer pump is stopped. When in this condition, if the vehicle were driven on a rough road surface, the fuel level would vary up and down and fuel pump would switch ON and OFF. The transfer pump would then operate excessively, shortening the pump life. In order to prevent this, a ten-second delay circuit is provided within the fuel pump control unit.

A/C CUT-OFF SYSTEM (For ATX)

To improve the reliability of the engine at high temperature condition, the water thermostatic switch on the radiator is switched OFF **above approx. 111°C (232°F)** and stops the A/C operation.

03U0FX-829

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with 1990 Mazda 323 Workshop Manual (1195-10-89E).

Fuel tank

- Removal / Inspection / Installation

4x4 control unit (Fuel pump control unit)

- Inspection procedure added
- Replacement procedure added

Transfer pump switch

- Inspection procedure added
- Replacement procedure added


Transfer pump

- Inspection procedure added
- Replacement procedure added


Exhaust system components

- Removal / Inspection / Installation


03U0FX-810



03U0FX-811



9MU0F2-122



03U0FX-127

FUEL SYSTEM

PRECAUTION

Fuel Pressure Release and Servicing Fuel System

Fuel in the fuel system remains under high pressure when the engine is not running.

- Before disconnecting any fuel line, release the fuel pressure from the fuel system to reduce the possibility of injury or fire.
 - Start the engine.
 - Push the rear seat cushion buttons and remove the cushion.
 - Disconnect the fuel pump connector.
 - After the engine stalls, turn off the ignition switch.
 - Reconnect the fuel pump connector and install the rear seat cushion.
- Use a rag as protection from fuel spray when disconnecting the hoses.
Plug the hoses after removal.
- When inspecting the fuel system, use a suitable fuel pressure gauge.

Caution

- Install hose clamps to secure the fuel pressure gauge to the fuel filter and the fuel main hose to prevent fuel leakage.

Priming Fuel System

After releasing the fuel pressure for repairs or inspection, the system must be primed to avoid excessive cranking when first starting the engine. Follow the steps below.

- Connect the diagnosis connector terminals **F/P** and **GND** with a jumper wire.
- Turn the ignition switch ON for **approx. 10 sec.** and check for fuel leaks.
- Turn the ignition switch OFF and remove the jumper wire.



FUEL TANK

Removal / Inspection / Installation

Warning

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F-9.)
- When removing the fuel tank, keep sparks, cigarettes, and open flames away from it.
- Before repairing the fuel tank, clean it thoroughly with steam to remove all explosive gas.

1. Remove in the order shown in the figure.
2. Inspect the fuel tank components visually and repair or replace if necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)

Note

- Drain the fuel from the fuel tank before removing the tank.

- | | |
|--|--|
| 1. Fuel pump cover | 6. Fuel filler hose, breather hose, and evaporation hoses Installation Note page F-11 |
| 2. Fuel pump connector | |
| 3. Fuel hoses Installation Note page F-11 | 7. Fuel tank straps |
| 4. Exhaust pipe Removal / Installation page F-15 | 8. Fuel tank Inspect for cracks and corrosion |
| 5. Propeller shaft Removal / Installation Section L | |

03U0FX-813



03U0FX-135

Installation Note

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings **at least 25mm (1.0 in)**.
2. Push the fuel filler hose onto the fuel tank pipe and filler pipe **at least 35mm (1.4 in)**.


TRANSFER PUMP CONTROL SYSTEM

SYSTEM OPERATION


1. Turn the ignition switch ON and verify that the fuel gauge indicates more than half and that the transfer pump operating sound is heard.

Warning

- If the fuel level is less than one half, this inspection cannot be performed.




03U0FX-814




03U0FX-815


2. Ground the transfer pump connector terminal-wire (Y/L) with a jumper wire and verify that the transfer pump stops.
3. Remove the jumper wire and verify that the transfer pump begins operation after **approx. 10 sec**.
4. If not as specified, check the following parts.
 - 4x4 control unit (Fuel pump control unit). (Refer to page F-12.)
 - Transfer pump. (Refer to page F-13.)
 - Transfer pump switch. (Refer to page F-13.)




03U0FX-816




03U0FX-817



03U0FX-818



03U0FX-819



03U0FX-820

4x4 CONTROL UNIT (FUEL PUMP CONTROL UNIT)

Inspection

1. Remove the 4x4 control unit.
2. Disconnect the 4x4 control unit connector.
3. Check continuity between the 4x4 control unit connector terminal M and a ground.
4. Perform the following inspection according to the continuity.

Continuity exists


1. Turn the ignition switch ON.
2. Ground the 4x4 control unit terminal M with a jumper wire and verify that the voltage at the 4x4 control unit terminal N is **0V**.
3. Remove the jumper wire and verify that the voltage at the 4x4 control unit terminal N is **approx. 12V** after **approx. 10 sec.**

No continuity exists

1. Turn the ignition switch ON and verify that the voltage at the 4x4 control unit terminal N is **0V**.
2. Disconnect the transfer pump connector.
3. Turn the ignition switch ON and verify that the voltage at the 4x4 control unit terminal N is **approx. 12V**.

Replacement

1. Remove two bolts and remove the 4x4 control unit and the bracket as an assembly.
2. Remove the 4x4 control unit from the bracket.
3. Install in the reverse order of removal.




03U0FX-821

TRANSFER PUMP SWITCH

Removal / Installation

1. Refer to replacement of the transfer pump. (Refer to page F-13.)




03U0FX-822

Inspection

1. Check continuity between transfer pump connector terminal C and ground terminal.

| Float position | Continuity |
|----------------|------------|
| Up | No |
| Down | Yes |

2. If not as specified, replace the transfer pump switch.




03U0FX-823

TRANSFER PUMP


Inspection

1. Remove the rear seat cushion.



03U0FX-824

2. Disconnect the transfer pump connector.
3. Check for continuity between transfer pump connector terminal-wires (B/W) and (Y).
4. If no continuity exists, replace the transfer pump.




03U0FX-825

Replacement

Warning

- When servicing the fuel system, keep sparks, cigarettes, and open flames away from the fuel.

1. Remove the rear seat cushion.



03U0FX-826

2. Remove the service hole cover of the transfer pump.
3. Disconnect the transfer pump connectors.
4. Disconnect the fuel hose.
5. Remove the transfer pump.

Caution

- Install a new seal rubber.


6. Install in the reverse order of removal.

Disassembly / Assembly

Caution

- Prevent contaminants from entering into the transfer pump.

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.
3. Verify that the transfer pump operates correctly after assembling it.



03U0FX-827

1. Fuel filter
2. Rubber mount
3. Transfer pump


4. Fuel hose
5. Transfer pump switch

EXHAUST SYSTEM

COMPONENTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Check the exhaust system components and repair or replace as necessary.
3. Install in the reverse order of removal.



03U0FX-828

1. Main silencer
Inspect for deterioration and restriction
2. Middle pipe assembly
Inspect for deterioration and restriction
3. Pre-silencer
Inspect for deterioration and restriction

4. Catalytic converter
Inspect for deterioration and restriction
5. Front pipe assembly
Inspect for deterioration and restriction
6. Exhaust manifold insulator
7. Exhaust manifold
Inspect for deterioration and restriction

ENGINE ELECTRICAL SYSTEM

INDEX..... G- 2

FEATURES


OUTLINE..... G- 3
OUTLINE OF CONSTRUCTION G- 3
SPECIFICATIONS..... G- 3

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. G- 4
STARTING SYSTEM..... G- 4
STARTER..... G- 4

03U0GX-801

INDEX



03U0GX-802

1. Starter
Removal / Installation..... page G-4

OUTLINE

OUTLINE OF CONSTRUCTION

The engine electrical system of the 1990 323 4WD is as same as that of the 1990 323 2WD.

03U0PX-803

SPECIFICATIONS

| Item | | Engine | | BP SOHC | | |
|--|---|------------------------|--|--|------------------------|-------------|
| | | | | MTX | ATX | |
| Battery | Voltage | V | | 12 | | |
| | Type and capacity (20-hour rate) | | | 55D23L (60AH) | | |
| Dark current* ¹ | | mA | | Max. 20.0 | | |
| Alternator | Type | | | A.C. | | |
| | Output | V-A | | 12-65 | | |
| | Regulator type | | | Transistorized (built-in IC regulator) | | |
| | Regulated voltage | V | | 14.1—14.7 | | |
| | Brush length mm (in) | Standard | | | 21.5 (0.846) | |
| | | Minimum | | | 8.0 (0.315) | |
| | Drive belt deflection 98 N (10 kg, 22 lb) mm (in) | New | | | 8—9 (0.31—0.35) | |
| Used | | | | 9—10 (0.35—0.39) | | |
| Starter | Type | | | Direct | Coaxial reduction | |
| | Output | V-kW | | 12-0.85 | 12-1.4 | |
| | Brush length mm (in) | Standard | | | 17 (0.67) | 17.5 (0.69) |
| | | Minimum | | | 11.5 (0.453) | 10.0 (0.39) |
| Distributor | | | | Electronic spark advance (photo diode) | | |
| Ignition timing (TEN terminal of diagnosis connector grounded) | | BTDC | | 5 ± 1° | | |
| Ignition coil | Resistance (at 20°C [68°F]) | Primary coil winding | | | 0.81—0.99Ω | |
| | | Secondary coil winding | | | 10—16 kΩ | |
| Spark plug | Type | NGK | | | BKR5E11 BKR6E11 | |
| | | Nippon Denso | | | K16PR-U11 K20PR-U11 | |
| | Plug gap | mm (in) | | 1.0—1.1 (0.039—0.043) | | |
| | Firing order | | | 1—3—4—2 | | |

03U0GX-804

*¹ Dark current is the constant flow of current while the ignition switch is OFF. (i.e., engine control unit, EC-AT control unit, audio, etc.)

SUPPLEMENTAL SERVICE INFORMATION

The following point in this section is changed in comparison with 1990 Mazda 323 Workshop Manual (1195-10-89E).


Starter

- Removal / Installation

03U0GX-805

STARTING SYSTEM**STARTER****Removal / Installation**

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.



03U0GX-806

1. Battery
2. Intake manifold bracket
3. S terminal wire
4. B terminal wire

5. Starter
Remove from upper side of vehicle
6. Starter bracket (MTX)

CLUTCH

| | |
|--|-------------|
| OUTLINE | H- 2 |
| OUTLINE OF CONSTRUCTION | H- 2 |
| SPECIFICATIONS | H- 2 |
| INTERCHANGEABILITY OF MAJOR COMPONENTS..... | H- 2 |
| RELEASE BEARING | H- 3 |

03U0HX-801



OUTLINE

OUTLINE OF CONSTRUCTION

A hydraulic clutch control mechanism is used.

The basic construction is the same as that of 323 2WD model, but there is no interchangeability of component parts except for the clutch pedal, the master cylinder and the release cylinder.

- To improve clutch operation feeling and increased parts life, a newly designed friction plate with needle roller bearings is used between the release fork and the release bearing.

03U0HX-802

SPECIFICATIONS

| Engine/Transaxle Model | | BP SOHC | |
|---|------------------------------|-----------------------------|-------------|
| Item | | G5MX-R | |
| Clutch control | | Hydraulic | |
| Clutch cover | Type | Diaphragm spring | |
| | Set load N (kg, lb) | 3,846 (392, 862) | |
| Clutch disc | Outer diameter mm (in) | 225 (8.86) | |
| | Inner diameter mm (in) | 150 (5.91) | |
| | Thickness | Pressure plate side mm (in) | 4.1 (0.161) |
| | | Flywheel side mm (in) | 3.5 (0.138) |
| Clutch pedal | Type | Suspended | |
| | Pedal ratio | 6.55 | |
| | Full stroke mm (in) | 135 (5.32) | |
| | Height (With carpet) mm (in) | 196—204 (7.72—8.03) | |
| Master cylinder inner diameter mm (in) | | 15.87 (0.625) | |
| Release cylinder inner diameter mm (in) | | 19.05 (0.750) | |
| Clutch fluid | | SAE J1703 or FMVSS116 DOT-3 | |

03U0HX-803

INTERCHANGEABILITY OF MAJOR COMPONENTS


The following chart shows the major components interchangeability between the 2WD model and the 4WD model.

○.....Interchangeability X.....Not interchangeability

| Part name | Interchangeability | Remark |
|------------------|--------------------|----------------|
| Clutch cover | X | Shape, type |
| Clutch disc | X | Shape diameter |
| Clutch pedal | ○ | |
| Master cylinder | ○ | |
| Release cylinder | ○ | |
| Release bearing | X | Shape |

03U0HX-804

RELEASE BEARING



9MU0HX-505

To improve clutch operation feeling and increased parts life, a newly designed friction plate with needle roller bearings is used between the release fork and the release bearing. With the inclusion of this friction plate, the force required to depress the clutch pedal is reduced because the usual sliding-contact action between the release bearing and the release fork is changed to a rolling action of the friction plate.



MANUAL TRANSAXLE AND TRANSFER UNIT (G5MX-R)

INDEX J3- 2

FEATURES


OUTLINE J3- 3
 OUTLINE OF CONSTRUCTION J3- 3
 SPECIFICATIONS J3- 4
 TRANSAXLE AND TRANSFER UNIT J3- 5
 STRUCTURAL VIEW J3- 8
 POWERFLOW J3- 9

SERVICE

TROUBLESHOOTING GUIDE J3- 10
**TRANSAXLE AND
TRANSFER UNIT OIL** J3- 11
 INSPECTION J3- 11
 REPLACEMENT J3- 11
TRANSFER CARRIER OIL J3- 11
 INSPECTION J3- 11
 REPLACEMENT J3- 11

**TRANSAXLE AND
TRANSFER UNIT** J3- 13
 PREPARATION J3- 13
 REMOVAL J3- 16
 DISASSEMBLY J3- 20
 INSPECTION J3- 45
 ASSEMBLY J3- 48
 INSTALLATION J3- 86
SHIFT MECHANISM J3- 91
 OVERHAUL J3- 91
**CENTER DIFFERENTIAL
LOCK SYSTEM** J3- 93
 SYSTEM DIAGRAM J3- 93
 INSPECTION J3- 94
**CENTER DIFFERENTIAL
LOCK MOTOR** J3- 95
 INSPECTION J3- 95
 REPLACEMENT J3- 95
4x4 CONTROL UNIT J3- 97
 INSPECTION J3- 97
 REPLACEMENT J3- 97
**CENTER DIFFERENTIAL
LOCK SWITCH** J3- 98
 INSPECTION J3- 98
 REPLACEMENT J3- 98
**CENTER DIFFERENTIAL
LOCK SENSOR SWITCH** J3- 98
 INSPECTION J3- 98
 REPLACEMENT J3- 98

INDEX




03U0J3-002

- | | | | |
|--------------------------------|------------|---|------------|
| 1. Transaxle oil | | 5. Center differential lock motor | |
| Inspection..... | page J3-11 | Inspection..... | page J3-95 |
| Replacement..... | page J3-11 | Replacement..... | page J3-95 |
| 2. Transfer carrier oil | | 6. 4x4 Control unit | |
| Inspection..... | page J3-11 | Inspection..... | page J3-97 |
| Replacement..... | page J3-11 | Replacement..... | page J3-97 |
| 3. Transaxle and transfer unit | | 7. Center differential lock switch | |
| Removal..... | page J3-16 | Inspection..... | page J3-98 |
| Disassembly..... | page J3-20 | Replacement..... | page J3-98 |
| Inspection..... | page J3-45 | 8. Center differential lock sensor switch | |
| Assembly..... | page J3-48 | Inspection..... | page J3-98 |
| Installation..... | page J3-86 | Replacement..... | page J3-98 |
| 4. Shift mechanism | | | |
| Overhaul..... | page J3-91 | | |

OUTLINE

OUTLINE OF CONSTRUCTION

- Full-Time 4-Wheel-Drive, incorporating an electronically controlled, lockable center differential, is standard on the 1990 323 4WD. With this system all driving conditions are easily contended with; from good road to bad roads and inclement weather.
- The transaxle and transfer unit were developed based on the transaxle of the 1989 323 4WD. The transaxle, center differential, and front differential are a single compact unit.
- The center differential employs a planetary carrier system, and functions to distribute the driving force to the front and rear differentials.
- Through the use of this center differential, tire scuffing common to 4-wheel-drive vehicles during tight cornering, is eliminated.
- The speedometer driven gear (for detection of vehicle speed) is installed in the transfer carrier and detects the speed of the rear wheels.
- Lubrication oil of the transaxle and transfer unit and the carrier is contained separately.
- A cable shift control is used in order to reduce weight and vibration.



SPECIFICATIONS TRANSAXLE AND TRANSFER UNIT

| Item | Engine model | | 1990 323 (4WD) | 1989 323 (4WD) |
|----------------------------|-----------------------------|------------------|---|---|
| | | | BP SOHC | B6 DOHC |
| Transaxle control | | Floor shift | | |
| Synchronesh system | Forward | | Synchronesh | |
| | Reverse | | Selective sliding and synchronesh | Selective sliding |
| Gear ratio | 1st | | 3.307 | ← |
| | 2nd | | 1.833 | ← |
| | 3rd | | 1.233 | ← |
| | 4th | | 0.914 | 0.970 |
| | 5th | | 0.717 | 0.795 |
| | Reverse | | 3.166 | ← |
| Final gear ratio | | 4.388 | | 4.105 |
| Speedometer gear ratio | | 1.045 | | ← |
| Center differential | Type | | Planetary carrier | |
| | Number of ring gear teeth | Outer | 79 | 78 |
| | | Inner | 66 | ← |
| | Number of pinion gear teeth | Outer | 14 | ← |
| | | Inner | 14 | ← |
| | Number of sun gear teeth | Pinion gear side | 33 | ← |
| | | Idler gear side | 43 | 50 |
| Number of idler gear teeth | | 37 | 43 | |
| Oil | Type | | ATF: DEXRON-II, M-III Above -18°C (0°F) API servie GL-4 SAE 75W-90 | ATF: DEXRON-II API servie GL-4 SAE 80W-90 or 90 |
| | Capacity | | 2.6 liters (2.7 US qt, 2.2 Imp qt) | 3.6 liters (3.8 US qt, 3.2 Imp qt) |


03U0J3-004

Transfer Carrier

| | | |
|-----------------|-------------|--|
| Number of teeth | Ring gear | 37 |
| | Pinion gear | 11 |
| Oil | Type | API service GL-5 Above -18° (0°F) SAE 90 Below -18° (0°F): SAE 80W |
| | Capacity | 0.5 liter (0.53 US qt, 0.44 Imp qt) |

03U0J3-005


TRANSAXLE AND TRANSFER UNIT
Shift forks and shift rods



03U0J3-006

The shift mechanism is composed of three shift rods, shift forks, and shift rod ends. For the manual transaxle of the 1989 323 4WD, the 1-2 and 3-4 shift forks were moved by one shift rod, but, for the 1990 323 4WD, separate shift rods are used, thus reducing mechanical friction during shifting, and improving the shift feeling.


Interlock mechanism



03U0J3-007

The interlock mechanism is the pin type. For the manual transaxle of the 1989 323 4WD, the one shift rod was held by the other shift rod's interlock sleeve, but, for the manual transaxle of the 1990 323 4WD, when one shift rod is caused to move, the interlock pins are pushed out to hold the other shift rods.

Idler gear shaft




TAPERED ROLLER BEARING

03U0J3-008

For improved transaxle reliability, a tapered roller bearing is newly fitted at the ring gear end of the idler gear shaft for better support; in addition, the previously fitted bearing is changed from a ball bearing to a tapered roller bearing.

STRUCTURAL VIEW









03U0J3-010

- 1. Primary 1st gear
- 2. Primary 2nd gear
- 3. Primary 3rd gear
- 4. Primary 4th gear
- 5. Primary 5th gear
- 6. Primary reverse gear

- 7. Secondary 1st gear
- 8. Secondary 2nd gear
- 9. Secondary 3rd gear
- 10. Secondary 4th gear
- 11. Secondary 5th gear
- 12. Secondary reverse gear

- 13. Reverse idler gear
- 14. Front and center differential assembly
- 15. Idler gear assembly
- 16. Transfer carrier assembly


POWERFLOW




TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|---|---|--|---|
| Shift lever won't shift smoothly or is hard to shift | Worn change control cable | Replace | J3-91 |
| Difficult to shift | Worn change rod No grease in transaxle control Insufficient oil Deterioration of oil quality Wear or play of shift fork or shift rod Worn synchronizer ring Worn synchronizer cone of gear Bad contact of synchronizer ring and cone of gear Excessive longitudinal play of gears Worn bearing Worn synchronizer key spring Excessive primary shaft gear bearing preload Improperly adjusted change guide plate | Replace Lubricate Add oil Replace with oil of specified quality Replace Replace Replace Replace Replace Replace Adjust Adjust | J3-91 J3-91 J3-11 J3-11 J3-20 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-73 J3-31 |
| Won't stay in gear | Worn change control cable Weak shift lever ball spring Worn shift fork Worn clutch hub Worn clutch hub sleeve Worn gear sliding part of both shaft gears Worn gear sliding part of each gear Worn steel sliding groove of control end Weak spring pressing against steel ball Excessive thrust clearance Worn bearing Improperly installed or loose engine mount | Replace Replace Replace Replace Replace Replace Replace Replace Replace Replace Replace Tighten | J3-91 J3-91 J3-20 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-20 J3-20 J3-33, 35 J3-33, 35 J3-86 |
| Abnormal noise | Insufficient oil Deterioration of oil quality Worn bearing Worn sliding surfaces of gears or shafts Excessive gear backlash Damaged gear teeth Foreign material in gears Damaged differential gear or excessive backlash | Add oil Replace Adjust or replace Replace Replace Replace with oil of specified quality Replace Adjust or replace | J3-11 J3-11 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-33, 35 J3-58 |


03U0J3-011




03U0J3-012




03U0J3-013



03U0J3-014



03U0J3-015



03U0J3-016

TRANSAXLE OIL

INSPECTION

Note

- Park the vehicle on level ground.

1. Remove the check plug.
2. Verify that the oil is at the bottom of the plug port. If it is low, add the specified oil from plug port.
3. Install the check plug.

Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

REPLACEMENT

1. Remove the drain plug and washer. Drain the oil into a suitable container.
2. Install a new washer and the drain plug.

Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

3. Add the necessary amount of the specified oil through the check plug port.

Specified oil

All-season : ATF (DEXRON-II, M-III)

Above -18°C (0°F): SAE 75W-90

Grade : API service GL4

Capacity: 2.6 liters (2.7 US qt, 2.2 Imp qt)

4. Verify the oil level.
5. Install the check port plug.

Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

TRANSFER CARRIER OIL

INSPECTION

Note

- Park the vehicle on level ground.

1. Remove the check plug.
2. Verify that the oil is at the bottom of the plug port. If it is low, add the specified oil from plug port.
3. Install check plug.

Tightening torque:


39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

REPLACEMENT

1. Remove the drain plug. Drain the oil into a suitable container.
2. Install a new washer and the drain plug.

Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)



03U0J3-017

3. Add the necessary amount of the specified oil through the check plug port.

Grade : API servies GI-5

Specified oil: Above -18°C (0°F) SAE 90

Below -18°C (0°F) SAE 80W

Capacity : 0.5 liter (0.53 US qt, 0.44 Imp qt)

















4. Install the check plug.

















Tightening torque:















39—58 N·m (4.0—6.0 m·kg, 28—43 in·lb)

TRANSAXLE AND TRANSFER UNIT

PREPARATION
SST

| | | | |
|---|--|---|---|
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 0118 850C Puller, ball joint</p>  | <p>For removal of tie-rod end</p> |
| <p>49 0107 680A Stand, engine</p>  | <p>For disassembly and assembly of transaxle</p> | <p>49 G019 0A0 Transaxle, hanger</p>  | <p>For disassembly and assembly of transaxle</p> |
| <p>49 G030 440 Holder, primary shaft</p>  | <p>For holding primary shaft</p> | <p>49 G030 795 Installer, oil seal</p>  | <p>For installation of oil seal</p> |
| <p>49 0636 145 Puller, fan pulley boss</p>  | <p>For removal of bearing inner race</p> | <p>49 G030 370 Plate, removing</p>  | <p>For removal of secondary 3rd gear and 2nd gear</p> |
| <p>49 G017 1A0 Remover set, bearing</p>  | <p>For removal of bearing</p> | <p>49 F401 366A Plate (Part of 49 G017 1A0)</p>  | <p>For removal of bearing inner race</p> |
| <p>49 B092 373 Attachment G (Part of 49 G017 1A0)</p>  | <p>For removal of bearing inner race</p> | <p>49 B092 374 Attachment H (Part of 49 G017 1A0)</p>  | <p>For removal of bearing inner race</p> |
| <p>49 0839 425C Puller set, bearing</p>  | <p>For removal of bearing inner race</p> | <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of bearing</p> |
| <p>49 F401 331 Body (Part of 49 F401 330B)</p>  | <p>For installation of bearing inner race</p> | <p>49 F401 335A Attachment A (Part of 49 F401 330B)</p>  | <p>For installation of bearing inner race</p> |


| | | | | |
|---|---|---|--|--|
| <p>49 F401 337A Attachment B (Part of 49 F401 330B)</p> |  | <p>For installation of bearing inner race</p> | <p>49 G030 380C Selector set, shim</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G030 381 Selector for $\phi 68$ (Part of 49 G030 380C)</p> |  | <p>For adjustment of bearing preload</p> | <p>49 G030 382A Selector $\phi 58$ (Part of 49 G030 380C)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 F401 382A Selector $\phi 52$ (Part of 49 G030 380C)</p> |  | <p>For adjustment of bearing preload</p> | <p>49 F401 384 Collar (Part of 49 G030 380C)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G019 021 Set, bolt (Part of 49 G030 380C)</p> |  | <p>For adjustment of bearing preload</p> | <p>49 B027 002 Adapter, preload</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 F401 385 Bar (Part of 49 G030 380C)</p> |  | <p>For adjustment of bearing preload</p> | <p>49 U027 003 Installer, oil seal</p>  | <p>For installation of oil seal</p> |
| <p>49 G017 202 Adapter, preload</p> |  | <p>For adjustment of bearing preload</p> | <p>49 B027 001 Holder, diff. side gear</p>  | <p>For holding side gear</p> |
| <p>49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1)</p> |  | <p>For installation of bearing inner race</p> | <p>49 G017 1A0 Remover set, bearing</p>  | <p>For removal of bearing</p> |
| <p>49 F401 366A Plate (Part of 49 G017 1A0)</p> |  | <p>For removal of bearing</p> | <p>49 0710 520 Puller, bearing</p>  | <p>For removal of bearing</p> |

| | | | |
|---|--|--|--|
| <p>49 F027 0A1 Installer set, bearing</p>  | <p>For installation of bearing</p> | <p>49 M005 561 Hanger, differential carrier</p>  | <p>For disassembly and assembly of differentia</p> |
| <p>49 S120 710 Holder, coupling flange</p>  | <p>For removal and installation of companion flange</p> | <p>49 B027 003 Attachment M</p>  | <p>For removal of bearing</p> |
| <p>49 F027 0A0 Gauge set, pinion height adjustment</p>  | <p>For adjustment of pinion height</p> | <p>49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0)</p>  | <p>For adjustment of pinion height</p> |
| <p>49 F401 337A Attachment C (Part of 49 D017 2A1)</p>  | <p>For installation of bearing inner race (side bearing)</p> | <p>49 F027 003 Handle (Part of 49 F027 0A1)</p>  | <p>For installation of bearing</p> |
| <p>49 F027 005 Attachment φ62 (Part of 49 F027 0A1)</p>  | <p>For installation of bearing</p> | <p>49 0259 720 Wrench, differential side bearing adjusting nut</p>  | <p>For adjustment of drive pinion and ring gear backlash</p> |
| <p>49 W023 785 Boot, installer</p>  | <p>For installation of oil seal</p> | <p>49 G030 338 Attachment E</p>  | <p>For installation of bearing</p> |
| <p>49 H028 2A0 Rubber bush replacer</p>  | <p>For installation of bearing</p> | <p>49 H028 202 Block L (Part of 49 H028 2A0),</p>  | <p>For installation of bearing</p> |

03U0J3-018


REMOVAL

1. Disconnect the negative battery cable.
2. Raise the vehicle and support it with safety stands.
3. Drain the transaxle oil and transfer carrier oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.



- | | |
|--|--|
| 1. Wheel and tire | 17. Exhaust pipe |
| 2. Splash shield | 18. Tie-rod end Removal Note page J3-17 |
| 3. Air hose and air cleaner assembly | 19. Stabilizer |
| 4. Battery | 20. Joint shaft |
| 5. Battery carrier | 21. Driveshaft Removal Note page J3-17 |
| 6. Speedometer cable | 22. Center differential lock motor Removal Note page J3-18 |
| 7. Shift cable | 23. Starter |
| 8. Neutral switch connector | 24. Engine mount member Removal Note page J3-19 |
| 9. Back-up light switch connector | 25. Engine mount No.2 |
| 10. Differential lock motor connector | 26. Clutch release cylinder and clutch pipe Removal Note page J3-19 |
| 11. Bolt | 27. Transaxle and transfer carrier Removal Note page J3-19 |
| 12. Control cable | |
| 13. Undercover | |
| 14. Propeller shaft Removal Note page J3-17 | |
| 15. Integrated stiffener | |
| 16. Crossmember | |

03U0J3-020




03U0J3-021

Removal note Propeller shaft

Caution

- Do not mark with a punch.

1. Mark the companion flange and the front yoke.
2. Mark the companion flange and the rear yoke.
3. Remove the propeller shaft.



03U0J2-017


Tie-rod end

1. Remove the cotter pin.

Caution

- Do not damage the dust boot.

2. Loosen the nut and disconnect the tie-rod end with the **SST**.




03U0KX-159

Driveshaft

Caution

- Do not damage the ball joint dust boot.

1. Remove the clinch bolts from the lower arm ball joints.
2. Pull the lower arms downward to separate them from the knuckles.




03U0KX-160

Caution

- Do not damage the oil seal.

3. Separate the left driveshaft from the transaxle by prying with a bar inserted between the shaft and the transaxle case.




03U0KX-161

Caution

- If the SST is not installed, the differential side gears may become misaligned.


4. Slide the **SST** into the differential side gear.



03U0J3-022


Center differential lock motor

1. Remove the set bolt.




03U0J3-023

2. Remove the center differential lock sensor switch.
3. Remove the plug, and turn the rod with a screwdriver.



03U0J3-024


4. Remove the center differential lock motor.
5. Remove the O-ring from the center differential lock motor.



03U0J3-025

Engine mounting member

1. Suspend the engine with the **SST** before removing the engine mounting member.




03U0J2-016

Clutch release cylinder

Caution

- Do not damage the clutch pipe.

1. Remove the bolts shown.
2. Lay aside the clutch release cylinder and the clutch pipe.



03U0J3-026

Transaxle and transfer unit

1. Use an engine hoist, and remove the transaxle and transfer unit.


DISASSEMBLY

Precaution


1. Clean the transaxle exterior thoroughly with a steam cleaner and/or cleaning solvent before disassembly.
2. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and dry with compressed air. Clean out all holes and passages with a compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

5th/Reverse Gear and Housing Parts

1. Measure the thrust clearance between 5th gear and the transaxle case, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.



| | | | |
|---|------------|---|------------|
| 1. Clutch release bearing Disassembly Note..... | page J3-22 | 31. Reverse idler gear support | |
| 2. Clutch release fork Disassembly Note..... | page J3-22 | 32. Reverse idler gear shaft | |
| 3. Differential lock set bolt | | 33. Bolt | |
| 4. Differential lock switch | | 34. Steel ball, spring, and bolt | |
| 5. Differential lock motor Disassembly Note..... | page J3-22 | 35. Shift rod assembly | |
| 6. Speedometer assembly | | 36. Shift rod end | |
| 7. Rear cover | | 37. Shift rod | |
| 8. Locknut | | 38. Primary shaft assembly Disassembly Note..... | page J3-24 |
| 9. Spacer | | Disassembly..... | page J3-33 |
| 10. Locknut | | Assembly..... | page J3-64 |
| 11. Primary reverse synchronizer gear Inspect gear teeth for damage, wear, and cracks | | 39. Secondary shaft assembly Disassembly Note..... | page J3-35 |
| 12. Synchronizer ring Inspection..... | page J3-45 | Disassembly..... | page J3-24 |
| 13. Secondary reverse synchronizer gear Inspect gear teeth for damage, wear, and cracks | | Assembly..... | page J3-67 |
| 14. Shift fork Disassembly Note..... | page J3-23 | 40. Shift fork assembly (3rd/4th) | |
| Inspection..... | page J3-46 | 41. Shift fork assembly (1st/2nd) | |
| 15. Clutch hub assembly Disassembly Note..... | page J3-23 | 42. Shift gate | |
| Inspection..... | page J3-45 | 43. Front and center differential assembly Disassembly Note..... | page J3-24 |
| 16. Synchronizer ring Inspection..... | page J3-45 | Disassembly..... | page J3-38 |
| 17. Primary 5th gear Inspection..... | page J3-45 | Assembly..... | page J3-58 |
| 18. Secondary 5th gear Inspect gear teeth for damage, wear, and cracks | | 44. Idler gear assembly Disassembly..... | page J3-40 |
| 19. Gear sleeve Inspection..... | page J3-45 | Assembly..... | page J3-56 |
| 20. Interlock plate | | 45. Center differential lock shift fork Disassembly..... | page J3-38 |
| 21. Interlock pins | | Assembly..... | page J3-58 |
| 22. Neutral switch | | 46. Shift fork (3rd/4th) Inspection..... | page J3-45 |
| 23. Back-up light switch | | 47. Shift rod (3rd/4th) | |
| 24. Top cover assembly Disassembly Note..... | page J3-23 | 48. Shift rod end | |
| Disassembly..... | page J3-31 | 49. Shift fork (1st/2nd) Inspection..... | page J3-45 |
| Assembly..... | page J3-62 | 50. Shift rod (1st/2nd) | |
| 25. Steel balls and springs | | 51. Dynamic damper assembly | |
| 26. Lock bolt | | 52. Transfer carrier assembly Disassembly..... | page J3-42 |
| 27. Transaxle case assembly Disassembly Note..... | page J3-23 | Assembly..... | page J3-50 |
| Disassembly..... | page J3-28 | 53. Clutch housing assembly Disassembly..... | page J3-28 |
| Assembly..... | page J3-70 | Assembly..... | page J3-70 |
| 28. Interlock pin | | 54. O-ring | |
| 29. Reverse idler gear shaft assembly | | 55. Speedometer driven gear | |
| 30. Reverse idler gear Inspection..... | page J3-45 | 56. Oil seal Disassembly Note..... | page J3-25 |
| | | On-vehicle..... | page J3-25 |
| | | 57. Speedometer sleeve | |
| | | 58. Synchronizer key spring | |
| | | 59. Clutch hub sleeve Inspection..... | page J3-45 |
| | | 60. Synchronizer key | |
| | | 61. Clutch hub | |




03U0J3-029

Preinspection

5th gear thrust clearance

1. Mount the transaxle and transfer carrier on the **SST**.
2. Remove the rear cover.




03U0J3-030

3. Measure the 5th gear thrust clearance with a dial indicator.

Clearance: 0.1—0.22mm (0.0039—0.0087 in)

Maximum : 0.27mm (0.0106 in)

4. If the clearance exceeds the maximum, check the contact surfaces of 5th gear and the clutch hub. Replace worn or damaged parts.




03U0J3-031

Disassembly note

Clutch release bearing, clutch release fork


1. Slide the clutch release fork to the boot.
2. Remove the clutch release bearing.
3. Remove the clutch release fork.



03U0J3-032


Center differential lock motor

1. Remove the set bolt.



03U0J3-033

2. Remove the plug and turn the differential lock shift rod 180° clockwise with screwdriver.
3. Remove the differential lock assembly.



03U0J3-034

Shift fork, clutch hub assembly


1. Lock the primary shaft with the **SST**.
2. Shift to 1st or 2nd gear to lock the rotation of the primary shaft.

Caution

- Do not reuse the removed locknut.

3. Uncrimp the tabs of the locknuts.
4. Remove the locknuts from the primary and secondary shafts.


5. Remove the shift fork together with the clutch hub assembly.



03U0J3-035

Top cover assembly


1. Remove the top cover assembly.
2. Remove the springs.
3. Remove the steel balls with a magnet.



03U0J3-036


Transaxle case assembly

1. Remove the bolt.




03U0J3-037

2. Remove the bolts and transaxle case by tapping lightly with a plastic hammer.
3. Remove the magnet.




03U0J3-038



03U0J3-039


**Primary shaft assembly, secondary shaft assembly,
front and center differential assembly**

1. Lean the clutch housing as shown.




03U0J3-040

2. Hold the front differential assembly and the idler gear assembly so that primary shaft and secondary shaft can be removed.




03U0J3-041

3. Remove the primary shaft assembly, secondary shaft assembly and shift fork assembly together.




03U0J3-042

4. Remove the shift gate.



03U0J3-043


5. Remove the front and center differential assembly, idler gear assembly and center differential lock shift fork assembly together.



03U0J1-034

Oil seal (Speedometer gear case)


1. Remove the oil seal as shown in the figure.



03U0J3-044

Oil seal (Driveshaft) Replacement (On-vehicle)

1. Jack up the vehicle and support it with safety stands.
2. Drain the transaxle oil.
3. Remove the concerned front wheel.
4. Remove the splash shield.
5. Separate the front stabilizer from the lower arm.




03U0J3-045

Caution

- Do not damage the dust boots.

6. Remove the clinch bolt and pull the lower arm downward. Separate the knuckle from the lower arm ball joint.
7. Loosen the nut and disconnect the tie-rod end with the **SST**.




03U0J3-046

Caution


- Do not subject the tripod joint to shock when removing the driveshaft.

8. Disconnect the driveshaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle.
9. Suspend the driveshaft with a rope.




03U0J3-047


10. Remove the oil seal with a screwdriver.




03U0J3-048



03U0J3-049



03U0J3-050



03U0J3-051

Note

- Tap in until the oil seal installer contacts the case.
- Coat the oil seal lip with transaxle oil.

11. Tap the new oil seal into the transaxle case with the **SST**.

12. Replace the driveshaft end clip with a new one. Insert the driveshaft with the end-gap of the clip facing upward.

13. Install the joint shaft.

Tightening torque:

42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)

14. Install the lower arm ball joint to the knuckle and tighten.

Tightening torque:

43—54 N·m (4.4—5.5 m·kg, 32—40 ft·lb)

15. Install the tie-rod end to the knuckle and tighten it.

Tightening torque:

29—44 N·m (3.0—4.5 m·kg, 22—33 ft·lb)

16. Install a new gasket, and the drain plug, and add the specified oil from check plug port.

Tightening torque:

39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)


MEMO

Clutch Housing and Transaxle Case Components

Caution


- Do not remove an oil seal if not necessary.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.



- 1. Plug
- 2. Plug
- 3. Oil guide
- 4. Bearing outer race
- 5. Diaphragm spring
- 6. Adjustment shim
- 7. Bearing outer race
- 8. Diaphragm spring
- 9. Adjustment shim
- 10. Oil seal
Disassembly Note page J3-29
- 11. Bearing outer race
Disassembly Note page J3-30
- 12. Adjustment shim
- 13. Bearing outer race
- 14. Adjustment shim
- 15. Transaxle case
- 16. Dust cover
- 17. Ventilator covers
- 18. Plug
- 19. Magnet
- 20. Oil guide
- 21. Baffle
- 22. Bolt
- 23. Air breather dust boot and air breather
- 24. Air breather
- 25. Baffle
- 26. Lever set spring and steel ball
- 27. Reverse lever support
- 28. Bearing outer race
- 29. Oil seal
- 30. Bearing outer race
Disassembly Note page J3-30
- 31. Funnel
Disassembly Note page J3-30
- 32. Bearing outer race
- 33. Bearing outer race
(Front and center differential side)
Disassembly Note page J3-29
- 34. Oil seal
Disassembly Note page J3-29
- 35. Pivot pin
- 36. Plug
- 37. Oil seal
Disassembly Note page J3-29
- 38. Oil seal
- 39. Front cover
- 40. Clutch housing

03U0J3-053




03U0J3-054

Disassembly Note

Oil seal


1. Remove the oil seal with a screwdriver.



03U0J3-055

Bearing outer race (Front and center differential side)

1. Remove the bearing outer race with a screwdriver.



03U0J3-057

Funnel, bearing outer race**Note**

- Remove the bearing outer race with a screwdriver if necessary.


(1) Insert a screwdriver between the clutch housing and bearing outer race.

(2) Pry the bearing outer race free.

1. Remove the bearing outer race by lifting out the funnel and race together.


Top Cover Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



03U0J3-058


- | | |
|-----------------------------------|-----------------------------------|
| 1. Inner select lever | 9. Springs |
| 2. Select lever | Disassembly Note page J3-32 |
| 3. Roll pin | 10. Guide springs |
| Disassembly Note page J3-32 | 11. Base plate assembly |
| 4. Retaining rings | 12. Reverse gate spring |
| Disassembly Note page J3-32 | 13. Oil seal |
| 5. Shift lever | Disassembly Note page J3-32 |
| 6. Boot | 14. Oil seal (Select lever side) |
| 7. Inner shift lever | 15. Top cover |
| 8. Washer | |



03U0J3-059

Disassembly note**Roll pin**


1. Slide the inner shift cover to the boot side.
2. Remove the roll pin.



03U0J3-060

Retaining rings


1. Slide the guide spring and remove the retaining ring.
2. Remove the inner shift lever.



03U0J3-061

Oil seal

1. Remove the oil seal with a screwdriver.



03U0J3-062

Springs**Caution**


- Do not confuse the springs.
The boot side spring is shortest.

Note

- Mark the springs as shown.


Primary Shaft Assembly

1. Measure the thrust clearance of all gears before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



03U0J3-063

- | | |
|--------------------------------------|---|
| 1. Bearing inner race (4th gear end) | 7. 3rd gear |
| Preinspection page J3-34 | Preinspection page J3-45 |
| Disassembly Note page J3-34 | Inspection page J3-45 |
| 2. 4th gear | 8. Bearing inner race (Primary shaft end) |
| Inspection page J3-45 | Disassembly Note page J3-45 |
| 3. Synchronizer ring (4th) | 9. Primary shaft |
| Inspection page J3-45 | Inspection page J3-46 |
| 4. Retaining ring | 10. Synchronizer springs |
| 5. Clutch hub assembly (3rd/4th) | 11. Synchronizer keys |
| Disassembly Note page J3-34 | 12. Clutch hub |
| Inspection page J3-45 | 13. Clutch hub sleeve |
| 6. Synchronizer ring (3rd) | |
| Inspection page J3-45 | |




03U0J3-064

Preinspection

1. Measure the clearance between the 4th gear and bearing inner race.

Clearance: 0.165—0.365mm (0.0064—0.0144 in)

Maximum: 0.415mm (0.0163 in)




03U0J3-065

2. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)

Maximum: 0.25mm (0.010 in)



03U0J3-066


Disassembly note

Bearing inner race (4th gear end)

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race with the **SST**.



03U0J2-044


Clutch hub assembly (3rd/4th), synchronizer ring (3rd) and 3rd gear

1. Remove the retaining ring.

Caution

- Hold the shaft with one hand so that it does not fall.

2. Remove the clutch hub assembly (3rd/4th) synchronizer ring (3rd) and 3rd gear with the **SST**.




03U0J2-045

Bearing inner race (Primary shaft end)

1. Remove the bearing inner race with the **SST**.


Secondary Shaft Assembly

1. Measure the thrust clearance of all gears before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



03U0J3-067

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Bearing inner race Disassembly Note..... page J3-36 Inspection..... page J3-45 2. Secondary 4th gear Disassembly Note..... page J3-36 Inspection..... page J3-45 3. Retaining ring 4. Secondary 3rd gear Preinspection page J3-36 Disassembly Note..... page J3-36 Inspection..... page J3-45 5. 2nd gear Disassembly Note..... page J3-36 Inspection..... page J3-45 6. Synchronizer ring (2nd) Inspection..... page J3-45 7. Retaining ring | <ol style="list-style-type: none"> 8. Clutch hub assembly (1st/2nd) Inspection..... page J3-45 9. Synchronizer ring (1st) Inspection..... page J3-45 10. 1st gear Preinspection page J3-36 Disassembly Note..... page J3-36 Inspection..... page J3-45 11. Bearing inner race Disassembly Note..... page J3-37 12. Secondary shaft Inspection..... page J3-46 13. Synchronizer springs 14. Synchronizer keys 15. Clutch hub 16. Clutch hub sleeve (Reverse gear) |
|--|---|




03U0J2-035

Preinspection Thrust clearance

1. Measure the clearance between the 2nd gear and secondary 3rd gear.


Clearance: 0.175—0.455mm (0.0069—0.0179 in)
Maximum: 0.505mm (0.0199 in)



03U0J2-036

2. Measure the clearance between the 1st gear and differential drive gear.

Clearance: 0.05—0.28mm (0.002—0.011 in)
Maximum: 0.33mm (0.0130 in)



03U0J2-039


Disassembly note

Bearing inner race and secondary 4th gear

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race and secondary 4th gear with the **SST**.



03U0J2-040


Secondary 3rd gear and 2nd gear

1. Remove the retaining ring.
2. Shift the gears to 1st gear.

Caution

- Hold the shaft with one hand so that it does not fall.

3. Remove the secondary 3rd gear and 2nd gear with the **SST**.



03U0J2-041


Clutch hub assembly (1st/2nd), synchronizer ring (1st), and 1st gear

1. Remove the retaining ring.

Caution

- Hold the shaft with one hand so that it does not fall.

2. Remove the clutch hub assembly (1st/2nd), synchronizer ring (1st), and 1st gear with a press.



03U0J2-042


Bearing inner race (Secondary shaft end)**Caution**

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race with the **SST**.


Front and Center Differential Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Inspect all bearings for damage and rough rotation, and replace as necessary.



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Center differential lock shift fork 2. Center differential lock shift rod 3. Bearing inner race (Gear sleeve side) Disassembly Note page J3-39 4. Differential lock gear sleeve 5. Differential lock hub Inspect for damage and wear 6. Gear case needle bearing 7. Ring gear case Inspect gear teeth for wear and cracks 8. Gear case needle bearing 9. Differential lock thrust washer 10. Front differential gear case 11. Gear case needle bearings 12. Gear case needle bearing 13. Bearing inner race (Sun gear side) Disassembly Note page J3-39 14. Spacer | <ol style="list-style-type: none"> 15. Thrust washer 16. Gear case needle bearing 17. Sun gear Inspect gear teeth for wear and cracks 18. Gear case needle bearing 19. Planetary carrier Inspect gears for wear, cracks and rough rotation 20. Gear case needle bearings 21. Differential gear case sleeve Disassembly Note page J3-39 22. Pinion shaft 23. Washers 24. Pinion gears Inspect gear teeth for wear and cracks 25. Side gears Inspect gear teeth for wear and cracks 26. Washers |
|--|---|

03U0J3-069




03U0J3-070

Disassembly note
Bearing inner race (Differential lock gear sleeve side)

Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the bearing inner race.




03U0J3-071

Bearing inner race (Sun gear side)

Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the bearing inner race.



03U0J3-072

Differential gear case sleeve


Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the gear case sleeve with a press.

Idler Gear Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.



03U0J3-073

1. Bearing inner race (Idler gear side)
Disassembly Note..... page J3-40
2. Idler gear
Inspect gear teeth for wear and cracks


3. O-ring
4. Joint sleeve
5. Bearing inner race (Joint sleeve side)
Disassembly Note..... page J3-40



03U0J3-074

Bearing inner race (Idler gear side)

1. Fit a punch through a hole in the idler gear and tap off the bearing inner race.



03U0J3-075

Bearing inner race (Joint sleeve side)

Caution


- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race with the **SST**.

MEMO


Transfer Carrier Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.



- | | |
|---|--|
| 1. Transfer carrier Disassembly Note page J3-43 | 12. Drive pinion Disassembly Note page J3-44 |
| 2. Bolts | 13. Bearing inner race Disassembly Note page J3-44 Inspect for damage and rough rotation |
| 3. Lock plates | 14. Collapsible spacer |
| 4. Bearing caps | 15. Bearing inner race Disassembly Note page J3-44 Inspect for damage and rough rotation |
| 5. Adjusting screws Disassembly Note page J3-43 | 16. Bearing inner race Disassembly Note page J3-44 Inspect for damage and rough rotation |
| 6. Side bearings | 17. Spacer |
| 7. Ring gear assembly | 18. Bearing inner races (Side bearing) Disassembly Note page J3-44 |
| 8. Nut Disassembly Note page J3-43 | 19. Ring gear |
| 9. Washer | |
| 10. Companion flange Disassembly Note page J3-43 | |
| 11. Oil seal | |

03U0J3-077




03U0J3-078

Disassembly Note Transfer carrier

1. Mark one bearing cap and the carrier for proper reassembly.

Adjusting screw


1. Mark one adjusting screw and the carrier for proper reassembly.



03U0J3-079

Nut


1. Hold the companion flange with the **SST** and remove the nut.



03U0MX-863

Companion flange

1. Remove the companion flange with the **SST**.



03U0MX-864

Drive pinion


1. Push out the drive pinion by attaching a miscellaneous nut to the drive pinion and tapping it with a copper hammer.

Bearing outer race

Note

- Identify the bearing outer races for proper reassembly.

1. Remove the bearing outer races by alternately tapping the races at the two grooves in the carrier.




03U0J3-080

Bearing inner race (Drive pinion)

Note

- Support the drive pinion by hand so that it does not fall.

1. Remove the bearing with the SST.




03U0J3-081

Bearing inner races (Side bearing)

Note

- Support the ring gear by hand so that it does not fall.

1. Remove the bearing inner race with the SST.




03U0J3-218


INSPECTION

Inspect all parts and repair or replace as necessary.


05U0JX-023




03U0J3-082



03U0J3-083



03U0J2-119



03U0J3-084

Gears (1st, 2nd, 3rd, 4th)

1. Inspect the synchronizer cones for wear.
2. Inspect the individual gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer ring matching teeth for damage and wear.

Synchronizer ring, gear (1st, 2nd, 3rd, 4th)

1. Inspect the individual synchronizer ring teeth for damage, wear, and cracks.
2. Inspect the taper surface for wear and cracks.

Note

- **Set the synchronizer ring squarely in the gear; then measure around the circumference.**


3. Measure the clearance between the synchronizer ring and flank surface of the gear.

Standard clearance: 1.5mm (0.059 in)

Minimum: 0.8mm (0.031 in)

Clutch hub assembly

1. Inspect the clutch hub sleeve and hub operation.
2. Inspect the individual gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer keys for damage, wear, and cracks.



03U0J3-219


Shift fork

1. Measure the clearance between hub sleeve and shift fork.

Clearance

mm (in)

| | Standard | Maximum |
|----------|--------------------------|---------------|
| 1st/2nd | 0.10—0.358 (0.004—0.014) | 0.858 (0.034) |
| 3rd/4th | 0.10—0.40 (0.004—0.016) | 0.90 (0.035) |
| 5th/Rev. | 0.10—0.40 (0.004—0.016) | 0.90 (0.035) |



03U0J3-220


Reverse idler gear and reverse lever

1. Inspect gear teeth for damage, wear, and cracks.
2. Measure the clearance between the reverse idler gear bushing and the reverse lever.

Standard clearance:

0.095—0.345mm (0.0037—0.0136 in)


Maximum: 0.845mm (0.0333 in)



03U0J2-115

Bearing

1. Inspect for damage and rough rotation.




03U0J3-085

Primary Shaft and Secondary Shaft

1. Inspect the gear contact surface for damage and wear.
2. Inspect the splines for damage and wear.
3. Inspect the gear teeth for damage, wear, and cracks.
4. Inspect the oil passage for clogging.
5. Inspect the shaft gear runout.

Primary shaft gear runout: 0.05mm (0.002 in)




03U0J3-221



Secondary shaft gear runout: 0.015mm (0.0006 in)

Note


- If the shaft gear is replaced, adjust the bearing preload.



03U0J3-222



03U0J3-086



03U0J3-087

6. Oil clearance between shaft gears and gears.

Oil Clearance

mm (in)

| | Shaft (Outer dia.) | Gear (Inner dia.) | Sleeve (Outer dia.) | Oil clearance |
|-----|--------------------------------|--------------------------------|--------------------------------|----------------------------|
| 1st | 39.445—39.470 (1.553—1.554) | 39.500—39.525 (1.555—1.556) | — | 0.03—0.08 (0.001—0.003) |
| 2nd | 34.945—34.970 (1.376—1.377) | 35.000—35.025 (1.378—1.379) | — | |
| 3rd | 35.945—35.970 (1.415—1.416) | 36.000—36.025 (1.417—1.418) | — | |
| 4th | 30.945—30.970 (1.218—1.219) | 31.000—31.025 (1.220—1.221) | — | |
| 5th | — | 34.000—34.025 (1.339—1.400) | 33.945—33.970 (1.336—1.337) | |

Differential Lock Gear Sleeve

1. Measure the clearance between the gear sleeve groove and shift fork.

Standard clearance: 0.15—0.50mm (0.006—0.02 in)
Maximum: 1.0mm (0.394 in)


2. Inspect for damage and rough rotation.

ASSEMBLY

Precaution

1. All O-rings and gaskets must be replaced with the new ones supplied in the overhaul kit.
2. Verify that all parts are completely clean before assembly.
3. Assemble parts within 10 minutes after applying sealant.
Allow all sealant to cure at least 30 minutes after assembly before filling the transaxle with transaxle oil.
4. Bearing outer races and inner races must be replaced as assemblies.

03U0J3-088



03U0J3-089

Clutch hub assembly

Note

- Synchronizer ring diameters are as follows.


mm (in)

| | |
|-----------------|--------------|
| 1st and 2nd | 67.7 (2.665) |
| 3rd and 4th | 67.7 (2.665) |
| 5th and Reverse | 55.7 (2.192) |


- Synchronizer key dimensions are as follows.

mm (in)

| | ① | ② | ③ |
|---------|---------------|--------------|--------------|
| 1st/2nd | 19.00 (0.748) | 4.25 (0.167) | 5.00 (0.197) |
| 3rd/4th | 17.00 (0.669) | 4.25 (0.167) | 5.00 (0.197) |
| 5th | 17.00 (0.669) | 4.25 (0.167) | 5.00 (0.197) |




03U0J3-223



03U0J1-066

1. Install the synchronizer key springs in the clutch hub with the hooks in the grooves to hold the three synchronizer keys in place.

2. Align the synchronizer ring grooves with the synchronizer key during assembly.




03U0J1-067

MEMO

Transfer Carrier Assembly

1. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N-m (m-kg, ft-lb)


03U0J3-090

- 1. Bearing inner races (Side bearing)
 Assembly Note..... page J3-51
- 2. Ring gear
- 3. Transfer carrier
- 4. Spacer
 Assembly Note..... page J3-53
- 5. Bearing inner race (Drive pinion side)
 Assembly Note..... page J3-53
- 6. Collapsible spacer
- 7. Bearing inner race
- 8. Drive pinion
 Assembly Note..... page J3-52
- 9. Bearing inner race
- 10. Oil seal
 Assembly Note..... page J3-54
- 11. Companion flange
 Assembly Note..... page J3-54
- 12. Washer
- 13. Nut (Companion flange)
- 14. Ring gear assembly
- 15. Bearing outer races (Side bearing)
- 16. Adjusting screws
 Assembly Note..... page J3-54
- 17. Bearing caps
- 18. Bolts
- 19. Lock plates
- 20. Bolts

03U0J3-091




03U0J3-092




03U0J3-093

Assembly note
Bearing inner races (Side bearing)


1. Install the bearing with the **SST**.
2. Install the front and rear bearing outer races with a brass drift and a hammer.




03U0MX-869



03U0MX-870



97U0MX-082



03U0MX-871

Adjustment of pinion height

1. Adjust the drive pinion height as follows with the **SST**.


Note

- Use the spacer that was removed.
- Do not install the collapsible spacer.

- Install the bearing inner race (rear), spacer, O-ring and **SST**.
- Install the bearing inner race (front), companion flange, washer, and nut.
- Tighten the nut just enough so that the **SST** can be turned by hand.

- Place the **SST** on a surface plate and set the dial indicator to "Zero".


- Place the **SST** atop the drive pinion model. Set the gauge body atop the gauge block.
- Place the feeler of the dial indicator so that it contacts where the bearing inner race (side bearing) is installed in the carrier. Measure the lowest position on the left and right sides of the carrier.




03U0J3-094

| Mark | Thickness | Mark | Thickness |
|------|-----------------------|------|-----------------------|
| 08 | 3.08mm (0.1213 in) | 29 | 3.29mm (0.1295 in) |
| 11 | 3.11mm (0.1224 in) | 32 | 3.32mm (0.1307 in) |
| 14 | 3.14mm (0.1236 in) | 35 | 3.35mm (0.1319 in) |
| 17 | 3.17mm (0.1248 in) | 38 | 3.38mm (0.1331 in) |
| 20 | 3.20mm (0.1260 in) | 41 | 3.41mm (0.1343 in) |
| 23 | 3.23mm (0.1271 in) | 44 | 3.44mm (0.1354 in) |
| 26 | 3.26mm (0.1283 in) | 47 | 3.47mm (0.1366 in) |


97U0MX-085



03U0J3-095



03U0MX-873



03U0J3-096

g) Average the values obtained in Step f.

Specification: 0mm (0 in)

h) If it is not within specification, adjust the pinion height by selection of a spacer.

Note

- Spacers are available in increments of 0.03mm. Select the spacer thickness that is closest to that necessary.

Adjustment of drive pinion preload

1. Install the spacer.

Note

- Install the spacer selected from the pinion height adjustment above, being careful that the installation direction is correct.
- Press the bearing on until the force required suddenly increases.

2. Press the bearing inner race (rear bearing) on with the SST.

Caution

- Do not install the oil seal.

3. Install the collapsible spacer.

4. Install the drive pinion assembly.

5. Install the companion flange, and tighten the flange nut.

Tightening torque: 117 N·m (12 m·kg, 86 ft·lb)

6. Turn the companion flange by hand to seat the bearing.

7. Measure the drive pinion preload.

Adjust the preload by tightening the flange nut.

Preload:


1.00—1.56 N·m (10—16 cm·kg, 8.7—13.8 in·lb)

Tightening torque:

117—176 N·m (12—18 m·kg, 86—130 ft·lb)

If the specified preload cannot be obtained, replace the collapsible spacer with a new one and check again.

8. Remove the nut, washer, and companion flange.




03U0MX-875

Oil seal (Companion flange)

Caution

- Apply differential oil to the oil seal lip.


1. Tap a new oil seal into the differential carrier with the **SST**.



03U0MX-876

Companion flange

1. Apply a light coat of grease to the end face of the companion flange.



03U0J3-097

Nut (Companion flange)


1. Adjust the preload by tightening the flange nut.

Preload:

1.00—1.56 N·m (10—16 cm·kg, 8.7—13.8 in·lb)

Tightening torque:


117—176 N·m (12—18 cm·kg, 86—130 in·lb)



03U0J3-098


Adjustment of Backlash

1. Position the idler gear assembly in the carrier.




03U0J3-099

2. Install the differential bearing caps making sure that the marks on the cap and carrier agree.
3. Loosely tighten the bearing cap bolts on each side and adjust the backlash by turning the adjusting screws with the **SST**.
4. Mark the ring gear at four points at **approx. 90°** intervals on the ring gear and mount a dial indicator to the carrier so that the feeler comes in contact at a 90° angle with one of the ring gear teeth.



03U0J3-215

5. Check the backlash at the three other marked points, and make sure the minimum backlash is above **0.05mm (0.0020 in)** and the difference between the maximum and minimum is less than **0.07mm (0.0028 in)**.



03U0J3-216

6. Tighten the adjusting screws equally until the distance between the pilot sections on the bearing caps is as specified.

Specified distance: 32mm (1.259 in)

Note


- When adjusting the differential bearing preload, be careful not to affect the backlash of the drive pinion and ring gear.

Tightening torque:

18—25 N·m (1.8—2.6 m·kg, 13—19 ft·lb)


Inspection and adjustment of teeth contact

1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, readjust the pinion height, and then readjust the backlash.




03U0MX-883

- (1) Toe and flank contact
Replace the spacer with a thinner one to move the drive pinion outward.



63G09X-385


- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.



9MU0MX-068

Idler Gear Assembly

1. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



03U0J3-101


- 1. Bearing inner race (Joint sleeve side)
Assembly Note..... page J3-56
- 2. Joint sleeve
- 3. O-ring

- 4. Idler gear
- 5. Bearing inner race (Idler gear side)
Assembly Note..... page J3-56

Assembly note

Bearing inner race (Joint sleeve side)


- 1. Install the bearing with the **SST**.



03U0J3-102

Bearing inner race (Idler gear side)

- 1. Install the bearing with the **SST**.




03U0J3-103

MEMO


Front and Center Differential Assembly

1. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




03U0J3-104


- | | |
|--|---|
| 1. Front differential gear case | 14. Spacer |
| 2. Washers | 15. Bearing inner race (Sun gear side) |
| 3. Side gears | Assembly Note..... page J3-61 |
| Assembly Note..... page J3-59 | 16. Needle bearings |
| 4. Pinion gears | 17. Needle bearing |
| Assembly Note..... page J3-59 | 18. Washer |
| 5. Washers | Assembly Note..... page J3-60 |
| 6. Pinion shaft | 19. Needle bearing |
| 7. Front differential gear case sleeve | 20. Front ring gear |
| Assembly Note..... page J3-59 | 21. Needle bearing |
| 8. Needle bearings | 22. Differential lock gear hub |
| 9. Planetary carrier assembly | 23. Differential lock gear sleeve |
| 10. Needle bearing | 24. Bearing inner race (Gear sleeve side) |
| 11. Sun gear | Assembly Note..... page J3-61 |
| 12. Needle bearing | 25. Center differential lock shift rod |
| 13. Washer | 26. Center differential lock shift fork |




03U0J3-106




63G07C-141



03U0J3-107



63G07C-143



03U0J3-108

Side gears, pinion gears

1. Install the side gears and washers, and fix them with the SST.

2. Install a pinion gear and turn it 180°.

Note

- Do not install the washer at this time.

3. Install the other pinion gear and washer.


4. Turn the pinion gear and washer 150°.

5. Install the washer under the opposite pinion gear.

6. Align the pinion shaft holes of the pinion gears with the differential gear case.

Front differential case sleeve

1. Install the front differential case sleeve with a press as shown in the figure.



03U0J3-109

Adjustment of sun gear clearance


1. Install the washer (4.3mm) onto the gear case with the **SST**.

2. Set a dial indicator onto the gear case and measure the sun gear thrust clearance.


Clearance: 0.1—0.3mm (0.0003—0.0118 in)

3. If the clearance is not within specification, select the proper washer from the chart below.

| Measured clearance mm (in) | Washer thickness mm (in) |
|----------------------------|--------------------------|
| 0.9—1.1 (0.0354—0.0433) | 3.5 (0.137) |
| 0.7—0.9 (0.0275—0.0354) | 3.7 (0.145) |
| 0.5—0.7 (0.0196—0.0275) | 3.9 (0.153) |
| 0.3—0.5 (0.0118—0.0196) | 4.1 (0.1614) |
| 0.1—0.3 (0.0003—0.0118) | 4.3 (0.1692) |




03U0J3-110



03U0J3-111

Bearing inner race (Sun gear side)

1. Install the bearing inner race with the **SST**.




03U0J3-225

Adjustment of front differential gear case radial clearance

1. Install the front differential gear case into the ring gear case.

Note


- Available gear case needle bearing part numbers.
Small..... G0D0 27 519
Medium . G0D0 27 518
Large..... G0D0 27 517



03U0J3-226


2. Verify that the medium-size gear case needle bearing can be installed.

3. If can not, install the small-size gear case needle bearing.




03U0J3-227

4. If the medium-size gear case needle bearing can be installed, measure the clearance between the ring gear case and the needle bearing.



03U0J3-228

5. If the clearance exceeds 0.06mm (0.002 in), install the large-size gear case needle bearing.



03U0J3-114


Adjustment of front ring gear clearance

1. Install the washer and front differential gear case.
2. Install the needle bearing and differential lock hub.
3. Measure the clearance between the front ring gear and needle bearing.

Clearance: 0.15—0.30mm (0.0059—0.0118 in)

4. If the clearance is not within specification, select the proper washer from the chart below.

| Washer thickness mm (in) | | |
|--------------------------|---------------|---------------|
| 1.20 (0.0472) | 1.35 (0.0531) | 1.50 (0.0590) |
| 1.65 (0.0649) | 1.80 (0.0708) | |




03U0J3-115

Bearing inner race (Gear sleeve side)

1. Install the bearing inner race with the SST.


Top Cover Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



03U0J3-116

- | | |
|--|--|
| 1. Top cover | 8. Washer |
| 2. Oil seal (Select lever side) Assembly Note..... page J3-63 | 9. Inner shift lever |
| 3. Oil seal Assembly Note..... page J3-63 | 10. Boot Assembly Note..... page J3-63 |
| 4. Reverse gate spring | 11. Shift lever Assembly Note..... page J3-63 |
| 5. Base plate assembly | 12. Snap rings |
| 6. Spring guides | 13. Roll pin |
| 7. Springs Assembly Note..... page J3-63 | 14. Select lever |
| | 15. Inner select lever |




03U0J3-117

Assembly note
Oil seal (Select lever side)

Caution

- Apply transaxle oil to outer circumference of the oil seal.

1. Install the new oil seal with a suitable pipe.




03U0J3-118

Oil seal

Caution

- Apply transaxle oil to the oil seal lip.

1. Install the new oil seal with a suitable pipe.




03U0J3-119

Springs

Caution

- Do not misinstall the springs.




03U0J3-120

Boot

Caution

- Install the boot with the air bleed downward as shown in the figure.

1. Install the boot.




03U0J3-121

Shift lever

1. Install the shift lever as shown in the figure.


Secondary Shaft Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



03U0J3-122

- | | |
|--|--|
| 1. Clutch hub Assembly Note..... page J3-48 | 10. Retaining ring |
| 2. Synchronizer keys | 11. Synchronizer ring (2nd) Assembly Note..... page J3-65 |
| 3. Clutch hub sleeve | 12. 2nd gear Assembly Note..... page J3-65 |
| 4. Synchronizer springs | 13. Secondary 3rd gear Assembly Note..... page J3-65 |
| 5. Secondary shaft | 14. Retaining ring |
| 6. Bearing inner race (Secondary shaft end) Assembly Note..... page J3-65 | 15. Secondary 4th gear Assembly Note..... page J3-65 |
| 7. 1st gear Assembly Note..... page J3-65 | 16. Bearing inner race Assembly Note..... page J3-65 |
| 8. Synchronizer ring (1st) Assembly Note..... page J3-65 | |
| 9. Clutch hub assembly (1st/2nd) Assembly Note..... page J3-48 | |




03U0J2-059

Bearing inner race (Secondary shaft end)

1. Install the new bearing inner race with the **SST**.

Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




03U0J3-123

1st gear, synchronizer ring (1st) and clutch hub assembly (1st/2nd)

Note

- Align the synchronizer ring, grooves and clutch housing hub keys when installing.

1. Assemble the 1st gear, synchronizer ring (1st), and clutch hub assembly (1st/2nd), as shown in the figure.




03U0J2-061

2. Press the clutch hub assembly (1st/2nd) on with the **SST**.

Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




03U0J2-062

Synchronizer ring (2nd), 2nd gear and secondary 3rd gear

1. Install the synchronizer ring (2nd) and 2nd gear.
2. Install the secondary 3rd gear with the **SST**.

Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




03U0J3-124

Secondary 4th gear and bearing inner race

1. Install the secondary 4th gear and new bearing inner race.

Note


- Press to 19,620 N (2,000 kg, 4,400 lb).



03U0J3-224

2. Measure the clearance between the 1st gear and differential drive gear.

Clearance: 0.05—0.28mm (0.002—0.011 in)
Maximum: 0.33mm (0.013 in)



03U0J2-065


3. Measure the clearance between the 2nd gear and secondary 3rd gear.

Clearance: 0.175—0.455mm (0.0069—0.0179 in)
Maximum: 0.505mm (0.0199 in)

4. If not as specified, reassemble the secondary shaft assembly.


Primary Shaft Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



03U0J3-125

- | | |
|---|---|
| <p>1. Clutch hub Assembly Note..... page J3-48</p> <p>2. Synchronizer keys</p> <p>3. Clutch hub sleeve (Reverse gear)</p> <p>4. Synchronizer springs</p> <p>5. Primary shaft</p> <p>6. Bearing inner race (Primary shaft end) Assembly Note..... page J3-68</p> <p>7. 3rd gear Assembly Note..... page J3-68</p> | <p>8. Synchronizer ring (3rd) Assembly Note..... page J3-68</p> <p>9. Clutch hub assembly (3rd/4th) Assembly Note..... page J3-48</p> <p>10. Retaining ring</p> <p>11. Synchronizer ring (4th) Assembly Note..... page J3-68</p> <p>12. 4th gear Assembly Note..... page J3-68</p> <p>13. Bearing inner race Assembly Note..... page J3-68</p> |
|---|---|




03U0J2-053

Bearing inner race (Primary shaft end)

1. Install the new bearing inner race with the **SST**.

Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




03U0J3-126

3rd gear, synchronizer ring (3rd) and clutch hub assembly (3rd/4th)

Note

- The size of the 1st, 2nd, 3rd, and 4th synchronizer rings are the same. Be careful when installing them. The 2nd gear ring has the larger cut-out as shown in the illustration.
- Align the synchronizer ring grooves and clutch housing hub keys when installing.




03U0J2-055

1. Install the 3rd gear, synchronizer ring (3rd), and clutch hub assembly (3rd/4th) with the **SST**.

Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




03U0J2-056

Synchronizer ring (4th), 4th gear, and bearing inner race

1. Install the synchronizer ring (4th), 4th gear, and bearing inner race with the **SST**.

Note


- Press to 19,620 N (2,000 kg, 4,400 lb).



03U0J2-057

2. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)
Maximum: 0.25mm (0.010 in)



03U0J2-058


3. Measure the clearance between the 4th gear and bearing inner race.

Clearance: 0.165—0.365mm (0.0064—0.0144 in)
Maximum: 0.415mm (0.0163 in)

4. If not as specified, reassemble the primary shaft assembly.

- | | |
|---|--|
| 1. Clutch housing | 21. Baffle |
| 2. Front cover | 22. Magnet |
| 3. Oil seal | 23. Plug |
| 4. Oil seal | 24. Ventilator covers |
| 5. Plug | 25. Dust cover |
| 6. Pivot pin | 26. Transaxle case |
| 7. Oil seal | 27. Adjustment shim |
| 8. Bearing outer race (Idler gear) | 28. Bearing outer race |
| Assembly Note..... page J3-78 | 29. Adjustment shim |
| 9. Bearing outer race | 30. Bearing outer race |
| (Front and center differential) | 31. Oil seal (Front and center differential) |
| Assembly Note..... page J3-78 | Assembly Note..... page J3-78 |
| 10. Funnel | 32. Adjustment shim |
| 11. Bearing outer race | 33. Diaphragm spring |
| 12. Oil seal | Assembly Note..... page J3-79 |
| 13. Bearing outer race | 34. Bearing outer race |
| 14. Reverse lever support | 35. Adjustment shim |
| 15. Lever set spring and steel ball | 36. Diaphragm spring |
| 16. Baffle | Assembly Note..... page J3-79 |
| 17. Air breather | 37. Bearing outer race |
| 18. Breather dust boot and air breather | 38. Oil guide |
| 19. Bolt | 39. Plug |
| 20. Baffle | 40. Plug |

03U0J3-128




03U0J3-129

Idler gear adjustment shim selection

Note


- Measure at three locations and average the reading.

1. Place a straightedge on the transaxle case.
2. Measure the depth on the bearing outer race bore.



03U0J3-130

3. Set the idler gear assembly into the clutch housing.
4. Turn the idler gear assembly to seat the bearing.
5. Install the bearing outer race to the idler gear assembly.



03U0J3-131

6. Measure from the top of the bearing outer race to the clutch housing.

| Adjust shim thickness | mm (in) |
|-----------------------|--------------|
| 0.10 (0.003) | 0.20 (0.008) |
| 0.25 (0.010) | 0.30 (0.012) |
| 0.35 (0.014) | 0.40 (0.016) |
| 0.45 (0.018) | 0.50 (0.020) |
| 0.55 (0.022) | 0.60 (0.024) |
| 0.65 (0.026) | 0.70 (0.028) |
| 0.75 (0.030) | 0.80 (0.032) |
| 0.85 (0.034) | 0.90 (0.035) |
| 0.95 (0.037) | 1.00 (0.039) |
| 1.05 (0.041) | 1.10 (0.043) |
| 1.15 (0.045) | 1.20 (0.047) |

03U0J3-132


Caution

- The number of shims used must not exceed two.


7. Select the shim as follows.
 - (a) Subtract the bearing height (Step 6) from the depth of the bearing bore (Step 2).
 - (b) Add 0.17mm (0.0067 in) to (a).
 - (c) Add 0.22mm (0.0087 in) to (a).
 - (d) Select the shim in the range between (b) and (c) from the table.


Bearing preload adjustment

Adjust the bearing preload of the primary shaft, secondary shaft, and front and center differential by selecting and installing the proper adjustment shim(s).




03U0J3-133







03U0J3-134




03U0J3-135



03U0J3-136



03U0J3-137



03U0J3-138

Primary and secondary shaft gear

1. Install the primary and secondary shaft bearing outer races into the transaxle case (shims removed).

2. As shown in the figure, put the outer races into the **SST**.

Note

- Turn the selector to eliminate the gap indicated by the arrow in the figure.

3. Set the **SST** (selectors) in place.

4. Mount the primary and secondary shaft gear assemblies onto the **SST** (selectors).


5. Set the **SST** (collars) between the transaxle case and the clutch housing, and install the **SST** (bolts), and tighten to the specified torque.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

6. To seat the bearings, mount the **SST** (bar) on parts (A) and (B) of the **SST** (selectors), and turn the selector so the gap is enlarged.

Move the bars by hand until the selector can no longer be turned, and then turn it in the reverse direction until the gap is eliminated.




03U0J3-139

7. Manually expand the **SST** (selector) for both shafts until the **SST** (selector) no longer turns.

Note

- Make sure that each shaft turns smoothly.



03U0J3-140

8. Measure the gap of the **SST** (selector) for both gears.

Note

- Measure the gap around the entire circumference of the **SST** (selector).

Note

- The number of shims used must not exceed two.

| Thickness | mm (in) |
|-----------|---------|
| 0.20 | (0.008) |
| 0.25 | (0.010) |
| 0.30 | (0.012) |
| 0.35 | (0.014) |
| 0.40 | (0.016) |
| 0.45 | (0.018) |
| 0.50 | (0.020) |
| 0.55 | (0.022) |
| 0.60 | (0.024) |
| 0.65 | (0.026) |
| 0.70 | (0.028) |

03U0J3-141

9. Select an appropriate adjustment shim.


- (1) The shim for the primary shaft gear should be selected by referring to the table and selecting the shim which is nearest (on the thin side) to the value obtained by subtracting the thickness of the diaphragm spring which goes between the shim and the race from the measured value of the gap in the **SST** (selector).

Example: 0.94mm (0.0370 in)
0.94mm (0.0370 in) – 0.70mm (0.0276 in)
[Diaphragm spring]
= 0.24mm (0.009 in)
So the nearest shim (on thin side) to 0.24mm (0.009 in) is 0.20mm (0.008 in).

- (2) The shim for the secondary shaft gear should be selected by referring to the table and selecting the shim which is nearest (on the thick side) to the value obtained by subtracting the thickness of the diaphragm spring which goes between the shim and the race from the measured value of the gap in the **SST** (selector).

Example: 0.94mm (0.0370 in)
0.94mm (0.0370 in) – 0.70mm (0.0276 in)
[Diaphragm spring]
= 0.24mm (0.009 in)
So the nearest shim (on thick side) to 0.24mm (0.009 in) is 0.25mm (0.010 in).

03U0J3-142




03U0J3-143

10. Remove the **SST** (bolts and collars) and then remove the transaxle case, shaft gears and **SST** (selectors).
11. Remove the bearing outer races for both shafts from the transaxle case.


Front and center differential

1. Install the bearing outer race with the **SST**.



03U0J3-144

2. Install the front and center differential and bearing outer race.
3. Set the **SST** (selector) in place.




03U0J3-145

4. Set the **SST** (collars) between the transaxle case and the clutch housing, and install the **SST** (bolts), and tighten to the specified torque.

Tightening torque:


37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

5. Seat the bearings by turning the **SST** (selector) with the **SST** (bar) until the gap is enlarged.



03U0J3-146

6. Insert the **SST**.




03U0J3-147


7. Expand the **SST** (selector) until the proper preload specification is obtained.

Preload:

0.3—1.2 N·m (3—12 cm·kg, 2.6—10.4 in·lb)



03U0J3-148



03U0J3-149

| Thickness | | mm (in) | |
|--------------|--------------|--------------|--------------|
| 0.10 (0.004) | 0.20 (0.008) | 0.70 (0.028) | 0.75 (0.030) |
| 0.25 (0.010) | 0.30 (0.012) | 0.80 (0.032) | 0.85 (0.034) |
| 0.35 (0.014) | 0.40 (0.016) | 0.90 (0.036) | 0.95 (0.037) |
| 0.45 (0.018) | 0.50 (0.020) | 1.00 (0.040) | 1.05 (0.041) |
| 0.55 (0.022) | 0.60 (0.024) | 1.10 (0.044) | 1.15 (0.045) |
| 0.65 (0.026) | 0.65 (0.026) | 1.20 (0.048) | 1.20 (0.048) |

03U0J3-150

Note

- Measure the gap around the entire circumference of the selector.

8. Measure the gap in the **SST** (selector).

Note

- The number of shims used must not exceed three.

9. Select an appropriate adjustment shim to be used for the differential. It should be selected by referring to the table and selecting the shim which is nearest (on thick side) to the largest measured value of the gap in the **SST** (selector).

Example: 0.54mm (0.021 in)

So the nearest shim (on thick side) to 0.54mm (0.021 in) is 0.6mm (0.014 in).

10. Remove the **SST** (bolts and collars) and then remove transaxle case.
11. Remove the **SST** (selector), bearing outer race and front and center differential.

Bearing Preload

Check the shaft gears and the differential bearing preload.

Note

- Install the diaphragm springs and selected shims.
- If the bearing preload is not within specification, adjust again.

1. Set the primary shaft gear and the front and center differential assembly into the clutch housing.
2. Install the transaxle case, and tighten to the specified torque.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

3. Connect the **SST** and install it through the driveshaft hole.

Note


- Extend the handle fully and hook the pull scale to the end of the handle.

4. Hook a spring scale to the attachment and measure the preload.


Preload:

1.4—2.0 N·m (14—20 cm·kg, 12.2—17.5 in·lb)



03U0J3-152




03U0J3-151




03U0J3-153



03U0J3-154



03U0J3-155



03U0J3-156

5. Connect the **SST** to the primary shaft gear.
6. Check the primary shaft preload.

Preload:

0.10—0.25 N·m (1.0—2.5 cm·kg, 0.87—2.18 in·lb)

7. Remove the **SST**, transaxle case, primary shaft gear and front and center differential assembly.
8. Install the secondary shaft gear and transaxle case, and tighten to the specified torque.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

9. Check the secondary shaft preload with the **SST**.

Preload:

0.3—0.4 N·m (3.0—4.3 cm·kg, 2.6—3.7 in·lb)

10. Remove the **SST**, transaxle case and secondary shaft gear.

Assembly note

Oil seal (Front and center differential)

Caution

- Apply transaxle oil to the outer edge of the oil seal.


1. Install the new oil seal with the **SST**.

Bearing outer race (Idler gear)

1. Install the bearing outer race with the **SST**.

Bearing outer race (Front and center differential)

1. Install the bearing outer race with the **SST**.




03U0J2-081

Diaphragm spring


1. Install the diaphragm spring as shown in the figure.

5th/Reverse Gear and Housing Parts

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



| | |
|---|--|
| 1. Clutch hub | 33. Reverse idler gear shaft assembly Assembly Note..... page J3-83 |
| 2. Synchronizer keys | 34. Interlock pin Assembly Note..... page J3-83 |
| 3. Clutch hub sleeve | 35. Transaxle case assembly Assembly Note..... page J3-83 |
| 4. Synchronizer key springs | 36. Bolt |
| 5. Speedometer sleeve | 37. Steel balls and springs |
| 6. Oil seal (Speedometer driven gear assembly) Assembly Note..... page J3-82 | 38. Top cover assembly Assembly Note..... page J3-83 |
| 7. Speedometer driven gear Assembly Note..... page J3-82 | 39. Back-up light switch |
| 8. O-ring | 40. Neutral switch |
| 9. Clutch housing assembly | 41. Interlock pins |
| 10. Transfer carrier assembly | 42. Interlock plate |
| 11. Dynamic damper | 43. Gear sleeve |
| 12. Shift rod (1st/2nd) | 44. Secondary 5th gear |
| 13. Shift fork (1st/2nd) | 45. Primary 5th gear Assembly Note..... page J3-84 |
| 14. Shift rod end | 46. Synchronizer ring |
| 15. Shift rod (3rd/4th) | 47. Clutch hub assembly |
| 16. Shift fork (3rd/4th) | 48. Shift fork |
| 17. Center differential lock shift fork | 49. Secondary reverse synchronizer gear |
| 18. Idler gear assembly Assembly Note..... page J3-82 | 50. Synchronizer ring |
| 19. Front and center differential assembly Assembly Note..... page J3-82 | 51. Primary reverse synchronizer gear |
| 20. Shift gate | 52. Locknut Assembly Note..... page J3-84 |
| 21. Shift fork assembly (1st/2nd) | 53. Spacer |
| 22. Shift fork assembly (3rd/4th) | 54. Locknut Assembly Note..... page J3-84 |
| 23. Secondary shaft assembly Assembly Note..... page J3-82 | 55. Rear cover Assembly Note..... page J3-84 |
| 24. Primary shaft assembly Assembly Note..... page J3-82 | 56. Speedometer driven gear assembly |
| 25. Shift rod | 57. Center differential lock motor Assembly Note..... page J3-84 |
| 26. Shift rod end | 58. Center differential lock switch |
| 27. Shift rod assembly | 59. Differential lock set bolt |
| 28. Bolt | 60. Clutch release fork |
| 29. Bolt | 61. Clutch release bearing |
| 30. Reverse idler gear shaft | |
| 31. Reverse idler gear support | |
| 32. Reverse idler gear | |




03U0J3-158

Assembly note**Oil seal (Speedometer driven gear assembly)**

1. Install the new oil seal with a suitable pipe.


Pipe diameter: 16mm (0.629 in)



03U0J3-159

Speedometer driven gear


1. Install the new roll pin as shown in the figure.



03U0J3-160


Primary shaft assembly, secondary shaft assembly, front and center differential, idler gear assembly**Caution**

- Do not incision the hands to install time.
- Do not damage the oil seal.



03U0J3-161

1. Lean the clutch housing.
2. Install the front and center differential assembly, idler gear, and center differential shift fork assembly.
3. Hold up the front and center differential assembly and idler gear assembly so that primary shaft and secondary shaft can be removed.



03U0J3-162


4. Align the shift forks (1st/2nd and 3rd/4th) as shown.
5. Install the primary shaft assembly, secondary shaft assembly, and shift fork assembly.
6. Verify that the gears are properly engaged.

Reverse idler gear shaft assembly

Caution

- Verify that the gears are properly engaged.


1. Align the lock bolt hole and mark of the clutch housing.



03U0J3-163

Interlock pin


1. Install the interlock pins as shown in the figure.



03U0J3-164


Top cover assembly

1. Install the steel balls and the springs.



03U0J3-165

2. Install the top cover.
3. Install the boot with the air bleed downward as shown in the figure.




03U0J3-166

Transaxle case assembly


1. Apply a thin coat of sealant to the contact surfaces of the clutch housing and transaxle case.
2. Install and tighten the transaxle case installation bolts to the specified torque.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



03U0J3-167



03U0J3-168

3. Install the bolt.


Locknut

1. Shift to 1st gear.
2. Lock the primary shaft with the **SST**.
3. Tighten new locknuts on the primary and secondary shafts.

Tightening torque:

128—206 N·m (13.0—21 m·kg, 94—152 ft·lb)

4. Stake the locknuts to the groove.




03U0J3-169

Primary 5th gear

Note

- After installation, move the shift rod to verify that the gear change operation is smooth.

1. Shift to neutral and install the roll pin.



03U0J3-170

Rear Cover


Note

- Clean the contact surfaces before applying sealant.

1. Apply sealant to the transaxle case and rear cover.
2. Install the rear cover.

Tightening torque:

7.8—11 N·m (0.8—1.1 m·kg, 5.8—8.0 ft·lb)




03U0J3-171

Center Differential Lock motor


1. Install the center differential lock motor.

Tightening torque:

19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)



03U0J3-172



03U0J3-173

2. Turn the rod 180° counterclockwise with a screwdriver, and install the plug.
3. Install the bolts.

Tightening torque:

9—14 N·m (90—140 cm·kg, 78—122 ft·lb)


4. Install the differential lock switch.

Tightening torque:

20—29 N·m (2—3 m·kg, 14—22 ft·lb)


INSTALLATION

1. Raise the vehicle and support it with safety stands.
2. Install in the order shown in the figure, referring to **Installation Note**.
3. Add the specified amount of the specified transaxle oil. (Refer to page J3-11.)
4. Warm-up the engine and transaxle, and inspect for oil leakage and transaxle operation.



| | |
|--|--|
| 1. Transaxle and transfer unit Installation Note page J3-87 | 14. Propeller shaft Installation Note page J3-89 |
| 2. Clutch release cylinder and clutch pipe | 15. Undercover |
| 3. Engine mount No.2 | 16. Control cable Installation Note page J3-89 |
| 4. Engine mounting member Installation Note page J3-87 | 17. Bolt |
| 5. Starter | 18. Differential lock motor connector |
| 6. Center differential lock motor | 19. Back-up light switch connector |
| 7. Driveshaft Installation Note page J3-88 | 20. Neutral switch connector Installation Note page J3-89 |
| 8. Joint shaft | 21. Shift cable |
| 9. Stabilizer Installation Note page J3-88 | 22. Speedometer cable Assembly Note..... page J3-90 |
| 10. Tie-rod end Installation Note page J3-89 | 23. Battery carrier |
| 11. Exhaust pipe | 24. Battery |
| 12. Crossmember | 25. Air hose and air cleaner assembly |
| 13. Integrated stiffener | 26. Splash shield |
| | 27. Wheel and tire |

03U0J3-175




03U0J3-176

Installation Note Transaxle and transfer carrier

1. Mount the transaxle to the engine.

Tightening torque:

55—80 N·m (5.6—8.2 m·kg, 41—59 ft·lb)



03U0J3-177


Engine mounting member

1. Tighten the bolts as shown.

Tightening torque:

A 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

B 64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)



03U0J3-178

2. Tighten engine mount No.4 nuts.

Tightening torque:

66—93 N·m (6.8—9.5 m·kg, 49—68 ft·lb)

Driveshaft

Caution

- Do not damage the oil seal.
- After installation, pull the front hub outward to verify that the driveshaft is secured.

1. Replace the clips at the ends of the driveshafts and joint shaft with new ones.
2. Push the driveshafts into the differential with the groove of the clips upward.

Note

- Apply ATF to the oil seal lip.

3. Install the driveshaft.

4. Tighten the joint shaft mounting bolts in the order shown.

Tightening torque:

42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)


5. Install the lower arm ball joint to the knuckle and tighten the bolt.

Tightening torque:


43—54 N·m (4.4—6.0 m·kg, 32—40 ft·lb)

Stabilizer


1. Tighten the stabilizer nut so that **17mm (0.67 in) to 19mm (0.75 in)** of thread is exposed at the end of the bolt.




03U0J3-217




03U0J3-179




03U0J3-180



03U0J3-181



03U0KX-499



03U0J1-126


Tie-rod end

1. Install the locknut.

Tightening torque:

42—57 N·m (4.3—5.8 m·kg, 31—42 ft·lb)


2. Secure the locknut with a new cotter pin.



03U0J3-182

Propeller shaft

1. Align the marks and install the propeller shaft.
(Refer to Section L.)



03U0J3-183


Control cable

1. Install the bracket.

Tightening torque:

18—25 N·m (1.9—2.6 m·kg, 13—18 ft·lb)

2. Attach the control cable to the bracket with the clip.
3. Connect the control cable to the transaxle and transfer unit and install the washers and the pins.




03U0J3-184

4. Connect the ground to the clutch pipe bracket.

Tightening torque:

15—22 N·m (1.6—2.3 m·kg, 11—16 ft·lb)




03U0J3-185

Neutral switch connector

1. Install the bracket.
2. Connect the neutral switch connector.

Speedometer cable

1. Connect the speedometer cable.




03U0J3-186

SHIFT MECHANISM

OVERHAUL


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



03U0J3-187

1. Rear console
Assembly Note..... page J3-92
2. Front console
Disassembly Note page J3-92
3. Shift lever knob
4. Nut (Cable)
5. Clips (Cable)
6. Nuts (Shift lever assembly)


7. Shift lever assembly
Assembly Note..... page J3-92
8. Snap pins
9. Washers
10. Clips (Cable)
11. Select cable
12. Shift cable



03U0J3-188

Disassembly Note**Front console**


1. Loosen the bolt as shown.
2. Remove the rear console.
3. Remove the front console.



03U0J3-189


Shift lever assembly

1. Remove the nut and the clips.
2. Disconnect the shift cable and select cable from the shift lever assembly.



03U0J3-190

3. Remove the 4 mounting nuts.
4. Remove the shift lever assembly.




03U0J3-191


Assembly Note**Rear console**

1. After install the rear console, adjust the parking brake lever. (Refer to Section P.)


CENTER DIFFERENTIAL LOCK SYSTEM

SYSTEM DIAGRAM







03U0J3-193



03U0J3-194



03U0J3-195



03U0J3-196

INSPECTION

1. Turn the ignition switch ON.
2. Push the center differential lock switch ON.

3. Verify that the indicator lamp in the instrument cluster is turned on and a beep is heard.

Note

- **The indicator lamp will flash until the center differential is fully engaged. If necessary, move the vehicle forward until the differential engages.**

4. Push the center differential lock switch OFF.

5. Verify that the indicator lamp in the instrument cluster goes OFF.

CENTER DIFFERENTIAL LOCK MOTOR


INSPECTION

Continuity



1. Disconnect the negative battery terminal.
2. Disconnect the connectors of the center differential lock motor.
3. Check resistance between terminals at the motor side connectors.

Unit: Ω (Ohm)


| Motor | B-G | D-G | W-L |
|-------|----------|----------|-----|
| Free | ∞ | 0 | 1-3 |
| Lock | 0 | ∞ | |




03U0J3-197



03U0J3-198




03U0J3-199



03U0J3-200


REPLACEMENT

1. Disconnect the negative battery terminal.
2. Disconnect the connector and breather hose of center differential lock motor and center differential lock sensor switch.
3. Remove the set bolt and center differential lock sensor switch.
4. Remove the undercover and crossmember.
5. Remove the exhaust pipe.




03U0J3-201

6. Remove the plug and turn shift rod 180° clockwise with the screwdriver.



03U0J3-202

7. Remove the center differential lock motor from the transaxle and transfer unit.
8. Remove the O-ring from the center differential lock motor.




03U0J3-203

9. Measure the shift rod length in FREE and LOCK position.

Standard length:

FREE: 75mm (2.95 in)

LOCK: 83mm (3.26 in)




03U0J3-204

Note


- Apply ATF to the O-ring.

10. Fit a new O-ring onto the center differential lock motor.
11. Confirm that the flat edge of the shift rod is upward.



03U0J3-205


12. Turn the shift rod 180° counterclockwise with a screwdriver.



03U0J3-206

13. Install the mounting bolts.

Tightening torque:
20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)




03U0J3-207

14. Install the set bolt.

Tightening torque:
20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)

15. Install the center differential lock sensor switch.

Tightening torque:
20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)



03U0J3-208

4x4 CONTROL UNIT

INSPECTION

Terminal Voltage


1. Turn the ignition switch ON.
2. Measure the voltage at each terminal.

Unit: Volt


| | a | b | c | d | e | f | h | i | j | k | l | m | n |
|------|----|---|----|----|----|----|----|----|----|----|---|-----|------|
| Free | 12 | 0 | 0 | 12 | 0 | *0 | 12 | 0 | 12 | 12 | — | 6↔0 | 0↔12 |
| Lock | 12 | 0 | 12 | 0 | *0 | 0 | 0 | 12 | 0 | 0 | — | 6↔0 | 0↔12 |

↔: Repeat the timer time.

*: Start the differential lock motor time is 12 volt.



03U0J3-209



REPLACEMENT

1. Disconnect the negative battery terminal.
2. Remove the driver's seat.
3. Replace the 4x4 control unit.

CENTER DIFFERENTIAL LOCK SWITCH

INSPECTION Terminal Voltage

1. Turn the ignition switch ON.
2. Measure the voltage at each terminal at the switch side of the connector in LOCK and FREE position.

Unit: Volt

| Motor | a | b | c | d | e |
|-------|-----|---|----|----|----|
| Free | *12 | 0 | 12 | 12 | 0 |
| Lock | 0 | 0 | 12 | 0 | 12 |

* Turn the light switch (first position).

Continuity

1. Disconnect the negative battery terminal.
2. Disconnect the connector of switch.
3. Check continuity in LOCK and FREE position.

| Motor | a | b | c | d | e |
|-------|-----|-----|-----|-----|-----|
| Free | ○—○ | ○—○ | ○—○ | ○—○ | |
| Lock | ○—○ | ○—○ | ○—○ | | ○—○ |

○—○: Indicates continuity

REPLACEMENT

1. Disconnect the negative battery terminal.
2. Remove the switch.
3. Replace the switch.

CENTER DIFFERENTIAL LOCK SENSOR SWITCH

INSPECTION Continuity

1. Disconnect the negative battery terminal.
2. Remove the center differential lock sensor switch.
3. Check continuity between terminals in LOCK and FREE position.

| Motor | a | b |
|-------|-----|-----|
| Free | | |
| Lock | ○—○ | ○—○ |


○—○: Indicates continuity

REPLACEMENT


1. Disconnect the negative battery terminal.
2. Disconnect the connector of the center differential lock sensor switch.
3. Replace the switch.

Tightening torque:


20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)




03U0J3-210




03U0J3-211



03U0J3-212



03U0J3-213



03U0J3-214

AUTOMATIC TRANSAXLE AND TRANSFER (Electronically-Controlled)

INDEX..... K2- 2

FEATURES


OUTLINE K2- 3
 OUTLINE OF CONSTRUCTION K2- 3
 OUTLINE OF OPERATION K2- 4
 SPECIFICATIONS K2- 5
 STRUCTURAL VIEW..... K2- 6
 POWERFLOW DIAGRAM K2- 7
 OPERATION OF COMPONENTS K2- 8
 FLUID PASSAGE LOCATIONS K2- 9
ELECTRONIC CONTROL SYSTEM COMPONENTS . K2- 11
 SYSTEM DIAGRAM..... K2- 11
 COMPONENT DESCRIPTIONS..... K2- 12
 ELECTRICAL CIRCUIT..... K2- 13
 SOLENOID VALVE OPERATION TABLE K2- 14
SELF-DIAGNOSIS SYSTEM..... K2- 15
 SELF-DIAGNOSIS FUNCTION K2- 16
 DISPLAY OF MALFUNCTION CODE..... K2- 16
SHIFT CONTROL..... K2- 18
 SHIFT PATTERN..... K2- 18
 HIGH ATF TEMPERATURE DETERMINATION K2- 19

SERVICE

TROUBLESHOOTING GUIDE..... K2- 20
 GENERAL NOTES K2- 20
 QUICK DIAGNOSIS CHART..... K2- 21
 USING THIS SECTION..... K2- 24
 SYMPTOM TROUBLESHOOTING K2- 28
SELF-DIAGNOSIS FUNCTION..... K2-104
 DESCRIPTION..... K2-104
 PREPARATION..... K2-104
 EC-AT TESTER..... K2-104
 MALFUNCTION CODE NUMBER K2-106
 GENERAL NOTES K2-107
ELECTRONIC SIGNAL INSPECTION K2-115
 INSPECTION PROCEDURE K2-115
MECHANICAL SYSTEM TEST K2-119
 PREPARATION..... K2-119
 STALL TEST K2-119
 TIME LAG TEST..... K2-122
 LINE PRESSURE TEST..... K2-123
 THROTTLE PRESSURE TEST K2-125
ROAD TEST..... K2-127
 D-RANGE TEST..... K2-127
 S-RANGE TEST K2-129
 L-RANGE TEST K2-130
 P-RANGE TEST K2-131
AUTOMATIC TRANSAXLE FLUID K2-134
 ATF K2-134
TRANSFER CARRIER OIL..... K2-136
 INSPECTION..... K2-136
 REPLACEMENT K2-136
THROTTLE CABLE K2-137
 PREPARATION..... K2-137
 THROTTLE CABLE K2-137
ELECTRONIC SYSTEM COMPONENTS K2-140
 HOLD SWITCH..... K2-140
 INHIBITOR SWITCH K2-140
 ATF THERMOSWITCH K2-142
 PULSE GENERATOR K2-142
 SPEED SENSOR..... K2-143

SOLENOID VALVE..... K2-143
 EC-AT CONTROL UNIT K2-144
 WIRE HARNESS K2-146
TRANSAXLE AND TRANSFER K2-147
 TRANSAXLE AND TRANSFER ASSEMBLY..... K2-147
 TRANSAXLE AND TRANSFER UNIT
 (DISASSEMBLY)..... K2-152
 TORQUE CONVERTER..... K2-167
 OIL PUMP..... K2-168
 CLUTCH ASSEMBLY..... K2-173
 SMALL SUN GEAR AND ONE-WAY CLUTCH K2-182
 ONE-WAY CLUTCH CARRIER
 HUB ASSEMBLY K2-185
 3-4 CLUTCH K2-187
 LOW AND REVERSE BRAKE..... K2-192
 2-4 BRAKE BAND, SERVO..... K2-197
 2-3 ACCUMULATOR K2-200
 IDLER GEAR (TRANSAXLE)..... K2-202
 OUTPUT GEAR K2-205
 BEARING COVER ASSEMBLY K2-207
 OIL SEAL (TRANSAXLE) SECTION J3
 CONTROL VALVE BODY
 (DISASSEMBLY / INSPECTION)..... K2-209
 PREMAIN CONTROL VALVE BODY..... K2-214
 CONTROL VALVE BODY K2-218
 REAR CONTROL VALVE BODY K2-222
 CONTROL VALVE BODY (ASSEMBLY)..... K2-225
 CONTROL VALVE BODY
 (ON-VEHICLE REMOVAL / INSTALLATION) K2-235
 IDLER GEAR ASSEMBLY (TRANSFER)..... K2-237
 FRONT AND CENTER DIFFERENTIAL
 ASSEMBLY K2-240
 TRANSFER CARRIER ASSEMBLY K2-245
 BEARING PRELOAD K2-253
 TRANSAXLE AND TRANSFER UNIT
 (ASSEMBLY) K2-259
 INSTALLATION K2-276
OIL COOLER..... K2-280
 OIL COOLER K2-280
HYDRAULIC CIRCUIT..... K2-281
 P RANGE..... K2-281
 R RANGE..... K2-282
 N RANGE; BELOW APPROX. 18 km/h (11 mph) ... K2-283
 N RANGE; ABOVE APPROX. 18 km/h (11 mph).... K2-284
 D RANGE; 1ST GEAR K2-285
 D RANGE; 2ND GEAR K2-286
 D RANGE; 3RD GEAR, BELOW APPROX.
 40 km/h (25 mph) K2-287
 D RANGE; 3RD GEAR, ABOVE APPROX.
 40 km/h (25 mph) K2-288
 D RANGE; 4TH GEAR LOCKUP ON K2-289
 S RANGE; 1ST GEAR..... K2-290
 S RANGE; 2ND GEAR..... K2-291
 S RANGE; HOLD 2ND GEAR K2-292
 S RANGE; 3RD GEAR, BELOW APPROX.
 40 km/h (25 mph) K2-293
 S RANGE; 3RD GEAR, ABOVE APPROX.
 40 km/h (25 mph) K2-294
 L RANGE; 1ST GEAR..... K2-295
 L RANGE; HOLD 1ST GEAR K2-296
 L RANGE; 2ND GEAR, BELOW APPROX.
 110 km/h (68 mph)..... K2-297
 L RANGE; 2ND GEAR, ABOVE APPROX.
 110 km/h (68 mph)..... K2-298

INDEX



03U0K2-002

- | | | |
|--|--|---|
| <p>1. ATF Inspection / Replacement page K2-134</p> <p>2. Transfer carrier oil Inspection / Replacement page K2-136</p> <p>3. Inhibitor switch Inspection / Replacement / Adjustment page K2-140</p> <p>4. ATF thermoswitch Inspection page K2-142</p> | <p>5. Solenoid valves Inspection / Replacement page K2-143</p> <p>6. Throttle sensor 7. EC-AT control unit Inspection page K2-144</p> <p>8. Throttle cable Inspection / Replacement / Adjustment. page K2-137</p> <p>9. Transaxle and transfer Removal / Installation page K2-147</p> | <p>10. 2-4 brake band Adjustment ... page K2-199</p> <p>11. Control valve body assembly Disassembly / Inspection page K2-209 Assembly page K2-225 On-vehicle removal / Installation .. page K2-235</p> <p>12. Oil cooler Removal / Inspection / Installation .. page K2-280</p> |
|--|--|---|

OUTLINE

OUTLINE OF CONSTRUCTION

- The newly developed EC-AT (G4AX-EL) with Full-time 4-wheel-drive (4WD) is based upon the 1989 626 EC-AT (G4A-EL).
This new transaxle and transfer carrier has been made available for the 1990 323 for improved driveability and roadability.
- The construction and operation of the transaxle is the same as the 1989 626 EC-AT (G4A-EL). The Construction and operation of the transfer unit and carrier are basically the same as the 1989 323 with 4WD. The electronic control system of EC-AT is the same as the 1989 626 EC-AT (G4A-EL) non-turno model.
- The center differential employs a planetary carrier system, and functions to distribute the driving force to the front and rear differentials.
- The electronically controlled, lockable center differential means all driving conditions are easily contended with; from good road to bad roads and inclement weather.
- To improve serviceability, the EC-AT control unit diagnoses malfunctions of the major electrical components and outputs memorized malfunction codes by coded flashing of the HOLD indicator
The diagnosis connector is installed in the engine compartment by the left side suspension tower.
- The 1990 323 4WD EC-AT also has a shift-lock system for improved safety.

03U0K2-003

OUTLINE OF OPERATION


Driving force from engine is transmitted via the drive plate and torque converter to the transaxle.

Driving force through the transaxle is applied to the center differential, from which it is distributed to the front and rear axles.

The front axle applies the driving force, via the front differential, to the left and right wheels. Driving force for the rear axle is transmitted through the transfer unit, the transfer carrier, the propeller shaft, and to the rear differential.

If the vehicle encounters very slippery conditions and one wheel starts to spin, the center differential absorbs the speed difference and the other three wheels lose driving force.

At times like this, the center differential can be locked so that the front and rear axles are directly connected and driving force is transmitted to both axles.




03U0K2-004

SPECIFICATIONS


| | | | |
|--|---------------------------------|------------------|--|
| Transaxle | | | |
| Engine model | | BP SOHC (4WD) | |
| Transaxle model | | G4AX-EL | |
| Transaxle control | | Floor shift | |
| Lockup Mechanism | | Adapted | |
| Gear ratio | 1st | | 2.800 |
| | 2nd | | 1.540 |
| | 3rd | | 1.000 |
| | OD (4th) | | 0.700 |
| | Reverse | | 2.333 |
| Final gear ratio | | | 3.842 |
| Center differential | Type | | Planetary carrier |
| | Number of ring gear teeth | Outer | 73 |
| | | Inner | 66 |
| | Number of pinion gear teeth | Outer | 14 |
| | | Inner | 14 |
| | Number of sun gear teeth | Pinion gear side | 33 |
| Idle gear side | | 50 | |
| Number of idle gear teeth | | 43 | |
| Oil | Type | | ATF: M-III or DEXRON-II |
| | Capacity liters (US qt, Imp qt) | | 6.6 (7.0, 5.8) |
| Torque converter stall torque ratio | | | 2.7 |
| Number of drive/ driven plates | Forward clutch | | 3/3 |
| | Coasting clutch | | 2/2 |
| | 3-4 clutch | | 4/4 |
| | Reverse clutch | | 2/2 |
| | Low and reverse clutch | | 3/3 |
| 2-4 brake band (Piston outer dia./retainer inner dia.) | | | 78/59 |
| Number of planetary gear teeth | Large sun gear | | 36 |
| | Small sun gear | | 30 |
| | Long pinion gear | | 24 |
| | Short pinion gear | | 22 |
| | Internal gear | | 84 |
| Number of output gear teeth | | | 19 |
| Number of idle gear teeth | | | 40 |
| Number of ring gear teeth | | | 73 |
| Transfer carrier | | | |
| Number of ring gear teeth | | | 37 |
| Number of pinion gear teeth | | | 11 |
| Speedometer gear ratio (Number of driven/drive gear teeth) | | | 1.000 (22/22) |
| Oil | Type | | API: GL-5 Above -18°C (0°F): SAE 90 Below -18°C (0°F): SAE 80W |
| | Capacity liter (US qt, Imp qt) | | 0.5 (0.52, 0.44) |

03U0K2-005

STRUCTURAL VIEW



POWERFLOW DIAGRAM



03U0K2-007

- | | | |
|---------------------|---------------------------|-----------------------|
| 1. Crank shaft | 9. 3-4 clutch | 17. Long pinion gear |
| 2. Drive plate | 10. Reverse clutch | 18. Short pinion gear |
| 3. Torque converter | 11. 2-4 Brake band | 19. Internal gear |
| 4. Turbine shaft | 12. Low and reverse brake | 20. Parking gear |
| 5. Oil pump shaft | 13. One-way clutch 1 | 21. Output gear |
| 6. Oil pump | 14. One-way clutch 2 | 22. Idler gear |
| 7. Forward clutch | 15. Large sun gear | 23. Ring gear |
| 8. Coasting clutch | 16. Small sun gear | |




OPERATION OF COMPONENTS

| Mode | Range | Gear position | Engine braking effect | Forward clutch | Coasting clutch | 3-4 clutch | Reverse clutch | 2-4 brake | | Low & reverse brake | One-way clutch 1 | One-way clutch 2 | |
|--------|---------------------------------|---|---|---|-----------------|------------|----------------|-----------|----------|---------------------|------------------|------------------|---|
| | | | | | | | | Applied | Released | | | | |
| Normal | P | — | — | | | | | | | | | | |
| | R | Reverse | Yes | | | | ○ | | | ○ | | | |
| | N | — | Below approx. 4 km/h (2.5 mph) | — | | | | | | | | | |
| | | | Above approx. 5 km/h (3.1 mph) | — | | | | | | | | | |
| | D | 1st | 1st | No | ○ | | | | | | | ○ | ○ |
| | | | 2nd | No | ○ | | | ○ | | | | ○ | |
| | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | Yes | ○ | ○ | ○ | | | ○ | | ○ | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | Yes | ○ | ○ | ○ | | ⊗ | ○ | | ○ | |
| | | OD | Lockup OFF | Yes | ○ | | ○ | | ○ | | | ⊗ | |
| | | | Lockup ON | Yes | | | | | | | | | |
| | S | 1st | 1st | No | ○ | | | | | | | ○ | ○ |
| | | | 2nd | No | ○ | | | ○ | | | | ○ | |
| | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | Yes | ○ | ○ | ○ | | | ○ | | ○ | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | Yes | ○ | ○ | ○ | | ⊗ | ○ | | ○ | |
| | | OD | OD | Yes | ○ | | ○ | | ○ | | | ⊗ | |
| | L | 2nd | 1st | No | ○ | | | | | | ○ | ○ | |
| | | | Above approx. 110 km/h (68 mph) | Yes | ○ | ○ | | | ○ | | | ○ | |
| | Hold | D | 1st | 1st | No | ○ | | | | | | ○ | |
| 2nd | | | | No | ○ | | | ○ | | | ○ | | |
| 3rd | | | Below approx. 5 km/h (3.1 mph) at operating temperature | Yes | ○ | ○ | ○ | | | ○ | | ○ | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | Yes | ○ | ○ | ○ | | ⊗ | ○ | | ○ | |
| OD | | OD | Yes | ○ | | ○ | | ○ | | | ⊗ | | |
| S | | 2nd | 2nd | Yes | ○ | | | | ○ | | | ○ | |
| | | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | Yes | ○ | ○ | ○ | | | ○ | | ○ |
| | | Above approx. 5 km/h (3.1 mph) or cold engine | | Yes | ○ | ○ | ○ | | ⊗ | ○ | | ○ | |
| OD | | OD | Yes | ○ | | ○ | | ○ | | | ⊗ | | |
| L | | 1st | 1st | Yes | ○ | ○ | | | | | ○ | ○ | |
| | Above approx. 110 km/h (68 mph) | | Yes | ○ | ○ | | | ○ | | | ○ | | |
| L | 2nd | 2nd | Yes | ○ | ○ | | | ○ | | | ○ | | |
| | | Above approx. 110 km/h (68 mph) | Yes | ○ | ○ | | | ○ | | | ○ | | |


03U0KX-007

⊗ : Fluid pressure to servo but band not applied due to pressure difference in servo.
 ⊙ : Does not transmit power.

FLUID PASSAGE LOCATIONS
Transaxle Case




Clutch Housing



03U0KX-009


Oil Pump



03U0KX-010

ELECTRONIC CONTROL SYSTEM COMPONENTS

SYSTEM DIAGRAM




COMPONENT DESCRIPTIONS

| Part name | | Function |
|--------------------|--|--|
| EC-AT control unit | | Regulates shift points and lockup points according to signals from various sensors; sends ON/OFF signals to solenoid valves |
| Input | Pulse generator | Detects reverse and forward drum revolution speed |
| | Vehicle speed sensor | Detects vehicle speed |
| | Throttle sensor | Detects amount of throttle valve opening |
| | Idle switch | Detects throttle valve fully-closed position |
| | Inhibitor switch | Detects position (range) of gear selector |
| | Hold switch | Sets Hold mode |
| | Stoplight switch | Detects use of service brakes |
| | Water thermo signal | Indicates engine coolant temperature |
| | ATF thermostwitch | Detects automatic transaxle fluid temperature |
| Output | Solenoid valve | Switched ON/OFF by electrical signals from EC-AT control unit; regulates shifting and lockup actuation by switching oil passages |
| | 1-2 | For 1-2 shift (1st gear → 2nd gear: OFF-ON) |
| | 2-3 | For 2-3 shift (2nd gear → 3rd gear: ON-OFF) |
| | 3-4 | For 3-4 shift (3rd gear → OD: OFF-ON) |
| | Lockup | For lockup (lockup at ON) |
| Hold indicator | Illuminates when Hold mode selected Flashes when malfunction detected as result of self-diagnosis | |
| No load signal | Send no load signal (P and N ranges) to engine control unit | |


03U0K2-009

ELECTRICAL CIRCUIT

1990 323 4WD (G4AX-EL)



1990 323 (F4A-EL)



SOLENOID VALVE OPERATION TABLE


| RANGE | GEAR | | SOLENOID VALVES | | | | | | | | | |
|-------|---------|---|---|-----|-----|--------|--------------|-----|-----|--------|----|--|
| | | | 1990 323 2WD | | | | 1990 323 4WD | | | | | |
| | | | 1-2 | 2-3 | 3-4 | Lockup | 1-2 | 2-3 | 3-4 | Lockup | | |
| P | — | | | | ON | | | | ON | | | |
| R | Reverse | | ON | | | | | ON | | | | |
| N | — | Below approx. 4 km/h (2.5 mph) | | | ON | | | | | ON | | |
| | | Above approx. 5 km/h (3.1 mph) | ON | | | | | ON | | | | |
| D | 1st | | | ON | ON | | | | ON | ON | | |
| | 2nd | | ON | ON | ON | | | ON | ON | ON | | |
| | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | | | | | | |
| | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | | | ON | | | |
| | OD | Lockup OFF | ON | | | ON | | | ON | | ON | |
| | | Lockup ON | ON | | | ON | ON | | ON | | ON | |
| S | 1st | | | ON | ON | | | | ON | ON | | |
| | 2nd | | ON | ON | ON | | | ON | ON | ON | | |
| | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | | | | | | |
| | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | | | ON | | | |
| | | Lockup OFF | | | | | | | ON | | | |
| | | Lockup ON | | | | | | | ON | | ON | |
| | OD | | ON | | | ON | | ON | | ON | | |
| L | 1st | | | ON | ON | | | | ON | ON | | |
| | 2nd | Below approx. 110 km/h (68 mph) | ON | ON | | | | ON | ON | | | |
| | | Above approx. 110 km/h (68 mph) | ON | | | | | ON | | | | |
| HOLD | D | 1st | | | ON | ON | | | | — | | |
| | | 2nd | | ON | ON | ON | | | ON | ON | ON | |
| | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | | | | | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | | | ON | | |
| | | OD | | ON | | | ON | | | | — | |
| | | 2nd | | ON | ON | | | | ON | ON | | |
| | S | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | | | | | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | | ON | | | |
| | | OD | | ON | | | ON | | | | — | |
| | | 1st | | | ON | | | | | ON | | |
| | L | 2nd | Below approx. 110 km/h (68 mph) | ON | ON | | | | ON | ON | | |
| | | | Above approx. 110 km/h (68 mph) | ON | | | | | ON | | | |

03U0K2-011

SELF-DIAGNOSIS SYSTEM

The EC-AT control unit has built-in self-diagnosis, fail-safe, and warning code display function for the main input sensors and all of the output solenoid valves.

SELF-DIAGNOSIS FUNCTION



03U0K2-012

If a malfunction occurs in any of the EC-AT system components described below, the HOLD indicator flashes to warn the driver of the malfunction.

- Vehicle speed sensor.
- Throttle sensor.
- Pulse generator.
- 1-2 shift solenoid valve.
- 2-3 shift solenoid valve.
- 3-4 shift solenoid valve.
- Lockup solenoid valve.

If a condition, as shown in the table below, exists, the EC-AT control unit judges that the component has a malfunction.

| Component | Conditions for judgement of malfunction |
|----------------------|--|
| Vehicle speed sensor | No input signal from speed sensor while driving at drum speed above 600 rpm in D, S, or L range |
| Throttle sensor | Open circuit when accelerator pedal depressed (idle switch: OFF) or incorrect adjustment |
| Pulse generator | No input signal from pulse generator while driving at 40 km/h (25 mph) or higher in D, S, or L range |
| Solenoid valve | Open or short-circuit of transistor within EC-AT control unit or solenoid valve wire harness |

03U0K2-013

FAIL-SAFE FUNCTION

If a malfunction occurs in any of the following components, the fail-safe function makes it possible to drive the vehicle with only slightly diminished performance. Hold mode cannot be selected while driving in the fail-safe mode.

1. Vehicle speed sensor
Shifting is performed normally. If the pulse generator or a solenoid valve also fails, operation of all solenoid valves is canceled.
2. Throttle sensor
The EC-AT control unit considers the throttle opening to be at 4/8 stroke. Shifting is performed in accordance with signals from the vehicle speed sensor and the shift pattern for that fail-safe mode. Lockup is not provided.
3. Pulse generator
Shifting is performed in accordance with signals from the vehicle speed sensor and the shift pattern for that fail-safe mode. If a malfunction occurs at one of the solenoid valves along with a malfunction of the pulse generator, the operation of the malfunctioning valve is canceled.
4. 1-2, 2-3, or 3-4 solenoid valve
The operation of the remaining solenoid valve(s) performs the shifting with as little interference as possible with driving performance. If a malfunction occurs at all four solenoid valves, 3rd, 1st and reverse gears are obtained hydraulically.

Note

- If all solenoid valves are switched OFF, D and S ranges become 3rd gear position, L range becomes 1st gear position, and R range remains reverse gear position.

5. Lockup solenoid valve
The solenoid valves for shifting operate normally but no lockup is obtained.

03U0K2-014

DISPLAY OF MALFUNCTION CODE


If a malfunction occurs in components which the EC-AT control unit can diagnose, the control unit causes the HOLD indicator to flash while the malfunction is continuing. At the same time, the control unit memorizes the code of the malfunction for later retrieval with the **EC-AT Tester** and **System Selector**.

The flashing of the HOLD indicator ceases if the malfunction recovers.

When the TAT and GND terminals of the diagnosis connector are jumped with the ignition switch ON, the EC-AT control unit outputs any memorized malfunction codes by flashing the HOLD indicator.

The **EC-AT Tester** with **System Selector** will display these codes as malfunction code numbers when connected to the diagnosis connector.

If there is more than one malfunction, the code numbers are displayed sequentially in numerical order.



03U0K2-015

Malfunction Code Table

The following table shows representative malfunction code numbers and code patterns.

| Malfunction | Code No. | Code pattern (HOLD indicator) |
|--------------------------|----------|-------------------------------|
| Vehicle speed sensor | 06 | |
| Throttle sensor | 12 | |
| Pulse generator | 55 | |
| 1-2 shift solenoid valve | 60 | |
| 2-3 shift solenoid valve | 61 | |
| 2-3 shift solenoid valve | 62 | |
| Lockup solenoid valve | 63 | |

03U0K2-016

Note

- The memory of a malfunction can be canceled by disconnecting the negative battery terminal and depressing the brake pedal for approximately 5 seconds.

SHIFT CONTROL

SHIFT PATTERN

| Range | Gear | Gear ratio | Normal mode | | | Hold mode | | | |
|-------|------|------------|-------------|--------|----------------|-----------|--------|----------------|---|
| | | | Shift | Lockup | Engine braking | Shift | Lockup | Engine braking | |
| | P | — | | | | | | | |
| | R | Reverse | 2.333 | | | X | | | X |
| | N | — | | | | | | | |
| | D | 1st | 2.800 | ⇕ | | | ⇕ | | |
| | | 2nd | 1.540 | ⇕ | | | ⇕ | | |
| | | 3rd | 1.000 | ⇕ | X | X | ⇕ | X | X |
| | | OD | 0.700 | ⇕ | X | X | ⇕ | | X |
| | S | 1st | 2.800 | ⇕ | | | | | |
| | | 2nd | 1.540 | ⇕ | | | ⇕ | | X |
| | | 3rd | 1.000 | ⇕ | X | X | ⇕ | X | X |
| | | OD | 0.700 | ⇕ | | X | ⇕ | | X |
| | L | 1st | 2.800 | ⇕ | | | | X | |
| | | 2nd | 1.540 | ⇕ | | X | ⇕ | | X |

⇕⇕: Will not shift unless selector button depressed.

⇕⇓: Will shift without selector button depressed.

⇕: Directions of possible shift.

X: Lockup or engine braking possible.

03U0K2-017

HIGH ATF TEMPERATURE DETERMINATION

The ATF thermosensor sends "high-fluid-temperature" signals to the EC-AT control unit if the temperature of the ATF exceeds 128°C (262°F).

The EC-AT control unit then changes the lockup point (lower speed), available gear, and shift point (higher speed) without regard to coolant signals. The shift pattern is as shown below.

This function does not effect R or L range.

Shift Pattern at High ATF Temperature

| Range | Gear | Gear ratio | Normal mode | | | Hold mode | | |
|-------|---------|------------|-------------|--------|----------------|-----------|--------|----------------|
| | | | Shift | Lockup | Engine braking | Shift | Lockup | Engine braking |
| P | — | — | | | | | | |
| R | Reverse | 2.333 | | | X | | | X |
| N | — | — | | | | | | |
| D | 1st | 2.800 | ↕ | | | ↕ | | |
| | 2nd | 1.540 | ↕ | | | ↕ | | |
| | 3rd | 1.000 | ↕ | X | X | ↑ | X | X |
| | OD | 0.700 | ↕ | X | X | ↑ | X | X |
| S | 1st | 2.800 | ↕ | | | | | |
| | 2nd | 1.540 | ↕ | | | ↑ | | X |
| | 3rd | 1.000 | ↑ | X | X | ↑ | | X |
| | OD | 0.700 | ↑ | X | X | ↑ | | X |
| L | 1st | 2.800 | ↕ | | | ↑ | | X |
| | 2nd | 1.540 | ↕ | | X | ↑ | | X |

‡: Directions of possible shift.

X: Lockup or engine braking possible.

03U0K2-018


TROUBLESHOOTING GUIDE

GENERAL NOTES

A problem with the EC-AT may be caused by the engine, the EC-AT powertrain, the hydraulic control system, or the electronic control system.

When troubleshooting, therefore, begin with those points which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.

03U0KX-011




03U0K2-019

Step 1: Self-diagnosis Function

Check for malfunction code(s) memorized in the EC-AT control unit with the **EC-AT Tester**. (Refer to page K2-104.)

Note

- Malfunction code(s) can also be checked for by the flashing sequence of the HOLD indicator lamp. (Refer to page K2-108.)




03U0K2-020

Step 2: Electric Signal Inspection

Check the signals to/from the EC-AT control unit with the **EC-AT Tester**. (Refer to page K2-144.)

Note


- Signals can also be checked by checking the EC-AT control unit terminal voltages with a voltmeter. (Refer to page K2-115.)



03U0K2-021

Step 3: Mechanical System Test

Check the engine stall speed, time lag, line pressure, and throttle pressure. (Refer to page K2-119.)



03U0K2-022

Step 4: Road Test

Note

- For correct testing, vehicle speed, engine speed, throttle opening (throttle sensor voltage), and gear position should be checked with the **EC-AT Tester**.

Check the shift point, shift schedule, and shift shock. (Refer to page K2-127.)

If the 4 steps on page K2-16 are followed, the cause of the problem should be located. Another guide to faster location of the causes of problems, the QUICK DIAGNOSIS CHART, is on pages K2-17 through 19.

In this chart, numbers are used to indicate the components that may be the cause of 24 possible problems. It is necessary to check only those components indicated by numbers during each step of the troubleshooting process to locate the cause of the problem quickly.

QUICK DIAGNOSIS CHART

The Quick Diagnosis Chart shows various problems and the relationship of various components that might be the cause of the problem.

1. Components indicated in the "Self-Diag." column are diagnosed by the EC-AT control unit self-diagnosis function.

The **EC-AT Tester** can be used for easy retrieval of these signals.

2. Components indicated in the "Adjustment" column indicate that there is a possibility that the problem may be the result of an incorrect adjustment.

Check the adjustment of each component, and readjust if necessary.

3. Input and output signals of the EC-AT control unit for the components indicated in the "EC-AT TESTER" column can be easily checked by using of the **EC-AT Tester**.

4. Components indicated in the "Stall Test" column can be checked for malfunction by the results of the stall test.

5. Components indicated in the "Time Lag Test" column can be checked for malfunction by the results of the time lag test.

6. Components indicated in the "Oil Pressure Test" column can be checked for malfunction by the results of the oil pressure test.

7. Components indicated in the "Road Test" column can be checked for malfunction by the results of the road test.

8. The checking, adjusting, repair or replacement procedures for each component is described in the page(s) noted in the "Reference Page" column.

03U0K2-023

| Item | Inspection point and reference page | Preliminary | | Electronic control system | | | | | | | | | | | | Hydraulic control system | | | | Power train | | | | | | | | | | | | | | | | | | | | |
|--------------------------------|-------------------------------------|-------------|--------|---------------------------|------------|------------|--------|--------|------------|------------|--------|------------|--------|--------|--------|--------------------------|--------|--------|--------|-------------|--------|------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--|--|--|
| | | K2-134 | *K-264 | K2-137 | *Section F | *Section T | K2-140 | K2-140 | *Section F | *Section F | K2-145 | *Section T | K2-142 | K2-143 | K2-143 | K2-143 | K2-143 | K2-143 | K2-142 | K2-197 | K2-209 | K2-200,209 | K2-168 | K2-281 | K2-167 | K2-173 | K2-173 | K2-173 | K2-173 | K2-187 | K2-197 | K2-192 | K2-185 | K2-182 | K2-164 | K2-185 | K2-239 | | | |
| ATF level and condition | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Selector lever | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Throttle cable | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Idle speed and ignition timing | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Stoplight switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Inhibitor switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hold switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Idle switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Throttle sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Water thermo signal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Vehicle speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pulse generator | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1-2 solenoid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2-3 solenoid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3-4 solenoid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lockup solenoid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ATF thermostat | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Band servo (2-4 brake band) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Control valves | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Accumulators | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Oil pump | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hydraulic circuit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Torque converter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Forward clutch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Coasting clutch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reverse clutch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3-4 clutch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2-4 brake band | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Low and reverse brake | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| One-way clutch 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| One-way clutch 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Parking gear | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Planetary gear | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Differential assembly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).

OFF-VEHICLE

| Hydraulic control system | | Powertrain | | | | | | | | | | Inspection point and reference page | Item | | | | | |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|-------------------------------------|--------------------------|---|----|--------------|--------|--|
| K2-168 | *K-270 | K2-167 | K2-173 | K2-173 | K2-173 | K2-187 | K2-197 | K2-192 | K2-185 | K2-182 | K2-164 | | | | | K2-185 | K2-239 | |
| Oil pump | Hydraulic circuit | Torque converter | Forward clutch | Coasting clutch | Reverse clutch | 3-4 clutch | 2-4 brake band | Low and reverse brake | One-way clutch 1 | One-way clutch 2 | Parking gear | Planetary gear | Differential assembly | | | | | |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | Vehicle does not move in D, S, L, and R ranges | 1 | Accelerating | | |
| <input type="checkbox"/> | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | Vehicle moves in N range | 2 | | | |
| | | | | | | | | | | | <input type="checkbox"/> | | | Vehicle moves in P range or parking gear not disengaged when P disengaged | 3 | | | |
| | | | | | | | | | | | | | | Excessive creep | 4 | | | |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | No creep at all | 5 | | | |
| <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | | No shift | 6 | Shifting | | |
| | <input type="checkbox"/> | | | | | | | | | | | | | Abnormal shift | 7 | | | |
| | <input type="checkbox"/> | | | | | | | | | | | | | Frequent shifting | 8 | | | |
| | <input type="checkbox"/> | | | | | | | | | | | | | Shift point high or low | 9 | | | |
| | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | No lockup | 10 | | | |
| | | | | | | | | | | | | | | No kickdown | 11 | | | |
| <input type="checkbox"/> | | | <input type="checkbox"/> | | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | Engine flares up or slips when accelerating vehicle | 12 | Slipping | | |
| <input type="checkbox"/> | <input type="checkbox"/> | | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | | | | Engine flares up or slips when upshifting or downshifting | 13 | | | |
| | <input type="checkbox"/> | | | | | | | | | | | | | Excessive N to R or N to D range shift shock | 14 | Shift shock | | |
| | <input type="checkbox"/> | | | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | Excessive shift shock when upshifting and downshifting | 15 | | | |
| <input type="checkbox"/> | | <input type="checkbox"/> | | | | | | | | | | | | Transaxle noisy in N or P ranges | 16 | Noise | | |
| <input type="checkbox"/> | | <input type="checkbox"/> | | | | | | | | | | <input type="checkbox"/> | <input type="checkbox"/> | Transaxle noisy in D, S, L, and R ranges | 17 | | | |
| | <input type="checkbox"/> | | | <input type="checkbox"/> | | | | | | | | | | No engine braking | 18 | Others | | |
| | | | | | | | | | | | | | | No mode changes | 19 | | | |
| <input type="checkbox"/> | | <input type="checkbox"/> | | | | | | | | | | | | Transaxle overheats | 20 | | | |
| | | | | | | | | | | | | | | Hold indicator lamp flashes | 21 | | | |
| | | | | | | | | | | | | | | Engine will not start in N or P ranges or will start in other ranges | 22 | | | |
| | | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | Engine stalls when shifted to D, S, L, and R ranges | 23 | | | |
| | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | Engine stalls when brake pedal depressed while driving at low speed or stopping | 24 | | | |


* Refer to 1990 323 Workshop Manual (1195-10-89E).

USING THIS SECTION

Introduction

Most of the automatic transaxle control system is electrically controlled, often making it difficult to diagnose problems in the system, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially intermittent ones. Through talks with the customer, one can find out what the symptoms are and under what conditions they occur.

Work Flow



03U0KX-019

Diagnostic Index

No.:

Each troubleshooting item is assigned a number.

Description:

Describes each troubleshooting item.

Page:

Shows the reference page.

| K2 TROUBLESHOOTING GUIDE | | | | | |
|--------------------------|----------------|--|--|-------|-------|
| ITEM | No | TROUBLE | DESCRIPTION | PAGE | |
| Accelerating | 1 | Vehicle does not move in D, S, L, and R ranges. | | K2-28 | |
| | 2 | Vehicle moves in M range. | | K2-30 | |
| | 3 | Vehicle moves in P range or parking gear not disengaged when P disengaged. | | K2-31 | |
| | 4 | Excessive creep | Creep occurs in D, S, L, and R ranges. | K2-32 | |
| | 5 | No creep at all | Creep occurs in D, S, L, and R ranges. | K2-33 | |
| Shifting | 6 | No shift | Shift schedule is as follows: D range: Normal mode: 1st-2nd-3rd-OD Hold mode: 1st-2nd-3rd-OD S range: Normal mode: 1st-2nd-3rd-OD Hold mode: 3rd-3rd-OD L range: Normal mode: 1st-2nd Hold mode: 1st-2nd | K2-35 | |
| | 7 | Abnormal shift | Shift schedule is as follows: D range: Normal mode: 1st-2nd-3rd-OD Hold mode: 1st-2nd-3rd-OD S range: Normal mode: 1st-2nd-3rd-OD Hold mode: 2nd-3rd-OD L mode: Normal mode: 1st-2nd Hold mode: 1st-2nd | K2-41 | |
| | 8 | Frequent shifting | | K2-47 | |
| | 9 | Shift point high or low | Refer to page K2-132 for vehicle speed or engine load | K2-49 | |
| | 10 | No lockup | Lockup available in following: D range (Normal mode), SO D range (Hold mode), 3rd S range (Normal mode), 3rd S range (Hold mode), 3rd | K2-53 | |
| | 11 | No kickdown | | K2-61 | |
| | Stalling | 12 | Engine flares up or slips when accelerating vehicle | | K2-65 |
| | | 13 | Engine flares up or slips when upshifting or downshifting | | K2-67 |
| | Shifting shock | 14 | Excessive shock in M or H to D range shift | | K2-69 |
| | | 15 | Excessive shift shock when upshifting and downshifting | | K2-72 |
| Noise | 16 | Transaxle noisy in N and P ranges | | K2-75 | |
| | 17 | Transaxle noisy in D, S, L, and R ranges | | K2-77 | |

Troubleshooting Item:

There are 24 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

03U0KX-020

Troubleshooting chart

| | | | | | |
|--|---|---------------|---|---|---|
| 1 | VEHICLE DOES NOT MOVE IN D, S, L, AND R RANGES | | | | |
| DESCRIPTION | • Vehicle does not move when accelerator depressed, engine speed increases | | | | |
| [TROUBLESHOOTING HINTS] | | | | | |
| <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;"> ① ATF level low ② Selector lever installation or adjustment incorrect ③ Powertrain slippage (Forward clutch, one-way clutch 1, one-way clutch 2, low and reverse brake or reverse clutch) ④ Control valve stuck (Manual valve or pressure regulator valve) </td> <td style="width: 50%; border: none;"> ⑤ Oil pump worn ⑥ Torque converter worn ⑦ Hydraulic circuit clogged or leaking (Forward clutch, reverse clutch or low and reverse brake) ⑧ Parking mechanism malfunction </td> </tr> </table> | | | | ① ATF level low ② Selector lever installation or adjustment incorrect ③ Powertrain slippage (Forward clutch, one-way clutch 1, one-way clutch 2, low and reverse brake or reverse clutch) ④ Control valve stuck (Manual valve or pressure regulator valve) | ⑤ Oil pump worn ⑥ Torque converter worn ⑦ Hydraulic circuit clogged or leaking (Forward clutch, reverse clutch or low and reverse brake) ⑧ Parking mechanism malfunction |
| ① ATF level low ② Selector lever installation or adjustment incorrect ③ Powertrain slippage (Forward clutch, one-way clutch 1, one-way clutch 2, low and reverse brake or reverse clutch) ④ Control valve stuck (Manual valve or pressure regulator valve) | ⑤ Oil pump worn ⑥ Torque converter worn ⑦ Hydraulic circuit clogged or leaking (Forward clutch, reverse clutch or low and reverse brake) ⑧ Parking mechanism malfunction | | | | |
| STEP | INSPECTION | Yes/No | ACTION | | |
| 1 | Check if ATF level is OK <div style="text-align: right;">☞ page K2-134</div> Level: Between notches on HOT side of level gauge at 65°C (149°F) | Yes | Go to next step | | |
| | | No | Add ATF to specified level <div style="text-align: right;">☞ page K2-134</div> | | |

05U0FX-021

DESCRIPTION:

Further describes the symptom. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page shown by the "☞" mark.

ACTION:

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page shown by the "☞" mark.




03U0KX-022

| TROUBLESHOOTING ITEM | | | DESCRIPTION | PAGE |
|----------------------|----|---|--|-------|
| ITEM | No | TROUBLE | | |
| Accelerating | 1 | Vehicle does not move in D, S, L, and R ranges | | K2-28 |
| | 2 | Vehicle moves in N range | | K2-30 |
| | 3 | Vehicle moves in P range or parking gear not disengaged when P disengaged | | K2-31 |
| | 4 | Excessive creep | Creep occurs in D, S, L, and R ranges | K2-32 |
| | 5 | No creep at all | Creep occurs in D, S, L, and R ranges | K2-33 |
| Shifting | 6 | No shift | Shift schedule is as follows: D range Normal mode: 1st↔2nd↔3rd↔OD Hold mode: 1st↔2nd↔3rd(←OD) S range Normal mode: 1st↔2nd↔3rd(←OD) Hold mode: 2nd(←3rd)(←OD) L range Normal mode: 1st↔2nd Hold mode: 1st(←2nd) | K2-35 |
| | 7 | Abnormal shift | Shift schedule is as follows: D range Normal mode: 1st↔2nd↔3rd↔OD Hold mode: 1st↔2nd↔3rd(←OD) S range Normal mode: 1st↔2nd↔3rd(←OD) Hold mode: 2nd(←3rd)(←OD) L range Normal mode: 1st↔2nd Hold mode: 1st(←2nd) | K2-41 |
| | 8 | Frequent shifting | | K2-47 |
| | 9 | Shift point high or low | Refer to page K2-132 for vehicle speed at shiftpoint table | K2-49 |
| | 10 | No lockup | Lockup available as follows: D range (Normal mode): OD D range (Hold mode): 3rd S range (Normal mode): 3rd S range (Hold mode): 3rd | K2-53 |
| | 11 | No kickdown | | K2-61 |
| Slipping | 12 | Engine flares up or slips when accelerating vehicle | | K2-65 |
| | 13 | Engine flares up or slips when upshifting or downshifting | | K2-67 |
| Shifting shock | 14 | Excessive N to R or N to D range shift shock | | K2-69 |
| | 15 | Excessive shift shock when upshifting and downshifting | | K2-72 |
| Noise | 16 | Transaxle noisy in N and P ranges | | K2-75 |
| | 17 | Transaxle noisy in D, S, L, and R ranges | | K2-77 |


| TROUBLESHOOTING ITEM | | | DESCRIPTION | PAGE |
|----------------------|----|---|--|--------|
| ITEM | No | TROUBLE | | |
| Others | 18 | No engine braking | Engine braking is available as follows: D range Normal mode: 3rd, OD Hold mode: 3rd, (OD) S range Normal mode: 3rd, (OD) Hold mode: 2nd, (3rd), (OD) L range Normal mode: 2nd Hold mode: 1st, (2nd) | K2-79 |
| | 19 | No mode changes | | K2-83 |
| | 20 | Transaxle overheats | | K2-88 |
| | 21 | Hold indicator lamp flashes | Hold indicator flashes if a malfunction occurs of any of components as follows: <ul style="list-style-type: none"> • Vehicle speed sensor • Throttle sensor • Pulse generator • Solenoid valves (1-2, 2-3, 3-4, or lockup) | K2-92 |
| | 22 | Engine will not start in N or P ranges or will start in other ranges | | K2-93 |
| | 23 | Engine stalls when shifted to D, S, L, and R ranges | Engine will start and run in P, or N ranges | K2-95 |
| | 24 | Engine stalls when brake pedal depressed while driving at low speed or stopping | | K2-100 |

03U0K2-026



SYMPTOM TROUBLESHOOTING

| 1 | VEHICLE DOES NOT MOVE IN D, S, L, AND R RANGES | | | | | |
|---|---|--|-----|-----------------|----|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle does not move when accelerator depressed, engine speed increases | | | | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① ATF level low ② Selector lever installation or adjustment incorrect ③ Powertrain slippage (Forward clutch, one-way clutch 1, one-way clutch 2, low and reverse brake or reverse clutch) ④ Control valve stuck (Manual valve or pressure regulator valve) ⑤ Oil pump worn ⑥ Torque converter worn ⑦ Hydraulic circuit clogged or leaking (Forward clutch, reverse clutch or low and reverse brake) ⑧ Parking mechanism malfunction | | | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F)  | <table border="0"> <tr> <td data-bbox="769 539 784 769">Yes</td> <td data-bbox="784 539 1414 769">Go to next step</td> </tr> <tr> <td data-bbox="769 769 784 990">No</td> <td data-bbox="784 769 1414 990">Add ATF to specified level ☞ page K2-134</td> </tr> </table> | Yes | Go to next step | No | Add ATF to specified level ☞ page K2-134 |
| Yes | Go to next step | | | | | |
| No | Add ATF to specified level ☞ page K2-134 | | | | | |
| 2 | Check if ATF condition is OK ☞ page K2-134 <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid  | <table border="0"> <tr> <td data-bbox="769 990 784 1294">Yes</td> <td data-bbox="784 990 1414 1294">Go to next step</td> </tr> <tr> <td data-bbox="769 1294 784 1597">No</td> <td data-bbox="784 1294 1414 1597"> No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 </td> </tr> </table> | Yes | Go to next step | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |
| Yes | Go to next step | | | | | |
| No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 | | | | | |
| 3 | Check if selector lever operation is OK ☞ page *K-264  | <table border="0"> <tr> <td data-bbox="769 1597 784 1765">Yes</td> <td data-bbox="784 1597 1414 1765">Go to next step</td> </tr> <tr> <td data-bbox="769 1765 784 1917">No</td> <td data-bbox="784 1765 1414 1917">Adjust or repair selector lever ☞ page *K-264</td> </tr> </table> | Yes | Go to next step | No | Adjust or repair selector lever ☞ page *K-264 |
| Yes | Go to next step | | | | | |
| No | Adjust or repair selector lever ☞ page *K-264 | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|--|-------------------------------------|---|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 4 | Set selector lever in P range with vehicle on a gentle slope, release brakes, and check if vehicle rolls  | Yes | Check parking mechanism ⇒ If OK, go to next step ⇒ If not OK, repair or replace parking mechanism | | | | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | | | | | |
| 5 | Check if line pressure and throttle pressure are within specification ☞ page K2-123 125 Line pressure: <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> Throttle pressure: <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| | | | Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | |
| Idle | Stall | | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| No | Check for cause (Refer to evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | | | |
| 6 | Try known good control valve body assembly or replace transaxle | | | | | | | | | | | | | | | | | | | | | |

03U0K2-027



| 2 | VEHICLE MOVES IN N RANGE | | |
|--|---|-----|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle creeps at idle and shifts normally when accelerator depressed | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① Selector lever installation or adjustment incorrect ② Powertrain slippage (Forward clutch or coasting clutch) ③ Control valve stuck (Manual valve) ④ Hydraulic circuit clogged or leaking (Forward clutch or coasting clutch) | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check if selector lever operation is OK ☞ page *K-264  | Yes | Go to next step |
| | | No | Adjust or repair selector lever ☞ page *K-264 |
| 2 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |
| 3 | Try known good EC-AT control unit, control valve body assembly, or replace transaxle | | |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

03U0K2-028




| 3 VEHICLE MOVES IN P RANGE OR PARKING GEAR NOT DISENGAGED WHEN P DISENGAGED | | |
|--|--|---|
| DESCRIP-TION | <ul style="list-style-type: none"> • Vehicle rolls in P range but does not accelerate when accelerator depressed • Vehicle will not move in D, S, L, and R ranges and engine in stall condition (Vehicle in stall condition) | |
| [TROUBLESHOOTING HINTS] | | |
| ① Selector lever installation or adjustment incorrect ② Parking mechanism malfunction | | |
| STEP | INSPECTION | ACTION |
| 1 | Check if selector lever operation is OK ☞ page *K-264  | Yes Go to next step |
| | | No Adjust or repair selector lever ☞ page *K-264 |
| 2 | Set selector lever in P range with vehicle on a gentle slope, release brakes, and check if vehicle rolls  | Yes Check parking mechanism ☞ If OK, go to next step. ☞ If not OK, repair or replace parking mechanism |
| | | No Go to next step |
| 3 | Rebuild or replace transaxle | |



* Refer to 1990 323 Workshop Manual (1195-10-89E).



| 5 | NO CREEP AT ALL | | |
|--|---|--------|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle does not move in D, S, L, and R ranges when idling • Road condition: flat paved road <p>Note</p> <ul style="list-style-type: none"> • S range HOLD mode creep reduced because transaxle in 2nd gear position | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Powertrain slippage (Forward clutch, reverse clutch, low and reverse brake, one-way clutch 1 or one-way clutch 2) ③ Control valve stuck (Pressure regulator valve or manual valve) ④ Oil pump worn ⑤ Torque converter worn ⑥ Hydraulic circuit clogged or leaking (Forward clutch, reverse clutch, low and reverse brake, one-way clutch 1 or one-way clutch 2) | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Check if ATF level is OK ☞ page K2-134 <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p> <div style="text-align: center;">  <p>The diagram shows a horizontal level gauge with two notches. The right side is labeled 'HOT RANGE' and has temperature markers for 20°C and 65°C. The left side is labeled 'COOL RANGE'.</p> </div> | Yes | Go to next step |
| | | No | Add ATF to specified level ☞ page K2-134 |
| 2 | Check if ATF condition is OK ☞ page K2-134 <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid <div style="text-align: center;">  <p>The illustration shows two mechanics in caps and work clothes. One is holding a dipstick and looking at it, while the other stands behind him, also looking at the dipstick.</p> </div> | Yes | Go to next step |
| | | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |






| STEP | INSPECTION | | ACTION | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-----|-----------------|
| 3 | Check if ignition timing at idle is OK ☞ page *F-72 Ignition timing (BTDC): 7 ± 1°  | Yes | Check for correct idle speed ☞ page *F-72 Idle speed: 750 ± 50 rpm (with parking brake applied) ⇒ If OK, go to next step ⇒ If not OK, adjust idle speed ☞ page *F-72 | | | | | | | | | | | |
| 4 | Check if selector lever operation is OK ☞ page *K-264  | Yes | Go to next step | | | | | | | | | | | |
| 5 | Check if throttle cable operates smoothly and is installed correctly ☞ page K2-137  | Yes | Go to next step | | | | | | | | | | | |
| 6 | Check if line pressure at idle is OK ☞ page K2-123 Line pressure: <table border="1" data-bbox="164 1448 682 1636"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | |
| 7 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm | Yes | Go to next step | | | | | | | | | | | |
| 8 | Rebuild or replace transaxle | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | | | | | | | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).



| 6 | NO SHIFT | |
|---|---|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • Vehicle upshifts and downshifts in HOLD mode forward ranges only | |
| <p>[TROUBLESHOOTING HINTS]</p> <ol style="list-style-type: none"> ATF level low Hold switch circuit shorted Throttle sensor malfunction or misadjustment Pulse generator malfunction Shift solenoid valve stuck (1-2, 2-3, or 3-4) Control valve stuck (Pressure regulator valve, 1-2 shift valve, 2-3 shift valve, 3-4 shift valve, or manual valve) Oil pump worn Hydraulic circuit clogged or leaking | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Check if ATF level is OK ☞ page K2-134</p> <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p> <div style="text-align: center;">  <p>HOT RANGE</p> <p>20°C 65°C</p> <p>COOL RANGE</p> </div> | <p>Yes Go to next step</p> <p>No Add ATF to specified level ☞ page K2-134</p> |
| 2 | <p>Check if ATF condition is OK ☞ page K2-134</p> <ol style="list-style-type: none"> Clear pink: Normal condition Dark or black (with friction material): Worn powertrain components Milky pink: Water contamination Light to dark brown (Oxidation): Overheated or old fluid <div style="text-align: center;">  </div> | <p>Yes Go to next step</p> <p>No No.2 condition Overhaul transaxle and repair or replace parts as necessary ☞ page K2-134 No.3 or No.4 condition Replace ATF</p> |
| 3 | <p>Check if "00" is displayed on EC-AT Tester with ignition switch ON ☞ page K2-106</p> <div style="text-align: center;">  <p>49 B019 9A0</p> </div> | <p>Yes Go to next step</p> <p>No Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108</p> <p>No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit</p> <p>Voltage: Approx. 12V (Ignition switch ON)</p> <p>"88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector</p> <p>⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring</p> |


| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially hold switch, solenoid valves, throttle sensor voltage, and drum speed) | Yes | Go to Steps 6, 12, 14, 17, 20, 21 and 22 in sequence |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ☞ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | Yes | Go to next step |
| | | No | Repair wiring |
| 6 | Disconnect solenoid valve connector and check if vehicle is driven as follows: R range: Reverse D and S ranges: 3rd L range: 1st Note • Engine rpm at 40 km/h (25 mph) 1st gear: 3,950 rpm 3rd gear: 1,400 rpm | Yes | Go to next step |
| | | No | Overhaul transaxle and repair or replace any faulty parts ☞ page K2-152 |
| 7 | Check if voltage at 2E, 2G, or 2I terminals of EC-AT control unit is OK ☞ page K2-144 Voltage: Approx. 12V (When solenoid valve ON)  | Yes | Go to Step 9 |
| | | No | Go to next step |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | |
|----------------|--|----------------|--|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|-----|-----------------|
| 8 | <p>Check if continuity of transistors of EC-AT control unit is OK</p> <table border="1" data-bbox="239 252 766 399"> <thead> <tr> <th>Solenoid valve</th> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | Yes | Go to next step |
| Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | |
| | | No | Replace EC-AT control unit | | | | | | | | | | | | |
| 9 | <p>Check if resistance between 2E, 2G, and 2I terminals of EC-AT control unit and ground is OK</p> <p>Resistance: 13—27Ω</p> | Yes | Go to Step 11 | | | | | | | | | | | | |
| |  | No | Go to next step | | | | | | | | | | | | |
| 10 | <p>Check if resistance of solenoid valves is OK</p> <p>☞ page K2-147</p> <p>Resistance: 13—27Ω</p> | Yes | <p>Check for poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> | | | | | | | | | | | | |
| |  | No | Replace solenoid valve | | | | | | | | | | | | |
| 11 | <p>Disconnect 20-pin connector of EC-AT control unit</p> <p>Apply 12V to 2E, 2G, and 2I terminals and check if operation sound (clicking) of solenoid is heard</p> | Yes | Try known good EC-AT control unit and go to next step | | | | | | | | | | | | |
| | | No | Replace solenoid valve | | | | | | | | | | | | |



| STEP | INSPECTION | ACTION | | | | | | |
|----------|--|--|-------------|----|------------------------|----|---|--|
| 12 | <p>Check if voltage at 2A and 2T terminals of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <table border="1" data-bbox="158 278 680 407"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table>  | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | <p>Yes: Go to Step 14</p> <p>No: Check for poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> |
| Terminal | Voltage (V) | | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | |
| 13 | <p>Check if throttle sensor is OK</p> <p style="text-align: right;">☞ page *F-143</p>  | <p>Yes: Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> <p>No: Adjust or replace throttle sensor ☞ page *F-143</p> | | | | | | |
| 14 | <p>Disconnect 20-pin connector of EC-AT control unit</p> <p>Check if resistance between 2J terminal and 2L terminal of EC-AT control unit is OK</p> <p>Resistance: 200—400Ω</p>  | <p>Yes: Go to Step 16</p> <p>No: Go to next step</p> | | | | | | |
| 15 | <p>Check if resistance of pulse generator is OK</p> <p style="text-align: right;">☞ page K2-142</p> <p>Resistance: 200—400Ω</p>  | <p>Yes: Check for poor connection at connectors and go to next step</p> <p>No: Replace pulse generator</p> | | | | | | |
| 16 | <p>Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit</p> <p>Check if pulse display is OK</p>  | <p>Yes: Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> <p>No: Very low voltage: Replace pulse generator</p> <p>Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator</p> | | | | | | |



* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | | ACTION | | | | | | | | | | |
|-----------------|---|-----------------|--|-----------|-----|----------------|-----|-----|--|-----------|----|-----|---|
| 17 | <p>Check if voltage at 1H terminal of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <p>Voltage: Approx. 12V (Hold switch released)</p>  | Yes | Go to Step 19 | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | |
| 18 | <p>Check if continuity between a terminal of hold switch and 1H terminal of EC-AT control unit is OK</p> | Yes | Go to next step | | | | | | | | | | |
| | | No | Repair wiring | | | | | | | | | | |
| 19 | <p>Check if operation of hold switch is OK</p> <p style="text-align: right;">☞ page K2-140</p> <table border="1" data-bbox="227 922 749 1015"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table>  | Switch | Continuity | Depressed | No | Released | Yes | Yes | <p>Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> | | | | |
| Switch | Continuity | | | | | | | | | | | | |
| Depressed | No | | | | | | | | | | | | |
| Released | Yes | | | | | | | | | | | | |
| | | No | Replace selector lever knob assembly | | | | | | | | | | |
| 20 | <p>Disconnect connectors from EC-AT control unit</p> <p>Apply 12V to solenoid valve terminals shown and check if vehicle drives in conditions below in D range</p> <table border="1" data-bbox="227 1471 749 1626"> <thead> <tr> <th>12V to terminal</th> <th>Vehicle condition</th> </tr> </thead> <tbody> <tr> <td>2G and 2I</td> <td>1st</td> </tr> <tr> <td>2E, 2G, and 2I</td> <td>2nd</td> </tr> <tr> <td>—</td> <td>3rd</td> </tr> <tr> <td>2E and 2I</td> <td>OD</td> </tr> </tbody> </table> <p style="text-align: right;">☞ page K2-144</p> | 12V to terminal | Vehicle condition | 2G and 2I | 1st | 2E, 2G, and 2I | 2nd | — | 3rd | 2E and 2I | OD | Yes | Try known-good EC-AT control unit and go to next step |
| 12V to terminal | Vehicle condition | | | | | | | | | | | | |
| 2G and 2I | 1st | | | | | | | | | | | | |
| 2E, 2G, and 2I | 2nd | | | | | | | | | | | | |
| — | 3rd | | | | | | | | | | | | |
| 2E and 2I | OD | | | | | | | | | | | | |
| | | No | Overhaul transaxle and check for cause ☞ page K2-152 | | | | | | | | | | |






| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|--|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 21 | <p>Check if engine stall speed is OK ☞ page K2-119</p> <p>Engine stall speed: 2,550—2,650 rpm</p> <div style="text-align: center;">  </div> | Yes | Go to next step | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | | | | | | | | | | | | | | | | | | | |
| 22 | <p>Check if line pressure and throttle pressure are within specification ☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="158 754 680 935"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="158 997 680 1123"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | |
| 23 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | | | | | | | | | | | | | | | | | | | | |

03U0K2-032




| 7 | ABNORMAL SHIFT | |
|--|---|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Abnormal shifting (ex. 1st → 3rd, 1st → OD) | |
| [TROUBLESHOOTING HINTS] | | |
| <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <ul style="list-style-type: none"> ① ATF level low ② Throttle sensor malfunction or misadjusted ③ Pulse generator malfunction ④ Hold switch circuit shorted ⑤ 2-4 brake band misadjusted </div> <div style="width: 45%;"> <ul style="list-style-type: none"> ⑥ Shift solenoid valves stuck (1-2, 2-3, or 3-4) ⑦ Control valve stuck (Pressure regulator valve, 1-2 shift valve, 2-3 shift valve, or 3-4 shift valve) ⑧ Hydraulic circuit clogged or leaking </div> </div> | | |
| STEP | INSPECTION | ACTION |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F) <div style="text-align: center;">  </div> | Yes: Go to next step No: Add ATF to specified level ☞ page K2-134 |
| 2 | Check if ATF condition is OK ☞ page K2-134 <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid <div style="text-align: center; margin-top: 20px;">  </div> | Yes: Go to next step No: <ul style="list-style-type: none"> No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |


| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 3 | Check if '00' is displayed on EC-AT Tester with ignition switch ON ➤ page K2-106  | Yes | Go to next step |
| | | No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ➤ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring |
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially hold switch, solenoid valves, throttle sensor voltage, and drum speed) | Yes | Go to Steps 6, 11, 13, 16, 19, 20 and 21 in sequence |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ➤ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | Yes | Go to next step |
| | | No | Repair wiring |
| 6 | Disconnect solenoid valve connector and check if vehicle is driven as follows: R range: Reverse D and S ranges: 3rd L range: 1st Note <ul style="list-style-type: none"> • Engine rpm at 40 km/h (25 mph) 1st gear: 3,950 rpm 3rd gear: 1,400 rpm | Yes | Go to next step |
| | | No | Overhaul transaxle and repair or replace any faulty parts ➤ page K2-152 |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | |
|----------------|--|----------------|---|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|----|----------------------------|
| 7 | Check if continuity of transistors of EC-AT control unit is OK | Yes | Go to next step | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Solenoid valve</th> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | No | Replace EC-AT control unit |
| Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | |
| 8 | Check if resistance between 2E, 2G, or 2I terminals of EC-At control unit and ground is OK | Yes | Go to Step 10 | | | | | | | | | | | | |
| | <p>Resistance: 13—27Ω</p>  | No | Go to next step | | | | | | | | | | | | |
| 9 | Check if resistance of solenoid valve is OK | Yes | Check for poor connection at connectors | | | | | | | | | | | | |
| | <p>Resistance: 13—27Ω</p> <p>☞ page K2-143</p>  | ☞ | If OK, go to next step If not OK, repair wiring | | | | | | | | | | | | |
| | | No | Replace solenoid valve | | | | | | | | | | | | |
| 10 | Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E, 2G, and 2I terminals and check if operation sound (clicking) of solenoid is heard | Yes | Try known good EC-AT control unit and go to next step | | | | | | | | | | | | |
| | | No | Replace solenoid valve | | | | | | | | | | | | |



| STEP | INSPECTION | | ACTION | | | | | | |
|----------|--|----------------------|---|----|------------------------|----|---|----------------------|--|
| 11 | <p>Check if voltage at 2A and 2T terminals of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <table border="1" data-bbox="156 276 677 409"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table>  | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | <p>Yes</p> <p>No</p> | <p>Go to Step 13</p> <p>Check for poor connection at connectors</p> <p>⇒ If OK, go to next step ⇒ If not OK, repair wiring</p> |
| Terminal | Voltage (V) | | | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | |
| 12 | <p>Check if throttle sensor is OK</p> <p style="text-align: right;">☞ page *F-143</p>  | <p>Yes</p> <p>No</p> | <p>Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step ⇒ If not OK, repair wiring</p> <p>Replace throttle sensor</p> | | | | | | |
| 13 | <p>Disconnect 20-pin connector of EC-AT control unit</p> <p>Check if resistance between 2J terminal and 2L terminal of EC-AT control unit is OK</p> <p>Resistance: 200—400Ω</p>  | <p>Yes</p> <p>No</p> | <p>Go to Step 15</p> <p>Go to next step</p> | | | | | | |
| 14 | <p>Check if resistance of pulse generator is OK</p> <p style="text-align: right;">☞ page K2-142</p> <p>Resistance: 200—400Ω</p>  | <p>Yes</p> <p>No</p> | <p>Check for poor connection at connectors and go to next step</p> <p>Replace pulse generator</p> | | | | | | |
| 15 | <p>Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit</p> <p>Check if pulse display is OK</p>  | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Very low voltage: Replace pulse generator</p> <p>Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator</p> | | | | | | |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION | | | | | | |
|-----------|--|--------|---|-----------|----|----------|-----|-----|--|
| 16 | <p>Check if voltage at 1H terminal of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <p>Voltage: Approx. 12V (Hold switch released)</p>  | Yes | Go to Step 18 | | | | | | |
| | | No | Go to next step | | | | | | |
| 17 | <p>Check if continuity between terminal a of hold switch and 1H terminal of EC-AT control unit is OK</p> | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 18 | <p>Check if operation of hold switch is OK</p> <p style="text-align: right;">☞ page K2-140</p> <table border="1" data-bbox="236 947 759 1045"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table>  | Switch | Continuity | Depressed | No | Released | Yes | Yes | <p>Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> |
| Switch | Continuity | | | | | | | | |
| Depressed | No | | | | | | | | |
| Released | Yes | | | | | | | | |
| | | No | Replace selector lever knob assembly | | | | | | |
| 19 | <p>Check if servo piston stroke is OK</p> <p style="text-align: right;">☞ page K2-198</p>  | Yes | Go to next step | | | | | | |
| | | No | Adjust ☞ page K2-198 | | | | | | |




| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 20 | <p>Check if engine stall speed is OK ☞ page K2-119</p> <p>Engine stall speed: 2,550—2,650 rpm</p>  | Yes | Go to next step | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | | | | | | | | | | | | | | | | | | | |
| 21 | <p>Check if line pressure and throttle pressure are within specification ☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="148 763 674 946"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="148 1006 674 1139"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | |
| 22 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | | | | | | | | | | | | | | | | | | | | |

03U0K2-033





| 8 | FREQUENT SHIFTING | | | | | | | |
|--|---|---|-----|-------------------------|----|---|--|--|
| DESCRIP-TION | • Downshift occurs when accelerator depressed slightly in D, S, and L ranges, Normal mode | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | |
| ① Throttle sensor malfunction or misadjusted ② Control valve stuck ③ Hydraulic circuit clogged or leaking | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | |
| 1 | Check if '00' is displayed on EC-AT Tester with ignition switch ON ⇨ page K2-106  | <table border="0"> <tr> <td data-bbox="790 409 853 472">Yes</td> <td data-bbox="853 409 1508 472">Go to next step</td> </tr> <tr> <td data-bbox="790 472 853 751">No</td> <td data-bbox="853 472 1508 751"> Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ⇨ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) </td> </tr> <tr> <td colspan="2" data-bbox="790 751 1508 947"> "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring </td> </tr> </table> | Yes | Go to next step | No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ⇨ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) | "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring | |
| Yes | Go to next step | | | | | | | |
| No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ⇨ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) | | | | | | | |
| "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring | | | | | | | | |
| 2 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially throttle sensor voltage) | <table border="0"> <tr> <td data-bbox="790 947 853 1157">Yes</td> <td data-bbox="853 947 1508 1157">Go to Steps 4, 6, and 7</td> </tr> <tr> <td data-bbox="790 1157 853 1398">No</td> <td data-bbox="853 1157 1508 1398"> No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause </td> </tr> </table> | Yes | Go to Steps 4, 6, and 7 | No | No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause | | |
| Yes | Go to Steps 4, 6, and 7 | | | | | | | |
| No | No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause | | | | | | | |
| 3 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ⇨ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | <table border="0"> <tr> <td data-bbox="790 1398 853 1581">Yes</td> <td data-bbox="853 1398 1508 1581">Go to next step</td> </tr> <tr> <td data-bbox="790 1581 853 1770">No</td> <td data-bbox="853 1581 1508 1770">Repair wiring</td> </tr> </table> | Yes | Go to next step | No | Repair wiring | | |
| Yes | Go to next step | | | | | | | |
| No | Repair wiring | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | |
|-------|--|----------------------------------|---|--|------------------------|-------|---|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 4 | Check if voltage at 2A and 2T terminals of EC-AT control unit is OK ☞ page K2-144 <table border="1"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table>  | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | Yes | Go to Step 6 | | | | | | | | | | | | | |
| | | Terminal | Voltage (V) | | | | | | | | | | | | | | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | | | | | | | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | | | | | | | | | | | | | | |
| No | Check for poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace | | | | | | | | | | | | | | | | | | | | | |
| 5 | Check if throttle sensor is OK ☞ page *F-143  | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace | | | | | | | | | | | | | | | | | | | |
| | | No | Adjust or replace throttle sensor ☞ page *F-143 | | | | | | | | | | | | | | | | | | | |
| 6 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | | | | | | | | | | | | | | | | | | | |
| 7 | Check if line pressure and throttle pressure are within specification ☞ page K2-123 125 Line pressure: <table border="1"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2">D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> Throttle pressure: <table border="1"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| | | | Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | |
| Idle | Stall | | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| No | Check for cause (Refer to Evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | | | |
| 8 | Try known good EC-AT control unit, control valve assembly, or replace | | | | | | | | | | | | | | | | | | | | | |


* Refer to 1990 323 Workshop Manual (1195-10-89E).


| 9 | SHIFT POINT HIGH OR LOW | |
|---|---|---|
| DESCRIP-TION | • Shift points do not match shift diagram (Refer to road test in this section) | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① ATF level low ② Throttle sensor malfunction or misadjusted ③ Idle switch worn ④ Pulse generator malfunction</p> <p>⑤ Vehicle speed sensor malfunction ⑥ Control valve stuck (1-2 shift valve, 2-3 shift valve, or 3-4 shift valve)</p> | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Check if ATF level is OK ☞ page K2-134</p> <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p>  | <p>Yes Go to next step</p> <p>No Add ATF to specified level ☞ page K2-134</p> |
| 2 | <p>Check if ATF condition is OK ☞ page K2-134</p> <p>① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid</p>  | <p>Yes Go to next step</p> <p>No No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134</p> |
| 3 | <p>Check if '00' is displayed on EC-AT tester with ignition switch ON ☞ page K2-106</p>  | <p>Yes Go to next step</p> <p>No Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108</p> <p>No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit</p> <p>Voltage: Approx. 12V (Ignition switch ON)</p> <p>“88” flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector</p> <p>⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring</p> |

| STEP | INSPECTION | ACTION | | | | | | | |
|------|--|----------|---|----|------------------------|----|---|-----|---------------|
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially idle switch, throttle sensor voltage, vehicle speed and drum speed) | Yes | Go to Steps 6, 8, 10, 13, 14 and 15 in sequence | | | | | | |
| | | No | No indication at all lamps ⇒ Go to Step Individual lamp(s) does not illuminate ⇒ Check for cause | | | | | | |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Ignition switch ON) | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 6 | Check if voltage at 1O terminal of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Throttle valve open) | Yes | Go to Step 8 | | | | | | |
| | | No | Go to next step | | | | | | |
| 7 | Check for continuity between 1O terminal of EC-AT control unit and idle switch terminal | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 8 | Check if voltage at 2A and 2T terminals of EC-AT control unit is OK ↗ page K2-144 <table border="1" data-bbox="145 1574 671 1698"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table> | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | Yes | Go to Step 10 |
| | | Terminal | Voltage (V) | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | |
| No | Check for poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace | | | | | | | | |



| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 9 | Check if throttle sensor is OK ➔ page *F-143  | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace |
| | | No | Adjust or replace throttle sensor ➔ page *F-143 |
| 10 | Disconnect 20-pin connector of EC-AT control unit Check if resistance between 2J terminal and 2L terminals of EC-AT control unit is OK Resistance: 200—400Ω  | Yes | Go to Step 12 |
| | | No | Go to next step |
| 11 | Check if resistance of pulse generator is OK ➔ page K2-142 Resistance: 200—400Ω  | Yes | Check for poor connection at connectors and go to next step |
| | | No | Replace pulse generator |
| 12 | Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit Check if pulse display is OK  | Yes | Go to next step |
| | | No | Very low voltage: Replace pulse generator |
| | | | Noise in wave from: Check for improper grounding of shield-wiring or replace pulse generator |



* Refer to 1990 323 Workshop Manual (1195-10-89E).





| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | |
|-----------------|--|---|--|-----------|------|----------------|-------|-----------------------------|----------------------------------|-----------|------------------------------|---|-------|--|--|------|-------|---|--------------------------|-----------------------------|
| 13 | Disconnect connectors from EC-AT control unit Apply 12V to solenoid valve terminals shown and check if vehicle drives in conditions below in D range | Yes Try known-good EC-AT control unit and go to next step | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>12V to terminal</th> <th>Vehicle condition</th> </tr> </thead> <tbody> <tr> <td>2G and 2I</td> <td>1st</td> </tr> <tr> <td>2E, 2G, and 2I</td> <td>2nd</td> </tr> <tr> <td>—</td> <td>3rd</td> </tr> <tr> <td>2E and 2I</td> <td>OD</td> </tr> </tbody> </table> | 12V to terminal | Vehicle condition | 2G and 2I | 1st | 2E, 2G, and 2I | 2nd | — | 3rd | 2E and 2I | OD | No Overhaul transaxle and check for cause page K2-152 | | | | | | | | |
| 12V to terminal | Vehicle condition | | | | | | | | | | | | | | | | | | | |
| 2G and 2I | 1st | | | | | | | | | | | | | | | | | | | |
| 2E, 2G, and 2I | 2nd | | | | | | | | | | | | | | | | | | | |
| — | 3rd | | | | | | | | | | | | | | | | | | | |
| 2E and 2I | OD | | | | | | | | | | | | | | | | | | | |
| 14 | Check if engine stall speed is OK page K2-119 Engine stall speed: 2,550—2,650 rpm | Yes Go to next step | | | | | | | | | | | | | | | | | | |
| |  | No Check for cause (Refer to Evaluation) page K2-119 | | | | | | | | | | | | | | | | | | |
| 15 | Check if line pressure and throttle pressure are within specification page K2-123 125 | Yes Go to next step | | | | | | | | | | | | | | | | | | |
| | <p>Line pressure:</p> <table border="1"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | |
| 16 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | | | | | | | | | | | | | | | | | | |

| 10 | NO LOCKUP | | |
|---|--|-----|--|
| DESCRIP-TION | • No lockup in D range OD | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Stoplight switch or circuit shorted ② Solenoid valve stuck (1-2, 2-3, 3-4, or lockup) ③ Water thermo signal malfunction ④ Throttle sensor malfunction or misadjusted ⑤ Pulse generator malfunction ⑥ Hold switch circuit shorted ⑦ Control valve stuck (Lockup control valve) ⑧ Torque converter worn ⑨ Hydraulic circuit clogged or leaking</p> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check if "00" is displayed on EC-AT Tester with ignition switch ON | Yes | Go to next step |
| | <p style="text-align: right;">☞ page K2-106</p>  | No | <p>Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108</p> <p>No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit</p> <p>Voltage: Approx. 12V (Ignition switch ON)</p> <p>"88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector</p> <p>⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring</p> |
| 2 | Turn ignition switch ON Check if malfunction indicator lamp (MIL) is illuminated | Yes | Go to Step 4 |
| | | No | Check for cause (Refer to troubleshooting guide) ☞ page *F-12 |
| 3 | Start engine and let it at idle Check if malfunction indicator lamp (MIL) goes OFF | Yes | Go to next step |
| | | No | Check for malfunction Code No. ☞ page *F-12 |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | |
|-----------|--|----------------|--|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|--------|-----------------|-----|-----|-----------------|
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially hold switch, water thermo signal, solenoid valves, throttle sensor voltage, and drum speed) | Yes | Go to Steps 6, 12, 16, 19, 22, 24, 27 and 28 in sequence | | | | | | | | | | | | | | | |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause | | | | | | | | | | | | | | | |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | Yes | Go to next step | | | | | | | | | | | | | | | |
| | | No | Repair wiring | | | | | | | | | | | | | | | |
| 6 | Drive vehicle above 80 km/h (50 mph) in D range OD Check if voltage at terminal 2K of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Lockup solenoid ON [Lockup])  | Yes | Go to Step 8 | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | |
| 7 | Check if continuity of transistor in EC-AT control unit is OK <table border="1" data-bbox="174 1550 696 1712"> <thead> <tr> <th>Solenoid valve</th> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>Lockup</td> <td>2K and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | Lockup | 2K and 1J or 2P | Yes | Yes | Go to next step |
| | | Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| Lockup | 2K and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| No | Replace EC-AT control unit | | | | | | | | | | | | | | | | | |




| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 8 | Check if resistance between 2E, 2G, 2I, or 2K terminals of EC-AT control unit and ground is OK Resistance: 13—27Ω  | Yes | Go to Step 10 |
| | | No | Go to next step |
| 9 | Check if resistance of solenoid valve(s) is OK ➔ page K2-143 Resistance: 13—27Ω  | Yes | Check for poor connection at connectors ➔ If OK, go to next step ➔ If not OK, repair wiring |
| | | No | Replace solenoid valve |
| 10 | Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E, 2G, 2I and 2K terminals and check if operation sound (clicking) of solenoid is heard | Yes | Try known good EC-AT control unit and go to next step |
| | | No | Replace solenoid valve |
| 11 | Apply 12V to 2K terminal of EC-AT control unit start engine in P range and let it idle Shift to D range and check if engine stalls | Yes | Go to next step |
| | | No | Replace lockup solenoid valve |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 12 | <p>Check if voltage at 1N terminal of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <p>Voltage: Approx. 12V After engine warmed up (Above 72°C [162°F])</p>  | Yes | Go to Step 16 |
| 13 | <p>Check if voltage at 2Z terminal of engine control unit is OK</p> <p>Voltage: Approx. 12V After engine warmed up (Above 72°C [162°F])</p>  | Yes | <p>Check for continuity between terminal 1N of EC-AT control unit and terminal 2Z of engine control unit</p> <p>If OK, try known good EC-AT control unit and go to next step</p> <p>If not OK, repair wiring</p> |
| 14 | <p>Check if voltage at terminal 2Q of engine control unit is OK</p> <p>Approx. 2.5V: Engine coolant temp. 20°C (68°F) Below 0.5V: After engine warmed up</p>  | Yes | Replace engine control unit |
| 15 | <p>Check if operation of water thermosensor is OK</p> <p style="text-align: right;">☞ page *F-142</p>  | Yes | <p>Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> |
| | | No | <p>Replace water thermosensor</p> <p style="text-align: right;">☞ page *F-142</p> |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION | | | | | | |
|-----------|---|--------|--------------------------|-----------|-----|----------|----|-----|---|
| 16 | <p>Check if voltage at 1F terminal of EC-AT control is OK</p> <p>Voltage: Approx. 12V (Brake pedal depressed)</p>  | Yes | Go to Step 19 | | | | | | |
| | | No | Go to next step | | | | | | |
| 17 | <p>Check for continuity between terminal 1F of EC-AT control unit and stoplight switch</p> | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 18 | <p>Check if operation of stoplight switch is OK</p> <p>☞ page *T-45</p> <table border="1" data-bbox="229 978 751 1075"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>Yes</td> </tr> <tr> <td>Released</td> <td>No</td> </tr> </tbody> </table>  | Switch | Continuity | Depressed | Yes | Released | No | Yes | <p>Check for short or open circuit of wiring and poor connection at connector</p> <p>⇒ If OK, go to next step</p> <p>⇒ If not OK, repair wiring</p> |
| Switch | Continuity | | | | | | | | |
| Depressed | Yes | | | | | | | | |
| Released | No | | | | | | | | |
| | | No | Replace stoplight switch | | | | | | |
| 19 | <p>Check if voltage at 1H terminal of EC-AT control unit is OK</p> <p>☞ page K2-144</p> <p>Voltage: Approx. 12V (Hold switch released)</p>  | Yes | Go to Step 22 | | | | | | |
| | | No | Go to next step | | | | | | |
| 20 | <p>Check if continuity between a terminal of hold switch and 1H terminal of EC-AT control unit is OK</p> | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | ACTION | | | | | | | |
|-----------|---|----------|---|-----------|------------------------|----------|---|-----|---|
| 21 | Check if operation of hold switch is OK ☞ page K2-140 <table border="1" style="margin: 10px 0;"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table>  | Switch | Continuity | Depressed | No | Released | Yes | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring |
| | | Switch | Continuity | | | | | | |
| Depressed | No | | | | | | | | |
| Released | Yes | | | | | | | | |
| No | Replace selector lever knob assembly | | | | | | | | |
| 22 | Check if voltage at 2A and 2T terminals of EC-AT control unit is OK ☞ page K2-144 <table border="1" style="margin: 10px 0;"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table>  | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | Yes | Go to Step 24 |
| | | Terminal | Voltage (V) | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | |
| No | Check if poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace | | | | | | | | |
| 23 | Check if throttle sensor is OK ☞ page *F-143  | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring | | | | | | |
| | | No | Adjust or replace throttle sensor ☞ page *F-143 | | | | | | |
| 24 | Disconnect 20-pin connector of EC-AT control unit Check if resistance between 2J and 2L terminals of EC-AT control unit is OK Resistance: 200—400Ω | Yes | Go to Step 26 | | | | | | |
| | | No | Go to next step | | | | | | |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 25 | Check if resistance of pulse generator is OK ☞ page K2-142 Resistance: 200—400Ω  | Yes | Check for poor connection at connectors and go to next step |
| | | No | Replace pulse generator |
| 26 | Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit Check if pulse display is OK  | Yes | Go to next step |
| | | No | Very low voltage: Replace pulse generator |
| | | No | Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator |
| 27 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |




| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|----------------------|---|
| 28 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="140 340 667 526"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="140 592 667 716"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check for cause (Refer to Evaluation) ☞ page K2-124 126</p> |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| 29 | <p>Try known good EC-AT control unit, control valve assembly, or replace transaxle</p> | | | | | | | | | | | | | | | | | | | | | |

03U0K2-036




| 11 | NO KICKDOWN | |
|--|---|--|
| DESCRIPTION | • Does not downshift when accelerator depressed more than 7/8 within kickdown range | |
| [TROUBLESHOOTING HINTS] | | |
| ① Throttle sensor malfunction or misadjustment ② Pulse generator malfunction ③ Hold switch circuit shorted ④ Shift solenoid valves stuck (1-2, 2-3, or 3-4) | | |
| STEP | INSPECTION | ACTION |
| 1 | Check if "00" is displayed on EC-AT Tester with ignition switch ON ➤ page K2-106 | Yes Go to next step |
| |  | No Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ➤ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring |
| 2 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially hold switch, solenoid valves, throttle sensor voltage and drum speed) | Yes Go to Steps 4, 7, 9 and 12 in sequence |
| | | No No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 3 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ➤ page K2-144 Voltage: Approx. 12V (Ignition switch ON) | Yes Go to next step |
| |  | No Repair wiring |










| STEP | INSPECTION | ACTION | | | | | | | |
|-----------|--|----------|---|-----------|------------------------|----------|--------------------------------------|-----|---|
| 4 | Check if voltage at 1H terminal of EC-AT control unit is OK ☞ page K2-144 Voltage: Approx. 12V (Hold switch released)  | Yes | Go to Step 7 | | | | | | |
| | | No | Go to next step | | | | | | |
| 5 | Check if continuity between a terminal of hold switch and 1H terminal of EC-AT control unit is OK | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 6 | Check if operation of hold switch is OK ☞ page K2-140 <table border="1" data-bbox="137 962 661 1061"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table> | Switch | Continuity | Depressed | No | Released | Yes | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring |
| | | Switch | Continuity | | | | | | |
| Depressed | No | | | | | | | | |
| Released | Yes | | | | | | | | |
| No | Replace selector lever knob assembly | | | | | | | | |
| 7 | Check if voltage at 2A and 2T terminals of EC-AT control unit is OK ☞ page K2-144 <table border="1" data-bbox="137 1305 661 1426"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table>  | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | Yes | Go to Step 9 |
| | | Terminal | Voltage (V) | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | |
| No | Check if poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair or replace | | | | | | | | |
| 8 | Check if throttle sensor is OK ☞ page *F-143  | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring | | | | | | |
| | | No | Adjust or replace throttle sensor ☞ page *F-143 | | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 9 | <p>Disconnect 20-pin connector of EC-AT control unit</p> <p>Check if resistance between 2J terminal and 2L terminals of EC-AT control unit is OK</p> <p>Resistance: 200—400Ω</p>  | Yes | Go to Step 11 |
| | | No | Go to next step |
| 10 | <p>Check if resistance of pulse generator is OK</p> <p>☞ page K2-142</p> <p>Resistance: 200—400Ω</p>  | Yes | Check for poor connection at connectors and go to next step |
| | | No | Replace pulse generator |
| 11 | <p>Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit</p> <p>Check if pulse display is OK</p>  | Yes | Go to next step |
| | | No | Very low voltage: Replace pulse generator |
| | | | Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator |
| 12 | <p>Disconnect solenoid valve connector and check if vehicle is driven as follows:</p> <p>R range: Reverse D and S ranges: 3rd L range: 1st</p> <p>Note</p> <ul style="list-style-type: none"> • Engine rpm at 40 km/h (25 mph) 1st gear: 3,950 rpm 3rd gear: 1,400 rpm | Yes | Go to next step |
| | | No | Overhaul transaxle and repair or replace any faulty parts ☞ page K2-152 |




| STEP | INSPECTION | ACTION | | | | | | | | | | | | | |
|----------------|--|----------------|---|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|----|----------------------------|
| 13 | Check if continuity of transistors in EC-AT control unit is OK | Yes | Go to next step | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Solenoid valve</th> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | No | Replace EC-AT control unit |
| Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | |
| 14 | Check if resistance between 2E, 2G, or 2I terminals of EC-AT control unit and ground is OK | Yes | Go to Step 16 | | | | | | | | | | | | |
| | Resistance: 13—27Ω | No | Go to next step | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| 15 | Check if resistance of solenoid valve(s) is OK page K2-143 | Yes | Check for poor connection at connectors If OK, go to next step If not OK, repair wiring | | | | | | | | | | | | |
| | Resistance: 13—27Ω | No | Replace solenoid valve | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| 16 | Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E, 2G, and 2I terminals and check if operation sound (clicking) of solenoid is heard | Yes | Try known good EC-AT control unit and go to next step | | | | | | | | | | | | |
| | | No | Replace solenoid valve | | | | | | | | | | | | |
| 17 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | | | | | | | | | | | | | |

| 12 | ENGINE FLARES UP OR SLIPS WHEN ACCELERATING VEHICLE | | |
|--|---|--|-----------------|
| <p>[TROUBLESHOOTING HINTS]</p> <ul style="list-style-type: none"> ① ATF level low ② Powertrain slippage (Forward clutch, reverse clutch, low and reverse brake, one-way clutch 1, or one-way clutch 2) ③ Control valve stuck (Pressure regulator valve) ④ Oil pump worn | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>Check if ATF level is OK ☞ page K2-134</p> <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p> <div style="text-align: center;">  </div> | Yes | Go to next step |
| | No | Add ATF to specified level ☞ page K2-134 | |
| 2 | <p>Check if ATF condition is OK ☞ page K2-134</p> <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid <div style="text-align: center;">  </div> | Yes | Go to next step |
| | No | <p>No.2 condition Overhaul transaxle and repair or replace parts as necessary</p> <p>No.3 or No.4 condition Replace ATF</p> ☞ page K2-134 | |
| 3 | <p>Check if engine stall speed is OK ☞ page K2-119</p> <p>Engine stall speed: 2,550—2,650 rpm</p> <div style="text-align: center;">  </div> | Yes | Go to next step |
| | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | |




| 13 | ENGINE FLARES UP OR SLIPS WHEN UPSHIFTING OR DOWNSHIFTING | | |
|--|---|-----|--|
| <p>[TROUBLESHOOTING HINTS]</p> <p>① ATF level low ② Throttle cable misadjusted ③ Powertrain slippage (Forward clutch, 3-4 clutch, 2-4 brake band, one-way clutch 1, one-way clutch 2, or reverse clutch) ④ Control valve stuck (Pressure regulator valve) ⑤ Oil pump worn ⑥ Hydraulic circuit clogged or leaking (Forward clutch, 3-4 clutch, 2-4 brake band, or reverse clutch)</p> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>Check if ATF level is OK  page K2-134</p> <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p>  | Yes | Go to next step |
| 2 | <p>Check if ATF condition is OK  page K2-134</p> <p>① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid</p>  | Yes | Go to next step |
| 3 | <p>Check if engine stall speed is OK  page K2-119</p> <p>Engine stall speed: 2,550—2,650 rpm</p>  | Yes | Go to next step |
| | | No | <p>Add ATF to specified level  page K2-134</p> <p>No.2 condition Overhaul transaxle and repair or replace parts as necessary  page K2-134 No.3 or No.4 condition Replace ATF</p> <p>Check for cause (Refer to Evaluation)  page K2-121</p> |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|--|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----------------------------------|
| 4 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="153 340 680 526"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="153 592 680 714"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | <p>Yes</p> <p>Go to next step</p> |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | |
| | | <p>No</p> <p>Check for cause (Refer to Evaluation) ☞ page K2-124 126</p> | | | | | | | | | | | | | | | | | | | |
| 5 | <p>Try known good EC-AT control unit or control valve assembly, or replace transaxle</p> | | | | | | | | | | | | | | | | | | | | |

03U0K2-039




| 14 | EXCESSIVE N TO R OR N TO D RANGE SHIFT SHOCK | |
|--|--|--|
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Engine idle speed misadjusted ② Throttle cable misadjusted ③ Accumulator malfunction (N-D accumulator or N-R accumulator) ④ Hydraulic circuit clogged or leaking (N-D accumulator or N-R accumulator) ⑤ Control valve stuck (Pressure control valve, throttle valve, or throttle modulator valve)</p> | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Check if ATF level is OK ☞ page K2-134</p> <p>Level: Between notches on HOT side of level gauge at 65°C (149°F)</p> <div style="text-align: center;">  <p>HOT RANGE</p> <p>20°C 65°C</p> <p>COOL RANGE</p> </div> | <p>Yes Go to next step</p> <p>No Add ATF to specified level ☞ page K2-134</p> |
| 2 | <p>Check if ATF condition is OK ☞ page K2-134</p> <p>① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid</p> <div style="text-align: center;">  </div> | <p>Yes Go to next step</p> <p>No No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134</p> |
| 3 | <p>Check if ignition timing at idle is OK ☞ page *F-72</p> <p>Ignition timing (BTDC): 7 ± 1°</p> <div style="text-align: center;">  </div> | <p>Yes Check for correct idle speed ☞ page *F-72</p> <p>Idle speed: 750 ± 50 rpm (with parking brake applied)</p> <p>⇒ If OK, go to next step ⇒ If not OK, adjust the idle speed ☞ page *F-72</p> <p>No Adjust ignition timing ☞ page *F-72</p> |




* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | | ACTION | | | | | | | | | | | |
|-------|--|--|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-----|-----------------|
| 4 | Check if throttle cable operates smoothly and is installed correctly ☞ page K2-137  | Yes | Go to next step | | | | | | | | | | | |
| | No | Replace throttle cable ☞ page K2-137 | | | | | | | | | | | | |
| 5 | Check if line pressure at idle is OK ☞ page K2-139 Line pressure: <table border="1" data-bbox="153 690 682 873"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Yes | Go to next step |
| | Range | | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | |
| Idle | | Stall | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | |
| No | Adjust throttle cable ☞ page K2-139 | | | | | | | | | | | | | |
| 6 | Check if time lag is within specification at idle ☞ page K2-122 Time lag: N → D: 0.5—1.0 second N → R: 0.6—1.0 second  | Yes | Go to next step | | | | | | | | | | | |
| | No | Check for cause (Refer to Evaluation) ☞ page K2-122 | | | | | | | | | | | | |
| 7 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step | | | | | | | | | | | |
| | No | Check for cause (Refer to Evaluation) ☞ page K2-121 | | | | | | | | | | | | |



| STEP | INSPECTION | Yes | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 8 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="240 352 767 541"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="240 604 767 730"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | |
| 9 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | | | | | | | | | | | | | | | | | | | | |

03U0K2-040


| 15 | EXCESSIVE SHIFT SHOCK WHEN UPSHIFTING AND DOWNSHIFTING | | |
|--|--|--------|---|
| <p>[TROUBLESHOOTING HINTS]</p> <ul style="list-style-type: none"> ① ATF level low ② Throttle cable misadjusted ③ 2-4 brake band (band servo) misadjusted ④ Accumulator malfunction (1-2 accumulator or 2-3 accumulator) ⑤ Shift solenoid valves stuck (1-2, 2-3, or 3-4) ⑥ Powertrain slippage (Coasting clutch, 3-4 clutch, or 2-4 brake band) ⑦ Control valve stuck (Pressure regulator valve, throttle valve, or throttle modulator valve) ⑧ Hydraulic circuit clogged or leaking (Coasting clutch, 3-4 clutch, or 2-4 brake band) | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F) | Yes | Go to next step |
| |  | No | Add ATF to specified level ☞ page K2-134 |
| 2 | Check if ATF condition is OK ☞ page K2-134 <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid | Yes | Go to next step |
| |  | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |
| 3 | Check if "00" is displayed on EC-AT Tester with ignition switch ON ☞ page K2-106 | Yes | Go to next step |
| |  | No | <p>Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108</p> <p>No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit</p> <p>Voltage: Approx. 12V (Ignition switch ON)</p> |
| | | | <p>"88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector</p> <ul style="list-style-type: none"> ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring |









| STEP | INSPECTION | | ACTION | | | | | | | | | | | | |
|-----------|---|----------------|---|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|-----|-----------------|
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct | Yes | Go to Steps 6, 11, 13 and 14 in sequence | | | | | | | | | | | | |
| | | No | No indication at all lamps ⇒ Go to next step <i>Individual lamp(s) does not illuminate</i> ⇒ Check for cause | | | | | | | | | | | | |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Ignition switch ON) <div style="text-align: center;"> 2S, 2Q  </div> | Yes | Go to next step | | | | | | | | | | | | |
| | | No | Repair wiring | | | | | | | | | | | | |
| 6 | Check if voltage at 2E, 2G, or 2I terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (When solenoid ON) <div style="text-align: center;"> 2I 2G 2E  </div> | Yes | Go to Step 8 | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |
| 7 | Check if continuity in transistors of EC-AT control unit is OK <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 25%;">Solenoid valve</th> <th style="width: 25%;">Terminal</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | Yes | Go to next step |
| | | Solenoid valve | Terminal | Continuity | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | |
| No | Replace EC-AT control unit | | | | | | | | | | | | | | |
| 8 | Check if resistance between 2E, 2G, and 2I terminals of EC-AT control unit and ground is OK Resistance: 13—27Ω <div style="text-align: center;"> 2I 2G 2E  </div> | Yes | Go to Step 10 | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |




| STEP | INSPECTION | ACTION | |
|---|--|--|---|
| 9 | Check if resistance of solenoid valves is OK ☞ page K2-143 | Yes | Check for poor connection at connectors ⇨ If OK, go to next step ⇨ If not OK, repair wiring |
| | Resistance: 13—27Ω | No | Replace solenoid valve |
|  | 10 Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E, 2G, and 2I terminals and check if operation sound (clicking) of solenoid is heard | Yes | Try known good EC-AT control unit and go to next step |
| | | No | Replace solenoid valve |
| 11 | Check if throttle cable operates smoothly and is installed correctly ☞ page K2-137 | Yes | Go to next step |
| |  | No | Replace throttle cable ☞ page K2-137 |
| 12 | | Check if line pressure at idle is OK ☞ page K2-139 | Yes |
| | Line pressure: 402—422 kPa (4.1—4.3 kg/cm², 58—61 psi) | No | Adjust throttle cable ☞ page K2-139 |

| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 13 | Check if time lag is within specification at idle ☞ page K2-122 Time lag: N → D: 0.5—1.0 second N → R: 0.6—1.0 second  | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-122 |
| 17 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |
| 15 | Try known good EC-AT control unit, control valve body, or replace transaxle | | |

03U0K2-041




| 16 TRANSAXLE NOISY IN N AND P RANGES | | | |
|--------------------------------------|---|--------|--|
| DESCRIP-TION | •Noise corresponds to engine speed | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① ATF level low ② Oil pump worn | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F)  | Yes | Go to next step |
| | | No | Add ATF to specified level ☞ page K2-134 |



| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|--|-------------------------------------|---|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 2 | <p>Check if ATF condition is OK  page K2-134</p> <p>① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid</p>  | Yes | Go to next step | | | | | | | | | | | | | | | | | | | |
| | | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary  page K2-134 No.3 or No.4 condition Replace ATF | | | | | | | | | | | | | | | | | | | |
| 3 | <p>Check if engine stall speed is OK  page K2-110</p> <p>Engine stall speed: 2,550—2,650 rpm</p>  | Yes | Go to next step | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation)  page K2-121 | | | | | | | | | | | | | | | | | | | |
| 4 | <p>Check if line pressure and throttle pressure are within specification  page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="133 1426 658 1603"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="133 1670 658 1802"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation)  page K2-124 126 | | | | | | | | | | | | | | | | | | | |
| 5 | Check for other cause of noise or overhaul transaxle | | | | | | | | | | | | | | | | | | | | | |




| 17 | TRANSAXLE NOISY IN D, S, L AND R RANGES | | |
|--|--|-----|---|
| DESCRIP-TION | •Noise corresponds to vehicle speed | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① ATF level low ② Differential backlash incorrect ③ Torque converter worn ④ Oil pump worn | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F) | Yes | Go to next step |
| |  | No | Add ATF to specified level ☞ page K2-134 |
| 2 | Check if ATF condition is OK ☞ page K2-134 ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid | Yes | Go to next step |
| |  | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |
| 3 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm | Yes | Go to next step |
| |  | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|-----|-----------------|
| 4 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="166 336 696 517"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="166 583 696 707"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | Yes | Go to next step |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-124 126 | | | | | | | | | | | | | | | | | | | |
| 5 | Check other cause of noise or overhaul transaxle | | | | | | | | | | | | | | | | | | | | | |

03U0K2-043




| 18 | NO ENGINE BRAKING | | |
|--|---|--|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • No engine braking as follows <ul style="list-style-type: none"> D range (Normal and Hold mode): 3rd and OD S range (Normal mode): 3rd S range (Hold mode): 2nd L range (Normal mode): 2nd L range (Hold mode): 1st | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Shift solenoid valve stuck (1-2 shift valve or 2-3 shift valve) ③ Powertrain slippage (Coasting clutch, or low and reverse brake) ④ Control valve stuck (1-2 shift valve, 2-3 shift valve, low reducing valve, or manual valve) ⑤ Hydraulic circuit clogged or leaking (Coasting clutch, or low and reverse brake) | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F) | Yes | Go to next step |
| | | No | Add ATF to specified level ☞ page K2-134 |
|  | | | |
| 2 | Check if ATF condition is OK ☞ page K2-134 <ul style="list-style-type: none"> ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid | Yes | Go to next step |
| | | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |
|  | | | |
| 3 | Check if "00" is displayed on EC-AT Tester with ignition switch ON ☞ page K2-106 | Yes | Go to next step |
| | | No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) |
| | | "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring | |
|  | | | |



| STEP | INSPECTION | | ACTION | | | | | | | | | | | | |
|----------------|--|----------------|--|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|-----|-----------------|
| 4 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially solenoid valves) | Yes | Go to Steps 6, 10, 11 and 12 in sequence | | | | | | | | | | | | |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause | | | | | | | | | | | | |
| 5 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Ignition switch ON) | Yes | Go to next step | | | | | | | | | | | | |
| |  | No | Repair wiring | | | | | | | | | | | | |
| 6 | Check of continuity in transistors in EC-AT control unit is OK <table border="1" data-bbox="169 1046 699 1194"> <thead> <tr> <th>Solenoid valve</th> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>1-2 shift</td> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>2-3 shift</td> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> <tr> <td>3-4 shift</td> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | Yes | Go to next step |
| Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | |
| | | No | Replace EC-AT control unit | | | | | | | | | | | | |
| 7 | Check if resistance between 2E, and 2G terminals of EC-AT control unit and ground is OK Resistance: 13—27Ω | Yes | Go to Step 9 | | | | | | | | | | | | |
| |  | No | Go to next step | | | | | | | | | | | | |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 8 | <p>Check if resistance of solenoid valves is OK ☞ page K2-143</p> <p>Resistance: 13—27Ω</p>  | Yes | <p>Check for poor connection at connectors</p> <p>⇒ If OK, go to next step ⇒ If not OK, repair wiring</p> |
| | | No | <p>Replace solenoid valve</p> |
| 9 | <p>Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E and 2G terminals and check if operation sound (clicking) of solenoid is heard</p> | Yes | <p>Try known good EC-AT control unit and go to next step</p> |
| | | No | <p>Replace solenoid valve</p> |
| 10 | <p>Check if time lag is within specified at idle ☞ page K2-122</p> <p>Time lag N → D: 0.5—1.0 second N → R: 0.6—1.0 second</p>  | Yes | <p>Go to next step</p> |
| | | No | <p>Check for cause (Refer to Evaluation) ☞ page K2-122</p> |
| 11 | <p>Check if engine stall speed is OK ☞ page K2-119</p> <p>Engine stall speed: 2,550—2,650 rpm</p>  | Yes | <p>Go to next step</p> |
| | | No | <p>Check for cause (Refer to Evaluation) ☞ page K2-121</p> |


| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|----------------------|---|
| 12 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" data-bbox="147 349 675 533"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" data-bbox="147 599 675 725"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check for cause (Refer to Evaluation) ☞ page K2-124 126</p> |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| 13 | <p>Try known good EC-AT control unit, control valve assembly, solenoid valves, or replace transaxle</p> | | | | | | | | | | | | | | | | | | | | | |

03U0K2-044



| | | |
|---|---|--|
| 19 | NO MODE CHANGES | |
| DESCRIP-TION | • Hold mode cannot be selected or is not canceled when ignition switch turned OFF | |
| [TROUBLESHOOTING HINTS] | | |
| ① Hold switch circuit shorted ② Throttle sensor malfunction or misadjusted ③ ATF thermosensor malfunction ④ Vehicle speed sensor malfunction ⑤ Pulse generator malfunction ⑥ Solenoid valves stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Check if "00" is displayed on EC-AT Tester with ignition switch ON ⇨ page K2-106  | Yes: Go to next step No: Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ⇨ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12 (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring |
| 2 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially hold switch, solenoid valves, ATF thermosensor, shift signal, throttle sensor voltage, vehicle speed, and drum speed) | Yes: Go to Steps 4, 7, 9, 11, 14 and 16 in sequence No: No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 3 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ⇨ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | Yes: Go to next step No: Repair wiring |
| 4 | Check if voltage at 1H terminal of EC-AT control unit is OK ⇨ page K2-144 Voltage: Approx. 12V (Hold switch released)  | Yes: Go to Step 7 No: Go to next step |




| STEP | INSPECTION | ACTION | | | | | | |
|---|--|--|------------|-----------|----|----------|-----|--|
| 5 | Check if continuity between a terminal of hold switch and 1H terminal of EC-AT control unit is OK | Yes Go to next step | | | | | | |
| | | No Repair wiring | | | | | | |
| 6 | Check if operation of hold switch is OK ➔ page K2-140 <table border="1" data-bbox="153 620 683 716"> <thead> <tr> <th>Switch</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table> | Switch | Continuity | Depressed | No | Released | Yes | Yes Check for open or short circuit of wiring and poor connection at connectors ➔ If OK, go to next step ➔ If not OK, repair wiring |
| | Switch | Continuity | | | | | | |
| Depressed | No | | | | | | | |
| Released | Yes | | | | | | | |
|  | No Replace selector lever knob assembly | | | | | | | |
| 7 | Measure resistance while warming up ATF (driving vehicle) Check if resistance between 1G terminal and 1J or 2P terminals of EC-AT control unit is OK | Yes Go to Step 22 | | | | | | |
| | | No Go to next step | | | | | | |
| 8 | Check if resistance between terminals of ATF thermosensor is OK  | Yes Check for poor connection at connectors ➔ If OK, try known good EC-AT control unit or ATF thermosensor and go to next step ➔ If not OK, repair wiring | | | | | | |
| | | No Go to next step | | | | | | |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | |
|-----------|---|----------------|---|------------|-----------|-----------------|-----|-----------|-----------------|-----|-----------|-----------------|-----|--------|-----------------|-----|-----|-----------------|
| 9 | Drive vehicle above 80 km/h (50 mph) in D range OD Check if voltage at 2K terminal of EC-AT control unit is OK ➤ page K2-144 Approx. 12V: Lockup solenoid ON (Lockup) | Yes | Go to Step 14 | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | |
| 10 | Check if continuity of transistors in EC-AT control unit is OK <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 2px;">Solenoid valve</th> <th style="padding: 2px;">Terminal</th> <th style="padding: 2px;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">1-2 shift</td> <td style="padding: 2px;">2E and 1J or 2P</td> <td style="padding: 2px;">Yes</td> </tr> <tr> <td style="padding: 2px;">2-3 shift</td> <td style="padding: 2px;">2G and 1J or 2P</td> <td style="padding: 2px;">Yes</td> </tr> <tr> <td style="padding: 2px;">3-4 shift</td> <td style="padding: 2px;">2I and 1J or 2P</td> <td style="padding: 2px;">Yes</td> </tr> <tr> <td style="padding: 2px;">Lockup</td> <td style="padding: 2px;">2K and 1J or 2P</td> <td style="padding: 2px;">Yes</td> </tr> </tbody> </table> | Solenoid valve | Terminal | Continuity | 1-2 shift | 2E and 1J or 2P | Yes | 2-3 shift | 2G and 1J or 2P | Yes | 3-4 shift | 2I and 1J or 2P | Yes | Lockup | 2K and 1J or 2P | Yes | Yes | Go to next step |
| | | Solenoid valve | Terminal | Continuity | | | | | | | | | | | | | | |
| 1-2 shift | 2E and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| 2-3 shift | 2G and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| 3-4 shift | 2I and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| Lockup | 2K and 1J or 2P | Yes | | | | | | | | | | | | | | | | |
| No | Replace EC-AT control unit | | | | | | | | | | | | | | | | | |
| 11 | Check if resistance between 2E, 2G, 2I, or 2K terminals of EC-AT control unit and ground is OK Resistance: 13—27Ω | Yes | Go to Step 13 | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | |
| 12 | Check if resistance of solenoid valve(s) is OK ➤ page K2-143 Resistance: 13—27Ω | Yes | Check for poor connection at connectors ➡ If OK, go to next step ➡ If not OK, repair wiring | | | | | | | | | | | | | | | |
| | | No | Replace solenoid valve | | | | | | | | | | | | | | | |





| Solenoid valve | Terminal | Continuity |
|----------------|-----------------|------------|
| 1-2 shift | 2E and 1J or 2P | Yes |
| 2-3 shift | 2G and 1J or 2P | Yes |
| 3-4 shift | 2I and 1J or 2P | Yes |
| Lockup | 2K and 1J or 2P | Yes |







| STEP | INSPECTION | | ACTION | | | | | | |
|---|---|-----|--|-------------|----|------------------------|----|---|--|
| 13 | Disconnect 20-pin connector of EC-AT control unit Apply 12V to 2E, 2G, 2I and 2K terminals and check if operation sound (clicking) of solenoid is heard | Yes | Try known good EC-AT control unit and go to next step | | | | | | |
| | | No | Replace solenoid valve | | | | | | |
| 14 | Apply 12V to 2K terminal of EC-AT control unit Start engine in P range and let it idle Shift to D range and check if engine stalls | Yes | Go to next step | | | | | | |
| | | No | Replace lockup solenoid valve | | | | | | |
| 15 | Check if voltage at 2A and 2T terminals of EC-AT control unit is OK  page K2-144 | Yes | Go to Step 16 | | | | | | |
| | | No | Check for poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring | | | | | | |
| <table border="1" data-bbox="155 794 686 917"> <thead> <tr> <th>Terminal</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>5 (Ignition switch ON)</td> </tr> <tr> <td>2T</td> <td>0.4—4.4 (Accelerator closed to open)</td> </tr> </tbody> </table> | | | Terminal | Voltage (V) | 2A | 5 (Ignition switch ON) | 2T | 0.4—4.4 (Accelerator closed to open) | |
| Terminal | Voltage (V) | | | | | | | | |
| 2A | 5 (Ignition switch ON) | | | | | | | | |
| 2T | 0.4—4.4 (Accelerator closed to open) | | | | | | | | |
| 16 | Check if throttle sensor is OK  page *F-143 | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇒ If OK, go to next step ⇒ If not OK, repair wiring | | | | | | |
| | | No | Adjust or replace throttle sensor  page *F-143 | | | | | | |
| 17 | Disconnect 20-pin connector of EC-AT control unit Check if resistance between 2J terminal and 2L terminal of EC-AT control unit is OK Resistance: 200—400Ω | Yes | Go to Step 19 | | | | | | |
| | | No | Go to next step | | | | | | |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 18 | Check if resistance of pulse generator is OK ↗ page K2-142 Resistance: 200—400Ω  | Yes | Check for poor connection at connectors and go to next step |
| | | No | Replace pulse generator |
| 19 | Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit Check if pulse display is OK  | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇨ If OK, go to next step ⇨ If not OK, repair wiring |
| | | No | Very low voltage: Replace pulse generator |
| | | | Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator |
| 20 | Try known good EC-AT control unit | | |

03U0K2-045

| 20 | TRANSAXLE OVERHEATS | | |
|--|--|-----|---|
| DESCRIPTION | • Burned smell from transaxle | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① ATF level low ② Lockup solenoid stuck ③ ATF thermosensor malfunction ④ Oil pump worn ⑤ Torque converter worn | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check if ATF level is OK ☞ page K2-134 Level: Between notches on HOT side of level gauge at 65°C (149°F) | Yes | Go to next step |
| |  | No | Add ATF to specified level ☞ page K2-134 |
| 2 | Check if ATF condition is OK ☞ page K2-134 ① Clear pink: Normal condition ② Dark or black (with friction material): Worn powertrain components ③ Milky pink: Water contamination ④ Light to dark brown (Oxidation): Overheated or old fluid | Yes | Go to next step |
| |  | No | No.2 condition Overhaul transaxle and repair or replace parts as necessary No.3 or No.4 condition Replace ATF ☞ page K2-134 |
| 3 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially lockup solenoid valve) | Yes | Go to Steps 5, 8, 10, 11 and 12 in sequence |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |

| STEP | INSPECTION | ACTION | | | | | |
|-----------------|--|----------|-------------------------------|-----------------|-----|-----|-----------------|
| 4 | <p>Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <p>Voltage: Approx. 12V (Ignition switch ON)</p>  | Yes | Go to next step | | | | |
| | | No | Repair wiring | | | | |
| 5 | <p>Drive vehicle above 80 km/h (50 mph) in D range OD</p> <p>Check if voltage at terminal 2K of EC-AT control unit is OK</p> <p style="text-align: right;">☞ page K2-144</p> <p>Voltage: Approx. 12V (Lockup solenoid ON [Lockup])</p>  | Yes | Go to Step 7 | | | | |
| | | No | Go to next step | | | | |
| 6 | <p>Check if continuity of transistor in EC-AT control unit is OK</p> <table border="1" data-bbox="225 1115 751 1178"> <thead> <tr> <th>Terminal</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>2K and 1J or 2P</td> <td>Yes</td> </tr> </tbody> </table> | Terminal | Continuity | 2K and 1J or 2P | Yes | Yes | Go to next step |
| Terminal | Continuity | | | | | | |
| 2K and 1J or 2P | Yes | | | | | | |
| | | No | Replace EC-AT control unit | | | | |
| 7 | <p>Apply 12V to 2K terminal of EC-AT control unit</p> <p>Start engine in P range and let it idle</p> <p>Shift to D range and check if engine stalls</p> | Yes | Go to next step | | | | |
| | | No | Replace lockup solenoid valve | | | | |




| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 8 | Measure resistance while warming up ATF (driving vehicle) Check for correct resistance between G terminal and J or 2P terminals of EC-AT control unit | Yes | Go to Step 10 |
| | | No | Go to next step |
| 9 | Check for correct resistance between terminals of ATF thermosensor ↗ page K2-142 | Yes | Check for poor connection at connectors ⇨ If OK, try known good EC-AT control unit or ATF thermosensor and go to next step ⇨ If not OK, replace wiring |
| |  | No | Go to next step |
| 10 | Check if time lag is within specification at idle ↗ page K2-122 Time lag N → D: 0.5—1.0 second N → R: 0.6—1.0 second | Yes | Go to next step |
| |  | No | Check for cause (Refer to Evaluation) ↗ page K2-122 |
| 11 | Check if engine stall speed is OK ↗ page K2-119 Engine stall speed: 2,550—2,650 rpm | Yes | Go to next step |
| |  | No | Check for cause (Refer to Evaluation) ↗ page K2-121 |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | |
|-------|---|-------------------------------------|--|--|------|-------|-------|-----------------------------|----------------------------------|---|------------------------------|-------------------------------------|-------|--|--|------|-------|---|--------------------------|-----------------------------|----------------------|---|
| 12 | <p>Check if line pressure and throttle pressure are within specification</p> <p style="text-align: right;">☞ page K2-123 125</p> <p>Line pressure:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D,S,L</td> <td>353—432 (3.6—4.4, 51—63)</td> <td>873—1,040 (8.9—10.6, 127—151)</td> </tr> <tr> <td>R</td> <td>598—942 (6.1—9.6, 87—137)</td> <td>1,668—2,011 (17.0—20.5, 242—292)</td> </tr> </tbody> </table> <p>Throttle pressure:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Range</th> <th colspan="2">Throttle pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>39—88 (0.4—0.9, 6—13)</td> <td>471—589 (4.8—6.0, 68—85)</td> </tr> </tbody> </table> | Range | Line pressure kPa (kg/cm ² , psi) | | Idle | Stall | D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | Range | Throttle pressure kPa (kg/cm ² , psi) | | Idle | Stall | D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check for cause (Refer to Evaluation) ☞ page K2-124 126</p> |
| Range | Line pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D,S,L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) | | | | | | | | | | | | | | | | | | | | |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) | | | | | | | | | | | | | | | | | | | | |
| Range | Throttle pressure kPa (kg/cm ² , psi) | | | | | | | | | | | | | | | | | | | | | |
| | Idle | Stall | | | | | | | | | | | | | | | | | | | | |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) | | | | | | | | | | | | | | | | | | | | |
| 13 | <p>Try known good EC-AT control unit, control valve assembly, or replace transaxle</p> | | | | | | | | | | | | | | | | | | | | | |






03U0K2-046

| 21 | | HOLD INDICATOR LAMP FLASHES | | | | | | | | | | | | | | | | | |
|--|---|---|-------------------------|----|----------------------|----|-----------------|----|-----------------|----|--------------------------|----|--------------------------|----|--------------------------|----|-----------------------|-----|---|
| DESCRIPTION | | • Malfunction in EC-AT system component (Vehicle speed sensor, pulse generator, shift signal, or solenoid valve(s)) | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] Check for Malfunction Code No. and repair system (Refer to SELF-DIAGNOSIS FUNCTION; page K2-104) | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | |
| 1 | Connect EC-AT Tester to diagnosis connector and set TEST SW to SELF TEST Check if Malfunction Code No. is displayed <table border="1"> <thead> <tr> <th>Code No.</th> <th>LOCATION OF MALFUNCTION</th> </tr> </thead> <tbody> <tr> <td>06</td> <td>Vehicle speed sensor</td> </tr> <tr> <td>12</td> <td>Throttle sensor</td> </tr> <tr> <td>55</td> <td>Pulse generator</td> </tr> <tr> <td>60</td> <td>1-2 shift solenoid valve</td> </tr> <tr> <td>61</td> <td>2-3 shift solenoid valve</td> </tr> <tr> <td>62</td> <td>3-4 shift solenoid valve</td> </tr> <tr> <td>63</td> <td>Lockup solenoid valve</td> </tr> </tbody> </table> | Code No. | LOCATION OF MALFUNCTION | 06 | Vehicle speed sensor | 12 | Throttle sensor | 55 | Pulse generator | 60 | 1-2 shift solenoid valve | 61 | 2-3 shift solenoid valve | 62 | 3-4 shift solenoid valve | 63 | Lockup solenoid valve | Yes | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108 |
| | | Code No. | LOCATION OF MALFUNCTION | | | | | | | | | | | | | | | | |
| 06 | Vehicle speed sensor | | | | | | | | | | | | | | | | | | |
| 12 | Throttle sensor | | | | | | | | | | | | | | | | | | |
| 55 | Pulse generator | | | | | | | | | | | | | | | | | | |
| 60 | 1-2 shift solenoid valve | | | | | | | | | | | | | | | | | | |
| 61 | 2-3 shift solenoid valve | | | | | | | | | | | | | | | | | | |
| 62 | 3-4 shift solenoid valve | | | | | | | | | | | | | | | | | | |
| 63 | Lockup solenoid valve | | | | | | | | | | | | | | | | | | |
| No | No Code No. displayed Check main relay, and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between terminal 1C of EC-AT control unit and diagnosis connector ⇒ If OK, replace EC-AT control unit ⇒ If not OK, repair wiring | | | | | | | | | | | | | | | | | | |



03U0K2-047



| 22 | ENGINE WILL NOT START IN N OR P RANGE OR WILL START IN OTHER RANGES | | | | | |
|--|---|---|-----|-----------------|----|---|
| [TROUBLESHOOTING HINTS] ① Inhibitor switch worn or misadjusted ② Selector lever misinstalled or misadjusted | | | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Check if selector lever operation is OK ☞ page *K-264  | <table border="0" style="width: 100%;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Go to next step</td> </tr> <tr> <td style="width: 10%; text-align: center;">No</td> <td>Adjust or repair selector lever ☞ page *K-264</td> </tr> </table> | Yes | Go to next step | No | Adjust or repair selector lever ☞ page *K-264 |
| Yes | Go to next step | | | | | |
| No | Adjust or repair selector lever ☞ page *K-264 | | | | | |
| 2 | Check if "00" is displayed on EC-AT Tester with ignition switch ON ☞ page K2-106  | <table border="0" style="width: 100%;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Go to next step</td> </tr> <tr> <td style="width: 10%; text-align: center;">No</td> <td> Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring </td> </tr> </table> | Yes | Go to next step | No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring |
| Yes | Go to next step | | | | | |
| No | Malfunction Code No. displayed Check for cause (Refer to specified check sequence) ☞ page K2-108 No Code No. displayed Check main relay and voltage of terminals 2Q and 2S of EC-AT control unit Voltage: Approx. 12V (Ignition switch ON) "88" flashes Check wiring between 1C terminal of EC-AT control unit and diagnosis connector ⇨ If OK, replace EC-AT control unit ⇨ If not OK, repair wiring | | | | | |
| 3 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially inhibitor switch) ☞ page K2-115 | <table border="0" style="width: 100%;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Go to Step 7</td> </tr> <tr> <td style="width: 10%; text-align: center;">No</td> <td> No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause </td> </tr> </table> | Yes | Go to Step 7 | No | No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause |
| Yes | Go to Step 7 | | | | | |
| No | No indication at all lamps ⇨ Go to next step Individual lamp(s) does not illuminate ⇨ Check for cause | | | | | |
| 4 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ☞ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | <table border="0" style="width: 100%;"> <tr> <td style="width: 10%; text-align: center;">Yes</td> <td>Go to next step</td> </tr> <tr> <td style="width: 10%; text-align: center;">No</td> <td>Repair wiring</td> </tr> </table> | Yes | Go to next step | No | Repair wiring |
| Yes | Go to next step | | | | | |
| No | Repair wiring | | | | | |




* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 5 | <p>Check if voltage at 2B, 2D, 2F, and 2H terminals of EC-AT control unit is OK  page K2-144</p> <p>Voltage: Approx. 12V (D,S,L range switch ON) Below 1.5V (P or N range switch ON)</p>  | Yes | Check other cause of malfunction |
| | | No | Go to next step |
| 6 | <p>Check for correct continuity between each terminal of inhibitor switch and terminal of EC-AT control unit</p> | Yes | Go to next step |
| | | No | Repair wiring |
| 7 | <p>Check if operation of inhibitor switch is OK  page K2-140</p>  | Yes | <p>Check for open or short circuit of wiring and poor connection at connectors</p> <p>⇒ If OK, go to next step ⇒ If not OK repair wiring</p> |
| | | No | <p>Replace inhibitor switch  page K2-141</p> |
| 8 | <p>Check other cause of malfunction or try known good EC-AT control unit and see if condition improves</p> | | |




03U0K2-048

| 23 | ENGINE STALLS WHEN SHIFTED TO D, S, L, AND R RANGES | | |
|---|---|-----|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine stalls when shifting from N or P range to D, S, L, or R range and strong shift shock • Engine will start and run in P and N ranges | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① Engine idle speed misadjusted ② Stoplight switch or circuit shorted ③ Inhibitor switch worn or misadjusted ④ Pulse generator malfunction ⑤ Lockup solenoid stuck ⑥ Lockup control valve stuck ⑦ Powertrain slippage (Forward clutch) ⑧ Torque converter worn | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially inhibitor switch, stoplight switch, lockup solenoid valve and drum speed) | Yes | Go to Steps 3, 6, 9, 12, 15 and 16 in sequence |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 2 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ➤ page K2-144 Voltage: Approx. 12V (Ignition switch ON)  | Yes | Go to next step |
| | | No | Repair wiring |
| 3 | Drive vehicle above 80 km/h (50 mph) in D range OD Check if voltage at 2K terminal of EC-AT control unit is OK ➤ page K2-144 Voltage: Approx. 12V (Lockup solenoid ON [Lockup])  | Yes | Go to Step 6 |
| | | No | Go to next step |


| STEP | INSPECTION | | ACTION | | | | |
|-----------------|--|--|---|-----------------|-----|-----|-----------------|
| 4 | Check if continuity of transistor in EC-AT control unit is OK <table border="1" data-bbox="156 243 682 309"> <thead> <tr> <th data-bbox="156 243 415 276">Terminal</th> <th data-bbox="415 243 682 276">Continuity</th> </tr> </thead> <tbody> <tr> <td data-bbox="156 276 415 309">2K and 1J or 2P</td> <td data-bbox="415 276 682 309">Yes</td> </tr> </tbody> </table> | Terminal | Continuity | 2K and 1J or 2P | Yes | Yes | Go to next step |
| | Terminal | Continuity | | | | | |
| 2K and 1J or 2P | Yes | | | | | | |
| No | Replace EC-AT control unit | | | | | | |
| 5 | Apply 12V to 2K terminal of EC-AT control unit Start engine in P range and let it idle Shift to D range and check if engine stalls | Yes | Go to next step | | | | |
| | No | Replace solenoid valve | | | | | |
| 6 | Disconnect 20-pin connector of EC-AT control unit Check if resistance between 2J and 2L terminals of EC-AT control unit is OK Resistance: 200—400Ω | Yes | Go to Step 8 | | | | |
| | No | Go to next step | | | | | |
| 7 | Check if resistance of pulse generator is OK  Resistance: 200—400Ω | Yes | Check for poor connection at connectors and go to next step | | | | |
| | No | Replace pulse generator  | | | | | |

| STEP | INSPECTION | | ACTION | | | | | | |
|-----------|--|--------|---|-----------|-----|----------|----|-----|--|
| 8 | Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit Check if pulse display is OK  | Yes | Go to next step | | | | | | |
| | | No | Very low voltage: Replace pulse generator | | | | | | |
| | | | Noise in wave form: Check for improper grounding of shield-wiring or replace pulse generator | | | | | | |
| 9 | Check if voltage at 1F terminal of EC-AT control is OK Voltage: Approx. 12V (Brake pedal depressed)  | Yes | Go to Step 12 | | | | | | |
| | | No | Go to next step | | | | | | |
| 10 | Check for continuity between terminal 1F of EC-AT control unit and stoplight switch | Yes | Go to next step | | | | | | |
| | | No | Repair wiring | | | | | | |
| 11 | Check if operation of stoplight switch is OK ⇨ page *T-45 <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 50%;">Switch</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Depressed</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">Released</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>  | Switch | Continuity | Depressed | Yes | Released | No | Yes | Check for short or open circuit of wiring and poor connection at connector ⇨ If OK, go to next step ⇨ If not OK, repair wiring |
| | | Switch | Continuity | | | | | | |
| Depressed | Yes | | | | | | | | |
| Released | No | | | | | | | | |
| No | Replace stoplight switch | | | | | | | | |

* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 12 | Check if voltage at 2B, 2D, 2F, and 2H terminal of EC-AT control unit is OK ☞ page K2-144 Voltage: Approx. 12V (D,S,L ranges switch ON) Below. 1.5V (P or N ranges switch ON) | Yes | Go to Step 15 |
| |  | No | Go to next step |
| 13 | Check if continuity between each terminal of inhibitor switch and terminal of EC-AT control unit is OK | Yes | Go to next step |
| | | No | Repair or replace wiring |
| 14 | Check if operation of inhibitor switch is OK ☞ page K2-140 | Yes | Check for open or short circuit of wiring and poor connection at connectors ⇨ If OK, go to next step ⇨ If not OK, repair or replace |
| |  | No | Replace inhibitor switch ☞ page K2-141 |
| 15 | Check if ignition timing at idle is OK ☞ page *F-72 Ignition timing (BTDC): $7 \pm 1^\circ$ | Yes | Check for correct idle speed ☞ page *F-72 Idle speed: 750 ± 50 rpm (with parking brake applied) ⇨ If OK, go to next step ⇨ If not OK, adjust idle speed ☞ page *F-72 |
| |  | No | Adjust ignition timing ☞ page *F-72 |

* Refer to 1990 323 Workshop Manual (1195-10-89E).



| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 16 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm  | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |
| 17 | Check engine control system or Try known good EC-AT control unit, control valve assembly or replace transaxle | | |




03U0K2-049

| 24 | ENGINE STALLS WHEN BRAKE PEDAL DEPRESSED WHILE DRIVING AT LOW SPEED OR STOPPING | | |
|--|---|-----|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stalls with strong shift shock | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① Engine idle speed misadjusted ② ATF thermosensor malfunction ③ Pulse generator malfunction ④ Lockup solenoid stuck ⑤ Lockup control valve stuck ⑥ Torque converter worn ⑦ Hydraulic circuit clogged or leaking | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Connect EC-AT Tester to EC-AT control unit Check if all output and input component indications are correct (Especially lockup solenoid valve, ATF thermosensor, and drum speed) | Yes | Go to Steps 3, 6, 9, 10 and 12 in sequence |
| | | No | No indication at all lamps ⇒ Go to next step Individual lamp(s) does not illuminate ⇒ Check for cause |
| 2 | Check if voltage at 2Q and 2S terminals of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Ignition switch ON) | Yes | Go to next step |
| | | No | Repair wiring |
| 3 | Drive vehicle above 80 km/h (50 mph) in D range OD Check if voltage at 2K terminal of EC-AT control unit is OK ↗ page K2-144 Voltage: Approx. 12V (Lockup solenoid ON [Lockup]) | Yes | Go to Step 6 |
| | | No | Go to next step |




| STEP | INSPECTION | | ACTION | | | | |
|-----------------|--|----------|---|-----------------|-----|-----|-----------------|
| 4 | Check if continuity of transistor in EC-AT control unit is OK <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="padding: 2px;">Terminal</td> <td style="padding: 2px;">Continuity</td> </tr> <tr> <td style="padding: 2px;">2K and 1J or 2P</td> <td style="padding: 2px;">Yes</td> </tr> </table> | Terminal | Continuity | 2K and 1J or 2P | Yes | Yes | Go to next step |
| | | Terminal | Continuity | | | | |
| 2K and 1J or 2P | Yes | | | | | | |
| No | Replace EC-AT control unit | | | | | | |
| 5 | Apply 12V to 2K terminal of EC-AT control unit Start engine in P range and let it idle Shift to D range and check if engine stalls | Yes | Go to next step | | | | |
| | | No | Replace solenoid valve | | | | |
| 6 | Disconnect 20-pin connector of EC-AT control unit Check if resistance between 2J terminal and 2L terminals of EC-AT control unit is OK Resistance: 200—400Ω | Yes | Go to Step 9 | | | | |
| | | No | Go to next step | | | | |
| 7 | Check if resistance of pulse generator is OK ➤ page K2-142 Resistance: 200—400Ω | Yes | Check for poor connection at connectors and go to next step | | | | |
| | | No | Replace pulse generator | | | | |



| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 8 | Connect oscilloscope ground terminal to 2L terminal of EC-AT control unit, and oscilloscope input terminal to 2J terminal of EC-AT control unit Check if pulse display is OK  | Yes | Go to next step |
| | | No | Very low voltage: Replace pulse generator |
| | | | Noise in wave form Check improper grounding of shield-wiring or replace pulse generator |
| 9 | Check if ignition timing at idle is OK ☞ page *F-72 Ignition timing (BTDC): $7 \pm 1^\circ$  | Yes | Check for correct idle speed ☞ page *F-72 Idle speed: 750 ± 50 rpm (with parking brake applied) ⇒ If OK, go to next step ⇒ If not OK, adjust idle speed ☞ page *F-72 |
| | | No | Adjust ignition timing ☞ page *F-72 |
| 10 | Measure resistance while warming up ATF (driving vehicle) Check for correct resistance between 1G terminal and J or 2P terminals of EC-AT control unit | Yes | Go to Step 12 |
| | | No | Go to next step |
| 11 | Check for correct resistance between terminal and terminals of ATF thermosensor  | Yes | Check for poor connection at connectors ⇒ If OK, try known good EC-AT control unit or ATF thermosensor and go to next step ⇒ If not OK, repair wiring |
| | | No | Go to next step |

* Refer to 1990 323 Workshop Manual (1195-10-89E).

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 12 | Check if engine stall speed is OK ☞ page K2-119 Engine stall speed: 2,550—2,650 rpm <div style="text-align: center;">  </div> | Yes | Go to next step |
| | | No | Check for cause (Refer to Evaluation) ☞ page K2-121 |
| 13 | Try known good EC-AT control unit, control valve assembly, or replace transaxle | | |

03U0K2-050

SELF-DIAGNOSIS FUNCTION

DESCRIPTION

The self-diagnostic system integrated in the EC-AT control unit diagnoses malfunction of the main sensors (input) and solenoid valves (output) and the EC-AT control unit.

Malfunions or intermittent malfunions are memorized in the EC-AT control unit to later be output as malfunction codes.


The **EC-AT Tester and EC-AT Selector** are used to retrieve these malfunction codes. Each malfunction is indicated by a code number and the buzzer.

Use the plate 323 2WD model.

03U0K2-308

PREPARATION


SST

| | |
|---|---|
| <p>49 B019 9A0</p> <p>System Selector</p>  | <p>For inspection of input and output devices</p> |
|---|---|


03U0KX-049

EC-AT TESTER


Components




03U0KX-050




03U0KX-051



03U0K2-051



03U0KX-053



03U0K2-052

Assembly of EC-AT Tester

For EC-AT tester body (49 G019 901) and adapter unit (49 H019 902)

1. Connect the **EC-AT selector** (49 B019 9A1) to the assembled **EC-AT tester body** (49 G019 901) and **adapter unit** (49 H019 902).

2. Place the **panel** (49 B019 905) onto the assembled EC-AT tester.

3. Set the code switch on the adapter unit to position A.

4. Set the vehicle switch on the adapter unit to the 323 position.

5. Set the vehicle switch on the EC-AT selector to position 1.

For EC-AT tester body (49 G019 901A)


1. Connect the **EC-AT selector** (49 B019 9A1) to the **EC-AT tester body** (49 G019 901A).

2. Place the **panel** (49 B019 904) onto the EC-AT Tester body.


3. Set the code switch on the EC-AT Tester to position A.

4. Set the vehicle switch on the EC-AT Tester to the 323 position.


5. Set the vehicle switch on the EC-AT selector to position 1.



03U0KX-055



03U0KX-056



03U0K2-053

MALFUNCTION CODE NUMBER**Inspection procedure**

1. Connect the **SST** to the diagnosis connector.
2. Connect the **EC-AT Tester** to the System Selector connector and a ground.
3. Set the **EC-AT Tester** code selector switch to position A.
4. Set the System Selector to position 2 and SELF TEST as shown.
5. Turn the ignition switch ON.
6. Check that **"88"** flashes on the digital display and that the buzzer sounds for **3 seconds**.
7. If **"88"** does not flash, check the diagnosis connector wiring.
8. If **"88"** flashes and the buzzer sounds continuously for more than **20 seconds**, check the wiring to terminal 1C of the EC-AT control unit for a short-circuit. If necessary, replace the EC-AT control unit and repeat from Step 2.
9. Note any code number(s) and check for the cause(s). Repair as necessary. (Refer to page K2-108.)

Note

- After repairs are made, recheck for code numbers by performing the After-repair Procedure. (Refer to page K2-115.)


06 → 4-SEC. PERIOD →
62 → 4-SEC. PERIOD →
64 → 4-SEC. PERIOD →
REPEATS ABOVE

03U0KX-058


WHEN THE CHECK CONNECTOR IS NOT GROUNDED

| | | |
|--------------------------------|------------|--|
| MALFUNCTIONS | YES | |
| | NO | |
| HOLD INDICATOR FLASHING | YES | |
| | NO | |
| MEMORY IN CONTROL UNIT | YES | |
| | NO | |

03U0KX-059



9MU0K1-027



03U0KX-060














GENERAL NOTES

1. If there is more than one malfunction, the code numbers will be indicated in numerical order, lowest number first.
2. The HOLD indicator flashes to indicate the same pattern as the buzzer of the **EC-AT Tester** (49 G019 901A). When the check connector is not grounded, the indicator flashes at a constant frequency until the malfunction recovers. However, the malfunction code is memorized in the EC-AT control unit.
3. The EC-AT control unit has a built-in fail-safe function for the throttle sensor, the speed sensors, and all the solenoids. If a malfunction occurs, the EC-AT control unit will control operation of the remaining components according to a preset fail-safe program. The vehicle may still be driven, although driving performance will be slightly affected.
4. The memory of malfunction codes is canceled when the negative battery cable is disconnected for approximately five seconds and the brake pedal is depressed.

Troubleshooting

If a malfunction code number is shown on the **SST**, check for the cause by using the chart related to the code number shown.

Malfunction code number

| CODE No. | LOCATION OF MALFUNCTION | BUZZER | | SELF-DIAGNOSIS | FAIL-SAFE |
|----------|--------------------------|---|---|--|---|
| | | 49 G019 901 TESTER BODY | 49 G019 901A TESTER BODY | | |
| 06 | Vehicle speed sensor |  |  | No input signal from speed sensor while driving at drum speed above 600 rpm in D, S or L ranges | Shifting performed normally |
| 12 | Throttle sensor |  |  | Open circuit when accelerator depressed (idle switch: OFF) or incorrect adjustment | Throttle opening judged as 4/8 stroke Lockup not provided |
| 55 | Pulse generator |  |  | No input signal from pulse generator while driving at 40 km/h (25 mph) or higher in D, S or L ranges | Shifting performed in accordance with signals from vehicle speed sensor |
| 60 | 1-2 shift solenoid valve |  |  | Open or short-circuit of transistor within EC-AT control unit or solenoid valve wiring | Solenoid valve(s) performs the shifting with as little interference as possible with driving performance Lockup not provided |
| 61 | 2-3 shift solenoid valve |  |  | | |
| 62 | 3-4 shift solenoid valve |  |  | | |
| 63 | Lockup solenoid valve |  |  | | |


03U0K2-054

| CODE No.06 VEHICLE SPEED SENSOR | | | |
|---------------------------------|---|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Are there any poor connections in vehicle speed sensor circuit? | Yes | Repair connector and/or wiring |
| | | No | Go to next step |
| 2 | Does EC-AT Tester display vehicle speed? (Refer to page K2-116) | Yes | Vehicle speed sensor OK Cancel memory of code number or replace EC-AT control unit |
| | | No | Go to next step |
| 3 | Does vehicle speed sensor operate correctly? (Refer to page *T-67) | Yes | Check for open or short circuit in wiring from speedometer to EC-AT control unit |
| | | No | Replace speed sensor (Refer to page *T-67) |

* Refer to 1990 323 Workshop Manual (1195-10-89E).

03U0K2-055

Circuit Diagram



03U0KX-063


CODE No.12 THROTTLE SENSOR

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 1 | Are there any poor connections in throttle sensor circuit? | Yes | Repair connector and/or wiring |
| | | No | Go to next step |
| 2 | Does EC-AT Tester display throttle sensor voltage? (Refer to page K2-116) | Yes | Throttle sensor OK Cancel memory of code number or replace EC-AT control unit |
| | | No | Go to next step |
| 3 | Is variable resistor of throttle sensor OK? (Refer to page *F-143) | Yes | Check for open or short circuit in wiring from throttle sensor to EC-AT control unit |
| | | No | Replace throttle sensor |

* Refer to 1990 323 Workshop Manual (1195-10-89E).

03U0K2-056

Circuit Diagram




03U0KX-065

| CODE No.55 PULSE GENERATOR | | | |
|----------------------------|---|--------|--|
| STEP | INSPECTION | ACTION | |
| 1 | Are there any poor connections in pulse generator circuit? | Yes | Repair connector and/or wiring |
| | | No | Go to next step |
| 2 | Does EC-AT Tester display drum speed? | Yes | Pulse generator OK Cancel memory of code number or replace EC-AT control unit |
| | | No | Go to next step |
| 3 | Is resistance of pulse generator OK? Resistance: 200—400Ω | Yes | Check for open or short circuit in wiring from pulse generator to EC-AT control unit |
| | | No | Replace pulse generator |

03U0K2-057

Circuit Diagram



03U0KX-067

CODE No.60 1-2 SHIFT SOLENOID VALVE

| STEP | INSPECTION | | ACTION | | | | |
|-----------------|---|----------|---|-----------------|--------|--|--|
| 1 | Are there any poor connections in 1-2 shift solenoid valve circuit? | Yes | Repair connector and/or wiring | | | | |
| | | No | Go to next step | | | | |
| 2 | Does EC-AT Tester 1-2 solenoid valve lamp illuminate as shown in solenoid valve operation table? (Refer to page K2-117) | Yes | 1-2 shift solenoid valve OK Cancel memory of code number | | | | |
| | | No | Go to next step | | | | |
| 3 | Is there continuity of transistor in EC-AT control unit? | Yes | Go to next step | | | | |
| | | No | Replace EC-AT control unit then continue with next step | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Continuity</td> </tr> <tr> <td>2E and 1J or 2P</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2E and 1J or 2P | Yes | | |
| Terminal | Continuity | | | | | | |
| 2E and 1J or 2P | Yes | | | | | | |
| 4 | Is resistance of 1-2 shift solenoid valve OK? | Yes | Go to Step 6 | | | | |
| | | No | Go to next step | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Resistance</td> </tr> <tr> <td>A and ground</td> <td>13—27Ω</td> </tr> </table> | Terminal | Resistance | A and ground | 13—27Ω | | |
| Terminal | Resistance | | | | | | |
| A and ground | 13—27Ω | | | | | | |
| 5 | Are there any poor connections at connector in transaxle? | Yes | Repair connector | | | | |
| | | No | Go to next step | | | | |
| 6 | Is there continuity between terminal of EC-AT control unit connector and ground? | Yes | Replace EC-AT control unit | | | | |
| | | No | Check for open circuit in wiring | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Continuity</td> </tr> <tr> <td>2E and ground</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2E and ground | Yes | | |
| Terminal | Continuity | | | | | | |
| 2E and ground | Yes | | | | | | |

03U0K2-058

CODE No.61 2-3 SHIFT SOLENOID VALVE

| STEP | INSPECTION | | ACTION | | | | |
|-----------------|---|----------|---|-----------------|--------|--|--|
| 1 | Are there any poor connections in 2-3 shift solenoid valve circuit? | Yes | Repair connector and/or wiring | | | | |
| | | No | Go to next step | | | | |
| 2 | Does EC-AT Tester 2-3 solenoid valve lamp illuminate as shown in solenoid valve operation table? (Refer to page K2-117) | Yes | 2-3 shift solenoid valve OK Cancel memory of code number | | | | |
| | | No | Go to next step | | | | |
| 3 | Is there continuity of transistor in EC-AT control unit? | Yes | Go to next step | | | | |
| | | No | Replace EC-AT control unit and continue with next step | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Continuity</td> </tr> <tr> <td>2G and 1J or 2P</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2G and 1J or 2P | Yes | | |
| Terminal | Continuity | | | | | | |
| 2G and 1J or 2P | Yes | | | | | | |
| 4 | Is resistance of 2-3 shift solenoid valve OK? | Yes | Go to Step 6 | | | | |
| | | No | Go to next step | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Resistance</td> </tr> <tr> <td>B and ground</td> <td>13—27Ω</td> </tr> </table> | Terminal | Resistance | B and ground | 13—27Ω | | |
| Terminal | Resistance | | | | | | |
| B and ground | 13—27Ω | | | | | | |
| 5 | Are there any poor connections at connector in transaxle? | Yes | Repair connector | | | | |
| | | No | Go to next step | | | | |
| 6 | Is there continuity between terminal of EC-AT control unit connector and ground? | Yes | Replace EC-AT control unit | | | | |
| | | No | Check for open circuit in wiring | | | | |
| | <table border="1"> <tr> <td>Terminal</td> <td>Continuity</td> </tr> <tr> <td>2G and ground</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2G and ground | Yes | | |
| Terminal | Continuity | | | | | | |
| 2G and ground | Yes | | | | | | |

03U0K2-059


| CODE No.62 3-4 SHIFT SOLENOID VALVE | | | | | | | |
|-------------------------------------|---|----------|---|-----------------|---------|-----|----------------------------|
| STEP | INSPECTION | | ACTION | | | | |
| 1 | Are there any poor connections in 3-4 shift solenoid valve circuit? | Yes | Repair connector and/or wiring | | | | |
| | | No | Go to next step | | | | |
| 2 | Does EC-AT Tester 3-4 solenoid valve lamp illuminate as shown in solenoid valve operation table? (Refer to page K2-117) | Yes | 3-4 shift solenoid valve OK Cancel memory of code number | | | | |
| | | No | Go to next step | | | | |
| 3 | Is there continuity of transistor in EC-AT control unit? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Continuity</td> </tr> <tr> <td>2I and 1J or 2P</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2I and 1J or 2P | Yes | Yes | Go to next step |
| | | Terminal | Continuity | | | | |
| 2I and 1J or 2P | Yes | | | | | | |
| No | Replace EC-AT control unit and continue with next step | | | | | | |
| 4 | Is resistance of 3-4 shift solenoid valve OK? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Resistance</td> </tr> <tr> <td>D and ground</td> <td>13--27Ω</td> </tr> </table> | Terminal | Resistance | D and ground | 13--27Ω | Yes | Go to Step 6 |
| | | Terminal | Resistance | | | | |
| D and ground | 13--27Ω | | | | | | |
| No | Go to next step | | | | | | |
| 5 | Are there any poor connections at connector in transaxle? | Yes | Repair connector | | | | |
| | | No | Go to next step | | | | |
| 6 | Is there continuity between terminal of EC-AT control unit connector and ground? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Continuity</td> </tr> <tr> <td>2I and ground</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2I and ground | Yes | Yes | Replace EC-AT control unit |
| | | Terminal | Continuity | | | | |
| 2I and ground | Yes | | | | | | |
| No | Check for open circuit in wiring | | | | | | |


03U0K2-060

| CODE No.63 LOCKUP SOLENOID VALVE | | | | | | | |
|----------------------------------|---|----------|--|-----------------|---------|-----|----------------------------|
| STEP | INSPECTION | | ACTION | | | | |
| 1 | Are there any poor connections in lockup solenoid valve circuit? | Yes | Repair connector and/or wiring | | | | |
| | | No | Go to next step | | | | |
| 2 | Does EC-AT Tester lockup solenoid valve lamp illuminate as shown in solenoid valve operation table? (Refer to page K2-117) | Yes | Lockup solenoid valve OK Cancel memory of code number | | | | |
| | | No | Go to next step | | | | |
| 3 | Is there continuity of transistor in EC-AT control unit? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Continuity</td> </tr> <tr> <td>2K and 1J or 2P</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2K and 1J or 2P | Yes | Yes | Go to next step |
| | | Terminal | Continuity | | | | |
| 2K and 1J or 2P | Yes | | | | | | |
| No | Replace EC-AT control unit then continue with next step | | | | | | |
| 4 | Is resistance of lockup solenoid valve OK? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Resistance</td> </tr> <tr> <td>E and ground</td> <td>13--27Ω</td> </tr> </table> | Terminal | Resistance | E and ground | 13--27Ω | Yes | Go to Step 6 |
| | | Terminal | Resistance | | | | |
| E and ground | 13--27Ω | | | | | | |
| No | Go to next step | | | | | | |
| 5 | Are there any poor connections at connector in transaxle? | Yes | Repair connector | | | | |
| | | No | Go to next step | | | | |
| 6 | Is there continuity between terminal of EC-AT control unit connector and ground? <table border="1" style="width: 100%; margin: 5px 0;"> <tr> <td style="width: 50%;">Terminal</td> <td style="width: 50%;">Continuity</td> </tr> <tr> <td>2K and ground</td> <td>Yes</td> </tr> </table> | Terminal | Continuity | 2K and ground | Yes | Yes | Replace EC-AT control unit |
| | | Terminal | Continuity | | | | |
| 2K and ground | Yes | | | | | | |
| No | Check for open circuit in wiring | | | | | | |

03U0K2-061

Circuit Diagram






03U0KX-075

DRIVE AT 50 km/h (31 mph)


KICKDOWN

STOP THE VEHICLE


79G07C-069



03U0KX-076



03U0KX-077



03U0K2-062

After-repair Procedure

1. Cancel the memory of malfunctions by disconnecting the negative battery cable for at least **five seconds** and depressing the brake pedal. Reconnect the battery cable.
2. Remove the **EC-AT Tester** if it is connected.

3. Drive the vehicle at 50 km/h (31 mph), then depress the accelerator pedal fully to activate kickdown. Stop the vehicle gradually.

4. Connect the **SSTs** to the diagnosis connector as shown.
5. Turn the ignition switch ON.
6. Verify that no code numbers are displayed.

ELECTRICAL SIGNAL INSPECTION

In this step, the input and output signals are checked with the EC-AT Tester.

The tester checks for proper operation of the various switches and sensors in the EC-AT system. It also checks the EC-AT control unit for output of the various control signals.

INSPECTION PROCEDURE

1. Assemble the EC-AT Tester. (Refer to page K2-104.)
2. Disconnect the connectors from the EC-AT control unit.
3. Connect the harness between the control unit and the connectors.
4. Turn the vehicle ignition switch and main switch of the EC-AT Tester ON.
5. Verify indication of the respective light or digital display in each condition, referring to the indication table on the following page.

Indication Table of Light and Digital Display

| Item | | Specified indication | Test condition | If incorrect, possible cause |
|--------------------------------|---|----------------------|--|--|
| Input (Light) | | | | |
| INHIBITOR SW | P,N | ON | P or N ranges | Inhibitor or wiring |
| | | OFF | Other ranges | |
| | D | ON | D range | |
| | | OFF | Other ranges | |
| | S | ON | S range | |
| | | OFF | Other ranges | |
| | L | ON | L range | |
| | | OFF | Other ranges | |
| WATER THERMO SW | | ON | Water temperature above 72°C (162°F) | EC-AT control unit, engine control unit, or wiring |
| | | OFF | Water temperature below 72°C (162°F) | |
| ATF THERMOSENSOR | | ON | ATF temperature above 142—148°C (288—298°F) | ATF thermostwitch or wiring |
| | | OFF | ATF temperature below 138°C (280°F) | |
| HOLD SW | | ON | Hold switch released | Hold switch or wiring |
| | | OFF | Hold switch depressed | |
| IDLE SW | | ON | Throttle valve fully closed | Idle switch or wiring |
| | | OFF | Throttle valve open | |
| STOPLIGHT SW | | ON | Brake pedal depressed | Stoplight switch or wiring |
| | | OFF | Brake pedal released | |
| Input (Digital display) | | | | |
| THROTTLE SENSOR | EC-AT control unit terminal voltage | Constant | Throttle sensor, idle switch, or wiring | |
| VEHICLE SPEED* | Vehicle speed calculated from speed sensor signal | Constant | Vehicle speed sensor, speedometer cable, or wiring | |
| DRUM SPEED* | Drum speed | Constant | Pulse generator or wiring | |

03U0K2-063

Note

* Item must be checked with engine running or while driving.

| Item | Specified indication | Test condition | If incorrect possible cause |
|-------------------------------------|----------------------|---|---|
| Output (Light) | | | |
| 1-2 SOLENOID VALVE* ¹ | ON | Refer to Solenoid valve operation table (Refer to page K2-118) | EC-AT control unit, 1-2 shift solenoid, or wiring |
| | OFF | | |
| 2-3 SOLENOID VALVE* ¹ | ON | | EC-AT control unit, 2-3 shift solenoid, or wiring |
| | OFF | | |
| 3-4 SOLENOID VALVE* ¹ | ON | | EC-AT control unit, 3-4 shift solenoid, or wiring |
| | OFF | | |
| LOCKUP SOLENOID VALVE* ¹ | ON | Lockup condition | EC-AT control unit, lock-up solenoid, or wiring |
| | OFF | Non-Lockup condition | |
| SHIFT* ² | Not used | | |
| HOLD INDICATOR | ON | Hold mode | EC-AT control unit, hold switch, or wiring |
| | OFF | Normal mode | |

03U0K2-064

| Item | Specified indication | Test condition |
|---------------------------------|----------------------|----------------|
| Output (Digital display) | | |
| GEAR* ¹ | 1 | 1st |
| | 2 | 2nd |
| | 3 | 3rd |
| | 4 | Overdrive (OD) |

03U0K2-065

Note*¹ Item must be checked with the engine running or while driving.*² 2WD only.

Comprehensive usage

The EC-AT Tester is used to inspect for slippage of friction elements, shift points, and shift sequence of the transaxle.

The following inspection must be done while driving the vehicle.

03U0KX-082



Solenoid valve operation table

| Range | Gear | | Specified light indication and Solenoid valve operation | | | | |
|-------|---------|---|---|-----|-----|--------|----|
| | | | 1-2 | 2-3 | 3-4 | Lockup | |
| P | — | | | ON | ON | | |
| R | Reverse | | ON | | | | |
| N | — | Below approx. 4 km/h (2.5 mph) | | | ON | | |
| | | Above approx. 5 km/h (3 mph) | ON | | | | |
| D | 1st | | | ON | ON | | |
| | 2nd | | ON | ON | ON | | |
| | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | |
| | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | |
| | OD | Lockup OFF | ON | | ON | | |
| | | Lockup ON | ON | | ON | ON | |
| S | 1st | | | ON | ON | | |
| | 2nd | | ON | ON | ON | | |
| | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | | |
| | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | | |
| | | Lockup OFF | | | ON | | |
| | | Lockup ON | | | ON | ON | |
| | OD | | ON | | ON | | |
| L | 1st | | | ON | ON | | |
| | 2nd | Below approx. 110 km/h (68 mph) | ON | ON | | | |
| | | Above approx. 110 km/h (68 mph) | ON | | | | |
| HOLD | D | 1st | | | ON | ON | |
| | | 2nd | | ON | ON | ON | |
| | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | |
| | | | Lockup ON | ON | | | ON |
| | | OD | | ON | | ON | |
| | S | 2nd | | ON | ON | | |
| | | 3rd | Below approx. 5 km/h (3.1 mph) at operating temperature | | | | |
| | | | Above approx. 5 km/h (3.1 mph) or cold engine | ON | | | |
| | | OD | | ON | | ON | |
| | L | 1st | | | ON | | |
| | | 2nd | Below approx. 110 km/h (68 mph) | ON | ON | | |
| | | | Above approx. 110 km/h (68 mph) | ON | | | |

03U0K2-066

MECHANICAL SYSTEM TEST

PREPARATION
SST

| | | | |
|--|------------------------------|---|------------------------------|
| <p>49 0378 400A</p> <p>Gauge set, oil pressure</p>  | <p>For oil pressure test</p> | <p>49 B019 901</p> <p>Gauge, oil pressure</p>  | <p>For oil pressure test</p> |
|--|------------------------------|---|------------------------------|


03U0K2-067

STALL TEST

This test is performed to determine if there is slippage of the friction elements or malfunction of the hydraulic components.

Preparation

1. Check, and correct as necessary, the engine coolant, engine oil, and ATF levels before testing.
2. Warm the engine thoroughly to raise the ATF temperature to operating level (60–70°C, 140–158°F).
3. Engage the parking brake and use wheel chocks at the front and rear of the wheels.



ENGAGE PARKING BRAKE

WARM UP ENGINE

COOLANT LEVEL

ENGINE OIL LEVEL


ATF LEVEL

WHEEL CHOCK

03U0KX-085

K2-119

Procedure



03U0KX-086

1. Connect a tachometer to the engine.
2. Start the engine and check the idle speed in P range. (Refer to Section F.)

Idle speed: 750 ± 50 rpm (with parking brake applied)

3. Shift the selector lever to R range.

Caution

- Steps 4 and 5 must be performed within 5 seconds to prevent possible transaxle damage.

4. Firmly depress the foot brake with the left foot, and gently depress the accelerator pedal with the right.
5. When the engine speed no longer increases, quickly read the engine speed and release the accelerator.

Caution

- Idling for at least one minute to cool the ATF and to prevent deterioration of the fluid.

6. Move the selector lever to N range and let the engine idle for at least one minute.

Caution

- Be sure to allow sufficient cooling time between each stall test.

7. Perform stall tests for the remaining ranges in the same manner.

- (1) D range
- (2) S range
- (3) L range

Engine stall speed: 2,550—2,650 rpm

Note

- The stall test can be performed with the EC-AT Tester in place of a tachometer.

Drum stall speed indication: 0 rpm

03U0K2-068

Evaluation of Stall Test

| Condition | | Possible cause | |
|----------------------|---------------------------------|---|---|
| Above specification | In all ranges | Insufficient line pressure | Worn oil pump |
| | | | Oil leakage from oil pump, control valve, and/or transaxle case |
| | | | Stuck pressure regulator valve |
| | In forward ranges | Forward clutch slipping One-way clutch 1 slipping | |
| | In D range | One-way clutch 2 slipping | |
| | In S (Hold) and L (Hold) ranges | Coasting clutch slipping | |
| | In D (Hold) and S (Hold) ranges | 2-4 brake band slipping | |
| Below specification | In R, L and L (Hold) ranges | Low and reverse brake slipping | |
| | In R range | Low and reverse brake slipping Reverse clutch slipping Perform road test to determine whether problem is low and reverse brake or reverse clutch a) Engine breaking felt in L range 1st ...Reverse clutch b) Engine breaking not felt in L range 1st ...Low and reverse brake | |
| Within specification | | All shift control elements within transaxle are functioning normally | |
| Below specification | | Engine out of tune | |
| | | One-way clutch slipping within torque converter | |

03U0KX-088


TIME LAG TEST

If the selector lever is shifted while the engine is idling, there will be a certain time lapse, or time lag, before shock is felt. This step measures this time lag for checking conditions of the N-D, 1-2, and N-R accumulators, forward and one-way clutches, 2-4 brake band, and low and reverse brake.

Preparation

Perform the preparation procedure outlined in STALL TEST. (Refer to page K2-119.)

Procedure



03U0K2-069

1. Start the engine and check the idle speed in P range. (Refer to Section F.)

Idle speed: 750 ± 50 rpm (with parking brake applied)

2. Shift from N range to D range.
3. Use a stopwatch to measure the time it takes from shifting until shock is felt.

Caution

- **Idling for at least one minute is to cool the ATF and prevent deterioration of the fluid.**

4. Shift the selector to N range and run the engine at idle speed for at least one minute.

Note

- **Make three measurements for each test and take the average value.**

5. Perform the test for the following shifts in the same manner.

- (1) N→D range
- (2) N→D range (Hold mode)
- (3) N→R range

Time lag: N→D range 0.5—1.0 second
 N→R range 0.6—1.0 second

Evaluation of Time Lag Test

| Condition | | Possible Cause |
|--------------------|-------------------------|---|
| N → D shift | More than specification | Insufficient line pressure Forward clutch slipping One-way clutch 1 slipping One-way clutch 2 slipping |
| | Less than specification | N-D accumulator not operating properly Excessive line pressure |
| N → D (Hold) shift | More than specification | Insufficient line pressure Forward clutch slipping 2-4 brake band slipping One-way clutch 1 slipping |
| | Less than specification | 1-2 accumulator not operating properly Excessive line pressure |
| N → R shift | More than specification | Insufficient line pressure Low and reverse brake slipping Reverse clutch slipping |
| | Less than specification | N-R accumulator not operating properly Excessive line pressure |


03U0KX-090

LINE PRESSURE TEST

This test measures line pressures as a means of checking the hydraulic components and inspecting for oil leakage.

Preparation

1. Perform the preparation procedure outlined in STALL TEST. (Refer to page K2-119.)
2. Connect a tachometer to the engine.
3. Connect the **SST** to the line pressure inspection port (square head plug L).

Procedure

03U0K2-070

1. Start the engine and check the idle speed in P range. (Refer to Section F.)

Idle speed: 750 ± 50 rpm (with parking brake applied)

2. Shift the selector lever to D range and read the line pressure at idle.

Caution

- **Step 3 and 4 must be performed within 5 seconds to prevent possible transaxle damage.**

3. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.
4. Read the line pressure as soon as the engine speed becomes constant, then release the accelerator pedal.

Caution

- **Idling for at least one minute is to cool the ATF and to prevent deterioration of the fluid.**

5. Shift the selector lever to N range and run the engine at idle for at least one minute.
6. Read the line pressure at idle and at the engine stall speed for each range in the same manner.

Specified line pressure:

| Range | Line pressure kPa (kg/cm ² , psi) | |
|---------|--|----------------------------------|
| | Idle | Stall |
| D, S, L | 353—432 (3.6—4.4, 51—63) | 873—1,040 (8.9—10.6, 127—151) |
| R | 598—942 (6.1—9.6, 87—137) | 1,668—2,011 (17.0—20.5, 242—292) |

03U0K2-071

7. Install a new square head plug in the inspection port.

Tightening torque: 4.9—9.8 N·m (50—100 cm·kg, 43—87 in·lb)

Evaluation of Line Pressure Test

| Line pressure | Possible location of problem |
|--------------------------------|--|
| Low pressure in every position | Worn oil pump Fluid leaking from oil pump, control valve body, or transaxle case Pressure regulator valve sticking Throttle valve sticking Throttle modulator valve sticking Throttle cable misadjusted |
| Low pressure in D and S only | Fluid leaking from hydraulic circuit of forward clutch |
| Low pressure in R only | Fluid leaking from hydraulic circuit of low and reverse brake |
| Higher than specification | Throttle valve sticking Throttle modulator valve sticking Pressure regulator valve sticking Throttle cable misadjustment |


03U0KX-093

THROTTLE PRESSURE TEST

This test measures throttle pressures as a means of checking the hydraulic components and inspecting for oil leakage.

Preparation

1. Perform the preparation procedure outlined in STALL TEST. (Refer to page K2-119.)
2. Connect a tachometer to the engine.
3. Connect the **SST** to the line pressure inspection port (square head plug T).

Procedure

03U0K2-072

1. Start the engine and check the idle speed in P range. (Refer to Section F.)

Idle speed: 750 ± 50 rpm (with parking brake applied)

2. Shift the selector lever to D range and read the throttle pressure at idle.

Caution

- **Steps 3 and 4 must be performed within 5 seconds to prevent possible transaxle damage.**

3. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.
4. Read the throttle pressure as soon as the engine speed becomes constant, then release the accelerator pedal.

Caution

- **Idling for at least one minute is to cool the ATF and to prevent deterioration of the fluid.**

5. Shift the selector lever to N range and run the engine at idle for at least one minute.

Specified throttle pressure:

| Range | Throttle pressure kPa (kg/cm ² , psi) | |
|-------|--|--------------------------|
| | Idle | Stall |
| D | 39—88 (0.4—0.9, 6—13) | 471—589 (4.8—6.0, 68—85) |

03U0K2-073

6. Install a new square head plug in the inspection port.

Tightening torque: 4.9—9.8 N·m (50—100 cm·kg, 43—87 in·lb)

Evaluation of Throttle Pressure Test

| Throttle pressure | Possible location of problem |
|--------------------------|--|
| Not within specification | Throttle valve sticking Pressure regulator valve sticking Throttle cable misadjusted |

03U0KX-096

ROAD TEST

Caution

- Perform the test at normal ATF operating temperature (60—70°C, 140—158°F).

This step is performed to inspect for problems in the various gear ranges. If these tests show any problems, refer to the electronic system component or mechanical sections to adjust or replace.

D-RANGE TEST**Shift Point, Shift Pattern, and Shift Shock**

1. Shift the selector lever to D range.


Note

- Throttle sensor voltage of the EC-AT Tester represents the throttle valve opening.

2. Accelerate the vehicle with half- and full-throttle opening.
3. Check that 1-2, 2-3, and 3-OD upshifts, downshifts, and lockup are obtained. The shift points must be as shown in the D range shift diagram.


Note

- Drum speed (rpm) of the EC-AT Tester represents the shift point.
 - The vehicle's indicated speed as shown by the vehicle speedometer may not be accurate when the vehicle is on a chassis roller. Therefore, verify the shift points using only the drum speed as shown by the EC-AT Tester.
 - There is no lockup when the coolant temperature is below 72°C (162°F).
 - There is no lockup when the brake pedal is depressed.
4. Check the upshifts for shift shock or slippage in the same manner.
 5. While driving in OD (below 148 km/h, 92 mph), shift the selector lever to S range and check that OD-3 downshift immediately occurs.

D-range shift diagram

6. Select the Hold mode.
7. Accelerate the vehicle and verify that the 1-2 and 2-3 upshifts 3-1, and lockup downshifts are obtained. The shift points are as shown in the D range (Hold) shift diagram.

D-range (Hold) shift diagram



03U0K2-075

Evaluation

| Condition | Possible Cause |
|-----------------------------------|---|
| No 1-2 up- or downshift | Stuck 1-2 shift solenoid valve Stuck 1-2 shift valve |
| No 2-3 up- or downshift | Stuck 2-3 shift solenoid valve Stuck 2-3 shift valve |
| No 3-OD up- or downshift | Stuck 3-4 shift solenoid valve Stuck 3-4 shift valve |
| No lockup shift | Stuck lockup control solenoid valve Stuck lockup control valve |
| Incorrect shift point | Misadjusted throttle sensor Stuck shift valves |
| Excessive shift shock or slippage | Stuck accumulators Stuck or no one-way check orifice Worn clutches, brakes, or one-way clutch |
| No engine braking effect | Worn clutches or brakes |

03U0KX-103

Noise and Vibration

Note

- **Abnormal noise and vibration can also be caused by the torque converter, driveshaft, or differential. Therefore, check for the cause with extreme care.**

Drive the vehicle in OD (lockup), OD (no lockup), and 3rd (Hold) and check for abnormal noise or vibration.

Kickdown

Drive the vehicle in OD, 3rd, and 2nd gears and check that kickdown occurs for OD→3, OD→2, OD→1, 3→2, 3→1, 2→1, and that the shift points are as shown in the shift diagram.


03U0KX-104

S-RANGE TEST

Shift Pattern

1. Shift the selector lever to S range.
2. Accelerate the vehicle and verify that the 1-2 and 2-3 upshifts, downshifts, and lockup are obtained. The shift points must be as shown in the S range shift diagram.


S-range shift diagram



03U0K2-076

3. While driving in S range and 3rd gear, select the Hold mode and verify that 3rd gear is held until the 3-2 downshift point as shown in the S range (Hold) shift diagram is achieved.
4. Accelerate the vehicle in S range (Hold) and verify that 2nd gear is held.

S-range (Hold) shift diagram



03U0K2-077

Noise and vibration

Note

- **Abnormal noise and vibration can also be caused by the torque converter, drive shaft or differential. Therefore, check for the cause with extreme care.**

Drive the vehicle in 2nd gear (Hold mode) and check for abnormal noise or vibration.


03U0K2-078

L-RANGE TEST

Shift Pattern

1. Shift the selector lever to L range.
2. Accelerate the vehicle and verify that the 1-2 upshifts and downshifts are obtained and that no 3rd gear, OD, or lockup is obtained.
3. Check the upshifts for shift shock or slippage in the same manner.
4. Decelerate the vehicle and verify that engine braking effect is felt in 2nd gear.


L-range shift diagram



03U0K2-079

5. Select the Hold mode.
6. While driving in S range (Hold mode) and 2nd gear, shift the selector lever to L range and verify that 2nd gear is held until the 2 → 1 downshift point as shown in the L range (Hold) shift diagram is achieved.
7. Accelerate the vehicle in L range (Hold mode) and verify that 1st gear is held.

L-range (Hold) shift diagram



03U0K2-080

Noise and Vibration

Note

- **Abnormal noise and vibration can also be caused by the torque converter, driveshaft or differential. Therefore, check for the cause with extreme care.**

Drive the vehicle in 1st gear (Hold mode) and check for abnormal noise and vibration.

P-RANGE TEST

1. Shift into P range on a gentle slope, release the brake, and verify that the vehicle does not roll.

03U0KX-115

Vehicle Speed at Shiftpoint Table

| Mode | Range | Throttle condition (Throttle sensor voltage) | Shift | Drum speed rpm | Vehicle speed km/h (mph) |
|--------|-----------------------------|--|-------------------|----------------|--------------------------|
| NORMAL | D | Fully opened (4.0V) | D1 → D2 | 4,900—5,500 | 49—55 (30—34) |
| | | | D2 → D3 | 5,100—5,550 | 93—101 (58—63) |
| | | | D3 → OD | 5,200—5,500 | 145—155 (90—96) |
| | | Half throttle (1.6—2.2V) | D1 → D2 | 2,800—3,700 | 28—37 (17—23) |
| | | | D2 → D3 | 3,300—4,250 | 60—77 (37—48) |
| | | | D3 → OD | 3,500—4,300 | 98—121 (61—75) |
| | | | Lockup ON (OD) | 2,100—2,750 | 84—110 (52—68) |
| | | Kickdown | OD → D3 | 3,300—3,600 | 133—143 (82—89) |
| | | | D3 → D2 | 3,100—3,350 | 86—94 (53—58) |
| | D2 → D1 | | 2,000—2,300 | 36—42 (22—26) | |
| | S | Fully opened (4.0V) | S1 → S2 | 4,900—5,500 | 49—55 (30—34) |
| | | | S2 → S3 | 5,100—5,550 | 93—101 (58—63) |
| | | | Lockup ON (S3) | 3,850—4,150 | 108—116 (67—72) |
| | | | S3 → S2 | 3,100—3,350 | 86—94 (53—58) |
| | | | S2 → S1 | 2,000—2,300 | 36—42 (22—26) |
| | | Half throttle (1.6—2.2V) | S1 → S2 | 2,800—3,700 | 28—37 (17—23) |
| | | | S2 → S3 | 3,300—4,250 | 60—77 (37—48) |
| | | | Lockup ON (S3) | 3,700—4,150 | 104—116 (65—72) |
| | | | | | |
| L | Fully opened (4.0V) | L1 → L2 | 4,900—5,500 | 49—55 (30—34) | |
| | | L2 → L1 | 2,000—2,300 | 36—42 (22—26) | |
| | Half throttle (1.6—2.2V) | L1 → L2 | 2,800—3,700 | 28—37 (17—23) | |
| HOLD | D | Fully opened (4.0V) | D1 → D2 | 2,700—3,300 | 27—33 (17—20) |
| | | | D2 → D3 | 2,200—2,750 | 40—50 (25—31) |
| | | | D3 → D1 | 250—500 | 7—13 (4—9) |
| | S | Fully closed (0.5V) | S3 → S2 | 3,100—3,300 | 87—93 (54—58) |
| | | | L2 → L1 | 2,400—2,700 | 43—49 (27—30) |
| | L | | | | |

03U0K2-081

Slippage Test

This step is performed to inspect slippage of the friction elements.

Preparation

1. Connect a tachometer to the engine and set it in the cabin.
2. Connect the **EC-AT Tester Set** between the EC-AT control unit and wiring harness.

Procedure

Drive the vehicle in each of the gears indicated below and check whether the vehicle speed or engine speed is above or below specification as shown by the turbine speed.

| Driving condition | | | Speed | Drum speed (rpm) | | | |
|-------------------|-------|---------------------------------|-----------------------------|------------------|---------|----------|----------|
| No. | Gears | Other condition | | 1,000 | 2,000 | 3,000 | 4,000 |
| 1 | 1st | L range, Hold mode | Vehicle speed km/h (mph) | 10 (6) | 20 (12) | 30 (19) | 40 (25) |
| 2 | 1st | D range, Normal mode | | 10 (6) | 20 (12) | 30 (19) | 40 (25) |
| 3 | 2nd | S range, Hold mode | | 18 (11) | 36 (22) | 55 (34) | 73 (45) |
| 4 | 3rd | D range, Hold mode | | 28 (17) | 56 (35) | 84 (52) | 112 (69) |
| 5 | OD | D range, Normal mode | | 40 (25) | 80 (50) | 120 (74) | 160 (99) |
| 6 | OD | D range, Normal mode, Lockup | Engine speed (rpm) | 1,000 | 2,000 | 3,000 | 4,000 |

03U0K2-082

Evaluation

When there is no malfunction in the electrical system or hydraulic system, but vehicle speed or engine speed is below specification, the problem can be attributed to slippage of the friction elements.

| Driving conditions below specification | Possible Cause |
|--|-------------------------------------|
| No.1 condition only | Low and reverse brake |
| No.2 condition only | One-way clutch 1 |
| No.3 condition only | 2-4 brake band |
| No.4 condition only | Coasting clutch |
| No.5 condition only | 3-4 clutch |
| No.1—No.5 conditions | Forward clutch |
| No.6 condition only | Lookup piston (in torque converter) |

03U0KX-118

AUTOMATIC TRANSAXLE FLUID (ATF)

ATF
Inspection
Level


Caution

- Place the vehicle on a flat, level surface.

1. Apply the parking brake and position wheel chocks securely to prevent the vehicle from rolling.
2. Warm-up the engine until the ATF reaches **60—70°C (140—158°F)**.

03U0KX-119

3. While the engine is idling, shift the selector lever from P to L and back to P.
4. Let the engine idle.
5. Shift the selector lever to P.




03U0KX-120

Note

- Only use the COOL 20°C (68°F) range as a rough reference.

6. Ensure that the ATF level is in the HOT 65°C (149°F) range. Add ATF to specification, if necessary.

ATF type: M-III or DEXRON-II




03U0K2-309

Condition

Note

- Determine whether or not the automatic transmission should be disassembled by observing the condition of the ATF carefully. If the ATF is muddy and varnished, it indicates burned drive plates.

1. Check the ATF for discoloration.
2. Check the ATF for any unusual smell.




03U0KX-122


Fluid leaks

Check for fluid leaks of the transaxle at the points shown below and repair or replace as necessary.

1. Gaskets, O-rings, and plugs.
2. Oil hoses, oil pipes, and connections.
3. Oil cooler.



- (A) O-RING
- (B) GASKET
- (C) OIL SEAL
- (D) OTHERS



03U0K2-083

TRANSFER CARRIER OIL

INSPECTION

Note

- Park the vehicle on level ground.

1. Remove the check plug.
2. Verify that the oil is at the bottom of the plug port. If it is low, add the specified oil from plug port.
3. Install the check plug.

Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

REPLACEMENT

1. Remove the drain plug. Drain the oil into a suitable container.
2. Install the drain plug.


Tightening torque:

39—58 N·m (4.0—6.0 m·kg, 28—43 ft·lb)

3. Add the necessary amount of the specified oil through the plug port.

Specified oil: SAE 75W-90



Capacity: 0.5 liter (0.53 US qt, 0.44 Imp qt)




03U0K2-084

THROTTLE CABLE

PREPARATION SST

| | | | |
|--|---|---|---|
| <p>49 0378 400A</p> <p>Gauge set, oil pressure</p>  | <p>For adjustment of throttle cable</p> | <p>49 B019 901</p> <p>Gauge, oil pressure</p>  | <p>For adjustment of throttle cable</p> |
|--|---|---|---|

03U0K2-085




03U0KX-125

THROTTLE CABLE

Inspection


1. Check the inner and outer cable for damage.
2. Verify that the accelerator operates smoothly.



03U0K2-086


Replacement

1. Disconnect the oil hose.
2. Remove the throttle cable from the throttle lever.
3. Drain the ATF.




03U0K2-087

4. Remove the control valve body cover and gasket.
5. Remove the throttle cable from the throttle cam.
6. Remove the harness bracket.



03U0K2-088

7. Remove the throttle cable from the transaxle.
8. Remove the O-ring.




03U0K2-089

9. Install the throttle cable and a new O-ring into the transaxle.

Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)




03U0K2-090

10. Install the harness bracket.

Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)

11. Install the throttle cable to the throttle cam.
12. Temporarily install the throttle cable to the throttle lever.




03U0K2-091

13. Install the control valve body cover and a new gasket.


Tightening torque:

8.3—11.0 N·m (85—110 cm·kg, 74—100 in·lb)




03U0K2-092

14. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated against the ridge.
15. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
16. Verify that the hose clamp does not interfere with any other parts.
17. After installation, add ATF.
18. Check the ATF level and for leaks.
19. Adjust the throttle cable.




03U0K2-093


20. Fully open the throttle valve, and crimp the pin with the holder installed as shown.




03U0KX-130



03U0KX-131



03U0K2-310



03U0KX-133

Adjustment

1. Remove the square head plug L and install the **SST**.
2. Shift into P range and start the engine. Warm up the engine to normal operating temperature, and adjust the idle speed if necessary.

Idle speed:

750 ± 50 rpm (with parking brake applied)

3. Adjust the locknuts as follows:

When the locknuts are rotated, line pressure is increased or decreased as shown. Adjust the locknuts to the correct position using the following procedure.

- (1) Initially install the locknuts fully away from the throttle cam. (Loosen the cable all the way)
- (2) Adjust the locknuts in a clockwise direction as viewed from the passenger side of the vehicle until the line pressure exceeds the specification.

- (3) Adjust the locknuts in a counterclockwise direction until the line pressure decreases to the specification. Tighten the locknuts.

Adjustment pressure:

431—451 kPa (4.4—4.6 kg/cm², 63—65 psi)

- (4) Tighten the locknuts and verify that the line pressure is as specified.

Specified pressure: 441 kPa (4.5 kg/cm², 64 psi)

Note

- **Transaxle in P range.**

4. Turn off the engine.
5. Install a new square head plug L.

Tightening torque:

5—10 N·m (50—100 cm·kg, 43—87 in·lb)

ELECTRONIC SYSTEM COMPONENTS


HOLD SWITCH

Inspection

Inspection of operation

1. Turn the ignition switch OFF→ON.
2. Verify that the HOLD indicator is not illuminated. Depress the switch and verify that the HOLD indicator comes ON.
3. If not as specified, check the terminal voltage of the hold switch.

03U0KX-134



03U0KX-135

Inspection of voltage

1. Remove the rear console.
2. Turn the ignition switch ON.
3. Check the voltage between terminals A and B.

| Terminal voltage | Switch |
|------------------|-----------|
| Approx. 12V | Released |
| Below 1.5V | Depressed |


4. If not correct, go to the next step.

Inspection of continuity

1. Disconnect the connector.
2. Check continuity between terminals E and F.

| Continuity | Switch |
|------------|-----------|
| Yes | Released |
| No | Depressed |


3. If not correct, replace the selector lever knob as an assembly.



03U0KX-136

Replacement

1. Remove the rear console.
2. Disconnect the connector.
3. Remove the selector lever knob.
4. Install a new selector lever knob.
5. Install the rear console.




03U0KX-137

INHIBITOR SWITCH


Inspection

Inspection of operation

1. Verify that the starter operates with the ignition switch at START position and the selector lever in P and N ranges only.
2. Verify that the back-up lights illuminate when shifted to R range with the ignition switch in ON position.
3. Check the inhibitor switch if not as specified.



03U0KX-138



03U0KX-139


Inspection of continuity

1. Disconnect the inhibitor switch connector.
2. Check continuity of the terminals.

| Position | Connector terminal | | | | | | |
|----------|--------------------|---|---|---|---|---|---|
| | A | B | C | D | E | F | G |
| P | ○ | ○ | | | | | |
| R | | | ○ | ○ | | | |
| N | ○ | ○ | | | | | |
| D | | | ○ | | ○ | | |
| S | | | ○ | | | ○ | |
| L | | | ○ | | | | ○ |

○—○: Indicates continuity

3. If not correct, replace the switch and perform adjustment of the inhibitor switch.
4. If correct, check or adjust the selector lever.




03U0K2-094

Replacement

1. Disconnect the negative battery cable.
2. Remove the air hose and disconnect the harness.
3. Remove the clip.
4. Remove the bolts and the manual shaft nuts.
5. Install the new inhibitor switch and the manual shaft nuts.


Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)



03U0K2-095

6. Align the holes of the inhibitor switch and the selector lever by inserting an **approx. 2.0mm (0.079 in)** diameter pin.
7. Connect the harness and install the air hose.
8. Connect the negative battery cable.
9. Inspection of inhibitor switch.




03U0K2-096

Adjustment

1. Remove the air hose.
2. Turn the manual shaft to N position.
3. Loosen the inhibitor switch mounting bolts.
4. Align the holes of the inhibitor switch and the manual shaft lever by inserting an **approx. 2.0mm (0.079 in)** diameter pin.
5. Tighten the mounting bolts.


Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)



03U0K2-097

6. Recheck the continuity of the inhibitor switch.
7. If not correct, replace the inhibitor switch.



03U0K2-098

8. Connect the selector lever.

Tightening torque:
44—64 N·m (4.5—6.5 m·kg, 33—47 ft·lb)


ATF THERMOSWITCH

Inspection


1. Remove the ATF thermoswitch.
2. Place the switch in oil with a thermometer as shown, and heat it up gradually.
3. Check the continuity of the terminals. If necessary replace the switch.

Connection guide

| Fluid temperature | Continuity |
|--|------------|
| Above $150 \pm 3^{\circ}\text{C}$ ($302 \pm 37^{\circ}\text{F}$) | Yes |
| Below 143°C (289°F) | No |



03U0K2-099



03U0KX-145

PULSE GENERATOR

Inspection


Inspection of resistance

1. Disconnect the pulse generator connector.
2. Measure resistance between the terminals E and F.


Resistance: 200—400Ω

3. If not correct, replace the pulse generator.


Tightening torque:
8—11 N·m (80—110 cm·kg, 69—95 in·lb)




03U0KX-146



03U0KX-147



03U0KX-148



03U0KX-149

SPEED SENSOR

Inspection

1. Connect a voltmeter between the terminal 1P and a ground as shown.
2. Turn the ignition switch ON.

3. Remove the speedometer cable from the transmission.
4. Slowly turn the speedometer cable one turn.
5. Verify that **approx. 7V** is shown 4 times.
6. If not correct, check the speedometer and cable.

SOLENOID VALVE

Inspection

1. Disconnect the solenoid valve connector.
2. Measure resistance between each terminal and a ground.

Resistance: 13—27Ω

Note

- 1-2 shift solenoid valve: **A**
- 2-3 shift solenoid valve: **B**
- 3-4 shift solenoid valve: **C**
- Lockup solenoid valve: **D**

3. If not correct, check the wiring for an open-or short-circuit. Replace the solenoid valve.

Continuity

1. Disconnect the 20-pin connector from the EC-AT control unit.
2. Check continuity between terminals 2E, 2G, 2I, and 2K, and a ground.
3. If not correct, check the wiring for an open-circuit.

03U0KX-150

EC-AT CONTROL UNIT

Inspection

1. Turn the ignition switch ON, and check the EC-AT control unit terminal voltage, referring to the Terminal Voltage Chart.
2. If not correct, check and replace or repair the component(s), wiring, and/or EC-AT control unit.

03U0KX-151

Terminal Voltage Chart

| | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

9MU0K1-083


| Terminal | Connection to | Voltmeter | | Voltage | Condition |
|-------------|---------------------------------|------------|-------------|---|--|
| | | + terminal | -terminal | | |
| 1A | — | — | — | — | — |
| 1B (Output) | Hold indicator | 1B | Ground | Below 1.5V | Hold mode |
| | | | | Approx. 12V | Normal mode |
| 1C (Output) | EC-AT tester (Malfunction code) | 1C | | Approx. 12V | Normal (With EC-AT Tester) |
| | | | | Below 1.5V or Approx. 12V (fluctuating) | If malfunction present (With EC-AT Tester) |
| | | | | Code signal | Diagnosis connector grounded (With EC-AT Tester) |
| 1D (Output) | No load signal | 1D | | Approx. 12V | P or N ranges |
| | | | | Below 1.5V | Other ranges |
| 1E (Input) | Diagnosis connector | 1E | | Approx. 12V | Normal |
| | | | | Below 1.5V | TAT terminal grounded |
| 1F (Input) | Stoplight switch | 1F | | Approx. 12V | Brake pedal depressed |
| | | | | Below 1.5V | Brake pedal released |
| 1G (Input) | ATF thermoswitch | 1G | | Below 1.5V | Above 145°C (293°F) |
| | | | | Approx. 12V | Below 138°C (211°F) |
| 1H (Input) | Hold switch | 1H | | Below 1.5V | Switch depressed |
| | | | Approx. 12V | Switch released | |
| 1I | — | — | — | — | |
| 1J (Ground) | Battery ground | 1J | Ground | Below 1.5V | — |
| 1K | — | — | — | — | — |
| 1L | — | — | — | — | — |
| 1M | — | — | — | — | — |

| Terminal | Connected to | Voltmeter | | Voltage | Condition |
|--------------------|-----------------------------------|------------|------------|-----------------------------|--|
| | | + terminal | - terminal | | |
| 1N (Input) | Water thermo signal | 1N | Ground | Approx. 12V | Above 72°C (162°F) |
| | | | | Below 1.5V | Below 67°C (153°F) |
| 1O (Input) | Idle switch | 1O | Ground | Approx. 12V | Idle switch OFF (Throttle valve open) |
| | | | | Below 1.5V | Idle switch ON (Throttle valve fully closed) |
| 1P (Input) | Vehicle speed sensor | 1P | Ground | Approx. 3V—4V | While driving |
| | | | | Approx. 3V—4V or below 1.5V | Vehicle stopped |
| 2A (Input) | Throttle sensor | 2A | Ground | Approx. 5V | Ignition switch ON |
| | | | | Below 1.5V | Ignition switch OFF |
| 2B (Input) | Inhibitor switch (P and N ranges) | 2B | Ground | Below 1.5V | P and N ranges |
| | | | | Approx. 12V | Other ranges |
| 2C | — | — | — | — | — |
| 2D (Input) | Inhibitor switch (D range) | 2D | Ground | Approx. 12V | D range |
| | | | | Below 1.5V | Other ranges |
| 2E (Input) | 1-2 shift solenoid valve | 2E | Ground | Approx. 12V | Refer to page K2-109 of solenoid valve operation table |
| | | | | Below 1.5V | |
| 2F (Input) | Inhibitor switch (S range) | 2F | Ground | Approx. 12V | S range |
| | | | | Below 1.5V | Other ranges |
| 2G (Input) | 2-3 shift solenoid valve | 2G | Ground | Approx. 12V | Refer to page K2-109 of solenoid valve operation table |
| | | | | Below 1.5V | |
| 2H (Input) | Inhibitor switch (L range) | 2H | Ground | Approx. 12V | L range |
| | | | | Below 1.5V | Other ranges |
| 2I (Input) | 3-4 shift solenoid valve | 2I | Ground | Approx. 12V | Refer to page K2-109 of solenoid valve operation table |
| | | | | Below 1.5V | |
| 2J (Input) | Pulse generator* | 2J | Ground | Above 1V (AC) | Engine running (N range) |
| | | | | Approx. 0V (AC) | Engine stopped |
| 2K (Input) | Lockup solenoid valve | 2K | Ground | Approx. 12V | Lockup |
| | | | | Below 1.5V | Other |
| 2L (Ground) | Pulse generator | 2L | Ground | Below 1.5V | — |
| 2M (Input) | Engine control unit | 2M | Ground | Approx. 12V | Shift down with throttle valve opening 2/8 or more |
| | | | | Below 1.5V | Others |
| 2N | — | — | — | — | — |
| 2O (Memory power) | Battery | 2O | Ground | Approx. 12V | Constant |
| 2P (Ground) | Battery ground | 2P | Ground | Below 1.5V | — |
| 2Q (Battery power) | Battery | 2Q | Ground | Approx. 12V | Ignition switch ON |
| | | | | Below 1.5V | Ignition switch OFF |
| 2R | — | — | — | — | — |
| 2S (Battery power) | Battery | 2S | Ground | Approx. 12V | Ignition switch ON |
| | | | | Below 1.5V | Ignition switch OFF |
| 2T (Input) | Throttle sensor | 2T | Ground | Approx. 0.4—4.4V | Throttle valve fully closed to fully open |

* Checked in AC range

03U0K2-100

WIRE HARNESS Wiring diagram









TRANSAXLE AND TRANSFER UNIT

TRANSAXLE AND TRANSFER ASSEMBLY

Preparation

SST

| | | | |
|--|------------------------------|---|-----------------------------------|
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503 Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501 Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 0118 850C Puller, ball joint</p>  | <p>For removal of tie-rod end</p> |
| <p>49 G017 502 Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G030 455 Holder, differential side gear</p>  | <p>For holding side gear</p> |

03U0K2-101

Removal

1. Disconnect the negative battery cable.
2. Jack up the vehicle and support it with safety stands.

Note

- **Drain the ATF before transaxle removal.**

3. Drain the ATF into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.


Caution

- **Do no turn the transaxle and transfer over before removing the oil pan.**

03U0K2-102

| | |
|--|---|
| 1. Wheel and tire | 17. Exhaust pipe |
| 2. Splash shield | 18. Tie-rod end Removal Note..... page K2-149 |
| 3. Air hose and air cleaner assembly | 19. Stabilizer |
| 4. Battery | 20. Joint shaft |
| 5. Battery carrier | 21. Driveshaft Removal Note..... page K2-149 |
| 6. Speedometer cable | 22. Center differential lock motor Removal Note..... page K2-150 |
| 7. Selector cable | 23. Starter |
| 8. Inhibitor switch connector | 24. Engine mount member Removal Note..... page K2-151 |
| 9. Solenoid valve connector | 25. Engine mount No.2 |
| 10. Differential lock motor connector | 26. Oil hose (In side) |
| 11. Differential lock sensor switch connector | 27. Oil hose (Out side) |
| 12. Throttle cable | 28. Transaxle and transfer Removal Note..... page K2-151 |
| 13. Under cover | |
| 14. Propeller shaft Removal Note..... page K2-149 | |
| 15. Integrated stiffener | |
| 16. Cross member | |

03U0K2-103




03U0K2-104

**Removal note
Propeller shaft**

Caution

- Do not mark with a punch.

1. Mark the companion flange and the front yoke.
2. Mark the companion flange and the rear yoke.
3. Remove the propeller shaft.




03U0K2-311

Tie-rod end

1. Remove the tie-rod from the knuckle with the **SST**.
2. Loosen the nut and disconnect the tie-rod end with the **SST**.

Caution

- Do not damage the dust boot.




03U0KX-159

Driveshaft

Caution

- Do not damage the ball joint dust boot.

1. Remove the clinch bolts from the lower arm ball joints.
2. Pull the lower arms downward to separate them from the knuckles.




03U0KX-160

Caution

- Do not damage the oil seal.

3. Separate the left driveshaft from the transaxle by prying with a bar inserted between the shaft and the transaxle case.




03U0KX-161

Caution

- If the SST is not installed, the differential side gears may become misaligned.


4. Slide the **SST** into the differential side gear.



03U0K2-105


Center differential lock motor

1. Remove the set bolt.




03U0K2-106

2. Remove the center differential lock sensor switch.
3. Turn the differential lock shift rod 180° clockwise with a screwdriver.



03U0K2-107


4. Remove the center differential lock motor.
5. Remove the O-ring from center differential lock motor.



03U0K2-108

Engine mounting member

1. Suspend the engine with the **SST** before removing the engine mounting member.



03U0K2-109

Transaxle and transfer

1. Use an engine hoist, and remove the transaxle and transfer unit.

TRANSAXLE AND TRANSFER UNIT (DISASSEMBLY)

Precaution

General Notes:


1. Disassemble the transaxle in a clean area (dustproof work space) to prevent entry of dust into the mechanisms.
2. Inspect the individual transaxle components in accordance with the QUICK DIAGNOSIS CHART during disassembly. (Refer to page K2-21.)
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts resemble one another; organize them so that they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when the clutch or brake band has burned or when the ATF has degenerated.

Cleaning Notes:

1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents before disassembly.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

03U0K2-110


Components



03U0K2-111

- | | | |
|--|--|---|
| 1. Torque converter Inspection page K2-167 | 4. Oil pan and gasket | 8. Control valve body assembly Disassembly / Inspection page K2-209 Assembly page K2-225 |
| 2. Oil pump shaft | 5. Oil strainer | 9. Throttle cable |
| 3. Oil level gauge and oil filler tube | 6. Inhibitor switch Inspection page K2-140 Adjustment ... page K2-141 | 10. Oil pump and gasket |
| | 7. Oil pan and gasket | |


Components (cont'd)



03U0K2-112

- | | |
|---|--|
| <p>1. Piston stem</p> <p>2. Snap ring</p> <p>3. Clutch assembly Disassembly / Inspection / Assembly page K2-173</p> <p>4. 2-4 brake band Disassembly / Inspection / Assembly page K2-197</p> <p>5. Small sun gear and one-way clutch Disassembly / Inspection / Assembly page K2-182</p> <p>6. Anchor strut and shaft</p> <p>7. Servo Disassembly / Inspection / Assembly page K2-197</p> | <p>8. Snap ring</p> <p>9. One-way clutch and carrier hub assembly Disassembly / Inspection / Assembly page K2-185</p> <p>10. Wave washer</p> <p>11. Snap ring</p> <p>12. Retaining plate</p> <p>13. Low and reverse brake (Drive and driven plates)</p> <p>14. Snap ring</p> <p>15. Internal gear</p> <p>16. 3-4 clutch assembly Disassembly / Inspection / Assembly page K2-187</p> |
|---|--|

Components (cont'd)




03U0K2-113

- 1. Transaxle case
- 2. Output shell
- 3. Turbine shaft
- 4. Bracket

- 5. Manual shaft and manual plate
- 6. Actuator support
- 7. Parking assist lever
- 8. Parking pawl

Components (cont'd)



03U0K2-114

- | | |
|--|---|
| 1. Front and center differential assembly Disassembly / Inspection / Assembly..... page K2-239 | 11. Bearing cover Disassembly / Assembly..... page K2-207 |
| 2. Front and center differential shift fork | 12. O-ring |
| 3. Roll pin | 13. Side cover |
| 4. Bearing housing | 14. O-ring |
| 5. Idler gear assembly (Transaxle) Disassembly / Inspection / Assembly..... page K2-202 | 15. Idler gear assembly (Transfer) Disassembly / Inspection / Assembly..... page K2-237 |
| 6. Output gear Disassembly / Inspection / Assembly..... page K2-205 | 16. Transfer carrier assembly Disassembly / Inspection / Assembly..... page K2-244 |
| 7. Bearing outer races | 17. Converter housing |
| 8. Adjustment shim Adjustment page K2-252 | 18. 2-3 accumulator Disassembly / Inspection / Assembly..... page K2-200 |
| 9. Oil seal | 19. Oil seal (Transaxle case) |
| 10. Oil seal (Bearing cover) | 20. Bearing outer race (Transaxle case) |

Procedure

Note

- Do not allow the ATF to spill when removing the torque converter.


1. Remove the torque converter from the converter housing.

2. Pull out the oil pump shaft by hand.


3. Remove the oil level gauge and oil filler tube.

4. Remove the engine mounting bracket No.1.


5. Assemble the **SST**.




03U0KX-168




86U07B-119




86U07B-120



03U0K2-115




03U0K2-116




03U0K2-117

6. Attach a suitable hanger to the oil pump as shown.



03U0K2-118


7. Lift the transaxle and mount it on the **SST**.



76U07B-453


Warning

- Avoid leaning the transaxle to one side during disassembly, it may turn quickly and cause injury.




03U0K2-119

8. Remove the pulse generator, inhibitor switch and bracket.




03U0K2-120

9. Remove the center differential lock switch.
10. Remove the washer.




03U0K2-121

11. Remove the bolt.




03U0K2-122

12. Turn the differential lock shift rod 180° clockwise with a screwdriver.



03U0K2-123

13. Remove the bolts shown in the figure.
14. Remove the differential lock assembly.




03U0K2-124

15. Remove the oil pan and gasket.
Examine any material found in the pan or on the magnet to determine the condition of the transaxle.


| | |
|-----------------------------|--------------------------------------|
| Clutch facing material..... | Drive plate and brake band wear |
| Steel (magnetic) | Bearing, gear, and driven plate wear |
| Aluminum (nonmagnetic).... | Bushings or cast aluminum parts wear |

If large amounts of material are found, replace the torque converter and carefully check the transaxle for the cause.




03U0K2-125

16. Remove the oilstrainer and O-ring.



03U0K2-126


17. Remove the control valve body cover and gasket.



03U0K2-127


18. Remove the throttle cable.

- (1) Remove the throttle cable attaching bolt and bracket.
- (2) Remove the cable from the throttle lever of the valve body.




03U0K2-128

19. Pinch the tangs of the solenoid connector and remove it by pushing inward.




03U0K2-129

20. Remove the control valve body as an assembly.




03U0K2-130

21. Remove the oil pump as an assembly.




03U0K2-131

22. Remove the piston stem from the servo.




03U0K2-132

23. Remove the clutch assembly.
(1) Remove the turbine shaft snap ring.



86U07B-138

(2) Pull the reverse and forward drum and remove the clutch assembly.




03U0K2-133

Note


- Use a piece of wire to secure the brake band so that it is not damaged by being stretched.

24. Remove the 2-4 brake band.




03U0K2-134

25. Remove the small sun gear and one-way clutch.




03U0K2-135

26. Pull the anchor shaft while holding the strut, then remove the strut.




03U0K2-136

27. Remove the servo.
 (1) Remove the snap ring with the **SST**.
 (2) Remove the servo and spring.




03U0K2-137

28. Remove the one-way clutch and carrier hub assembly.
 (1) Remove the snap ring.




86U07B-144

(2) Remove the one-way clutch together with the carrier hub assembly.




03U0K2-138

29. Remove the low and reverse brake assembly.
 (1) Remove the snap ring.




86U07B-146

- (2) Remove the retaining plate and the drive and driven plates.




03U0K2-139

- 30. Remove the internal gear.
 - (1) Remove the snap ring.




86U07B-148

- (2) Remove the internal gear from the 3-4 clutch drum.




03U0K2-140

- 31. Remove the 3-4 clutch assembly.
 - (1) Remove the O-ring from the turbine shaft at the converter housing side.




86U07B-150

- (2) Pull out the turbine shaft to remove the 3-4 clutch assembly.
- (3) Remove the 3-4 clutch assembly.




03U0K2-141

32. Remove the manual shaft and manual plate.
 (1) Remove the plug, washer, spring, and detent ball.




86U07B-158

- (2) Remove the bracket.




86U07B-159

- (3) Loosen the nut and pull the manual shaft out.
 (4) Remove the nut, washer, spacer, and manual plate.




03U0K2-142

33. Remove the actuator support.




03U0K2-143

34. Remove the snap ring; then remove the parking assist lever.




03U0K2-144

35. Remove the parking pawl.
- (1) Remove the snap ring.
 - (2) Pull the parking shaft, then remove the spring and parking pawl.




03U0K2-145

36. Remove the side cover.




03U0K2-146

37. Remove the bolts shown in the figure.




03U0K2-147

38. Remove the transaxle case by tapping lightly with a plastic hammer.




03U0K2-148

39. Remove the low and reverse brake piston
- (1) Install the **SST**.
 - (2) Compress the spring and retainer assembly.




86U07B-155

- (3) Remove the snap ring with snap ring pliers; then remove the spring and retainer assembly.




86U07B-156

- (4) Remove the low and reverse brake piston by applying compressed air through the fluid passage.




03U0K2-149

40. Remove the output shell from the output gear.




03U0K2-150

41. Remove the idle gear and O-ring.




03U0K2-151

42. Remove the lockbolt shown in the figure.
43. Remove the front and center differential assembly.




03U0K2-152

44. Remove the speedometer driven gear.
45. Remove the transfer carrier.




03U0K2-153

46. Remove the 2-3 accumulator piston assembly.



03U0K2-154

47. Remove the bearing housing.
(1) Remove the bolt indicated in the figure.
(2) Remove the roll pin with a pin punch.
(3) Remove the bearing housing by tapping lightly with a plastic hammer.




03U0K2-155

48. Remove the idle gear assembly and output gear assembly by tapping out from the torque converter side.


Caution

- Hold the idle gear assembly with one hand so that it does not fall.




03U0K2-156

49. Remove the bearing cover.
(1) Remove the converter housing from the transaxle hanger.
(2) Remove the bearing cover bolts.



86U07B-169

- (3) Press the bearing cover assembly out of the converter housing.




03U0K2-157

50. Remove the bearing outer race.
 - (1) Press out the bearing outer races with the **SST**.

Note

- **Install the bearing outer race during reassembly to adjust the preload.**

51. Check the oil seals for damage, replace if necessary.
52. Check the O-rings for damage, replace if necessary.



03U0KX-195

TORQUE CONVERTER

The torque converter is welded together and cannot be disassembled.

Inspection

1. Check the outer surface of the converter for damage or cracks, and replace it if necessary.
2. Check whether there is any rust on the pilot hub of the converter or on the boss. If there is any, remove it completely.
3. Measure the bushing of the converter boss. Replace the converter assembly if the bushing is worn.


Bushing inner diameter

Standard: 53.030mm (2.088 in)

Maximum: 53.075mm (2.090 in)

Washing inside of converter

1. Drain any ATF remaining in the converter.
2. Pour in solvent (approximately **0.5 liter [0.53 US qt, 0.44 Imp qt]**).
3. Shake the converter to clean the inside. Pour out the solvent.
4. Clean the inside of the converter with compressed air so that the inside is perfectly empty.
5. Pour in ATF.
6. Shake the converter to clean the inside. Pour out the ATF.




03U0KX-196

OIL PUMP

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



N-m (m-kg, ft-lb)

03U0K2-158

- | | |
|--------------------------------|------------------------------|
| 1. Bearing race | 9. Cam ring |
| 2. Seal rings | 10. Pivot roller |
| 3. Oil pump cover | 11. Seal pin and spring |
| 4. Pump flange | 12. Plug and washer |
| 5. Guide ring and guide spring | 13. Spring (Valve side) |
| 6. Vane | Inspection page K2-168 |
| 7. Rotor | 14. Valve |
| 8. Spring (Come ring side) | 15. Oil pump body |
| Inspection page K2-168 | 16. O-rings |



03U0K2-159

Inspection Spring


1. Measure the spring free length.

Specification

- 41.6mm (1.64 in): (Can ring side)
- 35.0mm (1.38 in): (Valve side)

Clearance

Measure the clearances below; if not within specification, replace the oil pump.




03U0K2-160

- | | | |
|--|--|---|
| <p>1. Seal pin—Oil pump cover Standard: 0.005—0.020mm (0.0002—0.0008 in) Maximum: 0.060mm (0.002 in)</p> | <p>3. Cam ring—Oil pump cover Standard: 0.005—0.020mm (0.0002—0.0008 in) Maximum: 0.080mm (0.003 in)</p> | <p>5. Vane—Rotor groove Standard: 0.010—0.045mm (0.0004—0.0018 in) Maximum: 0.065mm (0.0026 in)</p> |
| <p>2. Rotor—Oil pump cover Standard: 0.005—0.020mm (0.0002—0.0008 in) Maximum: 0.030mm (0.0012 in)</p> | <p>4. Vane—Oil pump cover Standard: 0.015—0.050mm (0.0006—0.0020 in) Maximum: 0.080mm (0.003 in)</p> | |


Wear limit

Check each part for wear; if not within specification, replace the oil pump.



03U0K2-161

- | | |
|--|---|
| <p>1. Oil pump body sleeve outer diameter Standard: 28.00mm (1.102 in)</p> | <p>4. Valve outer diameter Standard: 12.00mm (0.472 in) Minimum: 11.86mm (0.467 in)</p> |
| <p>2. Rotor bushing inner diameter Standard: 28.00mm (1.102 in) Maximum: 28.05mm (1.104 in)</p> | <p>5. Seal pin outer diameter Standard: 5.00mm (0.197 in) Minimum: 4.90mm (0.193 in)</p> |
| <p>3. Guide ring outer diameter Standard: 57.85mm (2.278 in) Minimum: 57.70mm (2.272 in)</p> | |




03U0K2-162

Assembly procedure

1. Install the valve and spring into the oil pump body, and check that the valve moves smoothly.
2. Install the plug.


Tightening torque:

24—35 N·m (2.4—3.6 m·kg, 17—26 ft·lb)




86U07B-179

3. Install the cam ring and pivot roller onto the oil pump body.




86U07B-180

4. Install the rotor onto the oil pump body.




86U07B-181

5. Install the vanes into the rotor as shown.




86U07B-182

6. Install the guide spring and guide ring while expanding the vanes toward the cam ring.




86U07B-183

7. Install the pump flange onto the rotor.



86U07B-184

8. Install the spring between the cam ring and oil pump body.




03U0K2-163

Note

- Install the seal pins round end first.

9. Install the seal pins and springs with the pins facing toward the oil pump body.
 10. Install the new O-rings.




86U07B-186

11. Install the oil pump cover to the oil pump body. Tighten the bolts in sequence.


Tightening torque:

8—11 N·m (82—112 cm·kg, 71—97 in·lb)



03U0K2-164

12. Install the oil pump shaft and check for smooth oil pump operation.
 13. Install the new seal rings.



86U07B-188







14. Apply petroleum jelly to the bearing race to secure it to the oil pump cover; then install it on the oil pump cover.

Bearing race outer diameter: 88.0mm (3.46 in)


CLUTCH ASSEMBLY

Preparation

SST

| | | | |
|--|--|--|--|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly/assembly of clutch assembly</p> | <p>49 G019 025</p> <p>Body B (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of clutch assembly</p> |
| <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of clutch assembly</p> | <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of clutch assembly</p> |
| <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of clutch assembly</p> | <p>49 G019 024</p> <p>Body (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of clutch assembly</p> |

03U0K2-165




03U0KX-217

Preinspection

Clutch operation

1. Set the clutch assembly onto the oil pump.
2. Check the clutch operation by applying compressed air through the fluid passages shown.

Applied air pressure: 392 kPa (4.0 kg/cm², 57 psi)



03U0KX-221

Forward clutch


1. Measure the clearance between the retaining plate and the snapping.

Clearance: 1.0—1.2mm (0.040—0.047 in)

2. If not as specified, replace parts as necessary.
3. Select and install the correct snap ring when assembling.

Disassembly / Inspection / Assembly

1. Disassembly in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



P APPLY RETROLEUM JELLY

03U0K2-166

—Forward clutch—

1. Thrust bearings
Inspect for damage and rough rotation
2. Snap ring
3. Retaining plate
4. Drive and driven plate
Inspect for wear and burning
Inspection page K2-176
5. Dished plate

—Coasting clutch—


6. Snap ring
7. Retaining plate
8. Drive and driven plate
Inspect for wear and burning
Inspection page K2-176
9. Dished plate
10. Snap ring
Disassembly note page K2-176
11. Spring and retainer assembly
Inspection page K2-175
12. Coasting clutch drum
Disassembly note page K2-175
Inspection page K2-176

13. Coasting piston
Disassembly note page K2-175
Inspection page K2-177


14. Outer seal
15. Inner seal
16. Outer seal
17. Seal ring

—Reverse clutch—


18. Snap ring
19. Retaining plate
20. Drive and driven plate
Inspect for wear and burning
Inspection page K2-176
21. Dished plate
22. Snap ring
Disassembly note page K2-175
23. Return spring stop
24. Piston return spring
25. Reverse piston
Disassembly note page K2-176
26. Seal rings (Inner and outer)
27. Reverse and forward drum
Inspection page K2-177




03U0KX-223




03U0KX-224



96U07B-026



03U0KX-225



03U0KX-226

Disassembly note

Snap ring (coasting clutch)

1. Install the **SST** in the coasting clutch drum as shown.
2. Compress the spring and retainer assembly.
3. Remove the snap ring.
4. Remove the **SST**, then remove the spring and retainer assembly.

Coasting clutch drum

1. Remove the coasting clutch drum from the reverse and forward drum by applying compressed air through the fluid passage.


Coasting piston

1. Remove the coasting clutch piston from the coasting clutch drum by applying compressed air through the fluid passage.

Snap ring (reverse clutch)


1. Install the **SST** in the reverse and forward drum as shown.
2. Compress the piston return spring.

3. Remove one end of the snap ring from the groove with snap-ring pliers.



86U07B-195


4. Remove the **SST** from the reverse and forward drum.
5. Remove the snap ring with a screwdriver.



03U0KX-227

Reverse piston

1. Place the reverse and forward drum on the oil pump.
2. Remove the reverse piston by applying compressed air through the fluid passage.



03U0KX-228

Inspection


Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard: 1.6mm (0.063 in)

Minimum: 1.4mm (0.055 in)

2. If not within specification, replace the drive plates.




03U0K2-167

Spring and retainer assembly (coasting clutch)

1. Measure the spring free length and check for deformation.

Free length: 29.80mm (1.173 in)

2. If not within specification, replace the spring and retainer assembly.




03U0KX-230

Coasting clutch drum

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




03U0KX-231

Coasting piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




03U0KX-232

Reverse and forward drum

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




03U0KX-233


Assembly procedure

Reverse clutch

1. Install the reverse piston.
 - (1) Apply ATF to inner and outer faces of the seals, and install them to the reverse piston.
 - (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the reverse clutch drum.
- (3) Install the reverse piston by pushing evenly around the circumference, being careful not to damage the seal rings.




86U07B-200




03U0KX-234

2. Install the piston return spring with the tabs facing away from the reverse piston.
3. Install the return spring stop with the step facing upward.




86U07B-202

4. Install the snap ring half-way down the reverse forward drum as shown.



86U07B-203

5. Install the **SST** on the reverse and forward drum.
 6. Compress the spring and retainer assembly.
 7. Install the snap ring with a screwdriver.
 8. Remove the **SST**.



03U0KX-235

9. Install the dished plate with the dished side facing the piston as shown.
 10. Install the drive and driven plates.

Note

• **Installation order: Driven-Drive-Driven-Drive**

11. Install the retaining plate.
 12. Install the snap ring.

13. Measure the reverse clutch clearance.
 (1) Measure the clearance between the snap ring and the retaining plate of the reverse clutch.
 (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.

Reverse clutch clearance:

0.9—1.1mm (0.035—0.043 in)


Retaining plate size

mm (in)


| | | |
|--------------|--------------|--------------|
| 6.5 (0.2559) | 6.6 (0.2598) | 6.7 (0.2638) |
| 6.8 (0.2677) | 6.9 (0.2717) | 7.0 (0.2756) |
| 7.1 (0.2795) | 7.2 (0.2835) | 7.3 (0.2874) |
| 7.4 (0.2913) | 7.5 (0.2953) | 7.6 (0.2992) |
| 7.7 (0.3031) | 7.8 (0.3071) | 8.0 (0.3150) |

Coasting clutch


1. Install the coasting clutch drum.
 (1) Apply ATF to inner and outer faces of the seal, and install it onto the coasting clutch drum.
 (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the drum.




86U07B-206




03U0KX-237




86U07B-208



86U07B-209



86U07B-210



86U07B-211

- (3) Install the coasting clutch drum in the correct position in the reverse and forward drum as shown.
- (4) Push evenly around the circumference, being careful not to damage the outer seal.


2. Install the coasting piston.

- (1) Apply ATF to inner and outer faces of the seals and install them onto the coasting piston.
- (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the drum.

- (3) Install the coasting piston by pushing evenly around the circumference, being careful not to damage the outer seal.

3. Install the spring and retainer assembly.

4. Install the **SST** in the coasting clutch as shown.
5. Compress the spring and retainer assembly.
6. Install the snap ring.
7. Remove the **SST**.




03U0KX-238

8. Install the dished plate with the dished side downward.

Note

- **Installation order: Driven-Drive-Driven-Drive**

9. Install the drive and driven plates.
10. Install the retaining plate.
11. Install the snap ring.



03U0K2-169

12. Measure the coasting clutch clearance.
 - (1) Measure the clearance between the snap ring and the retaining plate of the coasting clutch.
 - (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.

Coasting clutch clearance:

1.0—1.2mm (0.040—0.047 in)

Retaining plate sizes

mm (in)

| | | |
|--------------|--------------|--------------|
| 4.6 (0.1811) | 4.8 (0.1890) | 5.0 (0.1969) |
| 5.2 (0.2047) | 5.4 (0.2126) | 5.6 (0.2205) |


Forward clutch

1. Install the dished plate with the dished side downward.

Note


- **Installation order: Driven-Drive-Driven-Drive-Driven-Drive**

2. Install the drive and driven plates.



03U0KX-240

3. Install the retaining plate.
4. Install the snap ring.



86U07B-215

5. Measure the forward clutch clearance.
 - (1) Measure the clearance between the snap ring and the retaining plate of the forward clutch.
 - (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.


Forward clutch clearance:

1.0—1.2mm (0.040—0.047 in)


Retaining plate sizes

mm (in)


| | | |
|--------------|--------------|--------------|
| 5.9 (0.2323) | 6.1 (0.2402) | 6.3 (0.2480) |
| 6.5 (0.2559) | 6.7 (0.2638) | 8.9 (0.3504) |




03U0K2-170



03U0KX-242



03U0KX-244



03U0KX-245

6. Check the clutch operation as follows.
 - (1) Set the clutch assembly onto the oil pump.
 - (2) Check the clutch operation by applying compressed air through the fluid passages shown.

Applied air pressure: 392 kPa (4.0 kg/cm², 57 psi)

Caution

- The compressed air must be under 392 kPa (4.0 kg/cm², 57 psi), and should not applied for over 3 seconds.


- (4) Verify that no bubbles come from between the piston and drum seal when applying compressed air through the fluid passages shown.

7. Apply petroleum jelly to the thrust bearings, and secure them on each side of the reverse and forward drum.

Thrust bearing outer diameter

Oil pump side: 86.0mm (3.39 in)

**Small sun gear and one-way clutch side:
56.1mm (2.21 in)**



03U0KX-246

SMALL SUN GEAR AND ONE-WAY CLUTCH


Preinspection

One-way clutch operation

While holding the one-way clutch outer race, verify that the one-way clutch inner race rotates smoothly when turned clockwise and locks when turned counterclockwise. If not as specified, replace the one-way clutch.

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



P APPLY PETROLEUM JELLY

03U0K2-171

- | | | |
|---|--|--|
| <p>1. Thrust bearing Inspect for damage and rough rotation</p> <p>2. Snap ring</p> <p>3. One-way clutch inner race</p> <p>4. Thrust bearing Inspect for damage and rough rotation</p> | <p>5. Snap ring</p> <p>6. Small sun gear Inspection ... page K2-182</p> <p>7. Sun gear drum Inspection ... page K2-182</p> | <p>8. Thrust bearing Inspect for damage and rough rotation</p> <p>9. One-way clutch outer race</p> <p>10. One-way clutch</p> |
|---|--|--|



86U07B-222


Inspection

Check the following and replace any faulty parts.

1. Sun gear drum and small sun gear for damage or wear
2. Bushing for damage or wear

Specification


Sun gear drum: 33.425mm (1.316 in) max.
Small sun gear: 24.021mm (0.946 in) max.



86U07B-224


Replacement of one-way clutch

1. Remove the one-way clutch inner race.
2. Remove the one-way clutch.
3. Remove the thrust bearing.



86U07B-225

4. Inspect the one-way clutch inner and outer races, and replace if necessary.




86U07B-226

5. Apply petroleum jelly to the thrust bearing to secure it; then install it to the one-way clutch inner race.

Thrust bearing outer diameter: 62.1mm (2.44 in)


Caution

- Check that the spring cage of the one-way clutch faces toward the outer race.




86U07B-227

6. Install the one-way clutch into the one-way clutch outer race.



86U07B-228


7. Install the one-way clutch inner race into the one-way clutch outer race by turning inner race counterclockwise.
8. Hold the one-way clutch outer race. Check that the inner race turns only counterclockwise.



03U0K2-172

Assembly procedure

1. Install the small sun gear into the sun gear drum.
2. Install the snap ring.




86U07B-230

3. Apply petroleum jelly to the thrust bearing to secure it; then install it to the one-way clutch inner race.

Thrust bearing outer diameter: 62.1mm (2.44 in)


Note

- **Align the splines of the one-way clutch inner race and small sun gear clutch hub.**




86U07B-231

4. Install the one-way clutch inner and outer race to the sun gear drum.




86U07B-232

5. Install the snap ring.



86U07B-233

6. Check that when the small sun gear is held, the one-way clutch outer race turns smoothly and only clockwise.



86U07B-234


7. Apply petroleum jelly to the thrust bearing to secure it; then install it to the sun gear drum.

Thrust bearing outer diameter: 72.0mm (2.83 in)

ONE-WAY CLUTCH CARRIER HUB ASSEMBLY


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-173

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Snap ring 2. One-way clutch Inspection page K2-185 3. Bearing races Inspect bearing for scoring and scratches | <ol style="list-style-type: none"> 4. Snap ring 5. Carrier hub assembly Inspection page K2-186 6. Inner race (Low and reverse hub) |
|--|---|



03U0KX-257

Inspection


One-way clutch

Check for the following and repair or replace as necessary.

Note

- Assemble the one-way clutch and the inner race, then verify that the one-way clutch rotates only clockwise and smoothly.

1. Damaged or worn one-way clutch and operation.
2. Detached roller.



03U0KX-258

Carrier hub assembly


Check for the following and repair or replace as necessary.

1. Damaged or worn gear and operation.
2. Clearance between pinion washers and planetary carrier.

Clearance: 0.2—0.7mm (0.008—0.028 in)


Assembly procedure

1. Assemble the carrier hub assembly to the inner race.



03U0KX-259

2. Install the snap ring.



86U07B-240

Note


- Install the tangs of the bearing race into the alignment holes.

3. Apply petroleum jelly to the bearing race and secure them to each side of the one-way clutch and carrier hub assembly.

Bearing race outer diameter







Sun gear drum side: 72.0mm (2.83 in)

3-4 clutch side: 57.0mm (2.21 in)




03U0K2-174

3-4 CLUTCH Preparation SST

| | | | |
|--|---|--|---|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly/assembly of 3-4 clutch</p> | <p>49 G019 025</p> <p>Body B (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of 3-4 clutch</p> |
| <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of 3-4 clutch</p> | <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of 3-4 clutch</p> |
| <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7)</p>  | <p>For disassembly/assembly of 3-4 clutch</p> | <p>49 G019 012</p> <p>Leak checker</p>  | <p>For disassembly/assembly of 3-4 clutch</p> |

03U0KX-261




03U0KX-262

Preinspection Clutch operation

1. Install the **SST** as shown, and check clutch operation by applying compressed air.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi)



03U0K2-175

Clutch clearance

1. Measure the clearance between the snap ring and the retaining plate of the 3-4 clutch.
2. If the clearance is not within specification, adjust it by selecting a proper snap ring.

3-4 clutch clearance: 1.3—1.5mm (0.051—0.059 in)


Retaining plate sizes

mm (in)

| | | |
|--------------|--------------|--------------|
| 4.2 (0.1654) | 4.4 (0.1732) | 4.6 (0.1811) |
| 4.8 (0.1890) | 5.0 (0.1969) | 5.2 (0.2047) |

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-176

1. Thrust bearings
Inspect for damage and rough rotation
2. Snap ring
3. Retaining plate
4. Drive and driven plates
Inspect for wear and burning
Inspection..... page K2-189
5. Snap ring

6. Spring and retainer assembly
Inspection..... page K2-189
7. 3-4 clutch piston
Inspection..... page K2-189
8. Outer seal
9. Inner seal
10. 3-4 clutch drum




03U0KX-266

Disassembly note

Snap ring


1. Install the **SST** to the 3-4 clutch as shown.
2. Compress the spring and retainer assembly.
3. Remove the snap ring.
4. Remove the **SST**, then remove the spring and retainer.



03U0KX-267

3-4 clutch piston

1. Remove the 3-4 clutch piston with the **SST** and compressed air.



03U0KX-268

Inspection


Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard: 1.6mm (0.063 in)

Minimum: 1.4mm (0.055 in)

2. If not within specification, replace the drive plate(s).



03U0K2-177


Spring and retainer assembly

1. Measure the spring free length.

Specifications

| Outer dia. mm (in) | Free length mm (in) | No. of coils | Wire dia. mm (in) |
|-----------------------|------------------------|--------------|----------------------|
| 74.4 (2.929) | 40.5 (1.594) | 1.0 | 5.0 (0.197) |

2. If not within specification, replace the spring.




9MUOK1-232

Clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on return spring side.


Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.



03U0KX-270


Assembly procedure

1. Install the 3-4 clutch piston.
 - (1) Apply ATF to the inner and outer seals, and install them onto the 3-4 clutch piston.
 - (2) Install the piston by pushing evenly around the circumference, being careful not to damage the seal rings.



03U0KX-271

2. Install the spring and retainer.




03U0KX-272

3. Install the **SST** to the 3-4 clutch as shown.
4. Compress the spring and retainer.
5. Install the snap ring.
6. Remove the **SST**.

Note

- **Installation order:**
Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive



03U0K2-178

7. Install the drive and driven plates.
8. Install the retaining plate.
9. Install the snap ring.

10. Measure the 3-4 clutch clearance.
 - (1) Measure the clearance between the snap ring and the retaining plate of the 3-4 clutch.
 - (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.


3-4 clutch clearance: 1.3—1.5mm (0.051—0.059 in)

Retaining plate sizes


mm (in)

| | | |
|--------------|--------------|--------------|
| 4.2 (0.1654) | 4.4 (0.1732) | 4.6 (0.1811) |
| 4.8 (0.1890) | 5.0 (0.1969) | 5.2 (0.2047) |


03U0K2-179



03U0K2-180



03U0K2-181



03U0K2-182

11. Check clutch operation as follows:

- (1) Install the **SST** as shown, and check clutch operation by applying compressed air.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi)

Caution

- The compressed air must be under 392 kPa (4.0 kg/cm², 57 psi) and not applied for over 3 seconds.

- (2) Verify that no bubbles escape past the 3-4 clutch piston seal while applying compressed air.

12. Apply petroleum jelly to the thrust bearings and secure them to each side of the 3-4 clutch drum.

Thrust bearing outer diameter






Carrier hub side: 56.1mm (2.21 in)

Output shell side: 72.1mm (2.84 in)

LOW AND REVERSE BRAKE


Preparation

SST

| | | | |
|---|---|---|---|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly/ assembly of low and reverse brake</p> | <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly/ assembly of low and reverse brake</p> |
| <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7A)</p>  | <p>For disassembly/ assembly of low and reverse brake</p> | <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly/ assembly of low and reverse brake</p> |
| <p>49 B019 002</p> <p>Body (Part of 49 G019 0A7A)</p>  | <p>For disassembly/ assembly of low and reverse brake</p> | <p style="text-align: right;">03U0KX-278</p> | |


Disassembly / Inspection / Assembly

1. Disassemble as in the shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-183

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Snap ring 2. Retaining plate 3. Drive and driven plates Inspect for wear and burning Inspection page K2-194 4. Snap ring Disassembly note page K2-194 | <ol style="list-style-type: none"> 5. Spring and retainer assembly Inspection page K2-194 6. Low and reverse brake piston Disassembly Note page K2-194 Inspection page K2-194 7. Outer seal 8. Inner seal 9. Transaxle case |
|---|--|




03U0KX-283

Disassembly note

Snap ring


1. Install the **SST** in the transaxle case as shown.
2. Compress the spring and retainer assembly.
3. Remove the snap ring.
4. Remove the **SST**, then remove the spring and spring retainer assembly.



03U0KX-284

Low and reverse brake piston

1. Remove the low and reverse brake piston by applying compressed air through the fluid passage.



03U0KX-285

Inspection


Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard: 1.6mm (0.063 in)

Minimum: 1.4mm (0.055 in)

2. If not within specification, replace the drive plates.




03U0KX-286

Spring and retainer assembly

1. Measure the spring free length and check for deformation.

Free length of spring: 14.3mm (0.563 in)

2. If not within specification, replace the spring and retainer assembly.




03U0KX-287


Low and reverse brake piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.


Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




03U0KX-288




86U07B-388



03U0KX-289



03U0KX-290



03U0K2-184

Assembly procedure

1. Install the low and reverse brake piston.
 - (1) Apply ATF to the inner and outer seals, and install them onto the low and reverse brake piston.
 - (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the case.
 - (3) Install the low and reverse brake piston by pushing evenly around the circumference, being careful not to damage the outer seal.


2. Install the spring and retainer assembly.

3. Install the **SST** in the transaxle case.
4. Compress the spring and retainer assembly.
5. Install the snap ring with snap-ring pliers.
6. Remove the **SST**.


Caution

- The compressed air must be under 392 kPa (4.0 kg/cm², 57 psi) and not applied for over 3 seconds.


7. Check the low and reverse brake piston operation.
 - (1) Check that no bubbles come from between the piston and seals when applying compressed air through the fluid passage.




03U0KX-292



03U0KX-293



03U0K2-185



03U0KX-295

Note

- Installation order:
Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive

8. Install the drive and driven plates.

9. Install the retaining plate.

10. Install the snap ring.

11. Measure the low and reverse brake clearance.

- (1) Measure the clearance between the snap ring and the low and reverse brake retaining plate.
- (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.

**Low and reverse brake clearance:
2.1—2.4mm (0.083—0.094 in)**

Retaining plate sizes

mm (in)

| | | |
|---------------|---------------|---------------|
| 10.0 (0.3937) | 10.2 (0.4016) | 10.4 (0.4094) |
| 10.6 (0.4173) | 10.8 (0.4252) | |








12. Check the low and reverse brake operation by applying compressed air through the fluid passage as shown in the figure.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi)

2-4 BRAKE BAND, SERVO

Preparation


SST

| | | | |
|--|---|---|---|
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 501 Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 502 Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 503 Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G019 028 Bolt</p>  | <p>For adjustment of 2-4 brake band</p> | <p>49 G019 029 Nut</p>  | <p>For adjustment of 2-4 brake band</p> |
| <p>49 G019 030 Plate</p>  | <p>For adjustment of 2-4 brake band</p> | <p>03U0K2-186</p> | |

03U0K2-186


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



03U0K2-187

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Bolt 2. Washer 3. Piston stem 4. Servo retainer 5. O-ring | <ol style="list-style-type: none"> 6. Servo piston 7. D-rings 8. Return servo spring 9. Anchor strut and shaft 10. 2-4 brake band |
|--|--|




03U0K2-188

Inspection

2-4 brake band

Check the following and replace if necessary.

1. Damaged or worn 2-4 brake band




03U0K2-189

Band Servo

Check the following and replace any faulty parts.

1. Damaged or worn piston
2. Weakened return spring

Free length of spring: 42.0mm (1.654 in)




03U0K2-190

Assembly note

Band servo

1. Install the servo to the transaxle case.
 - (1) Install the servo spring and servo.
 - (2) Compress the servo with the **SST**.
 - (3) Install the snap ring.
 - (4) Remove the **SST**.
 - (5) Install the piston stem.



03U0K2-312


Adjustment of 2-4 brake band

1. Remove the oil pan. (Refer to page K2-158.)
2. Adjust the 2-4 brake band. (Refer to page K2-271.)

2-3 ACCUMULATOR

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly referring to **Assembly Procedure**.



03U0K2-191

- | | |
|---------------------------|---------------------------|
| 1. Snap ring | 5. 2-3 accumulator piston |
| 2. Stopper plug | 6. Large seal ring |
| 3. O-ring | 7. Small seal ring |
| 4. 2-3 accumulator spring | |


Inspection..... page K2-200

Inspection


2-3 accumulator spring

1. Measure the spring free length.


Free length of spring: 75.9mm (2.988 in)




03U0K2-192



03U0K2-193



03U0K2-194



03U0K2-195

Assembly procedure

1. Apply ATF to new large seal ring and small seal ring; then install them to the accumulator piston.
2. Install the 2-3 accumulator piston.





3. Install the spring to the piston.
4. Apply ATF to new O-ring, and install it onto the stopper plug.
5. Install the stopper plug.

6. Install the snap ring while holding in the stopper plug.

IDLER GEAR (TRANSAXLE)

Preparation


SST

| | | | |
|--|--|--|---|
| <p>49 FT01 439</p> <p>Holder, idler gear shaft</p>  | <p>For adjustment of bearing preload</p> | <p>49 G019 013</p> <p>Bearing remover</p>  | <p>For removal of bearing</p> |
| <p>49 0180 510B</p> <p>Attachment, steering worm bearing preload measuring</p>  | <p>For adjustment of bearing preload</p> | <p>49 S120 785</p> <p>Installer, boot</p>  | <p>For installation of bearing outer race</p> |

03U0K2-196

Disassembly / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



N·m (m·kg, ft·lb)

03U0K2-197

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Locknut Disassembly note page K2-203 2. Bearing Inspect for wear and rough rotation 3. Spacer 4. Idler gear Inspect for wear and cracks 5. Adjust shim Adjustment of bearing preload 6. Bearing Inspect for wear and rough rotation | <ol style="list-style-type: none"> 7. Idler shaft Inspect for wear and rough rotation 8. Bearing outer race Disassembly note page K2-203 Inspect bearing surface for scoring and scratches 9. Bearing outer race Disassembly note page K2-203 Inspect bearing surface for scoring and scratches 10. O-ring |
|---|--|



03U0KX-319


Disassembly note

Locknut

Note

- Use protective plates in the vise to prevent damage to the SST.


1. Secure the idler shaft in a vise with the **SST**, and remove the locknut.



03U0KX-320

Bearing outer race


1. Remove the bearing outer race from the idler gear with the **SST**.



03U0KX-321

Assembly procedure

1. Press the bearing outer races in with the **SST**.




03U0KX-322

2. Install the idler gear bearing onto the idler shaft, then install the idler gear, adjustment shims, spacer, and bearing.

Note

- Use protective plates in the vise to prevent damage to the SST.




03U0KX-323


3. Secure the idler shaft in a vise with the **SST**, and tighten the locknut to the lower limit of the tightening torque.

Tightening torque:


128—177 N·m (13—18 m·kg, 94—130 ft·lb)



03U0KX-324



03U0KX-325



03U0KX-326

Note

- Use protective plates in the vise to prevent damage to the idler gear.

4. Check and adjust the idler gear bearing preload.
 - (1) Turn the idler gear assembly and **SST** over, and secure the gear in the vice.
 - (2) Attach the **SST** and spring scale or torque wrench, and measure the preload while tightening the locknut.

Note

- Read the preload when the idler shaft starts to turn.

Tightening torque:

128—177 N·m (13—18 m·kg, 94—130 ft·lb)

Preload:

0.03—0.9 N·m (0.3—9.0 cm·kg, 0.26—7.8 in·lb)

Value indicated on pull scale:

0.3—9 N (0.03—0.9 kg, 0.066—1.98 lb)

Note





- The maximum allowable number of shims is 7.
- Preload is reduced by increasing the thickness of the shims, or increased by reducing the thickness.

5. If the specified preload cannot be obtained within the specified tightening torque, adjust by selecting the proper adjustment shims.

| Thickness of shim | | | mm (in) |
|-------------------|--------------|--------------|--------------|
| 3.80 (0.150) | 3.85 (0.152) | 3.90 (0.154) | 3.95 (0.156) |
| 4.00 (0.158) | 4.05 (0.159) | 4.10 (0.161) | 4.15 (0.163) |
| 4.20 (0.165) | 4.25 (0.167) | 4.30 (0.169) | 4.35 (0.171) |
| 4.40 (0.173) | 4.45 (0.175) | 4.50 (0.177) | 4.55 (0.179) |
| 4.60 (0.181) | 4.65 (0.183) | 4.70 (0.185) | 4.75 (0.187) |

OUTPUT GEAR


**Preparation
SST**

| | | | |
|--|--|--|---|
| <p>49 B017 1A0</p> <p>Remover set, bearing</p>  | <p>For removal of bearing inner race</p> | <p>49 F401 366A</p> <p>Plate (Part of 49 B017 1A0)</p>  | <p>For removal of bearing inner race</p> |
| <p>49 G019 022</p> <p>Attachment K</p>  | <p>For removal of bearing inner race</p> | <p>49 G019 011</p> <p>Installer, bearing</p>  | <p>For installation of bearing inner race</p> |

03U0KX-327

Disassembly / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-198

1. Seal rings
2. Output gear
Inspect for wear and cracks


3. Bearings
Disassembly note page K2-205
Inspect for wear and rough rotation



03U0KX-329

**Disassembly note
Bearings**


1. Remove the bearings from the output gear with the **SST**.



03U0KX-330

Assembly Procedure Bearings

1. Press the output gear bearings onto the output gear with the **SST**.




Seal rings

1. Install the seal rings to the output gear.

BEARING COVER ASSEMBLY

Preparation


SST

| | | |
|--|---|---|
| <p>49 G019 017 Installer, oil seal</p> |  | <p>For installation of bearing outer race</p> |
|--|---|---|

03U0KX-332


Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-199


- | | |
|--|---------------------------------------|
| <p>1. Oil seal 2. Bearing outer race</p> | <p>3. O-ring 4. Bearing cover</p> |
|--|---------------------------------------|
- Disassembly note page K2-207
Inspect bearing surface for scoring and scratches



03U0KX-334

Disassembly note
Bearing outer race

1. Remove the bearing outer race with a pin punch and hammer as shown.




03U0KX-335

Assembly procedure

Bearing outer race

1. Press the bearing outer race into the cover.



03U0KX-336

Oil seal

1. Press the oil seal into the cover with the **SST**.

CONTROL VALVE BODY (DISASSEMBLY / INSPECTION)


Disassembly / Inspection

Caution


- Be especially careful when handling the control valve because it consists of the most precise and delicate parts of the transaxle.
- Neatly arrange the removed parts to avoid confusing the similar parts.
- Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.

1. Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.
2. Inspect all parts and repair or replace as necessary.

03U0K2-200




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. 1-2 solenoid valve Inspection..... page K2- 2. Oil strainer 3. 2-3 solenoid valve Inspection..... page K2- 4. Oil strainer 5. Bolts 6. Front control body Inspect for clogging and damage 7. Front/premain front gasket 8. Premain separator | <ol style="list-style-type: none"> 9. Front premain rear gasket 10. Orifice check valve and spring 11. Premain control body Disassembly / Inspection / Assembly..... page K2-214 12. Orifice check valve and spring 13. Orifice check valve and spring 14. Throttle relief ball and spring 15. Premain/main front gasket 16. Main separator |
|--|---|



03U0K2-201


- | | |
|--|---|
| <p>17. Pre-main/main rear gasket</p> <p>18. Converter relief ball and spring</p> <p>19. Orifice check valve and spring</p> <p>20. Main control body Disassembly / Inspection / Assembly page K2-218</p> <p>21. Steel ball</p> <p>22. Orifice check valve and spring</p> <p>23. Main/rear front gasket</p> <p>24. Rear separator</p> <p>25. Main/rear rear gasket</p> | <p>26. Orifice check valve and spring</p> <p>27. Orifice check valve and spring</p> <p>28. Rear control valve body Disassembly / Inspection / Assembly page K2-222</p> <p>29. 3-4 solenoid valve Inspection page K2-</p> <p>30. Oil strainer</p> <p>31. Lockup solenoid valve Inspection page K2-</p> <p>32. Oil strainer</p> |
|--|---|



03U0K2-202


Disassembly Procedure

1. Remove the 3-4 solenoid valve and lockup solenoid valve.
2. Remove the O-rings and oil strainers.




86U07B-268

3. Remove the 1-2 solenoid valve and 2-3 solenoid valve and wire harness.
4. Remove the O-rings and oil strainers.




86U07B-269

5. Remove the front indicated bolts and pull out the front control body with premain separator as a unit.




86U07B-270

6. Remove the front/premain gaskets and separator from the front control body.




86U07B-271

7. Remove the orifice check valve ($\phi 0.8\text{mm}$, 0.071 in) and spring from the premain control body.




86U07B-272

- Remove the bolts and hexagonal head bolt and remove the premain control body and the main separator as a unit.




03U0K2-313

- Remove the premain/main gaskets and separator from the premain control body.
- Remove the orifice check valves ($\phi 2.0\text{mm}$, 0.079 in; $\phi 2.5\text{mm}$, 0.098 in) and springs, and the throttle relief ball and spring from the premain control body.




86U07B-274

- Remove the converter relief ball and spring, and the orifice check valve ($\phi 0.8\text{mm}$, 0.031 in) and spring from the main control body.




86U07B-275

- Turn the assembly over and remove the bolts shown in the figure. Remove the rear separator as a unit.



03U0K2-314

- Remove the main/rear gaskets and separator from the rear control body.
- Remove the orifice check valves ($\phi 1.5\text{mm}$, 0.059 in; $\phi 1.0\text{mm}$, 0.039 in) and spring from the rear control body.



03U0K2-315


15. Remove the orifice check valve ($\phi 2.5\text{mm}$, 0.98 in) and spring and the steel ball from the main control body.

PREMAIN CONTROL VALVE BODY Disassembly / Inspection / Assembly

Caution


- Each valve should slide out/in under its own weight.
- When a valve will not slide out under its own weight, depending on the valve, push it out it with a wire or place the valve body open-side down and lightly tap it with a soft hammer. Never scratch or otherwise damage a valve surface or bore.
- Do not drop or lose the valves or internal parts.
- Before assembly, make sure all parts are thoroughly clean.
- Apply ATF to all parts and bores.
- Note the proper direction of the valves and internal parts.
- Do not reuse any part that has been dropped.
- Wrap a screwdriver or rod with a tape before using it to insert a valve.

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Retainer 2. 2-3 timing spring Inspection page K2-215 3. 2-3 timing valve Inspect for sticking, scoring and scratches 4. Stop pin 5. Stop plug 6. Servo control valve Inspect for sticking, scoring and scratches 7. Servo control spring Inspection page K2-215 8. Stop pin 9. Stop plug 10. Bypass valve Inspect for sticking, scoring and scratches 11. Bypass spring Inspection page K2-215 12. Bolts 13. 1-2 accumulator plate 14. Gasket 15. 1-2 accumulator spring Inspection page K2-215 16. 1-2 accumulator piston 17. 1-2 accumulator seal rings 18. Bolts 19. N-R accumulator plate 20. Gasket | <ul style="list-style-type: none"> 21. N-R accumulator front spring Inspection page K2-215 22. N-R accumulator piston 23. N-R accumulator rear spring Inspection K2-215 24. N-R accumulator seal rings 25. N-D accumulator front spring Inspection page K2-215 26. N-D accumulator piston 27. N-D accumulator seal rings 28. Coasting bypass spring Inspection page K2-215 29. Coasting bypass valve Inspect for sticking, and scratches 30. Coasting baypass plug 31. Retainer 32. 3-2 timing spring Inspection page K2-215 33. 3-2 timing valve Inspect for sticking, scoring and scratches 34. Stop pin 35. Stop plug 36. 3-2 capacity valve Inspection page K2-215 37. 3-2 capacity valve Inspect for sticking, scoring and scratches |
|--|--|

03U0K2-204



03U0KX-358

Inspection

1. Measure the spring free length.
2. If not within specification, replace the spring(s).


| Spring | Item | Outer dia. mm (in) | Free length mm (in) | Wire dia. mm (in) | Spring color |
|------------------------------|------|-----------------------|------------------------|----------------------|--------------|
| 1-2 accumulator spring | | 16.0 (0.630) | 72.1 (2.839) | 2.2 (0.087) | — |
| Bypass, servo control spring | | 4.9 (0.193) | 27.6 (1.087) | 0.55 (0.022) | Yellow |
| 2-3 timing spring | | *6.7 (0.263) | 26.5 (1.043) | 0.8 (0.031) | — |
| N-R accumulator rear spring | | 11.1 (0.437) | 62.0 (2.441) | 1.2 (0.047) | Light green |
| N-D accumulator front spring | | 9.8 (0.386) | 60.9 (2.398) | 1.1 (0.043) | Yellow |
| Coasting bypass spring | | 5.8 (0.228) | 37.7 (1.484) | 0.6 (0.024) | Dark blue |
| 3-2 timing spring | | *6.6 (0.260) | 28.6 (1.126) | 0.8 (0.031) | Red |
| 3-2 capacity spring | | *4.4 (0.173) | 30.6 (1.205) | 0.5 (0.020) | White |
| Throttle relief ball spring | | 6.6 (0.260) | 21.6 (0.850) | 0.8 (0.031) | — |

* Inner diameter

03U0K2-205


Assembly Procedure

1. Install the 3-2 capacity valve, 3-2 capacity spring, and stopper plug; then install the stopper pin.
2. Install the 3-2 timing valve, the 3-2 timing spring, and re-
tainer.



86U07B-280

3. Install the coasting bypass plug, coasting bypass valve and coasting bypass spring.
4. Apply ATF to the O-rings, and install them to the piston; then insert the N-R accumulator rear spring and N-R accumulator piston.
5. Apply ATF to the O-rings, and install them to the piston; then insert the N-D accumulator piston and N-D accumulator front spring.




86U07B-281

6. Install the N-R accumulator gasket and plate; then tighten the plate.


Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)



86U07B-282

7. Apply ATF to the O-rings, and install them onto the piston; then install the 1-2 accumulator piston and 1-2 accumulator springs.




86U07B-283


8. Install the 1-2 accumulator gasket and plate; then tighten the plate.

Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)



86U07B-284



86U07B-285

9. Install the bypass spring, bypass valve, stopper plug, and stopper pin.
10. Install the servo control spring, servo control valve, stopper plug, and stopper pin.
11. Install the 2-3 timing valve, 2-3 timing spring, and retainer.


MAIN CONTROL VALVE BODY

Disassembly / Inspection / Assembly

Caution

- Each valve should slide out/in under its own weight.
- When a valve will not slide out under its own weight, depending on the valve, push it out it with a wire or place the valve body open-side down and lightly tap it with a soft hammer. Never scratch or otherwise damage a valve surface or bore.
- Do not drop or lose the valves or internal parts.
- Before assembly, make sure all parts are thoroughly clean.
- Apply ATF to all parts and bores.
- Note the proper direction of the valves and internal parts.
- Do not reuse any part that has been dropped.
- Wrap a screwdriver or rod with a tape before using it to insert a valve.


1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



03U0K2-207

- | | |
|---|---|
| <ul style="list-style-type: none"> 1. Stop pin 2. Stop plug 3. Pressure modifier spring Inspection page K2-219 4. Pressure modifier valve Inspect for sticking, scoring and scratches 5. Retainer 6. Low reducing spring Inspection page K2-219 7. Low reducing valve Inspect for sticking, scoring and scratches 8. Stop pin 9. Stop plug 10. 1-2 shift valve Inspect for sticking, scoring and scratches 11. 1-2 shift spring Inspection page K2-219 12. Stop pin 13. Stop plug 14. 2-3 shift valve Inspect for sticking, scoring and scratches 15. 2-3 shift spring Inspection page K2-219 16. Stop pin 17. Stop plug | <ul style="list-style-type: none"> 18. 3-4 shift valve Inspect for sticking, scoring and scratches 19. 3-4 shift spring Inspection page K2-219 20. Retainer 21. Throttle back-up valve Inspect for sticking, scoring and scratches 22. Throttle back-up spring Inspection K2-219 23. Stop pin 24. Stop plug 25. Throttle modulator valve Inspect for sticking, scoring and scratches 26. Throttle modulator spring Inspection page K2-219 27. Throttle plug assembly Inspect for sticking, scoring and scratches 28. Throttle spring Inspection page K2-219 29. Throttle valve Inspect for sticking, scoring and scratches 30. Throttle assist spring Inspection page K2-219 31. Throttle adjust plug |
|---|---|

03U0K2-208




03U0KX-358

Inspection

1. Measure the spring free length.
2. If not within specification, replace the spring(s).

| Spring | Item | Outer dia. mm (in) | Free length mm (in) | No. of coils | Wire dia. mm (in) |
|------------------------------|------|-----------------------|------------------------|--------------|----------------------|
| Pressure modifier spring | | 8.3 (0.327) | 26.5 (1.043) | 0.8 (0.031) | — |
| Low reducing spring | | 8.7 (0.343) | 38.3 (1.508) | 0.9 (0.035) | Black |
| 1-2 shift spring | | 8.7 (0.343) | 41.3 (1.626) | 1.0 (0.039) | Yellow |
| 2-3, 3-4 shift spring | | 7.4 (0.291) | 36.6 (1.441) | 0.8 (0.031) | Gray |
| Throttle back-up spring | | 9.65 (0.380) | 26.9 (1.059) | 0.55 (0.022) | Red |
| Throttle modulator spring | | 6.3 (0.248) | 47.9 (1.886) | 0.8 (0.031) | — |
| Throttle assist spring | | 5.15 (0.203) | 32.3 (1.272) | 0.55 (0.022) | Dark green |
| Throttle spring | | 5.4 (0.213) | 47.2 (1.858) | 0.8 (0.031) | Pink |
| Converter relief ball spring | | *5.1 (0.200) | 24.1 (0.949) | 0.9 (0.035) | Maroon |
| Orifice check valve spring | | 5.0 (0.197) | 12.5 (0.492) | 0.23 (0.009) | — |


03U0K2-209



03U0K2-210

Assembly Procedure

1. Install the throttle adjust plug, throttle assist spring, throttle valve, and throttle plug assembly.




86U07B-289

Caution

- Install the throttle plug assembly with the groove aligned with the bolt hole.


2. Install the throttle return spring as shown.
3. Install the throttle lever assembly to the main control body.



96U07B-052


Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)




86U07B-291

4. Install the throttle modulator spring, throttle modulator valve, stopper plug, and stopper pin.
5. Install the throttle backup spring, throttle back valve, and retainer.
6. Install the 3-4 shift spring, 3-4 shift valve, stopper plug, and stopper pin.



86U07B-292

7. Install the 2-3 shift spring, 2-3 shift valve, stopper plug, and stopper pin.
8. Install the 1-2 shift spring, 1-2 shift valve, stopper plug, and stopper pin.



86U07B-293

9. Install the low reducing valve, low reducing spring, and retainer.
10. Install the pressure modifier valve, pressure modifier spring, stopper plug, and stopper pin.


REAR CONTROL VALVE BODY

Disassembly / Inspection / Assembly

Caution

- Each valve should slide out/in under its own weight.
- When a valve will not slide out under its own weight, depending on the valve, push it out it with a wire or place the valve body open-side down and lightly tap it with a soft hammer. Never scratch or otherwise damage a valve surface or bore.
- Do not drop or lose the valves or internal parts.
- Before assembly, make sure all parts are thoroughly clean.
- Apply ATF to all parts and bores.
- Note the proper direction of the valves and internal parts.
- Do not reuse any part that has been dropped.
- Wrap a screwdriver or rod with a tape before using it to insert a valve.

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




03U0K2-211

1. Manual valve
Inspect for sticking, scoring and scratches
2. Stop pin
3. Stop pin
4. Pressure regulator backup plug
5. Pressure regulator plug sleeve
6. Pressure regulator plug
7. Pressure regulator spring seat
8. Pressure regulator spring
Inspection page K2-223

9. Pressure regulator valve
Inspect for sticking, scoring and scratches
10. Stop pin
11. Stop plug
12. Lockup control valve
Inspect for sticking, scoring and scratches
13. Lockup control spring
Inspection page K2-223

03U0K2-212




03U0KX-358

Inspection


1. Measure the spring free length.
2. If not within specification, replace the spring(s).

| Spring | Item | Outer dia. mm (in) | Free length mm (in) | Wire diameter mm (in) | Spring color |
|---------------------------|------|-----------------------|------------------------|--------------------------|--------------|
| Pressure regulator spring | | 11.5 (0.452) | 26.5 (1.043) | 1.0 (0.039) | Maroon |
| Lockup control spring | | 5.0 (0.196) | 35.2 (1.386) | 0.6 (0.024) | Purple |

03U0K2-213



03U0K2-214




86U07B-297

Assembly Procedure

1. Install the lockup control spring, lockup control valve, stopper plug, and stopper pin.
2. Install the pressure regulator valve, pressure regulator spring, pressure regulator spring seat, pressure regulator plug, pressure regulator plug sleeve, pressure regulator backup plug, stopper plug, and stopper pin.

Note

- Install the stopper plug larger end first.



86U07B-298

3. Install the manual valve.


CONTROL VALVE BODY (ASSEMBLY)

Assembly

Caution


- Before assembly, make sure all parts are perfectly clean.
- Apply ATF to all parts.
- Do not reuse the gaskets or O-rings.

1. Assemble as shown in the figure, referring to **Assembly Procedure**.



03U0K2-215

- | | |
|--|--|
| <p>1. Oil strainer</p> <p>2. Lockup solenoid valve</p> <p>3. Oil strainer</p> <p>4. 3-4 solenoid valve</p> <p>5. Rear control valve body Bolt installation position page K2-229</p> <p>6. Orifice check valve and spring Installation position page K2-228</p> <p>7. Orifice check valve and spring Installation position page K2-228</p> <p>8. Main/rear rear gasket</p> <p>9. Rear separator</p> | <p>10. Main/rear front gasket</p> <p>11. Orifice check valve and spring Installation position page K2-228</p> <p>12. Steel ball Installation position page K2-228</p> <p>13. Main control valve body Bolt installation position page K2-229</p> <p>14. Orifice check valve and spring Installation position page K2-228</p> <p>15. Converter relief ball and spring Installation position page K2-228</p> <p>16. Pre-main/main rear gasket</p> |
|--|--|




03U0K2-216

- | | |
|--|--|
| 17. Main separator | 24. Front/premain rear gasket |
| 18. Premain/main front gasket | 25. Premain separator |
| 19. Throttle relief ball and spring | 26. Front/premain front gasket |
| Installation position page K2-227 | 27. Front control body |
| 20. Orifice check valve and spring | Bolt installation position page K2-229 |
| Installation position page K2-227 | 28. Bolts |
| 21. Orifice check valve and spring | 29. 2-3 solenoid valve |
| Installation position page K2-227 | 30. Oil strainer |
| 22. Premain control body | 31. 1-2 solenoid valve |
| Bolt installation position page K2-229 | 32. Oil strainer |
| 23. Orifice check valve and spring | |
| Installation position page K2-227 | |


Installation positions

PREMAIN CONTROL VALVE BODY

(MAIN CONTROL VALVE BODY SIDE)




(FRONT CONTROL BODY SIDE)




MAIN CONTROL VALVE BODY

(REAR CONTROL VALVE BODY SIDE)


(PREMAIN CONTROL VALVE BODY SIDE)










REAR CONTROL VALVE BODY



Bolt installation positions and external parts locations



03U0KX-379

| Identification mark | Bolt | Length mm (in) | Tightening torque N-m (cm-kg, in-lb) |
|---------------------|---|-------------------|---|
| H |  | 50 (1.969) | 7.8—11 (80—110, 69—95) |
| A |  | 40 (1.575) | |
| B |  | 35 (1.378) | |
| C |  | 25 (0.984) | |
| D |  | 20 (0.787) | |
| I |  | 16 (0.630) | |
| G |  | — | |


03U0K2-316

K2-229


Assembly Procedure

Note

- Do not mix-up the front and rear gaskets during assembly.
- Match the bolt head letter and the control valve body letter.




03U0K2-218



03U0K2-317

1. Install the orifice check valves ($\phi 1.5\text{mm}$, 0.059 in; $\phi 1.0\text{mm}$, 0.039 in) and springs in the rear control body as shown.




86U07B-301

2. Install the gaskets on both sides of the rear separator; then install it onto the rear control body.


Note

- The main/rear rear gasket and main/rear front gasket are not interchangeable.




86U07B-302

3. Install the orifice check valve ($\phi 2.5\text{mm}$, 0.098 in) and spring, and the steel ball in the main control body as shown.




03U0K2-318



86U07B-304

4. Install the rear control body to the main control body.




86U07B-305

Note


- Match the bolt head letter as shown.

5. Loosely tighten the bolts.




86U07B-306

6. Turn the assembly over and install the orifice check valve ($\phi 0.8\text{mm}$, 0.031 in) and spring, and the converter relief ball and spring in the main control body as shown.




03U0K2-319

7. Install the orifice check valves ($\phi 2.0\text{mm}$, 0.079 in; $\phi 2.5\text{mm}$, 0.098 in) and springs, and the throttle relief ball and spring in the premain control body as shown.



86U07B-308

8. Install the gaskets on both sides of the main separator; then install it onto the premain control body.




86U07B-309

Note

- The premain/main rear gasket and premain/main front gasket are not interchangeable.

9. Set the premain control body onto the main control body.




86U07B-310

Note


- Match the bolt head letter as shown.

10. Loosely tighten the bolts.




86U07B-311

11. Install the orifice check valve ($\phi 0.8\text{mm}$, 0.071 in) and spring in the premain control body as shown.




86U07B-312


12. Install the gaskets on both sides of the premain separator; then install it onto the front control body.



86U07B-313




86U07B-314



86U07B-315

13. Install the front control body on the premain control body.




86U07B-316

Note


- Match the bolt head letter as shown.

14. Loosely tighten the bolts.



86U07B-317

15. Install the control valve body mounting bolts as shown for alignment.




86U07B-318

16. Tighten the mounting bolts.
 (1) Tighten the front control body.

Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)




86U07B-319

(2) Tighten the rear control body.

Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)




86U07B-320

17. Install the 3-4 solenoid valve and lock-up solenoid valve along with new O-rings and oil strainers.

Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)



86U07B-321

18. Install the 1-2 solenoid valve and 2-3 solenoid valve along with new O-rings and oil strainers.

Tightening torque:

6—8 N·m (66—80 cm·kg, 57—69 in·lb)


CONTROL VALVE BODY (ON-VEHICLE REMOVAL / INSTALLATION)

On-vehicle Removal


Caution

- Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents before removal.


1. Disconnect the oil hose.
2. Drain the ATF into a suitable container.




03U0K2-219



03U0K2-220



03U0K2-221



03U0K2-222

3. Remove the control valve cover and the gasket.
4. Remove the throttle cable from the throttle cam of the valve body.


5. Disconnect the solenoid connector.
6. Pinch the tangs of the solenoid connector and remove it by pushing inward.

7. Remove the control valve body as an assembly.


On-vehicle Installation

Caution

- Be sure to align the manual plate and the manual valve.



03U0K2-223




03U0K2-224

1. Install the control valve body assembly.


Tightening torque:

11—15 N·m (1.1—1.5 m·kg, 8.0—11 ft·lb)




03U0K2-225

2. Apply ATF to a new O-ring and install it onto the solenoid connector.
3. Install the solenoid connector into the transaxle case.




03U0K2-226

4. Install the throttle cable to the throttle cam.



03U0K2-227

5. Install the control valve body cover along with a new gasket.


Tightening torque:

03U0K2-228

6. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated against the ridge.
7. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
8. Verify that the hose clamp does not interfere with any other parts.
9. Pour in ATF and with the engine idling, check the ATF level and check for leaks. (Refer to page K2-134.)
10. Drive the vehicle and check the shift points, shift schedule, and shift shock. (Refer to Road test; page K2-127.)

IDLER GEAR ASSEMBLY (TRANSFER)


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



N·m (m·kg, ft·lb)

03U0K2-229


- | | |
|--|---|
| <p>1. Locknut Disassembly Note page K2-237 Assembly Note page K2-238</p> <p>2. Retaining ring Disassembly Note page K2-238 Assembly Note page K2-238</p> <p>3. Side cover Disassembly Note page K2-238 Assembly Note page K2-238</p> | <p>4. Bearing Disassembly Note page K2-238 Assembly Note page K2-238</p> <p>5. Idle gear Inspect individual gear teeth for wear and cracks</p> |
|--|---|



03U0K2-230

Disassembly Note
Locknut

1. Raise the nut tab and loosen the locknut, but do not remove it.




03U0K2-231

Side cover, bearing

1. Tap the bearing and remove the side cover and the bearing.


2. Remove the bearing from the side cover with a press.



03U0K2-232

Assembly Note**Bearing**


1. Install the bearing with a press.



03U0K2-233

Side cover

1. Install the top cover with a press.




03U0K2-234

Locknut

1. Tighten a new locknut and crimp it.

Tightening torque:

157—206 N·m (16—21 m·kg, 116—152 ft·lb)







03U0K2-235

MEMO

FRONT AND CENTER DIFFERENTIAL ASSEMBLY

PREPARATION


SST

| | | | |
|---|------------------------------------|--|------------------------------------|
| <p>49 B027 001</p> <p>Holder, diff. side gear</p>  | <p>For holding side gear</p> | <p>49 B027 004</p> <p>Measuring plate</p>  | <p>For measure of clearance</p> |
| <p>49 F401 331</p> <p>Body</p>  | <p>For installation of bearing</p> | <p>49 G030 338</p> <p>Attachment E</p>  | <p>For installation of bearing</p> |

03U0K2-236

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary:
3. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.



03U0K2-237

1. Bearing inner race (Gear sleeve side)
Disassembly Note page K2-241
Inspect for damage or rough rotation
2. Differential lock gear sleeve
3. Differential lock hub
Inspect for wear or damage
4. Gear case needle bearing
Inspect for wear or damage
5. Ring gear case
Inspect for wear or damage
6. Gear case needle bearing
Inspect for wear or damage
7. Gear case needle bearing
Inspect for wear or damage
8. Differential lock thrust washer
9. Gear case needle bearings
Inspect for wear or damage
10. Bearing inner race (Sun gear side)
Disassembly Note page K2-241
Inspect for wear or damage
11. Thrust washer
12. Gear case needle bearing
Inspect for wear or damage
13. Sun gear
Inspect for wear or damage
14. Gear case needle bearing
Inspect for wear or damage
15. Planetary carrier
Inspect for engagement with pinion gears
16. Gear case needle bearing
Inspect for wear or damage
17. Spacer
18. Gear case needle bearing
Inspect for wear or damage
19. Differential gear case sleeve
Disassembly Note page K2-242
20. Pinion shaft
21. Washer
22. Pinion gear
Inspect for wear or damage
23. Washer
24. Side gear
Inspect for wear or damage
25. Differential gear case
Inspect for wear or damage

03U0K2-238




03U0K2-239

Disassembly note
Bearing inner race (Gear sleeve side)

Caution

- Hold the front differential with one hand so that it does not fall.

1. Remove the bearing with a press.




03U0K2-240

Bearing inner race (Sun gear side)

Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the bearing with a suitable pipe.


Differential gear case sleeve

03U0K2-241

Caution


- Hold the gear case one hand so that it dose not fall.

1. Remove the differential gear case sleeve with a press.

Assembly procedure**Front differential**

03U0K2-242

1. Install the side gears and washers, and fix them with the SST.




63G07C-141

2. Install a pinion gear and turn it 180°.


Note

- Do not install the washer at this time.




63G07C-142

3. Install the other pinion gear and washer.
4. Turn the pinion gear and washer 150°.
5. Install the washer on opposite pinion gear.




63G07C-143

6. Align the pinion shaft holes of the pinion gears with the differential gear case.



63G07C-144


7. Insert the pinion shaft.



63G07C-145

Center differential


1. Install the differential gear case sleeve.



03U0K2-243

- 2. Install the gear case needle bearings and spacer.
- 3. Install the planetary carrier assembly, gear case needle bearing, and the **SST**.

Measuring plate thickness: 4.3mm (0.169 in)




93U07C-040

- 4. Measure the clearance between the **SST** and gear case needle bearing.
If the clearance is not within specification, select the proper washer from the chart below.


Standard: 0.10—0.30mm (0.004—0.012 in)

| Measured clearance mm (in) | Washer thickness mm (in) |
|----------------------------|--------------------------|
| 0.10—0.25 (0.0039—0.0098) | 4.3 (0.169) |
| 0.30—0.45 (0.0118—0.0177) | 4.1 (0.161) |
| 0.50—0.65 (0.0196—0.0256) | 3.9 (0.154) |
| 0.70—0.85 (0.0276—0.0334) | 3.7 (0.146) |
| 0.90—1.10 (0.0354—0.0433) | 3.5 (0.138) |




93U07C-041


- 5. Install the proper washer and the bearing inner race with the **SST**.



63G07C-149



93U07C-042



83U07C-015

6. Install the gear case needle bearings and differential lock thrust washer.

7. Install the differential lock gear sleeve, differential lock hub and gear case needle bearing.

8. Measure the clearance between the differential lock hub and the gear case needle bearing.

If the clearance is not within specification, select the proper differential lock thrust washer.

Standard: 0.15—0.30mm (0.006—0.011 in)

Available washer thickness:

















1.20mm (0.047 in), 1.35mm (0.053 in),


1.50mm (0.059 in), 1.65mm (0.065 in),

1.80mm (0.071 in)

9. Install the bearing inner race with a press and the **SST**.

TRANSFER CARRIER ASSEMBLY PREPARATION SST

| | | | |
|--|--|--|--|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly and assembly of differential</p> | <p>49 M005 561 Hanger, differential carrier</p>  | <p>For disassembly and assembly of differential</p> |
| <p>49 0636 145 Puller, fan pulley boss</p>  | <p>For removal of bearing inner race (side bearing)</p> | <p>49 U027 003 Installer, oil seal</p>  | <p>For installation of oil seal (companion flange)</p> |
| <p>49 F027 0A0 Gauge set, pinion height adjustment</p>  | <p>For adjustment of pinion height</p> | <p>49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0)</p>  | <p>For adjustment of pinion height</p> |
| <p>49 8531 565 Pinion model</p>  | <p>For adjustment of pinion height</p> | <p>49 8531 567 Collar A (Part of 49 8531 565)</p>  | <p>For adjustment of pinion height</p> |
| <p>49 D017 2A1 Installer set, bearing</p>  | <p>For installation of bearing</p> | <p>49 F401 336B Attachment B (Part of 49 D017 2A1)</p>  | <p>For installation of bearing inner race (rear bearing)</p> |
| <p>49 F401 331 Body (Part of 49 D017 2A1)</p>  | <p>For installation of bearing inner race (rear bearing)</p> | <p>49 0839 425C Puller set, bearing</p>  | <p>For removal and installation of companion flange</p> |
| <p>49 S120 710 Holder, coupling flange</p>  | <p>For removal and installation of companion flange</p> | <p>49 0259 720 Wrench, differential side bearing adjusting nut</p>  | <p>For adjustment of drive pinion and ring gear backlash</p> |
| <p>49 F401 366A Plate</p>  | <p>For removal of bearing inner race</p> | <p>49 B027 003 Attachment M</p>  | <p>For removal of bearing inner race</p> |



03U0K2-246

Disassembly Note Transfer carrier assembly


1. Mount the transfer carrier assembly on the **SST**.

Bearing caps

1. Mark one bearing cap and the carrier.

Adjusting nuts


1. Mark one adjusting nuts and the carrier.



03U0K2-247

Locknut


1. Hold the companion flange with the **SST** and remove the locknut.



03U0K2-248

Companion flange


1. Remove the companion flange with the **SST**.



03U0K2-249

Drive pinion

1. Push the drive pinion out by attaching a miscellaneous locknut to it, then tapping it with a brass hammer.



03U0K2-250

Bearing outer race

Note


- For proper reassembly, identify the bearing outer race.

1. Remove the bearing outer races by using the two grooves in the carrier and tapping the races alternately.

Bearing inner race (Rear bearing)**Note**

- Support the drive pinion by hand so that it will not fall.

1. Remove the bearing inner race (rear bearing) with the **SST**.




03U0K2-251


Bearing inner race (Differential gear)**Note**

- Do not disassemble the bearing inner race unless necessary.
- For proper reassembly, identify the bearing inner race.
- Support the drive pinion by hand so that it will not fall.


1. Remove the bearing inner race with the **SST**.



03U0K2-252


**Assembly note****Adjustment of pinion height**

1. Install the bearing inner race with the **SST**.




03U0K2-253


2. Install the bearing outer race with a brass drift.




03U0K2-254




9MU0MX-052



9MU0MX-053



9MU0MX-054



9MU0MX-055

3. Adjust the drive pinion height as follows with the **SST**.

Note

- Use the spacer that was removed.

a) Install the spacer and bearing inner race to the **SST**.

b) Assemble the spacer, rear bearing, and **SST**. Secure the **SST** with the O-ring. Install the assembly in the carrier.


Note

- Use the same spacer and nut removed during disassembly.


c) Install the front bearing, **SST**, companion flange, washer, and nut.

d) Tighten the nut to the extent that the companion flange can still be turned by hand.

e) Place the **SST** on the surface plate and set the dial indicator to "Zero".




9MU0MX-056




9MU0MX-057

| Mark | Thickness | Mark | Thickness |
|------|-----------------------|------|-----------------------|
| 08 | 3.08mm (0.1213 in) | 29 | 3.29mm (0.1295 in) |
| 11 | 3.11mm (0.1224 in) | 32 | 3.32mm (0.1307 in) |
| 14 | 3.14mm (0.1236 in) | 35 | 3.35mm (0.1319 in) |
| 17 | 3.17mm (0.1248 in) | 38 | 3.38mm (0.1331 in) |
| 20 | 3.20mm (0.1260 in) | 41 | 3.41mm (0.1343 in) |
| 23 | 3.23mm (0.1271 in) | 44 | 3.44mm (0.1354 in) |
| 26 | 3.26mm (0.1283 in) | 47 | 3.47mm (0.1366 in) |

9MU0MX-058



9MU0MX-059



05U0MX-106

- f) Place the **SST** atop the drive pinion model; then set the gauge body atop the gauge block.
- g) Place the feeler of the dial indicator so that it contacts where the side bearing is installed in the carrier. Measure the lowest position on both the left and right sides.

- h) Add the two (left and right) values obtained by the measurements taken in step g, and divide the total by 2.

Standard: 0mm (0 in)

Note

- The spacer thicknesses are available in increments of 0.03mm. Select the spacer thickness that is closest to that necessary.


- i) If it is not within specification, adjust the pinion height by selection of a spacer.

Adjustment of drive pinion preload


Note

- Press on until the force required suddenly increases.
- Install the spacer selected for the pinion height adjustment, being careful that the installation direction is correct.


1. Install the spacer.
2. Press the rear bearing on with the **SST**.
3. Apply a light coat of grease to the end face of the companion flange.




05U0MX-107




05U0MX-108



05U0MX-109



05U0MX-110



9MU0MX-067

4. Install a new collapsible spacer.
5. Install the drive pinion assembly.

Note

- Do not install the oil seal.

6. Install the companion flange, and tighten the locknut with the **SST**.

Tightening torque: 118 N·m (12 m·kg, 87 ft·lb)

7. Turn the companion flange several turns by hand to seat the bearing.
8. Measure the drive pinion preload. Adjust the preload by tightening the locknut and record the tightening torque.

Preload:

0.3—0.7 N·m (3—7 cm·kg, 2.6—6.1 in·lb)

Tightening torque:


118—177 N·m (12—18 m·kg, 87—130 ft·lb)

9. Remove the nut, washer, and companion flange.
10. Tap a new oil seal into the differential carrier with the **SST**.

11. Install the companion flange and washer, and tighten the locknut to the tightening torque recorded in Step 8.


Inspection and adjustment of teeth contact

1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, adjust the pinion height, and then adjust the backlash.



63G09X-385

- (1) Toe and flank contact
Replace the spacer with a thinner one to move the drive pinion outward.



9MU0MX-068


- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.

BEARING PRELOAD Procedure


Note

- Use the SST shown below to adjust the preload.

1. Measure the output gear bearing preload, and select the proper adjustment shim(s) as described below.



03U0KX-421




03U0KX-422

- (1) Align the bearing cover with guide bolts as shown, and press it in. Tighten the bearing cover bolts.


Tightening torque:

11—14 N·m (1.1—1.4 m·kg, 8—10 ft·lb)




03U0KX-423


- (2) Install the converter housing onto the transaxle hanger.
- (3) Remove the bearing outer race and adjustment shims from the bearing housing.
- (4) Set the output gear assembly into the converter housing.




03U0KX-424




76G07B-723



03U0KX-425



03U0KX-426



03U0KX-427

Caution

- Eliminate the gap (arrow) by turning A or B of the selector.

(5) Install the outer race removed in Step (3) to the **SST**. Set the **SST** and outer race onto the output gear assembly.

(6) Set the four **SST** on the converter housing in the positions shown.

(7) Set the bearing housing on the **SST** (selector) and install the four **SST** (bolts); then tighten them to the specified torque.

Tightening torque:

19—26 N·m (1.9—2.6 m·kg, 14—18 ft·lb)

Note

- Seat the bearing.

(8) Turn the **SST** (selector) to increase the clearance indicated by the arrow with the **SST** (bars) until it no longer turns.

(9) Turn the selector in the opposite direction until the gap is reduced.

(10) Mount the **SST** and pull scale or torque wrench on the output gear.


(11) Adjust the clearance between A and B to obtain the specified preload/pull scale reading.

Preload:


0.03—0.9 N·m (0.3—9.0 cm·kg, 0.26—7.81 in·lb)

Reading on pull scale:



0.3—9 N (0.03—0.9 kg, 0.066—1.98 lb)




86U07B-361



03U0KX-428



76G07B-728



03U0KX-429

Note

- Read the preload when the output gear starts to turn.

Caution

- Measure the clearance around the entire circumference, and select shims equivalent to the maximum clearance.
- The maximum allowable number of shims is 7.

(12) Measure the clearance. Select adjustment shim(s) equivalent to the measured clearance.

| Thickness of shim mm (in) | | | |
|---------------------------|--------------|--------------|--------------|
| 0.50 (0.020) | 0.55 (0.022) | 0.60 (0.024) | 0.65 (0.026) |
| 0.70 (0.028) | 0.75 (0.030) | 0.80 (0.032) | 0.85 (0.034) |
| 0.90 (0.035) | 0.95 (0.037) | 1.00 (0.039) | 1.05 (0.041) |
| 1.10 (0.043) | 1.15 (0.045) | 1.20 (0.047) | 1.25 (0.049) |
| 1.30 (0.051) | 1.35 (0.053) | 1.40 (0.055) | 1.45 (0.057) |

- (13) Remove the bearing housing and **SST**.
 (14) Install the required shim(s) and press the bearing race into the bearing housing with the **SST**.

(15) Install the bearing housing.

Tightening torque:

19—26 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

(16) Verify that the preload/pull scale reading is within specification. If not within specification return to Step (3).

Preload:

0.03—0.9 N·m (0.3—9.0 cm·kg, 0.26—7.81 in·lb)

Reading on pull scale:


0.3—9 N (0.03—0.9 kg, 0.066—1.98 lb)

(17) Remove the bearing housing and output gear assembly.


Note

- Use the **SST** shown below to inspect and adjust the preload.

2. Measure the differential side bearing preload, and select the proper adjustment shim(s) as described below.



03U0KX-430




03U0KX-431

- (1) Remove the bearing outer race and adjustment shims from the transaxle case.
- (2) Set the differential assembly into the converter housing.

Caution


- Eliminate the gap (arrow) by turning either **A** or **B** of the selector.

- (3) Install the outer race removed in Step (1) into the **SST**. Set the **SST** and outer race onto the differential assembly.




03U0KX-432


- (4) Set the six **SST** on the converter housing in the positions shown.




86U07B-370



03U0KX-434



03U0K2-320



86U07B-373

- (5) Set the transaxle case on the selectors.
- (6) Tighten the **SST** (bolts) to the specified torque.

Tightening torque:

36—52 N·m (3.7—5.3 m·kg, 27—38 ft·lb)

Note

- **Seat the bearing.**
- **Bend the bar as shown to turn the SST at B.**

- (7) Turn the **SST** (selector) to increase the clearance indicated by the arrow with the **SST** (bars), until it no longer turns.
- (8) Turn the selector in the opposite direction until the gap is reduced.

- (9) Insert the **SST** through the transaxle case and attach it to the side gear.
- (10) Mount the **SST** and pull scale or torque wrench.

Note

- **Read the preload when the differential starts to turn.**

- (11) Adjust the clearance between A and B to obtain the specified preload/pull scale reading.

Preload: 2.9—3.9 N·m (30—40 cm·kg, 26—35 in·lb)

Reading on pull scale:

29—39 N (3.0—4.0 kg, 6.6—8.8 lb)


- (12) Measure the clearance between A and B.
- (13) Add **0.3mm (0.0118 in)** to the measured clearance, and select the shim(s) closest in value to that measurement.

Caution

- **Measure the clearance around the entire circumference, and select shims based on the maximum clearance.**
- **The maximum allowable number of shims is 3.**

| Thickness of shim mm (in) | | | |
|---------------------------|--------------|--------------|--------------|
| 0.50 (0.020) | 0.55 (0.022) | 0.60 (0.024) | 0.65 (0.026) |
| 0.70 (0.028) | 0.75 (0.030) | 0.80 (0.032) | 0.85 (0.034) |
| 0.90 (0.035) | 0.95 (0.037) | 1.00 (0.039) | 1.05 (0.041) |
| 1.10 (0.043) | 1.15 (0.045) | 1.20 (0.047) | 1.25 (0.049) |
| 1.30 (0.051) | 1.35 (0.053) | 1.40 (0.055) | 1.45 (0.057) |


03U0KX-436



49 F027 009

03U0KX-437

- (14) Remove the transaxle case and **SST**.
 (15) Install the required shim(s) and tap the bearing race into the transaxle case.



49 FT01 515A

03U0K2-321

- (16) Install the transaxle case.


Tightening torque:
37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

- (17) Verify that the preload is within specification. If not within specification, return to Step (1).

Preload: 2.9—3.9 N·m (30—40 cm·kg, 26—35 in·lb)

- (18) Remove the transaxle case.

3. Install the idler gear and output gear as an assembly by tapping in with a plastic hammer.




03U0KX-439

4. Install the bearing housing.
 (1) Mount the bearing housing onto the converter housing.

Tightening torque:
19—26 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

- (2) Align the groove on the idler shaft with the mark on the bearing housing.
 (3) Tap a new roll pin in with a pin punch and hammer.







03U0KX-440

TRANSAXLE AND TRANSFER UNIT (ASSEMBLY)

Preparation

SST

| | | | |
|--|------------------------------|--|------------------------------|
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503 Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501 Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502 Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |


03U0K2-255

Precaution

1. If the drive plates or brake band are replaced with new ones, soak the new part in ATF for at least 2 hours before installation.
2. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, and sliding parts.
3. All O-rings, seals, and gaskets must be replaced with the new ones included in the overhaul kit.
4. Use petroleum jelly, not grease, during reassembly.
5. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.
6. Assemble the housing within 10 minutes after applying sealant, and allow it to cure at least 30 minutes after assembly before filling the transaxle with ATF.

03U0KX-442

Bearing, and race locations




03U0KX-443

Outer diameter of bearing and race

| | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|---------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Bearing | mm (in) | 86.0 (3.39) | 56.1 (2.21) | 62.1 (2.44) | 62.1 (2.44) | 72.0 (2.83) | 56.1 (2.21) | 72.1 (2.84) |
| Race | mm (in) | 88.0 (3.46) | | | | 72.0 (2.83) | 57.0 | |


03U0K2-322

Assembly




03U0K2-256

- | | | |
|--------------------------------|-----------------------|--|
| 1. Oil pump and gasket | 5. Inhibitor switch | 8. Oil level gauge and oil filler tube |
| 2. Throttle cable | 6. Oil strainer | 9. Oil pump shaft |
| 3. Control valve body assembly | 7. Oil pan and gasket | 10. Torque converter |
| 4. Oil pan and gasket | | |



03U0K2-257


- | | |
|---|----------------------------|
| 1. 3-4 clutch assembly | 10. Snap ring |
| 2. Internal gear | 11. Servo |
| 3. Snap ring | 12. 2-4 brake band |
| 4. Low and reverse brake (Drive and drive plates) | 13. Anchor strut and shaft |
| 5. Retaining plate | 14. Small sun gear |
| 6. Snap ring | 15. One-way clutch |
| 7. Carrier hub | 16. Clutch assembly |
| 8. Wave washer | 17. Snap ring |
| 9. One-way clutch | |



03U0K2-258

- 1. Parking pawl
- 2. Parking assist lever
- 3. Actuator support
- 4. Manual shaft and manual plate


- 5. Bracket
- 6. Turbine shaft
- 7. Output shell
- 8. Transaxle case



N-m (m-kg, ft-lb)

03U0K2-259

- | | |
|--|--|
| 1. Bearing outer race (Transaxle case) | 11. Oil seal (Bearing cover) |
| 2. Oil seal (Transaxle case) | 12. Oil seal |
| 3. 2-3 accumulator | 13. Adjustment shim |
| 4. Converter housing | 14. Bearing outer race |
| 5. Transfer carrier assembly | 15. Output gear |
| 6. Idler gear assembly (Transfer) | 16. Idler gear assembly (Transaxle) |
| 7. O-ring | 17. Bearing housing |
| 8. Side cover | 18. Roll pin |
| 9. O-ring | 19. Front and center differential shift fork |
| 10. Bearing cover | 20. Front and center differential assembly |




03U0K2-260

1. Assemble the center differential lock shift fork assembly to the center differential assembly, and install the center differential assembly into the clutch housing.
2. Install the set bolt.


Note

- Before coating with sealant, clean the contact surfaces.



03U0K2-261

3. Coat both surfaces with sealant.




03U0K2-262

4. Install the transfer carrier assembly.


Tightening torque:

25—30 N·m (2.5—3.1 m·kg, 18—22 ft·lb)



03U0K2-263


5. Install the idle gear.




03U0K2-264

6. Install the output shell to the output gear, and install the bearing race onto the output shell.


Thrust bearing outer diameter: 72.1mm (2.84 in)




03U0K2-265




03U0K2-266



03U0K2-267



03U0K2-268



03U0KX-461

7. Apply a thin coat of silicone sealant to the contact surfaces of the converter housing and transaxle case.
8. Install the new O-rings.
9. Mount the transaxle case to the converter housing.

Tightening torque:**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

10. Install the **SST** to hold the turbine shaft.

11. Lift the idle gear slightly.
12. Install a new oil seal.


Note

- Before coating with sealant, clean the contact surfaces.

13. Coat the side cover and the converter housing with sealant.
14. Install the side cover.


Tightening torque:**A 37—52 N·m (3.8—5.3 m·kg, 27.5—38.3 ft·lb)****B 19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)**

15. Install the turbine shaft and 3-4 clutch assembly.
 - (1) Assemble the turbine shaft and 3-4 clutch assembly.




03U0KX-462

- (2) Verify that the thrust bearing is properly installed.
- (3) Install the turbine shaft and 3-4 clutch assembly into the transaxle case.




03U0KX-463

16. Install the internal gear.
 - (1) Install the internal gear to the 3-4 clutch drum.
 - (2) Install the snap ring.




03U0KX-464

17. Install the carrier hub assembly.
 - (1) Verify that the thrust bearing and bearing race are properly installed.



86U07B-401

- (2) Hold the turbine shaft with one hand to prevent it from rotating.
- (3) Install the carrier hub assembly into the 3-4 clutch drum by rotating it.




03U0KX-465

18. Install the drive and driven plates.


Note

- **Installation order:**
Driven-Drive-Driven-Drive-Driven-Drive-
Driven-Drive



03U0KX-466

19. Install the retaining plate.
20. Install the snap ring.



03U0K2-269


21. Check the low and reverse brake clearance.
 - (1) Measure the clearance between the snap ring and the low and reverse brake retaining plate.
 - (2) If the clearance is not within specification, adjust it by selecting a proper retaining plate.

Low and reverse brake clearance:
2.1—2.4mm (0.083—0.094 in)

Retaining plate sizes

mm (in)


| | | |
|-------------|-------------|-------------|
| 6.8 (0.268) | 7.0 (0.276) | 7.2 (0.283) |
| 7.4 (0.291) | 7.6 (0.299) | 7.8 (0.307) |



03U0K2-270


22. Check the low and reverse brake operation by applying compressed air through the fluid passage as shown in the figure.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi)




03U0K2-271

23. Install the wave washer.
24. Install the one-way clutch.
 - (1) Hold the one-way clutch horizontally.
 - (2) Install it by turning the carrier hub assembly counter-clockwise.
 - (3) Install the snap ring.



03U0K2-272

25. Install the servo to the transaxle case.
 - (1) Install the servo spring and servo.
 - (2) Compress the servo with the **SST**.
 - (3) Install the snap ring.
 - (4) Remove the **SST**.
 - (5) Install the piston stem.




03U0K2-273

26. Install the anchor strut.


Note

- **Interlock the 2-4 brake band and anchor strut as shown.**



03U0K2-274


27. Install the 2-4 brake band in the transaxle case so that it is fully expanded.



03U0K2-275


28. Install the small sun gear and one-way clutch.

- (1) Verify that the thrust bearing and bearing race are installed in the correct position.



03U0KX-472


- (2) Install the small sun gear and one-way clutch while rotating it.



03U0K2-276


29. Install the clutch assembly.

- (1) Verify that the thrust bearing is installed in the correct position.



03U0KX-474

(2) Install the clutch assembly while rotating it.




03U0KX-475

Note


- Measure the height difference between the reverse and forward drum and the transaxle case.

Maximum: 0.9mm (0.035 in)



03U0K2-277


30. Install the snap ring into the bottom ring groove of the turbine shaft.



03U0K2-278

31. Use the following procedure to adjust the total end play and select a suitable bearing race.

(1) Set the thrust bearing onto the clutch assembly.




03U0KX-478


(2) Remove the previously used race and gasket.

(3) Set the thickest bearing race **2.2mm (0.087 in)** onto the oil pump.


(4) Set the oil pump onto the clutch assembly.




03U0KX-479




86U07B-421



03U0K2-279



03U0K2-280



03U0K2-281

- (5) Measure clearance A between the transaxle case and the oil pump.
- (6) Select a suitable bearing race from the chart below.

| Clearance A | mm (in) | Select this bearing race mm (in) |
|-------------|---------------|-------------------------------------|
| 0.91—1.10 | (0.036—0.043) | 1.2 (0.047) |
| 0.71—0.90 | (0.028—0.035) | 1.4 (0.055) |
| 0.51—0.70 | (0.020—0.027) | 1.6 (0.063) |
| 0.31—0.50 | (0.012—0.019) | 1.8 (0.071) |
| 0.11—0.30 | (0.004—0.011) | 2.0 (0.078) |
| 0—0.10 | (0—0.003) | 2.2 (0.087) |

- (7) Remove the oil pump.
- (8) Place the selected bearing race and a new gasket onto the oil pump.
- (9) Install the oil pump onto the clutch assembly.

Tightening torque:

19—26 N·m (1.9—2.6 m·kg, 14—19 ft·lb)

32. Adjust the 2-4 brake band.

- (1) Loosen the locknut and tighten the piston stem to the specified torque.

Tightening torque:

9—11 N·m (90—110 cm·kg, 78—95 in·lb)

- (2) Loosen the piston stem 2 turns.

- (3) Hold the piston stem and tighten the locknut to the specified torque.


Tightening torque:

25—39 N·m (2.5—4.0 m·kg, 18—29 ft·lb)

33. Install the oil strainer along with a new O-ring to the transaxle.

Tightening torque:

8—11 N·m (80—110 cm·kg, 69—95 in·lb)



03U0K2-282


34. Install the oil pan along with a new gasket.

Tightening torque:

8—11 N·m (85—110 cm·kg, 74—95 in·lb)

Note

- Install the magnets in the positions shown in the illustration.




03U0K2-283

35. Align the manual valve with the pin on the manual plate, and install the control valve body into the transaxle case.


Tightening torque:

11—15 N·m (110—150 cm·kg, 95—130 in·lb)



03U0K2-284

36. Install the solenoid connector and a new O-ring in the transaxle case.



03U0K2-285


37. Install a new O-ring on the bracket; then feed the throttle cable through the transaxle case and connect it to the throttle lever.

38. Install the throttle cable bracket and attaching bolts.

Tightening torque:

A 8—11 N·m (80—110 cm·kg, 69—95 in·lb)

B 19—26 N·m (1.9—2.6 m·kg, 14—19 ft·lb)




03U0K2-286

39. Install the control valve body cover along with a new gasket.

Tightening torque:

8—11 N·m (85—110 cm·kg, 74—95 in·lb)




03U0K2-287

40. Install the center differential lock assembly.

Tightening torque:

19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)



03U0K2-288

41. Turn the rod 180° counterclockwise with a flat-tipped screwdriver.

42. Install the bolts.


Tightening torque:

9—14 N·m (90—140 cm·kg, 78—122 ft·lb)

43. Install the differential lock switch.

Tightening torque:

20—29 N·m (2—3 m·kg, 14—22 ft·lb)




03U0K2-289

44. Install the ball, spring, gasket, and a plug.


Tightening torque:

31—47 N·m (3.2—4.8 m·kg, 23—35 ft·lb)



03U0K2-290

45. Install the solenoid connector.



03U0K2-291

46. Install the pulse generator and fluid thermostatic switch.


Tightening torque:

Pulse generator

8—11 N·m (80—110 cm·kg, 69—95 in·lb)


Fluid thermostatic switch

29—39 N·m (3.0—4.0 m·kg, 22—29 in·lb)




03U0K2-292

47. Install the inhibitor switch.
 - (1) Turn the manual shaft to the N position.
 - (2) Install the inhibitor switch and loosely tighten the bolts.
 - (3) Remove the screw and move the inhibitor switch so that the small alignment hole is aligned with the screw hole.
 - (4) Set the alignment by inserting an **approx. 2.0mm (0.079 in)** diameter pin through the holes.
 - (5) Tighten the bolts to the specified torque.

Tightening torque:**8—11 N·m (80—110 cm·kg, 69—95 in·lb)**


03U0K2-293

- (6) Remove the pin, and install and tighten the screw to specification.
48. Install the harness with the remaining clip.

Tightening torque:**0.4—0.7 N·m (4—7 cm·kg, 4—6 in·lb)**


03U0K2-294

49. Remove the transaxle from the **SST**.
50. Install a new O-ring and install the oil level gauge and oil filler tube to the transaxle case.

Tightening torque:**7—10 N·m (70—100 cm·kg, 61—87 in·lb)**

03U0K2-295

51. Install the oil pump shaft.
52. Install a new O-ring onto the turbine shaft.




03U0K2-296

53. Fill the torque converter with ATF if it has been drained and washed.

ATF type: M-III or DEXRON-II**Caution**

- **Hold the torque converter in an erect position when filling it with ATF, do not allow the fluid to overflow.**
- **If the converter does not fit in easily, do not try to force it; install carefully.**


54. Install the torque converter in the converter housing while rotating it to align the splines.



03U0K2-297

55. To ensure that the torque converter is installed accurately, measure distance A between the end of the torque converter and the end of the converter housing.

(A): 13.6mm (0.535 in)



03U0K2-298


56. Install engine mount No.1.

Tightening torque:


58—67 N·m (5.9—6.8 m·kg, 43—49 ft·lb)

| | |
|---|---|
| 1. Transaxle and transfer Installation Note..... page K2-277 | 13. Cross member |
| 2. Oil hose (Outlet side) Installation Note..... page K2-277 | 14. Integrated stiffener |
| 3. Oil hose (Inlet side) Installation Note..... page K2-277 | 15. Propeller shaft Installation Note..... page K2-279 |
| 4. Engine mount No.2 | 16. Under cover |
| 5. Engine mounting member Installation Note..... page K2-278 | 17. Differential lock sensor switch connector |
| 6. Starter | 18. Differential lock motor connector |
| 7. Center differential lock motor | 19. Solenoid valve connector |
| 8. Driveshaft Installation Note..... page K2-278 | 20. Inhibitor switch connector |
| 9. Joint shaft | 21. Speedometer cable Installation Note..... page K2-279 |
| 10. Stabilizer Installation Note..... page K2-279 | 22. Battery carrier |
| 11. Tie-rod end | 23. Battery |
| 12. Exhaust pipe | 24. Air hose and air cleaner assembly |
| | 25. Splash shield |
| | 26. Wheel and tire |
| | 27. Throttle cable Installation Note..... page K2-279 |


03U0K2-299



03U0K2-300



03U0K2-301



03U0KX-497

Installation Note Transaxle and transfer

Caution

- **Do not lean the transaxle and transfer to torque converter side.**

1. Use an engine hoist, and install the transaxle and transfer.
2. Mount the transaxle and transfer to the engine.

3. Install the bolt.

Tightening torque:

55—80 N·m (5.6—8.2 m·kg, 41—59 ft·lb)

Oil hose (inlet and outlet side)


1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated against the ridge.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.

Engine mounting member

1. Tighten the bolts as shown.

Tightening torque:

A 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)
 B 64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)




03U0K2-323

2. Tighten the engine mount No.4 nuts.

Tightening torque:

66—93 N·m (6.8—9.5 m·kg, 49—68 ft·lb)



03U0K2-302

Driveshaft**Caution**

- Do not damage the oil seal.
- After installation, pull the front hub outward to verify that the driveshaft is secured.

1. Replace the clips at the ends of the driveshafts and joint shaft with new ones.
2. Push the driveshafts into the differential with the groove of clips upward.

Note


- Apply ATF to the oil seal lip.

3. Install the driveshaft.


4. Tighten the joint shaft mounting bolts in the order shown.

Tightening torque:


42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)




03U0KX-498



03U0K2-303



03U0K2-304




03U0K2-305

5. Install the lower arm ball joint to the knuckle and tighten the bolt.

Tightening torque:


43—58 N·m (4.4—6.0 m·kg, 32—43 ft·lb)



03U0KX-499

Stabilizer


1. Tighten the stabilizer nut so that **17mm (0.67 in)** to **19mm (0.75 in)** of thread is exposed at the end of the bolt.



03U0K2-306

Propeller shaft

1. Align the marks and install the propeller shaft. (Refer to Section L.)



03U0K2-307

Throttle cable

1. Connect the throttle cable.
2. Adjusting the throttle cable. (Refer to page K2-137.)

OIL COOLER


OIL COOLER

Removal / Inspection / Installation

Remove in the order shown in the figure.

Inspect all parts and repair or replace as necessary.

Install in the reverse order of removal, referring to **Installation Note**.



1. Connector bolts
Inspect for clogging

2. Packing

3. Oil pipes

Inspect for damage or cracks

4. Oil hoses

Inspect for damage or cracks

Installation note page K2-253

5. Hose clamps

6. Radiator

Service Section E


Installation note

Oil hose

1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated against the ridge.

2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.

3. Verify that the hose clamp does not interfere with any other parts.




03U0KX-503

HYDRAULIC CIRCUIT


P RANGE

HYDRAULIC CIRCUIT

K2




- Throttle pressure
- Throttle modulate pressure
- Line pressure
- Torque converter pressure




- ▨ Throttle pressure
- ▨ Throttle modulate pressure
- ▨ Line pressure
- ▨ Operating line pressure
- ▨ Torque converter pressure


N RANGE: BELOW APPROX. 18 km/h (11 mph)

HYDRAULIC CIRCUIT




N RANGE; ABOVE APPROX. 18 km/h (11 mph)





- XXXX Throttle pressure
- ▨ Throttle modulate pressure
- ▤ Line pressure
- ▧ Operating line pressure
- ▩ Torque converter pressure


D RANGE; 2ND GEAR



D RANGE; 3RD GEAR BELOW APPROX. 40 km/h (25 mph)

HYDRAULIC CIRCUIT


K2









- ⊗⊗⊗ Throttle pressure
- ▨ Throttle modulate pressure
- ▤ Line pressure
- ▧ Operating line pressure
- ▩ Torque converter pressure


03U0K2-330
K2-287


D RANGE: 3RD GEAR ABOVE APPROX. 40 km/h (25 mph)



-  Throttle pressure
-  Throttle modulate pressure
-  Line pressure
-  Operating line pressure
-  Torque converter pressure









- Throttle pressure
- Throttle modulate pressure
- Line pressure
- Operating line pressure
- Torque converter pressure

S RANGE; HOLD 2ND GEAR




03U0K2-335


S RANGE; 3RD GEAR BELOW APPROX. 40 km/h (25 mph)




S RANGE; 3RD GEAR ABOVE APPROX. 40 km/h (25 mph)



03U0K2-337






- Throttle pressure
- Throttle modulate pressure
- Line pressure
- Operating line pressure
- Low reducing pressure
- Operating low reducing pressure
- Torque converter pressure

L RANGE; 2ND GEAR BELOW APPROX. 110 km/h (68 mph)

HYDRAULIC CIRCUIT




- ⊗ Throttle pressure
- ▨ Throttle modulate pressure
- ▤ Line pressure
- ▧ Operating line pressure
- ▩ Low reducing pressure
- Torque converter pressure

03U0K2 340
K2-297

K2

L RANGE; 2ND GEAR ABOVE APPROX. 110 km/h (68 mph)



PROPELLER SHAFT

FEATURES

OUTLINE L- 2
 OUTLINE OF CONSTRUCTION..... L- 2
 SPECIFICATIONS L- 2
PROPELLER SHAFT L- 3

SERVICE

TROUBLESHOOTING GUIDE L- 4
PROPELLER SHAFT L- 4
 PREPARATION L- 4
 REMOVAL / INSPECTION / INSTALLATION .. L- 5
 OVERHAUL..... L- 7

03U0LX-801

OUTLINE

OUTLINE OF CONSTRUCTION


1. The propeller shaft is a three-piece, four-joint type with two center bearings for support.

03U0LX-802


SPECIFICATIONS

| Item | | Model | MTX | ATX |
|----------------|---------|-------|---------------|---------------|
| Length | mm (in) | L1 | 834.3 (32.84) | 836.5 (32.93) |
| | | L2 | | 634.0 (24.96) |
| | | L3 | | 437.0 (17.20) |
| Outer diameter | mm (in) | D1 | | 75.0 (2.95) |
| | | D2 | | 57.0 (2.24) |
| | | D3 | | 57.0 (2.24) |

03U0LX-803



PROPELLER SHAFT



03U0LX-804

A three-piece, four-joint type propeller shaft is used.

By employing two center bearings for support of the propeller shaft assembly, the shaft's flexibility is increased, thus reducing the amount of vibration and noise at high speed.

A constant-velocity joint, matched with either the automatic or manual transaxle, is employed at the front of the front propeller shaft for smoother power flow and improved riding comfort.

A Löbro joint is used for the front joint of MTX models for reduction of torque fluctuation, vibration and noise at the high-rpm range.

A double-offset joint, with low thrust resistance, is used for the front joint of ATX models for reduction of idle vibrations.





TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|-----------------------|--|---------|------|
| Vibration | Bent propeller shaft | Replace | L- 5 |
| | Improperly installed universal joint snap ring | Repair | L- 7 |
| | Worn or damaged center bearing | Replace | L- 7 |
| | Loose center bearing mounting bolts | Tighten | L- 5 |
| | Loose yoke mounting bolts | Tighten | L- 5 |
| | Improperly assembled center bearing yoke | Repair | L- 7 |
| Abnormal noise | Worn or damaged bearing cup | Replace | L- 7 |
| | Improperly installed universal joint snap ring | Repair | L- 7 |
| | Worn or damaged center bearing | Replace | L- 7 |
| | Loose yoke mounting bolts | Tighten | L- 5 |
| | Incorrect propeller shaft alignment angle | Adjust | L- 5 |

03U0LX-805

PROPELLER SHAFT

PREPARATION SST

| | | | |
|--|--|--|--|
| <p>49 0839 425C</p> <p>Puller set, bearing</p>  | <p>For removal of center companion flange and center bearing</p> | <p>49 0636 145</p> <p>Puller, fan pulley boss</p>  | <p>For removal of center bearing support assembly</p> |
| <p>49 F401 331</p> <p>Body</p>  | <p>For installation of center bearing support assembly</p> | <p>49 H025 003</p> <p>Installer, bearing</p>  | <p>For installation of center bearing support assembly</p> |


03U0LX-806

PROPELLER SHAFT

L

REMOVAL / INSPECTION / INSTALLATION


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)

03U0LX-807


- | | | |
|--------------------------------------|---|---|
| 1. Nut Removal Note page L-6 | 8. Bolt | 14. Washer |
| 2. Washer | 9. Lock washer | 15. Spacers Removal Note page L-6 |
| 3. Nut | 10. Nut | 16. Bushing |
| 4. Washer | 11. Propeller shaft Inspection..... page L-9 | 17. Spacer |
| 5. Bolt | Installation Note.. page L-6 | 18. Washer |
| 6. Lock washer | | 19. Spacer |
| 7. Nut | 12. Bushing | |
| | 13. Spacer | |




03U0LX-808




03U0LX-809



03U0LX-810



03U0LX-811



Removal Note

Nuts

1. Before removing the propeller shaft, mark the flanges for proper reassembly.

Spacers

1. Identify the spacers for proper reassembly.

Installation Note

Propeller shaft

1. Align the marks and install the propeller shaft.

2. Verify that there is no abnormal noise or vibration when driving the vehicle.

Note

- The spacer on each side must be the same size.

3. If noise or vibration seems to be the result of incorrect propeller shaft alignment angle, substitute different spacer at the center bearing support assembly to eliminate the problem.


| | Spacer size mm (in) | |
|-------------|---------------------|------------|
| No spacer | 1.6 (0.06) | 3.2 (0.13) |
| 4.5 (0.18) | 6.0 (0.24) | 8.0 (0.31) |
| 10.0 (0.39) | 13.0 (0.51) | |

OVERHAUL

Caution

- Use pads in the vise to prevent damaging the part.


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N-m (m-kg, ft-lb)

03U0LX-812


| | |
|---|---|
| <p>1. Snap ring Disassembly Note..... page L- 8 Assembly Note page L-10</p> <p>2. Bearing cup Disassembly Note..... page L- 8 Inspect for damage, wear and rough rotation Assembly Note page L- 9</p> <p>3. Spider</p> <p>4. Front propeller shaft Inspection page L- 9</p> <p>5. Rear propeller shaft Inspection page L- 9</p> | <p>6. Yoke (Diff side)</p> <p>7. Nut Disassembly Note..... page L- 8 Assembly Note page L- 9</p> <p>8. Lock washer</p> <p>9. Yoke</p> <p>10. Center bearing support assembly Disassembly Note..... page L- 8 Inspect for damage and rough rotation Assembly Note page L- 9</p> <p>11. Center propeller shaft Inspection page L- 9</p> |
|---|---|




03U0LX-813



9TG0LX-013




9TG0LX-014



49 0839 425C

03U0LX-814



49 0636 145

49 0839 425C

03U0LX-815

Disassembly Note**Snap ring**

1. Mark the yoke and propeller shaft for proper reassembly.
2. Clamp the propeller shaft in a vise.
3. Remove the snap ring.

Bearing cup


1. Push one bearing cup out of the propeller shaft by tapping the propeller shaft yoke.
2. Remove the opposite bearing cup in the same manner.
3. Separate the propeller shaft and yoke.
4. Clamp the yoke in a vise.
5. Remove the bearing cups and the spider from the yoke as in Steps 1 and 2.

Locknut

1. Align the marks on the center propeller shaft and yoke.
2. Remove the nut and lock washer.
3. Remove the yoke with the **SST**.

Center bearing support assembly

1. Remove the center bearing support assembly with the **SST**.



03U0LX-816


Inspection Center propeller shaft

Caution

- **Replace the center propeller shaft as an assembly if runout is excessive.**

1. Measure the center propeller shaft runout with a dial indicator.


Runout: 0.4mm (0.0157 in) max.



03U0LX-817

Assembly Note Center bearing support assembly

1. Install the center bearing support assembly with the **SST**.




03U0LX-818

Nut

1. Align the marks on the center propeller shaft and yoke.
2. Install the nut.

Tightening torque:

157—177 N·m (16—18 m·kg, 116—130 ft·lb)




03U0LX-819

Bearing cup

Caution

- **Do not reuse the snap rings, bearing cups, or spider.**


1. Apply lithium based grease to the roller bearings inside the bearing cups.
2. Clamp the yoke in a vise.



03U0LX-820

3. Set the new spider into the yoke and tap in a bearing cup using the spider to hold the rollers.
4. Slide the yoke to the opposite side and install the other bearing cup.

PROPELLER SHAFT



9TG0LX-024

Snap ring

Caution

- Use only new snap rings and ones of the same thickness.

1. Install the thinnest snap rings.

Caution

- Align the marks on the propeller shaft and yoke.

2. Install the yoke to the propeller shaft.
3. Lightly tap the yoke and propeller shaft flanges with a plastic hammer to seat the cups.

4. Measure the starting torque of the spider.

Starting torque:


0.29—0.98 N·m (3—10 cm·kg, 2.60—8.68 in·lb)

5. Install different snap rings to adjust the starting torque if necessary.


Snap ring thicknesses (19 types)

mm (in)

| | |
|---------------|---------------|
| 1.21 (0.0476) | 1.22 (0.0480) |
| 1.23 (0.0484) | 1.24 (0.0488) |
| 1.25 (0.0492) | 1.26 (0.0496) |
| 1.27 (0.0500) | 1.28 (0.0504) |
| 1.29 (0.0508) | 1.30 (0.0512) |
| 1.31 (0.0516) | 1.32 (0.0520) |
| 1.33 (0.0524) | 1.34 (0.0528) |
| 1.35 (0.0531) | 1.36 (0.0535) |
| 1.37 (0.0539) | 1.38 (0.0543) |
| 1.39 (0.0547) | |



03U0LX-821



03U0LX-822

FRONT AND REAR AXLES

INDEX M- 2

FEATURES


OUTLINE M- 3
 OUTLINE OF CONSTRUCTION M- 3
 SPECIFICATIONS..... M- 3
REAR AXLE AND DIFFERENTIAL..... M- 4
 REAR AXLE..... M- 4

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. M- 5
TROUBLESHOOTING GUIDE..... M- 5
 REAR AXLE M- 5
 DIFFERENTIAL (STANDARD)..... M- 5
REAR AXLE M- 6
 PREPARATION..... M- 6
 DISC BRAKE TYPE M- 7
REAR DRIVESHAFT M-12
 DOUBLE-OFFSET JOINT..... M-12
REAR DIFFERENTIAL..... M-16
 PREPARATION..... M-16
 DIFFERENTIAL OIL M-17
 OIL SEAL (OUTPUT SHAFT)..... M-18
 REAR DIFFERENTIAL..... M-20

03U0MX-801

INDEX



03U0MX-802

- 1. Rear axle
 - Removal / Inspection / Installation M- 7
 - Disassembly / Inspection / Assembly... M- 8
- 2. Rear driveshaft
 - Inspection / Removal / Installation M-12
 - Disassembly / Inspection / Assembly... M-13

- 3. Rear differential
 - Differential oil..... M-17
 - Oil seal (Output shaft) M-18
 - Removal / Installation..... M-20
 - Overhaul..... M-22

OUTLINE

OUTLINE OF CONSTRUCTION



1. Constant-velocity joints, which feature low rotational fluctuation and low noise, and show excellent vibration resistance, are used for the driveshafts.
2. Joint shafts are used for all models, and, because of the resultant equal lengths of the left and right driveshafts, torque-steer during sudden acceleration from a stop is reduced.
3. The rear differential is a standard non-limited-slip differential.
4. Angular type ball bearings are employed for the rear wheel bearings for improved durability and serviceability.

03U0MX-803

SPECIFICATIONS

| Item | | Model | BP SOHC | |
|--------------------------|-------------------|-----------------------|---------------------|-------------------|
| | | | MTX | ATX |
| Rear axle | | | | |
| Wheel bearing axial play | Maximum | mm (in) | 0.05 (0.002) | |
| Rear differential | | | | |
| Reduction gear | | Hypoid gear | | |
| Differential gear | | Straight bevel gear | | |
| Reduction ratio | | 3.909 | | |
| Number of teeth | Ring gear | | 43 | |
| | Drive pinion gear | | 11 | |
| Differential oil | Grade | | API Service GL-5 | |
| | Viscosity | Above -18°C (0°F) | | SAE 90 |
| | | Below -18°C (0°F) | | 80W |
| | Amount | liter (US qt, Imp qt) | | 0.65 (0.69, 0.57) |
| Rear driveshaft | | | | |
| Joint type | Inside | | Double-offset joint | |
| | Outside | | Bell joint | |
| Length of joint | Right | mm (in) | 689 (27.12) | |
| | Left | mm (in) | 659 (25.94) | |
| Shaft diameter | | mm (in) | 21 (0.82) | |

03U0MX-804

REAR AXLE AND DIFFERENTIAL**REAR AXLE
Wheel Bearings**

03UOMX-805

Angular type ball bearings, for which the bearing preload is set by tightening the driveshaft nut to the specified torque, are employed for the wheel bearings, thus improving durability and serviceability.

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with Workshop Manual (1195-10-89E).

Troubleshooting guide

- Rear axle
- Rear differential

Rear axle

- Removal / Inspection / Installation
- Disassembly / Assembly

Rear driveshaft

- Inspection / Removal / Installation
- Disassembly / Inspection / Assembly

Rear differential

- Removal / Installation
- Overhaul

Differential oil

- Inspection
- Replacement

03U0MX-806

TROUBLESHOOTING GUIDE

REAR AXLE

| Problem | Possible Cause | Action | Page |
|-----------------------|-------------------------------|---------|------|
| Abnormal noise | Bent bearing housing | Replace | — |
| | Bent driveshaft | Replace | M-12 |
| | Worn or damaged wheel bearing | Replace | M- 8 |
| | Worn driveshaft spline | Replace | M-13 |

03U0MX-807












DIFFERENTIAL (STANDARD)


| Problem | Possible Cause | Action | Page |
|---|--|-------------------|------|
| Abnormal noise | Insufficient differential oil | Add oil | M-17 |
| | Incorrect differential oil | Replace | M-17 |
| | Improperly adjusted ring gear backlash | Adjust | M-29 |
| | Poor contact of ring gear teeth | Adjust | M-29 |
| | Worn or damaged side bearing | Replace | M-22 |
| | Worn or damaged ring gear | Replace | M-22 |
| | Worn or damaged drive pinion bearing | Replace | M-22 |
| | Worn or damaged pinion and side gear | Replace | M-22 |
| | Seized side gear and case | Replace | M-22 |
| | Worn side gear spline | Replace | M-22 |
| | Worn pinion shaft | Replace | M-22 |
| | Loose companion flange nut | Tighten | M-28 |
| | Worn thrust washer | Replace | M-28 |
| | Improperly adjusted side gear preload | Adjust | M-28 |
| Improperly adjusted drive pinion gear preload | Adjust | M-27 | |
| Heat buildup | Insufficient differential oil | Add oil | M-17 |
| | Insufficient gear backlash | Adjust | M-28 |
| | Excessive bearing preload | Adjust | M-28 |
| Oil leakage | Excessive differential oil | Remove oil | M-17 |
| | Loose differential carrier | Tighten or repair | M-31 |
| | Worn or damaged oil seal | Replace | M-18 |
| No differential operation | Misassembled | Repair | M-22 |

03U0MX-808

REAR AXLE

PREPARATION SST

| | | | |
|--|---|--|--|
| <p>49 G030 370 Plate, removing</p>  | <p>For removal of wheel hub and wheel bearing</p> | <p>49 G030 727 Attachment A (Part of 49 B026 1A0)</p>  | <p>For removal of wheel hub</p> |
| <p>49 G033 102 Handle (Part of 49 B026 1A0)</p>  | <p>For removal of wheel hub</p> | <p>49 G030 797 Handle (Part of 49 G030 795)</p>  | <p>For removal of wheel hub</p> |
| <p>49 F027 005 Attachment 62 (Part of 49 F027 0A1)</p>  | <p>For removal of wheel bearing</p> | <p>49 F027 007 Attachment 72 (Part of 49 F027 0A1)</p>  | <p>For installation of wheel bearing</p> |
| <p>49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1)</p>  | <p>For installation of wheel bearing</p> | <p>49 V001 795 Installer, oil seal</p>  | <p>For installation of oil seal</p> |
| <p>49 F027 0A1 Installer set, bearing</p>  | <p>For installation of wheel bearing</p> | <p>49 B026 1A0 Puller, wheel hub</p>  | <p>For removal of wheel hub</p> |
| <p>49 G030 795 Installer, oil seal</p>  | <p>For installation of wheel bearing</p> | <p>03U0MX-809</p> | |



03U0MX-810

DISC BRAKE TYPE

Preinspection


Wheel bearing play

1. Remove the wheel and tire.
2. Remove the brake caliper assembly.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds specification, check and adjust the wheel hub nut torque or replace the wheel bearing if necessary.

Maximum wheel bearing play: 0.05mm (0.002 in)


Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



03U0MX-811

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Wheel hub nut Installation Note page M-8 3. Brake caliper assembly Service Section P 4. Disc plate Service Section P | <ol style="list-style-type: none"> 5. Trailing link 6. Lateral link 7. Shock absorber 8. Wheel hub, knuckle Disassembly / Inspection / Assembly page M-8 |
|--|--|



03U0MX-812

Installation Note

Wheel hub nut


1. Install a new nut, and stake it as shown.

Tightening torque:

177—235 N·m (18—24 m·kg, 130—174 ft·lb)


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



03U0MX-813

- | | | |
|--|---|---|
| <p>1. Oil seal Disassembly Note page M- 9 Assembly Note page M-11</p> | <p>3. Retaining ring 4. Wheel bearing Disassembly Note page M- 9 Assembly Note page M-10</p> | <p>6. Knuckle Inspect for cracks and other damage</p> |
| <p>2. Wheel hub Disassembly Note page M- 9 Inspect for cracks and other damage Assembly Note page M-11</p> | <p>5. Dust cover Disassembly Note page M-10 Inspect for damage and distortion Assembly Note page M-10</p> | <p>7. Wheel stud Disassembly Note page M-10 Assembly Note page M-10</p> |




03U0MX-814

Disassembly Note

Oil seal

1. Remove the oil seal with a screwdriver.




03U0MX-815

Wheel hub

1. Remove the wheel hub from the knuckle with the **SST** and a press.


Caution

- Support the wheel hub by hand to prevent it from falling.




03U0MX-816

2. Move the inner bearing race away from the axle with a hammer and chisel.



03U0MX-817

3. Set the **SST** between the wheel hub and bearing inner race, and remove the bearing inner race.




03U0MX-818

Wheel bearing

Caution

- Do not reuse the removed wheel bearing.

1. Remove the wheel bearing from the knuckle with the **SST** and a press.




03U0MX-819

Dust cover**Caution**

- Do not remove the dust cover if not necessary.
- Do not reuse the removed dust cover.

1. Mark the dust cover and knuckle for proper reassembly.
2. Remove the dust cover with a chisel.




03U0MX-820

Wheel studs**Caution**

- Do not remove the wheel studs unless necessary.
- Do not reuse the removed wheel.


1. Remove the wheel studs with a press.



03U0MX-821

Assembly Note**Wheel stud**

1. Install the new wheel studs with a press.



03U0MX-822


Dust cover

1. Mark the new dust cover the same as the one removed.
2. Align the marks of the new dust cover and the knuckle.

Caution

- Install the new dust cover as shown.


3. Install the new dust cover.



03U0MX-823

Wheel bearing


1. Press the new wheel bearing in with the **SST**.



03U0MX-824

Wheel hub

1. Press the wheel hub in with the **SST**.



03U0MX-014

Oil seal**Caution**

- Use a new oil seal, and apply grease to the lip of the seal.
- Install the oil seal flush with the knuckle.


1. Install the new oil seal with the **SST**.

REAR DRIVESHAFT

DOUBLE-OFFSET JOINT

Inspection / Removal / Installation


1. Inspection the rear driveshaft, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



N·m (m·kg, ft·lb)

03U0MX-826


- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Wheel nuts 2. Wheel and tire 3. Wheel hub nut 4. Nut (Driveshaft) | <ol style="list-style-type: none"> 5. Bolt (Trailing link) 6. Bolt (Lateral link) 7. Rear driveshaft |
|---|---|
- Removal Note..... page M-13 Disassembly / Inspection /
 Assembly page M-13



03U0MX-827

Inspection Driveshaft

1. Check the dust boot on the driveshaft for cracks, damage, leaking grease, and loose boot bands.
2. Check the driveshaft for bending, cracking, and wear of joints or splines.
 Replace the driveshaft if necessary.



03U0MX-828

Removal Note
Nuts (Driveshaft)


1. Before removing the driveshaft, mark the driveshaft and output shaft for proper reassembly.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.


Caution

- **Secure the driveshaft in a vise with protective material (such as copper plates) on the vise jaws.**
- **Be careful that dust or other foreign material does not enter the ball joint while the work is being performed.**
- **Do not disassemble the wheel side ball joint.**
- **Do not wash the ball joint unless it is being disassembled.**



03U0MX-829

- | | | |
|--|---|--|
| <p>1. Boot band 2. Boot band 3. Clip Disassembly Note page M-14</p> <p>4. Outer ring 5. Ball 6. Snap ring Disassembly Note page M-14</p> | <p>7. Cage Disassembly Note page M-14 Assembly Note page M-15</p> <p>8. Inner ring Disassembly Note page M-14</p> <p>9. Boot Disassembly Note page M-14</p> | <p>10. Boot band 11. Boot Disassembly Note page M-14 Assembly Note page M-15</p> <p>12. Axleshaft Inspect for bending, twisting and other damage</p> |
|--|---|--|



03U0MX-830


Disassembly Note

Clip

Caution

- Mark with paint, do not use a punch.

1. Mark the outer ring and the cage for proper reassembly.
2. Remove the clip with a screwdriver.




03U0MX-831

Snap ring

Caution

- Mark with paint, do not use a punch.


1. Mark the axleshaft, the cage and the inner ring for proper reassembly.
2. Remove the snap ring with snap-ring pliers.



03U0MX-832

Cage


1. Turn the cage approximately 30°, then pull it away from the inner ring.



03U0MX-833

Inner ring

1. Remove the inner ring from the driveshaft with a bar and a hammer.




03U0MX-834

Boot


Caution

- Do not remove the boot (wheel side) if not necessary.


1. Wrap the splines of the driveshaft with tape to prevent damaging the boot.
2. Remove the boot.




03U0MX-835




03U0MX-836



03U0MX-837



03U0MX-838



03U0MX-839

Assembly Note Boot

Caution

- The wheel-side and transaxle-side boots are different.

A: 89.9mm (3.54 in)

B: 85.2mm (3.35 in)

1. Wrap the splines of the wheel side of the shaft with tape and install the boot and a new boot band.

Caution

- Do not use other than the specified grease.

2. Apply molybdenum disulfide grease to the joint.

Quantity

Differential side: 75 g (2.64 oz)

Wheel side : 80 g (2.82 oz)

3. Measure the length of the driveshaft.

Standard length

Right side: 689mm (27.12 in)

Left side : 659mm (25.94 in)

















Cage


1. Install the cage at approximately 30° from the mark, then align the marks.

REAR DIFFERENTIAL


PREPARATION

SST

| | | | |
|---|--|---|---|
| <p>49 0107 680A Engine stand</p>  | <p>For installation of differential carrier</p> | <p>49 M005 561 Hanger, diff. carrier</p>  | <p>For support of differential carrier</p> |
| <p>49 S120 710 Holder, coupling flange</p>  | <p>For removal and installation of flange nut</p> | <p>49 0839 425C Puller set, bearing</p>  | <p>For removal of bearing inner race</p> |
| <p>49 0710 520 Puller, bearing</p>  | <p>For removal of bearing inner race</p> | <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of bearing inner race</p> |
| <p>49 8531 565 Pinion model</p>  | <p>For measurement of pinion height</p> | <p>49 0727 570 Gage body, pinion height (Part of 49 F027 0A0)</p>  | <p>For measurement of pinion height</p> |
| <p>49 N027 001 Gauge block</p>  | <p>For measurement of pinion height</p> | <p>49 M005 795 Installer set, oil seal</p>  | <p>For installation of oil seal</p> |
| <p>49 0259 720 Wrench, diff. side bearing adjusting nut</p>  | <p>For adjustment of drive pinion and ring gear backlash</p> | <p>49 0727 415 Installer, bearing</p>  | <p>For installation of oil seal</p> |
| <p>49 G038 338 Attachment E</p>  | <p>For installation of bearing inner race</p> | <p>49 8531 567 Collar A</p>  | <p>For measurement of pinion height</p> |
| <p>49 F401 331 Body (Part of 49 D017 2A1)</p>  | <p>For installation of bearing inner race</p> | <p>49 F401 336B Attachment B (Part of 49 D017 2A1)</p>  | <p>For installation of bearing inner race</p> |

| | |
|--|---|
| <p>49 M005 796</p> <p>Body (Part of 49 M005 795)</p> |  <p>For installation of oil seal</p> |
|--|---|

03U0MX-840



9MU0MX-033


DIFFERENTIAL OIL

Inspection

1. Remove the filler plug.
2. Verify that the oil is at the bottom of the filler plug hole. If it is low, add the specified oil.
3. Install the filler plug.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)




97U0MX-048

Replacement

1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install the drain plug and washer.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)



03U0MX-841

5. Add the specified oil from the filler plug until the level reaches the bottom of the plug hole.

Specified oil

Type:

Above -18°C (0°F): GL-5, SAE 90


Below -18°C (0°F): GL-5, SAE 80W

Capacity: 0.65 liter (0.6 US qt, 0.5 Imp qt)


6. Install the filler plug.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)




03U0MX-842




LATERAL LINK

TRAILING LINK


03U0MX-843



03U0MX-844



03U0MX-845



03U0MX-846

OIL SEAL (OUTPUT SHAFT)**Replacement**

1. Jack up the vehicle and support it with safety stands.
2. Drain the differential gear oil.

Note

- **Mark the driveshaft and output shaft flanges for proper reassembly.**

3. Separate the driveshaft from the differential, and suspend it as shown in the figure.

4. Remove the lateral link.


5. Remove the trailing link.

6. Pull the wheel hub out to separate the driveshaft from the output shaft.

7. Remove the output shaft with two pry bars as shown in the figure.


8. Remove the oil seal with a screwdriver.

9. Apply lithium-base grease to the new oil seal lip and install it with the **SST**.



03U0MX-847

10. Install a new clip at the end of the output shaft.
11. Install the output shaft into the side gear by lightly tapping with a plastic hammer.
12. Verify that the output shaft is hooked into the side gear by pulling it by hand.




03U0MX-848

13. Install the lateral link.

Tightening torque:
63—75 N·m (6.4—7.6 m·kg, 46—55 ft·lb)

14. Install the trailing link.


Tightening torque:
49—59 N·m (5.0—6.0 m·kg, 36—43 ft·lb)



03U0MX-849

15. Align the marks and reinstall the driveshaft.

Tightening torque:
49—59 N·m (5.0—6.0 m·kg, 36—43 ft·lb)



03U0MX-850

16. Add the specified oil through the filler plug hole until it reaches the bottom of the hole.

Specified oil

Type:

Above -18°C (0°F): GL-5, SAE 90

Below -18°C (0°F): GL-5, SAE 80W

Capacity:

0.65 liter (0.6 US qt, 0.5 Imp qt)

17. Install the filler plug and a new gasket.


Tightening torque:
39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)

REAR DIFFERENTIAL Removal / Installation


Note

- Drain the differential oil before removal.


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.




- | | | |
|---|--|---|
| 1. Propeller shaft Service Section L | 4. Trailing link Disassembly Note page M-21 Assembly Note page M-21 | 6. Rear differential Disassembly Note page M-21 Assembly Note page M-21 Overhaul..... page M-22 |
| 2. Wheel and tire | | |
| 3. Lateral link | | |
| | 5. Driveshaft | |




03U0MX-852




03U0MX-853



03U0MX-854



03U0MX-855



03U0MX-856

Removal Note Driveshaft

1. Before removing the driveshaft, mark the driveshaft and output shaft for proper reassembly.
2. Pull the wheel hub out to separate the driveshaft from the output shaft.

Rear differential

1. Support the differential with a jack while removing it.

Installation Note Rear differential

1. Support the differential with a jack while installing it.

Tightening torque:

Front: 45—68 N·m (4.6—6.9 m·kg, 33—50 ft·lb)
Rear: 93—116 N·m (9.5—11.9 m·kg, 68—86 ft·lb)

Driveshaft

1. Align the marks and reinstall the driveshaft.

Tightening torque:


53—63 N·m (5.5—6.5 m·kg, 39—47 ft·lb)

Overhaul

Caution

- Install the differential carrier within 10 min. after applying sealant. Allow the sealant to set at least 30 min. after installation before filling the differential with the specified oil.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N-m (m-kg, ft-lb)

03UOMX-857

| | |
|--|--|
| 1. Differential gear assembly Disassembly Note..... page M-24 | 14. Bearing inner race (Front bearing) Inspect for rough rotation |
| 2. Output shaft Disassembly Note..... page M-24 Assembly Note page M-31 | 15. Collapsible spacer |
| 3. Differential case Assembly Note page M-31 | 16. Bearing inner race (Rear bearing) Disassembly Note..... page M-25 Inspect for rough rotation |
| 4. Lock plate | 17. Bearing outer race (Rear bearing) Disassembly Note..... page M-25 |
| 5. Bearing cap Disassembly Note..... page M-24 | 18. Bearing outer race (Front bearing) Disassembly Note..... page M-25 |
| 6. Adjusting screw Disassembly Note..... page M-24 | 19. Differential carrier |
| 7. Bearing outer race (Side bearing) | 20. Ring gear Inspect for cracks and other damage |
| 8. Nut (Companion flange) Disassembly Note..... page M-24 Assembly Note page M-28 | 21. Roll pin Disassembly Note..... page M-25 |
| 9. Washer | 22. Pinion shaft |
| 10. Companion flange Disassembly Note..... page M-24 Inspect splines for cracks and other damage Assembly Note page M-28 | 23. Pinion gear Inspect for cracks and other damage |
| 11. Oil seal (Companion flange) Assembly Note page M-28 | 24. Thrust washer |
| 12. Drive pinion Assembly Note page M-25 Inspect splines for cracks and other damage | 25. Side gear Inspect for cracks and other damage |
| 13. Spacer | 26. Bearing inner race (Side bearing) |
| | 27. Gear case |
| | 28. Final gear set |
| | 29. Oil seal (Output shaft) Assembly Note page M-31 |

03U0MX-858



03U0MX-859


Disassembly Note

Differential gear assembly

1. Mount the differential carrier on the **SST**.

Output shaft

1. Remove the output shaft with a pry bar as shown in the figure.




03U0MX-860

Bearing cap

1. Mark one bearing cap and the carrier.

Adjusting screw


1. Mark one adjusting screw and the carrier.



03U0MX-861

Nut (Companion flange)


1. Hold the companion flange with the **SST** and remove the nut.




03U0MX-862

Companion flange

1. Remove the companion flange with the **SST**.




03U0MX-863



03U0MX-864

Drive pinion

1. Push out the drive pinion by attaching a miscellaneous nut to the drive pinion and tapping it with a copper hammer.




03U0MX-865

Bearing outer race (Front), (Rear)

Note

- Identify the bearing outer races for proper reassembly.

1. Remove the bearing outer races by alternately tapping the races at the two grooves in the carrier.




03U0MX-866

Bearing inner race (Rear bearing)

Note

- Support the drive pinion by hand so that it does not fall.

1. Remove the rear bearing with the **SST**.




9MU0MX-076

Knock pin

Note

- Tap out toward the ring gear side.

1. Secure the gear case in a vise and remove the knock pin.




03U0MX-867

Bearing inner races (Side bearing)

Note

- Do not remove the bearing inner races if not necessary.
- Replace the bearing inner races with new bearings if removed.


1. Remove the side bearings from the gear case with the **SST**.



03U0MX-868

Assembly Note Bearing outer race

1. Install the front and rear bearing outer races with a brass drift and a hammer.



03U0MX-869


Adjustment of pinion height

1. Adjust the drive pinion height as follows with the **SST**.

Note


- Use the spacer that was removed.
- Do not install the collapsible spacer.

- a) Install the bearing inner race (rear), spacer, O-ring and **SST**.
- b) Install the bearing inner race (front), companion flange, washer, and nut.
- c) Tighten the nut just enough so that the **SST** can be turned by hand.




03U0MX-870


- d) Place the **SST** on a surface plate and set the dial indicator to "Zero".



97U0MX-082




03U0MX-871




97U0MX-084

| Mark | Thickness | Mark | Thickness |
|------|-----------------------|------|-----------------------|
| 08 | 3.08mm (0.1213 in) | 29 | 3.29mm (0.1295 in) |
| 11 | 3.11mm (0.1224 in) | 32 | 3.32mm (0.1307 in) |
| 14 | 3.14mm (0.1236 in) | 35 | 3.35mm (0.1319 in) |
| 17 | 3.17mm (0.1248 in) | 38 | 3.38mm (0.1331 in) |
| 20 | 3.20mm (0.1260 in) | 41 | 3.41mm (0.1343 in) |
| 23 | 3.23mm (0.1271 in) | 44 | 3.44mm (0.1354 in) |
| 26 | 3.26mm (0.1283 in) | 47 | 3.47mm (0.1366 in) |

97U0MX-085



03U0MX-872



03U0MX-873

- e) Place the **SST** atop the drive pinion model. Set the gauge body atop the gauge block.
- f) Place the feeler of the dial indicator so that it contacts where the bearing inner race (side bearing) is installed in the carrier. Measure the lowest position on the left and right sides of the carrier.

- g) Add the two (left and right) values obtained in Step f, and divide the total by 2.

Specification: 0mm (0 in)

- h) If it is not within specification, adjust the pinion height by selection of a spacer.

Note

- **Spacers are available in increments of 0.03mm. Select the spacer thickness that is closest to that necessary.**

Adjustment of drive pinion preload

1. Install the spacer.

Note

- **Press the bearing on until the force required suddenly increases.**
- **Install the spacer selected from the pinion height adjustment above, being careful that the installation direction is correct.**


2. Press the bearing inner race (rear bearing) on with the **SST**.

Caution


- **Do not install the oil seal.**

3. Install the collapsible spacer.
4. Install the drive pinion assembly.
5. Install the companion flange, and tighten the flange nut.


Tightening torque: 117 N·m (12 m·kg, 86 ft·lb)




03U0MX-874




03U0MX-875



03U0MX-876



03U0MX-877



03U0MX-878

6. Turn the companion flange by hand to seat the bearing.

7. Measure the drive pinion preload.

Adjust the preload by tightening the flange nut.

Preload:

0.29—0.68 N·m (3—7 cm·kg, 2.6—6.0 in·lb)

Tightening torque:

117—176 N·m (12—18 m·kg, 86—130 ft·lb)

If the specified preload cannot be obtained, replace the collapsible spacer with a new one and check again.

8. Remove the nut, washer, and companion flange.

Oil seal (Companion flange)

Caution

- Apply differential oil to the oil seal lip.

1. Tap a new oil seal into the differential carrier with the **SST**.

Companion flange

1. Apply a light coat of grease to the end face of the companion flange.

Nut (Companion flange)

1. Adjust the preload by tightening the flange nut.

Preload:

0.29—0.68 N·m (3—7 cm·kg, 2.6—6.0 in·lb)


Tightening torque:

117—176 N·m (12—18 cm·kg, 86—130 in·lb)


Adjustment of side gear and pinion gear backlash

1. Measure the backlash of the side gears and pinion gears. Adjust by inserting the proper thickness thrust washer at both sides.


Backlash: 0—0.1mm (0—0.004 in)




97U0MX-094




97U0MX-095



03U0MX-879



03U0MX-880



03U0MX-881

Thrust washer thickness:

| Identification mark | Thickness |
|---------------------|--------------------|
| 0 | 2.00mm (0.0787 in) |
| 05 | 2.05mm (0.0807 in) |
| 1 | 2.10mm (0.0827 in) |
| 15 | 2.15mm (0.0846 in) |
| 2 | 2.20mm (0.0866 in) |

2. Install the knock pin to secure the pinion shaft. Stake the pin with a punch to prevent it from coming out of the case.

Adjustment of drive pinion and ring gear backlash

Note

- Apply approx. 0.04 cc (0.0024 cu in) of compound at each point.

1. Apply thread-locking compound to points (A) and (B) around the gear back face.
2. Mount the ring gear onto the gear case.

Tightening torque:


69—83 N·m (7.0—8.5 m·kg, 51—61 ft·lb)

3. Press the new bearing inner race (side gear) on with the **SST**.

4. Install the differential gear assembly in the carrier.
5. Note the identification mark on the adjusting screw, and install the screws to their respective sides.
6. Install the differential bearing caps, making sure that the identification mark on the cap corresponds with the one on the carrier with the **SST**.


7. Mark the ring gear at four points at approx. **90°** intervals. Mount a dial indicator to the carrier so that the feeler comes into contact at a right angle with one of the ring gear teeth.
8. Turn both bearing adjusting screw, equally with the **SST** until the backlash is as specified.

Backlash: 0.09—0.11mm (0.0035—0.0043 in)



97U0MX-104

9. Check the backlash at the three other marked points, and make sure the minimum backlash is above **0.05mm (0.0020 in)** and the difference between the maximum and minimum is less than **0.07mm (0.0028 in)**.



03U0MX-882


10. Tighten the adjusting screws equally until the distance between the pilot sections on the bearing caps is as specified.

Specified distance:

150.13—150.20mm (5.910—5.913 in)

Note


- **When adjusting the differential bearing preload, be careful not to affect the backlash of the drive pinion and ring gear.**



03U0MX-883


Inspection and adjustment of teeth contact

1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, readjust the pinion height, and then readjust the backlash.




63G09X-385

- (1) Toe and flank contact
Replace the spacer with a thinner one to move the drive pinion outward.



9MU0MX-068

- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.




03U0MX-884

Differential case

1. Apply sealant to the case face.
2. Tighten the bolts.

Tightening torque:

23—26 N·m (2.3—2.7 m·kg, 10—20 ft·lb)




03U0MX-885

Oil seal (Output shaft)

Caution

- Apply lithium-base grease to the new oil seal lip.


1. Install the new oil seal with the **SST**.



03U0MX-886

Output shaft

1. Install new clips.
2. Install the output shaft into the side gears by lightly tapping with a plastic hammer.
3. Verify that the output shafts are hooked into the side gears by pulling them by hand.



STEERING SYSTEM

INDEX..... N- 2

FEATURES


OUTLINE..... N- 3
SPECIFICATION..... N- 3

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. N- 3
ENGINE SPEED SENSING
POWER STEERING..... N- 4
PREPARATION N- 4
POWER STEERING FLUID..... N- 6
STEERING GEAR AND LINKAGE N- 7
POWER STEERING OIL PUMP..... N-17

03U0NX-801

INDEX



03U0NX-802

1. Steering gear and linkage
Removal / Installation..... page N- 7
Disassembly / Inspection / Assembly
..... page N-10

2. Power steering fluid
Inspection..... page N- 6
3. Power steering oil pump
Disassembly / Inspection / Assembly
..... page N-17

OUTLINE

- A rack-and-pinion type steering is used on all models.
- The structure of steering system is basically same as 2WD models.

SPECIFICATION

| Item | Type | Engine speed sensing power steering |
|--------------------------|--------------------------------|-------------------------------------|
| Steering wheel | Outer diameter mm (in) | 370 (14.57) |
| | Lock-to-lock turns | 2.76 |
| Steering shaft and joint | Shaft type | Collapsible |
| | Joint type | 2-cross joint |
| | Tilt stroke mm (in) | 30 (1.18) |
| Steering gear | Type | Rack-and-pinion |
| | Gear ratio | ∞ (Infinite) |
| | Rack stroke mm (in) | 121 (4.76) |
| Oil | Type | ATF M-III or DEXRON-II |
| | Capacity liter (US qt, Imp qt) | 0.9—1.0 (0.95—1.06, 0.79—0.88) |

03U0NX-803

SUPPLEMENTAL SERVICE INFORMATION

The following points shown in this section are changed in comparison with Workshop Manual (1195-10-89E).

Steering gear and linkage

- Removal / Installation procedure
- Disassembly / Inspection / Assembly procedure

Power steering fluid

- Inspection procedure

















Power steering oil pump













- Disassembly / Inspection / Assembly procedure

03U0NX-804


ENGINE SPEED SENSING POWER STEERING

**PREPARATION
SST**


| | | | | | |
|--|---|---|--|---|--|
| 49 B032 306 Wrench, plug |  | For removal and installation of plug | 49 B032 312 Protector, slipper seal |  | For installation of seal ring |
| 49 B032 327 Wrench, outer box |  | For removal and installation of outer box | 49 B032 326 Protector, outer box |  | For installation of outer box |
| 49 B032 323 Remover body, rod seal |  | For removal of oil seal | 49 B032 314 Slipper seal former |  | For form of seal ring |
| 49 F032 303 Handle |  | For removal of oil seal | 49 B032 315 Installer, oil seal |  | For installation of oil seal |
| 49 B032 309 Installer body, pinion seal |  | For installation of oil seal | 49 B032 316 Support block, plug |  | For removal of oil seal & bearing |
| 49 B032 310 Protector, pinion seal |  | For installation of oil seal | 49 B032 317 Remover, bearing & oil seal |  | For removal of oil seal & bearing |
| 49 B032 311 Protector, slipper seal |  | For installation of pinion shaft | 49 B032 325 Guide, rod seal |  | For installation of inner guide & oil seal |
| 49 G030 797 Handle |  | For installation of pinion seal | 49 B032 324 Protector body, rod seal |  | For installation of inner guide & oil seal |

| | | | |
|--|---|--|--|
| <p>49 B032 320 Wrench</p>  | <p>For removal and installation of adjustment cover locknut</p> | <p>49 0180 510B Attachment, preload</p>  | <p>For measurement of pinion torque</p> |
| <p>49 B032 321 Adapter</p>  | <p>For hermetic inspection</p> | <p>49 B032 305 Holder, power steering pump</p>  | <p>For installation of oil pump</p> |
| <p>49 G032 317 Hose (Part of 49 B032 3A1)</p>  | <p>For hermetic inspection</p> | <p>49 1232 670A Gauge set, power steering</p>  | <p>For measurement of fluid pressure</p> |
| <p>49 1232 673 Valve body (Part of 49 1232 670A)</p>  | <p>For measurement of fluid pressure</p> | <p>49 H032 301 Wrench</p>  | <p>For removal of tie-rod</p> |
| <p>49 1232 672 Gauge (Part of 49 1232 670A)</p>  | <p>For measurement of fluid pressure</p> | <p>49 B032 304 Adapter</p>  | <p>For measurement of fluid pressure</p> |
| <p>49 H002 671 Adapter</p>  | <p>For measurement of fluid pressure</p> | <p>49 G017 5A0 Support, engine</p>  | <p>For removal and installation of steering gear</p> |


03U0NX-805




03U0NX-806



03U0NX-807



03U0NX-808



03U0NX-809

POWER STEERING FLUID

Inspection

Fluid pressure

1. Assemble the **SST** as shown in the figure.

Tightening torque:

39—49 N·m (4.0—5.0 m·kg, 29—36 ft·lb)

Note

- Before disconnecting the hose, make marks at the connections for proper reinstallation.

2. Disconnect the high-pressure hose from the oil pump. Attach the **SST**.
3. Bleed air from the system.
4. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to **50—60°C (122—140°F)**.

5. Close the gauge valve completely. Increase the engine speed to **1,000—1,500 rpm** and measure the fluid pressure generated by the oil pump. If the pressure is below specification, replace the oil pump assembly.

Oil pump fluid pressure:

7,848 kPa (80 kg/cm², 1,137 psi)

Caution

- If the valve is left closed for more than 15 seconds, the fluid temperature will increase excessively and adversely affect the oil pump.

6. Open the gauge valve fully again and increase the engine speed to **1,000—1,500 rpm**.
7. Turn the steering wheel fully to the left and right and measure the fluid pressure generated by the gear housing. If the pressure is below specification, replace the gear housing assembly.

Gear housing fluid pressure:

7,848 kPa (80 kg/cm², 1,137 psi)

Caution

- If the steering wheel is kept in the fully turned position for more than 15 seconds, the fluid temperature will rise excessively.

8. Remove the gauge set. Install and tighten the high-pressure hose to the specified torque.

Tightening torque:

16—24 N·m (1.6—2.4 m·kg, 12—17 ft·lb)


9. Bleed air from the system.

03U0NX-810

STEERING GEAR AND LINKAGE


Removal / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove the battery and the battery tray.
5. Remove the undercover.
6. Remove in the order shown in the figure, referring to **Removal Note**.
7. Install in the reverse order of removal, referring to **Installation Note**.
8. After installation, bleed air from the steering system.



1. Crossmember
2. Cotter pin
3. Nut
4. Tie-rod end/Steering knuckle
5. Pressure pipe
6. Return pipe
7. Fixing bolt (intermediate shaft/pinion shaft)


8. Nut (Steering gear mounting nut)
9. Bolt (Steering gear mounting bolt)
Removal note page N- 8
Installation note page N- 9
10. Steering gear and linkage
Disassembly / Inspection / Assembly
..... page N-10



03U0NX-812


Removal note**Bolt (Steering gear mounting bolt)**

1. Set the SST as shown.




03U0NX-813

2. Remove the No.1 and No.2 engine mount nuts.
3. Remove the engine mount member.




03U0NX-814

4. Remove the No.4 engine mount mounting bolts.




03U0NX-815


5. Remove the front exhaust pipe and the catalytic converter together.




03U0NX-816



03U0NX-817



03U0NX-818



03U0NX-819

6. Separate the front of propeller shaft.

7. Lower the engine gradually until the lower left mounting bolt can be removed.

Caution

- Do not lower the engine too much because it will damage the front left driveshaft boot.

8. Remove the lower left mounting bolt.

9. Remove the pressure pipe and the return pipe.

10. Remove the left bracket.

11. Pull the steering gear from the left side to remove it.

Installation note

Bolt (Steering gear mounting bolt)

Tightening torque:

Pressure pipe (O-ring replace):

29—39 (3—4, 22—29)

Return pipe (O-ring replace):

29—39 (3—4, 22—29)

Propeller shaft (Refer to Section L):

27—30 (2.8—3.1, 20—22)

Exhaust pipe (Gasket replace)

A: 31—46 (3.2—4.7, 23—34)

B: 21—27 (2.1—2.8, 15—20)

C: 40—55 (4.1—5.6, 30—41)

No.4 engine mount: 67—93 (6.8—9.5, 49—69)

Engine mount member: 64—89 (6.5—9.1, 47—66)


No.1 and No.2 engine mount nut:

37—52 (3.8—5.3, 27—38)

Nm (m-kg, ft-lb)

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N-m (m-kg, ft-lb)

03U0NX-820

| | | | |
|---------------------------------|-----------|--------------------------------|-----------|
| 1. Oil pipe | | 19. Bearing | |
| Disassembly note..... | page N-12 | Disassembly note..... | page N-13 |
| 2. Tie-rod end | | Inspect for wear and operation | |
| 3. Locknut | | 20. Pinion shaft assembly | |
| 4. Boot band | | Inspect for damage and wear | |
| 5. Boot wire | | 21. Seal ring | |
| 6. Boot | | Assembly note | page N-15 |
| 7. Tie-rod | | 22. Outer box assembly | |
| Disassembly note..... | page N-12 | Disassembly note..... | page N-13 |
| Inspect for damage | | Assembly note | page N-14 |
| Inspect operation of ball joint | | 23. O-ring | |
| 8. Washer | | 24. U-gasket | |
| 9. Locknut | | 25. Steering rack | |
| Disassembly note..... | page N-12 | Inspection..... | page N-14 |
| 10. Adjusting cover | | Assembly note | page N-14 |
| Assembly note | page N-16 | 26. Seal ring | |
| 11. Spring | | 27. O-ring | |
| 12. Support yoke | | 28. Oil seal | |
| 13. Housing cover | | Disassembly note..... | page N-13 |
| Disassembly note..... | page N-12 | 29. Inner guide | |
| 14. Locknut | | Disassembly note..... | page N-13 |
| 15. Bearing | | 30. Bearing | |
| Inspect for wear and operation | | Inspect for wear and operation | |
| 16. Plug | | 31. Oil seal | |
| Disassembly note..... | page N-12 | Assembly note | page N-15 |
| Inspection..... | page N-14 | 32. Mounting bracket | |
| Assembly note | page N-15 | 33. Mounting rubber | |
| 17. O-ring | | 34. Gear box | |
| 18. Oil seal | | Inspect for damage and crack | |
| Disassembly note..... | page N-13 | | |

03U0NX-821




93G0NX-026

Disassembly note

Oil pipe

Caution

- After disconnecting the pipes, use a plug or adhesive type tape to seal each port to prevent the entry of foreign materials.




93G0NX-027

Tie-rod

1. Use the **SST** to remove the tie-rod.

Caution


- To avoid scratching the rack, secure the rack in a vise protected with brass pads or cloth.



93G0NX-028

Locknut

1. Use the **SST** to remove the locknut.




93G0NX-029

Housing cover

1. Use a drill ($\phi 1.5\text{mm}$ (0.06 in)) to make a recessed area (approx. 1.5mm (0.06 in)) at the punch-crimped part of the threaded part.

Caution


- If the drill diameter and/or the depth of the recess are excessive, the threads will be too loose when the plug is reused.



93G0NX-030

Plug

1. Use the **SST** to remove the plug.




93G0NX-031

Oil seal and bearing

1. Use the **SST** to remove the bearing and the oil seal from the plug.

Caution


- The oil seal can not be reused.



93G0NX-032

Outer box assembly

1. Use the **SST** to remove the outer box.




93G0NX-033

Oil seal and inner guide


1. Use the **SST** to remove the oil seal and inner guide toward the cylinder side.

Caution


- The oil seal can not be reused.




03U0NX-822




93G0NX-036



93G0NX-038



03U0NX-823



93G0NX-040

Inspection

Steering rack

1. Check the rack for cracking or other damage or for abnormal wear of the teeth; replace it if necessary.
2. Check the seal ring installation part of the rack for abnormal wear or damage; replace it if necessary.
3. Use V blocks to support both ends of the large-diameter part of the rack; check for excessive bending; replace it if necessary.

Bending limit: 0.15mm (0.006 in) (near rack center)

Plug

1. Check for scratches or other damage at the oil seal installation inner diameter; replace it if necessary.

Assembly note

Note

- With the oil seal, inner guide, steering rack and outer box installed to the gear box, check to confirm the air-tightness of the cylinder part of the gear box.

Steering rack


1. Install a new oil seal and new seal ring to the rack's piston.
2. After installing the seal ring, seat it properly at the piston circumference.
3. Install the oil seal and inner guide to the **SST**.
4. Using the **SST**, place the oil seal and inner, guide at the edge of the steering rack's pinion.
5. After mounting the steering rack to the gear box, use a press to install the oil seal and inner guide to the correct position.

Caution

- When pressing in, do not apply a load pressure of more than 29,430 kPa (300 kg/cm², 4,266 psi), because to do so will damage the oil seal and inner guide.
- Apply grease to the seal ring, oil seal and inner guide.

Outer box assembly

1. After installing the **SST** to the rack, install the outer box, and use the **SST** to tighten.




03U0NX-824

Oil seal

1. Use the **SST** to install a new oil seal to the gear housing.

Note


- Apply grease to the oil seal.



93G0NX-042


Seal ring

1. Use the **SST** to install a new seal ring to the valve part of the pinion shaft.
2. After installing it, use the **SST** to seat it properly.



93G0NX-043

3. Use the **SST** to install the pinion shaft assembly to the gear housing.




03U0NX-825

Plug

1. Use the **SST** to press in a new oil seal.
2. Press in by placing the flat plate against the bearing.


Caution

- Apply grease to the oil seal and bearing.




93G0NX-045


3. Use the **SST** to tighten the plug to the gear housing.




03U0NX-826



03U0NX-827



93G0NX-048



93G0NX-049

Adjusting cover

1. Apply sealant to the adjusting cover and temporarily tighten it to a torque of **11 N·m (110 cm·kg, 95 in·lb)**.
2. Move the rack back and forth **approx. 3 times** and loosen the adjusting cover.
3. Retighten the adjusting cover to the specified torque and then loosen it **0—40°**.

Tightening torque:

4.4—5.4 N·m (45—55 cm·kg, 39—48 in·lb)

4. Tighten the locknut with the **SST**.
5. Measure the pinion starting torque with the **SST** and a pull scale.

Starting torque:

At ± 90° from the straight-ahead position:
1.0—1.3 N·m (10—14 cm·kg, 8.7—12 in·lb)
(Pull scale reading: 1.0—1.4 kg)

At other position:

1.6 N·m (17 cm·kg, 14.7 in·lb) max.
(Pull scale reading: 1.7 kg max.)

6. If not as specified, repeat Steps 3 to 5.

Tie-rod**Note**

- **Install the tie-rod (with air bled out) at the rack housing side.**


Cylinder air-tightness check

1. Install the **SST** to the cylinder part of the gear housing.
2. Using a vacuum pump, apply a vacuum of 400 mmHg and check to be sure that the vacuum is maintained for 30 seconds.
3. If there is any leakage, replace the oil seal.

POWER STEERING OIL PUMP

Disassembly / Inspection / Assembly


1. The following procedures show replacement of the O-rings. If a problem is found in other parts, replace the oil pump assembly.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



N-m (m-kg, ft-lb)

03U0NX-828

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Suction pipe 2. O-ring 3. Pressure-switch assembly 4. O-ring 5. Connector 6. O-ring 7. Control valve Inspect for damage and wear 8. Spring Inspect for damage 9. Bracket 10. Pump body (rear) Inspect for damage and wear 11. O-ring | <ol style="list-style-type: none"> 12. Cam ring Inspect for damage and wear Assembly note page N-17 13. Vane Inspect for damage and wear Assembly note page N-17 14. Rotor Inspect for damage and wear Assembly note page N-17 15. Side plate Inspect for damage and wear 16. O-ring 17. O-ring 18. Pin 19. Pump body (front) Inspect for damage and wear |
|---|---|




93G0NX-052

Disassembly note

Oil pump

Note

- As shown in the figure, when securing the oil pump in a vise, be sure to use the SST so that force is not applied to the pulley or shaft.




93G0NX-056

Assembly note

Rotor


1. Install the rotor to the shaft with the rotor's identification mark facing upward.



93G0NX-057

Cam ring

1. Install the cam ring so that its identification mark is facing downward.



03U0NX-829

Vane

1. Install the vanes (10 pieces) to the rotor, with the R part of the vanes facing outward.

BRAKING SYSTEM

INDEX P- 2

FEATURES


OUTLINE P- 3
OUTLINE OF CONSTRUCTION..... P- 3
SPECIFICATIONS P- 3

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. P- 4
CONVENTIONAL BRAKE SYSTEM P- 4
DUAL PROPORTIONING VALVE..... P- 4

03U0PX-801

INDEX



03U0PX-802

- 1. Dual proportioning valve
Inspection page P-4

OUTLINE

OUTLINE OF CONSTRUCTION

The braking system is mostly unchanged however, the dual proportioning valve is changed on 4-wheel drive models. Other parts are basically the same as the previous models.

03U0PX-803

SPECIFICATIONS

| Item | | 5MTX | 4ATX |
|------------------------------|--|---|--------------------|
| Brake pedal | Type | Suspended | |
| | Pedal lever ratio | 4.2 | |
| | Maximum stroke | 131 (5.16) mm (in) | |
| Master cylinder | Type | Tandem (with level sensor) | |
| | Cylinder bore | 22.22 (0.875) mm (in) | |
| Power brake unit | Type | Single diaphragm | |
| | Diameter | 214 (8.43) mm (in) | 239 (9.41) mm (in) |
| Front disc brake | Type | Ventilated disc | |
| | Cylinder bore | 53.97 (2.12) mm (in) | |
| | Pad dimensions (Area x Thickness) | 4,300 (6.66) x 10 (0.39) mm ² x mm (in ² x in) | |
| | Disc plate dimensions (Outer diameter x Thickness) | 257 x 22 (10.12 x 0.87) mm (in) | |
| Rear disc brake | Type | Solid disc | |
| | Cylinder bore | 30.2 (1.19) mm (in) | |
| | Pad dimensions (Area x Thickness) | 2,600 (4.03) x 7.5 (0.30) mm ² x mm (in ² x in) | |
| | Disc plate dimensions (Outer diameter x Thickness) | 251 x 9 (9.88 x 0.35) mm x in | |
| Braking force control device | | Dual proportioning valve | |
| Parking brake | | Center lever (Mechanical, two rear brakes) | |
| Brake fluid | | FMVSS 116: DOT-3 SAE: J1703 | |

03U0PX-804


SUPPLEMENTAL SERVICE INFORMATION

The point shown in this section is comparison with workshop manual (1195-10-89E)

Dual proportioning valve

- Inspection

03U0PX-805



03U0PX-806

CONVENTIONAL BRAKE SYSTEM

DUAL PROPORTIONING VALVE

Inspection


1. Connect two pressure gauges (9,810 kPa [100 kg/cm², 1,422 psi]) to the brake pipes with adapters as shown in the figure.

Adapter and flare nut tightening torque:
 13—22 N·m (1.3—2.2 m·kg, 9.4—16 ft·lb)

Note

- **Disconnect and connect the brake pipes with SST.**

2. Bleed the air from the brake system.
3. Depress the brake pedal until the master cylinder pressure equals A; then record rear brake pressure A'.
4. Depress the brake pedal again, apply additional pressure until the pressure equals B; then record pressure B'.



03U0PX-807

Fluid pressure

kPa (kg/cm², psi)

| A | A' | B | B' |
|-----------------|----------------------------------|-----------------|--------------------------|
| 2,943 (30, 427) | 2,943 (30, 427) ± 196 (2, 28) | 5,886 (60, 853) | 3,826 (39, 555) ± 294 |


SUSPENSION

| | |
|---------------------------------------|-------------|
| INDEX | R- 2 |
| OUTLINE | R- 4 |
| SPECIFICATIONS..... | R- 4 |
| TROUBLESHOOTING GUIDE | R- 5 |
| WHEEL ALIGNMENT | R- 6 |
| PRE-INSPECTION..... | R- 6 |
| FRONT WHEEL ALIGNMENT..... | R- 6 |
| REAR WHEEL ALIGNMENT..... | R- 8 |
| FRONT SUSPENSION (STRUT) | R- 9 |
| PREPARATION | R- 9 |
| FRONT SHOCK ABSORBER AND SPRING.. | R-10 |
| FRONT LOWER ARM..... | R-15 |
| FRONT STABILIZER | R-17 |
| REAR SUSPENSION (STRUT) | R-19 |
| PREPARATION | R-19 |
| REAR SHOCK ABSORBER AND SPRING.... | R-20 |
| LATERAL LINK AND TRAILING LINK | R-25 |

03U0RX-001

INDEX

FRONT SUSPENSION



FRONT WHEEL ALIGNMENT

MAXIMUM STEERING ANGLE: $40^{\circ}00' \pm 2^{\circ}$ (Inner) $33^{\circ}00' \pm 2^{\circ}$ (Outer)

TOTAL TOE-IN: $2 \pm 3\text{mm}$ ($0.08 \pm 0.12\text{ in}$)
 $0.2^{\circ} \pm 0.3^{\circ}$

CAMBER: $-0^{\circ}05' \pm 45'$

CASTER: $1^{\circ}55' \pm 55'$

03UORX-002

1. Front shock absorber and spring

Removal / Installation..... page R-10

Disassembly / Inspection..... page R-11

Inspection..... page R-12

Assembly..... page R-13

2. Front lower arm


Removal / Inspection / Installation page R-15

Inspection..... page R-16

3. Front stabilizer

Removal / Inspection / Installation page R-17

REAR SUSPENSION



REAR WHEEL ALIGNMENT

TOTAL TOE-IN: $2 \pm 3\text{mm}$ ($0.08 \pm 0.12\text{ in}$)
 $0.2^\circ \pm 0.3^\circ$

CAMBER: $-0^\circ 20' \pm 45'$

03U0RX-003

- | | |
|--|--|
| <p>1. Rear shock absorber and spring Removal / Installation page R-20 Disassembly / Inspection page R-21 Inspection page R-22 Assembly page R-23</p> | <p>2. Lateral link and trailing link Removal / Inspection / Installation page R-25 3. Rear stabilizer Removal / Inspection / Installation page R-26</p> |
|--|--|

OUTLINE

SPECIFICATIONS

| Item | | | Specification | | |
|---|---------------------|------------------------|-------------------------------------|---------------------|--|
| Suspension type | | | | | |
| Shock absorber | Suspension | | Double-acting, oil-filled | | |
| Coil spring | Type | Front | Taper wound | | |
| | | Rear | Straight wound | | |
| | Dimension | | See coil spring specification below | | |
| Stabilizer | Type | | Torsion bar | | |
| | Diameter mm (in) | BP SOHC | Front | 19.1 (0.75) | |
| | | | Rear | 20.0 (0.79) | |
| | | BP DOHC | Front | 22.0 (0.87) | |
| | | | Rear | 20.0 (0.79) | |
| | | B6 SOHC | Front | — | |
| Rear | | | 20.0 (0.79) | | |
| Wheel alignment (* ¹ Unladen) | Front | Maximum steering angle | Inner | 40° ± 2° | |
| | | | Outer | 33° ± 2° | |
| | | Total toe-in | mm (in) | 2 ± 3 (0.08 ± 0.12) | |
| | | | degree | 0.2° ± 0.3° | |
| | | Camber angle | | -0°05' ± 45' | |
| | | Caster angle | | 1°55' ± 55' | |
| | Kingpin angle | | 12°25' | | |
| | Rear | Total toe-in | mm (in) | 2 ± 3 (0.08 ± 0.12) | |
| degree | | | 0.2° ± 3° | | |
| Camber angle | | -0°20' ± 45' | | | |

03U0RX-004

*¹ Fuel tank full; radiator coolant and engine oil at specified levels; and spare tire, jack, and tools in designated positions.

Coil Spring Specifications

| Item | Wire diameter mm (in) | Coil outer diameter mm (in) | Free length mm (in) | Coil number | Identification mark color | | |
|-------|--------------------------|--------------------------------|------------------------|-------------|---------------------------|-----------------|--------|
| | | | | | M ^{*1} | A ^{*2} | |
| Front | A | 12.7 (0.5) | 133-159 (5.24-6.26) | 293 (11.54) | 3.1 | Pink | Yellow |
| | B | 12.9 (0.51) | 133-159 (5.24-6.26) | 294 (11.57) | 3.2 | Light green | Yellow |
| | C | 13.2 (0.52) | 133-159 (5.24-6.26) | 300 (11.81) | 3.4 | Purple | Yellow |
| | D | 13.3 (0.52) | 132-158 (5.20-6.22) | 301 (11.85) | 3.4 | Light blue | Yellow |
| | E | 13.3 (0.52) | 132-158 (5.20-6.22) | 286 (11.26) | 3.2 | Orange | Red |
| | F | 13.4 (0.53) | 133-159 (5.24-6.26) | 287 (11.3) | 3.3 | Cream | Red |
| Rear | G | 11.6 (0.46) | 140 (5.51) | 334 (13.15) | 4.6 | Brown | — |
| | H | 11.9 (0.47) | | 333 (13.11) | 4.7 | Gray | — |
| | I | 12.1 (0.48) | | 332 (13.07) | 4.8 | Orange | — |
| | J | 11.7 (0.46) | | 333 (13.11) | 4.5 | Blue | — |
| | K | 12.3 (0.48) | | 332 (13.07) | 4.9 | Blue & White | — |
| | L | 12.5 (0.49) | | 331 (13.03) | 5.1 | Blue & Green | — |

*¹ Main identification mark color: Indicated on second coil from bottom.

*² Auxiliary identification mark color: Indicated on third coil from bottom.

03U0RX-005

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Remedy | Page |
|---|---|--|---|
| Body "rolls" | Weak stabilizer Worn or deteriorated stabilizer bushing Worn or deteriorated lower arm bushing Malfunction of shock absorber | Replace Replace Replace Replace | R-17,26 R-17,26 — R-10,20 |
| Poor riding comfort | Weak coil spring Malfunction of shock absorber | Replace Replace | R-11,21 R-10,20 |
| Body leans | Weak coil spring Worn or deteriorated stabilizer bushing Worn or deteriorated lower arm bushing | Replace Replace Replace | R-11,21 R-17,26 — |
| Abnormal noise from suspension system | Poor lubrication or wear of lower arm ball joint Looseness of peripheral connections Malfunction of shock absorber Worn or deteriorated stabilizer bushing Worn or deteriorated lower arm bushing | Lubricate or replace Tighten Replace Replace Replace | R-15 — R-10,20 R-17,26 — |
| General driving instability | Weak coil spring Malfunction of shock absorber Worn or deteriorated lower arm bushing Worn or deteriorated stabilizer bushing Improperly adjusted wheel alignment Damaged lower arm ball joint Malfunction of steering system Damaged or unbalanced wheel(s) | Replace Replace Replace Replace Adjust Replace — — | R-11,21 R-10,20 — R-17,26 R- 6 R-15 Section N Section Q |
| Heavy steering | Poor lubrication or wear of lower arm ball joint Improperly adjusted wheel alignment Malfunction of steering system Damaged or unbalanced wheel(s) | Lubricate or replace Adjust — — | R-15 R- 6 Section N Section Q |
| Steering wheel pulls to one side | Weak coil spring Worn or deteriorated stabilizer bushing Worn or deteriorated lower arm bushing Damaged lower arm ball joint Improperly adjusted wheel alignment Malfunction of steering system Malfunction of braking system Damaged or unbalanced wheel(s) | Replace Replace Replace Replace Adjust — — — | R-11,21 R-17,26 — R-15 R- 6 Section N Section P Section Q |
| "Shimmy" occurs (Steering wheel vibrates left/right) | Damaged lower arm ball joint Malfunction of shock absorber Loose shock absorber mounting Worn or deteriorated lower arm bushing Worn or deteriorated stabilizer bushing Improperly adjusted wheel alignment Damaged or worn wheel bearing Malfunction of steering system Damaged or unbalanced wheel(s) | Replace Replace Tighten Replace Replace Adjust Replace — — | R-15 R-10,20 R-10,20 — R-17,26 R- 6 Section M Section N Section Q |
| Steering wheel doesn't return properly | Stuck or damaged lower arm ball joint Improperly adjusted wheel alignment Malfunction of steering system Damaged or unbalanced wheel(s) | Replace Adjust — — | R-15 R- 6 Section N Section Q |

03U0RX 006

WHEEL ALIGNMENT

PRE-INSPECTION

1. Check the tire inflations and set to the recommended pressure, if necessary.
2. Inspect the front wheel bearing play; replace the bearing if necessary.
3. Inspect the wheel and tire runout.
4. Inspect the ball joints and steering linkage for any excessive looseness.
5. The vehicle must be on level ground and have no luggage or passenger load.
6. The difference in height between the left and right sides from the center of the wheel to the fender brim must not exceed **10mm (0.39 in)**.
7. Shake the vehicle to check operation of the shock absorbers.


03U0RX-007

FRONT WHEEL ALIGNMENT Specifications


| Item | | | Specification | |
|---|-------|------------------------|---------------|-------------------------------|
| Wheel alignment (* ¹ Unladen) | Front | Maximum steering angle | Inner | $40^{\circ} \pm 2^{\circ}$ |
| | | | Outer | $33^{\circ} \pm 2^{\circ}$ |
| | | Total toe-in | mm (in) | $2 \pm 3 (0.08 \pm 0.12)$ |
| | | | degree | $0.2^{\circ} \pm 0.3^{\circ}$ |
| | | Camber angle | | $-0^{\circ}05' \pm 45'$ |
| | | Caster angle | | $1^{\circ}55' \pm 55'$ |
| Kingpin angle | | $12^{\circ}25'$ | | |

*¹ Fuel tank full; radiator coolant and engine oil at specified level; and spare tire, jack, and tools in designated positions.

03U0RX-008



03U0RX-009



03U0RX-010

Adjustments

Maximum steering angle

1. Loosen the left and right tie-rod locknuts, then turn the tie-rods equally.

Maximum left/right difference: 3mm (0.12 in)

2. Tighten the tie-rod locknuts.

Tightening torque:

34—39 N·m (3.5—4.0 m·kg, 25—29 ft·lb)


3. Adjust the toe-in after adjusting the steering angle.
4. Inspect and adjust the toe-in after adjusting the turning angle.

Camber and Caster


Note

- Caster is not adjustable.

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the mounting block nuts.



03U0RX-011



03U0RX-100


3. Push the mounting block downward, and turn it to the desired position

| Direction indicator | Difference from standard position | |
|---------------------|-----------------------------------|--------------|
| | Camber angle | Caster angle |
| A | +14 | +14 |
| B | +29 | 0° |
| C | +14 | -14 |

4. Install and tighten the mounting nuts to the specified torque.

Tightening torque:

29—40 N·m (3.0—4.1 m·kg, 22—30 ft·lb)



03U0RX-012


Adjustments

Total toe-in

To adjust the toe-in, loosen the left and right tie-rod locknuts, then turn the tie-rods equally.

Caution

- The left and right tie-rods are both right threaded, so, to increase the toe-in, turn the right tie-rod toward the front of the vehicle and the left tie-rod equally toward the rear.
- One turn of the tie-rod (both sides) changes the toe-in by about 6mm (0.24 in).




03U0RX-013


Tighten the tie-rod locknuts.

Tightening torque:


34—39 N·m (3.5—4.0 m·kg, 25—29 ft·lb)




03U0RX-014



03U0RX-015



03U0RX-016



03U0RX-017

REAR WHEEL ALIGNMENT**Adjustment****Total toe-in**

1. Loosen the lateral link locknuts.

2. Turn the lateral link adjustment link to adjust.

Note

- One turn of the link changes 11.3 m (0.44 in).

3. Tighten the lateral link locknuts to the specified torque.

Tightening torque:

55—64 N·m (5.6—6.5 m·kg, 41—47 ft·lb)


REAR CROSSMEMBER

Removal / Installation

1. Jack up the vehicle and support it with safety stands.
2. Remove the wheels and tires.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.

Caution


- Loosely tighten the lateral link and trailing link bolts and nuts when installing. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.



N-m (m-kG, ft-lb)

03U0RX-814


- | | | |
|---------------------------------|----------------------------|---------------------------|
| 1. Nut (Stabilizer) | 9. Bolt (Lateral link) | 17. Rear crossmember |
| 2. Bushing and retainer | 10. Lateral link | 18. Front rubber mount |
| 3. Bolt, retainer and bushing | 11. Bolt | 19. Rear rubber mount |
| 4. Retainer, bushing and spacer | 12. Rear stabilizer | 20. Crossmember bushing |
| 5. Bolt (Lateral link) | 13. Propeller shaft | Removal note... page R-10 |
| 6. Bolt (Trailing link) | 14. Driveshaft | Installation note |
| 7. Bolt (Trailing link) | 15. Rear differential | page R-10 |
| 8. Trailing link | 16. Nut (Rear crossmember) | |



03U0RX-815

Removal note**Crossmember bushing**


1. Remove the crossmember bushing in the direction of the arrow with the **SST**.



03U0RX-816

Installation note**Crossmember bushing**

1. Apply soapy water to the crossmember bushing and position it with the direction tab forward.



03U0RX-817

2. Install the lower arm bushing with a plastic hammer.

BODY

INDEX S- 2

FEATURES


OUTLINE S- 2
OUTLINE OF CONSTRUCTION..... S- 2

SERVICE

SUPPLEMENTAL SERVICE INFORMATION .. S- 2
UNDERBODY DIMENSIONS..... S- 3
UNDERBODY PROJECTED DIMENSIONS... S- 3
UNDERBODY STRAIGHT-LINE
DIMENSIONS..... S- 4

03U0SX-801

INDEX



03U0SX-802

1. Underbody projected dimensions..... page S-3
2. Underbody straight-line dimensions..... page S-4

OUTLINE

OUTLINE OF CONSTRUCTION

- The body for the 4WD model is basically the same as for the 2WD model; however, underbody is changed. (Refer to pages S-2, 3.)

03U0SX-803

SUPPLEMENTAL SERVICE INFORMATION


The following points in this section are changed in comparison with Workshop Manual (1195-10-89E).

- Underbody projected dimensions**
- Underbody straight-line dimensions**

03U0SX-804

UNDERBODY DIMENSIONS


UNDERBODY PROJECTED DIMENSIONS



H: FRONT FRAME B REFERENCE HOLE ϕ 20 (0.79)
 I: TRAILING LINK BRACKET REFERENCE HOLE 10 x 12 (0.39 x 0.47)
 J: REAR CROSSMEMBER MOUNTING BOLT
 K: REAR SUSPENSION MOUNTING BLOCK MOUNTING SURFACE
 L: REAR CROSSMEMBER MOUNTING BOLT
 M: REAR SIDE FRAME REFERENCE HOLE 16 x 22 (0.63 x 0.87)
 N: REAR BUMPER MOUNTING HOLE ϕ 12 (0.47)

A: CROSSMEMBER REFERENCE HOLE ϕ 12 (0.47)
 B: CROSSMEMBER REFERENCE HOLE ϕ 12 (0.47)
 C: FRONT FRAME REFERENCE HOLE ϕ 16 (0.63)
 D: FRONT SUSPENSION MOUNTING BLOCK MOUNTING SURFACE
 E: STEERING GEAR MOUNTING BOLT
 F: CROSSMEMBER MOUNTING BOLT
 G: FRONT FRAME B REFERENCE HOLE ϕ 16 (0.63)

mm (in)



- A: CROSSMEMBER REFERENCE HOLE $\phi 12$ (0.47)
 B: CROSSMEMBER REFERENCE HOLE $\phi 12$ (0.47)
 C: FRONT FRAME REFERENCE HOLE $\phi 16$ (0.63)
 D: FRONT SUSPENSION MOUNTING BLOCK MOUNTING SURFACE
 E: STEERING GEAR MOUNTING BOLT
 F: CROSSMEMBER MOUNTING BOLT
 G: FRONT FRAME B REFERENCE HOLE $\phi 16$ (0.63)

- H: FRONT FRAME B REFERENCE HOLE $\phi 20$ (0.79)
 I: TRAILING LINK BRACKET REFERENCE HOLE 10 x 12 (0.39 x 0.47)
 J: REAR CROSSMEMBER MOUNTING BOLT
 K: REAR SUSPENSION MOUNTING BLOCK MOUNTING SURFACE
 L: REAR CROSSMEMBER MOUNTING BOLT
 M: REAR SIDE FRAME REFERENCE HOLE 16 x 22 (0.63 x 0.87)
 N: REAR BUMPER MOUNTING HOLE $\phi 12$ (0.47)

mm (in)

BODY ELECTRICAL SYSTEM

INDEX T- 2

FEATURES


OUTLINE T- 3
OUTLINE OF CONSTRUCTION..... T- 3
FUSE AND JOINT BOX..... T- 3
FUSE T- 3
WARNING SYSTEM T- 4
WARNING AND INDICATOR LAMPS T- 4

SERVICE

SUPPLEMENTAL SERVICE INFORMATION .. T- 6
INSTRUMENT CLUSTER T- 6
FUEL GAUGE SENDER UNIT..... T- 6

03U0TX-801

INDEX



03U0TX-802

- 1. Fuel gauge sender unit (in fuel tank)
Inspection page T-6

OUTLINE

OUTLINE OF CONSTRUCTION


- The body electrical system for the 4WD model is basically the same as for the 2WD model; however, with the addition of the 4WD components, an additional fuse is included and the warning and indicator lamp system is upgraded.

03U0TX-803

FUSE AND JOINT BOX





FUSE

- A center differential lock (DIF LOCK) fuse is added.



03U0TX-804

| Fuse | | Protected circuit |
|-----------------|-----|--|
| (REAR WIPER) | 10A | Rear wiper and washer |
| HAZARD | 15A | Hazard warning |
| ROOM | 10A | Clock, interior lamps, Cargo area lamp, Trunk compartment lamp |
| ENGINE | 15A | Alternator |
| RADIO | 15A | Audio |
| BELT | 30A | Passive shoulder belts |
| METER | 15A | Cruise control system, Turn signals, Instrument panel (gauges and warning lamps), Back-up lights |
| WIPER | 20A | Windshield wiper and washer |
| STOP | 15A | Stoplights, Horn |
| TAIL | 15A | Taillights, Side marker lights, Parking lights, illumination lights, License plate lights |
| DIF LOCK | 20A | Center differential lock |
| (DEFOG) | 20A | Rear window defroster |
| Circuit breaker | | |
| HEATER | 30A | Blower motor |



| TERMINAL | CONNECTED TO |
|----------|---------------------|
| 1A | COMBINATION SWITCH |
| 1B | GROUND |
| 1C | FUEL TANK UNIT |
| 1D | 4WD CONTROL UNIT |
| 1E | WASHER LEVEL SENSOR |
| 1F | FUEL TANK UNIT |
| 1G | EC-AT CONTROL UNIT |
| 1H | |
| 1I | |
| 1J | |

| TERMINAL | Connected to |
|----------|--------------------------|
| 2A | SPEED SENSOR OUTPUT |
| 2B | LIGHT SWITCH (HIGH BEAM) |
| 2C | TURN SWITCH (L) |
| 2D | TURN SWITCH (R) |
| 2E | GROUND |
| 2F | GROUND |
| 2G | IG COIL (IGNITER) |
| 2H | |
| 2I | |
| 2J | |
| 2K | |
| 2L | IG1 BATTERY |

| TERMINAL | Connected to |
|----------|--|
| 3A | |
| 3B | ALTERNATOR |
| 3C | |
| 3D | OIL PRESSURE SWITCH |
| 3E | |
| 3F | PARKING BRAKE SWITCH, BRAKE FLUID SWITCH |
| 3G | PASSIVE SHOULDER BELT CONTROL UNIT |
| 3H | EGI CONTROL UNIT |
| 3I | |
| 3J | |
| 3K | ST (MT), INHIBITOR (EC-AT) |
| 3L | WATER TEMPERATURE GAUGE UNIT |

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with Workshop Manual (1195-10-89E).

Fuel gauge sender unit

- Inspection


03U0TX-807

INSTRUMENT CLUSTER (METER)


FUEL GAUGE SENDER UNIT

Inspection

1. Remove the fuel tank gauge unit. (Refer to Section F.)
2. Disconnect the fuel gauge sender unit connector.
3. Check resistance while slowly moving the unit arm from point F to point E.
4. If not as specified, replace the fuel gauge sender unit.



03U0TX-808



HEATER AND AIR CONDITIONER SYSTEM

OUTLINE..... **U- 2**
OUTLINE OF CONSTRUCTION **U- 2**

03U0UX-801

OUTLINE


OUTLINE OF CONSTRUCTION

- The heater and air conditioner systems for the 4WD model is basically the same as for the 2WD model; however, for EC-AT equipped vehicles, the cooling efficiency of the engine is improved by operating the additional fan independent of the A/C switch.

Circuit Diagram

Z WIRING DIAGRAM

HEATER & AIR CONDITIONER



Z-72

A/C SWITCH & BLOWER SWITCH ILLUMINATION LAMPS REFER TO PAGE Z-62

TECHNICAL DATA

MEASUREMENTS..... TD- 2
ENGINE..... TD- 2
LUBRICATION SYSTEM..... TD- 5
COOLING SYSTEM..... TD- 6
FUEL AND EMISSION CONTROL
SYSTEMS..... TD- 6
ENGINE ELECTRICAL SYSTEM TD- 7
CLUTCH..... TD- 8
MANUAL TRANSAXLE AND TRANSFER.... TD- 8
AUTOMATIC TRANSAXLE TD-10
PROPELLER SHAFT..... TD-12
FRONT AND REAR AXLES..... TD-13
STEERING SYSTEM TD-13
BRAKING SYSTEM..... TD-14
WHEELS AND TIRES..... TD-15
SUSPENSION TD-15
BODY ELECTRICAL SYSTEM..... TD-16
STANDARD BOLT AND NUT TIGHTENING
TORQUE TD-16

03UTDX-001

MEASUREMENTS

| Item | Type | Sedan |
|----------------|---------|---------------|
| Overall length | mm (in) | 4,355 (171.5) |
| Overall width | mm (in) | 1,675 (65.9) |
| Overall height | mm (in) | 1,375 (54.1) |
| Wheel base | mm (in) | 2,500 (98.4) |
| Front tread | mm (in) | 1,430 (56.3) |
| Rear tread | mm (in) | 1,435 (56.5) |

B. ENGINE

| Item | | Engine | BP SOHC | |
|--|--|--|----------------------------|-----------------------------|
| Type | | | Gasoline, 4-cycle | |
| Cylinder arrangement and number | | | In-line 4-cylinder | |
| Combustion chamber | | | Pentroof | |
| Valve system | | | OHC, belt-driven 16 valves | |
| Bore x Stroke | | mm (in) | 83.0 x 85.0 (3.27 x 3.35) | |
| Total piston displacement | | cc (cu in) | 1,839 (112.2) | |
| Compression ratio | | | 8.9 | |
| Compression pressure kPa (kg/cm ² , psi)-rpm | | Standard | 1,197 (12.2, 173)-300 | |
| | | Minimum | 834 (8.5, 121)-300 | |
| | | Maximum difference between each cylinders | 196 (2.0, 28) | |
| Valve timing | | IN | Open BTDC | 2° |
| | | | Close ABDC | 50° |
| | | EX | Open BBDC | 55° |
| | | | Close ATDC | 8° |
| Valve clearance mm (in) (Warm engine) | | Valve side | IN | 0 Maintenance-free |
| | | | EX | 0 Maintenance-free |
| | | Cam side | IN | 0 Maintenance-free |
| | | | EX | 0 Maintenance-free |
| Cylinder head | | | | |
| Height | | mm (in) | 107.4—107.6 (4.228—4.236) | |
| Distortion | | mm (in) | 0.10 (0.004) max. | |
| Grinding | | mm (in) | 0.10 (0.004) max. | |
| Valve and valve guide | | | | |
| Valve head diameter | | mm (in) | IN | 29.9—30.1 (1.177—1.185) |
| | | | EX | 24.85—25.15 (0.978—0.990) |
| Valve head margin thickness | | mm (in) | IN | 0.65 (0.026) |
| | | | EX | 0.71 (0.028) |
| Valve face angle | | | IN | 45° |
| | | | EX | 45° |
| Valve length | | IN | Standard | 101.77 (4.007) |
| | | | Minimum | 101.27 (3.987) |
| | | EX | Standard | 102.97 (4.054) |
| | | | Minimum | 102.47 (4.034) |
| Valve stem diameter | | mm (in) | IN | 5.970—5.985 (0.2350—0.2356) |
| | | | EX | 5.965—5.980 (0.2348—0.2354) |
| Guide inner diameter | | mm (in) | 6.01—6.03 (0.2366—0.2374) | |
| Valve stem-to-guide clearance | | mm (in) | IN | 0.025—0.060 (0.0010—0.0024) |
| | | | EX | 0.030—0.065 (0.0011—0.0026) |
| | | | Maximum | 0.20 (0.008) |
| Guide projection (Height "A") | | mm (in) | IN | 18.3—18.9 (0.720—0.744) |
| | | | EX | 16.8—17.4 (0.661—0.685) |

| Item | | Engine | BP SOHC | | |
|--|--|---------|--|--|---|
| Valve seat | | | | | |
| Seat angle | | IN | 45° | | |
| | | EX | 45° | | |
| Seat contact width | | mm (in) | | | |
| | | IN | 0.8—1.4 (0.031—0.055) | | |
| | | EX | 0.8—1.4 (0.031—0.055) | | |
| Seat sinking | | mm (in) | IN | Standard | 42.05—42.95 (1.656—1.691) |
| | | | Maximum | 44.0 (1.732) | |
| | | EX | Standard | 40.55—41.45 (1.596—1.632) | |
| | | | Maximum | 42.5 (1.673) | |
| Valve spring | | | | | |
| Free length | | IN | Standard | mm (in) | 46.1 (1.815) |
| | | | Minimum | N (kg, lb)/mm (in) | 205—231 (20.9—23.5, 46—52)/39 (1.535) |
| | | EX | Standard | mm (in) | 43.6 (1.717) |
| | | | Minimum | N (kg, lb)/mm (in) | 129—147 (13.1—15.0, 29—33)/37.5 (1.476) |
| Out-of-square | | mm (in) | Maximum | IN...1.61 (0.063), EX...1.52 (0.060) | |
| Camshaft | | | | | |
| Lobe height | | mm (in) | IN | Standard | 35.993 (1.4170) |
| | | | Wear limit | 35.793 (1.4092) | |
| | | EX | Standard | 36.273 (1.4281) | |
| | | | Wear limit | 36.073 (1.4202) | |
| Journal diameter | | mm (in) | No.1 & No.5 | 43.440—43.460 (1.7102—1.7110) | |
| | | | No.2 & No.4 | 43.425—43.450 (1.7096—1.7106) | |
| | | | No.3 | 43.410—43.435 (1.7091—1.7100) | |
| | | | Out-of-round | 0.05 (0.002) max. | |
| Camshaft bearing oil clearance | | mm (in) | No.1 & No.5 | 0.040—0.075 (0.0016—0.0030) | |
| | | | No.2 & No.4 | 0.035—0.080 (0.0014—0.0031) | |
| | | | No.3 | 0.050—0.095 (0.0020—0.0037) | |
| | | | Maximum | 0.15 (0.006) | |
| Camshaft runout | | mm (in) | | 0.03 (0.0012) max. | |
| Camshaft end play | | mm (in) | Standard | 0.06—0.20 (0.0024—0.0079) | |
| | | | Maximum | 0.2 (0.008) | |
| Rocker arm and rocker arm shaft | | | | | |
| Rocker arm inner diameter | | mm (in) | IN...19.000—19.027 (0.7480—0.7491), EX...19.000—19.033 (0.7480—0.7493) | | |
| Rocker arm shaft diameter | | mm (in) | 18.959—18.980 (0.7464—0.7472) | | |
| Rocker arm to shaft clearance | | mm (in) | Standard | IN...0.020—0.068 (0.0008—0.0027), EX...0.020—0.074 (0.0008—0.0029) | |
| | | | Maximum | 0.10 (0.004) | |
| Cylinder block | | | | | |
| Height | | mm (in) | 221.5 (8.720) | | |
| Distortion | | mm (in) | 0.15 (0.006) max. | | |
| Grinding | | mm (in) | 0.20 (0.008) max. | | |
| Cylinder bore diameter | | mm (in) | Standard size | 83.006—83.013 (3.2679—3.2682) | |
| | | | 0.25 (0.010) oversize | 83.256—83.263 (3.2778—3.2781) | |
| | | | 0.50 (0.020) oversize | 83.506—83.513 (3.2876—3.2879) | |
| Cylinder bore taper and out-of-round | | mm (in) | 0.019 (0.0007) max. | | |

| Item | | Engine | BP SOHC |
|---|------------------------|-------------------------------|---------------------------------------|
| Piston | | | |
| Piston diameter Measured at 90° to pin bore axis and 16.5mm (0.650 in) below oil ring groove mm (in) | Standard size | | 82.954—82.974 (3.2659—3.2667) |
| | 0.25 (0.010) oversize | | 83.211—83.217 (3.2760—3.2763) |
| | 0.50 (0.020) oversize | | 83.461—83.467 (3.2859—3.2861) |
| Piston-to-cylinder clearance mm (in) | Standard | | 0.039—0.052 (0.0015—0.0020) |
| | Maximum | | 0.15 (0.006) |
| Piston ring | | | |
| Thickness mm (in) | Top | | 1.47—1.49 (0.0579—0.0587) |
| | Second | | 1.47—1.49 (0.0579—0.0587) |
| End gap (Measured in cylinder) mm (in) | Top | | 0.15—0.30 (0.006—0.012) |
| | Second | | 0.15—0.30 (0.006—0.012) |
| | Oil (rail) | | 0.20—0.70 (0.008—0.028) |
| | Maximum | | 1.0 (0.039) |
| Ring groove width in piston mm (in) | Top | | 1.520—1.535 (0.0598—0.0604) |
| | Second | | 1.520—1.535 (0.0598—0.0604) |
| | Oil | | 3.02—3.04 (0.1189—0.1197) |
| Piston ring-to-ring groove clearance mm (in) | Top | | 0.030—0.065 (0.0012—0.0026) |
| | Second | | 0.030—0.065 (0.0012—0.0026) |
| | Maximum | | 0.15 (0.006) |
| Piston pin | | | |
| Diameter | mm (in) | | 19.974—19.980 (0.7864—0.7866) |
| Interference in connecting rod | mm (in) | | 0.013—0.037 (0.0005—0.0015) |
| Installing pressure | N (kg, lb) | | 4,905—14,715 (500—1,500, 1,100—3,300) |
| Connecting rod and connecting rod bearing | | | |
| Length (Center to center) | mm (in) | | 132.85—132.95 (5.2303—5.2342) |
| Bending | mm (in) | | 0.075 (0.0030) max./50 (1.97) |
| Small end bore | mm (in) | | 19.943—19.961 (0.7852—0.7859) |
| Big end bore | mm (in) | | 48.000—48.016 (1.8898—1.8904) |
| Big end width | mm (in) | | 21.838—21.890 (0.8598—0.8618) |
| Connecting rod side clearance mm (in) | Standard | | 0.110—0.262 (0.0043—0.0103) |
| | Maximum | | 0.30 (0.012) |
| Crankshaft | | | |
| Crankshaft runout | mm (in) | | 0.04 (0.0016) max. |
| Main journal diameter mm (in) | Standard size | Standard | 49.938—49.956 (1.9661—1.9668) |
| | | Minimum | 49.904 (1.9647) |
| | 0.25 (0.010) undersize | Standard | 49.704—49.708 (1.9568—1.9570) |
| | | Minimum | 49.652 (1.9548) |
| 0.50 (0.020) undersize | Standard | 49.454—49.458 (1.9470—1.9472) | |
| | Minimum | 49.402 (1.9450) | |
| Main journal taper and out-of-round | mm (in) | | 0.05 (0.020) max. |
| Crankpin diameter mm (in) | Standard size | Standard | 44.940—44.956 (1.7693—1.7699) |
| | | Minimum | 44.908 (1.7680) |
| | 0.25 (0.010) undersize | Standard | 44.690—44.706 (1.7594—1.7601) |
| | | Minimum | 44.658 (1.7582) |
| | 0.50 (0.020) undersize | Standard | 44.440—44.456 (1.7496—1.7502) |
| | | Minimum | 44.408 (1.7483) |
| 0.75 (0.030) undersize | Standard | 44.190—44.206 (1.7398—1.7404) | |
| | Minimum | 44.158 (1.7385) | |
| Crankpin taper and out-of-round | mm (in) | | 0.05 (0.020) max. |
| Main bearing | | | |
| Main journal bearing oil clearance mm (in) | Standard | | 0.018—0.036 (0.0007—0.0014) |
| | Maximum | | 0.10 (0.004) |
| Available undersized bearing | mm (in) | | 0.25 (0.010), 0.50 (0.020) |

| Item | | Engine | BP SOHC |
|--------------------------------|---------|-----------------------------|--|
| Crankpin bearing | | | |
| Crankpin bearing oil clearance | mm (in) | Standard | 0.028—0.068 (0.0011—0.0027) |
| | | Maximum | 0.10 (0.004) |
| Available undersized bearing | | mm (in) | 0.25 (0.010), 0.50 (0.020), 0.75 (0.030) |
| Thrust bearing | | | |
| Crankshaft end play | mm (in) | Standard | 0.08—0.282 (0.0031—0.0111) |
| | | Maximum | 0.30 (0.012) |
| Bearing width | mm (in) | Standard size | 2.500—2.550 (0.0984—0.1004) |
| | | 0.25 (0.010) oversize | 2.625—2.675 (0.1033—0.1053) |
| | | 0.50 (0.020) oversize | 2.750—2.800 (0.1083—0.1102) |
| | | 0.75 (0.030) oversize | 2.875—2.925 (0.1132—0.1152) |
| Timing belt | | | |
| Belt deflection | | mm (in)/98 N (10 kg, 22 lb) | 11.0—13.0 (0.43—0.51) |

D. LUBRICATION SYSTEM

| Item | | Engine | BP SOHC |
|--|-------------------------|------------------------------------|--------------------------------|
| Lubricating method | | | Force-fed |
| Oil pump | | | |
| Type | | | Trochoid gear |
| Relief pressure | | kPa (kg/cm ² , psi) | 343—441 (3.5—4.5, 50—64) |
| Regulated pressure | | kPa (kg/cm ² , psi)-rpm | 294—392 (3.0—4.0, 43—57)-3,000 |
| Inner rotor tooth tip to outer rotor clearance | mm (in) | Standard | 0.02—0.16 (0.0008—0.0063) |
| | | Maximum | 0.20 (0.0078) |
| Outer rotor to body clearance | mm (in) | Standard | 0.09—0.18 (0.0035—0.0071) |
| | | Maximum | 0.22 (0.0087) |
| Side clearance | mm (in) | Standard | 0.03—0.11 (0.0012—0.0043) |
| | | Maximum | 0.14 (0.0055) |
| Oil filter | | | |
| Type | | | Full-flow, paper element |
| Relief pressure differential | | kPa (kg/cm ² , psi) | 78—118 (0.8—1.2, 11—17) |
| Engine oil | | | |
| Capacity liters (US qt, Imp qt) | Total (dry engine) | | 4.0 (4.2, 3.5) |
| | Oil pan | | 3.6 (3.8, 3.2) |
| | Oil filter | | 0.17 (0.18, 0.15) |
| Grade | | | API Service SF or SG |
| Viscosity number | Above 30°C (86°F) | | SAE 40 |
| | 0°C—40°C (32°F—104°F) | | SAE 30 |
| | -10°C—20°C (14°F—68°F) | | SAE 20W-20 |
| | Above -10°C (14°F) | | SAE 20W-40 or 20W-50 |
| | -25°C—30°C (-13°F—86°F) | | SAE 10W-30 |
| | Above -25°C (-13°F) | | SAE 10W-40 or 10W-50 |
| | Below 0°C (32°F) | | SAE 5W-30 |
| Below -20°C (-4°F) | | SAE 5W-20 | |

E. COOLING SYSTEM

| Item | Engine | BP SOHC | | |
|-----------------------------------|--------------------------------|---|----------------------|---------------------------------|
| | | MTX | ATX | |
| Cooling method | | Water-cooled, forced circulation | | |
| Water pump | | | | |
| Type | | Centrifugal, V-belt driven | | |
| Impeller diameter | mm (in) | 70 (2.76) | | |
| Number of impeller blades | | 6 | | |
| Speed ratio | | 1 : 1.05 | | |
| Water seal type | | Unified mechanical seal | | |
| Thermostat | | | | |
| Type | | Wax, two-stage | | |
| Opening temperature | °C (°F) | Sub: 83.5—86.5 (182—188), Main: 86.5—89.5 (188—193) | | |
| Full-open temperature | °C (°F) | 100 (212) | | |
| Full-open lift | mm (in) | Sub: 1.5 (0.06) min., Main: 8.0 (0.31) min. | | |
| Radiator | | | | |
| Type | | Corrugated fin | | |
| Cap valve opening pressure | kPa (kg/cm ² , psi) | 74—103 (0.75—1.05, 11—15) | | |
| Cooling circuit checking pressure | kPa (kg/cm ² , psi) | 103 (1.05, 15) | | |
| Cooling fan | | | | |
| Type | | Electric | | |
| Number of blades | | 4 | 5 | |
| Outer diameter | mm (in) | 320 (12.6) | 340 (13.4) | |
| Capacity | W-V | 80-12 | 160-12 | |
| Current | A | 6.6 | Hi : 13.3, Low : 8.8 | |
| Water thermostwitch | | | | |
| OFF→ON | °C (°F) | 97 (207) | | |
| Radiator thermostwitch | | | | |
| OFF→ON | °C (°F) | — | 105 (221) | |
| Coolant | | | | |
| Capacity | liters (US qt, Imp qt) | 5.0 (5.3, 4.4) | 6.0 (6.3, 5.3) | |
| Antifreeze solution | Coolant protection | Volume percentage % | | Specific gravity at 20°C (68°F) |
| | | Water | Coolant | |
| | Above -16°C (3°F) | 65 | 35 | 1.054 |
| | Above -26°C (-15°F) | 55 | 45 | 1.066 |
| Above -40°C (-40°F) | 45 | 55 | 1.078 | |

F. FUEL AND EMISSION CONTROL SYSTEMS

| Item | Engine | BP SOHC | |
|---------------------------------------|--------------------------------|---------------------------------------|-----|
| | | MTX | ATX |
| Idle speed | rpm | 750 ± 50 (with parking brake applied) | |
| Ignition timing | BTDC | 5 ± 1° | |
| Fuel pump | | | |
| Maximum output pressure | kPa (kg/cm ² , psi) | 441—589 (4.5—6.0, 64—85) | |
| Fuel filter | | | |
| Type | Low-pressure side | Nylon element (built-in fuel pump) | |
| | High-pressure side | Paper element | |
| Pressure regulator | | | |
| Regulating pressure | kPa (kg/cm ² , psi) | 265—314 (2.7—3.2, 38—46) | |
| Injector | | | |
| Type | | High-ohmic | |
| Type of drive | | Electromechanical | |
| Resistance | Ω | 12—16 | |
| Idle speed control (ISC) valve | | | |
| Type | | Rotary | |
| Resistance | Ω | 11—13 | |

F. FUEL AND EMISSION CONTROL SYSTEMS

| Item | | Engine | BP SOHC |
|-------------------------------------|---|--------------------------|-------------------------------------|
| Purge control solenoid valve | | | |
| Resistance | | Ω | 23—27 |
| Water thermosensor | | | |
| Resistance | k Ω | -20°C (-4°F) | 14.6—17.8 |
| | | 20°C (68°F) | 2.21—2.69 |
| | | 40°C (104°F) | 1.0—1.3 |
| | | 80°C (176°F) | 0.29—0.35 |
| Airflow meter | | | |
| Resistance | E2↔Vs | Fully closed | 200—600 |
| | | Fully open | 20—1,200 |
| | E2↔Vc | | 200—400 |
| | E2↔THAA (Intake air thermosensor) | -20°C (-4°F) | 13,600—18,400 |
| | | 20°C (68°F) | 2,210—2,690 |
| | | 60°C (140°F) | 493—667 |
| E1↔Fc | Fully closed | ∞ | |
| | Fully open | 0 | |
| Fuel tank | | | |
| Capacity | | liters (US gal, Imp gal) | 60 (15.8, 13.2) |
| Air cleaner | | | |
| Element type | | | Oil permeated |
| Fuel | | | |
| Specification | | | Unleaded regular (RON 91 or higher) |

G. ENGINE ELECTRICAL SYSTEM

| Item | | Engine | BP SOHC | | |
|---|----------------------------------|--------------------------------|--|-------------------|--------|
| | | | MTX | ATX | |
| Battery | Voltage | V | 12 | | |
| | Type and capacity (20-hour rate) | | 55D23L (60AH) | | |
| Dark current* ¹ | | mA | Max. 20.0 | | |
| Alternator | Type | | A.C | | |
| | Output | | V-A | | |
| | Regulator type | | Transistorized (built-in IC regulator) | | |
| | Regulated voltage | | V | | |
| | Brush length | mm (in) | Standard | 21.5 (0.846) | |
| | | | Minimum | 8.0 (0.315) | |
| | Drive belt deflection | mm (in)/98 N (10 kg, 22 lb) | New | 8—9 (0.31—0.35) | |
| Used | | | 9—10 (0.35—0.39) | | |
| Starter | Type | | Direct | Coaxial reduction | |
| | Output | | V-kW | 12-0.95 | |
| | Brush length | mm (in) | Standard | 17 (0.67) | 12-1.4 |
| Minimum | | | 11.5 (0.453) | 17.5 (0.69) | |
| Distributor | | | Electronic spark advance (photo diode) | | |
| Ignition timing (TEN terminal of diagnosis connector grounded) | | BTDC | 5 ± 1° | | |
| Ignition coil | Resistance (at 20°C [68°F]) | Primary coil winding | 0.81—0.99 Ω | | |
| | | Secondary coil winding | 10—16 k Ω | | |
| Spark plug | Type | NGK | BKR5E 11 | BKR6E 11 | |
| | | Nippon Denso | K16PR-U11 | K20PR-U11 | |
| | Plug gap | mm (in) | 1.0—1.1 (0.039—0.043) | | |
| Firing order | | | 1—3—4—2 | | |

*¹ Dark current is the constant flow of current while the ignition switch is OFF.
(i.e engine control unit, EC-AT control unit, audio, etc.)

H. CLUTCH

| Item | | Engine/Transaxle Model | | BP SOHC |
|---|--|------------------------|---------------------|-----------------------------|
| | | | | G5MX-R |
| Clutch control | | | | Hydraulic |
| Clutch pedal | | | | |
| Type | | | | Suspended |
| Pedal ratio | | | | 6.55 |
| Full stroke | | mm (in) | | 135 (5.32) |
| Height (With carpet) | | mm (in) | | 196—204 (7.72—8.03) |
| Free play | | mm (in) | | 5.5—17.4 (0.22—0.69) |
| Distance to carpet when clutch fully disengaged | | mm (in) | Minimum | 41.0 (1.61) |
| Flywheel | | | | |
| Runout limit | | mm (in) | | 0.2 (0.008) |
| Clutch disc | | | | |
| Type | | | | Single dry plate |
| Runout limit | | mm (in) | | 0.7 (0.027) |
| Wear limit | | mm (in) | | 0.3 (0.012) from rivet head |
| Outer diameter | | mm (in) | | 225 (8.85) |
| Inner diameter | | mm (in) | | 150 (5.91) |
| Facing thickness | | mm (in) | Flywheel side | 3.5 (0.138) |
| | | | Pressure plate side | 4.1 (0.161) |
| Clutch cover | | | | |
| Type | | | | Diaphragm spring |
| Set load | | N (kg, lb) | | 3,846 (392, 862) |

J3. MANUAL TRANSAXLE AND TRANSFER

| Item | | Model | | BP SOHC |
|---|------------|------------------------|------------|--|
| | | | | G5MX-R |
| Transmission | | | | |
| Shift lever position | | | | Floor shift |
| Gear ratio | First | | | 3.307 |
| | Second | | | 1.833 |
| | Third | | | 1.233 |
| | Fourth | | | 0.914 |
| | Fifth | | | 0.717 |
| | Reverse | | | 3.166 |
| Oil | All season | | | ATF: DEXRON-II or M-III API: GL-4 SAE 75W-90 |
| | Capacity | liters (US qt, Imp qt) | | 2.6 (2.748, 2.288) |
| Clearance | | | | |
| Clearance of lever and reverse idler gear | | mm (in) | Standard | 0.1—0.32 (0.004—0.013) |
| | | | Wear limit | 0.5 (0.02) |
| Clearance of shift fork and clutch sleeve | Standard | mm (in) | 1st—2nd | 0.08—0.228 (0.003—0.009) |
| | | | 3rd—4th | 0.1—0.5 (0.004—0.020) |
| | | | 5th—Rev. | 0.15—0.458 (0.060—0.018) |
| | Wear limit | mm (in) | 1st—2nd | 0.278 (0.011) |
| | | | 3rd—4th | 0.55 (0.022) |
| | | | 5th—Rev. | 0.508 (0.020) |
| Clearance of synchronizer ring and gear | | mm (in) | Standard | 1.5 (0.059) |
| | | | Wear limit | 0.8 (0.031) |

| Item | | Model | | BP SOHC |
|--|------------------|--|--|--|
| | | | | G5MX-R |
| Gear thrust clearance mm (in) | First | Standard | | 0.050—0.280 (0.002—0.011) |
| | | Limit | | 0.330 (0.013) |
| | Second | Standard | | 0.175—0.455 (0.007—0.018) |
| | | Limit | | 0.505 (0.020) |
| | Third | Standard | | 0.050—0.200 (0.002—0.008) |
| | | Limit | | 0.250 (0.039) |
| | Fourth | Standard | | 0.165—0.365 (0.065—0.144) |
| | | Limit | | 0.415 (0.016) |
| | Fifth | Standard | | 0.050—0.175 (0.002—0.007) |
| | | Limit | | 0.225 (0.010) |
| Bearing preload adjust shim mm (in) | Primary shaft | | 0.20 (0.007), 0.25 (0.009), 0.30 (0.011), 0.35 (0.013), 0.40 (0.015), 0.45 (0.017), 0.50 (0.019), 0.55 (0.021), 0.60 (0.023), 0.65 (0.025), 0.70 (0.027) | |
| | Secondary shaft | | 0.20 (0.007), 0.25 (0.009), 0.30 (0.011), 0.35 (0.013), 0.40 (0.015), 0.45 (0.017), 0.50 (0.019), 0.55 (0.021), 0.60 (0.023), 0.65 (0.025), 0.70 (0.027) | |
| Center differential | | | | |
| Type | | Planetary carrier | | |
| Number of ring gear teeth | Outer | | 79 | |
| | Inner | | 66 | |
| Number of pinion gear teeth | Outer | | 14 | |
| | Inner | | 14 | |
| Number of sun gear teeth | Pinion gear side | | 33 | |
| | Idle gear side | | 43 | |
| Number of idle-gear teeth | | 37 | | |
| Bearing preload | | Nm (cm-kg, in-lb) | | 2.9—3.9 (30—40, 26—34) |
| Bearing preload adjustment shim | | mm (in) | | 0.10 (0.003), 0.15 (0.005), 0.20 (0.007), 0.25 (0.009), 0.30 (0.011), 0.35 (0.013), 0.40 (0.015), 0.45 (0.017), 0.50 (0.019), 0.55 (0.021), 0.60 (0.023), 0.65 (0.025), 0.70 (0.027), 0.75 (0.029), 0.80 (0.031), 0.85 (0.033), 0.90 (0.035), 0.95 (0.037), 1.00 (0.039), 1.05 (0.041), 1.10 (0.043), 1.15 (0.045), 1.20 (0.047) |
| End play of ring gear | | 0.15—0.30 (0.006—0.012) | | |
| Ring gear end play adjustment washer | | 1.20 (0.047), 1.25 (0.049), 1.30 (0.051), 1.35 (0.053), 1.40 (0.055), 1.45 (0.057), 1.50 (0.059), 1.55 (0.061), 1.60 (0.063), 1.65 (0.065), 1.70 (0.067), 1.75 (0.069), 1.80 (0.071) | | |
| End play of sun gear | | 0.10—0.30 (0.004—0.012) | | |
| Sun gear adjustment wadher | | 3.50 (0.137), 3.55 (0.139), 3.60 (0.141), 3.65 (0.143), 3.70 (0.145), 3.75 (0.147), 3.80 (0.149), 3.85 (0.151), 3.90 (0.153), 3.95 (0.155), 4.00 (0.157), 4.05 (0.159), 4.10 (0.161), 4.15 (0.163), 4.20 (0.165), 4.25 (0.167), 4.30 (0.169) | | |
| Transfer carrier | | | | |
| Final gear reduction ratio | | | | |
| Number of teeth | Ring gear | | 37 | |
| | Pinion gear | | 11 | |
| Fluid | Grade | | API GL-5 | |
| | Viscosity | Above -18°C (0°F) | | SAE 90 |
| | | Below -18°C (0°F) | | SAE 80W |
| | Capacity | liter (US qt, Imp qt) | | 0.5 (0.53, 0.44) |

K2. AUTOMATIC TRANSAXLE

| Item | | Model | BP SOHC | |
|---|---------------------------------------|---------------------------------|--|--|
| | | | G4AX-EL | |
| Torque converter stall torque ratio | | | | |
| Gear ratio | | 1st | | 2.800 |
| | | 2nd | | 1.541 |
| | | 3rd | | 1.000 |
| | | OD (4th) | | 0.700 |
| | | Reverse | | 2.333 |
| Final gear ratio | | | | 3.842 |
| Automatic transaxle fluid (ATF) | | Type | DEXRON-II or M-III | |
| | | Capacity liters (US qt, Imp qt) | 6.6 (1.74, 1.45) | |
| Engine stall speed | rpm | D, S, L and R ranges | | 2,550—2,650 |
| Time lag | sec. | N→D range | | 0.5—1.0 |
| | | N→R range | | 0.6—1.0 |
| Line pressure kPa (kg/cm ² , psi) | At idle | D, S and L ranges | | 353—432 (3.6—4.4, 51—63) |
| | | R range | | 598—942 (6.1—9.6, 87—137) |
| | At stall | D, S and L ranges | | 873—1,040 (8.9—10.6, 127—151) |
| | | R range | | 1,668—2,011 (17.0—20.5, 242—292) |
| Throttle pressure kPa (kg/cm ² , psi) | At idle | D range | | 39—88 (0.4—0.9, 6—13) |
| | At stall | D range | | 471—589 (4.8—6.0, 68—85) |
| Oil pump | Cam ring and oil pump cover clearance | mm (in) | Standard | 0.005—0.020 (0.0002—0.0008) |
| | | | Maximum | 0.080 (0.003) |
| | Rotor and oil pump cover clearance | mm (in) | Standard | 0.005—0.020 (0.0002—0.0008) |
| | | | Maximum | 0.030 (0.0012) |
| | Vane and oil pump cover clearance | mm (in) | Standard | 0.015—0.050 (0.0006—0.0020) |
| | | | Maximum | 0.080 (0.003) |
| | Seal pin and oil pump cover clearance | mm (in) | Standard | 0.005—0.020 (0.0002—0.0008) |
| | | | Maximum | 0.060 (0.002) |
| | Vane and rotor groove clearance | mm (in) | Standard | 0.010—0.045 (0.0004—0.0018) |
| | | | Maximum | 0.065 (0.0026) |
| | Sleeve outer diameter | mm (in) | Standard | 28.00 (1.102) |
| | | | | |
| | Rotor bushing in inner diameter | mm (in) | Standard | 28.00 (1.102) |
| | | | Maximum | 28.05 (1.104) |
| Seal pin outer diameter | mm (in) | Standard | 5.00 (0.197) | |
| | | Maximum | 4.90 (0.193) | |
| Guide ring outer diameter | mm (in) | Standard | 57.85 (2.278) | |
| | | Maximum | 57.70 (2.272) | |
| Valve outer diameter | mm (in) | Standard | 12.00 (0.472) | |
| | | Maximum | 11.86 (0.467) | |
| 3-4 clutch | Number of drive/driven plates | | 4/4 | |
| | Drive plate thickness | mm (in) | Standard | 1.6 (0.063) |
| | | | Minimum | 1.4 (0.055) |
| | 3-4 clutch clearance | | mm (in) | 1.3—1.5 (0.051—0.059) |
| | Retaining ring size | | mm (in) | 4.2 (0.165), 4.4 (0.173), 4.6 (0.181), 4.8 (0.189), 5.0 (0.1969), 5.2 (0.2047) |
| Return spring free length | | mm (in) | 33.2 (1.307) | |
| Forward clutch | Number of drive/driven plates | | 3/3 | |
| | Drive plate thickness | mm (in) | Standard | 1.6 (0.063) |
| | | | Minimum | 1.4 (0.055) |
| | Forward clutch clearance | | mm (in) | 1.0—1.2 (0.040—0.047) |
| Retaining ring size | | mm (in) | 5.9 (0.232), 6.1 (0.240), 6.3 (0.248), 6.5 (0.256), 6.7 (0.267), 8.9 (0.350) | |

H. CLUTCH

| Item | Engine/Transaxle Model | | B6 SOHC | BP SOHC | BP DOHC |
|---|------------------------|---------------------|-----------------------------|------------------|------------------|
| | | | F5M-R | | G5M-R |
| Clutch control | | | Hydraulic | | |
| Clutch pedal | | | | | |
| Type | | | Suspended | | |
| Pedal ratio | | | 6.55 | | |
| Full stroke | | mm (in) | 135 (5.32) | | |
| Height (With carpet) | | mm (in) | 196—204 (7.72—8.03) | | |
| Free play | | mm (in) | 5.5—17.4 (0.22—0.69) | | |
| Distance to carpet when clutch fully disengaged | | mm (in) | Minimum | 41.0 (1.61) | |
| Flywheel | | | | | |
| Runout limit | | mm (in) | 0.2 (0.008) | | |
| Clutch disc | | | | | |
| Type | | | Single dry plate | | |
| Runout limit | | mm (in) | 0.7 (0.027) | | |
| Wear limit | | mm (in) | 0.3 (0.012) from rivet head | | |
| Outer diameter | | mm (in) | 190 (7.48) | 200 (7.87) | 215 (8.46) |
| Inner diameter | | mm (in) | 132 (5.20) | 150 (5.91) | |
| Facing thickness | mm (in) | Flywheel side | | 3.5 (0.138) | |
| | | Pressure plate side | | 3.5 (0.138) | 3.8 (0.150) |
| Clutch cover | | | | | |
| Type | | | Diaphragm spring | | |
| Set load | | N (kg, lb) | 3,630 (370, 814) | 3,826 (390, 858) | 3,846 (392, 862) |

J1. MANUAL TRANSAXLE (F5M-R)

| Item | | Engine/Transaxle Model | | B6 SOHC | | BP SOHC | | |
|---|-----------|------------------------|------------|--|--------------------------|--|-------------------------|--|
| | | | | F5M-R | | | | |
| Transmission | | | | | | | | |
| Shift lever position | | | | Floor shift | | | | |
| Gear ratio | First | | | | 3.416 | | | |
| | Second | | | | 1.842 | | | |
| | Third | | | | 1.290 | | | |
| | Fourth | | | | 0.918 | | | |
| | Fifth | | | | 0.731 | | | |
| | Reverse | | | | 3.214 | | | |
| Oil | Grade | | | | API service GL-4 or GL-5 | | | |
| | Viscosity | All season | | | | DEXRON-II, M2C33-F or SAE 75W-90 | | |
| | | Above -18°C (0°F) | | | | SAE 80W-90 | | |
| | Capacity | liters (US qt, Imp qt) | | | | 2.68 (2.83, 2.36) | | |
| Clearance | | | | | | | | |
| Clearance of lever and reverse idler gear | | mm (in) | | Standard | | 0.10—0.32 (0.004—0.013) | | |
| | | | | Wear limit | | 0.37 (0.015) | | |
| Clearance of shift fork and clutch sleeve | mm (in) | | Standard | | 1st—2nd | | 0.10—0.36 (0.004—0.014) | |
| | | | | | 3rd—4th | | 0.20—0.50 (0.008—0.020) | |
| | | | | | 5th—Rev. | | 0.40—0.75 (0.016—0.030) | |
| | mm (in) | | Wear limit | | 1st—2nd | | 0.46 (0.018) | |
| | | | | | 3rd—4th | | 0.60 (0.024) | |
| | | | | | 5th—Rev. | | 0.85 (0.034) | |
| Clearance of synchronizer ring and gear | | mm (in) | | Standard | | 1.12—1.88 (0.044—0.074) | | |
| | | | | Wear limit | | 0.8 (0.032) | | |
| Gear thrust clearance | mm (in) | | First | | Standard | | 0.05—0.28 (0.002—0.011) | |
| | | | | | Limit | | 0.33 (0.013) | |
| | mm (in) | | Second | | Standard | | 0.18—0.51 (0.007—0.020) | |
| | | | | | Limit | | 0.56 (0.022) | |
| | mm (in) | | Third | | Standard | | 0.06—0.21 (0.002—0.008) | |
| | | | | | Limit | | 0.26 (0.010) | |
| | mm (in) | | Fourth | | Standard | | 0.21—0.61 (0.008—0.024) | |
| | | | | | Limit | | 0.66 (0.026) | |
| | mm (in) | | Fifth | | Standard | | 0.06—0.26 (0.002—0.010) | |
| | | | | | Limit | | 0.31 (0.012) | |
| Bearing preload adjust shim | | mm (in) | | Primary shaft | | 0.1 (0.004), 0.2 (0.008), 0.3 (0.012), 0.4 (0.016) | | |
| | | | | Secondary shaft | | 0.15 (0.006), 0.20 (0.008), 0.25 (0.010), 0.30 (0.012), 0.35 (0.014), 0.40 (0.016), 0.45 (0.018), 0.50 (0.020) | | |
| Drive and differential | | | | | | | | |
| Final gear | | Type | | Helical | | | | |
| | | Reduction ratio | | 3.850 : 1 | | 3.619 : 1 | | |
| Bearing preload | | N·m (cm·kg, in·lb) | | 0.33—0.74 (0.3—7.8, 0.26—6.60) | | | | |
| Bearing preload adjust shim | | mm (in) | | 0.20 (0.008), 0.25 (0.010), 0.30 (0.012), 0.35 (0.014), 0.40 (0.016), 0.45 (0.018), 0.50 (0.020), 0.55 (0.022) | | | | |
| Backlash of side gear and pinion gear | | mm (in) | | 0—0.1 (0—0.004) | | | | |

M. FRONT AND REAR AXLES

| Item | | Engine/Transaxle type | BP SOHC | |
|---|-------------------|-----------------------|---------------------|-----|
| | | | MTX | ATX |
| Driveshaft | | | | |
| Joint type | Inside | | Double offset joint | |
| | Outside | | Bell joint | |
| Length of joint (between center of joint) mm (in) | Right | | 689 (27.12) | |
| | Left | | 659 (25.94) | |
| Shaft diameter | mm (in) | | 21.0 (0.82) | |
| Front axle | | | | |
| Bearing play axial direction | mm (in) | | 0.050 (0.002) | |
| Rear axle | | | | |
| Bearing play axial direction | mm (in) | | 0.050 (0.002) | |
| Rear differential | | | | |
| Reduction gear | | Hypoid gear | | |
| Differential gear | | Straight bevel gear | | |
| Differential ratio | | 3.909 | | |
| Number of teeth | Ring gear | | 43 | |
| | Drive pinion gear | | 11 | |
| Fluid | Grade | | API Service GL-5 | |
| | Viscosity | | SAE 90 or 80W | |
| | Capacity | liter (US qt, Imp qt) | 0.65 (0.69, 0.57) | |

N. STEERING SYSTEM

| Item | | POWER STEERING |
|--|--|--------------------------------|
| Steering wheel | | |
| Outer diameter | mm (in) | 370 (14.57) |
| Free play | mm (in) | 0-30 (0-1.18) |
| Operation force | N (kg, lb) | 29 (3.0, 6.6) or less |
| Lock-to-lock | | 2.76 |
| Steering gear | | |
| Type | | Rack and pinion |
| Steering gear ratio | | Infinite (∞) |
| Backlash between rack and pinion mm (in) | | 0 (0) |
| Pinion preload | Nm (cm-kg, in-lb) | 1.0-1.3 (10-14, 8.7-12.1) |
| | Preload measured by torque wrench | |
| Pinion preload | kg (oz) | 1.0-1.4 (35.3-49.4) |
| | Preload measured by pull scale with attachment | |
| Limit of rack housing movement | mm (in) | 1.5 (0.06) |
| Distance between left and right brackets | mm (in) | 258 (10.16) |
| Rack stroke | mm (in) | 121 (4.76) |
| Lubricant type | | ATF: M-III or DEXRON-II |
| Oil capacity | liter (US qt, Imp qt) | 0.8 (0.85, 0.70) |
| Drive belt | N-m (m-kg, ft-lb) | 0.9-1.0 (0.95-1.06, 0.79-0.88) |
| Deflection with force of 98 N (10 kg, 22 lb) | mm (in) | New belt: 8-9 (0.31-0.35) |
| | | Used belt: 9-10 (0.35-0.39) |

P. BRAKING SYSTEM

| Item | | Specifications | |
|---|---|--|-----------------|
| Brake type | | Front disc, Rear disc | |
| Brake pedal | | | |
| Height | mm (in) | 203—206 (7.99—8.11) | |
| Free play | mm (in) | 4—7 (0.16—0.28) | |
| Reserve travel Clearance when pedal depressed at 589 N (60 kg, 132 lb) | mm (in) | 70 (2.76) min | |
| Master cylinder | | | |
| Master cylinder | Type | Tandem | |
| | Bore diameter | mm (in) | 22.22 (0.875) |
| Front disc brake | | | |
| Type | | Ventilated | |
| Thickness of pad | mm (in) | Standard | 10 (0.39) |
| | | Minimum | 2 (0.08) |
| Thickness of disc plate | mm (in) | Standard | 22 (0.87) |
| | | Minimum | 20 (0.79) |
| Runout of disc plate | mm (in) | 0.1 (0.004) | |
| Cylinder bore | mm (in) | 53.97 (2.12) | |
| Rear brake (disc) | | | |
| Type | | Solid | |
| Thickness of pad | mm (in) | Standard | 7.5 (0.30) |
| | | Minimum | 1 (0.04) |
| Thickness of disc plate | mm (in) | Standard | 9 (0.35) |
| | | Minimum | 7 (0.28) |
| Runout of disc plate | mm (in) | 0.1 (0.004) | |
| Cylinder bore | mm (in) | 30.2 (1.19) | |
| Parking brake | | | |
| Type | | Mechanical two-rear-wheel control | |
| Parking brake lever notches When lever is pulled at 98N (10 kg, 22 lb) | | 5—7 | |
| Power brake unit | | | |
| Diameter | mm (in) | 5MTX: 214 (8.43) EC-AT: 239 (9.41) | |
| Fluid pressure per treading force | kPa (kg/cm ² , psi)/N (kg, lb) | 5TX More than 1,177 (12, 171)/196 (20, 44) at 0 mmHg (0 inHg) More than 7,063 (72, 1,024)/196 (20, 44) at 500 mmHg (19.7 inHg) EC-AT More than 1,517 (15, 213)/196 (20, 44) at 0 mmHg (0 inHg) More than 8,593 (88, 1,251)/196 (20, 44) at 500 mmHg (19.7 inHg) | |
| Rear wheel hydraulic control system | | | |
| Type | | Dual proportioning valve | |
| Switching point (Master cylinder pressure) | | kPa (kg/cm ² , psi) | 2,943 (30, 427) |

| Item | | | Model | F4A-EL | | |
|----------------------------------|--|---------|--------------------|--|-----------------------------|---------|
| | | | | B6 SOHC | BP SOHC | BP DOHC |
| Carrier hub | Clearance between pinion washer and planet carrier | mm (in) | Maximum | 0.2—0.7 (0.008—0.028) | | |
| Sun gear drum | Bushing inner diameter | mm (in) | Maximum | 30.425 (1.198) | | |
| Small sun gear | Busing inner diameter | mm (in) | Maximum | 21.021 (0.828) | | |
| Gear assembly | | | | | | |
| Total end play | | | mm (in) | 0.25—0.50 (0.010—0.020) | | |
| End play adjust race | | | mm (in) | 1.2 (0.047), 1.4 (0.055), 1.6 (0.063), 1.8 (0.071), 2.0 (0.079), 2.2 (0.087) | | |
| Idle gear bearing preload | | | N·m (cm·kg, in·lb) | 0.03—0.9 (0.3—9.0, 0.26—7.8) | | |
| Preload adjust shims | | | mm (in) | 3.80 (0.150), 3.85 (0.152), 3.90 (0.154), 3.95 (0.156), 4.00 (0.158), 4.05 (0.159), 4.10 (0.161), 4.15 (0.163), 4.20 (0.165), 4.25 (0.167), 4.30 (0.169), 4.35 (0.171), 4.40 (0.173), 4.45 (0.175), 4.50 (0.177), 4.55 (0.179), 4.60 (0.181), 4.65 (0.183), 4.70 (0.185), 4.75 (0.187) | | |
| Output gear bearing preload | | | N·m (cm·kg, in·lb) | 0.03—0.9 (0.3—9.0, 0.26—7.8) | | |
| Preload adjust shims | | | mm (in) | 0.50 (0.020), 0.55 (0.022), 0.60 (0.024), 0.65 (0.026), 0.70 (0.028), 0.75 (0.030), 0.80 (0.032), 0.85 (0.034), 0.90 (0.035), 0.95 (0.037), 1.00 (0.039), 1.05 (0.041), 1.10 (0.043), 1.15 (0.045), 1.20 (0.047), 1.25 (0.049), 1.30 (0.051), 1.35 (0.053), 1.40 (0.055), 1.45 (0.057) | | |
| Differential | | | | | | |
| Bearing preload | | | N·m (cm·kg, in·lb) | 2.9—3.9 (30—40, 26—35) | | |
| Preload adjust shims | | | mm (in) | 0.50 (0.020), 0.55 (0.022), 0.60 (0.024), 0.65 (0.026), 0.70 (0.028), 0.75 (0.030), 0.80 (0.032), 0.85 (0.034), 0.90 (0.035), 0.95 (0.037), 1.00 (0.039), 1.05 (0.041), 1.10 (0.043), 1.15 (0.045), 1.20 (0.047), 1.25 (0.049), 1.30 (0.051), 1.35 (0.053), 1.40 (0.055), 1.45 (0.057) | | |
| Backlash of side gear and pinion | | | mm (in) | Standard | 0.025—0.1 (0.001—0.004) | |
| | | | | Maximum | 0.5 (0.020) | |
| Torque converter | | | | | | |
| Bushing inner diameter | | | mm (in) | Standard | 53.030—53.075 (2.088—2.090) | |
| | | | | Maximum | 53.075 (2.090) | |

Spring Specification

| Spring name | | | Outer diameter mm (in) | Free length mm (in) | No. of coil | Wire diameter mm (in) |
|----------------------------|---------------------------|-------------|---------------------------|------------------------|-------------|--------------------------|
| Upper control valve body | Throttle modulator spring | | 8.1 (0.319) | 44.4 (1.748) | 10.5 | 0.8 (0.032) |
| | Throttle spring | | 5.4 (0.231) | 44.5 (1.752) | 24.6 | 0.9 (0.035) |
| | Throttle assist spring | | 5.15 (0.203) | 26.88 (1.058) | 16.2 | 0.6 (0.024) |
| Main control valve body | Pressure regulator spring | | 11.5 (0.453) | 34.2 (1.346) | 9.5 | 1.0 (0.039) |
| | 1-2 shift spring | | 7.4 (0.291) | 36.6 (1.441) | 12.0 | 0.8 (0.032) |
| | Low reducing spring | | 7.9 (0.311) | 34.5 (1.358) | 11.0 | 0.8 (0.032) |
| | 2-3 timing spring | | 8.0 (0.315) | 27.84 (1.096) | 10.0 | 0.8 (0.032) |
| | 3-2 timing spring | | 8.0 (0.315) | 29.98 (1.180) | 10.0 | 0.8 (0.032) |
| | 3-4 shift spring | | 7.4 (0.291) | 36.6 (1.441) | 12.0 | 0.8 (0.032) |
| Premain control valve body | Bypass spring | B6 SOHC | 4.9 (0.193) | 27.6 (1.087) | 23.0 | 0.55 (0.022) |
| | | BP SOHC | 4.9 (0.193) | 30.5 (1.201) | 23.0 | 0.55 (0.022) |
| | | BP DOHC | 4.9 (0.193) | 30.5 (1.201) | 23.0 | 0.55 (0.022) |
| | 2-3 shift spring | | 7.4 (0.291) | 36.6 (1.441) | 12.0 | 0.8 (0.032) |
| | Converter relief spring | | 8.6 (0.339) | 68.4 (2.693) | 27.5 | 1.2 (0.047) |
| Lockup control spring | | 5.0 (0.197) | 35.2 (1.386) | 19.0 | 0.6 (0.024) | |
| Control valve body | Throttle relief spring | | 6.6 (0.260) | 21.6 (0.850) | 11.5 | 0.8 (0.032) |
| Oil pump | Spring | | 13.0 (0.512) | 53.0 (2.087) | 12.0 | 1.2 (0.047) |

| Spring name | | | Outer diameter mm (in) | Free length mm (in) | No. of coil | Wire diameter mm (in) | |
|------------------------------|---------------------------------|--------------------|---------------------------|------------------------|--------------|--------------------------|-------------|
| Accumulator | 2-3 accumulator small spring | BP DOHC | 11.6 (0.457) | 59.7 (2.350) | 16.9 | 1.8 (0.071) | |
| | | B6 SOHC BP SOHC | 10.0 (0.394) | 71.8 (2.827) | 24.2 | 1.4 (0.055) | |
| | 2-3 accumulator large spring | BP DOHC | 15.0 (0.591) | 71.8 (2.827) | 9.8 | 1.2 (0.047) | |
| | | B6 SOHC BP SOHC | 15.0 (0.591) | 71.8 (2.827) | 15.8 | 2.0 (0.079) | |
| | 1-2 accumulator small spring | | | — | — | — | — |
| | 1-2 accumulator large spring | BP DOHC | 16.0 (0.630) | 79.0 (3.110) | 17.2 | 2.1 (0.083) | |
| | | B6 SOHC BP SOHC | 16.0 (0.630) | 87.8 (3.457) | 18.2 | 2.0 (0.079) | |
| | N-D Accumulator small spring | B6 SOHC | 10.5 (0.413) | 61.4 (2.417) | 15.0 | 1.0 (0.039) | |
| | | BP SOHC BP DOHC | 10.5 (0.413) | 53.6 (2.110) | 16.7 | 1.0 (0.039) | |
| | N-D Accumulator large spring | B6 SOHC | 14.7 (0.579) | 61.4 (2.417) | 12.9 | 1.5 (0.059) | |
| | | BP SOHC BP DOHC | 14.7 (0.579) | 53.6 (2.110) | 11.7 | 1.6 (0.063) | |
| | N-R Accumulator small spring | | | 9.8 (0.386) | 93.2 (3.669) | 31.5 | 1.3 (0.051) |
| N-R Accumulator large spring | | | 14.0 (0.551) | 106.5 (4.193) | 23.0 | 1.7 (0.067) | |
| 3-4 clutch | Return spring | | 74.4 (2.929) | 40.5 (1.594) | 1.0 | 5.0 (0.197) | |
| Coasting clutch | Return spring | | 7.3 (0.287) | 20.45 (0.805) | 10.0 | 1.0 (0.039) | |
| Low and reverse brake | Return spring | | 5.55 (0.219) | 14.3 (0.563) | 12.0 | 0.75 (0.030) | |
| Servo | Return spring | | 27.7 (1.091) | 43.25 (1.703) | 4.5 | 3.2 (0.126) | |

Vehicle Speed at Shiftpoint Table

| Mode | Range | Throttle condition (Throttle sensor voltage) | Shift | Drum speed rpm | | | Vehicle speed km/h (mph) | | |
|--------|-------|--|---------------------|----------------|-------------|-------------|--------------------------|-------------------|-------------------|
| | | | | B6 SOHC | BP SOHC | BP DOHC | B6 SOHC | BP SOHC | BP DOHC |
| NORMAL | D | Fully opened (4.0 volt) | D1 → D2 | 5,150—5,700 | 5,150—5,700 | 5,850—6,400 | 52—58 (32—36) | 56—62 (35—38) | 59—65 (37—40) |
| | | | D2 → D3 | 4,850—5,300 | 4,850—5,250 | 5,350—5,800 | 92—100 (57—62) | 99—107 (61—66) | 101—109 (63—68) |
| | | | D3 → OD | 5,500—5,850 | 5,500—5,850 | 5,950—6,300 | 158—166 (97—103) | 168—178 (104—110) | 167—177 (104—110) |
| | | Half throttle (1.6—2.2 volt) | D1 → D2 | 2,550—3,150 | 3,000—3,550 | 3,450—4,050 | 26—32 (16—20) | 33—39 (20—24) | 35—41 (22—25) |
| | | | D2 → D3 | 2,500—3,150 | 3,100—3,700 | 3,700—4,350 | 48—60 (30—37) | 63—75 (39—47) | 70—82 (43—51) |
| | | | D3 → OD | 2,750—3,350 | 3,400—4,000 | 4,200—4,750 | 78—96 (48—60) | 104—122 (64—76) | 119—137 (74—85) |
| | | | Lock-up ON (OD) | 1,900—2,350 | 2,350—2,800 | 2,950—3,400 | 78—96 (48—60) | 104—122 (64—76) | 119—137 (74—85) |
| | | Kickdown | Lock-up OFF (OD) | 1,850—2,050 | 2,150—2,350 | 2,400—2,600 | 76—84 (47—52) | 94—102 (58—63) | 97—105 (60—65) |
| | | | OD → D3 | 3,600—3,750 | 3,500—3,700 | 3,850—4,100 | 142—152 (88—94) | 153—163 (95—101) | 155—165 (96—102) |
| | | | OD → D2 | 2,000—2,200 | 2,000—2,200 | 2,300—2,500 | 82—90 (51—56) | 88—96 (55—60) | 94—102 (58—63) |
| | | | OD → D1 | 1,000—1,150 | 950—1,100 | 1,250—1,400 | 42—48 (26—30) | 42—48 (26—30) | 52—58 (32—36) |
| | | | D3 → D2 | 2,900—3,150 | 2,850—3,150 | 3,350—3,600 | 82—90 (51—56) | 88—96 (55—60) | 94—102 (58—63) |
| | S | Fully opened (4.0 volt) | D3 → D1 | 1,450—1,650 | 1,350—1,550 | 1,850—2,050 | 42—48 (26—30) | 42—48 (26—30) | 52—58 (32—36) |
| | | | D2 → D1 | 2,200—2,500 | 2,050—2,350 | 2,750—3,100 | 42—48 (26—30) | 42—48 (26—30) | 52—58 (32—36) |
| | | | S1 → S2 | 5,150—5,750 | 5,150—5,700 | 5,850—6,450 | 52—58 (32—36) | 56—62 (35—38) | 59—65 (37—40) |
| | | | S2 → S3 | 4,850—5,300 | 4,850—5,250 | 5,400—5,800 | 92—100 (57—62) | 99—107 (61—66) | 101—109 (63—68) |
| | | Half throttle (1.6—2.2 volt) | S3 → S2 | 2,900—3,150 | 2,850—3,150 | 3,350—3,600 | 82—90 (51—56) | 88—96 (55—60) | 94—102 (58—63) |
| | | | S2 → S1 | 2,200—2,500 | 2,050—2,350 | 2,750—3,100 | 42—48 (26—30) | 42—48 (26—30) | 52—58 (32—36) |
| | L | Fully opened (4.0 volt) | S1 → S2 | 2,550—3,150 | 3,000—3,550 | 3,450—4,050 | 26—32 (16—20) | 33—39 (20—24) | 35—41 (22—25) |
| | | | S2 → S3 | 2,500—3,150 | 3,100—3,700 | 3,700—4,350 | 48—60 (30—37) | 63—75 (39—47) | 70—82 (43—51) |
| | | Half throttle (1.6—2.2 volt) | L1 → L2 | 5,150—5,750 | 5,150—5,700 | 5,850—6,450 | 52—58 (32—36) | 56—62 (35—38) | 59—65 (37—40) |
| | | | L2 → L1 | 2,200—2,500 | 2,050—2,350 | 2,800—3,100 | 42—48 (26—30) | 42—48 (26—30) | 52—58 (32—36) |

| Mode | Range | Throttle condition (Throttle sensor voltage) | Shift | Drum speed rpm | | | Vehicle speed km/h (mph) | | | |
|-------------|----------|---|---------|----------------|-------------|-------------|--------------------------|----------------|-----------------|--|
| | | | | B6 SOHC | BP SOHC | BP DOHC | B6 SOHC | BP SOHC | BP DOHC | |
| HOLD | D | Fully opened (4.0 volt) | D1 → D2 | 2,650—3,250 | 2,450—3,000 | 2,650—3,250 | 27—33 (17—20) | | | |
| | | | D2 → D3 | 2,100—2,650 | 1,950—2,450 | 2,100—2,650 | 40—50 (25—31) | | | |
| | | | D3 → D1 | 300—500 | 250—450 | 400—600 | 9—15 (6—9) | 12—18 (7—11) | | |
| | S | Fully closed (0.5 volt) | S3 → S2 | 3,200—3,400 | 3,200—3,400 | 3,550—3,750 | 91—97 (56—60) | 98—104 (61—64) | 100—106 (62—66) | |
| | | | L | L2 → L1 | 2,250—2,600 | 2,100—2,400 | 2,250—2,600 | 43—49 (27—30) | | |

M. FRONT AND REAR AXLES

| Item | Engine/Transaxle type | B6 SOHC | | BP SOHC | | BP DOHC | |
|--|-----------------------|---------------|---------------|---------------|---------------|---------|-----|
| | | MTX | ATX | MTX | ATX | MTX | ATX |
| Driveshaft | | | | | | | |
| Joint type | Inside | Tripod joint | | | | | |
| | Outside | Ball joint | | | | | |
| Length of joint (between center of joint) mm (in) | Right | 662.0 (22.06) | 668.5 (23.32) | 427.5 (16.83) | | | |
| | Left | 383.5 (15.10) | 382.5 (15.06) | 365.5 (14.39) | 385.0 (15.16) | | |
| Shaft diameter | | 21.5 (0.85) | 23.0 (0.91) | | | | |
| Front axle | | | | | | | |
| Bearing play axial direction | mm (in) | 0.050 (0.002) | | | | | |
| Rear axle | | | | | | | |
| Bearing play axial direction | mm (in) | 0.050 (0.002) | | | | | |

N. STEERING SYSTEM

| Item | Specifications |
|--|--|
| Steering wheel | |
| Outer diameter | mm (in) 370 (14.57) |
| Free play | mm (in) 0—30 (0—1.18) |
| Operation force | N (kg, lb) M/S : 108 (11, 24.2) or less P/S : 29 (3.0, 6.6) or less |
| Lock-to-lock | M/S : 4.3 P/S : 3.0 |
| Max. steering angle | Inner 40°00' ± 2° |
| | Outer 33°00' ± 2° |
| Steering gear | |
| Type | Rack and pinion |
| Steering gear ratio | Infinite (∞) |
| Backlash between rack and pinion | mm (in) 0 (0) |
| Pinion preload | N·m (cm·kg, in·lb) M/S : 1.0—1.4 (10—14, 8.68—12.15) P/S : 1.0—1.2 (10—12, 8.68—10.42) |
| | g (oz) M/S : 1,000—1,400 (35.3—49.4) P/S : 1,000—1,200 (35.3—42.36) |
| Limit of rack housing movement | mm (in) 1.5 (0.06) |
| Distance between left and right brackets | mm (in) 298.5 (11.75) |
| Rack stroke | mm (in) 140 (5.51) |
| Lubricant type (power steering) | ATF: M-III or DEXRON-II |
| Oil capacity (power steering) | liter (US qt, Imp qt) 0.8 (0.85, 0.70) |
| Drive belt | |
| Deflection with force of 98 N (10 kg, 22 lb) | mm (in) New belt: 8—9 (0.31—0.35) Used belt: 9—10 (0.35—0.39) |

P. BRAKING SYSTEM

| Item | | Specifications | |
|--|---------------|---|---------------|
| Brake type | | Front disc, Rear disc or drum | |
| Brake pedal | | | |
| Height | mm (in) | 193—196 (7.60—7.72) | |
| Free play | mm (in) | 4—7 (0.16—0.28) | |
| Reserve travel Clearance when pedal depressed at 589 N (60 kg, 132 lb) | mm (in) | 70 (2.76) min | |
| Master cylinder | | | |
| Master cylinder | Type | Tandem | |
| | Bore diameter | mm (in) | 22.22 (0.875) |
| Front disc brake | | | |
| Type | | Ventilated | |
| Thickness of pad | mm (in) | Standard | 10 (0.39) |
| | | Minimum | 2 (0.08) |
| Thickness of disc plate | mm (in) | Standard | 22 (0.87) |
| | | Minimum | 20 (0.79) |
| Runout of disc plate | mm (in) | 0.1 (0.004) | |
| Cylinder bore | mm (in) | 53.97 (2.12) | |
| Rear brake (disc) | | | |
| Type | | Solid | |
| Thickness of pad | mm (in) | Standard | 7.5 (0.30) |
| | | Minimum | 1 (0.04) |
| Thickness of disc plate | mm (in) | Standard | 9 (0.35) |
| | | Minimum | 7 (0.28) |
| Runout of disc plate | mm (in) | 0.1 (0.004) | |
| Cylinder bore | mm (in) | 30.2 (1.19) | |
| Rear brake (drum) | | | |
| Type | | Leading & trailing | |
| Thickness of lining | mm (in) | Standard | 4.5 (0.18) |
| | | Minimum | 1 (0.04) |
| Drum inside diameter | mm (in) | Standard | 228.6 (9.0) |
| | | Minimum | 229.6 (9.04) |
| Wheel cylinder bore | mm (in) | 17.46 (0.687) | |
| Parking brake | | | |
| Type | | Mechanical two-rear-wheel control | |
| Parking brake lever notches When lever is pulled at 98N (10 kg, 22 lb) | | 5—7 | |
| Power brake unit | | | |
| Diameter | mm (in) | (a): 214 (8.43) (b): 239 (9.41) | |
| Fluid pressure per treading force kPa (kg/cm ² , psi)/N (kg, lb) | | More than 1,177 (12, 171)/196 (20, 44) at 0 mmHg (0 inHg) More than 7,063 (72, 1,024)/196 (20, 44) at 500 mmHg (19.7 inHg) | |
| Rear wheel hydraulic control system | | | |
| Type | | Dual proportioning valve | |
| Switching point (Master cylinder pressure) | | kPa (kg/cm ² , psi) 2,453 (25, 356) | |

(a): BP engine with 5MTX, B6 engine

(b): BP engine with EC-AT

Q. WHEELS AND TIRES

| Item | | Specifications | |
|--------------------------|--------------------------------|--|--|
| Wheel | | | |
| Size | | Standard: 5-Jx13, 5 1/2-JJx14 Temporary spare: 4-Tx14 | |
| Offset | mm (in) | Standard: 45 (1.77) Temporary spare: 45 (1.77) | |
| Diameter of pitch circle | mm (in) | 100 (3.94) | |
| Tire | | | |
| Size | | Standard: 155/80R13, 175/70R13, 185/60R14 Temporary spare: T115/70D14 | |
| Inflation pressure | kPa (kg/cm ² , psi) | Front | Standard: 216 (2.2, 31) Temporary spare: 415 (4.2, 60) |
| | | Rear | Standard: 216 (2.2, 31) Temporary spare: 415 (4.2, 60) |
| Wheel and tire | | | |
| Runout limit | mm (in) | Horizontal | 2.0 (0.079) |
| | | Vertical | 1.5 (0.059) |
| Unbalance limit | | g (oz) | 20 (0.71) |

R. SUSPENSION

| Item | | | Specifications | |
|---|---------------------|------------------------|-------------------------------------|---------------------|
| Suspension type | | | | |
| Shock absorber | Suspension | | Double-acting, oil-filled | |
| Coil spring | Type | Front | Taper wound | |
| | | Rear | Straight wound | |
| | Dimension | | See coil spring specification below | |
| Stabilizer | Type | | Torsion bar | |
| | Diameter mm (in) | BP SOHC | Front | 19.1 (0.75) |
| | | | Rear | 20.0 (0.79) |
| | | BP DOHC | Front | 22.0 (0.87) |
| | | | Rear | 20.0 (0.79) |
| | | B6 | Front | — |
| Rear | | | 20.0 (0.79) | |
| Wheel alignment (* ¹ Unladen) | Front | Maximum steering angle | Inner | 40° ± 2° |
| | | | Outer | 33° ± 2° |
| | | Total toe-in | mm (in) | 2 ± 3 (0.08 ± 0.12) |
| | | | degree | 0.2° ± 0.3° |
| | | Camber angle | | -0°05' ± 45' |
| | | Caster angle | | 2°05' ± 45' |
| | Kingpin angle | | 12°25' | |
| | Rear | Total toe-in | mm (in) | 2 ± 3 (0.08 ± 0.12) |
| | | | degree | 0.2° ± 3° |
| Camber angle | | -0°20' ± 45' | | |

*¹ Fuel tank full; radiator coolant and engine oil at specified level; and spare tire, jack, and tools in designated positions.

Coil Spring Specifications

| Item | Wire diameter mm (in) | Coil outer diameter mm (in) | Free length mm (in) | Coil number | Identification mark color | | |
|-------|-----------------------|-----------------------------|---------------------|-------------|---------------------------|-----------------|--------|
| | | | | | M* ¹ | A* ² | |
| Front | A | 12.7 (0.5) | 133-159 (5.24-6.26) | 293 (11.54) | 3.1 | Pink | Yellow |
| | B | 12.9 (0.51) | 133-159 (5.24-6.26) | 294 (11.57) | 3.2 | Light green | Yellow |
| | C | 13.2 (0.52) | 133-159 (5.24-6.26) | 300 (11.81) | 3.4 | Purple | Yellow |
| | D | 13.3 (0.52) | 132-158 (5.20-6.22) | 301 (11.85) | 3.4 | Light blue | Yellow |
| | E | 13.3 (0.52) | 132-158 (5.20-6.22) | 286 (11.26) | 3.2 | Orange | Red |
| | F | 13.4 (0.53) | 133-159 (5.24-6.26) | 287 (11.3) | 3.3 | Cream | Red |
| Rear | G | 11.6 (0.46) | 140 (5.51) | 334 (13.15) | 4.6 | Brown | — |
| | H | 11.9 (0.47) | | 333 (13.11) | 4.7 | Gray | — |
| | I | 12.1 (0.48) | | 332 (13.07) | 4.8 | Orange | — |
| | J | 11.7 (0.46) | | 333 (13.11) | 4.5 | Blue | — |
| | K | 12.3 (0.48) | | 332 (13.07) | 4.9 | Blue & White | — |
| | L | 12.5 (0.49) | | 331 (13.03) | 5.1 | Blue & Green | — |

*1 Main identification mark color: Indicated on second coil from bottom.

*2 Auxiliary identification mark color: Indicated on third coil from bottom.

T. BODY ELECTRICAL SYSTEM

| Item | | Specification (W) (Bulb Trade number) |
|-----------------------------|---------------------------------|---------------------------------------|
| Exterior lamps | Headlight | 65/45 (9004) |
| | Front turn signal/Parking light | 27/8 (1157) |
| | Stop/Taillight | 27/8 (1157) |
| | High mount stoplight | 18.4 (1141) |
| | Rear turn single light | 27 (1156) |
| | Back-up light | 27 (1156) |
| | Rear side marker light (Sedan) | 3.8 (194) |
| | License plate light | 7.5 (89) [Sedan], 5 (168) [3HB] |
| Interior lamps | Interior and spot lamp | Interior 10 Spot 6 |
| | Interior lamp | 10 |
| | Spot lamp (in overhead console) | 8 (67) |
| | Cargo room lamp | 5 (168) |
| | Trunk room lamp | 5 (168) |
| Indicator and warning lamps | High beam | 3.4 |
| | Turn light | 3.4 |
| | Brake | 3 |
| | Hold | 3 (158) |
| | Charge | 3 (158) |
| | Oil pressure | 3 (158) |
| | Washer | 3 (158) |
| | Seat belt | 3 (158) |
| | Malfunction | 3 (158) |
| | Fuel | 3 (158) |
| Illumination | 3.4 | |

SPECIAL TOOLS

| | |
|---|-------|
| GENERAL INFORMATION | ST- 2 |
| ENGINE..... | ST- 3 |
| CLUTCH AND MANUAL TRANSAXLE..... | ST- 4 |
| AUTOMATIC TRANSAXLE..... | ST- 6 |
| DIFFERENTIAL | ST- 6 |
| FRONT AND REAR AXLES..... | ST- 7 |
| STEERING SYSTEM | ST- 8 |
| BRAKING SYSTEM..... | ST- 9 |
| FRONT AND REAR SUSPENSIONS | ST-10 |
| HEATER AND AIR CONDITIONER SYSTEMS | ST-10 |
| CHECKER AND OTHER EQUIPMENT..... | ST-10 |

03USTX-801

GENERAL INFORMATION

The letters A and B in the priority column indicate the degree of importance of each tool.

A.....Indispensable

The tools ranked A in this list are indispensable for performing operations satisfactorily, easily, safely, and efficiently. It is, therefore advisable that all service shops have these tools.

B.....Selective









The tools in this list are not as necessary as tools ranked A, but all service shops should have these tools to perform repairs more easily and more efficiently.








Note

- **When ordering tool sets that consist of several tools, check the List in the Parts Catalogue to make sure that some tools are not duplicated in other sets you may already have. If they are, instead of ordering the set, order only those new tools that are needed.**
- **There are new SST explanations in this tool chart.
These tools are indicated by "NEW SST" in description column.**









03USTX-002









ENGINE

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 0107 680A Engine stand | A |  |
| 49 L010 1A0 Hanger set, engine stand | A |  |
| 49 0636 100A Arm, valve spring lifter | A |  |
| 49 B012 006 Pivot | A |  |
| 49 B012 005 Remover & installer, valve guide | A |  |
| 49 9200 145 Adapter set, radiator cap tester | A |  |
| 49 9200 020 Tension gauge, V-ribbed belt | B |  |
| 49 L012 0A0 Installer set, valve seal & valve guide | A |  |







| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0187 280 Oil pressure gauge | B |  |
| 49 H011 001A Support block head | A |  |
| 49 L011 0A0 Setting tool set, piston pin | A |  |
| 49 B011 102 Lock tool, crankshaft | A |  |
| 49 S120 710 Holder, coupling flange | A |  |
| 49 E301 060 Brake, ring gear | A |  |
| 49 1285 071 Puller, needle bearing | A |  |
| — | — | — |







CLUTCH AND MANUAL TRANSAXLE

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 G017 5A0 Engine support | A |  |
| 49 SE01 310 Clutch disc centering tool | A |  |
| 49 G019 0A0 Hanger, transaxle | A |  |
| 49 G026 103 Support block | A |  |
| 49 G030 370 Removing plate | A |  |
| 49 G030 380C Shim selector set | A |  |
| 49 0839 425C Puller set, bearing | A |  |
| 49 G030 795 Installer, oil seal | A |  |







| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0636 145 Puller, fan pulley boss | A |  |
| 49 G030 440 Holder, primary shaft | A |  |
| 49 H028 202 Block L | A |  |
| 49 U027 003 Installer, oil seal | A |  |
| 49 B027 001 Holder, differential side gear | A |  |
| 49 F401 330B Installer set, bearing | A |  |
| 49 F401 366A Plate | A |  |
| 49 B092 373 Attachment G | A |  |







CLUTCH AND MANUAL TRANSAXLE (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0710 520 Puller bearing | A |  |
| 49 W032 2A0 Remover, bearing NEW SST | A |  |
| 49 M005 561 Hanger, differential carrier | A |  |
| 49 B027 002 Preload adapter | A |  |
| 49 G030 338 Attachment E | A |  |
| 49 B017 102 Preload adapter | A |  |


| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 B027 003 Attachment M | A |  |
| 49 B092 374 Attachment H | A |  |
| 49 0259 720 Wrench, differential side bearing adjust nut | B |  |
| 49 0727 570 Gauge body, pinion height adjust | A |  |
| 49 8531 555 Gauge block | A |  |
| 49 8531 565 Pinion model | A |  |


AUTOMATIC TRANSAXLE

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 G019 0A5A Shim selector set | A |  |
| 49 G019 011 Installer, bearing | A |  |
| 49 FT01 439 Holder, idle gear shaft | A |  |
| 49 G019 013 Remover, bearing | A |  |
| 49 G019 022 Attachment K | A |  |
| 49 G019 0A2 Holder, turbine shaft | A |  |



| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 G019 012 Leak checker | A |  |
| 49 G019 017 Installer, oil seal | A |  |
| 49 S120 785 Installer, dust boot | A |  |
| 49 G019 0A7A Compressor set, return spring | A |  |
| 49 B019 901 Gauge, oil pressure | A |  |
| 49 0378 400A Gauge set, oil pressure | A |  |


DIFFERENTIAL

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|----------------------------|----------|---|
| 49 N027 001 Gauge block | A |  |





| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---------------------------------|----------|---|
| 49 H033 101 Remover, bearing | A |  |





DIFFERENTIAL (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|------------------------------------|----------|---|
| 49 B001 795 Installer, oil seal | A |  |
| 49 H027 002 Remover, bearing | A |  |









| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|-------------------------------------|----------|---|
| 49 F027 005 Attachment $\phi 62$ | A |  |
| — | — | — |









FRONT AND REAR AXLES

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 F027 007 Attachment $\phi 72$ | A |  |
| 49 G030 727 Attachment A | A |  |
| 49 H034 201 Support block | A |  |
| 49 F027 009 Attachment $\phi 68$ and 77 | A |  |





| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|------------------------------------|----------|---|
| 49 V001 795 Installer, oil seal | A |  |
| 49 G033 102 Handle | A |  |
| 49 F026 103 Puller, wheel hub | A |  |
| 49 F026 102 Installer, bearing | A |  |





STEERING SYSTEM

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0118 850C Puller, ball joint | B |  |
| 49 H002 671 Adapter | A |  |
| 49 B032 323 Remover body, rod seal NEW SST | A |  |
| 49 B032 309 Installer body, pinion seal | A |  |
| 49 B032 306 Wrench, plug | A |  |
| 49 B032 327 Wrench, outer box NEW SST | A |  |
| 49 B032 310 Protector, pinion seal | A |  |
| 49 B032 311 Protector, slipper seal | A |  |




| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 1232 670A Gauge set, power steering | A |  |
| 49 B032 304 Adapter | A |  |
| 49 B032 314 Slipper seal former | A |  |
| 49 B032 315 Installer, oil seal | A |  |
| 49 B032 316 Support block, plug | A |  |
| 49 B032 325 Guide, rod seal | A |  |
| 49 B032 320 Wrench | A |  |
| 49 F032 303 Handle | A |  |



STEERING SYSTEM (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 B032 324 Protector body, rod seal NEW SST | A |  |
| 49 B032 321 Adapter | A |  |
| 49 B032 312 Protector, slipper seal | A |  |
| 49 B032 326 Protector, outer box NEW SST | A |  |




| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|--|
| 49 G032 317 House | A |  |
| 49 B032 305 Holder, power steering pump | A |  |
| 49 H032 301 Wrench | A |  |
| 49 B032 317 Remover, bearing & oil seal NEW SST | B |  |




BRAKE SYSTEM

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 0259 770B Wrench, flare nut | A |  |
| 49 F043 001 Adjust gauge | A |  |
| 49 FA18 602 Wrench disc, brake piston | B |  |


| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0221 600C Expand tool, disc brake | B |  |
| 49 B043 002 Installer, bearing | A |  |
| — | — | — |

FRONT AND REAR SUSPENSIONS

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|-------------------------------------|----------|---|
| 49 1243 785 Installer, dust boot | A |  |
| 49 8038 785 Installer, dust boot | A |  |
| 49 0180 510B Preload attachment | B |  |



| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 G034 1A0 Compressor, coil spring | A |  |
| 49 0208 701A Air out tool, boot | B |  |
| 49 B034 2A0 Replacer, rubber bush | A |  |



HEATER AND AIR CONDITIONER SYSTEMS

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|-------------------------------------|----------|---|
| 49 B061 005 Replacer, seal plate | A |  |








| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---------------------------|----------|--------------|
| — | — | — |







CHECKER AND OTHER EQUIPMENT

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0839 285 Checker, fuel & thermometer | A |  |
| 49 0259 866A Inserting tool, seal pusher & blade | B |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 B019 905 Panel (EC-AT tester) | A |  |
| 49 F019 901 Adapter harness (EC-AT tester) | A |  |

CHECKER AND OTHER EQUIPMENT (CONT'D)


| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0305 870A Tool set, window | A |  |
| 49 G019 901A EC-AT tester | A |  |
| 49 B019 9A1 EC-AT selector (EC-AT tester) | A |  |
| 49 G019 901 EC-AT tester | A |  |
| 49 H019 902 Adapter unit (EC-AT tester) | A |  |
| 49 B019 904 Panel (EC-AT tester) | A |  |
| 49 N018 001 Adapter harness (igniter checker) | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 9200 162 Monitor, engine signal | A |  |
| 49 G018 903 Adapter harness (Engine signal monitor) | A |  |
| 49 G018 904 Sheet (Engine signal monitor) | A |  |
| 49 H018 9A1 Checker, self-diagnosis | A |  |
| 49 B019 9A0 System selector (Self-diagnosis checker) | A |  |
| 49 F018 002 Igniter checker | A |  |
| — | — | — |



Mazda 323 2WD & 4WD

1990
Wiring Diagram



MAZDA

323 2WD & 4WD Wiring Diagram

- HOW TO USE THIS WIRING DIAGRAM
- SYMBOLS IN THIS WIRING DIAGRAM
- HOW TO READ ELECTRIC PARTS

Z-3

- CIRCUIT DIAGRAM

Z-12

- PARTS LOCATION
- HARNESS DIAGRAM

Z-126

FOREWORD

This wiring diagram incorporates the wiring schematic for the basic vehicle and its available optional equipment. Actual vehicle wiring may vary slightly depending upon optional equipment and/or local specifications. All information contained in this booklet is based on the latest information available at the time of printing. Mazda Motor Corporation reserves the right to make changes without previous notice.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

This manual is applicable from the following Vehicle Identification Numbers (VIN).

| 4 DOOR SEDAN | 4WD |
|----------------------|----------------------|
| JM1 BG223*LO 100001~ | JM1 BG227*LO 100001~ |
| JM1 BG224*LO 100001~ | JM1 BG228*LO 100001~ |
| JM1 BG225*LO 100001~ | |
| JM1 BG226*LO 100001~ | |

3 DOOR HATCHBACK
JM1 BG231*LO 100001~
JM1 BG232*LO 100001~
JM1 BG233*LO 100001~
JM1 BG234*LO 100001~

© 1989 Mazda Motor Corporation
PRINTED IN JAPAN JUL '89 ®
5145-10-89G

Note:

This wiring diagram includes 1990 2WD and 4WD models and supersedes 1990 323 Wiring Diagram (5128-10-89E, 9999-95-019G-90).

SYSTEM INDEX

| SYSTEM | PAGE | SYSTEM | PAGE |
|--------------------------------------|-------|---|-------|
| AUDIO | Z-122 | INTERIOR & SPOT LAMPS | Z- 98 |
| BACK-UP LIGHTS | Z- 86 | JOINT BOX | Z-125 |
| CARGO ROOM LAMP | Z-100 | JOINT CONNECTOR & GROUND CIRCUIT | Z-134 |
| LENER DIF-LOCK SYSTEM(4WD)..... | Z-118 | LICENSE PLATE LIGHTS | Z- 74 |
| CHARGING SYSTEM | Z- 16 | METER & WARNING LAMPS | Z- 58 |
| CIGARETTE LIGHTER | Z-102 | PARTS INDEX | Z- 10 |
| COOLING FAN SYSTEM | Z- 50 | PARTS LOCATION | Z-126 |
| CRUISE CONTROL SYSTEM | Z-116 | PASSIVE SHOULDER BELT CONTROL SYSTEM | Z-112 |
| DAYTIME RUNNING LIGHTS | Z- 72 | POWER DOOR LOCK | Z-104 |
| DIGITAL CLOK | Z-102 | POWER SYSTEM | Z- 12 |
| EC-AT CONTROL SYSTEM | Z- 54 | POWER WINDOW | Z-108 |
| ELECTRICAL WIRING SCHEMATIC | Z- 14 | REAR WINDOW DEFROSTER | Z-102 |
| ENGINE CONTROL SYSTEM | Z- 18 | REAR WIPER & WASHER | Z- 66 |
| FRONT WIPER & WASHER | Z- 62 | REMOTE CONTROL MIRROR | Z-106 |
| HARNESS DIAGRAM | Z-127 | SHIFT LOCK SYSTEM | Z- 84 |
| HEADLIGHTS | Z- 68 | SIDE MARKER LIGHTS | Z- 74 |
| HEATER & AIR CONDITIONER | Z- 90 | SLIDING SUNROOF | Z-120 |
| HORN | Z- 86 | SOUND WARNING SYSTEM | Z- 98 |
| HOW TO READ ELECTRIC PARTS | Z- 8 | STARTING SYSTEM | Z- 16 |
| HOW TO USE THIS WIRING DIAGRAM | Z- 3 | STOP LIGHTS | Z- 84 |
| IGNITION KEY CYLINDER LAMP | Z- 98 | TAIL LIGHTS | Z- 74 |
| ILLUMINATION LAMPS | Z- 78 | TURN & HAZARD FLASHER LIGHTS | Z- 82 |
| INTER CONNECTING OF JOINT BOX | Z-124 | | |

The Way to View a Wiring Diagram

This Wiring Diagram is made up of circuit diagrams, connector diagrams, location diagrams, and harness diagrams.


The circuit diagrams are divided according to each system, and by using them, the wiring of each system's circuit can be understood.

Connector diagrams and location diagrams are divided according to vehicle harness, and the location diagrams are designed so that the connector locations and the circuit's course in the vehicle harnesses can be understood.

From the connector diagrams the connector shape and the arrangement of the pins used in the circuit diagrams can be understood.


In the circuit diagrams and the location diagrams, the different kinds of harnesses are colored differently, which makes easy distinguishing.

The harness diagrams on the last page can be understood to indicate the connector shape for each harness, the wiring color, and each part and each turning point in the vehicle.




Circuit Diagram
Designed so that operation of electrical parts and the layout of the wiring may be understood.

Connector Diagram
Lists the connectors that are used in the circuit on the left page. As a rule, it shows the connectors on the harness side.



Location Diagram
This page illustrates the actual location of each connector and the routing diagram of the harness.





Harness Diagram
Indicate the connectors used in the circuit diagrams, arranging them according to each different kind of harness.

Z HOW TO USE THIS WIRING DIAGRAM

Overview of Power Source Diagrams and Ground Circuit Diagrams

The electrical power sources on the circuit are shown by designated code numbers. Therefore, by extending to the left the folding power source diagram, the power sources and fuse that are used be seen and understood at one glance.

The ground locations are shown on the diagram.



Here are listed together the fuses that have been designated for use in the vehicle.

Some Points to Remember When Viewing a Wiring Diagram


WIRING COLOR CODE

Two-color wires are indicated by a Two-letter symbol. The first letter indicates the base color of the wire and the second indicates the color of the stripe.

For example:

W/R is a white wire with a red strip
BR/Y is a brown wire with a yellow strip

| CODE | COLOR | CODE | COLOR |
|------|------------|------|-------------|
| B | Black | LG | Light green |
| BR | Brown | O | Orange |
| G | Green | R | Red |
| L | Blue | Y | Yellow |
| LB | Light blue | W | White |
| P | Pink | V | Violet |
| GY | Gray | | |




Legend in the parenthesis () indicates the reference Page.

Some Points to Remember When Viewing a Connector Diagram



Connector numbers are written in sequence according to each harness, and the letter at the head of each code number indicates the kind of harness.

For example:


"F-11" stands for the 11th connector in the Front Harness.



Direction of current is shown by the arrow




CONNECTOR AND NO.



The connector numbers are decided according to each kind of harness.

For example:

- (F-20 Front Harness
- I-01 Instrument panel Harness
- R-12 Rear Harness




Abbreviation

The Way to View a Electrical Wiring Schematic

The electrical wiring schematic explains the outline of all the electrical parts in the vehicle. Also, it clarifies power line and the way to use each fuses.


| | Relay | | Switch | |
|------------------|---------------|---------------|-----------|-----------|
| | NO type relay | NC type relay | NO switch | NC switch |
| Not in operation | | | | |
| | Stop | Flow | Stop | Flow |
| In operation | | | | |
| | Flow | Stop | Flow | Stop |

The NC (Normally Closed) type relay and switch are shown by "●", the NO (Normally Open) are shown by "○". These are shown without operation in this book




Z HOW TO USE THIS WIRING DIAGRAM

Some Points to Remember When Viewing a Location Diagram




Connectors in circuit diagram are all described in location diagram, and connector numbers are shown by leader line.
Each frame has the alphabets and numerical numbers to search the connector easily.
For example:
"F-11" connector is across "E" on horizontal line and "7" on vertical line.
Connector Color:
Color is shown unless connector is white.

Some Points to Remember When Viewing a Harness Diagram



Designed in order that the connector shape and the arrangement of the pins used in the circuit diagrams might be understood.

The way of looking at a connector




HOW TO USE THIS WIRING DIAGRAM


HARNESS SYMBOLS

Each harness is distinguished by a symbol to indicate to which harness belong a wiring and connector in circuit diagrams and connector charts.

| DESCRIPTION OF HARNESS | COLOR | SYMBOL | DESCRIPTION OF HARNESS | SYMBOL |
|--------------------------|-------|--------|-------------------------|--------|
| Front Harness | Black | [F] | Interior Lamp Harness | [IN] |
| Engine Harness | Black | [E] | Door No. 1 Harness | [DR1] |
| Instrument Panel Harness | Black | [I] | Door No. 2 Harness | [DR2] |
| Rear Harness | Black | [R] | Door No. 3 Harness | [DR3] |
| Rear No. 2 Harness | Black | [R2] | Door No. 4 Harness | [DR4] |
| Rear No. 3 Harness | Black | [R3] | Air Conditioner Harness | [AC] |
| Emission Harness | Black | [EM] | | |




EXAMPLE OF CIRCUIT DIAGRAM



- It is seen from the above that the male-side black line of the FE-63 shows the engine harness and the female-side black line shows the front harness.
- It is seen from the above that the FE-63 connector is a connector connecting the engine and the front.

EXAMPLE OF CONNECTOR



- This sign (*) means "empty" - Not Used.
- It is seen from the above that this connector R-03 is on the Rear harness.

SYMBOLS IN THIS WIRING DIAGRAM

SYMBOLS IN THIS WIRING DIAGRAM

LOGICAL SYMBOLS

The logical symbols are of four kinds: OR, AND, INV. (Inverter), PROCESS. The circuit operation can be easily read by understanding these symbols.

| | |
|------------------------|--|
| <p>OR</p> | <p>In case of input to either A or B, an output comes out from C. When A and B are off (0V), C is off (0V). When either A or B is on (12V), C is on (12V). This can be simply shown in the relay circuit on the right-hand side.</p> |
| <p>AND</p> | <p>In case on input to both A and B, an output comes out from C. When A and B are on (12V), C is on (12V). When either A or B is off (0V), C is off (0V). This can be simply shown in the relay circuit on the right-hand side.</p> |
| <p>INV. (Inverter)</p> | <p>In case of input to A, B is grounded. When A is off (0V), B is on (12V). When A is on (12V), B is off (0V). This can be simply shown in the relay circuit on the right-hand side.</p> |
| | <p>PROCESS makes a simplified representation of complicated functions of the circuit. Functions mainly used: 1. Detection of signals 2. Conversion of signals The process of the full transistor ignition control unit is as shown in the right-hand figure.</p> |

GRAPHIC SYMBOLS

| | | | | | |
|---------------|-------------------|---------------------|--------------------|-------------|-------------|
| | | | | | |
| Battery | Harness | Holder | Box | Main Fuse | Motor |
| | | | | | |
| Coil solenoid | Resistance | Variable resistance | Thermister | Diode | Diode |
| | | | | | |
| Condenser | Transistor | Pump | Light | Horn | Horn |
| | | | | | |
| Speaker | Cigarette lighter | Heater | Illuminating Diode | Zener Diode | Zener Diode |

ABBREVIATIONS


ABBREVIATIONS USED IN THIS BOOKLET

| | | | |
|-------|--------------------------------|--------------------|---------------------------------|
| A | Ampere | HI | High |
| AAS | Auto Adjusting Suspension | ISC | Idle Speed Control |
| ABS | Anti-lock Brake System | IG | Ignition |
| ACV | Air Control Valve | ILLUMI | Illumination |
| AE | Acoustic Equilibration | INT | Intermittent |
| AIS | Air Injection System | JB | Joint Box |
| ALL | Automatic Load Leveling | LH | Left Hand |
| AS | Auto Stop | LCD | Liquid Crystal Display |
| ASV | Air Supply Valve | LO | Low |
| A/C | Air Conditioner | LW | Low Wave |
| A/F | Air Fuel | M | Motor |
| A/R | Auto Reverse | MIL | Mulfanction Indicator Light |
| A/T | Automatic Transmission | MTR | Mechanical Tuning Radio |
| ACC | Accessory | M/T | Manual Transmission |
| ACCEL | Accelerator | MI | Middle |
| ADD | Additional | MIN | Minute |
| ALT | Alternator | MIX | Mixture |
| AM | Amplitude Modulation | MPX | Multiplex |
| AMP | Amplifier | MTX | Manual Transaxle |
| ANT | Antenna | MW | Middle Wave |
| ATP | Atmospheric Pressure | NC | Normally Closed |
| ATX | Automatic Transaxle | NO | Normally Open |
| B | Battery | OD | Over Drive |
| BAC | By-pass Air Control Valve | P | Power |
| B/L | Bi-Level | PRCV | Pressure Regulator Control |
| CPU | Central Processing Unit | Solenoid Valve | |
| CSD | Cold Start Device | PTC | Positive Temperature |
| CARB | Carburator | Coefficient Heater | |
| CCT | Circuit | P/S | Power Steering |
| CIGAR | Cigarette | PRG | Purge Solenoid Valve |
| COMBI | Combination | QSS | Quick Start System |
| CON | Conditioner | R | Rear |
| CONT | Control | RH | Right Hand |
| DOHC | Double Over Head Camshaft | RL | Rear Left |
| DEF | Defroster | RPM | Revolution Per Minute |
| ECE | Economic Commission For Europe | RR | Rear Right |
| EGI | Electric Gasoline Injection | REC | Recirculation |
| EGR | Exhaust Gas Recirculation | SOL | Solenoid |
| EGRP | Exhaust GAS Recirculation | SQ | Square Per Milimeter |
| | Pressure Sensor | ST | Start |
| ELR | Emergency Locking Retractor | SW | Short Wave |
| ELEC | Electric | SW | Switch |
| ETR | Electronic Tuner | TCV | Twin Scrol Turbocharger |
| EXH | Exhaust | Solenoid Valve | |
| F | Front | TICS | Triple Induction Control System |
| FICB | Fast Idle Cam Breaker | TEMP | Temperature |
| FL | Front Left | TR | Transistor |
| FR | Front Right | TWS | Total Wiring System |
| F/B | Feed Back | V | Volt |
| F/I | Fuel Injector | VRIS | Variable Resonance Induction |
| FM | Frequency Modulation | System | |
| GEN | Generator | VENT | Ventiration |
| HEI | High Energy Ignition | VOL | Volume |
| H/D | Heat/Defroster | W | Watt |
| HEAT | Heater | | |

AN OVERVIEW OF ELECTRICAL COMPONENTS

Following is an overview of electrical components representative of the many electrical components related to the control and warning instruments in automobiles.


DIODE



The nature of diode is to allow a current to flow in only one direction. It is used in a circuit when desiring to let current flow in only one direction, or as a rectifier when changing an alternating current to a direct current. The different terminals of a diode are called anode (A) and cathode (K). Electric current flows from anode to cathode, but never from cathode to anode.

In checking a diode with a tester be careful about the tester's polarity. The tester's (-) means positive electrical potential, and (+) means negative electrical potential. To check a diode's current, touch the tester's (-) lead to the anode, and the tester's (+) lead to the cathode.


ILLUMINATING DIODE



An illuminating diode emits light from the contact surface of a semiconductor when an electric current flows in its forward direction.

in setting the two battery in tester for the 10kΩ range, touch the tester's (-) lead to the anode (A), and the (+) lead to the cathode (K), it lights up.


RESISTOR



| Color Band | No. 1 Value | No. 2 Value | No. 3 Multiplier | No. 4 Clearance |
|------------|-------------|-------------|------------------|-----------------|
| Black | 0 | 0 | $\times 10^0$ | |
| Brown | 1 | 1 | $\times 10^1$ | |
| Red | 2 | 2 | $\times 10^2$ | |
| Orange | 3 | 3 | $\times 10^3$ | |
| Yellow | 4 | 4 | $\times 10^4$ | |
| Green | 5 | 5 | $\times 10^5$ | |
| Blue | 6 | 6 | $\times 10^6$ | |
| Purple | 7 | 7 | $\times 10^7$ | |
| Gray | 8 | 8 | $\times 10^8$ | |
| White | 9 | 9 | $\times 10^9$ | |
| Gold | | | $\times 10^{-1}$ | $\pm 5\%$ |
| Silver | | | $\times 10^{-2}$ | $\pm 10\%$ |
| Non | | | | $\pm 20\%$ |

As resistors are essential to make an electric circuit. Reading the resistance value of the widely used resistor is explained below.

As shown in the chart at left, there are four color bands to represent resistances. Each resistance value can be understood from each color band. For example:




The resistance value is $200k\Omega \pm 5\%$.


Code number clarification

The first two digits in each code number represent the resistance value, and the third digit represents multiplier. For example:

$$332 \rightarrow 33 \times 10^2(\Omega) \rightarrow 3.3 \times 10^3(\Omega) \rightarrow 3.3(k\Omega)$$



CONDENSER




A Condenser is for storing electricity. In the case of an open circuit, a condenser is not able to store electric charge. And the circuit remains in an open state.

A short circuit, its name indicate, means the break-down phenomena when voltage is applied.

Inspection of low voltage condenser with circuit tester

- (1) Short a condenser and discharge the remaining electric charge
- (2) Set $\times 10k\Omega$; largest resistance range in the circuit tester
- (3) When the test lead touches both ends, the indicate moves a little bit; and then returns to $\infty (\Omega)$

TRANSISTOR




There are two types of transistor function:

- (1) Switching Acting as a switch
- (2) Amplification action Amplifying a small signal to a big signal


Transistors are classified according to polarity (structure): NPN and PNP. Generally, the NPN are widely used. Transistor has three terminals: Emitter (E), Collector (C), and Base (B).

To operate the transistor, make a base current flow to the arrow direction (B to E). Then the resistance between the collector and the emitter becomes extremely small, and large current flows from the collector to the emitter (In the case of PNP transistor, electric current flows to the emitter to the collector).

Electrodes indication




Name of Models



A simply way of checking

PNP and NPN transistor can be simplified shown in diagrams on the left-hand side. Set $\times 100\Omega$ or $1k\Omega$ resistance measurement range in the circuit tester, and touch leads to each electrode to check conductivity.



- Current Flow only C to B
- Current Flow only E to B
- Current Flow only B to C
- Current Flow only B to E


PARTS INDEX

| PARTS | PAGE | PARTS | PAGE |
|--|----------------------------------|--|---------------|
| Ⓐ A/C Relay | Z-90, 94 | Headlight Relay | Z-54 |
| A/C Switch | Z-90, 94 | High Mount Stop Light | Z-84 |
| Actuator | Z-116 | Hold Switch | Z-54 |
| Airflow Meter | Z-30, 46 | Horn | Z-86, 88 |
| Alternator | Z-16 | Horn Relay | Z-86, 88 |
| Audio | Z-122 | Horn Switch | Z-86, 88 |
| Ⓑ Back-up Light | Z-86, 88 | Ⓘ Igniter | Z-18, 34 |
| Back-up Light Switch | Z-86, 88 | Ignition Coil | Z-18, 34 |
| Battery | Z-12 | Ignition Key Cylinder Lamp | Z-98 |
| Blower Motor | Z-90, 94 | Ignition Key Reminder Switch | Z-98 |
| Blower Switch | Z-90, 94 | Ignition Switch | Z-12 |
| Brake Fluid Switch | Z-58 | Illumination Lamp | Z-78 |
| Buckle Switch | Z-98, 112 | Inhibitor Switch | Z-16, 54 |
| Ⓒ Cargo Room Lamp | Z-100 | Injector | Z-26, 42 |
| Cargo Room Lamp Switch | Z-100 | Interior Lamp | Z-98 |
| Cassette Deck | Z-122 | ISC Valve | Z-26, 42 |
| Center Dif-Lock Motor | Z-118 | Ⓛ License Plate Light | Z-74 |
| Center Dif-Lock Switch | Z-118 | Limit Switch | Z-112 |
| Cigarette Lighter | Z-102 | Ⓜ Magnetic Clutch | Z-90, 94 |
| Circuit Opening Relay | Z-18, 34 | Main Fuse | Z-12 |
| Clutch Switch | Z-30, 46 | Main Relay (Fuel Inj) | Z-18, 34 |
| Combination Switch (Light Switch) | Z-68, 70 | Meter | Z-58 |
| Condenser | Z-18, 34 | Ⓝ Neutral Switch | Z-30, 46 |
| Condenser Fan | Z-90, 94 | Ⓞ Oil Pressure Switch | Z-58 |
| Condenser Fan Relay | Z-90, 94 | Oxygen Sensor | Z-22, 38 |
| Cooling Fan Motor | Z-50, 52 | Ⓟ Panel Light Control | Z-78 |
| Cooling Fan Relay | Z-50, 52 | Parking Brake Switch | Z-58 |
| Cruise Control Main Switch | Z-116 | Passive Shoulder Belt Control Unit | Z-112 |
| Cruise Control Switch | Z-116 | Passive Shoulder Belt Motor | Z-112 |
| Cruise Control Unit | Z-116 | Power Door Lock Motor | Z-104 |
| Ⓓ Daytime Running Light Control Unit | Z-72 | Power Door Lock Relay | Z-104 |
| Daytime Running Light Relay | Z-72 | Power Door Lock Switch | Z-104 |
| Daytime Running Light Resistor | Z-72 | Power Steering Pressure Switch | Z-22, 38 |
| Diagnosis Connector | Z-18, 34 | Power Window Main Switch | Z-108 |
| Digital Clock | Z-102 | Power Window Motor | Z-108 |
| Diode | Z-90, 94 | Power Window Switch | Z-108 |
| Distributor | Z-26, 42 | Ⓡ Radio | Z-122 |
| Door Catch Switch | Z-112 | Rear Side Marker Light | Z-74 |
| Door Speaker | Z-122 | Rear Speaker | Z-122 |
| Door Switch | Z-98 | Rear Turn Light | Z-82 |
| Ⓔ EC-AT Control Unit | Z-54 | Rear Washer Motor | Z-64 |
| Engine Control Unit | Z-18, 22, 26, 30, 34, 38, 42, 46 | Rear Washer Switch | Z-64 |
| Ⓕ Flasher Unit | Z-82 | Rear Window Defroster | Z-102 |
| 4x4 Control Unit | Z-118 | Rear Window Defroster Switch | Z-102 |
| Front Side Marker Light | Z-74 | Rear Wiper Motor | Z-64 |
| Front Turn Light | Z-82 | Rear Wiper Switch | Z-64 |
| Front Washer Motor | Z-62, 64 | Refrigerant Pressure Switch | Z-90, 94 |
| Front Wiper Motor | Z-62, 64 | Remote Control Mirror Motor | Z-106 |
| Front Wiper Relay | Z-64 | Remote Control Mirror Switch | Z-106 |
| Front Wiper Switch | Z-62, 64 | Resistor Assembly | Z-90, 94 |
| Fuel Tank Unit | Z-18, 34 | Ⓢ Shift Lock Unit | Z-84 |
| Fuse Box | Z-12, 16 | Short Connector | Z-50, 52, 118 |
| Ⓖ Hazard Switch | Z-82 | | |
| Headlight | Z-68, 70 | | |


PARTS INDEX

| PARTS | PAGE | PARTS | PAGE |
|--------------------------------|----------|-----------------------------|--------------|
| Sliding Sunroof Motor | Z-120 | Stop Light Switch | Z-84, 116 |
| Sliding Sunroof Relay | Z-120 | Sub Fuel Tank Unit | Z-34 |
| Sliding Sunroof Switch | Z-120 | | |
| Solenoid Valve | | ① Tail Light | Z-74 |
| EC-AT | Z-54 | Tail Light Relay | Z-70 |
| Pressure Regulator | Z-26, 42 | Thermo Switch | Z-90, 94 |
| Purge Control | Z-26, 42 | Throttle Sensor | Z-30, 46 |
| VICS | Z-26 | Turn Switch | Z-82 |
| Spot Lamp | Z-98 | | |
| Starter | Z-16 | Ⓜ Washer Level Sensor | Z-58 |
| Starter Interlock Switch | Z-16 | Water Thermosensor | Z-26, 42, 58 |
| Stop Light | Z-84 | Water Thermo Switch | Z-50, 52, 94 |


■ POWER SYSTEM




F-01 FUSE BOX (F)




F-02 IGNITION SWITCH (F)



E-01 MAIN FUSE (E)




E-03 FUSE BOX (E)




*...4WD

FE-01 FRONT (F) -ENGINE (E)




EAC-01 ENGINE (E) -A/C (AC)







FUSE BOX



FUSE BOX




JOINT BOX

F-02

Z WIRING DIAGRAM


EXCEPT 4WD ELECTRICAL WIRING SCHEMATIC

— CURRENT FROM BATTERY
 - - - CURRENT FROM IG1, IG2
 - · - · CURRENT FROM ACC
 — OTHERS




4WD
ELECTRICAL WIRING SCHEMATIC

— CURRENT FROM BATTERY
 - - - CURRENT FROM IG1, IG2
 ···· CURRENT FROM ACC
 ——— OTHERS



WIRING DIAGRAM


- STARTING SYSTEM
- CHARGING SYSTEM




F-03 STARTER INTERLOCK SWITCH (F)




F-04 INHIBITOR SWITCH (F)




E-03 FUSE BOX (E)




E-04 STARTER (E)




E-05 ALTERNATOR (E)




FE-02 FRONT (F) -ENGINE (E)







EXCEPT 4WD ■ ENGINE CONTROL SYSTEM (1/4)




F-05 JOINT CONNECTOR (F)




E-06 MAIN RELAY (E)
(FUEL INJ)




EM-01 ENGINE CONTROL UNIT (EM)




EM-02 CIRCUIT OPENING RELAY (EM)




EM-03 IGNITER (EM)




EM-04 CONDENSER (EM)




EM-05 IGNITION COIL (EM)



EM-06 DIAGNOSIS CONNECTOR (EM)





R-01 FUEL TANK UNIT (R)





() ...EC-AT

FEM-01 FRONT (F) -EMISSION (EM)




FEM-02 FRONT (F) -EMISSION (F)



() ...EC-AT


() ...EC-AT <> ...CANADA * ...4WD

FEM-03 FRONT (F) -EMISSION (EM)




() ...EC-AT * ...4WD

FE-01 FRONT (F) -ENGINE (E)




() ...EC-AT







EEM-01 ENGINE (E) -EMISSION (EM)



FR-01 FRONT (F) -REAR (R)



() ...EC-AT <> ...CANADA * ...WITH PASSIVE SHOULDER BELT () ...SEDAN * ...4WD



Engine control unit terminal (unit side)


| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|---|--|--|---|
| 1A | — | — | Battery | Constant | Approx. 12V | For backup |
| 1B | ○ | | Main relay (FUEL INJ relay) | Ignition switch OFF ON | Approx. 0V Approx. 12V | — |
| 1C | ○ | | Ignition switch (START) | While cranking Ignition switch ON | Approx. 10V Approx. 0V | — |
| 1D | | ○ | Self-Diagnosis Checker (Monitor lamp) | Test switch at "SELF-TEST" Lamp illuminated for 3 sec. after ignition switch OFF→ON Lamp not illuminated after 3 sec. | Approx. 5V Approx. 12V | With Self-Diagnosis Checker and System Selector |
| | | | | Test switch at "O ₂ MONITOR" at idle Monitor lamp illuminated Test switch at "O ₂ MONITOR" at idle Monitor lamp illuminated | Approx. 5V Approx. 12V | |
| 1F | | ○ | Self-Diagnosis Checker (Code Number) | Buzzer sounded for 3 sec. after ignition switch OFF→ON Buzzer not sounded after 3 sec. Buzzer sounded Buzzer not sounded | Below 2.5V Approx. 12V Below 2.5V Approx. 12V | |
| | | | | | | |
| 1G | | ○ | Igniter | Ignition switch ON Idle | Approx. 0V Approx. 0.2V | — |
| 1K | ○ | | Diagnosis connector (TEN terminal) | System selector test switch at "O ₂ MONITOR" System selector test switch at "SELF-TEST" | Approx. 12V Below 1.0V | — |
| 1R | ○ | | Fan switch | Fan operating (Engine coolant temperature over 91°C (196°F), CANADA, 97°C (207°F), USA or diagnosis connector terminal TFA grounded) Fan not operating (Idle) | Below 1.0V Approx. 12V | — |
| 2J | ○ | | Open (MTX) Main relay (FUEL INJ relay) (ATX) | Constant Ignition switch ON | Approx. 0V Approx. 12V | — |

EXCEPT 4WD ■ ENGINE CONTROL SYSTEM (2/4)

A
C
S
S
B

EM-01 ENGINE CONTROL UNIT



F-06 POWER STEERING PRESSURE SWITCH (F)



EM-01 ENGINE CONTROL UNIT (EM)

| | | | | | | | | | | |
|---------------|-----|-----|------------|-----|-------------|-----|-----|-----|-----|-----|
| 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/B | O/L | G/B | (G/R) G | * | L/G/Y | * | G/W | Y/B | V | L/R |
| BR/Y (B/L) | B/L | B/G | L/Y | R/W | * (BR/W) | L/B | * | W/B | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

() ... EC-AT ▲ ... DOHC <> ... CANADA

EM-07 OXYGEN SENSOR (EM)



FEM-01 FRONT (F) -EMISSION (EM)

| | | | | | |
|-----|--------------|-----|-----|-----|---|
| B/D | (G/O) G/B | | R/B | B/P | |
| L/R | L/B | B/G | O/L | Y/L | * |

() ... EC-AT

(EM)

| | | | | | |
|-----|-----|-----|--------------|-----|-----|
| B/P | R/B | | (G/O) G/B | B/D | |
| * | Y/L | O/L | B/G | L/B | L/R |


FEM-02 FRONT (F) -EMISSION (EM)

| | | | | | | | | | |
|-----|-----|-------|-------|-------|--------|-----|-------|--------|---------|
| B | Y/B | (L/G) | (R/W) | (G/R) | | (*) | <B/Y> | * | (L/G/W) |
| R/G | L/Y | * | (W) | (R) | <BR/W> | R/G | Y/W | (BL/G) | (L/G/R) |
| * | * | * | * | * | * | * | * | * | * |

() ... EC-AT <> ... CANADA * ... 4WD

(EM)

| | | | | | | | | | |
|---------|--------|-------|------|--------|-------|-------|-------|-----|-----|
| (L/G/W) | * | <B/Y> | (*) | | (G/R) | (R/W) | (L/G) | Y/B | B |
| * | * | * | BR/Y | * | G | * | * | * | * |
| (L/G/R) | (BL/G) | *Y/W | R/G | <BR/W> | (R) | (W) | * | L/Y | R/G |
| * | B/L | * | * | * | G/Y | * | * | * | * |




F-06

EM-07
(GRAY)

JOINT BOX

JB-02

JB-08



EM-01

JOINT BOX

FEM-02
(BLACK)

FEM-01

6


Engine control unit terminal (unit side)

| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1G | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|---|--|--|--|---|
| 1E | | ○ | Malfunction indicator lamp (MIL) | Lamp illuminated for 3 sec. after ignition switch OFF→ON | Below 2.5V | With System Selector test switch at "SELF-TEST" |
| | | | | Lamp not illuminated after 3 sec. | Approx. 12V | |
| | | | | Lamp illuminated | Below 2.5V | |
| | | | | Lamp not illuminated | Approx. 12V | |
| 1J | | ○ | A/C relay | Ignition switch ON | Approx. 12V | — |
| | | | | A/C switch ON at idle | Below 2.5V | |
| | | | | A/C switch OFF at idle | Approx. 12V | |
| 1L | ○ | DRL relay (Canada) | Parking brake pulled with ignition switch ON (DRL OFF) | Approx. 12V | ●DRL: Daytime Running Light | |
| | | | Idle (DRL ON) | Below 2.5V | | |
| 1O | ○ | Stoplight switch/EC-AT control unit (ATX) | Brake pedal released | Below 1.0V | — | |
| | | | Brake pedal depressed | Approx. 12V | | |
| 1P | ○ | P/S pressure switch | Ignition switch ON | Approx. 12V | — | |
| | | | P/S ON at idle | Below 1.0V | | |
| | | | P/S OFF at idle | Approx. 12V | | |
| 1Q | ○ | A/C switch | A/C switch ON | Below 2.5V | Ignition switch ON and blower motor ON | |
| | | | A/C switch OFF | Approx. 12V | | |
| 1S | ○ | Blower control switch | Blower control switch OFF or 1st position | Approx. 12V | Ignition switch ON | |
| | | | Blower control switch 2nd or more position | Below 1.0V | | |
| 1T | ○ | Rear window defroster switch | Rear window defroster switch OFF | Below 1.0V | Ignition switch ON | |
| | | | Rear window defroster switch ON | Approx. 12V | | |
| 1U | ○ | Headlight switch | Headlights ON | Approx. 12V | — | |
| | | | Headlights OFF | Below 1.0V | | |
| 2N | ○ | Oxygen sensor | Ignition switch ON | 0V | — | |
| | | | Idle (Cold engine) | 0V | | |
| | | | Idle (After warm-up) | 0-1.0V | | |
| | | | Increase engine speed (After warm-up) | 0.5-1.0V | | |
| | | | Deceleration | 0-0.4V | | |

EXCEPT 4WD ■ ENGINE CONTROL SYSTEM (3/4)

A
2
1
5
B




EM-01 ENGINE CONTROL UNIT (EM)

| | | | | | | | | | | |
|---------------|-----|-----|------------|-----|-------------|-----|-----|-----|-----|-----|
| 1U | 1S | 1Q | 10 | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/B | O/L | G/B | (G/R) G | * | LG/Y | * | G/W | Y/B | V | L/R |
| BR/Y (B/L) | B/L | B/G | L/Y | R/W | * <BR/W> | L/B | * | W/B | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |


() ... EC-AT ▲ ... DOHC <> ... CANADA

| | | | | | | | | | | | | | |
|----|-------|-----|-----------|-----|----|--------------|------|-------------|------------|-------|------|------|-----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | |
| * | L/D | Y | ▲B/R * | L/W | R | (L/G/W) * | LG/R | * | ▲Y/L * | W | B/LG | B/O | |
| * | (L/G) | W/L | Y/B | G/O | * | R/B | B | LG/W (*) | * (W/R) | <B/Y> | * | B/BR | B/O |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | |


EM-08 DISTRIBUTOR (EM)




EM-09 ISC VALVE (EM)




EM-10 SOLENOID VALVE (PURGE CONTROL) (EM)




INJ-01 SOLENOID VALVE (VICS) (INJ)




INJ-02 SOLENOID VALVE (PRESSURE REGULATOR) (INJ)




INJ-03 INJECTOR NO. 1 (INJ)




INJ-04 INJECTOR NO. 3 (INJ)




INJ-05 INJECTOR NO. 2 (INJ)





INJ-06 INJECTOR NO. 4 (INJ)





INJ-07 WATER THERMOSENSOR (INJ)



EMINJ-01 EMISSION (EM) - INJECTOR (INJ)




EMINJ-02 EMISSION (EM) - INJECTOR (INJ)



Z WIRING DIAGRAM

HARNESS COLOR FRONT ENGINE




Engine control unit terminal (unit side)

| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |


| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|--|---|--|---|
| 2E | ○ | | Distributor (Ne-signal) | Ignition switch ON Idle | Approx. 0V or 5V Approx. 2V | |
| 2G | ○ | | Distributor (G-signal) [DOHC] | Ignition switch ON Idle | Approx. 0V or 5V Approx. 1.5V | |
| 2Q | ○ | | Water thermo-sensor | Engine coolant temperature 20°C (68°F) After warm-up | Approx. 2.5V Below 0.5V | |
| 2S | ○ | | Solenoid valve (VICS) | Engine speed below 5,000 rpm Engine speed above 5,000 rpm | Below 1.5V Approx. 12V | ● VICS: Variable Inertia Charging System |
| 2T | ○ | | Solenoid valve (Pressure regulator) (BP) | 60 seconds after engine started when engine coolant temperature above 90°C (194°F) and intake air temperature above 58°C (136°F) Other condition at idle | Below 1.5V Approx. 12V | |
| 2U | ○ | | Injector (Nos. 1, 3) | Ignition switch ON Idle Engine speed above 2,000 rpm on deceleration (After warm-up) | Approx. 12V Approx. 12V* Approx. 12V | *Engine Signal Monitor: Green and red lamps flash |
| 2V | ○ | | Injector (Nos. 2, 4) | Ignition switch at idle Idle Engine speed above 2,000 rpm on deceleration (After warm-up) | Approx. 12V Approx. 12V* Approx. 12V | |
| 2W | ○ | | ISC valve | Ignition switch ON Idle | Approx. 12V Approx. 10V | |
| 2X | ○ | | Solenoid valve (Purge control) | Ignition switch ON Idle | Approx. 12V Approx. 12V | |

Z WIRING DIAGRAM


EXCEPT 4WD ■ ENGINE CONTROL SYSTEM (4/4)



F-07 CLUTCH SWITCH (F)




EM-01 ENGINE CONTROL UNIT (EM)




EM-11 AIRFLOW METER (EM)



EM-12 THROTTLE SENSOR (EM)





EM-13 THROTTLE SENSOR (EM)




EM-14 NEUTRAL SWITCH (EM)




FEM-02 FRONT (F) -EMISSION (EM)



FEM-03 FRONT (F) -EMISSION (EM)



() ...EC-AT * ...4WD




Engine control unit terminal (unit side)


| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|---|---|---------------------------|------------------------|
| 1N | ○ | | Throttle sensor (Idle switch) (MTX/ATX) EC-AT control unit (ATX) | Accelerator pedal released Accelerator pedal depressed | Below 1.0V Approx. 12V | Ignition switch ON |
| 1V | ○ | | Neutral/Clutch switches (MTX) Inhibitor switch (ATX) | Neutral position or clutch pedal depressed | Below 1.0V | |
| | | | | Others | Approx. 12V | |
| | | | | N or P range | Below 1.0V | |
| | | | | Others | Approx. 12V | |
| 2A | — | — | Ground (Injector) | Constant | 0V | — |
| 2B | — | — | Ground (Output) | Constant | 0V | — |
| 2C | — | — | Ground (CPU) | Constant | 0V | — |
| 2D | — | — | Ground (Input) | Constant | 0V | — |
| 2H | ○ | | Ground (California) | Constant | 0V | — |
| | | | Open (Federal) | Constant | Approx. 2V | — |
| | | | Main relay (Canada) | Ignition switch ON | Approx. 12V | — |
| 2K | ○ | | Throttle sensor (ATX)/EC-AT control unit (ATX)/Airflow meter | Constant | 4.5-5.5V | |
| 2L | ○ | | Throttle sensor (Power switch) (MTX) | Accelerator pedal released | Approx. 5V | — |
| | | | | Accelerator pedal fully opened | Below 1.0V | |
| 2M | ○ | | Throttle sensor (ATX)/EC-AT control unit (ATX) | Accelerator pedal released | Approx. 0.5V | — |
| | | | | Accelerator pedal fully opened | Approx. 4.0V | |
| 2O | ○ | | Airflow meter | Ignition switch ON | Approx. 3.8V | — |
| | | | | Idle | Approx. 3.3V | |
| 2P | ○ | | Intake air thermo-sensor | Ambient air temperature 20°C (68°F) | Approx. 2.5V | Built in airflow meter |
| 2Z | ○ | | EC-AT control unit (ATX) | Engine coolant temperature below 72°C (162°F) at idle | Below 2.5V | |
| | | | | Engine coolant temperature above 72°C (162°F) at idle | Approx. 12V | |



F-05 JOINT CONNECTOR (F)




E-06 MAIN RELAY (E)
(FUEL INJ)




EM-01 ENGINE CONTROL UNIT (EM)




EM-02 CIRCUIT OPENING RELAY (EM)



EM-03 IGNITER (EM)




EM-04 CONDENSER (EM)




EM-05 IGNITION COIL (EM)




EM-06 DIAGNOSIS CONNECTOR (EM)




R-01 FUEL TANK UNIT (R)




R-26 SUB FUEL TANK UNIT (R)




FEM-01 FRONT (F) -EMISSION (EM)




() ...EC-AT




FEM-02 FRONT (F) -EMISSION (EM)



() ...EC-AT <>...CANADA *...4WD




FEM-03 FRONT (F) -EMISSION (EM)




() ...EC-AT *...4WD

FE-01 FRONT (F) -ENGINE (E)




() ...EC-AT





EEM-01 ENGINE (E) -EMISSION (EM)



FR-01 FRONT (F) -REAR (R)



() ...EC-AT <>...CANADA *...WITH PASSIVE SHOULDER BELT []...SEDAN *...4WD



Engine control unit terminal (unit side)

| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2O | 2N | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |


| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|---------------------------------------|---|--|--|
| 1A | — | — | Battery | Constant | Approx. 12V | For backup |
| 1B | ○ | | Main relay (FUEL INJ relay) | Ignition switch OFF ON | Approx. 0V Approx. 12V | |
| 1C | ○ | | Ignition switch (START) | While cranking Ignition switch ON | Approx. 10V Approx. 0V | |
| 1D | ○ | | Self-Diagnosis Checker (Monitor lamp) | Test switch at "SELF-TEST" Lamp illuminated for 3 sec. after ignition switch OFF→ON Lamp not illuminated after 3 sec. Test switch at "O ₂ MONITOR" at idle Monitor lamp illuminated Test switch at "O ₂ MONITOR" at idle Monitor lamp illuminated | Approx. 5V Approx. 12V Approx. 5V Approx. 12V | With Self-Diagnosis Checker and System Selector |
| 1F | ○ | | Self-Diagnosis Checker (Code Number) | Buzzer sounded for 3 sec. after ignition switch OFF→ON Buzzer not sounded after 3 sec. Buzzer sounded Buzzer not sounded | Below 2.5V Approx. 12V Below 2.5V Approx. 12V | •With Self-Diagnosis Checker and System Selector •With System Selector test Selector at "SELF-TEST" |
| 1G | ○ | | Igniter | Ignition switch ON Idle | Approx. 0V Approx. 0.2V | |
| 1K | ○ | | Diagnosis connector (TEN terminal) | System selector test switch at "O ₂ MONITOR" System selector test switch at "SELF-TEST" | Approx. 12V Below 1.0V | |
| 1R | ○ | | Fan switch | Fan operating (Engine coolant temperature over 91°C (196°F). CANADA. 97°C (207°F) USA or diagnosis connector terminal TFA grounded) Fan not operating (Idle) | Below 1.0V Approx. 12V | |

Z WIRING DIAGRAM


4WD ■ ENGINE CONTROL SYSTEM (2/4)

A
S
S
E
M
B
L

EM-01 ENGINE CONTROL UNIT



F-06 POWER STEERING PRESSURE SWITCH (F)



EM-01 ENGINE CONTROL UNIT (EM)

| | | | | | | | | | | |
|---------------|-----|--------------|------------|-----|-------|-----|-----|-----|-----|-----|
| 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/B | O/L | (G/O) G/B | (G/R) G | * | L/G/Y | * | G/W | Y/B | V | L/R |
| BR/Y (W/L) | B/L | B/G | L/Y | R/W | BR/W | L/B | * | W/B | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

() ...EC-AT

EM-07 OXYGEN SENSOR (EM)



| | | | | | | | | | | | | |
|----|-----|-----|-----|-----|-----|--------------|--------------|--------------|-----|----|------|-----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| * | L/D | Y | * | L/W | R | (L/G/W) * | L/G/R | * | * | W | B/LG | B/O |
| * | W/L | Y/B | G/O | * | R/B | R/L | L/G/W (*) | B (L/G/R) | B/Y | * | B/BR | B/O |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

FEM-01 FRONT (F) -EMISSION (EM)

| | | | | | |
|-----|--------------|-----|-----|-----|---|
| B/O | (G/O) G/B | | R/B | B/P | |
| L/R | L/B | B/G | O/L | Y/L | * |

() ...EC-AT

(EM)

| | | | | | |
|-----|-----|-----|--------------|-----|-----|
| B/P | R/B | | (G/O) G/B | B/O | |
| * | Y/L | O/L | B/G | L/B | L/R |


FEM-02 FRONT (F) -EMISSION (EM)

| | | | | | | | | | | |
|----------|-----|------------|------------|------------|-------------|-------------|------------|--------------|-----|--------------|
| B | Y/B | (L/G) * | (R/W) * | (G/R) G | | (*) BR/Y | <B/Y> * | (L/G/W) * | | |
| R/G * | L/Y | * | (W) * | (R) G/Y | <BR/W> * | R/G * | Y/W * | (BL/G) * | B/L | (L/G/R) * |



() ...EC-AT <> ...CANADA * ...4WD

(EM)

| | | | | | | | | | |
|--------------|-----|-------------|-------------|----------|------------|------------|------------|-----|----------|
| (L/G/W) * | * | <B/Y> * | (*) BR/Y | | (G/R) G | (R/W) * | (L/G) * | Y/B | B |
| (L/G/R) * | B/L | (BL/G) * | Y/W * | R/G * | (R) G/Y | (W) * | * | L/Y | R/G * |



JOINT BOX



Engine control unit terminal (unit side)


| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|---|---|--|---|
| 1E | | ○ | Malfunction indicator lamp (MIL) | Lamp illuminated for 3 sec. after ignition switch OFF→ON Lamp not illuminated after 3 sec. Lamp illuminated Lamp not illuminated | Below 2.5V Approx. 12V Below 2.5V Approx. 12V | With System Selector test switch at "SELF-TEST" |
| 1J | | ○ | A/C relay | Ignition switch ON A/C switch ON at idle A/C switch OFF at idle | Approx. 12V Below 2.5V Approx. 12V | — |
| 1L | | ○ | DRL relay (Canada) | Parking brake pulled with ignition switch ON (DRL OFF) Idle (DRL ON) | Approx. 12V Below 2.5V | •DRL Daytime Running Light |
| 1O | | ○ | Stoplight switch/EC-AT control unit (ATX) | Brake pedal released Brake pedal depressed | Below 1.0V Approx. 12V | — |
| 1P | | ○ | P/S pressure switch | Ignition switch ON P/S ON at idle P/S OFF at idle | Approx. 12V Below 1.0V Approx. 12V | — |
| 1Q | | ○ | A/C switch | A/C switch ON A/C switch OFF | Below 2.5V Approx. 12V | Ignition switch ON and blower motor ON |
| 1S | | ○ | Blower control switch | Blower control switch OFF or 1st position Blower control switch 2nd or more position | Approx. 12V Below 1.0V | Ignition switch ON |
| 1T | | ○ | Rear window defroster switch | Rear window defroster switch OFF Rear window defroster switch ON | Below 1.0V Approx. 12V | Ignition switch ON |
| 1U | | ○ | Headlight switch | Headlights ON Headlights OFF | Approx. 12V Below 1.0V | |
| 2N | | ○ | Oxygen sensor | Ignition switch ON Idle (Cold engine) Idle (After warm-up) Increase engine speed (After warm-up) Deceleration | 0V 0V 0-1.0V 0.5-1.0V 0-0.4V | |

4WD ■ ENGINE CONTROL SYSTEM (3/4)

A
2
1
S
B

EM-01 ENGINE CONTROL UNIT




EM-01 ENGINE CONTROL UNIT (EM)

| | | | | | | | | | | |
|---------------|-----|--------------|------------|-----|------|-----|-----|-----|-----|-----|
| 1U | 1S | 1Q | 10 | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/B | O/L | (G/O) G/B | (G/R) G | * | LG/Y | * | G/W | Y/B | V | L/R |
| BR/Y (W/L) | B/L | B/G | L/Y | R/W | BR/W | L/B | * | W/B | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |


| | | | | | | | | | | | | |
|----|-----|-----|-----|-----|-----|--------------|------------|--------------|-----|----|------|-----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| * | L/O | Y | * | L/W | R | (L/G/W) * | LG/R | * | * | W | B/LG | B/O |
| * | W/L | Y/B | G/O | * | R/B | R/L | G/W (*) | B (L/G/R) | B/Y | * | B/BR | B/O |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

() ... EC-AT


EM-08 DISTRIBUTOR (EM)




EM-09 ISC VALVE (EM)




EM-10 SOLENOID VALVE (PURGE CONTROL) (EM)




INJ-02 SOLENOID VALVE (PRESSURE REGULATOR) (INJ)




INJ-03 INJECTOR NO. 1 (INJ)




INJ-04 INJECTOR NO. 3 (INJ)




INJ-05 INJECTOR NO. 2 (INJ)





INJ-06 INJECTOR NO. 4 (INJ)




INJ-07 WATER THERMOSENSOR (INJ)



EMINJ-01 EMISSION (EM) - INJECTOR (INJ)






Engine control unit terminal (unit side)

| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|--|---|---|---|
| 2E | ○ | | Distributor (Ne signal) | Ignition switch ON Idle | Approx 0V or 5V Approx 2V | |
| 2Q | ○ | | Water thermo-sensor | Engine coolant temperature 20°C (68°F) After warm-up | Approx 2.5V Below 0.5V | |
| 2T | ○ | | Solenoid valve (Pressure regulator) (BP) | 60 seconds after engine started when engine coolant temperature above 90°C (194°F) and intake air temperature above 58°C (136°F) Other condition at idle | Below 1.5V Approx 12V | |
| 2U | ○ | | Injector (Nos. 1, 3) | Ignition switch ON Idle Engine speed above 2,000 rpm on deceleration (After warm-up) | Approx 12V Approx 12V Approx 12V | *Engine Signal Monitor. Green and red lamps flash |
| 2V | ○ | | Injector (Nos. 2, 4) | Ignition switch at idle Idle Engine speed above 2,000 rpm on deceleration (After warm-up) | Approx 12V Approx 12V* Approx 12V | |
| 2W | ○ | | ISC valve | Ignition switch ON Idle | Approx 12V Approx 10V | |
| 2X | ○ | | Solenoid valve (Purge control) | Ignition switch ON Idle | Approx 12V Approx 12V | |

4WD ■ ENGINE CONTROL SYSTEM (4/4)



F-07 CLUTCH SWITCH (F)



EM-01 ENGINE CONTROL UNIT (EM)


| | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|-----|--------------|------------|-----|------|-----|-----|-----|-----|-----|-------|-----|-----|-----|-----|-----|--------------|----------------|----|-----|----|------|-----|
| 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A | 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| R/B | O/L | (G/O) G/B | (G/R) G | * | LG/Y | * | G/W | Y/B | V | L/R | * | L/O | Y | * | L/W | R | (L/G/W) * | LG/R | * | * | W | B/LG | B/O |
| BR/Y (W/L) | B/L | B/G | L/Y | R/W | BR/W | L/B | * | W/B | W/Y | W/R | (L/G) | W/L | Y/B | G/O | * | R/B | R/L | (L/G/R) (*) | B | B/Y | * | B/BR | B/O |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

() ...EC-AT


EM-11 AIRFLOW METER (EM)




EM-12 THROTTLE SENSOR (EM)



EM-13 THROTTLE SENSOR (EM)



EM-14 NEUTRAL SWITCH (EM)



FEM-02 FRONT (F) -EMISSION (EM)

| | | | | | | | |
|------------|-----|------------|------------|------------|-------------|------------|--------------|
| B | Y/B | (L/G) * | (R/W) * | (G/R) G | (*) BR/Y | (*) * | (L/G/W) * |
| (R/G) * | L/Y | * | (W) * | (R) G/Y | (BR/W) * | (R/G) * | (L/G/R) * |


() ...EC-AT <> ...CANADA * ...4WD

| | | | | | | | | |
|--------------|-----|-------------|-------------|------------|------------|------------|-----|------------|
| (L/G/W) * | * | (B/Y) * | (*) BR/Y | (G/R) G | (R/W) * | (L/G) * | Y/B | B |
| (L/G/R) * | B/L | (BL/G) * | (R/W) * | (R) G/Y | (W) * | * | L/Y | (R/G) * |

FEM-03 FRONT (F) -EMISSION (EM)

| | |
|------------|------------|
| * | (B/L) * |
| (B/L) * | * |

() ...EC-AT * ...4WD




Engine control unit terminal (unit side)

| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|--------|--------|--|--|--|------------------------|
| 1N | ○ | | Throttle sensor (Idle switch) (MTX/ATX) EC-AT control unit (ATX) | Accelerator pedal released Accelerator pedal depressed | Below 1.0V Approx. 12V | Ignition switch ON |
| 1V | ○ | | Neutral/Clutch switches (MTX) Inhibitor switch (ATX) | Neutral position or clutch pedal depressed Others N or P range Others | Below 1.0V Approx. 12V Below 1.0V Approx. 12V | |
| 2A | — | — | Ground (Injector) | Constant | 0V | — |
| 2B | — | — | Ground (Output) | Constant | 0V | — |
| 2C | — | — | Ground (CPU) | Constant | 0V | — |
| 2D | — | — | Ground (Input) | Constant | 0V | — |
| 2H | ○ | | Ground (California) Open (Federal) Main relay (Canada) | Constant Constant Ignition switch ON | 0V Approx. 2V Approx. 12V | — — — |
| 2J | — ○ | — | Ground (MTX) Throttle sensor (ATX)/EC-AT control unit (ATX)/Airflow meter | Constant Constant | 0V 4.5-5.5V | — — |
| 2K | ○ | | Throttle sensor (ATX)/EC-AT control unit (ATX)/Airflow meter | Constant | 4.5-5.5V | — |
| 2L | ○ | | Throttle sensor (Power switch) (MTX) | Accelerator pedal released Accelerator pedal fully opened | Approx. 5V Below 1.0V | — |
| 2M | ○ | | Throttle sensor (ATX)/EC-AT control unit (ATX) | Accelerator pedal released Accelerator pedal fully opened | Approx. 0.5V Approx. 4.0V | — |
| 2O | ○ | | Airflow meter | Ignition switch ON Idle | Approx. 3.8V Approx. 3.3V | — |
| 2P | ○ | | Intake air thermo-sensor | Ambient air temperature 20°C (68°F) | Approx. 2.5V | Built in airflow meter |
| 2Z | ○ | | EC-AT control unit (ATX) | Engine coolant temperature below 72°C (162°F) at idle Engine coolant temperature above 72°C (162°F) at idle | Below 2.5V Approx. 12V | |


MT ■ COOLING FAN SYSTEM




F-08 COOLING FAN MOTOR (F)



E-07 COOLING FAN RELAY (E)




EM-15 SHORT CONNECTOR (EM)




EM-16 WATER THERMO SWITCH (EM)




FE-01 FRONT (F) -ENGINE (E)



FEM-01 FRONT (F) -EMISSION (EM)






FUSE BOX




JOINT BOX




JB-04


FUSE BOX




EC-AT ■ COOLING FAN SYSSYTEM




F-08 COOLING FAN MOTOR (F)




F-09 COOLING FAN RELAY NO.2 (F)




F-10 WATER THERMO SWITCH (F)




F-11 COOLING FAN RELAY NO.3 (F)



E-07 COOLING FAN RELAY NO.1 (E)




EM-15 SHORT CONNECTOR (EM)




EM-16 WATER THERMO SWITCH (EM)




FE-01 FRONT (F) -ENGINE (E)




FEM-01 FRONT (F) -EMISSION (EM)







■ EC-AT CONTROL SYSTEM



F-04 INHIBITOR SWITCH (F)



F-05 JOINT CONNECTOR (F)




F-12 EC-AT CONTROL UNIT (F)

| | | | | | | | |
|-----|-----|----|------|------|----|----------------|------|
| 1D | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/W | * | * | * | W/B | W | R | * |
| G/R | L/G | * | B/LG | BR/B | G | W/L | BR/Y |
| 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |


*...4WD

| | | | | | | | | | |
|------|-----|------|-----|-----|-----|-----|-----|----|------|
| 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| B/Y | B/Y | L/R | G/R | L | O | L/Y | L/O | * | LG/R |
| LG/W | * | B/LG | * | Y/L | Y/G | Y/W | Y/R | Y | B/L |
| 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

F-13 SOLENOID VALVE (EC-AT) & INHIBITOR SWITCH (F)



R-02 HOLD SWITCH (R)



FEM-02 FRONT (F) -EMISSION (EM)

| | | | | | | | | | |
|----------------|-----|-------|-------|-------|-----------------|----------------|-----|--------|--------|
| B | Y/B | (L/G) | (R/W) | (G/R) | W/L | (*) | B/Y | * | (LG/W) |
| R/G | L/Y | * | (W) | (R) | BR/W | R/G | Y/W | (BL/G) | B/L |






| | | | | | | | | | |
|--------|-----|--------|----------------|----------------|-------|-------|-------|-----|----------------|
| (LG/W) | * | B/Y | (*) | W/L | (G/R) | (R/W) | (L/G) | Y/B | B |
| * | * | * | BR/Y | W/L | G | * | * | * | * |
| (LG/R) | B/L | (BL/G) | Y/W | R/G | (R) | (W) | * | L/Y | R/G |
| * | * | * | * | * | G/Y | * | * | * | * |

()...EC-AT <>...CANADA *...4WD

FR-01 FRONT (F) -REAR (R)


| | | | | | | | | | | | | | |
|----------------|----------------|----------------|----------------|----------------|----------------|-----|-----------------|-----|-----|-----|-----|-----|---|
| R/L | L/Y | W/B | Y/R | Y/G | L/O | O | B/LG | Y | Y/W | Y/L | L/Y | L | |
| W/L | L/O | R/Y | G/R | Y/L | B/G | W/R | (BR/B) | (R) | W/G | L | B/P | R/G | G |
| B/G | * | O | * | G/Y | * | W/L | * | * | * | * | * | * | * |

()...EC-AT <>...CANADA *...WITH PASSIVE SHOULDER BELT ||...SEDAN *...4WD






METER & WARNING LAMPS




F-14 METER (F)



() ...EC-AT <> ...CANADA * ...4WD


F-05 JOINT CONNECTOR (F)



F-15 BRAKE FLUID SWITCH (F)



F-16 WASHER LEVEL SENSOR (F)




R-03 PARKING BRAKE SWITCH (R)




* ... WITH PASSIVE SHOULDER BELT


E-08 OIL PRESSURE SWITCH (E)



EM-17 WATER THERMO-SENSOR (EM)




FEM-01 FRONT (F) -EMISSION (EM)




() ...EC-AT


FE-02 FRONT (F) -ENGINE (E)



FR-01 FRONT (F) -REAR (R)




() ...EC-AT <> ...CANADA * ...WITH PASSIVE SHOULDER BELT [] ...SEDAN * ...4WD






Z WIRING DIAGRAM


CANADA WITHOUT CRUISE CONTROL ■ FRONT WIPER & WASHER



F-05 JOINT CONNECTOR (F)



F-17 FRONT WIPER SWITCH (F)




F-18 FRONT WASHER MOTOR (F)



F-19 FRONT WIPER MOTOR (F)






Z WIRING DIAGRAM

EXCEPT CANADA WITHOUT CRUISE CONTROL


FRONT WIPER & WASHER



F-05 JOINT CONNECTOR (F)



F-17 FRONT WIPER SWITCH (F)




F-18 FRONT WASHER MOTOR (F)




F-19 FRONT WIPER MOTOR (F)




F-20 FRONT WIPER RELAY (F)






Z WIRING DIAGRAM



REAR WIPER & WASHER



F-05 JOINT CONNECTOR (F)




F-17 REAR WIPER & WASHER SWITCH (F)




R-04 REAR WASHER MOTOR (R)




R3-01 REAR WIPER MOTOR (R3)




FR-01 FRONT (F) - REAR (R)







RR2-01 REAR (R) - REAR NO. 2 (R2)




R2R3-01 REAR NO. 2 (R2) - REAR NO. 3 (R3)






Z WIRING DIAGRAM


CANADA WITHOUT CRUISE CONTROL ■ HEADLIGHTS




F-21 COMBINATION SWITCH (F)




F-22 HEADLIGHT LH (F)





F-23 HEADLIGHT RH (F)






JOINT BOX




Z WIRING DIAGRAM


EXCEPT CANADA
WITHOUT CRUISE CONTROL ■ HEADLIGHTS




F-21 COMBINATION SWITCH (F)



F-22 HEADLIGHT LH (F)



F-23 HEADLIGHT RH (F)






F-24 HEADLIGHT RELAY (F)




F-25 TAIL LIGHT RELAY (F)





Z WIRING DIAGRAM

CANADA ■ DAYTIME RUNNING LIGHTS



F-26 DAYTIME RUNNING LIGHT RELAY (F)




F-27 DAYTIME RUNNING LIGHT RESISTOR (F)



F-28 DAYTIME RUNNING LIGHT CONTROL UNIT (F)





●...WITHOUT CRUISE CONTROL




F-27

①

JOINT BOX



JB-07



F-28

F-26


JOINT BOX

Z WIRING DIAGRAM


■ SIDE MARKER LIGHTS ■ LICENSE PLATE LIGHTS ■ TAIL LIGHTS

A
2
1
B


BULB TRADE NUMBER
 FRONT SIDE MARKER : 1157 (8W)
 LICENSE PALTE (3HB) : 168 (5W)
 LICENSE PLATE (SEDAN) : 89 (7.5W)
 TAIL : 1157 (8W)
 REAR SIDE MARKER : 194 (3.8W)




F-29 FRONT SIDE
MARKER LIGHT LH (F)




F-30 FRONT SIDE
MARKER LIGHT RH (F)



R-05 LICENSE PLATE
LIGHT (R)




R-06 LICENSE PLATE
LIGHT LH (R)




R-07 LICENSE PLATE
LIGHT RH (R)




R-08 TAIL LIGHT LH (R)




R-09 TAIL LIGHT RH (R)




R-10 REAR SIDE
MARKER LIGHT LH (R)



R-11 REAR SIDE
MARKER LIGHT RH (R)









Z WIRING DIAGRAM

ILLUMINATION LAMPS


A
2
1
S
B



F-14 METER (F)



I-01 PANEL LIGHT CONTROL (I)




I-02 JOINT CONNECTOR (I)




I-03 CIGARETTE LIGHTER ILLUMINATION LAMP (I)




I-04 HAZARD SWITCH (I)



I-05 BLOWER SWITCH (I)




I-07 REAR WINDOW DEFROSTER SWITCH (I)



I-11 CRUISE CONTROL MAIN SWITCH (I)




I-12 AUDIO (I)




I-14 CENTER DIF-LOCK SWITCH (I)




R-02 EC-AT SELECT (R)




AC-09 A/C SWITCH (AC)




FI-01 FRONT (F) - INSTRUMENT PANEL (F)




* ... 4WD




FR-01 FRONT (F) - REAR (R)







() ... EC-AT <> ... CANADA * ... WITH PASSIVE SHOULDER BELT [] ... SEDAN * ... 4WD




FAC-01 FRONT (F) - A/C (AC)





Z WIRING DIAGRAM

TURN & HAZARD FLASHER LIGHTS



F-31 TURN SWITCH (F)

| | | | |
|-----|---|---|---|
| Y | * | * | * |
| B/Y | G | * | * |

CANADA
WITHOUT CRUISE
CONTROL


| | | | | | |
|----|----|-----|---|---|-----|
| ●* | ●* | G/O | Y | G | B/Y |
|----|----|-----|---|---|-----|

●...WITHOUT CRUISE CONTROL
EXCEPT CANADA
WITHOUT CRUISE
CONTROL


F-32 FLASHER UNIT (F)

| | | | |
|-----|---|-----|---|
| G/W | G | O | B |
| B/R | Y | G/B | * |



F-29 FRONT TURN LIGHT LH (F)



F-30 FRONT TURN LIGHT RH (F)




I-02 JOINT CONNECTOR (I)




I-04 HAZARD SWITCH (I)




R-08 REAR TURN LIGHT LH (R)




R-09 REAR TURN LIGHT RH (R)



FI-01 FRONT (F) - INSTRUMENT PANEL (I)





(I)




*...4WD

(BLACK)
F-30




JOINT BOX



F-29
(BLACK)

(EXCEPT CANADA WITHOUT
CRUISE CONTROL)
F-31



(BLUE)
F-32



JOINT BOX





FI-01
(BLUE)

F-31
(CANADA WITHOUT
CRUISE CONTROL)





Z WIRING DIAGRAM

- STOP LIGHTS
- SHIFT LOCK SYSTEM




() ... EC-AT <> ... CANADA
 * ... WITH PASSIVE SHOULDER BELT I ... SEDAN * ... 4WD



Z WIRING DIAGRAM

EXCEPT 4WD ■ HORN
 ■ BACK-UP LIGHTS



F-21 HORN SWITCH (F)

| | | |
|-----|-----|-----|
| G/O | R/L | * |
| R/B | R | R/W |

F-31 HORN SWITCH (F)

| | | | | | |
|----|----|-----|---|---|-----|
| ●* | ●* | G/O | Y | G | B/Y |
| R | B | | | | |

●...WITHOUT CRUISE CONTROL

F-34 HORN RELAY (F)

| | | |
|-----|-----|-----|
| G/Y | G/O | G/W |
| | G/W | |

F-35 HORN (F)

| | |
|-----|--|
| G/Y | |
|-----|--|

F-36 BACK-UP LIGHT SWITCH (F)

| | |
|-----|---|
| R/G | * |
| B/Y | * |

R-08 BACK-UP LIGHT LH (R)

| | | |
|---|-----|-----|
| * | R/G | G/B |
| B | R/B | G |

R-09 BACK-UP LIGHT RH (R)


| | | |
|---|-----|-----|
| * | R/G | G/W |
| B | R/B | G |

FR-01 FRONT (F) - REAR (R)

| | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|---------|-----|-----|
| R/L | L/Y | ** | L/B | * | Y | | G | R/G | B/P | L |
| W/L | L/O | R/Y | R/G | R/B | Y/L | B/G | W/R | (B/R/B) | (R) | W/G |
| B/G | * | O | * | G/Y | * | W/L | | * | * | |


| | | | | | | | | | |
|-----|-----|---------|-----|-----|-----|-----|-----|-----|-----|
| L | B/P | R/G | G | | Y | L/B | ** | L/Y | R/L |
| W/G | (R) | (B/R/B) | W/R | B/G | Y/L | R/B | R/Y | L/O | W/L |
| * | * | * | | W/L | * | G/Y | * | O | B/G |

()...EC-AT <>...CANADA
 *...WITH PASSIVE SHOULDER BELT I...SEDAN **...4WD



Z WIRING DIAGRAM

4WD
 ■ HORN
 ■ BACK-UP LIGHTS



F-21 HORN SWITCH (F)

| | | |
|-----|-----|-----|
| G/O | R/L | * |
| R/B | R | R/W |

F-31 HORN SWITCH (F)

| | | | | | |
|---|---|-----|---|---|-----|
| R | B | G/O | Y | G | B/Y |
|---|---|-----|---|---|-----|

F-34 HORN RELAY (F)

| | | |
|-----|-----|-----|
| G/Y | G/O | G/W |
| | G/W | |

F-35 HORN (F)

| | |
|-----|--|
| G/Y | |
|-----|--|

EM-18 BACK-UP LIGHT SWITCH (EM)

| | |
|-----|---|
| B/Y | * |
| R/G | * |

R-08 BACK-UP LIGHT LH (R)

| | | |
|---|-----|-----|
| * | R/G | G/B |
| B | R/B | G |

R-09 BACK-UP LIGHT RH (R)

| | | |
|---|-----|-----|
| * | R/G | G/W |
| B | R/B | G |

FR-01 FRONT (F) -REAR (R)

| | | | | | | | | | |
|------|-----|-----|-----|-----|-----|------|-----|---------|-----|
| R/L | L/Y | X* | L/B | Y | | G | R/G | B/P | L |
| X*/L | L/O | R/Y | R/G | R/B | Y/L | X*/B | G | (B/R/B) | (R) |
| B/G | * | O | * | G/Y | * | W/L | W/R | * | W/G |

| | | | | | | | | | |
|-----|-----|---------|-----|------|-----|------|------|-----|------|
| L | B/P | R/G | G | | Y | X*/L | X*/B | L/Y | R/L |
| W/G | (R) | (B/R/B) | W/R | X*/B | G | R/B | R/G | R/B | X*/R |
| * | * | * | W/L | * | G/Y | * | O | * | B/G |

() ... EC-AT <> ... CANADA
 * ... WITH PASSIVE SHOULDER BELT [] ... SEDAN X ... 4WD

FEM-02 FRONT (F) -EMISSION (EM)

| | | | | | | | | | |
|------|-----|-------|-------|-------|-----|---------|-------|---------|---------|
| B | Y/B | (L/G) | (R/W) | (G/R) | | (X) | <B/Y> | * | (L/G/W) |
| X*/R | G | L/Y | * | (W) | (R) | <B/R/W> | X*/R | G | X*/Y |
| * | L/Y | * | | G/Y | * | * | * | (B/L/G) | B/L |





| | | | | | | | | | |
|---------|-----|---------|-------|-----|-------|---------|-------|-----|------|
| (L/G/W) | * | <B/Y> | (*) | | (G/R) | (R/W) | (L/G) | Y/B | B |
| * | * | * | B/R/Y | | G | * | * | * | |
| (L/G/R) | B/L | (B/L/G) | X*/Y | W/X | R/G | <B/R/W> | (R) | (W) | X*/R |

() ... EC-AT <> ... CANADA X ... 4WD

FEM-03 FRONT (F) -EMISSION (EM)


| | | |
|------|-------|---|
| * | (B/L) | * |
| X*/B | Y | * |
| * | L | * |

() ... EC-AT X ... 4WD




Z WIRING DIAGRAM


EXCEPT 4WD ■ HEATER & AIR CONDITIONER




F-37 BLOWER MOTOR (F)




I-05 RESISTOR ASSEMBLY (I)




I-06 BLOWER SWITCH (I)



AC-01 CONDENSER FAN RELAY (AC)



AC-02 CONDENSER FAN (AC)




AC-03 REFRIGERANT PRESSURE SWITCH NO.2 (AC)



AC-04 DIODE (AC)



AC-05 A/C RELAY (AC)



AC-06 REFRIGERANT PRESSURE SWITCH NO. 1 (AC)




AC-07 MAGNETIC CLUTCH (AC)




AC-08 THERMO SWITCH (AC)




AC-09 A/C SWITCH (AC)





FI-01 FRONT (F) - INSTRUMENT PANEL (I)




*...4WD





FAC-01 FRONT (F) - A/C (AC)



FAC-02 FRONT (F) - A/C (AC)




()...EC-AT




Z WIRING DIAGRAM


4WD ■ HEATER & AIR CONDITIONER



F-37 BLOWER MOTOR (F)




F-43 WATER THERMO SWITCH (F)




I-05 RESISTOR ASSEMBLY (I)




I-06 BLOWER SWITCH (I)




AC-01 CONDENSER FAN RELAY (AC)



AC-02 CONDENSER FAN (AC)




AC-03 REFRIGERANT PRESSURE SWITCH NO. 2 (AC)



AC-04 DIODE (AC)



AC-05 A/C RELAY (AC)



AC-06 REFRIGERANT PRESSURE SWITCH NO. 1 (AC)



AC-07 MAGNETIC CLUTCH (AC)




AC-08 THERMO SWITCH (AC)




AC-09 A/C SWITCH (AC)





FI-01 FRONT (F) - INSTRUMENT PANEL (I)




* ... 4WD






FAC-01 FRONT (F) - A/C (AC)




FAC-02 FRONT (F) - A/C (AC)






JOINT BOX




Z WIRING DIAGRAM


- INTERIOR & SPOT LAMPS
- IGNITION KEY CYLINDER LAMP
- SOUND WARNING SYSTEM




F-05 JOINT CONNECTOR (F)




F-17 IGNITION KEY CYLINDER LAMP (F)




F-38 IGNITION KEY REMINDER SWITCH (F)




R-14 BUCKLE SWITCH (R)




R-15 DOOR SWITCH FL (R)




R-16 DOOR SWITCH FR (R)




R-17 DOOR SWITCH RL (R)



R-18 DOOR SWITCH RR (R)




IN-01 INTERIOR & SPOT LAMP (IN)




IN-02 SPOT LAMP (IN)







SU-01 SPOT LAMP (SU)




SU-02 GROUND (SU)






Z WIRING DIAGRAM

■ CARGO ROOM LAMP




R-19 CARGO ROOM LAMP (R)





R-20 CARGO ROOM LAMP SWITCH (R)





R3-03 CARGO ROOM LAMP (R3)




RR2-01 REAR (R) - REAR NO. 2 (R2)




R2R3-01 REAR NO. 2 (R2) - REAR NO. 3 (R3)





Z WIRING DIAGRAM


- DIGITAL CLOCK ▪ CIGARETTE LIGHTER
- REAR WINDOW DEFROSTER




I-02 JOINT CONNECTOR (I)




I-07 REAR WINDOW DEFROSTER SWITCH (I)




I-08 DIGITAL CLOCK (I)




I-09 CIGARETTE LIGHTER (I)





R-21 REAR WINDOW DEFROSTER (R)




R3-04 REAR WINDOW DEFROSTER (R3)







RR2-01 REAR (R) - REAR NO. 2 (R2) (R)




R2R3-02 REAR NO. 2 (R2) - REAR NO. 3 (R3)





■ POWER DOOR LOCK



F-39 POWER DOOR LOCK RELAY (F)

| | | | |
|---|---|-----|-----|
| * | G | G/O | B |
| * | R | G/R | W/G |

DR1-01 POWER DOOR LOCK SWITCH (DR1)

| |
|---------|
| L/R |
| G/O G/R |

DR2-01 POWER DOOR LOCK MOTOR (FR) (DR2)

| |
|---|
| R |
| G |

DR3-01 POWER DOOR LOCK MOTOR (RL) (DR3)

| |
|---|
| R |
| G |

DR4-01 POWER DOOR LOCK MOTOR (RR) (DR4)

| |
|---|
| R |
| G |

FDR1-01 FRONT (F) -DOOR NO.1 (DR1)

| | | | | | | | | | | |
|------|-----|-----|-----|-----|-----|-----|------|------|--|---|
| B/L | | B | | L/O | | LG | | BR/Y | | * |
| AL/Y | G/Y | Y/W | R/W | L/R | L/O | LG | BR/Y | * | | |
| *B | W/R | L/W | G/W | BR | V | G/O | * | G/R | | |
| * | | | | | | | | | | |

(DR1)

| | | | | | | | | | | |
|-----|------|-----|-----|-----|-----|-------|-------|------|---|---|
| B/W | | B | | L/O | | LG | | BR/Y | | * |
| * | BR/Y | LG | L/O | L/R | R/W | [Y/W] | [G/Y] | L/Y | | |
| G/R | * | G/O | V | BR | G/W | [L/W] | [W/R] | * | B | |
| | | | | | | | | | | |

*...WITH PASSIVE SHOULDER BELT []...SEDAN

FDR2-01 FRONT (F) -DOOR NO.2 (DR2)

| | | | | | | | | | |
|------|---|---|-----|-----|-----|----|------|---|--|
| B/L | | G | | L/O | | R | | * | |
| AL/C | * | * | R/W | * | W | LG | BR/B | * | |
| *B | * | * | G/W | BR | L/W | * | * | * | |
| * | | | | | | | | | |

(DR2)

| | | | | | | | | | |
|---|------|----|-----|-----|-----|-----|---|-----|--|
| R | | G | | L/O | | B/L | | * | |
| * | BR/B | LG | W | * | R/W | * | * | L/O | |
| * | * | * | L/W | BR | G/W | * | * | B | |
| | | | | | | | | | |

*...WITH PASSIVE SHOULDER BELT

FFR-01 FRONT (F) -FLOOR (FR)

| | | |
|-----|-----|-----|
| L/W | Y/W | R |
| B/L | G/Y | W/R |

| | | |
|---|-----|-----|
| R | Y/W | L/W |
| G | W/R | G/Y |

FRDR3-01 FLOOR (FR) -DOOR NO.3 (DR3)


| | |
|---|-----|
| R | B/L |
| G | W/R |

| | |
|-----|-----|
| B/L | R |
| L/W | Y/W |


FRDR4-01 FLOOR (FR) -DOOR NO.4 (DR4)

| | |
|---|-----|
| R | B/L |
| G | Y/W |


| | |
|-----|-----|
| B/L | R |
| L/W | Y/W |




■ REMOTE CONTROL MIRROR




I-02 JOINT CONNECTOR (I)




I-10 REMOTE CONTROL MIRROR SWITCH (I)



DR1-02 REMOTE CONTROL MIRROR MOTOR LH (DR1)





DR2-02 REMOTE CONTROL MIRROR MOTOR RH (DR2)



CONNECT



CONNECT

FI-01 FRONT (F) - INSTRUMENT PANEL (I)





*...4WD

FDR1-01 FRONT (F) - DOOR NO. 1 (DR1)




*...WITH PASSIVE SHOULDER BELT (I)...SEVAN

FDR2-01 FRONT (F) - DOOR NO. 2 (DR2)




*...WITH PASSIVE SHOULDER BELT




Z WIRING DIAGRAM

■ POWER WINDOW

A
2
1
S
B




DR1-03 POWER WINDOW MAIN SWITCH (DR1)



DR1-04 POWER WINDOW MOTOR FL (DR1)




DR2-03 POWER WINDOW SWITCH FR (DR2)



DR2-04 POWER WINDOW MOTOR FR (DR2)




DR3-02 POWER WINDOW SWITCH RL (DR3)



DR3-03 POWER WINDOW MOTOR RL (DR3)




DR4-02 POWER WINDOW SWITCH RR (DR4)



DR4-03 POWER WINDOW MOTOR RR (DR4)




FDR1-01 FRONT (F) -DOOR NO. 1 (DR1)




*... WITH PASSIVE SHOULDER BELT []... SEDAN

FDR2-01 FRONT (F) -DOOR NO. 2 (DR2)




*... WITH PASSIVE SHOULDER BELT


FFR-01 FRONT (F) -FLOOR (FR)




FRDR3-01 FLOOR (FR) -DOOR NO. 3 (DR3)




FRDR4-01 FLOOR (FR) -DOOR NO. 4 (DR4)






Z WIRING DIAGRAM

■ PASSIVE SHOULDER BELT CONTROL SYSTEM



F-40 LIMIT SWITCH RH (F)



R-15 PASSIVE SHOULDER BELT MOTOR LH (R)

| | | | |
|-----|-----|---|-----|
| R/W | | * | BR |
| B | Y/R | * | L/G |

R-16 PASSIVE SHOULDER BELT MOTOR RH (R)

| | | | |
|-----|---|---|-----|
| R/W | | * | Y/G |
| B | W | * | W/B |

R-22 PASSIVE SHOULDER BELT CONTROL UNIT (R)

| | | | | | | | | | |
|-----|-----|-----|-----|---|-----|-----|-----|-----|-----|
| U | S | Q | O | M | I | G | E | C | A |
| BR | Y/R | * | O/G | B | G/R | B/Y | * | W | Y/G |
| L/G | L/Y | Y/L | P | B | LG | Y | Y/B | L/B | L/O |
| V | T | R | P | N | L | J | H | F | D |

R-23 BUCKLE SWITCH (R)

| | |
|-----|---|
| O/G | P |
| B | B |

DR1-05 DOOR CATCH SWITCH LH (DR1)

| | |
|---|-----|
| B | L/Y |
| * | * |

3HB

| |
|-----|
| B |
| L/Y |

SEDAN

DR2-05 DOOR CATCH SWITCH RH (DR2)

| | |
|---|-----|
| B | L/O |
| * | * |

3HB

| |
|-----|
| B |
| L/O |

SEDAN

IN-03 LIMIT SWITCH LH (IN)



FR-01 FRONT (F) - REAR (R)

| | | | | | | | | | | | | | | | | | | | | |
|------|------|------|------|------|------|-----|-------|-----|-----|-----|-----|-------|-----|------|------|------|------|------|------|------|
| R/L | *L/Y | ** | L/B | Y | G | R/G | B/P | L | L | B/P | R/G | G | Y | *L/B | ** | *L/Y | R/L | | | |
| *W/L | *L/O | *R/Y | *G/R | *Y/L | *B/G | W/R | (R/B) | (R) | W/G | W/G | (R) | (R/B) | W/R | *B/G | *Y/L | *G/R | *G/T | *R/Y | *L/O | *W/L |
| B/G | * | O | * | G/Y | * | W/L | * | * | * | * | * | * | W/L | * | G/Y | * | O | * | B/G | |

() ... EC-AT <> ... CANADA * ... WITH PASSIVE SHOULDER BELT [] ... SEDAN % ... 4WD

FDR1-01 FRONT (F) - DOOR NO. 1 (DR1)

| | | | | | | | | | | | | | | | | | |
|------|-----|-----|-----|-----|----|------|---|-------|-----|-----|-----|-----|-----|-----|-----|-----|---|
| *L/Y | B/L | B | B/W | B/W | B | B/L | | | | | | | | | | | |
| *G/Y | Y/W | R/W | L/R | L/O | LG | BR/Y | * | *BR/Y | LG | L/O | L/R | R/W | Y/W | G/Y | L/Y | | |
| *B | W/R | L/W | G/W | BR | V | G/O | * | G/R | G/R | * | G/O | V | BR | G/W | L/W | W/R | B |


* ... WITH PASSIVE SHOULDER BELT [] ... SEDAN


FDR2-01 FRONT (F) - DOOR NO. 2 (DR2)

| | | | | | | | | | | | | | | | | |
|------|-----|-----|-----|----|-----|------|---|-------|-----|---|------|----|------|---|---|---|
| *L/O | B/L | G | R | R | G | B/L | | | | | | | | | | |
| *G/Y | Y/W | R/W | * | W | LG | BR/B | * | *BR/B | G/B | W | *R/W | * | *L/O | | | |
| *B | W/R | L/W | G/W | BR | L/W | * | * | * | * | * | L/W | BR | G/W | * | * | B |

* ... WITH PASSIVE SHOULDER BELT

FIN-01 FRONT (F) - INTERIOR LAMP (IN)









Z WIRING DIAGRAM


■ CRUISE CONTROL SYSTEM




F-05 JOINT CONNECTOR (F)



F-31 CRUISE CONTROL SWITCH (F)




F-41 STOP LIGHT SWITCH (F)



F-42 ACTUATOR (F)




F-43 CRUISE CONTROL UNIT (F)




() ... EC-AT


I-02 JOINT CONNECTOR (I)







I-11 CRUISE CONTROL MAIN SWITCH (I)














FI-02 FRONT (F) - INSTRUMENT PANEL (I)




• ... WITHOUT CRUISE CONTROL




4WD ■ CENTER DIF-LOCK SYSTEM





Z WIRING DIAGRAM


■ SLIDING SUNROOF




IN-02 SLIDING SUNROOF (IN)




SU-01 SLIDING SUNROOF SWITCH (SU)








SU-02 SLIDING SUNROOF MOTOR (SU)




SU-03 SLIDING SUNROOF RELAY (SU)







JB CONNECTOR LOCATION



JOINT BOX

JB-01 INTERIOR LAMP HARNESS

| | | |
|------|-----|-----|
| AG/O | R/W | L/R |
| * | | |
| C | B | A |

JB-02 INSTRUMENT PANEL HARNESS

| | | | | | |
|-----|-----|-----|-----|---|-----|
| J | I | G | E | C | A |
| L/R | R/B | B/Y | X | X | O/L |
| * | B/L | B/W | L/B | | * |
| K | H | F | D | B | |

JB-03 REAR HARNESS

| | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|
| N | L | K | I | G | E | C | A |
| * | LG | L/G | G/B | L/W | R/B | * | Y/B |
| G/W | B/Y | * | L/B | * | B/L | L/R | R/W |
| O | M | X | R/W | H | F | D | B |
| | | J | | | | | |

JB-04 FRONT HARNESS

| | | | | | | |
|-------|-----|-------|-----|-----|-----|-----|
| L | K | I | G | E | C | A |
| R/B | R/B | (B/Y) | B/Y | G/W | B/W | G/B |
| (B/W) | * | W/B | L/W | L | * | * |
| M | J | H | F | D | B | |

JB-05 FRONT HARNESS

| | | |
|-----|-----|-----|
| E | C | A |
| W/G | B/W | * |
| W/R | * | G/W |
| F | D | B |

JB-06 FRONT HARNESS

| | | |
|-----|-----|---|
| C | B | A |
| B/R | B/W | L |

JB-07 FRONT HARNESS

| | | | | | | | | | |
|------|-----|-----|-----|-------|---|-----|-----|-----|-----|
| S | X | R/W | Q | O | M | G | E | C | A |
| <<X> | L/B | B/L | G/W | B/Y | X | R/B | L/R | L/R | |
| B/R | L/G | G/B | * | (B/Y) | * | * | * | * | R/B |
| T | R | P | N | L | J | H | F | D | B |


JB-08 FRONT HARNESS


| | | | | | | | |
|---|---|----|---|---|---|---|-----|
| V | B | LG | W | * | * | * | O/L |
| H | G | F | E | D | C | B | A |

JB-09 CPU

| | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| P | O | N | M | L | K | J | I | H | G | F | E | D | C | B | A |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|


☆...WITH SUNROOF ★...WITH PASSIVE SHOULDER BELT
 ()...EC-AT <>...CANADA []...SEDAN X...4WD






FRONT HARNESS 1/2


Z WIRING DIAGRAM





FRONT HARNESS 2/2



Z WIRING DIAGRAM





INSTRUMENT PANEL HARNESS



ENGINE HARNESS




Z WIRING DIAGRAM





JOINT CONNECTOR & GROUND CIRCUIT

WIRING ORDER INTO JOINT CONNECTOR MAY BE CHANGED



PA
T
Y B
NEC
T
NEC

IT
SION
RUM
3
3)
JAN)



| | | | | |
|---------------|---------------------------|--------------|--------------|---------------|
| LOC. PART NO. | K1575E 9999-95-0276-90 | mazda | 10 K67795 | INV. LINE NO. |
| DESC. | 323 4WD W/DGM | | 11/01/89 | INV. DATE |
| QTY. ORD. | 1 | | 10828 | DLR. CODE |
| | SHIP | | | |

CUSTOMER SATISFACTION

© 1990 Mazda Motor Corporation
Mazda of America, Inc.
5145-10-39G

Part No. 9999-95-0276-90