

WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury and property damage increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing servicing operations. However, all users of this manual are expected to know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Nonrecommended procedures and tools should include consideration for safety of the technician and continued safe operation of the vehicle.

Parts should be replaced with genuine Mazda replacement parts, not parts of lesser quality. Use of a nonrecommended replacement part should include consideration for safety of the technician and continued safe operation of the vehicle.

VEHICLE IDENTIFICATION NUMBERS (VIN)

626

1YV GE22C*T5 500001—

1YV GE22D*T5 500001—

MX-6

1YV GE31C*T5 500001—

1YV GE31D*T5 500001—

1996 Mazda 626/MX-6 Workshop Manual

FOREWORD

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical—including photocopying and recording and the use of any kind of information storage and retrieval system—without permission in writing.

WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

| Title | | Section |
|-------------------------------------|----------|---------|
| General Information | | GI |
| Engine | FS | B1 |
| | KL | B2 |
| Lubrication System | FS | D1 |
| | KL | D2 |
| Cooling System | FS | E1 |
| | KL | E2 |
| Fuel and Emission Control Systems | FS (MTX) | F1 |
| | KL | F2 |
| | FS (ATX) | F3 |
| Engine Electrical System | | G |
| Clutch | | H |
| Manual Transaxle | G25M-R | J |
| Automatic Transaxle | GF4A-EL | K1 |
| | LA4A-EL | K2 |
| Front and Rear Axles | | M |
| Steering System | | N |
| Braking System | | P |
| Wheels and Tires | | Q |
| Suspension | | R |
| Body | | S |
| *Body Electrical System | | T |
| *Heater and Air Conditioner Systems | | U |

* Refer to the 1996 626/MX-6 Body Electrical Troubleshooting Manual (Form No.1493-10-95F, Part No.9999-95-084F-96) for servicing of the body electrical components.

© 1995 Mazda Motor Corporation
PRINTED IN THE U.S.A. JUNE, '95
Form No.1492-10-95F
Part No.9999-95-019B-96

GENERAL INFORMATION

| | |
|---|-------|
| SAFETY INFORMATION | GI- 2 |
| LUBRICANTS | GI- 2 |
| JACKING POSITIONS | GI- 2 |
| SAFETY STAND POSITIONS | GI- 2 |
| VEHICLE LIFT POSITIONS | GI- 3 |
| DYNAMOMETER | GI- 3 |
| COMPRESSED AIR | GI- 3 |
| HOW TO USE THIS MANUAL | GI- 4 |
| ADVISORY MESSAGES | GI- 4 |
| PREPARATION | GI- 4 |
| REPAIR PROCEDURE | GI- 4 |
| SYMBOLS | GI- 5 |
| IDENTIFICATION NUMBER LOCATIONS | GI- 6 |
| UNITS | GI- 7 |
| ABBREVIATIONS | GI- 8 |
| SAE STANDARDS | GI- 9 |
| FUNDAMENTAL PROCEDURES | GI-11 |
| PROTECTION OF THE VEHICLE | GI-11 |
| PREPARATION OF TOOLS AND MEASURING EQUIPMENT | GI-11 |
| SPECIAL TOOLS | GI-11 |
| REMOVAL OF PARTS | GI-11 |
| DISASSEMBLY | GI-11 |
| REASSEMBLY | GI-12 |
| ADJUSTMENTS | GI-13 |
| RUBBER PARTS AND TUBING | GI-13 |
| HOSE CLAMPS | GI-13 |
| TORQUE FORMULAS | GI-13 |
| VISE | GI-13 |
| ELECTRICAL TROUBLESHOOTING TOOLS ... | GI-14 |
| TEST LIGHT | GI-14 |
| JUMPER WIRE | GI-14 |
| VOLTMETER | GI-14 |
| OHMMETER | GI-14 |
| ELECTRICAL PARTS | GI-15 |
| BATTERY CABLE | GI-15 |
| CONNECTORS | GI-15 |
| TERMINALS | GI-16 |
| SENSORS, SWITCHES, AND RELAYS | GI-16 |
| WIRING HARNESS | GI-17 |
| MAIN FUSE BLOCK | GI-17 |
| FUSE BLOCK | GI-17 |
| INSTALLATION OF RADIO SYSTEM | GI-18 |
| TOWING | GI-19 |
| PRE-DELIVERY INSPECTION | GI-20 |
| PRE-DELIVERY INSPECTION TABLE | GI-20 |
| SCHEDULED MAINTENANCE | GI-21 |
| MAINTENANCE TABLE (EXCEPT CANADA) .. | GI-21 |
| MAINTENANCE TABLE (CANADA) | GI-24 |

SAFETY INFORMATION

LUBRICANTS

Avoid prolonged and repeated contact with petroleum-based oils. Used oil may irritate the skin, and can cause skin cancer and other skin disorders.

Wash thoroughly after working with oil. We recommend water soluble hand cleaners. Do not use kerosene, gasoline, or any other solvent, to remove oil from your skin.

If repeated or prolonged contact with oil is necessary, wear protective clothing. Soiled clothing, particularly those soiled with used oils and greases containing lead, should be cleaned at regular intervals.

JACKING POSITIONS


Warning

- **Improperly jacking a vehicle is dangerous. The vehicle can slip off the jack and cause serious injury. Use only the correct front and rear jacking positions and block the wheels.**

Use safety stands to support the vehicle after it has been lifted.


Front

At the center of the crossmember



Rear


At the center of the crossmember



SAFETY STAND POSITIONS


Front

Both sides of the vehicle



Rear

Both sides of the vehicle




VEHICLE LIFT POSITIONS


GI

Front

Both sides of the side sill

**Rear**

Both sides of the side sill

**DYNAMOMETER**

When test-running a vehicle on a dynamometer:

- Place a fan, preferably a vehicle-speed proportional type, in front of the vehicle.
- Connect an exhaust gas ventilation unit.
- Cool the exhaust pipes with a fan.
- Keep the area around the vehicle uncluttered.
- Watch the water temperature gauge.

COMPRESSED AIR

When using compressed air to clean or remove parts:

- Wear protective eye wear.
- Hold a rag over the opening to prevent parts from shooting out.
- Take precautions so that people around you are not struck by flying debris.

HOW TO USE THIS MANUAL

ADVISORY MESSAGES

You'll find several **Warnings**, **Cautions**, and **Notes** in this manual.

Warning

- A **Warning** indicates a situation in which serious injury or death could result if the warning is ignored.

Caution

- A **Caution** indicates a situation in which damage to the vehicle could result if the caution is ignored.


Note

- A **Note** provides added information that will help you to complete a particular procedure.

PREPARATION

This points out the needed **SSTs** for the service operation. It is best to gather all necessary **SSTs** before beginning work.

Example:



REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.


Example:

SHOWS SPECIAL SERVICE TOOL (SST) FOR THE SERVICE OPERATION

SHOWS EXPENDABLE PARTS

SHOWS APPLICATION POINT OF OIL, ETC.

SHOWS RELATED PAGE FOR SERVICE



SHOWS TIGHTENING TORQUE SPECIFICATIONS

SHOWS TIGHTENING TORQUE UNITS

SHOWS VISUAL INSPECTION INFORMATION

*1: The numbers (①, etc.) refer to part identification and servicing procedures.


SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.


| Symbol | Meaning | Kind |
|--------|---------------------------------|---|
| | Apply oil | New engine oil or gear oil as appropriate |
| | Apply brake fluid | FMVSS116: DOT-3 |
| | Apply automatic transaxle fluid | M-III or Dexron®II |
| | Apply grease | Appropriate grease |
| | Apply sealant | Appropriate sealant |
| | Apply petroleum jelly | Appropriate petroleum jelly |

IDENTIFICATION NUMBER LOCATIONS


VEHICLE IDENTIFICATION NUMBER (VIN)




AUTOMATIC TRANSAXLE MODEL AND NUMBER



ENGINE MODEL AND NUMBER
FS ENGINE



KL ENGINE



UNITS

| | |
|--------------------|---|
| Electrical current | A (ampere) |
| Electric potential | V (volt) |
| Electric power | W (watt) |
| Length | mm (millimeter) in (inch) |
| Negative pressure | kPa (kilo Pascal) mmHg (millimeters of mercury) inHg (inches of mercury) |
| Positive pressure | kPa (kilo Pascal) kgf/cm ² (kilogram force per square centimeter) psi (pounds per square inch) |
| Resistance | Ω (ohm) |
| Torque | N·m (Newton meter) kgf·m (kilogram force per meter) kgf·cm (kilogram force per centimeter) ft·lbf (foot pound) in·lbf (inch pound) |
| Volume | L (liter) US qt (U.S. quart) Imp qt (Imperial quart) ml (milliliter) cc (cubic centimeter) cu in (cubic inch) fl oz (fluid ounce) |
| Weight | g (gram) oz (ounce) |

Conversion to SI Units (Système International d’Unités)

All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

Rounding off

Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

Upper and lower limits

When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7 kgf/cm² in the following specifications:

- 210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}
- 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

The actual converted values for 2.7 kgf/cm² are 264 kPa and 38.4 psi. In the top specification, 2.7 is used as an upper limit, so its converted values are rounded down to 260 and 38. In the bottom specification, 2.7 is used as a lower limit, so its converted values are rounded up to 270 and 39.

ABBREVIATIONS

| | |
|---------|--|
| ABDC | After bottom dead center |
| ABS | Antilock brake system |
| ACC | Accessory |
| A/CP SW | A/C pressure switch |
| ATDC | After top dead center |
| ATF | Automatic transaxle fluid |
| ATFT | Transaxle fluid temperature |
| ATFT V | Transaxle fluid temperature signal voltage |
| ATX | Automatic transaxle |
| BAC | Bypass air control |
| BARO V | Barometric pressure signal voltage |
| BBDC | Before bottom dead center |
| BDC | Bottom dead center |
| BLR SW | Fan switch |
| BRK SW | Brake switch |
| BTDC | Before top dead center |
| CM | Control module |
| CTP SW | Closed throttle position switch |
| D range | Drive range |
| DEF SW | Rear window defroster switch |
| DRL | Daytime running light |
| D SW | Transaxle range switch (D range) |
| ECT V | Engine coolant temperature signal voltage |
| EGRBV | EGR boost sensor solenoid valve |
| EGRP V | EGR valve position signal voltage |
| EGRVAC | EGR solenoid valve (vacuum) duty value |
| EGRVENT | EGR solenoid valve (vent) duty value |
| ESPS | Engine speed sensing power steering |
| EX | Exhaust |
| FANC | Coolant fan control |
| FANCH | Coolant fan control (hi) |
| FANCN | Coolant fan, condenser fan control |
| FANNH | Condenser fan control (hi) |
| FHO2S | Heated oxygen sensor (front) |
| FHO2S L | Heated oxygen sensor (front LH) |
| FHO2S R | Heated oxygen sensor (front RH) |
| FHO2SH | Heated oxygen sensor heater (front) |
| FHO2SHL | Heated oxygen sensor heater (front LH) |
| FHO2SHR | Heated oxygen sensor heater (front RH) |
| FMEM | Failure mode effects management |
| HDL SW | Headlight switch |
| HLA | Hydraulic lash adjuster |
| HU | ABS hydraulic unit |
| IACV | Idle air control valve |
| IAT V | Intake air temperature signal voltage |
| IC | Integrated circuit |
| IDM | Ignition diagnostic monitor |
| IG | Ignition |
| IG SW | Ignition switch |
| IGT | Ignition timing |
| IN | Intake |
| INJ | Fuel injection duration |
| INJ L | Fuel injection duration (left bank) |
| INJ R | Fuel injection duration (right bank) |
| INJ#1 | Fuel injector (cylinder No.1) |
| KAM | Keep alive memory |
| KOEO | Key on engine off |
| KOER | Key on engine running |
| KR | Knocking retard |
| LH | Left hand |

| | |
|------------|--|
| LINE | LINE pressure solenoid valve duty value |
| L SW | Transaxle range switch (L or 1 range) |
| M | Motor |
| MAF RTN | Mass airflow return |
| MAF V | Mass air flow signal voltage |
| MTX | Manual transaxle |
| N position | Neutral position |
| NL SW | Neutral/clutch switch |
| O/D | Overdrive |
| O/DF LP | O/D OFF indicator light |
| O/DF SW | O/D OFF switch |
| P position | Park position |
| PCV | Positive crankcase ventilation |
| PRC | Pressure regulator control |
| PRCV | PRC solenoid valve |
| PRGV | Purge solenoid valve |
| P/S | Power steering |
| PWR GND | Power ground |
| R | Reverse |
| RH | Right hand |
| RHO2S | Heated oxygen sensor (rear) |
| RHO2S L | Heated oxygen sensor (rear LH) |
| RHO2S R | Heated oxygen sensor (rear RH) |
| RLY | Relay |
| RPM | Engine speed |
| R SW | Transaxle range switch (R position) |
| SAS | Sophisticated air bag sensor |
| SHIFT A | Shift solenoid A |
| SHIFT B | Shift solenoid B |
| SHIFT C | Shift solenoid C |
| SIG RTN | Signal return |
| SS1 | Shift solenoid No.1 |
| SS2 | Shift solenoid No.2 |
| SST | Special service tool |
| S SW | Transaxle range switch (S or 2 range) |
| SW | Switch |
| TCC CON | Torque converter clutch control solenoid valve |
| TEN | TEN terminal (Data link connector) |
| TFT | Transaxle fluid temperature |
| TNS | Tail number side lights |
| TP V | Throttle position sensor signal voltage |
| TSS | Turbine shaft speed |
| TURBINE | Input/turbine speed sensor |
| VAF V | Volume air flow signal voltage |
| VPWR | Vehicle power |
| VRIS | Variable inertia charging system |
| VRISV1 | VRIS solenoid valve No.1 |
| VRISV2 | VRIS solenoid valve No.2 |
| VS | Vehicle speed |
| 1GR | First gear |
| 2GR | Second gear |
| 3-2T/CCS | 3-2 timing/coasting clutch solenoid |
| 3-2TIME | 3-2 Timing solenoid valve |

SAE STANDARDS

In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

| Previous Standard | | SAE Standard | | |
|-------------------|--------------------------------------|--------------|---|--------|
| Abbreviation | Name | Abbreviation | Name | Remark |
| — | Accelerator Pedal | AP | Accelerator Pedal | |
| — | Air Cleaner | ACL | Air Cleaner | |
| — | Air Conditioning | A/C | Air Conditioning | |
| — | Airflow Meter | VAF | Volume Air Flow Sensor | |
| — | Airflow Sensor | MAF | Mass Air Flow Sensor | |
| — | Alternator | GEN | Generator | |
| — | ATF Thermosensor | — | Transmission (Transaxle) Fluid Temperature Sensor | |
| — | Atmospheric Pressure | BARO | Barometric Pressure | |
| VB | Battery Voltage | B+ | Battery Positive Voltage | |
| — | Catalytic Converter | OC | Oxidation Catalytic Converter | |
| | | TWC | Three-way Catalytic Converter | |
| | | WU-TWC | Warm Up Three-way Catalytic Converter | #1 |
| — | Circuit Opening Relay | FPR | Fuel Pump Relay | #2 |
| — | Clutch Position | CPP | Clutch Pedal Position | |
| — | Crank Angle Sensor | CMP | Camshaft Position Sensor | |
| — | Crank Angle Sensor 2 | CKP | Crankshaft Position Sensor | |
| — | Diagnosis Connector | DLC | Data Link Connector | |
| — | Diagnosis/Self-Diagnosis | OBD | On-Board Diagnostic | |
| — | Direct Ignition | DLI | Distributorless Ignition | |
| — | EC-AT Control Unit | TCM | Transmission (Transaxle) Control Module | |
| EGI | Electronic Gasoline Injection System | CIS | Continuous Fuel Injection System | |
| — | Electronic Spark Ignition | EI | Electronic Ignition | #3 |
| ECU | Engine Control Unit | PCM | Powertrain Control Module | #4 |
| | | ECM | Engine Control Module | |
| — | Engine Modification | EM | Engine Modification | |
| — | Engine RPM Signal | — | Engine Speed Input Signal | |
| — | Evaporative Emission | EVAP | Evaporative Emission | |
| — | Exhaust Gas Recirculation | EGR | Exhaust Gas Recirculation | |
| — | Fan Control | FC | Fan Control | |
| — | Feedback System | CLS | Closed Loop System | |
| — | Flexible Fuel | FF | Flexible Fuel | |
| — | Fuel Pump | FP | Fuel Pump | |
| — | Fully Closed | CTP | Closed Throttle Position | |
| — | Fully Open | WOT | Wide Open Throttle | |
| — | Ground/Earth | GND | Ground | |

#1: Directly connected to exhaust manifold


#2: In some models, there is a fuel pump relay that controls pump speed. That relay is now called the fuel pump relay (speed).

#3: Controlled by the ECM (PCM)

#4: Device that controls engine and powertrain

| Previous Standard | | SAE Standard | | |
|-------------------|--------------------------------|--------------|--------------------------------------|------------------------|
| Abbreviation | Name | Abbreviation | Name | Remark |
| — | IC Regulator | VR | Voltage Regulator | |
| — | Idle Speed Control | IAC | Idle Air Control | |
| — | Idle Switch | — | Closed Throttle Position Switch | |
| — | Igniter | ICM | Ignition Control Module | |
| — | Inhibitor Position | TR | Transmission (Transaxle) Range | |
| — | Intake Air Pressure | MAP | Manifold Absolute Pressure | |
| — | Intake Air Thermo | IAT | Intake Air Temperature | |
| — | Intercooler | CAC | Charge Air Cooler | |
| — | Knock Sensor | KS | Knock Sensor | |
| — | Line Pressure Solenoid Valve | — | Pressure Control Solenoid | |
| — | Lock-up Position | TCC | Torque Converter Clutch | |
| — | Malfunction Indicator Light | MIL | Malfunction Indicator Lamp | |
| — | Multiport Fuel Injection | MFI | Multiport Fuel Injection | |
| — | Open Loop | OL | Open Loop | |
| — | Overdrive | 4GR | Fourth Gear | |
| — | Oxygen Sensor | HO2S | Heated Oxygen Sensor | With heater |
| | | O2S | Oxygen Sensor | |
| — | Park/Neutral Range | PNP | Park/Neutral Position | |
| — | Power Steering Pressure | PSP | Power Steering Pressure | |
| — | Pulse Generator | — | Input/Turbine Speed Sensor | |
| — | Reed Valve | SAPV | Secondary Air Pulse Valve | |
| — | Secondary Air Injection System | PAIR | Pulsed Secondary Air Injection | Pulsed injection |
| | | AIR | Secondary Air Injection | Inject with compressor |
| — | Sequential Fuel Injection | SFI | Sequential Multipoint Fuel Injection | |
| — | Service Code(s) | DTC | Diagnostic Trouble Code(s) | |
| — | Spark Ignition | DI | Distributor Ignition | |
| — | Stoplight Switch | — | Brake Switch | |
| — | Test Mode | DTM | Diagnostic Test Mode | #5 |
| — | Throttle Body | TB | Throttle Body | |
| — | Throttle Sensor | TP | Throttle Position Sensor | |
| — | Turbocharger | TC | Turbocharger | |
| — | Vehicle Speed Sensor | VSS | Vehicle Speed Sensor | |
| — | Vehicle Speed Sensor 1 | — | Output Speed Sensor | |
| — | Water Thermo | ECT | Engine Coolant Temperature | |
| — | 1-2 Shift Solenoid Valve | — | Shift Solenoid A | |
| | Shift A Solenoid Valve | | | |
| — | 2-3 Shift Solenoid Valve | — | Shift Solenoid B | |
| | Shift B Solenoid Valve | | | |
| — | 3-4 Shift Solenoid Valve | — | Shift Solenoid C | |
| — | 3rd Gear | 3GR | Third Gear | |
| — | — | — | Incorrect Gear Ratio | |


#5: Diagnostic trouble codes depend on the diagnostic test mode



FUNDAMENTAL PROCEDURES


PROTECTION OF THE VEHICLE

Always be sure to cover fenders, seats, and floor areas before starting work.




PREPARATION OF TOOLS AND MEASURING EQUIPMENT

Be sure that all necessary tools and measuring equipment are available before starting any work.




SPECIAL TOOLS

Use special tools when they are required.




REMOVAL OF PARTS

While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair. After removing the part, plug all holes and ports to prevent foreign material from entering.




DISASSEMBLY

If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



1. Inspection of parts


When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.



2. Arrangement of parts

All disassembled parts should be carefully arranged for reassembly.

Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.




3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.



REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.


If removed, these parts should be replaced with new ones:

- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:


1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.






ADJUSTMENTS

Use suitable gauges and testers when making adjustments.




RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.



HOSE CLAMPS

When reinstalling, position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.




TORQUE FORMULAS

When using a torque wrench-SST combination, the written torque must be recalculated due to the extra length that the SST adds to the torque wrench. Recalculate the torque by using the following formulas. Choose the formula that applies to you.


| Torque Unit | Formula |
|-------------|-------------------------------------|
| N·m | $N \cdot m \times [L / (L + A)]$ |
| kgf·m | $kgf \cdot m \times [L / (L + A)]$ |
| kgf·cm | $kgf \cdot cm \times [L / (L + A)]$ |
| ft·lbf | $ft \cdot lbf \times [L / (L + A)]$ |
| in·lbf | $in \cdot lbf \times [L / (L + A)]$ |

A = The length of the SST past the torque wrench drive.
 L = The length of the torque wrench.



WISE

When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




ELECTRICAL TROUBLESHOOTING TOOLS

TEST LIGHT

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

Caution

- Using a bulb over 3.4W when checking the control unit may damage the control unit.




JUMPER WIRE

A jumper wire is used to create a temporary circuit. Connect the jumper wire between the terminals of a circuit to bypass a switch.


Caution

- Do not connect a jumper wire from the power source line to a body ground; this may cause burning or other damage to wiring harnesses or electronic components.



VOLTMETER

The DC voltmeter is used to measure circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.




OHMMETER

The ohmmeter is used to measure the resistance between two points in a circuit, and to check for continuity and short circuits.

Caution


- Do not connect the ohmmeter to any circuit to which voltage is applied; this will damage the ohmmeter.



ELECTRICAL PARTS

BATTERY CABLE

Before disconnecting connectors or removing electrical parts, disconnect the negative battery cable.




CONNECTORS

Data Link Connector

Insert the probe into the service hole when connecting a jumper wire to the data link connector.


Caution

- Inserting a jumper wire probe into the data link connector terminal may damage the terminal.




Disconnecting Connectors

When disconnecting two connectors, grasp the connectors, not the wires.




Connectors can be disconnected by pressing or pulling the lock lever as shown.




Locking connector

When locking connectors, listen for a click that will indicate they are securely locked.

**Inspection**


1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wiring harness side.




2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wiring harness side.

Caution

- To prevent damage to the terminal, wrap a thin wire around the lead before inserting it into the terminal.


**TERMINALS****Inspection**

Pull lightly on individual wires to check that they are secured in the terminal.


**Replacement**

Use the appropriate tools to remove a terminal as shown. When installing a terminal, be sure to insert it until it locks securely.

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.

**SENSORS, SWITCHES, AND RELAYS**


Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.

**WIRING HARNESS****Wiring color codes**


Two-color wires are indicated by a two-color code symbol.

The first letter indicates the base color of the wire and the second the color of the stripe.

| CODE | COLOR | CODE | COLOR |
|------|-------------|------|--------|
| B | Black | O | Orange |
| BR | Brown | P | Pink |
| G | Green | R | Red |
| GY | Gray | V | Violet |
| L | Blue | W | White |
| LB | Light Blue | Y | Yellow |
| LG | Light Green | — | — |

**MAIN FUSE BLOCK****Cartridge Fuse (100A)****Removal / Installation**

1. Disconnect the negative battery cable.
2. Open the main fuse block lid.
3. Remove the bolts.
4. Remove **MAIN 100A** fuse.
5. Install in the reverse order of removal.

**FUSE BLOCK****Removal / Installation**

1. Remove the fuse block cover.
2. Use the puller found on the fuse block cover to remove the fuses. If one or more of the fuses are burnt, check for a short in the harness.

Caution

- Determine and correct the cause of the burnt fuse before replacing it. If the fuse is replaced before doing this, it may burn again.


3. Install in the reverse order of removal.





INSTALLATION OF RADIO SYSTEM

If a radio system is installed improperly or if a high-powered type is used, the CIS and other systems may be affected.

When the vehicle is to be equipped with a radio, observe the following precautions:

1. Install the antenna at the farthest point from control modules.
2. Install the antenna feeder as far as possible from the control module harnesses (**at least 30 cm {11.8 in}**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered radio system.





TOWING

Proper towing equipment is necessary to prevent damage to the vehicle.

Laws and regulations applicable to vehicles in tow must always be observed.

As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

With either automatic or manual transaxle:

1. Set the ignition switch in the ACC position;
2. Place the selector lever or shift lever in N (Neutral);
3. Release the parking brake.

Caution

- Do not tow the vehicle backward with driving wheels on the ground. This may cause internal damage to the transaxle.

Caution

- Don't use the hook loops under the front and rear for towing. They are designed **ONLY** for tying down the vehicle when it's being transported. Using them for towing will damage the bumper.

PRE-DELIVERY INSPECTION

PRE-DELIVERY INSPECTION TABLE

The following items may be done at any time prior to delivery to your customer.

EXTERIOR

INSPECT and **ADJUST**, if necessary, the following items to specification:

- Glass, exterior bright metal and paint for damage
- Wheel lug nuts and locks (if equipped)
89—117 N·m {9—12 kgf·m, 66—86 ft·lbf}
- All weatherstrips for damage or detachment
- Operation of hood release and lock
- Operation of trunk lid and fuel lid opener
- Door operation and alignment
- Headlight aim

INSTALL the following parts:

- Wheel caps

UNDER HOOD—ENGINE OFF

INSPECT and **ADJUST**, if necessary, the following items to specification:

- Fuel, engine coolant, and hydraulic lines, fittings, connections, and components for leaks
- Engine oil level
- Power steering fluid level
- Brake (clutch) fluid level
- Windshield washer reservoir fluid level
- Radiator coolant level
- Tightness of battery terminals
- Manual transaxle oil level

INTERIOR

CHECK the operations of the following items:

- Seat controls (slide and recline) and headrests
- Folding rear seat
- Door locks, including childproof door locks (if equipped)
- Seat belts and warning system
- Ignition switch and steering lock
- Air bag system by using warning light
- Cruise set
- Shift-lock system and transaxle range switch (ATX only)
- Starter interlock switch (clutch pedal, MTX only)
- All lights including warning, and indicator lights
- Sound warning system
- Horn, wipers, and washers
- Audio system (if equipped)
- Cigarette lighter and clock
- Sunroof (if equipped)
- Power outside mirrors (if equipped)
- Power windows (if equipped)
- Heater, defroster, and air conditioner at various mode selections (if equipped)

CHECK the following items:

- Presence of spare fuse
- Upholstery and interior finish

CHECK and **ADJUST**, if necessary, the following items:

- Pedal height and free play of brake and clutch pedal

| | Pedal height mm {in} | Free play mm {in} |
|--------------|---|---------------------|
| Clutch pedal | 186—211 {7.32—8.31} (with carpet) | 5—14 {0.20—0.55} |
| Brake pedal | 191.5—196.5 {7.54—7.74} (with carpet) | 4—12 {0.16—0.47} |

- Parking brake

5—7 notches/98 N {10 kgf, 22 lbf}

UNDER HOOD—ENGINE RUNNING AT OPERATING TEMPERATURE

CHECK the following items:

- Automatic transaxle fluid level
- Operation of idle-up system for electrical load, air conditioner or power steering (if equipped)
- Ignition timing (except FS ATX model)
- Idle speed

ON HOIST

CHECK the following items:

- Underside fuel, coolant and hydraulic lines, fittings, connections, and components for leaks
- Tires for cuts or bruises
- Steering linkage, suspension, exhaust system, and all underside hardware for looseness or damage

ROAD TEST

CHECK the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of gauges
- Squeaks, rattles, and unusual noises
- Emergency locking retractors
- Cruise control system (if equipped)

AFTER ROAD TEST

CHECK for necessary owner information materials, tools, and spare tire in vehicle

The following items must be done just before the delivery to your customer.

- Load test battery and charge if necessary
- Adjust tire pressure to specification
(Refer to door label)
- Clean outside of vehicle

| |
|------------------|
| Volts |
| Load test result |

- Install fuses for accessories
- Remove seat and cabin carpet protective covers
- Vacuum inside of vehicle

SCHEDULED MAINTENANCE**MAINTENANCE TABLE (EXCEPT CANADA)****Schedule 1 (Normal driving conditions)**

The vehicle is mainly operated where none of the “unique driving conditions” apply.

Chart symbols:

- I : Inspect and repair, clean, or replace if necessary.
- R : Replace
- L : Lubricate

Remarks:

- After 48 months or 60,000 miles {96,000 km}, continue to follow the described maintenance at the recommended intervals.
 - *1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
 - *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule 2 (Unique driving conditions)

- Repeated short-distance driving.
- Driving in dusty conditions.
- Driving with extended use of brakes.
- Driving in areas where road salt or other corrosive materials are used.
- Driving on rough or muddy roads.
- Extended periods of idling or low-speed operation.
- Driving for long prolonged periods in cold temperatures or extremely humid climates.

Chart symbols:

- I : Inspect and repair, clean, or replace if necessary. (Inspect, and if necessary replace Air cleaner element only)
- R : Replace
- L : Lubricate

Remarks:

- After 48 months or 60,000 miles {96,000 km}, continue to follow the described maintenance at the recommended intervals.
 - *1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
 - *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

Schedule 1 (Normal driving conditions)

| Maintenance Interval | Number of months or miles {kilometers}, whichever comes first | | | | | | | | | |
|----------------------|---|------------|-----|----|------|----|------|----|------|----|
| | Months | 6 | 12 | 18 | 24 | 30 | 36 | 42 | 48 | |
| | × 1000 | Kilometers | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 |
| Maintenance Item | | Miles | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | 60 |

Engine

| | | | | | | | | | | |
|---------------------------------|--|---|---|---|---|---|---|---|---|-----------------|
| Engine oil | R | R | R | R | R | R | R | R | R | |
| Oil filter | R | R | R | R | R | R | R | R | R | |
| Tension of all drive belts | | | | I | | | | | I | |
| Engine timing belt | Replace every 60,000 miles {96,000 km} | | | | | | | | | |
| Engine timing belt (California) | * ² Inspect at 60,000 miles {96,000 km}, and again at 90,000 miles {144,000 km} | | | | | | | | | |
| | Replace every 105,000 miles {168,000 km} | | | | | | | | | |
| Hose and tube for emission | | | | | | | | | | I* ² |

Air cleander

| | | | | | | | | | | |
|---------------------|--|--|--|--|---|--|--|--|--|---|
| Air cleaner element | | | | | R | | | | | R |
|---------------------|--|--|--|--|---|--|--|--|--|---|

Ignition system

| | | | | | | | | | | |
|-------------|--|--|--|--|---|--|--|--|--|---|
| Spark plugs | | | | | R | | | | | R |
|-------------|--|--|--|--|---|--|--|--|--|---|

Fuel system

| | | | | | | | | | | |
|--------------------------|--|--|--|--|-----------------|--|--|--|--|-----------------|
| Idle speed* ² | | | | | I* ² | | | | | I* ¹ |
| Fuel filter | | | | | | | | | | R* ¹ |
| Fuel lines and hoses | | | | | I* ² | | | | | I* ¹ |
| Fuel hose (California) | Inspect every 105,000 miles {168,000 km} | | | | | | | | | |

Cooling system

| | | | | | | | | | | |
|----------------|---|--|--|--|---|--|--|--|--|---|
| Cooling system | | | | | I | | | | | I |
| Engine coolant | Replace at first 45,000 miles {72,000 km} or 36 months; after that, every 30,000 miles {48,000 km} or 24 months | | | | | | | | | |

Chassis and body

| | | | | | | | | | | |
|------------------------------------|---|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections | | | | | I | | | | | I |
| Disc brakes | | | | | I | | | | | I |
| Drum brakes | | | | | I | | | | | I |
| Steering operation and linkages | | | | | I | | | | | I |
| Front suspension ball joints | | | | | I | | | | | I |
| Drive shaft dust boots | | | | | I | | | | | I |
| Bolts and nuts on chassis and body | | | | | I | | | | | I |
| Exhaust system heat shield | | | | | I | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L | L |

Air conditioner system (if equipped)

| | | | | | | | | | | |
|-------------|--|---|--|--|---|--|--|---|--|---|
| Refrigerant | | I | | | I | | | I | | I |
| Compressor | | I | | | I | | | I | | I |

Schedule 2 (Unique driving conditions)

| Maintenance Interval | Number of months or miles {kilometers}, whichever comes first | | | | | | | | | | | | |
|----------------------|---|------------|---|----|----|----|----|----|----|----|----|----|----|
| | Months | 4 | 8 | 12 | 16 | 20 | 24 | 28 | 32 | 36 | 40 | 44 | 48 |
| | × 1000 | Kilometers | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 |
| Maintenance Item | | Miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 |

Engine

| | | | | | | | | | | | | | |
|---------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|-----|
| Engine oil | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Engine oil (Puerto Rico) | Replace every 3,000 miles {4,800 km} or 3 months | | | | | | | | | | | | |
| Oil filter | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Tension of all drive belts | | | | | | | I | | | | | | I |
| Engine timing belt | Replace every 60,000 miles {96,000 km} | | | | | | | | | | | | |
| Engine timing belt (California) | *2Inspect at 60,000 miles {96,000 km}, and again at 90,000 miles {144,000 km} | | | | | | | | | | | | |
| | Replace every 105,000 miles {168,000 km} | | | | | | | | | | | | |
| Hose and tube for emission | | | | | | | | | | | | | I*2 |

Air cleander

| | | | | | | | | | | | | | | |
|---------------------|--|--|--|-----|--|--|---|--|--|--|--|-----|--|---|
| Air cleaner element | | | | I*2 | | | R | | | | | I*2 | | R |
|---------------------|--|--|--|-----|--|--|---|--|--|--|--|-----|--|---|

Ignition system

| | | | | | | | | | | | | | | |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|--|---|
| Spark plugs | | | | | | | R | | | | | | | R |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|--|---|

Cooling system

| | | | | | | | | | | | | | | |
|----------------|---|--|--|--|--|--|---|--|--|--|--|--|--|---|
| Cooling system | | | | | | | I | | | | | | | I |
| Engine coolant | Replace at first 45,000 miles {72,000 km} or 36 months; after that, every 30,000 miles {48,000 km} or 24 months | | | | | | | | | | | | | |

Fuel system

| | | | | | | | | | | | | | | |
|------------------------|--|--|--|--|--|--|-----|--|--|--|--|--|--|-----|
| Fuel filter | | | | | | | | | | | | | | R*1 |
| Fuel lines and hoses | | | | | | | I*2 | | | | | | | I*1 |
| Idle speed | | | | | | | I*2 | | | | | | | I*1 |
| Fuel hose (California) | Inspect every 105,000 miles {168,000 km} | | | | | | | | | | | | | |

Chassis and body

| | | | | | | | | | | | | | | |
|------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections | | | | | | | I | | | | | | | I |
| Drum brakes | | | | | | | I | | | | | | | I |
| Disc brakes | | | | I | | | I | | | I | | | | I |
| Steering operation and linkages | | | | | | | I | | | | | | | I |
| Front suspension ball joints | | | | | | | I | | | | | | | I |
| Drive shaft dust boots | | | | | | | I | | | | | | | I |
| Bolts and nuts on chassis and body | | | | I | | | I | | | I | | | | I |
| Exhaust system heat shield | | | | | | | I | | | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L | L | L | L | L | L |

Air conditioner system (if equipped)

| | | | | | | | | | | | | | | |
|-------------|--|--|--|---|--|--|---|--|--|---|--|--|--|---|
| Refrigerant | | | | I | | | I | | | I | | | | I |
| Compressor | | | | I | | | I | | | I | | | | I |

MAINTENANCE TABLE (CANADA)**Chart symbols:**

- I : Inspect and repair, clean, or replace if necessary. (Inspect, and if necessary replace ... Air cleaner element only)
- R : Replace
- L : Lubricate
- Rt : Rotation (tires)

Remarks:

- After 60 months or 60,000 miles {96,000 km}, continue to follow the described maintenance at the recommended intervals.
 - *1: Replacement of the timing belt is required every 60,000 miles {96,000 km}. Failure to replace this belt may result in damage to the engine.
 - *2: This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.
 - *3: This maintenance operation is recommended by Mazda.

SCHEDULED MAINTENANCE



| Maintenance Interval Maintenance Item | Number of months or miles {kilometers}, whichever comes first | | | | | | | | | | | | |
|--|---|---|----|----|----|----|----|----|----|----|----|----|----|
| | Months | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |
| | × 1000 Kilometers | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | 96 |
| | Miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

Engine

| | | | | | | | | | | | | | | |
|----------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Engine oil | R | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Oil filter | R | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Tension of all drive belts | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Engine timing belt*1 | | | | | | | | | | | | | | R |

Air cleander

| | | | | | | | | | | | | | | |
|---------------------|--|--|---|--|--|--|---|--|--|---|--|--|--|---|
| Air cleaner element | | | I | | | | R | | | I | | | | R |
|---------------------|--|--|---|--|--|--|---|--|--|---|--|--|--|---|

Ignition system

| | | | | | | | | | | | | | | |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|--|---|
| Spark plugs | | | | | | | R | | | | | | | R |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|--|---|

Cooling system

| | | | | | | | | | | | | | | |
|-----------------------------------|--|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Engine coolant level and strength | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Cooling system for leaks | | | I | | | | I | | | I | | | | I |
| Engine coolant | Replace at first 72,000 km {45,000 miles} or 45 months; after that, every 48,000 km {30,000 miles} or 30 months | | | | | | | | | | | | | |

Fuel system

| | | | | | | | | | | | | | | |
|--------------------------|--|--|---|--|--|--|-----|--|--|---|--|--|--|---|
| Idle speed | | | I | | | | I | | | I | | | | I |
| Fuel lines and hoses | | | | | | | I*2 | | | | | | | I |
| Fuel filter | | | | | | | R | | | | | | | R |
| PCV valve*2 | | | | | | | | | | | | | | I |
| Emission hoses and tubes | | | | | | | | | | | | | | I |

Chassis and body

| | | | | | | | | | | | | | | |
|--|---|---|----|---|---|---|----|---|---|----|---|---|---|----|
| Automatic transaxle fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Transaxle oil (MTX and ATX) | | | | | | | R | | | | | | | R |
| Drive shaft dust boots | | | | | | | I | | | | | | | I |
| Brake lines and hoses | | | | | | | I | | | | | | | I |
| Brake and clutch fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Brake fluid*3 | | | | | | | R | | | | | | | R |
| Disc brakes (front and rear) | | | I | | | | I | | | I | | | | I |
| Rear drum brakes | | | | | | | I | | | | | | | I |
| Tire inflation pressure and tire wear | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Tires | | | Rt | | | | Rt | | | Rt | | | | Rt |
| Power steering fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Steering operation and linkages (Includes four wheel alignment) | | | | | | | I | | | | | | | I |
| Suspension components (front and rear) | | | | | | | I | | | | | | | I |
| All chassis and body nuts and bolts | | | I | | | | I | | | I | | | | I |
| Exhaust system heat shields | | | | | | | I | | | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L | L | L | L | L | L |
| Washer fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Function of all lights | I | I | I | I | I | I | I | I | I | I | I | I | I | I |

Air conditioner system (if equipped)

| | | | | | | | | | | | | | | |
|-------------|--|--|---|--|--|--|---|--|--|---|--|--|--|---|
| Refrigerant | | | I | | | | I | | | I | | | | I |
| Compressor | | | I | | | | I | | | I | | | | I |

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

ENGINE

(FS)

| | |
|---|--|
| <p>INDEX B1- 2</p> <p>OUTLINE B1- 3</p> <p style="padding-left: 20px;">SPECIFICATIONS B1- 3</p> <p>TROUBLESHOOTING GUIDE B1- 3</p> <p>ENGINE TUNE-UP B1- 5</p> <p style="padding-left: 20px;">PREPARATION B1- 5</p> <p style="padding-left: 20px;">ENGINE OIL B1- 5</p> <p style="padding-left: 20px;">ENGINE COOLANT B1- 5</p> <p style="padding-left: 20px;">DRIVE BELT B1- 6</p> <p style="padding-left: 20px;">HLA TROUBLESHOOTING GUIDE B1- 7</p> <p>COMPRESSION B1- 8</p> <p style="padding-left: 20px;">INSPECTION B1- 8</p> <p>ON-VEHICLE MAINTENANCE B1- 9</p> <p style="padding-left: 20px;">PREPARATION B1- 9</p> <p style="padding-left: 20px;">TIMING BELT B1- 10</p> <p style="padding-left: 20px;">CYLINDER HEAD GASKET B1- 16</p> <p style="padding-left: 20px;">HLA B1- 22</p> <p style="padding-left: 20px;">FRONT OIL SEAL B1- 24</p> <p style="padding-left: 20px;">REAR OIL SEAL B1- 26</p> <p>REMOVAL B1- 29</p> <p style="padding-left: 20px;">PROCEDURE B1- 29</p> <p>ENGINE STAND MOUNTING B1- 37</p> <p style="padding-left: 20px;">PREPARATION B1- 37</p> <p style="padding-left: 20px;">PROCEDURE B1- 38</p> <p>DISASSEMBLY B1- 40</p> <p style="padding-left: 20px;">PREPARATION B1- 40</p> <p style="padding-left: 20px;">AUXILIARY PARTS B1- 42</p> <p style="padding-left: 20px;">TIMING BELT B1- 43</p> <p style="padding-left: 20px;">CYLINDER HEAD B1- 46</p> <p style="padding-left: 20px;">CYLINDER BLOCK (EXTERNAL PARTS) B1- 49</p> <p style="padding-left: 20px;">CYLINDER BLOCK (INTERNAL PARTS) B1- 52</p> | <p>INSPECTION / REPAIR B1- 57</p> <p style="padding-left: 20px;">PREPARATION B1- 57</p> <p style="padding-left: 20px;">CYLINDER HEAD B1- 57</p> <p style="padding-left: 20px;">VALVE MECHANISM B1- 58</p> <p style="padding-left: 20px;">CAMSHAFT B1- 61</p> <p style="padding-left: 20px;">HLA B1- 64</p> <p style="padding-left: 20px;">CYLINDER BLOCK B1- 64</p> <p style="padding-left: 20px;">PISTON, PISTON RING, AND PISTON PIN B1- 66</p> <p style="padding-left: 20px;">CONNECTING ROD B1- 67</p> <p style="padding-left: 20px;">CONNECTING ROD BOLT B1- 68</p> <p style="padding-left: 20px;">MAIN BEARING CAP BOLT B1- 68</p> <p style="padding-left: 20px;">CRANKSHAFT B1- 68</p> <p style="padding-left: 20px;">BEARING B1- 69</p> <p style="padding-left: 20px;">TIMING BELT B1- 69</p> <p style="padding-left: 20px;">TENSIONER B1- 69</p> <p style="padding-left: 20px;">IDLER B1- 70</p> <p style="padding-left: 20px;">TENSIONER SPRING B1- 70</p> <p style="padding-left: 20px;">PULLEY B1- 70</p> <p style="padding-left: 20px;">TIMING BELT COVER B1- 70</p> <p>ASSEMBLY B1- 71</p> <p style="padding-left: 20px;">PREPARATION B1- 71</p> <p style="padding-left: 20px;">CYLINDER BLOCK (INTERNAL PARTS) B1- 73</p> <p style="padding-left: 20px;">CYLINDER BLOCK (EXTERNAL PARTS) B1- 79</p> <p style="padding-left: 20px;">CYLINDER HEAD B1- 84</p> <p style="padding-left: 20px;">TIMING BELT B1- 89</p> <p style="padding-left: 20px;">AUXILIARY PARTS B1- 94</p> <p>ENGINE STAND DISMOUNTING ... B1- 98</p> <p style="padding-left: 20px;">PROCEDURE B1- 98</p> <p>INSTALLATION B1-101</p> <p style="padding-left: 20px;">PROCEDURE B1-101</p> |
|---|--|

INDEX

INTAKE MANIFOLD
TIGHTENING TORQUE
19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

COMPRESSION INSPECTION, PAGE B1-10
STANDARD: 1,177 kPa {12.0 kgf/cm², 171 psi}—300 rpm
MINIMUM: 824 kPa {8.4 kgf/cm², 119 psi}—300 rpm
MAX. DIFFERENCE BETWEEN CYLINDERS:
196 kPa {2.0 kgf/cm², 28 psi}

③ HLA INSPECTION, PAGE B1-23

ENGINE OIL, SECTION D1

ENGINE COOLANT, SECTION E1

EXHAUST MANIFOLD
TIGHTENING TORQUE
NUT: 20—28 N·m {2.0—2.9 kgf·m, 15—20 ft·lbf}
BOLT: 16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

DRIVE BELT DEFLECTION AT 98 N {10 kgf, 22 lbf} mm {in}

| DRIVE BELT | NEW | USED | LIMIT |
|----------------|---------------------|---------------------|-----------|
| GENERATOR | 6.5—7.0 {0.26—0.27} | 7.0—9.0 {0.28—0.35} | 10 {0.39} |
| P/S, P/S + A/C | 7.5—9.0 {0.30—0.35} | 8.0—9.5 {0.32—0.37} | 11 {0.43} |

- 1. Timing belt
Removal / Installation page B1-10
- 2. Cylinder head gasket
Replacement page B1-16
- 3. HLA
Removal / Installation page B1-22
- 4. Front oil seal
Replacement page B1-24
- 5. Rear oil seal
Replacement page B1-26

- 6. Engine
Removal page B1- 29
- Engine stand mounting page B1- 37
- Disassembly page B1- 40
- Inspection / Repair page B1- 57
- Assembly page B1- 71
- Engine stand dismounting ... page B1- 98
- Installation page B1-101

OUTLINE

SPECIFICATIONS

| Item | | Engine | FS |
|---------------------------------|----|-------------------------------------|------------------------------|
| Type | | | Gasoline, 4-cycle |
| Cylinder arrangement and number | | | In-line, 4-cylinders |
| Combustion chamber | | | Pentroof |
| Valve system | | | DOHC, belt-driven, 16 valves |
| Displacement | | ml {cc, cu in} | 1,991 {1,991, 121.5} |
| Bore × stroke | | mm {in} | 83.0 × 92.0 {3.27 × 3.62} |
| Compression ratio | | | 9.0 |
| Compression pressure | | kPa {kgf/cm ² , psi}-rpm | 1,177 {12.0, 171}-300 |
| Valve timing | IN | Open BTDC | 8° |
| | | Close ABDC | 50° |
| | EX | Open BBDC | 54° |
| | | Close ATDC | 8° |
| Valve clearance | | IN mm {in} | 0 {0}: Maintenance-free |
| | | EX mm {in} | 0 {0}: Maintenance-free |

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|---------------------------------------|---|--|---|
| Difficult starting | Malfunction of engine-related components Burnt valve Worn piston, piston ring, or cylinder Damaged cylinder head gasket | Replace Replace or repair Replace | B1-58 B1-64, 66 B1-16 |
| | Malfunction of fuel system | Refer to sections F1, F3 | |
| | Malfunction of ignition system | Refer to section G | |
| | Poor idling | Malfunction of engine-related components Malfunction of HLA* Poor valve-to-valve seat contact Damaged cylinder head gasket | Replace Replace or repair Replace |
| Malfunction of fuel system | | Refer to sections F1, F3 | |
| Malfunction of ignition system | | Refer to section G | |
| Excessive oil consumption | | Oil working up Worn piston ring groove or stuck piston ring Worn piston or cylinder | Replace Replace or repair |
| | Oil working down Worn valve seal Worn valve stem or guide | Replace Replace | B1-48, 84 B1-58 |
| | Oil leakage | Refer to section D1 | |

* Tappet noise may occur if the engine has set idle for an extended period. The noise should stop after the engine has reached normal operating temperature. (HLA troubleshooting: Refer to page B1-7.)

| Problem | Possible Cause | Action | Page | |
|--|---|---|-------------------|-------|
| Insufficient power | Insufficient compression | | | |
| | Malfunction of HLA* | Replace | B1-22 | |
| | Compression leakage from valve seat | Repair | B1-60 | |
| | Seized valve stem | Replace | B1-58 | |
| | Weak or broken valve spring | Replace | B1-61 | |
| Abnormal combustion | Damaged cylinder head gasket | Replace | B1-16 | |
| | Cracked or distorted cylinder head | Replace | B1-57 | |
| | Stuck, damaged, or worn piston ring | Replace | B1-66 | |
| | Cracked or worn piston | Replace | B1-66 | |
| | Malfunction of fuel system | Refer to sections F1, F3 | | |
| Engine noise | Malfunction of ignition system | Refer to section G | | |
| | Others | | | |
| | Slipping clutch | Refer to section H | | |
| | Dragging brakes | Refer to section P | | |
| | Incorrect tire size | Refer to section Q | | |
| Abnormal combustion | Malfunction of engine-related components | | | |
| | Malfunction of HLA* | Replace | B1-22 | |
| | Stuck or burnt valve | Replace | B1-58 | |
| | Weak or broken valve spring | Replace | B1-61 | |
| | Carbon accumulation in combustion chamber | Eliminate carbon | — | |
| Engine noise | Malfunction of fuel system | Refer to sections F1, F3 | | |
| | Malfunction of ignition system | Refer to section G | | |
| | Engine noise | Crankshaft- or bearing-related parts | | |
| | | Excessive main bearing oil clearance | Replace or repair | B1-74 |
| | | Main bearing seized or heat-damaged | Replace | B1-69 |
| Excessive crankshaft end play | | Replace or repair | B1-75 | |
| Excessive connecting rod bearing oil clearance | | Replace or repair | B1-78 | |
| Engine noise | Connecting rod bearing seized or heat-damaged | Replace | B1-69 | |
| | Piston-related parts | | | |
| | Worn cylinder | Replace or repair | B1-64 | |
| | Worn piston or piston pin | Replace | B1-66 | |
| | Seized piston | Replace | B1-66 | |
| Engine noise | Damaged piston ring | Replace | B1-66 | |
| | Bent connecting rod | Replace | B1-67 | |
| | Valve train-related parts | | | |
| | Malfunction of HLA* | Replace | B1-22 | |
| | Broken valve spring | Replace | B1-61 | |
| Engine noise | Excessive valve guide clearance | Replace | B1-59 | |
| | Malfunction of cooling system | Refer to section E1 | | |
| | Malfunction of fuel system | Refer to sections F1, F3 | | |
| | Others | | | |
| | Malfunction of water pump bearing | Refer to section E1 | | |
| Improper drive belt tension | Adjust | B1-6 | | |
| Malfunction of generator bearing | Refer to section G | | | |
| Exhaust gas leakage | Refer to sections F1, F3 | | | |
| Malfunction of timing belt tensioner | Replace | B1-10 | | |

* Tappet noise may occur if the engine has set idle for an extended period. The noise should stop after the engine has reached normal operating temperature. (HLA troubleshooting: Refer to page B1-7.)

Warning





- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**

ENGINE TUNE-UP

PREPARATION

SST

49 9200 020A

V-ribbed belt
tension
gaugeFor
inspection of
drive belt tension

ENGINE OIL

Inspection

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil if necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.9 Imp qt}.

ENGINE COOLANT

Inspection

Coolant level (Engine cold)

Warning

- **Removing the radiator cap or the coolant drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam can shoot out and cause serious injury. It can also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.**

When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.





1. Verify that the coolant level is at the filler neck.
2. Verify that the coolant level on the coolant dipstick is between the F and L marks.
3. Add coolant if necessary.

Note

- The distance between the L and F marks on the dipstick represents 0.55 L {0.55 US qt, 0.44 Imp qt}.

Coolant quality

1. Verify that there is no buildup of rust or scale around the radiator cap and radiator filler neck.
2. Verify that the coolant is free of oil. Replace the coolant if necessary.



DRIVE BELT

Inspection

1. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.

3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure **98 N {10 kgf, 22 lbf}** midway between the specified pulleys.

Deflection

mm {in}

| Drive belt | *New | Used | Limit |
|-----------------|------------------------|------------------------|-----------|
| Generator | 6.5—7.0 {0.26—0.27} | 7.0—9.0 {0.28—0.35} | 10 {0.39} |
| P/S, P/S+A/C | 7.5—9.0 {0.30—0.35} | 8.0—9.5 {0.32—0.37} | 11 {0.43} |

* A belt that has been on a running engine for less than five minutes.

4. If the deflection is not within the specification, adjust it.

Drive belt tension check

Belt tension can be checked in place of belt deflection.


1. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the **SST**, check the belt tension between any two pulleys.

N {kgf, lbf}

| Drive belt | *New | Used | Limit |
|-----------------|-----------------------------|-----------------------------|--------------|
| Generator | 740—830 {75—85, 170—180} | 500—680 {50—70, 110—150} | 390 {40, 88} |
| P/S, P/S+A/C | 590—780 {60—80, 140—170} | 500—680 {50—70, 110—150} | 390 {40, 88} |

* A belt that has been on a running engine for less than five minutes.

2. If the tension is not within the specification, adjust it.




**Adjustment
Generator belt**

1. Loosen generator mounting bolts (A) and (B) and adjust the belt deflection/tension by turning adjusting bolt (C).
2. Tighten mounting bolts (A) and (B) and recheck the deflection/tension.

B1

Tightening torque

- (A): 16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}
- (B): 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}



P/S belt, P/S+A/C belt

1. Loosen bolts (A) and (B) and adjust the belt deflection/tension by turning adjusting bolt (C).
2. Tighten mounting bolts (A) and (B) and recheck the deflection/tension.

Tightening torque

- (A): 44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}
- (B): 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}



HLA TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action |
|---|--|---|
| 1. Noise when engine is started immediately after oil is changed. | Oil leakage in oil passage or in HLA | Run engine at 2,000—3,000 rpm. If noise stops within 20 minutes*, HLA is normal. If not, replace HLA. *Time required for engine oil to circulate within HLA includes tolerance for engine oil condition and ambient temperature. |
| 2. Noise when engine is started after setting one day or more. | | |
| 3. Noise when engine is started after new HLA is installed. | Oil leakage in HLA | Check oil pressure. If lower than specification, check for cause. (Refer to section D1.) |
| 4. Noise during idle after warm up. | Insufficient oil pressure | |
| | 5. Noise during idle after high-speed running. | Faulty HLA |
| Incorrect oil amount | | Check oil level. Drain or add oil as necessary. |
| Deteriorated oil | Check oil quality. If deteriorated, replace with specified type and amount of oil. | |

COMPRESSION

If the engine exhibits low power, poor fuel economy, or poor idle, check the following:

1. Ignition system (Refer to section G.)
2. Compression (Refer to below.)
3. Fuel system (Refer to sections F1, F3.)



INSPECTION

1. Verify that the battery is fully charged. Recharge it if necessary. (Refer to section G.)
2. Warm up the engine to the normal operating temperature.
3. Stop the engine and allow it to cool for about 10 minutes.
4. Remove the all spark plugs.
5. Disconnect the primary wire connector from the ignition coil as shown.
6. Install a compression gauge to No.1 spark plug hole.
7. Fully depress the accelerator pedal and crank the engine.
8. Record the maximum gauge reading.
9. Check each cylinder as above.

Compression

| | kPa {kgf/cm ² , psi}-rpm |
|-----------------------------------|-------------------------------------|
| Standard | 1,177 {12.0, 171}-300 |
| Minimum | 824 {8.4, 119}-300 |
| max. difference between cylinders | 196 {2.0, 28} |

10. If the compression in one or more cylinders is low, pour a small amount of engine oil into the cylinder and recheck the compression.
 - (1) If the compression increases, the piston, piston rings, or cylinder wall may be worn.
 - (2) If the compression stays low, the valve may be stuck or improperly seated.
 - (3) If the compression in adjacent cylinders stays low, the cylinder head gasket may be damaged or the cylinder head distorted.
11. Connect the ignition coil connector.
12. Install the all spark plugs.
















Tightening torque:

15—22 N·m {1.5—2.3 kgf·m, 11—16 ft·lb}

ON-VEHICLE MAINTENANCE

PREPARATION
SST

B1

| | | | |
|---|--|--|--|
| <p>49 S120 710</p> <p>Holder, coupling flange</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 1A1</p> <p>Set, holder</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 101</p> <p>Holder (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 102</p> <p>Bolts (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 G011 103</p> <p>Bolts</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> |
| <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 E011 1A0</p> <p>Brake set, ring gear</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 0118 850C</p> <p>Puller, ball joint</p>  | <p>For removal of tie-rod end</p> |
| <p>49 G033 107A</p> <p>Installer, dust cover</p>  | <p>For installation of rear oil seal</p> | <p>—</p> | <p>—</p> |


TIMING BELT

Removal / Installation


Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

1. Disconnect the negative battery cable.
2. Remove the right front wheel.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Splash shield 2. P/S and/or A/C drive belt Adjustment page B1- 7 3. Generator drive belt Adjustment page B1- 7 4. Pulley shield 5. P/S oil pump and hose Removal Note below 6. Water pump pulley 7. Crankshaft pulley Removal Note below Installation Note page B1-15 8. Guide plate 9. High-tension lead 10. Spark plug | <ul style="list-style-type: none"> 11. Cylinder head cover Removal Note below Installation Note page B1-15 12. Dipstick and pipe 13. Timing belt cover, upper 14. Timing belt cover, lower 15. No.3 engine mount rubber Removal Note page B1-12 Installation Note page B1-14 16. Timing belt Removal Note page B1-12 Installation Note page B1-13 17. Tensioner and tensioner spring 18. Idler |
|--|--|



Removal Note


P/S oil pump and hose

1. Remove the P/S oil pump with the hoses still connected.
2. Position the pump away from the engine and affix it with wire.




Crankshaft pulley

1. Hold the crankshaft pulley by using the SST.
2. Loosen the crankshaft pulley bolt.
3. Remove the crankshaft pulley bolt and the crankshaft pulley.




Cylinder head cover

1. Loosen the cylinder head cover bolts in five or six steps in the order shown.
2. Remove the cylinder head cover bolts.
3. Remove the cylinder head cover.




No.3 engine mount rubber

1. Suspend the engine by using the SST.



2. Remove the ground harness.


3. Remove the No.3 engine mount rubber.



Timing belt


1. Install the crankshaft pulley bolt.

2. Turn the crankshaft to align the matching marks of the pulleys as shown.



3. Turn the tensioner clockwise by using an Allen wrench.

4. Disconnect the tensioner spring from the hook pin.




Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.


5. When the belt will be reused, mark its rotation for proper reinstallation.

6. Remove the timing belt.


7. Check the timing belt for damage, wear, peeling, cracks and hardening. Replace the timing belt if necessary.

**Installation Note****Timing belt**


1. Turn the crankshaft clockwise and align the timing marks as shown.

**Note**


- The timing marks (grooves) can also be used to align the pulleys.




2. Verify that the camshaft pulley I and E marks are aligned with the cylinder head upper line.




3. Install the timing belt so that there is no looseness at the idler side or between the two camshaft pulleys.




4. Turn the crankshaft clockwise two turns, and align the timing marks.
5. Verify that all timing marks are correctly aligned. If not aligned, remove the timing belt and repeat from step 1.



- Turn the tensioner clockwise by using an Allen wrench and connect the tensioner spring to the hook pin. Verify that tension is applied to the timing belt.



- Turn the crankshaft clockwise two turns, and verify that all timing marks are aligned. If not aligned, repeat from step 1.




No.3 engine mount rubber

- Install the No.3 engine mount rubber.

Tightening torque


Bolt: 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}
Nut: 74—102 N·m {7.5—10.5 kgf·m, 55—75.9 ft·lbf}




- Install the ground harness.

Tightening torque:

64—89 N·m {6.5—9.1 kgf·m, 48—65 ft·lbf}




- Remove the SST from the engine.




Cylinder head cover

1. Install a new cylinder head cover gasket.




2. Apply silicone sealant to the shaded areas of the cylinder head as shown.



3. Set the cylinder head cover on the cylinder head.
4. Tighten the cylinder head cover bolts in five or six steps in the order shown.

Tightening torque:

6.9—10.7 N·m {70—110 kgf·cm, 61—95.4 in·lbf}



Crankshaft pulley

1. Remove the crankshaft pulley bolt.
2. Install the crankshaft pulley and hand tighten the crankshaft pulley bolt.
3. Install the **SST** to the crankshaft pulley.
4. Tighten the crankshaft pulley bolt.

Tightening torque:

157—166 N·m {16.0—17.0 kgf·m, 116—122 ft·lbf}

Steps After Installation


1. Install the right front wheel.
2. Connect the negative battery cable.
3. Perform the necessary engine adjustments. (Refer to sections F1, F3.)

CYLINDER HEAD GASKET Replacement

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedure" on sections F1, F3.

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E1.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.





- | | |
|--|------------|
| 1. Splash shield | |
| 2. Fresh-air duct | |
| 3. Mass air flow sensor connector | |
| 4. Intake air temperature sensor connector | |
| 5. Air cleaner and resonance chamber No.2 | |
| 6. Accelerator cable | |
| Installation Note | page B1-21 |
| 7. Hose | |
| Removal Note | below |
| Installation Note | page B1-21 |
| 8. Harness connectors | |
| 9. Timing belt | |
| Removal / Installation | page B1-10 |
| 10. Distributor | |
| Installation Note | page B1-20 |
| 11. Camshaft pulley | |
| Removal Note | page B1-18 |
| Installation Note | page B1-20 |
| 12. Camshaft | |
| Removal Note | page B1-18 |
| Installation Note | page B1-19 |
| 13. Intake manifold bracket | |
| 14. Cylinder head bolt | |
| Removal Note | page B1-18 |
| Installation Note | page B1-18 |
| 15. Cylinder head | |
| 16. Cylinder head gasket | |

Removal Note

Hose

Disconnect the hoses shown in the figure.






Fuel hose

Warning


- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedure" on section F1, F3.

Plug the disconnected hoses to prevent fuel leakage.




Camshaft pulley

1. Hold the camshaft by using a wrench on the cast hexagon as shown, and loosen the camshaft pulley bolt.
2. Remove the camshaft pulley.




Camshaft

1. Loosen the camshaft cap bolts in five or six steps in the order shown.
2. Remove the camshaft caps.
3. Remove the camshafts.
4. Remove the camshaft oil seals from the camshafts.



Cylinder head bolt

1. Loosen the cylinder head bolts in two or three steps in the order shown.
2. Remove the cylinder head bolts.



Installation Note


Cylinder head bolt

1. Measure the length of each cylinder head bolt below its head.

Length


Standard: 104.2—104.8 mm {4.103—4.125 in}

Maximum: 105.5 mm {4.154 in}




2. If the length exceeds the maximum, replace the bolt.
3. Apply clean engine oil to the bolt threads and head seat.
4. Install and tighten the cylinder head bolts.
 - (1) Tighten the bolts to the specified torque in the order shown.

Tightening torque: 17.2—22.0 N·m
{1.75—2.25 kgf·m, 12.7—16.2 ft·lbf}



- (2) Put a paint mark on each bolt head.
- (3) Use this mark as a reference, tighten the bolts **85°—95°** in the order shown.
- (4) Further tighten each bolt by turning **another 85°—95°**.




Camshaft

Note


- The exhaust camshaft is machined with the distributor drive gear.

1. Apply clean engine oil to the camshaft journals and bearings and install the camshaft in position.
2. Apply silicone sealant to the shaded areas as shown.



3. Install the camshaft caps according to the cap number as shown.
4. Install the camshaft cap bolts and tighten them in five or six steps in the order shown.


Tightening torque:
11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}



5. Apply clean engine oil to the lip of each new camshaft oil seal.
6. Push the oil seal slightly in by hand.
7. Using a pipe and hammer, tap the oil seal in evenly until it is flush with the edge the camshaft cap.


Note

- Oil seal outer diameter: 48.0 mm {1.89 in}
- Oil seal inner diameter: 34.0 mm {1.34 in}



Camshaft pulley


1. Install the camshaft pulleys, positioning the dowel pins as shown.



2. Apply clean engine oil to the bolt threads and hand tighten the lock bolts.
3. Hold the camshaft by using a wrench on the cast hexagon as shown, and tighten each bolt.


Tightening torque:

50—60 N·m {5.0—6.2 kgf·m, 37—44 ft·lbf}



Distributor



1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply clean engine oil to the drive gear.
3. Align the matching marks as shown.



4. Install the distributor and hand tighten the mounting bolts.

Hose

Connect the hoses shown in the figure.

**Accelerator cable**

1. Verify that the throttle valve is fully closed.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.0 mm {0.06—0.15 in}

3. If not as specified, turn stopper (B) while pressing lock button (A) to release the lock.
4. Push the spring in direction (C) and adjust the cable free play.
5. Lock stopper (A) after locking stopper (B).

Steps After Installation


1. Connect the negative battery cable.
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E1.)
3. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to sections F1, F3.)
 - (3) check the operation of the emission control system.
4. Recheck the engine oil and engine coolant levels.

HLA Removal / Installation

Caution


- Removal and installation of the HLA must be carried out only when the problem cannot be solved by the HLA troubleshooting (Refer to page B1-7.)

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|--|------------|
| 1. Timing belt Removal / Installation | page B1-10 |
| 2. Distributor Installation Note | page B1-20 |
| 3. Camshaft pulley Removal Note | page B1-18 |
| Installation Note | page B1-20 |

- | | |
|---------------------------------------|------------|
| 4. Camshaft Removal Note | page B1-18 |
| Installation Note | page B1-19 |
| 5. HLA Removal Note | page B1-23 |
| Installation Note | page B1-23 |



Removal Note HLA


Caution

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.

Note

- Mark the HLA to show their original positions.

1. Remove the HLA from the cylinder head.
2. Store the HLA upside down in an oil-filled container.



Installation Note

HLA

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the positions from which they were removed.
3. Verify that the HLA move smoothly in their bores.


Step After Installation

1. Connect the negative battery cable.
2. Start the engine and
 - (1) check the engine oil leakage.
 - (2) check the ignition timing and idle speed. (Refer to sections F1, F3.)
 - (3) check the operation of the emission control system. (Refer to section F1.)
 - (4) check the HLA tappet noise. (Refer to page B1-7.)
3. Recheck the engine oil and engine coolant levels.

FRONT OIL SEAL

Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




1. Timing belt
Removal / Installation page B1-10
2. Timing belt pulley
Removal Note below
Installation page B1-25

3. Oil seal
Removal Note page B1-25
Installation Note page B1-25


Removal Note

Timing belt pulley

1. Remove the timing belt pulley.
2. Remove the timing belt pulley key.

**Oil seal**


1. Cut the oil seal lip by using a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.

**Installation Note****Oil seal**

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Using a pipe and a hammer, tap the oil seal in evenly until it is flush with the edge of the oil pump body.

Note

- Oil seal outer diameter: 54.5 mm {2.15 in}
- Oil seal inner diameter: 42.5 mm {1.67 in}

**Timing belt pulley**

1. Install the timing belt pulley.
2. Install the timing belt pulley key.


Steps After Installation

1. Connect the negative battery cable.
2. Start the engine and check follows:
 - Ignition timing. (Refer to sections F1, F3.)

REAR OIL SEAL


Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




1. Transaxle
 MTX
 Removal / Installation section J
 ATX
 Removal / Installation section K2
2. Clutch cover, clutch disc (MTX)
 Removal / Installation section H
3. Flywheel (MTX)
 Removal Note below
 Installation Note page B1-27

4. Drive plate (ATX)
 Removal Note page B1-27
 Installation Note page B1-28
5. Oil seal
 Removal Note page B1-27
 Installation Note page B1-27




Removal Note Flywheel (MTX)


1. Hold the flywheel by using the SST.
2. Remove the flywheel bolts.
3. Remove the flywheel.

**Drive plate (ATX)**


1. Hold the drive plate by using the **SST**.
2. Remove the drive plate bolts.
3. Remove the backing plate, drive plate, and adapter.

**Oil seal**

1. Cut the oil seal lip by using a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.

**Installation Note****Oil seal**

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Using the **SST** and a hammer, tap the oil seal in evenly until it is flush with the edge of the rear cover.

**Flywheel (MTX)**


1. Remove the sealant from the flywheel bolt holes in the crankshaft and from the flywheel bolts.

Caution

- If all of the old thread sealant cannot be removed from the bolt, it will not torque properly. Replace the bolt.

Note



- If a new bolt is used, do not apply thread locking sealant. New Mazda bolts have sealant on them.



2. Set the flywheel onto the crankshaft.
3. Apply sealant to the flywheel bolts and install them.
4. Hold the flywheel by using the **SST**.
5. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

97—102 N·m {9.8—10.5 kgf·m, 71—75.9 ft·lbf}



Drive plate (ATX)

1. Remove the sealant from the drive plate bolt holes in the crankshaft and from the drive plate bolts.

Caution

- If all of the old thread sealant cannot be removed from the bolt, it will not torque properly. Replace the bolt.

Note

- If a new bolt is used, do not apply thread locking sealant. New Mazda bolts have sealant on them.

2. Install the adapter, drive plate, and backing plate onto the crankshaft.
3. Apply sealant to the drive plate bolts and install them.
4. Hold the drive plate by using the SST.
5. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

97—102 N·m {9.8—10.5 kgf·m, 71—75.9 ft·lbf}

Steps After Installation

1. Connect the negative battery cable.
2. Start the engine and perform engine adjustments as necessary.
3. Check the oil level.

REMOVAL


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedure" on sections F1, F3.


PROCEDURE

1. Disconnect the negative battery cable.
2. Drain the engine coolant and transaxle oil. (Refer to section E1 and section J, K2.)
3. Remove the hood and front wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.


Step 1



- | | |
|--|---------------------------------------|
| 1. Splash shield | 11. Radiator hose |
| 2. Fresh-air duct | 12. Oil cooler hose (ATX) |
| 3. Mass air flow sensor connector | 13. Cooling fan motor connector |
| 4. Intake air temperature sensor connector | 14. Coolant reservoir pipe |
| 5. Air cleaner assembly | 15. Radiator bracket |
| 6. Air hose | 16. Radiator and cooling fan assembly |
| 7. Resonance chamber No.2 | 17. P/S oil pump and adjuster |
| 8. Battery and carrier | Removal Note page B1-30 |
| 9. Accelerator cable | 18. A/C compressor (if equipped) |
| 10. Fuel filter | Removal Note page B1-30 |

**Removal Note****P/S oil pump**

1. Remove the P/S oil pump with the hoses still connected.
2. Position the pump away from the engine and affix it with wire.

**A/C compressor (if equipped)**


1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and affix it with wire.

Step 2


Disconnect the harness connectors.

Step 3

Disconnect the hoses shown in the figure.



- | | |
|----------------|------------------------|
| 1. Fuel hose | 3. Brake vacuum hose |
| 2. Heater hose | 4. Vacuum hose (Purge) |
- Removal Note below




Removal Note
Fuel hose

Warning


- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Plug the disconnected hoses to avoid fuel leakage.

Step 4



- | | |
|--|---|
| 1. Clutch release cylinder (MTX) Removal Note below | 7. Exhaust pipe |
| 2. Shift control cable (ATX) | 8. Shift control rod (MTX) |
| 3. Transverse member | 9. Extension bar (MTX) |
| 4. No.5 engine mount rubber | 10. Stabilizer control link |
| 5. No.2 engine mount nuts | 11. Tie-rod end ball joint Removal Note page B1-33 |
| 6. Engine mount member Removal Note page B1-33 | 12. Drive shaft Removal Note page B1-33 |



Removal Note


Clutch release cylinder (MTX)

1. Remove the bolts and clips as shown.

Caution

- Bending the pipe can cause kinks or cracks.

2. Remove the release cylinder with the hose still connected and position it away from the transaxle.




Engine mount member

Warning


- Removing the member without first suspending the engine can cause the engine to tilt or fall and cause injury. Suspend the engine properly before removing the member.

1. Suspend the engine by using a chain block.
2. Remove the No.2 engine mount nuts.
3. Remove the engine mount member bolts and nuts and remove the engine mount member.



Tie-rod end ball joint

1. Remove the cotter pin and loosen the nut so that it is flush with the end of the ball joint stud.
2. Separate the knuckle arm and ball joint by using the SST.




Drive shaft

1. Remove the bolts and nuts from the lower arm ball joints.


Caution

- The ball joint dust boots and oil seals are damaged easily if this procedure is not done correctly.


2. Pry the lower arm downward to separate it from the knuckles.



3. Separate the drive shafts from the transaxle by prying with a bar inserted between the shaft and the case. (Left side)




4. As shown in the figure, insert a pry bar between the drive shaft and the joint shaft and tap on the bar to uncouple them. (Right side)



5. Remove the joint mounting bolts.
6. Remove the joint shaft.


Step 5



- 1. No.1 engine mount stay bracket
- 2. No.3 engine mount rubber
- 3. No.1 engine mount bolts (MTX)
- 4. No.1 engine mount (ATX)

- 5. No.4 engine mount rubber
- 6. No.4 engine mount bracket
- 7. Engine and transaxle assembly

Removal Note below




Removal Note

Engine and transaxle assembly

Slowly lift the engine and transaxle assembly as a unit. Keep the engine from swinging or bumping into components in the engine compartment.

Step 6











1. Intake manifold bracket
2. Starter
3. No.2 engine mount rubber

4. Manual transaxle
5. Automatic transaxle
6. Engine assembly

ENGINE STAND MOUNTING


PREPARATION
SST

| | | | |
|---|---|---|---|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 1A0 Hanger set, engine stand</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 101 Plate (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 102 Arms (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 103 Hooks (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 104 Nuts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 105 Bolts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 106 Bolts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |

PROCEDURE


Step 1

Remove in the order shown in the figure.



1. P/S oil pump bracket
2. Exhaust manifold insulator
3. EGR pipe
4. Exhaust manifold
5. A/C compressor bracket (if equipped)


6. Thermostat cover
7. Thermostat
8. Water bypass pipe
9. Thermostat housing




Step 2

Engine stand mounting procedure


1. Use the holes shown in the figure.




2. Install the **SST** (arms) to the holes as shown in the figure, and hand tighten the **SST** (bolts).




3. Assemble the **SST** (bolts and plate) in the specified position.



4. Assemble the **SST** (nuts, hooks, and bolts).
5. Install the **SST** to the respective arms.



















6. Adjust the **SST** (bolts) so that less than **20 mm {0.79 in}** of thread is exposed.
7. Make the **SST** (plate and arms) parallel by adjusting the **SST** (bolts and nuts).
8. Tighten the **SST** (bolts and nuts) to affix the **SST** firmly.




9. Mount the engine on the **SST** (engine stand).

DISASSEMBLY

PREPARATION SST

| | | | |
|---|--|--|--|
| <p>49 E011 1A0 Brake, ring gear</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 B012 0A2 Pivot</p>  | <p>For removal / installation of valves</p> | <p>49 B012 012 Body (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 B012 013 Foot (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> | <p>49 B012 014 Locknut (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 0636 100B Arm, valve spring lifter</p>  | <p>For removal / installation of valves</p> | <p>49 L011 0A0B Tool set, piston pin setting</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 L011 001 Body, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 006 Installer, piston pin (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 002 Screw</p>  | <p>For removal / installation of piston pins</p> | <p>49 D011 002B Head, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 001 Guide</p>  | <p>For removal / installation of piston pins</p> | <p>49 G014 001 Wrench, oil filter</p>  | <p>For removal / installation of oil filter</p> |

| | | | |
|---|----------------------------|---|---|
| 49 S120 170 Remover, valve seal  | For removal of valve seals | — | — |
|---|----------------------------|---|---|


1. Code or arrange all identical parts (such as HLA, pistons, piston rings, connecting rods, and valve springs) so that they can be reinstalled in the cylinder from which they were removed.
2. Clean the parts by using a steam cleaner. Blow dry with compressed air.

Warning

- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**

AUXILIARY PARTS

1. Drain the engine oil.
2. Disassemble in the order shown in the figure.




1. Engine hanger
2. Distributor and high-tension lead
3. Spark plug
4. Intake manifold assembly
5. Drive belt
6. Generator stay (MTX)
7. Generator strap

8. Generator
9. Generator bracket
10. Engine coolant temperature sensor
11. Heat gauge sender unit
12. Water outlet
13. Oil filter


Removal section D1

TIMING BELT

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | |
|---|--|
| 1. Cylinder head cover Disassembly Note page B1-44 | 9. Timing belt Disassembly Note page B1-44 Inspection page B1-69 |
| 2. Crankshaft pulley Disassembly Note page B1-44 | 10. Tensioner, tensioner spring Inspection pages B1-69, 70 |
| 3. Water pump pulley | 11. Idler Inspection page B1-70 |
| 4. Dipstick and pipe | 12. Timing belt pulley Disassembly Note page B1-45 |
| 5. Timing belt cover, upper | |
| 6. Timing belt cover, lower | |
| 7. No.3 engine mount bracket | |
| 8. Timing belt guide plate | |




Disassembly Note Cylinder head cover

1. Loosen the cylinder head cover bolts in five or six steps in the order shown.
2. Remove the cylinder head cover bolts.
3. Remove the cylinder head cover.




Crankshaft pulley

1. Hold the flywheel (MTX) or the drive plate (ATX) by using the SST.




2. Remove the crankshaft pulley bolt.
3. Remove the crankshaft pulley.




Timing belt

1. Install the crankshaft pulley bolt.
2. Turn the crankshaft to align the matching marks as shown.



3. Turn the tensioner clockwise by using an Allen wrench.
4. Disconnect the tensioner spring from the hook pin.

**Note**

- Mark the timing belt rotation for proper reinstallation.

5. Remove the timing belt.

Caution


- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

Timing belt pulley


1. Remove the timing belt pulley.
2. Remove the timing belt pulley key.

CYLINDER HEAD


Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | |
|---|--|
| 1. Camshaft pulley Disassembly Note page B1-47 Inspection page B1-70 | 6. Cylinder head gasket |
| 2. Camshaft Disassembly Note page B1-47 Inspection page B1-61 | 7. Valve keeper Disassembly Note page B1-47 |
| 3. HLA Disassembly Note page B1-47 Inspection page B1-64 | 8. Valve spring seat, upper |
| 4. Cylinder head bolt Disassembly Note page B1-47 Inspection page B1-58 | 9. Valve spring Inspection page B1-61 |
| 5. Cylinder head Inspection page B1-57 | 10. Valve Inspection page B1-58 |
| | 11. Valve seal Disassembly Note page B1-48 |
| | 12. Valve spring seat, lower |
| | 13. Valve guide Inspection page B1-59 Replacement page B1-59 |

**Disassembly Note****Camshaft pulley**

1. Hold the camshaft by using a wrench on the cast hexagon as shown, and loosen the camshaft pulley bolt.
2. Remove the camshaft pulley.

**Camshaft**

1. Loosen the camshaft cap bolts in five or six steps in the order shown.
2. Remove the camshaft caps.
3. Remove the camshafts.
4. Remove the camshaft oil seals from the camshafts.


**HLA****Caution**

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.


Note

- Mark the HLA to show their original positions.


1. Remove the HLA from the cylinder head.
2. Store the HLA upside down in an oil-filled container.

**Cylinder head bolt**

1. Loosen the cylinder head bolts in two or three steps in the order shown.
2. Remove the cylinder head bolts.

**Valve keeper**

1. Set the **SST** against the upper valve spring seat as shown.
2. Compress the spring and remove the valve keepers.




Valve seal

Remove the valve seal by using the SST.


CYLINDER BLOCK (EXTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- 1. Water pump
- 2. Rubber seal
- 3. Oil pump
Disassembly / Assembly section D1
- 4. Front oil seal
Disassembly Note page B1-51
- 5. Clutch cover and clutch disc (MTX)
Disassembly Note page B1-50
- 6. Flywheel (MTX)
Disassembly Note page B1-50
- 7. Backing plate, drive plate, and adapter (ATX)
Disassembly Note page B1-50


- 8. End plate
- 9. Oil pan
Disassembly Note page B1-50
Inspect for damage
- 10. Oil strainer
Disassembly Note page B1-51
Inspect for damage
- 11. Oil pan upper block
Disassembly Note page B1-51
- 12. Rear cover
- 13. Rear oil seal
Disassembly Note page B1-51



Disassembly Note


Clutch cover and clutch disc (MTX)

1. Hold the flywheel by using the **SST**.
2. Loosen the clutch cover bolts in two or three steps and remove them.
3. Remove the clutch cover.
4. Remove the clutch cover and clutch disc.




Flywheel (MTX)

1. Hold the flywheel by using the **SST**.
2. Loosen the flywheel bolts in two or three steps and remove them.
3. Remove the flywheel.
4. Remove the **SST**.



Backing plate, drive plate, and adapter (ATX)

1. Hold the drive plate by using the **SST**.
2. Loosen the drive plate bolts in two or three steps and remove them.
3. Remove the backing plate, drive plate, and adapter.
4. Remove the **SST**.




Oil pan


1. Remove the oil pan mounting bolts.

Caution


- Pry tools can easily scratch the oil pan stiffener and oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.




2. Remove the sealant from the bolt threads.
3. Screw an oil pan bolt into the weld nut to make a small gap between the oil pan upper block and the oil pan.
4. Using a screwdriver, pry apart the oil pan and oil pan upper block.
5. Remove the oil pan.

**Oil strainer**


1. Remove bolt (A).
2. Remove bolts (B).
3. Remove the oil strainer.

**Oil pan upper block**


1. Remove the two nuts at the rear of the cylinder block.
2. Loosen the oil pan upper block bolts in two or three steps in the order shown.
3. Remove the bolts.



4. Insert a screwdriver as shown in the figure and pry loose the oil pan upper block.

**Front oil seal**


Remove the front oil seal by using a screwdriver protected with a rag.

**Rear oil seal**


Remove the rear oil seal by using a screwdriver protected with a rag.

CYLINDER BLOCK (INTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | |
|---|--|
| 1. Connecting rod bolt Inspection page B1-68 | 7. Piston Inspection page B1-66 |
| 2. Connecting rod cap Disassembly Note page B1-53 | 8. Main bearing cap bolt Inspection page B1-68 |
| 3. Connecting rod Disassembly Note page B1-53 Inspection page B1-67 | 9. Main bearing cap Disassembly Note page B1-54 |
| 4. Connecting rod bearing Inspection page B1-69 | 10. Crankshaft Disassembly Note page B1-55 Inspection page B1-68 |
| 5. Piston ring Disassembly Note page B1-53 Inspection page B1-66 | 11. Main bearing Inspection page B1-69 |
| 6. Piston pin Disassembly Note page B1-53 Inspection page B1-67 | 12. Thrust bearing |
| | 13. Cylinder block Inspection page B1-64 Oil jet page B1-55 |




Disassembly Note
Connecting rod cap

Before removing the connecting rod caps, measure the connecting rod side clearance. (Refer to page B1-78.)




Connecting rod

1. Before removing the connecting rods, measure the connecting rod bearing oil clearance. (Refer to page B1-78.)




2. Remove the Plastigage from the crankpin journals.
3. Use the handle of a hammer to remove the piston and connecting rod assembly through the top of the cylinder block.



Piston ring

Remove the piston rings by using a piston ring expander.




Piston pin


Caution

- The connecting rods must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.


1. Before disassembling the piston and connecting rod, check the oscillation torque as shown. If the large end does not drop by its own weight, replace the piston and/or the piston pin.




2. Use the **SSTs** shown in the figure and a press.



3. Assemble the **SST** into the piston pin as shown.




4. Verify that the **SST** fits squarely into the piston before pressing.




5. Set the piston and connecting rod on the **SST** as shown.

6. Press out the piston pin. While removing the piston pin, check the pressure. If it is lower than **4,903 N {500 kgf, 1,100 lbf}**, replace the piston pin and/or connecting rod.




Main bearing cap

1. Before removing the main bearing caps, measure the crankshaft end play. (Refer to page B1-75.)




2. Loosen the main bearing cap bolts in two or three steps in the order shown.
3. Remove the main bearing caps.



Crankshaft

Before removing the crankshaft, measure the main bearing oil clearances. (Refer to page B1-73.)



Oil jet


Removal / Installation

Removal

1. Drill a hole into the center of the oil jet head with a 7 mm {0.28 in} drill bit.
2. Remove the spring and ball through the hole.
3. Tap the hole with a M8 × 1.25 tap to 8 mm {0.31 in} deep.
4. Screw a M8 × 1.25 bolt into the tapped hole.
5. Attach the sliding hammer to the bolt.

Caution


- **Twisting or turning the sliding hammer while removing the oil jet can damage the cylinder block.**



6. Pull the sliding hammer straight upward and discard the oil jet.


Installation

1. Temporarily install the crankshaft, connecting rod, and piston to the cylinder block.
2. Coat the oil jet installation hole with a small amount of clean engine oil.
3. Fit the oil jet into the hole and align the nozzle with the piston's notch.
4. Remove the crankshaft, connecting rod and piston.
5. Remove the cylinder block from the SST (engine stand).
6. Put the cylinder block on the press stand.
7. Verify that the oil jet nozzle is properly aligned.



Caution

- **If the oil jet nozzle is not properly aligned after being pressed in, it can damage the oil jet, cylinder block, and the piston.**



8. Press-fit the oil jet into the cylinder block.

Depth: 11.0—10.5 mm {0.44—0.41 in}
Pressure: 3.2 kN {330 kgf, 726 lbf} min.






Caution

- **Depth over specification can damage the oil jet nozzle.**
 - **Pressure below specification indicates loose fit. Replace the cylinder block and oil jet.**
9. Mount the cylinder block on the **SST** (engine stand).
 10. Install the crankshaft, connecting rod, and piston to the cylinder block.
 11. Turn the crankshaft clockwise and check that the crankshaft and piston do not contact the oil jet.



INSPECTION / REPAIR

PREPARATION

SST

| | | | |
|--|--|---|--|
| <p>49 B012 005</p> <p>Remover & installer, valve guide</p>  | <p>For removal / installation of valve guide</p> | <p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p>  | <p>For installation of valve guide</p> |
| <p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> | <p>49 L012 003</p> <p>Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> |
| <p>49 L012 004</p> <p>Nut (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> | <p>—</p> | <p>—</p> |

1. Clean all parts, being sure to remove all foreign materials.
2. Inspection and repairs must be performed in the order specified.

**CYLINDER HEAD**

1. Inspect the cylinder head for damage, cracks, and leakage of water and oil. Replace if necessary.
2. Using a straightedge, measure the cylinder head for distortion in the six directions as shown.


Distortion: 0.10 mm {0.004 in} max.

3. Inspect for the following and repair or replace.
 - (1) Sunken valve seats
 - (2) Damaged intake and exhaust manifold contact surfaces
 - (3) Excessive camshaft oil clearances and end play
4. If the cylinder head distortion exceeds the specification, grind the cylinder head surface.

Grinding: 0.15 mm {0.006 in} max.

5. If the cylinder head height is not within the specification, replace it.

Height: 124.45—124.55 mm {4.8996—4.9035 in}




- Using a straightedge, measure the manifold contact surfaces for distortion in the six directions shown.

Distortion: 0.10 mm {0.004 in} max.

- If distortion exceeds the specification, grind the surface or replace the cylinder head.

Grinding: 0.15 mm {0.006 in} max.




Cylinder Head Bolt

Measure the length of each bolt. Replace if necessary.

Length : 104.2—104.8 mm {4.103—4.125 in}

Maximum: 105.5 mm {4.154 in}



VALVE MECHANISM


Valve and Valve Guide

- Inspect each valve for the following. Replace or resurface the valves as necessary.
 - Damaged or bent stem
 - Rough or damaged face
 - Damaged or unevenly worn stem tip
- Measure the head margin thickness of each valve. Replace the valves if necessary.

Margin thickness

IN : 1.10 mm {0.0433 in}

EX : 1.20 mm {0.0472 in}



- Measure the length of each valve and replace the valves if necessary.


Length

Standard IN : 89.68 mm {3.5307 in}

EX : 89.78 mm {3.5346 in}

Minimum IN : 89.28 mm {3.5150 in}

EX : 89.38 mm {3.5189 in}



- Measure the diameter of each valve stem and replace the valves if necessary.

Diameter


Standard

IN : 5.970—5.985 mm {0.2351—0.2356 in}

EX : 5.965—5.980 mm {0.2349—0.2354 in}

Minimum IN : 5.940 mm {0.2339 in}

EX : 5.935 mm {0.2337 in}




5. Measure the inner diameter of each valve guide at the points shown.

Inner diameter

IN : 6.01—6.03 mm {0.2367—0.2374 in}

EX : 6.01—6.03 mm {0.2367—0.2374 in}



6. Calculate the valve stem-to-guide clearance by subtracting the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.


Clearance

IN : 0.025—0.060 mm {0.0010—0.0023 in}

EX : 0.030—0.065 mm {0.0012—0.0025 in}

Maximum: 0.10 mm {0.004 in}

7. If the clearance exceeds the maximum, replace the valve and/or the valve guide.




8. Measure each valve guide projection height (A). Replace the guides if necessary.

Height (A)

IN : 13.5—14.1 mm {0.532—0.555 in}


EX : 13.5—14.1 mm {0.532—0.555 in}



Replacement of valve guide






Note

- The intake and exhaust valve guides are the same.



Removal

Remove the valve guide from the combustion chamber side by using the **SST**.



Installation

1. Assemble the **SST** so that depth **L** is as specified.

Depth L: 13.5—14.1 mm {0.532—0.555 in}

2. Tighten the locknut.

3. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
4. Verify that the valve guide height is within the specification. (Refer to page B1-59.)
5. If not within the specification, repeat steps 1—4.






Valve Seat

1. Inspect the contact surface of each valve seat and valve face for the following:
 - (1) Roughness
 - (2) Damage
2. If necessary, resurface the valve seat with a **45°** valve seat cutter and/or resurface the valve face.

3. Apply a thin coat of Prussian blue to the valve face.
4. Check the valve seating by pressing the valve against the seat.
 - (1) If blue does not appear **360°** around the valve face, replace the valve.
 - (2) If blue does not appear **360°** around the valve seat, resurface the seat.

5. Measure the seat contact width.

Width: 0.9—1.3 mm {0.036—0.051 in}



6. Verify that the valve seating position is at the center of the valve face.
 - (1) If the seating position is too high, correct the valve seat using **65° (IN)** or **75° (EX)** cutter, and a **45°** cutter.
 - (2) If the seating position is too low, correct the valve seat using a **35°** cutter and a **45°** cutter.
7. Seat the valve to the valve seat by using a lapping compound.
8. Check the sinking of the valve seat.
Measure the protruding length (dimension **L**) of the valve stem.

Dimension L: 39.0 mm {1.535 in}

- (1) If L is 39.0—39.5 mm {1.536—1.555 in}, no correction needed.
- (2) If L is 40.6 mm {1.598 in} or more, replace cylinder head.

Valve Spring

1. Inspect each valve spring for cracks or damage.
2. Measure the free length and out-of-square. Replace the valve springs if necessary.

Free length

Standard: 44.0 mm {1.732 in}


**Minimum: 36.5 mm {1.437 in}/177.1—200.2 N
{18.05—20.42 kgf, 39.71—44.92 lbf}**

Out-of-square: 1.54 mm {0.061 in} max.

CAMSHAFT

1. Set the front and rear journals on V-blocks.
2. Measure the camshaft runout. Replace the camshaft if necessary.

Runout: 0.03 mm {0.0012 in} max.




3. Inspect the camshaft for wear and damage. Replace the camshaft if necessary.
4. Measure the camshaft lobe height at the point shown.

Height

mm {in}

| | | |
|----|----------|-----------------|
| IN | Standard | 42.973 {1.6918} |
| | Minimum | 42.823 {1.6859} |
| EX | Standard | 43.338 {1.7062} |
| | Minimum | 43.188 {1.7003} |




5. Measure the journal diameters in X and Y directions at two points (A and B) shown.

Diameter: 25.940—25.965 mm {1.0213—1.0222 in}


Minimum: 25.910 mm {1.0201 in}

Out-of-round: 0.03 mm {0.001 in} max.



6. Measure the camshaft journal oil clearances with the HLA removed.


- (1) Remove all foreign material and oil from the journals and bearing surfaces.
- (2) Set the camshaft onto the cylinder head.
- (3) Position Plastigage atop the journals in the axial direction.
- (4) Do not rotate the camshaft when measuring the oil clearances.
- (5) Install the camshaft caps according to the cap numbers as shown.




- (6) Install the camshaft cap bolts and tighten them in five or six steps in the order shown.


Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}






- (7) Loosen the camshaft cap bolts in five or six steps in the order shown.
- (8) Remove the camshaft caps.



- (9) Measure the oil clearances.


Oil clearance: 0.035—0.081 mm {0.0014—0.0031 in}
Maximum: 0.15 mm {0.006 in}

- (10) If the oil clearance exceeds the maximum, replace the cylinder head.



- 7. Measure the camshaft end play. If it exceeds the maximum, replace the camshaft and/or the cylinder head.


End play: 0.08—0.20 mm {0.0032—0.0078 in}
Maximum: 0.21 mm {0.008 in}



HLA

1. Measure the HLA bores in X and Y directions at two points (A and B) as shown.

Diameter: 30.000—30.025 mm {1.1811—1.1820 in}



2. Measure the HLA diameters in X and Y directions at two points (A and B) as shown.


Diameter: 29.959—29.975 mm {1.1795—1.1801 in}

3. Calculate the clearance between the HLA and the related HLA bore.

Clearance: 0.025—0.066 mm {0.00099—0.00259 in}

Maximum: 0.180 mm {0.0071 in}

4. If the clearance exceeds the maximum, replace the HLA and/or to cylinder head.




CYLINDER BLOCK

1. Inspect the cylinder block for the following. Repair or replace the cylinder block if necessary.

- (1) Leakage damage
- (2) Cracks
- (3) Scoring of wall


2. Using a straightedge, measure the top deck of the cylinder block for distortion in the six directions as shown.

Distortion: 0.05 mm {0.002 in} max.



3. If the distortion exceeds the specification, replace it.

Height: 271.0 mm {10.67 in}




4. Measure the cylinder bore in X and Y directions at three levels (A, B, and C) in each cylinder as shown.

Cylinder bore

Base the boring diameter on the diameter of an oversize piston. All cylinders must be the same diameter.


mm {in}

| Bore size | Diameter |
|----------------------|-------------------------------|
| Standard | 83.000—83.019 {3.2678—3.2684} |
| 0.25 {0.01} oversize | 83.250—83.269 {3.2776—3.2783} |
| 0.50 {0.02} oversize | 83.500—83.519 {3.2874—3.2881} |




- (1) If the cylinder bore exceeds the maximum, rebore it to oversize.
- (2) If the difference between measurements A and C exceeds the maximum taper, rebore the cylinder to oversize.

Taper: 0.019 mm {0.0007 in} max.




- (3) If the difference between measurements X and Y exceeds the maximum out-of-round, rebore the cylinder to oversize.

Out-of-round: 0.020 mm {0.0008 in} max.



5. If the upper part of a cylinder wall shows uneven wear, remove the ridge by using a ridge reamer.



PISTON, PISTON RING, AND PISTON PIN

Piston


If the piston is replaced, the piston rings must also be replaced.

1. Inspect the outer circumferences of all pistons for seizing and scoring. Replace if necessary.
2. Measure the outer diameter of each piston at a right angle (90°) to the piston pin, **16.5 mm {0.65 in}** below the oil ring groove lower edge.

Piston diameter

mm {in}


| Piston size | Diameter |
|----------------------|-------------------------------|
| Standard | 82.954—82.974 {3.2659—3.2666} |
| 0.25 {0.01} oversize | 83.204—83.224 {3.2758—3.2765} |
| 0.50 {0.02} oversize | 83.454—83.474 {3.2856—3.2863} |



3. Measure the piston-to-cylinder clearance.

Clearance: 0.039—0.052 mm {0.0016—0.0020 in}
Maximum: 0.15 mm {0.006 in}

4. If the clearance exceeds the maximum, replace the piston or rebore the cylinders to accept oversize pistons. If the piston is replaced, the piston rings must also be replaced.




Piston and Piston Rings


1. Measure the piston ring-to-ring land clearance around the entire circumference of the piston by using a new piston ring.

Clearance

Top: 0.035—0.065 mm {0.0014—0.0025 in}
Second: 0.030—0.065 mm {0.0012—0.0025 in}
Maximum: 0.085 mm {0.0033 in}

2. If the clearance exceeds the maximum, replace the piston.
3. Inspect the piston rings for damage and abnormal wear. Replace the piston rings if necessary.
4. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.





5. Measure the end gap of each piston ring by using a feeler gauge. Replace the piston rings if necessary.

End gap

Top: 0.15—0.30 mm {0.006—0.011 in}


Second: 0.15—0.30 mm {0.006—0.011 in}

Oil rail: 0.20—0.70 mm {0.008—0.027 in}

Maximum


Top, Second: 0.50 mm {0.020 in}

Oil rail: 0.90 mm {0.035 in}

**Piston and Piston Pin**

1. Measure each piston pin bore diameter in X and Y directions at four points.

Diameter: 18.988—19.000 mm {0.7476—0.7480 in}




2. Measure each piston pin diameter in X and Y directions at four points.

Diameter: 18.974—18.980 mm {0.7471—0.7472 in}

3. Calculate the related piston pin-to-piston clearance.

Clearance: 0.008—0.026 mm {0.0003—0.0010 in}

4. If the clearance exceeds the specification, replace the piston and/or piston pin.

CONNECTING ROD


1. Measure the small end inner diameter of each connecting rod.

Diameter: 18.943—18.961 mm {0.7458—0.7464 in}

2. Calculate the interference between the connecting rod small end bore and the related piston pin.

Interference: 0.013—0.037 mm {0.0006—0.0014 in}

If the connecting rod is replaced, the connecting rod cap, bolts, and nuts must also be replaced because they are a matched set.




3. Measure each connecting rod for bending. Replace the connecting rod if necessary.

Bending: 0.05 mm {0.002 in} max./50 mm {1.97 in}

Length (Center to Center):


135.15—135.25 mm {5.3209—5.3247 in}



CONNECTING ROD BOLT

Measure the length of each connecting rod bolt. Replace if necessary.


Length: 46.7—47.3 mm {1.839—1.862 in}
Maximum: 48.0 mm {1.890 in}



MAIN BEARING CAP BOLT

Measure the length of each main bearing cap bolt. Replace if necessary.


Length: 67.7—68.3 mm {2.666—2.688 in}
Maximum: 69.0 mm {2.717 in}



CRANKSHAFT

1. Check the journals and pins for damage, scoring, and oil hole clogging.
2. Set the crankshaft on V-blocks.
3. Measure the crankshaft runout at the center journal. Replace the crankshaft if necessary.

Runout: 0.03 mm {0.0012 in} max.




4. Measure each journal diameter in X and Y directions at two points.

Main journal

Diameter: 55.937—55.955 mm {2.2023—2.2029 in}
Out-of-round: 0.003 mm {0.0001 in} max.

Crankpin journal






Diameter: 47.940—47.955 mm {1.8874—1.8879 in}
Out-of-round: 0.003 mm {0.0001 in} max.



5. If the diameter is less than the minimum, grind the journals to accept undersize bearings.

Undersize bearing:

0.25 mm {0.01 in} (main journal and crankpin),
0.50 mm {0.02 in} (crankpin)

**Main journal diameter undersize**

mm {in}

| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 55.687—55.705 {2.1924—2.1931} |

Crankpin journal diameter undersize

mm {in}

| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 47.690—47.705 {1.8776—1.8781} |
| 0.50 {0.02} undersize | 47.440—47.455 {1.8678—1.8683} |

BEARING**Main Bearing and Connecting Rod Bearing**

Check the main bearings and the connecting rod bearings for peeling, scoring, and other damage.

TIMING BELT**Caution**


- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

1. Replace the timing belt if there is any oil or grease on it.
2. Check the timing belt for damage, wear, peeling, cracks, and hardening. Replace if necessary.

TENSIONER**Caution**


- Using cleaning fluids or a steam cleaner to clean the tensioner can dissolve the grease in its sealed bearing.

1. Use a clean, soft rag to wipe the tensioner contact surface.
2. If the tensioner does not rotate smoothly, replace it.
3. If there are silicone oil leaks, scratches or abnormal noise when turning the tensioner, replace it.
4. If the spring bracket and grommet are loose or damaged, replace the tensioner.

**IDLER****Caution**


- Using cleaning fluids or a steam cleaner to clean the idler can dissolve the grease in its sealed bearing.

1. Use a clean, soft rag to wipe the idler contact surface.
2. If the idler does not rotate smoothly, replace it.
3. If there are silicone oil leaks, scratches or abnormal noise when turning the idler, replace it.

**TENSIONER SPRING**

Measure the free length of the tensioner spring. Replace the tensioner spring if necessary.

Free length: 36.6 mm {1.441 in}

**PULLEY****Timing Belt Pulley, Camshaft Pulley**

















Inspect the pulley teeth for wear, deformation, and other damage. Replace the pulley if necessary.










TIMING BELT COVER

Inspect the timing belt covers for damage and cracks. Replace as necessary.

ASSEMBLY



PREPARATION
SST

| | | | |
|---|---|--|---|
| <p>49 E011 1A0 Brake, ring gear</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 SE01 310A Centering tool, clutch disc</p>  | <p>For installation of clutch disc</p> | <p>49 L012 0A0 Installer set, valve seal & valve guide</p>  | <p>For installation of valve seal</p> |
| <p>49 L012 005 Spacer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> | <p>49 L012 001 Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seal</p> |
| <p>49 L012 002 Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve seal</p> | <p>49 L011 0A0B Tool set, piston pin setting</p>  | <p>For removal / installation of piston pin</p> |
| <p>49 L011 001 Body, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pin</p> | <p>49 L011 005 Bolt, stopper (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pin</p> |
| <p>49 L011 006 Installer, piston pin (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pin</p> | <p>49 E011 001 Guide</p>  | <p>For removal / installation of piston pin</p> |
| <p>49 E011 002 Screw</p>  | <p>For removal / installation of piston pin</p> | <p>49 D011 002B Head, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pin</p> |

| | | | |
|---|--|---|---|
| <p>49 0636 100B</p> <p>Arm, valve spring lifter</p>  | <p>For removal / installation of valve</p> | <p>49 B012 0A2</p> <p>Pivot</p>  | <p>For removal / installation of valve</p> |
| <p>49 B012 012</p> <p>Body (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valve</p> | <p>49 B012 013</p> <p>Foot (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valve</p> |
| <p>49 B012 014</p> <p>Locknut (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valve</p> | <p>49 G014 001</p> <p>Wrench, oil filter</p>  | <p>For removal / installation of oil filter</p> |
| <p>49 B014 001</p> <p>Installer, oil seal</p>  | <p>For installation of camshaft oil seal</p> | <p>49 H010 401</p> <p>Installer, oil seal</p>  | <p>For installation of front oil seal</p> |
| <p>49 G033 107A</p> <p>Installer, dust cover</p>  | <p>For installation of rear oil seal</p> | <p>—</p> | <p>—</p> |

1. Do not reuse gaskets or oil seals.
2. Clean all parts before reinstallation.
3. Apply clean engine oil to all sliding and rotating parts.
4. Replace plain bearings if they are peeled, burned, or otherwise damaged.
5. Tighten all bolts and nuts to the specified torque.

CYLINDER BLOCK (INTERNAL PARTS)
Torque Specifications




Crankshaft


1. Before installing the crankshaft, inspect the main bearing oil clearances as follows.

Oil clearance inspection

- (1) Remove all foreign material and oil from the journals and bearings.




- (2) Install the grooved upper main bearings in the cylinder block.
- (3) Install the thrust bearings with the oil groove facing the crankshaft.
- (4) Set the crankshaft in the cylinder block.
- (5) Position Plastigage atop the journals in the axial direction.
- (6) Do not rotate the crankshaft when measuring the oil clearances.




- (7) Install the lower main bearings and the main bearing caps according to the cap number, facing the mark toward the front.
- (8) Tighten the main bearing cap bolts in two or three steps in the order shown.

Tightening torque:

17.2—22.0 N·m {1.75—2.25 kgf·m, 12.7—16.2 ft·lbf}




- (9) Put a paint mark on each bolt head.
- (10) Using the mark as a reference, tighten the bolts by turning each **85°—95°** in the sequence shown.




- (11) Remove the main bearing caps, and measure the Plastigage at each journal at the widest point for the smallest clearance, and at the narrowest point for the largest clearance.
- (12) If the oil clearance exceeds the specification, grind the crankshaft and install undersize main bearings. (Refer to page B1-68.)

| | mm {in} | |
|---------------|--------------------------------|--------------------------------|
| | No.1, 2, 4, 5 | No.3 |
| Oil clearance | 0.024—0.050 {0.0010—0.0019} | 0.030—0.056 {0.0012—0.0022} |
| Maximum | 0.067 {0.0026} | |




2. Apply clean engine oil to the main bearings, thrust bearings and main journals.
3. Install the main bearing caps according to the cap number, facing the mark toward the front.




4. Tighten the main bearing cap bolts in two or three steps in the order shown.

Tightening torque: 17.2—22.0 N·m
 {1.75—2.25 kgf·m, 12.7—16.2 ft·lbf} +85°—95°



5. Measure the crankshaft end play.


End play: 0.080—0.282 mm {0.0032—0.0111 in}
Maximum: 0.30 mm {0.0118 in}



6. If the end play exceeds the maximum, grind the crankshaft and install oversize thrust bearings, or replace the crankshaft and thrust bearings.


Thrust bearing width

Standard:
 2.500—2.550 mm {0.0985—0.1003 in}
 0.25 mm {0.01 in} **oversize:**
 2.625—2.675 mm {0.1034—0.1053 in}
 0.50 mm {0.02 in} **oversize:**
 2.750—2.800 mm {0.1083—0.1102 in}
 0.75 mm {0.03 in} **oversize:**
 2.875—2.925 mm {0.1132—0.1151 in}



Connecting Rod


1. Assemble the **SST** and the piston pin as shown.
2. Apply clean engine oil to the piston pin.




3. Adjust the **SST** (stopper bolt) so that depth L is as specified.

Depth L: 59.1 mm {2.33 in}

4. Tighten the locknut.




5. Set the piston on the **SST** with the **F** mark facing upward.
6. Assemble the piston and the connecting rod in the direction from which they were disassembled.
7. Verify that the **SST** is set squarely into the piston.




8. Set the piston and connecting rod on the **SST** as shown and press the piston pin through the piston and connecting rod until the **SST** contacts the stopper bolt.
9. While inserting the piston pin, check the pressing force. If it is less than specified, replace the piston pin and/or the connecting rod.

Pressing force:

4,904—14,709 N {500—1,500 kgf, 1,100—3,300 lbf}



10. Check the oscillation torque of the connecting rod. If the large end does not drop by its own weight, replace the piston and/or piston pin.



Piston Ring


1. Install the three-piece oil rings on the pistons.
 - (1) Apply clean engine oil to the oil ring spacer and rails.
 - (2) Install the oil ring spacer with the ends upward.


Note

- The upper and lower rails are the same. They can be installed with either face upward.


- (3) Install the upper and lower rails.

2. Verify that the spacer tang separates the rails, and that the rails turn smoothly in both directions.






3. Install the second ring with the scraper face downward.
4. Apply clean engine oil to the top and second piston rings.
5. Install the second ring to the piston; then install the top ring. Use a piston ring expander.




6. Position the end gaps of the rings as shown.



Piston and connecting rod assembly

The piston and the cylinder block have matching marks on them to ensure correct installation. Note these marks when installing the pistons.




Mark Standard






| Piston | Cylinder block |
|--------|----------------|
| a | A |
| b | B |
| c | C |

Oversize (piston)

| | |
|----|-----------|
| 25 | 0.25 O.S. |
| 50 | 0.50 O.S. |



1. Apply clean engine oil to the cylinder walls, pistons, and piston rings.
2. Check the piston rings for correct end gap alignment.
3. Using a piston ring compressor, insert each piston assembly into the cylinder block with the F mark facing the front of the engine.



Connecting Rod Cap

1. Measure the connecting rod bearing oil clearances using the same procedure as for the main bearing oil clearance.

Tightening torque: 22.1—26.9 N·m
{2.25—2.75 kgf·m, 16.3—19.8 ft·lbf} + 82.5°—97.5°

Oil clearance: 0.024—0.061 mm {0.0010—0.0024 in}
Maximum: 0.067 mm {0.0026 in}

2. If the oil clearance exceeds the maximum, grind the crankshaft to accept undersize bearings. (Refer to page B1-68.)

3. Measure the connecting rod side clearances.

Side clearance:
0.110—0.262 mm {0.0044—0.0103 in}
Maximum: 0.30 mm {0.012 in}

4. If the clearance exceeds the maximum, replace the connecting rod and the cap.



5. Apply clean engine oil to the crankpin journals and the connecting rod bearings.

6. Install the connecting rod caps with the knock pins and the alignment marks aligned.

7. Tighten the connecting rod cap bolts.


Tightening torque: 22.1—26.9 N·m
{2.25—2.75 kgf·m, 16.3—19.8 ft·lbf} + 82.5°—97.5°

CYLINDER BLOCK (EXTERNAL PARTS)
Torque Specifications




Rear Cover

1. Apply clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.
3. Using the **SST** and a hammer, tap the oil seal in evenly until it is flush with the edge of the rear cover.




4. Apply silicone sealant to the rear cover as shown.



5. Install the rear cover within five minutes of applying the sealant.


Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Oil Pump

1. Apply clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.
3. Press the oil seal into the oil pump body by using the **SST**.




4. Apply silicone sealant to the oil pump housing as shown.




5. Install the oil pump within five minutes of applying the sealant.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



- Remove any sealant that is pushed out at the oil pan side.




Water Pump

Install the water pump along with a new gasket and new rubber seals. Verify that the rubber seals stay in place when installing the pump.


Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



Oil Pan Upper Block


- Remove all foreign material from the contact surfaces.
- Apply silicone sealant to the oil pan upper block as shown.



- Install the oil pan upper block within five minutes of applying the sealant.
- Tighten the two nuts.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



- Tighten the oil pan upper block bolts in two or three steps in the order shown.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

**Oil Strainer**


1. Install the oil strainer along with a new gasket.
2. Tighten the bolts marked (A) first.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

**Oil Pan**


1. Remove all foreign material from the contact surfaces.
2. Apply silicone sealant to the oil pan as shown.



3. Install the oil pan within five minutes of applying the sealant.
4. Tighten the oil pan bolts.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

**End Plate**

Install the end plate.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

**Flywheel (MTX)**

1. Remove the sealant from the flywheel bolt holes in the crankshaft and from the flywheel bolts.


Caution

- If all of the old thread locking sealant cannot be removed from the bolt, it will not torque properly. Replace the bolt.

Note

- If a new bolt is used, do not apply thread locking sealant. New Mazda bolts have sealant on them.


2. Set the flywheel onto the crankshaft.
3. Apply sealant to the flywheel bolts and install them.



4. Hold the flywheel by using the **SST**.
5. Tighten the bolts in two or three steps in the order shown.

Tightening torque:


97—102 N·m {9.8—10.5 kgf·m, 71—75.9 ft·lbf}

**Clutch Disc and Clutch Cover (MTX)**

1. Install the clutch disc and the clutch cover by using the **SST**.
2. Tighten the clutch cover bolts in two or three steps in the order shown.

Tightening torque:

18—26 N·m {1.8—2.7 kgf·m, 14—19 ft·lbf}

**Drive Plate (ATX)**


1. Remove the sealant from the drive plate bolt holes in the crankshaft and from the drive plate bolts.

Caution

- If all of the old thread locking sealant cannot be removed from the bolt, it will not torque properly. Replace the bolt.

Note

- If a new bolt is used, do not apply thread locking sealant. New Mazda bolts have sealant on them.



2. Set the adapter, drive plate, and backing plate onto the crankshaft.

3. Apply sealant to the drive plate bolts and install them.



4. Hold the drive plate by using the **SST**.

5. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

97—102 N·m {9.8—10.5 kgf·m, 71—75.9 ft·lbf}


CYLINDER HEAD Torque Specifications



Valve Seal


The intake and exhaust valve seals are different as shown.

| | Ridge | Color |
|---------|-----------|---------------|
| Intake | No or One | Gray |
| Exhaust | Two | Gray or Green |




1. Assemble the **SST** so that depth **L** is as specified.

Depth L: 17.7—18.3 mm {0.697—0.720 in}




2. Slide the valve seal onto the valve guide.
3. Set the **SST** against the valve seal.



Caution


- Using a hammer will damage the valve seal.

4. Using the **SST**, press the valve seal on by hand until the **SST** touches the cylinder head.




Valve and Valve Spring

1. Install the lower spring seat.
2. Install the valve.
3. Install the valve spring with the closer pitch toward the cylinder head.
4. Install the upper spring seat.




5. Compress the valve spring by using the **SST**, and install the valve keepers.
6. Remove the **SST**.
7. Tap the end of the valve stem lightly two or three times with a plastic hammer to verify that the keepers are fully seated.



Cylinder Head Gasket

1. Remove all foreign material from the top of the cylinder block.
2. Place the new cylinder head gasket in position.




Cylinder Head


1. Install the cylinder head.
2. Tighten the cylinder head bolts.
 - (1) Apply clean engine oil to the bolt threads and seat faces.
 - (2) Tighten the cylinder head bolts in two or three steps in the order shown.

Tightening torque:

17.2—22.0 N·m {1.75—2.25 kgf·m, 12.7—16.2 ft·lbf}




- (3) Put a paint mark on each bolt head.
- (4) Use this mark as a reference, tighten the bolts **85°—95°** in the order shown.
- (5) Further tighten each bolt **another 85°—95°**.



HLA

1. Apply clean engine oil to the friction surfaces of the HLA.
2. If the HLA are being reused, install them in the position from which they were removed.
3. Verify that the HLA move smoothly in their bores.




Camshaft


Note

- The exhaust camshaft is machined with the distributor drive gear.


1. Apply clean engine oil to the camshaft journals and bearings.
2. Install the camshaft in position, facing the dowel pin upward.



3. Apply silicone sealant to the shaded areas shown.




4. Install the camshaft caps according to the cap number as shown.




5. Install the camshaft cap bolts and tighten them in five or six steps in the order shown.

Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}




- 6. Apply clean engine oil to the lip of each new camshaft oil seal.
- 7. Push the oil seals slightly in by hand.
- 8. Using the **SST** and a hammer, tap the oil seal in evenly until it is flush with the edge of the camshaft cap.



Camshaft Pulley

1. Install the camshaft pulleys, positioning the dowel pins as shown.





2. Apply clean engine oil to the camshaft bolt threads and hand tighten the bolts.
3. Hold the camshafts by using a wrench on the cast hexagon as shown, and tighten the bolts.

Tightening torque:


50—60 N·m {5.0—6.2 kgf·m, 37—44 ft·lbf}

TIMING BELT
Torque Specifications



Timing Belt


1. Install the timing belt pulley and key.



2. Install the tensioner spring to the tensioner.
3. Install the tensioner and the idler.

Tightening torque


- Ⓐ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}
- Ⓑ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}




4. Using a torque wrench, rotate the tensioner right and left to measure the resistance. Replace the tensioner if the torque (resistance) is not as specified.

Resistance:


- 0.50—2.25 N·m {5.0—23.0 kgf·cm, 4.4—19.9 in·lbf}
- [10—30°C {50—86°F}]




5. Temporarily install the crankshaft pulley bolt.
6. Turn the crankshaft clockwise and align the timing marks.




7. Verify that the camshaft pulley marks are aligned with the cylinder head parting line.




8. Install the timing belt so that there is no looseness at the idler side or between the two camshaft pulleys.




9. Turn the crankshaft two turns clockwise, and align the timing belt pulley marks.
10. Verify that all timing marks are correctly aligned.
If not aligned, remove the timing belt and repeat from tensioner installation.




11. Turn the tensioner clockwise by using an Allen wrench.
12. Connect the tensioner to the hook pin.




13. Turn the crankshaft two turns clockwise and again verify that the timing marks are correctly aligned.



14. Hold the flywheel (MTX) or the drive plate (ATX) by using the SST.



15. Remove the crankshaft pulley bolt.




No.3 engine mount bracket

Install the No.3 engine mount bracket.

Tightening torque:

44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}




Timing Belt Cover

1. Install the lower, then upper covers.
2. Install the dipstick and pipe.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Water Pump Pulley

Install the water pump pulley, facing the “F” marks outward.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Crankshaft Pulley

1. Install the timing belt guide plate, facing the flat side toward the timing belt.

2. Hold the flywheel (MTX) or the drive plate (ATX) by using the SST.






3. Install the crankshaft pulley.
4. Tighten the crankshaft pulley bolt.


Tightening torque:

157—166 N·m {16.0—17.0 kgf·m, 116—122 ft·lbf}




Cylinder Head Cover

1. Install a new cylinder head cover gasket.



2. Apply silicone sealant to the shaded areas of the cylinder head as shown.





3. Install the cylinder head cover.
4. Install the cylinder head cover bolts and tighten them in five or six steps in the order shown.

Tightening torque:

6.9—10.7 N·m {70—110 kgf·cm, 61—95.4 in·lbf}

AUXILIARY PARTS Torque Specifications




**Oil Filter**

1. Remove all foreign material from the oil filter mounting surface.
2. Apply a small amount of clean engine oil to the rubber seal of the oil filter.
3. Install the oil filter and tighten it by hand until the rubber seal contacts the mounting surface.
4. Tighten the filter 1-1/6 turns by using the SST.

Tightening torque:


14—17 N·m {1.4—1.8 kgf·m, 11—13 ft·lbf}

**Water Outlet**

1. Place the water outlet in position.
2. Hand tighten bolt (A).
3. Install the water outlet.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

**Heat Gauge Sender Unit and Engine Coolant Temperature Sensor**

1. Apply silicone sealant to the top two-thirds of the threads.

2. Install the heat gauge sender unit.


Tightening torque:

6.4—9.3 N·m {65—95 kgf·cm, 57—82 in·lbf}

3. Install the engine coolant temperature sensor.

Tightening torque:


16—23 N·m {1.6—2.4 kgf·m, 12—17 ft·lbf}

**Generator**

1. Install the generator bracket.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



2. Install the generator and the strap.

Tightening torque


- Ⓐ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}
- Ⓑ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}
- Ⓒ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



3. Install the generator stay. (MTX)

Tightening torque:

- 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




Intake Manifold Assembly

1. Remove all foreign material from the intake manifold contact surface.
2. Install a new gasket and the intake manifold assembly.

Tightening torque:

- 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




Spark Plug

- Install the spark plugs.


Tightening torque:

- 15—22 N·m {1.5—2.3 kgf·m, 11—16 ft·lbf}




Distributor and High-tension Lead

1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply clean engine oil to the drive gear.
3. Verify that the No.1 cylinder is at the top dead center and the distributor matching marks are aligned.



4. Install the distributor and hand tighten the installation bolts.
5. Connect the high-tension leads.



Engine Hanger

Install the front and rear engine hangers.

Tightening torque:



38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

ENGINE STAND DISMOUNTING

PROCEDURE

1. Remove the engine from the **SST** (engine stand).
2. Remove the **SST** (engine hanger) from the engine.
3. Install the parts shown in the figure.

Torque Specifications




Thermostat Housing

Install a new gasket and the thermostat housing.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

**Water Bypass Pipe**

1. Apply a small amount of clean engine coolant to new O-rings.
2. Install the water bypass pipes.


Note

- Bolt (A) is at the water outlet. (Refer to page B1-95.)


Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}


3. Connect the water hose.

**Thermostat, Thermostat Cover**

1. Remove all foreign material from the thermostat cover mounting surface.
2. Verify that the left jiggle pin is aligned with the tab of the thermostat gasket as shown.




3. Install the thermostat and gasket into the thermostat housing, aligning the tab to the housing as shown.



4. Install the thermostat cover.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

**A/C Compressor Bracket (if equipped)**

Install the A/C compressor bracket.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}




Exhaust Manifold

1. Remove all foreign material from the exhaust manifold contact surface.
2. Install the new gasket and the exhaust manifold.

Tightening torque

Nut: 20—28 N·m {2.0—2.9 kgf·m, 15—20 ft·lbf}
 Bolt: 16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}




EGR Pipe

Install the EGR pipe.

Tightening torque

Ⓐ: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}
 Ⓑ: 32—47 N·m {3.2—4.8 kgf·m, 24—34 ft·lbf}




Exhaust Manifold Insulator

Install the exhaust manifold insulator.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



P/S Oil Pump Bracket

Install the P/S oil pump bracket.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



INSTALLATION

PROCEDURE

Tighten all bolts and nuts to the specified torques.

Step 1

Torque Specifications




No.2 engine mount bracket


Install the No.2 engine mount bracket.

Tightening torque:

44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}

**No.2 engine mount rubber**


Install the No.2 engine mount rubber and hand tighten the through bolt.

**Starter**

Install the starter to the transaxle housing.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

**Intake manifold bracket**

Install the intake manifold bracket.

Tightening torque:



38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

Step 2

Warning


- A vehicle that is lifted but not securely supported on safety stands is dangerous. It can slip or fall, causing death or serious injury. Never work around or under a lifted vehicle if it is not securely supported on safety stands.

Torque Specifications



Engine and transaxle assembly

1. Suspend the engine and transaxle assembly.
Slowly lower the engine and transaxle assembly as a unit.
Keep the engine from swinging or bumping into components in the engine compartment.
2. Position the engine and transaxle assembly in the engine compartment.
3. Align the engine mounts with the engine mount member mounting holes.




Engine mount

1. Hand tighten the nuts marked **Ⓑ**. (No.2 engine mount)
2. Install the bolts and nuts shown.

Tightening torque

Ⓐ: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}



3. Install the No.1 engine mount mounting bolts.

Tightening torque


MTX: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

ATX

Ⓐ: 67—104 N·m {6.8—10.7 kgf·m, 50—77.3 ft·lbf}

Ⓑ: 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}

Ⓒ: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}




4. Install the No.3 engine mount rubber.

Tightening torque

Nut: 74—102 N·m {7.5—10.5 kgf·m, 55—75.9 ft·lbf}

Bolt: 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}



5. Install the No.4 engine mount bracket.
6. Hand tighten bolts **Ⓑ**.
7. Tighten bolts **Ⓑ**.
8. Tighten bolts **Ⓐ**.

Tightening torque

Ⓐ: 59—80 N·m {6.0—8.2 kgf·m, 44—59 ft·lbf}

Ⓑ: 59—80 N·m {6.0—8.2 kgf·m, 44—59 ft·lbf}

9. Install the No.4 engine mount rubber.

Tightening torque


MTX

Ⓐ: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

Ⓑ: 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}

ATX


Ⓒ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



10. Remove the chain from the engine hangers.
11. Tighten the No.2 engine mount nuts. (Refer to step 1.)

Tightening torque:

75—104 N·m {7.6—10.7 kgf·m, 55—77.3 ft·lbf}




12. Tighten the No.2 engine mount rubber through bolt.
(Refer to page B1-102.)

Tightening torque:
86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}

13. Install the No.5 engine mount rubber as shown.


Tightening torque
A: 55—80 N·m {5.6—8.2 kgf·m, 41—59 ft·lbf}
B: 44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}




14. Install the No.1 engine mount stay bracket and ground harness (MTX).

Tightening torque:
6.9—9.8 N·m {70—100 kgf·cm, 61—86.8 in·lbf}

Step 3
Torque Specifications




**Joint shaft**

1. Install the new clip.
2. Install the joint shaft.
3. Tighten the bolts in the order shown.

Tightening torque:

43—61 N·m {4.3—6.3 kgf·m, 32—45 ft·lbf}

4. Apply grease to the end of joint shaft.

**Drive shaft**

1. Apply grease to the end of the drive shafts.


Caution

- The oil seals are damaged easily if this procedure is not done correctly.

2. Install the drive shaft.
3. Install the new clip with the end gap facing upward.
4. Push the drive shaft into the joint shaft.
5. After installation, pull the front hub outward to confirm that the drive shaft is securely held by the clip.
6. Install the lower arm ball joint to the knuckle and tighten the through bolt.

Tightening torque:

35—56 N·m {3.5—5.8 kgf·m, 26—41 ft·lbf}


**Tie-rod end**

1. Install the tie-rod end to the knuckle.

Tightening torque:

32—44 N·m {3.2—4.5 kgf·m, 24—32 ft·lbf}


2. Install a new cotter pin.


**Stabilizer control link**

Install the stabilizer control link.

Tightening torque:

37—53 N·m {3.7—5.5 kgf·m, 27—39 ft·lbf}





Extension bar (MTX)

Install the extension bar to the transaxle.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

Shift control rod (MTX)

Install the shift control rod to the transaxle.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}




Front exhaust pipe

1. Install a new gasket and connect the front exhaust pipe to the exhaust pipe. Hand tighten the new nuts.
2. Connect the exhaust pipe to the vehicle body by the mount rubbers.
3. Tighten the exhaust pipe mounting nuts.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



Exhaust pipe

1. Install a new gasket and the exhaust pipe. Hand tighten the new nuts.
2. Hand tighten the bracket bolts.
3. Tighten the exhaust pipe mounting nuts.


Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

4. Tighten the bracket bolts.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}




Transverse member

Install the transverse member.

Tightening torque:

94—131 N·m {9.5—13.4 kgf·m, 69—96.9 ft·lbf}



Clutch release cylinder


Install the clutch release cylinder.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

Step 4



Connect the hoses shown in the figure.



Step 5

Connect the harness connectors.

Step 6
Torque Specifications




A/C compressor (if equipped)

Install the A/C compressor to the bracket.

Tightening torque:

24—35 N·m {2.4—3.6 kgf·m, 18—26 ft·lbf}



P/S oil pump and adjuster

1. Install the P/S oil pump adjuster.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}


2. Install the P/S oil pump.

Tightening torque

Ⓐ: 44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}

Ⓑ: 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}


3. Connect the P/S oil pump pressure switch connector.



4. Install the P/S pipe brackets to the cylinder head cover.


Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



Drive belt

1. Install the drive belt.
2. Adjust the drive belt deflections. (Refer to page B1-6.)




Radiator and cooling fan assembly


1. Install the radiator and cooling fan assembly.
Verify that the radiator is centered in the radiator upper brackets.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



2. Connect the upper and lower radiator hoses.
3. Connect the coolant reservoir hose.
4. Connect the cooling fan motor connector.
5. Connect the oil cooler hoses. (ATX)




Accelerator cable

1. Verify that the throttle valve is fully closed.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.0 mm {0.06—0.16 in}

3. If not as specified, turn stopper (B) while pressing lock button (A) to release the lock.
4. Push the spring in direction (C) and adjust the cable free play.
5. Lock stopper (A) after locking stopper (B).




Battery

1. Install the battery.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

2. Connect the positive battery terminal.




Resonance chamber No.2


1. Slide the hose clamp onto the hose and push it onto resonance chamber No.2.



2. Rotate the hose and hook it securely onto the locating knob.



3. Tighten the hose clamp.




Air cleaner assembly

1. Install the air cleaner assembly.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

2. Connect the mass air flow sensor connector.
3. Connect the intake air temperature sensor connector.

**Fresh-air duct**

Install the fresh-air duct.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

Splash shield

Install the splash shield.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

Steps After Installation

1. Fill with the specified amount and type of engine oil. (Refer to section D1.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E1.)
3. Fill with the specified amount and type of transaxle oil. (Refer to sections J, K2.)
4. Install the hood and front wheels.
5. Start the engine and:
 - (1) check the engine oil, transaxle oil, and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to sections F1, F3.)
 - (3) check the operation of the emission control system.
6. Turn off the engine and check drive belt deflection. (Refer to page B1-6.)
7. Perform a road test.
8. Recheck the engine oil and coolant levels.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

ENGINE (KL)

| | | | |
|-------------------------------------|--------|-------------------------------------|--------|
| INDEX | B2- 2 | INSPECTION / REPAIR | B2- 72 |
| OUTLINE | B2- 3 | PREPARATION | B2- 72 |
| SPECIFICATIONS | B2- 3 | CYLINDER HEAD | B2- 72 |
| TROUBLESHOOTING GUIDE | B2- 3 | VALVE MECHANISM | B2- 73 |
| ENGINE TUNE-UP | B2- 5 | CAMSHAFT | B2- 76 |
| PREPARATION | B2- 5 | HLA | B2- 79 |
| ENGINE OIL | B2- 5 | CYLINDER BLOCK | B2- 80 |
| ENGINE COOLANT | B2- 5 | PISTON, PISTON RING, | |
| DRIVE BELT | B2- 6 | AND PISTON PIN | B2- 80 |
| HLA TROUBLESHOOTING | | CONNECTING ROD | B2- 82 |
| GUIDE | B2- 7 | CRANKSHAFT | B2- 82 |
| COMPRESSION | B2- 8 | BEARING | B2- 83 |
| PREPARATION | B2- 8 | OIL JET | B2- 83 |
| INSPECTION | B2- 8 | TIMING BELT | B2- 83 |
| ON-VEHICLE MAINTENANCE | B2- 9 | TIMING BELT AUTO TENSIONER | B2- 84 |
| PREPARATION | B2- 9 | PULLEY | B2- 84 |
| TIMING BELT | B2- 10 | TIMING BELT COVER | B2- 84 |
| CYLINDER HEAD GASKET | B2- 20 | ASSEMBLY | B2- 85 |
| HLA | B2- 34 | PREPARATION | B2- 85 |
| FRONT OIL SEAL | B2- 37 | CYLINDER BLOCK | |
| REAR OIL SEAL | B2- 39 | (INTERNAL PARTS) | B2- 87 |
| REMOVAL | B2- 42 | CYLINDER BLOCK | |
| PROCEDURE | B2- 42 | (EXTERNAL PARTS) | B2- 95 |
| ENGINE STAND MOUNTING | B2- 51 | CYLINDER HEAD | B2- 99 |
| PREPARATION | B2- 51 | TIMING BELT | B2-106 |
| PROCEDURE | B2- 52 | AUXILIARY PARTS | B2-111 |
| DISASSEMBLY | B2- 55 | ENGINE STAND DISMOUNTING ... | B2-115 |
| PREPARATION | B2- 55 | PROCEDURE | B2-115 |
| AUXILIARY PARTS | B2- 57 | INSTALLATION | B2-116 |
| TIMING BELT | B2- 59 | PROCEDURE | B2-116 |
| CYLINDER HEAD | B2- 62 | | |
| CYLINDER BLOCK | | | |
| (EXTERNAL PARTS) | B2- 65 | | |
| CYLINDER BLOCK | | | |
| (INTERNAL PARTS) | B2- 68 | | |

INDEX

INTAKE MANIFOLD TIGHTENING TORQUE
19—25 N·m
{1.9—2.6 kgf·m, 14—18 ft·lbf}

INTAKE MANIFOLD TIGHTENING TORQUE
19—25 N·m
{1.9—2.6 kgf·m, 14—18 ft·lbf}

ENGINE OIL, SECTION D2

ENGINE COOLANT, SECTION E2

EXHAUST MANIFOLD TIGHTENING TORQUE
19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

DRIVE BELT DEFLECTION AT 98 N {10 kgf, 22 lbf}

| DRIVE BELT | NEW | USED | LIMIT | COMPRESSION | kPa {kgf/cm ² , psi}-rpm |
|---------------|---------------------|---------------------|------------|-----------------------------------|-------------------------------------|
| GENERATOR | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} | STANDARD | 1,402 {14.3, 203}—250 |
| GENERATOR+A/C | 5.5—6.5 {0.22—0.25} | 6.5—7.5 {0.26—0.29} | 8.0 {0.31} | MINIMUM | 981 {10.0, 142}—250 |
| P/S | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} | MAX. DIFFERENCE BETWEEN CYLINDERS | 196 {2.0, 28} |

COMPRESSION INSPECTION, PAGE B2-8

- 1. Timing belt
Removal / Installation page B2-10
- 2. Cylinder head gasket
Replacement page B2-20
- 3. HLA
Removal / Installation page B2-34
- 4. Front oil seal
Replacement page B2-37
- 5. Rear oil seal
Replacement page B2-39

- 6. Engine
Removal page B2-42
- Engine stand mounting page B2-51
- Disassembly page B2-55
- Inspection / Repair page B2-72
- Assembly page B2-85
- Engine stand dismounting ... page B2-115
- Installation page B2-116


OUTLINE

SPECIFICATIONS

| Item | | Engine | KL | |
|---------------------------------|----|-------------------------------------|----------------------------------|-----|
| Type | | | Gasoline, 4-cycle | |
| Cylinder arrangement and number | | | 60°-V configuration, 6 cylinders | |
| Combustion chamber | | | Pentroof | |
| Valve system | | | DOHC, belt-driven, 24 valves | |
| Displacement | | ml {cc, cu in} | 2,496 {2,496, 152.3} | |
| Bore × stroke | | mm {in} | 84.5 × 74.2 {3.33 × 2.92} | |
| Compression ratio | | | 9.2 | |
| Compression pressure | | kPa {kgf/cm ² , psi}-rpm | 1,402 {14.3, 203}-250 | |
| Valve timing | IN | Open | BTDC | 8° |
| | | Close | ABDC | 47° |
| | EX | Open | BBDC | 50° |
| | | Close | ATDC | 5° |
| Valve clearance | IN | mm {in} | 0 {0}: Maintenance-free | |
| | EX | mm {in} | 0 {0}: Maintenance-free | |

B2

Cylinder Arrangement



TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|--------------------|---|---------------------|-----------|
| Difficult starting | Malfunction of engine-related components | | |
| | Burnt valve | Replace | B2-73 |
| | Worn piston, piston ring, or cylinder | Replace or repair | B2-80, 81 |
| | Damaged cylinder head gasket | Replace | B2-20 |
| | Malfunction of fuel system | Refer to section F2 | |
| | Malfunction of electrical system | Refer to section G | |
| Poor idling | Malfunction of engine-related components | | |
| | Malfunction of HLA* | Replace | B2-34 |
| | Poor valve-to-valve seat contact | Repair or replace | B2-75 |
| | Damaged cylinder head gasket | Replace | B2-20 |
| | Malfunction of fuel system | Refer to section F2 | |
| | Malfunction of ignition system | Refer to section G | |

* Tappet noise may occur if the engine has not been started for an extended period of time. The noise should stop after the engine reaches normal operating temperature. (HLA troubleshooting: Refer to page B2-7.)

| Problem | Possible Cause | Action | Page |
|---|---|---------------------|-----------|
| Insufficient power | Insufficient compression | | |
| | Malfunction of HLA* | Replace | B2-34 |
| | Compression leakage from valve seat | Repair | B2-75 |
| | Stuck valve | Replace | B2-73 |
| | Weak or broken valve spring | Replace | B2-76 |
| | Damaged cylinder head gasket | Replace | B2-20 |
| | Cracked or distorted cylinder head | Replace | B2-72 |
| | Stuck, damaged, or worn piston ring | Replace | B2-81 |
| | Cracked or worn piston | Replace | B2-80 |
| | Malfunction of fuel system | Refer to section F2 | |
| Malfunction of ignition system | Refer to section G | | |
| | Others | | |
| | Slipping clutch | Refer to section H | |
| | Dragging brake | Refer to section P | |
| | Incorrect tire size | Refer to section Q | |
| | Malfunction of engine-related components | | |
| | Malfunction of HLA* | Replace | B2-34 |
| Abnormal combustion | Stuck or burnt valve | Replace | B2-73 |
| | Weak or broken valve spring | Replace | B2-76 |
| | Carbon accumulation in combustion chamber | Eliminate carbon | |
| Malfunction of fuel system | Refer to section F2 | | |
| Malfunction of ignition system | Refer to section G | | |
| Excessive oil consumption | Oil working up | | |
| | Worn piston ring groove or stuck piston ring | Replace | B2-81 |
| | Worn piston or cylinder | Replace or repair | B2-80, 81 |
| | Oil working down | | |
| | Worn valve seal | Replace | B2-64 |
| | Worn valve stem or guide | Replace | B2-73, 74 |
| Oil leakage | Refer to section D2 | | |
| Engine noise | Crankshaft or bearing-related parts | | |
| | Excessive main bearing oil clearance | Replace or repair | B2-89 |
| | Main bearing heat-damaged | Replace | B2-83 |
| | Excessive crankshaft end play | Replace or repair | B2-92 |
| | Excessive connecting rod bearing oil clearance | Replace or repair | B2-93 |
| | Connecting rod bearing heat-damaged | Replace | B2-83 |
| | Piston-related parts | | |
| | Worn cylinder | Replace or repair | B2-80 |
| | Worn piston or piston pin | Replace | B2-80, 81 |
| | Damaged piston ring | Replace | B2-81 |
| | Bent connecting rod | Replace | B2-82 |
| | Valve train-related parts | | |
| | Malfunction of HLA* | Replace | B2-79 |
| | Broken valve spring | Replace | B2-76 |
| | Excessive valve guide clearance | Replace | B2-73 |
| Malfunction of timing belt auto tensioner | Replace | B2-84 | |
| Malfunction of friction gear | Replace | B2-76 | |
| Malfunction of cooling system | Refer to section E2 | | |
| Malfunction of fuel system | Refer to section F2 | | |
| Others | Malfunction of water pump bearing | Refer to section E2 | |
| | Improper drive belt tension | Adjust | B2- 5 |
| | Malfunction of generator bearing | Refer to section G | |
| | Exhaust gas leakage | Refer to section F2 | |
| | Malfunction of timing belt tensioner | Replace | B2-10 |

* Tappet noise may occur if the engine has not been started for an extended period of time. The noise should stop after the engine reaches normal operating temperature. (HLA troubleshooting: Refer to page B2-7.)


Warning




- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**

ENGINE TUNE-UP

PREPARATION

SST

| | |
|--|---|
| <p>49 9200 020A</p> <p>V-ribbed belt tension gauge</p>  | <p>For inspection of drive belt tension</p> |
|--|---|



ENGINE OIL

Inspection

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil if necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.9 Imp qt}.

ENGINE COOLANT

Inspection

Coolant level (Engine cold)

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam can shoot out and cause serious injury. It can also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.






1. Verify that the coolant level is at the filler neck.
2. Verify that the coolant level on the dipstick is between the F and L marks.
3. Add coolant if necessary.

Note

- The distance between the L and F marks on the dipstick represents 0.5 L {0.5 US qt, 0.4 Imp qt}.

Coolant quality

1. Verify that there is no buildup of rust or scale around the radiator cap, filler cap, and filler neck.
2. Verify that the coolant is free of oil. Replace the coolant if necessary.



DRIVE BELT

Inspection

1. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.

3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure **98 N {10 kgf, 22 lbf}** midway between the specified pulleys.

Deflection

| Drive belt | mm {in} | | |
|-----------------|------------------------|------------------------|------------|
| | *New | Used | Limit |
| Generator | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} |
| Generator + A/C | 5.5—6.5 {0.22—0.25} | 6.5—7.5 {0.26—0.29} | 8.0 {0.31} |
| P/S | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} |

* A belt that has been on a running engine for less than five minutes.

4. If the deflection is not within the specification, adjust it. (Refer to page B2-7.)

Drive belt tension check

Belt tension can be checked in place of belt deflection.



1. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the **SST**, check the belt tension between any two pulleys.

Tension

| Drive belt | N {kgf, lbf} | | |
|-----------------|-----------------------------|-----------------------------|--------------|
| | *New | Used | Limit |
| Generator | 690—880 {70—90, 160—190} | 500—680 {50—70, 110—150} | 440 {45, 99} |
| Generator + A/C | 690—880 {70—90, 160—190} | 500—680 {50—70, 110—150} | 440 {45, 99} |
| P/S | 540—680 {55—70, 130—150} | 400—530 {40—55, 88—120} | 340 {35, 77} |

* A belt that has been on a running engine for less than five minutes.

2. If the tension is not within the specification, adjust it.



Adjustment

Generator+A/C, Generator

1. Loosen idler pulley locknut (A).
2. Adjust the belt deflection by turning adjusting bolt (B).

B2

Deflection

(Generator+A/C)

New: 5.5—6.5 mm {0.22—0.25 in}

Used: 6.5—7.5 mm {0.26—0.29 in}

(Generator)

New: 6.0—7.0 mm {0.24—0.27 in}

Used: 7.0—8.0 mm {0.28—0.31 in}

3. Tighten pulley locknut (A).

Tightening torque:

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

P/S

1. Loosen idler pulley locknut (A).
2. Adjust the belt deflection by turning adjusting bolt (B).

Deflection

New: 6.0—7.0 mm {0.24—0.27 in}


Used: 7.0—8.0 mm {0.28—0.31 in}

3. Tighten pulley locknut (A).

Tightening torque:

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

HLA TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action |
|---|--------------------------------------|--|
| 1. Noise when engine is first started after oil is changed. 2. Noise when engine is started after setting one day or more. | Oil leakage in oil passage or in HLA | Run engine at 2,000—3,000 rpm. If noise stops with 20 minutes*, HLA is normal. If not, replace HLA. * Time required for engine oil to circulate within HLA includes tolerance for engine oil condition and ambient temperature. |
| 3. Noise when engine is started after new HLA is installed. | Oil leakage in HLA | |
| 4. Noise during idle after warm up. | Insufficient oil pressure | Check oil pressure. If lower than specification, check for cause. (Refer to section D2.) |
| | Faulty HLA | Measure valve clearance. If more than 0.15 mm {0.0059 in}, replace HLA.  |
| 5. Noise during idle after high-speed running. | Incorrect oil amount | Check oil level. Drain or add oil as necessary. |
| | Deteriorated oil | Check oil quality. If deteriorated, replace with specified type and amount of oil. |



COMPRESSION



If the engine exhibits low power, poor fuel economy, or poor idle, check the following:

1. Ignition system (Refer to section G.)
2. Compression (Refer to below.)
3. Fuel system (Refer to section F2.)

PREPARATION

SST

| | | | |
|---|--------------------------------------|---|--------------------------------------|
| <p>49 H010 103</p> <p>Compression gauge</p>  | <p>For inspection of compression</p> | <p>49 H010 104</p> <p>Adapter</p>  | <p>For inspection of compression</p> |
|---|--------------------------------------|---|--------------------------------------|



INSPECTION

1. Verify that the battery is fully charged. Recharge it if necessary. (Refer to section G.)
2. Warm up the engine to the normal operating temperature.
3. Stop the engine and allow it to cool for about 10 minutes.
4. Remove the all spark plugs.
5. Disconnect the primary wire connector from the ignition coil.
6. Install the **SST** to No.1 spark plug hole.
7. Fully depress the accelerator pedal and crank the engine.
8. Record the maximum gauge reading.
9. Check each cylinder as above.

Compression

| | kPa {kgf/cm ² , psi}-rpm |
|-----------------------------------|-------------------------------------|
| Standard | 1,402 {14.3, 203}-250 |
| Minimum | 981 {10.0, 142}-250 |
| max. difference between cylinders | 196 {2.0, 28} |
















10. If the compression in one or more cylinders is low, pour a small amount of clean engine oil into the cylinder and recheck the compression.
 - (1) If the compression increases, the piston, piston rings, or cylinder wall may be worn.
 - (2) If the compression stays low, a valve may be stuck or improperly seated.
 - (3) If the compression in adjacent cylinders stays low, the cylinder head gasket may be damaged or the cylinder head distorted.
11. Connect the ignition coil connector.
12. Install the all spark plugs.

Tightening torque:

15—22 N·m {1.5—2.3 kgf·m, 11—16 ft·lbf}

ON-VEHICLE MAINTENANCE

PREPARATION
SST

| | | | |
|--|--|--|--|
| <p>49 S120 710</p> <p>Holder, coupling flange</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 1A1</p> <p>Set, holder</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 101</p> <p>Holder (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 102</p> <p>Bolts (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 E011 1A0</p> <p>Brake set, ring gear</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 F401 330B</p> <p>Installer set, bearing</p>  | <p>For installation of camshaft oil seal</p> | <p>49 F401 337A</p> <p>Attachment C (Part of 49 F401 330B)</p>  | <p>For installation of camshaft oil seal</p> |
| <p>49 G019 017</p> <p>Installer, oil seal</p>  | <p>For installation of rear oil seal</p> | <p>—</p> | <p>—</p> |

B2


TIMING BELT

Removal / Installation


Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

1. Disconnect the negative battery cable.
2. Remove the splash shield and right front wheel.
3. Remove the drive belts.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.




| | |
|---|------------|
| 1. Water pump pulley | |
| 2. Idler pulley bracket | |
| 3. P/S oil pump | |
| Removal Note | below |
| Installation Note | page B2-19 |
| 4. Crankshaft pulley | |
| Removal Note | page B2-12 |
| Installation Note | page B2-18 |
| 5. Dipstick and pipe | |
| Removal Note | page B2-12 |
| Installation Note | page B2-18 |
| 6. Crankshaft position sensor harness bracket | |
| 7. Engine harness bracket | |
| 8. Timing belt cover | |
| Removal Note | page B2-13 |
| Installation Note | page B2-17 |
| 9. Timing belt | |
| Removal Note | page B2-13 |
| Inspection | page B2-83 |
| Installation Note | page B2-15 |
| 10. Timing belt auto tensioner | |
| Inspection | page B2-84 |
| Installation Note | page B2-14 |
| 11. Tensioner pulley | |
| 12. No.2 idler pulley | |
| 13. No.1 idler pulley | |
| 14. Timing belt pulley | |
| Removal Note | page B2-14 |




Removal Note
P/S oil pump


1. Remove the bolts shown and secure the P/S oil reservoir away from the engine.




2. Loosen the pulley nut as shown.
3. Remove the pulley.




4. Remove the bolt shown.



5. Remove the bolts shown and remove the P/S oil pump.




6. Position the P/S oil pump away from the engine and secure it with wire.




Crankshaft pulley

Caution

- The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.




1. Install the **SST** with bolts (M10 × 1.25) to the crankshaft pulley.
2. Remove the crankshaft pulley bolt and the pulley.




Dipstick and pipe

1. Disconnect the crankshaft position sensor connector.
2. Remove the clip from the dipstick pipe.




3. Remove the dipstick and pipe.
4. Plug the hole in the engine after removing the pipe.




Timing belt cover


1. Support the engine by using the SST (engine support).



2. Remove the No.3 engine mount.




3. Remove the right and left timing belt covers.



Timing belt


1. Install the crankshaft pulley bolt into the crankshaft.
2. Turn the crankshaft clockwise so that the No.1 piston is at TDC of the compression stroke.
3. Mark the timing belt rotation on the belt for proper reinstallation.



- Loosen the auto tensioner bolts and remove the lower bolt.

Caution


- When removing the bolt, hold the tensioner so that the bolt holes are aligned, otherwise the threads can be damaged.



- Remove the No.1 idler pulley and remove the timing belt.

Caution


- When removing the pulley bolt, hold the pulley so that the bolt holes are aligned, otherwise the threads can be damaged.
- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.



Timing belt pulley

Note


- If necessary, remove the pulley by using a steering wheel puller.



Inspection

Inspect the following and repair or replace as necessary.

- Timing belt (Refer to page B2-83.)
- Timing belt auto tensioner (Refer to page B2-84.)
- Timing belt pulley (Refer to page B2-84.)
- Camshaft pulleys (Refer to page B2-84.)




Installation Note

Timing belt auto tensioner

- Slowly press in the tensioner rod by using a press or a vise.


Caution

- Do not press the tensioner rod to more than 9,807 N {1,000 kgf, 2,200 lbf}. It will damage the tensioner.



2. Insert a pin into the second hole in the body as shown to hold the tensioner rod.


Pin diameter: 1.6 mm {0.063 in}



3. Set the tensioner in place and snugly tighten the tensioner upper bolt.


Note

- This must be done to reduce the timing belt resistance when the idler pulley is installed.




Timing belt


1. Turn the camshaft pulleys clockwise and align the timing marks of the camshaft pulleys with those of the cylinder heads.



2. Using the crankshaft bolt, turn the crankshaft clockwise and align the timing marks of the timing belt pulley and the oil pump.




3. With the No.1 idler pulley removed, install the timing belt on the pulleys in the order shown below.
 - ① Timing belt pulley
 - ② No.2 idler pulley
 - ③ LH camshaft pulley
 - ④ Tensioner pulley
 - ⑤ RH camshaft pulley
4. Verify that there is tension between pulleys ③ and ①, and between pulleys ① and ⑤.



5. Install the No.1 idler pulley while applying the pressure on the timing belt.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}




6. Push the auto tensioner in the direction of the arrow and tighten the bolts.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



7. Remove the pin from the auto tensioner to apply tension to the belt.




8. Turn the crankshaft clockwise twice, and align the timing marks.
9. Verify that all timing marks are correctly aligned. If necessary, repeat the procedure beginning from installation of the timing belt auto tensioner.



10. Check the timing belt deflection by applying moderate pressure **98 N {10 kgf, 22 lbf}** midway between the timing belt pulley and the tensioner pulley. If not correct, replace the auto tensioner.


Deflection: 6.0—8.0 mm {0.24—0.31 in}

**Timing belt cover**

1. Install the right timing belt cover.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



2. Install the left timing belt cover.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



3. Install the crankshaft position sensor connector bracket on the left timing belt cover.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



4. Install the harness bracket on the right timing belt cover.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




5. Install the No.3 engine mount.


Tightening torque

Ⓐ: 75—104 N·m {7.6—10.7 kgf·m, 55—77.3 ft·lbf}

Ⓑ: 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}



6. Remove the **SST** (engine support).




Dipstick and pipe

1. Apply clean engine oil to a new O-ring and install it on the pipe.
2. Remove the plug from the engine and install the pipe.


Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

3. Install the dipstick.



4. Install the crankshaft position sensor harness and clip to the dipstick pipe.
5. Connect the connector.




Crankshaft pulley

1. Remove the crankshaft pulley bolt.
2. Install the crankshaft pulley and hand tighten the crankshaft pulley bolt.
3. Install the **SST** to the crankshaft pulley.
4. Tighten the crankshaft pulley bolt.

Tightening torque:

157—166 N·m {16.0—17.0 kgf·m, 116—122 ft·lbf}

**P/S oil pump**

1. Install the P/S oil pump.

Tightening torque


- Ⓐ: 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}
- Ⓑ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



2. Install the P/S oil pump pulley and hand tighten the pulley nut.
3. Tighten the pulley nut by using a 12 mm {0.47 in} socket on one of the P/S oil pump mounting bolts.

Tightening torque:


- 63—93 N·m {6.4—9.5 kgf·m, 47—68 ft·lbf}



4. Install the P/S oil reservoir and the engine ground.

Tightening torque:

- 6.9—9.8 N·m {70—100 kgf·cm, 61—86.6 in·lbf}

**Steps After Installation**


1. Install the drive belts. (Refer to page B2-7.)
2. Install the splash shield and the right front wheel.
3. Perform the necessary engine adjustments. (Refer to section F2.)

CYLINDER HEAD GASKET Replacement

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.
- Do not support the engine by using a jack under the oil pan. It will damage the oil pan. Reinstall the engine mount No.3 to support the engine after removing the timing belt.



1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E2.)
3. Remove the timing belt. (Refer to page B2-10.)
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.



1. Fresh-air duct
2. Air cleaner assembly
3. Accelerator cable
Installation Note page B2-33
4. High-tention leads
5. Harness
Removal Note page B2-22
Installation Note page B2-33
6. Intake manifold assembly
Removal Note page B2-22
Installation Note page B2-32
7. Distributor
Installation Note page B2-31
8. Cylinder head cover
Removal Note page B2-24
Installation Note page B2-30
9. Camshaft pulley
Removal Note page B2-24
Installation Note page B2-29
10. Radiator hose, upper
11. No.3 engine mount bracket
Removal Note page B2-24
Installation Note page B2-29
12. Seal plate
13. Water outlet
14. Exhaust pipe
15. Engine hanger
16. Camshaft cap, blind cap, and oil seal
Removal Note page B2-24
Installation Note page B2-28
17. Camshaft
Installation Note page B2-27
18. Cylinder head bolt
Removal Note page B2-25
19. Generator strap
20. Cylinder head
Installation Note page B2-26
21. Cylinder head gasket and O-ring


Removal Note**Harness**


Disconnect the harness connectors shown in the figure.

**Intake manifold assembly****Warning**

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.


1. Plug the disconnected hoses to avoid fuel leakage.
2. Temporarily install the No.3 engine mount bracket to support the engine.






3. Remove the **SST** installed for timing belt removal.


4. Remove the stays, bracket, fuel pipe, and hoses as shown in the figure.
5. Loosen the mounting bolts and nuts in two or three steps.






Cylinder head cover

1. Remove the bolts shown in the figure.
2. Disconnect the ventilation pipe (left cylinder head).
3. Remove the cylinder head cover.




Camshaft pulley

1. Hold the camshaft by using a wrench on the cast hexagon as shown, and loosen the camshaft pulley bolt.
2. Remove the camshaft pulley.



No.3 engine mount bracket

1. Install the **SST** and support the engine.




2. Disconnect the No.3 engine mount bracket from the engine mount rubber.
3. Remove the No.3 engine mount bracket from the engine.

Camshaft cap, blind cap, and oil seal

Perform this same procedure for the right and left cylinder heads.

Caution


- When the camshaft lobe is pressing on the HLA, removing the camshaft caps can damage the cylinder head thrust journal support.



1. Loosen the front camshaft cap bolts in five or six steps in the order shown.
2. Remove the front camshaft cap.

Note

- Bolt ⑤ fits only the right cylinder head.




3. Loosen the camshaft cap bolts gradually in five or six steps in the order shown.

Caution


- Remove the thrust caps only after removing all camshaft caps. Otherwise, the thrust caps can be damaged.

4. Remove the camshaft caps.




Note

- Before removing the camshaft caps, note their locations. They are identified as follows;
Right head: numbers
Left head: letters




Cylinder head bolt


1. Temporarily install the No.3 engine mount bracket to support the engine.



2. Remove the **SST** (engine support).




3. Loosen the cylinder head bolts in two or three steps in the order shown.
4. Remove the cylinder head bolts.




Installation Note Cylinder head

1. Apply clean engine oil to new O-rings and install them to the oil control plugs.




2. Thoroughly remove all dirt, oil, and other material from the decks of the cylinder block.
3. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
4. Place a new cylinder head gasket on the left bank with the **L** mark.
5. Place a new cylinder head gasket on the right bank with the **R** mark.



6. Install the cylinder head to the cylinder block.
7. Tighten the cylinder head bolts as described below.
 - (1) Before installation, measure the length of each bolt. Replace a bolt if it exceeds the maximum length.

Length: 131.2—131.8 mm {5.166—5.188 in}


Maximum: 132.5 mm {5.217 in}




- (2) Apply clean engine oil to the threads and the seat face of each bolt, and install them.
- (3) Tighten the bolts in two or three steps in the order shown.

Tightening torque:


23.1—25.9 N·m {2.35—2.65 kgf·m, 17.0—19.1 ft·lbf}




- (4) Put a paint mark on each bolt head.
- (5) Using the marks as a reference, tighten the bolts by turning each 85° — 95° in the sequence shown.
- (6) Further tighten each bolt by turning another 85° — 95° .



8. Support the engine by using the SST.



9. Disconnect the No.3 engine mount bracket.
10. Remove the No.3 engine mount bracket from the engine.





Camshaft

Caution

- Camshafts must be assembled in the following procedure. Otherwise, camshaft can be broken or damaged because there is little camshaft clearance.

1. Apply clean engine oil to the camshaft journals and the supports
2. Install the camshafts so that the intake camshaft gear mark and exhaust camshaft gear mark align.
3. Remove the oil, dirt from the mating surfaces between the front camshaft cap and the cylinder head, and degrease.






Camshaft cap, blind cap, and oil seal

1. Apply silicone sealant to the shaded areas shown.


Thickness: $\phi 1.5\text{--}2.5\text{ mm}$ {0.06—0.09 in}



Caution

- Install the thrust caps (RH is marked 4, LH is marked A) first. Otherwise, camshaft can be broken or damaged.

2. Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the thrust caps fully seated on the cylinder heads.



3. Install the camshaft caps onto the cylinder heads. Hand tighten the bolts gradually in five or six steps in the order shown, until the camshaft caps fully seated on the cylinder heads.
4. Tighten the bolts in the order shown.



Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}


5. Retighten the bolts in the order shown.

Tightening torque:


11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}



6. Apply clean engine oil to the lip of the new camshaft oil seal.
7. Push the oil seal slightly in by hand.
8. Using the **SST** and a hammer, tap the camshaft oil seal in evenly until it is flush with the edge of the front camshaft cap.



9. Tap in the blind cap by using a plastic hammer.




No.3 engine mount bracket


1. Install the No.3 engine mount bracket to the engine.

Tightening torque:


44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}



2. Temporarily install the No.3 engine mount bracket to the engine mount rubber.




3. Remove the **SST** (engine support).




Camshaft pulley

The right and left pulleys are different and must be installed on the same head that they were removed from.

1. Install the RH camshaft pulley so that the "R" mark can be seen and the groove aligns with the camshaft knock pin.




2. Install the LH camshaft pulley so that the “L” mark can be seen and the groove aligns with the camshaft knock pin.



3. Apply engine oil to the camshaft pulley bolt threads and hand tighten the bolt.
4. Hold the camshaft by using a wrench on the cast hexagon as shown, and tighten the camshaft pulley bolt.


Tightening torque:

123—140 N·m {12.5—14.3 kgf·m, 90.5—103 ft·lbf}




Cylinder head cover

1. Remove all old silicone sealant from the cylinder head and cover.
2. Coat a new cylinder head cover gasket with silicone sealant, and install onto the cylinder head cover.




3. Remove all dirt and other material from the cylinder head, and apply silicone sealant to the shaded areas shown.



4. Install the cylinder head cover and tighten the bolts in five or six steps in the order shown.


Tightening torque:

5.0—8.8 N·m {50—90 kgf·cm, 44—78 in·lbf}




5. Recheck the torque of the bolts indicated, and tighten them if necessary.

RH: ⑤, ⑥
 LH: ⑥, ⑦




6. Install the ventilation pipe to the left cylinder head cover.

Tightening torque:
 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Distributor

1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply clean engine oil to the drive blade.




3. Install the distributor with the blade fit into the camshaft groove.
4. Hand tighten the distributor mounting bolts.



Intake manifold assembly

1. Install a new gasket and the intake manifold. Hand tighten the bolts and nuts.



2. Connect the stays, bracket, fuel pipe, and hoses as shown in the figure.
3. Tighten the intake manifold bolts and nuts in two or three steps.



N-m {kgf-m, ft-lbf}

Harness

Connect the harness connectors shown in the figure.

**Accelerator cable**

1. Verify that the throttle valve is fully closed.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.5 mm {0.06—0.17 in}

3. If not as specified, turn stopper (B) while pressing lock button (A) to release the lock.
4. Push the spring in direction (C) and adjust the cable free play.
5. Lock stopper (A) after locking stopper (B).

Steps After Installation

1. Install the timing belt. (Refer to page B2-10.)
2. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E2.)
3. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F2.)
 - (3) check the operation of the emission control system.
4. Recheck the engine coolant and engine oil levels.


HLA

Removal / Installation

Caution

- Removal and installation of the HLA must be carried out only when the problem cannot be solved by the HLA troubleshooting. (Refer to page B2-7.)


- Disconnect the negative battery cable.
- Remove the timing belt. (Refer to page B2-10.)
- Remove in the order shown in the figure, referring to **Removal Note**.
- Install in the reverse order of removal, referring to **Installation Note**.



| | | | |
|---|------------|--|------------|
| 1. Accelerator cable Installation Note | page B2-33 | 7. Camshaft pulley Removal Note | page B2-24 |
| 2. High-tension lead | | Installation Note | page B2-29 |
| 3. Harness Removal Note | below | 8. Camshaft cap, blind cap, and oil seal Removal Note | page B2-24 |
| 4. Intake manifold assembly Removal Note | page B2-22 | Installation Note | page B2-28 |
| Installation Note | page B2-32 | 9. Camshaft Installation Note | page B2-27 |
| 5. Cylinder head cover Installation Note | page B2-30 | 10. HLA Removal Note | page B2-36 |
| 6. Distributor Installation Note | page B2-31 | Installation Note | page B2-36 |

Removal note
Harness

Disconnect the harness connectors shown in the figure.




HLA

Caution

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.

Note

- Mark the HLA to show their original positions.
1. Remove the HLA from the cylinder head.
 2. Store the HLA upside down in an oil-filled container.

**Installation Note****HLA**

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the positions from which they were removed.
3. Verify that the HLA move smoothly in their bores.


Steps After Installation

1. Install the timing belt. (Refer to page B2-10.)
2. Fill the engine with the specified amount and type of engine oil. (Refer to section D2.)
3. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant. (Refer to section E2.)
4. Connect the negative battery cable.
5. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F2.)
 - (3) check the operation of the emission control system. (Refer to section F2.)
6. Recheck the engine coolant and oil levels.

FRONT OIL SEAL


Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|--|------------|
| 1. Timing belt Removal / Installation | page B2-10 |
| 2. Timing belt pulley Removal Note | page B2-38 |
| Installation Note | page B2-38 |

- | | |
|---------------------------------------|------------|
| 3. Oil seal Removal Note | page B2-38 |
| Installation Note | page B2-38 |




Removal Note

Timing belt pulley

Note


- If necessary, remove the pulley by using a steering wheel puller.

1. Remove the timing belt pulley.
2. Remove the timing belt pulley key.



Oil seal

1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.




Installation Note

Oil seal

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Using a pipe and a hammer, tap the oil seal in evenly until it is flush with the edge of the oil pump body.

Note

- Oil seal outer diameter: 54.5 mm {2.15 in}
- Oil seal inner diameter: 43.0 mm {1.69 in}



Timing belt pulley

1. Install the timing belt pulley.
2. Install the timing belt pulley key with the tapered side toward the oil pump body.


Steps After Installation

1. Connect the negative battery cable.
2. Start the engine and check follows:
 - Ignition timing. (Refer to section F2.)

REAR OIL SEAL


Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




1. Transaxle
 MTX
 Removal / Installation section J
 ATX
 Removal / Installation section K1
2. Clutch cover, clutch disc (MTX)
 Removal / Installation section H
3. Flywheel (MTX)
 Removal Note page B2-40
 Installation Note page B2-40

4. Drive plate, backing plate, adaptor (ATX)
 Removal Note page B2-40
 Installation Note page B2-41
5. Oil seal
 Removal Note page B2-40
 Installation Note page B2-40




**Removal Note
Flywheel (MTX)**

1. Hold the flywheel by using the **SST**.
2. Remove the flywheel mounting bolts in two or three steps in the order shown in the figure.
3. Remove the flywheel.




Drive plate, backing plate, adapter (ATX)

1. Hold the drive plate by using the **SST**.
2. Remove the drive plate mounting bolts. (Refer to above.)
3. Remove the backing plate, drive plate, and adapter.



Oil seal


1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.



Installation Note

Oil seal

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand
3. Using the **SST** and a hammer, tap the oil seal in evenly until it is flush with the edge of the rear cover.




Flywheel (MTX)


1. Set the flywheel onto the crankshaft.
2. Hand tighten the mounting bolts.
3. Hold the flywheel by using the **SST**.
4. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}

**Drive plate (ATX)**

1. Install the following parts to the crankshaft.
 - (1) Adapter
 - (2) Drive plate
 - (3) Backing plate
2. Hand tighten the mounting bolts.



3. Hold the drive plate by using the **SST**.
4. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}

Steps after installation

1. Connect the negative battery cable.
2. Start the engine and perform engine adjustments as necessary.
3. Check the oil level.

REMOVAL


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.


PROCEDURE

1. Disconnect the negative battery cable.
2. Drain the engine coolant and transaxle oil. (Refer to section E2 and sections J, K1.)
3. Remove the hood and front wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.

Step 1




- | | |
|-----------------------------------|--|
| 1. Splash shield | 12. Radiator and cooling fan assembly |
| 2. Fresh-air duct | 13. Drive belts |
| 3. Air cleaner assembly | Removal Note page B2- 5 |
| 4. Battery and carrier | 14. P/S oil pump |
| 5. Accelerator cable | Removal Note page B2-43 |
| 6. Radiator hoses | 15. A/C compressor (if equipped) |
| 7. Oil cooler hose (ATX) | Removal Note page B2-44 |
| 8. Coolant reservoir hose | 16. Cruise actuator |
| 9. Cooling fan motor connector | Removal / Installation section T |
| 10. Condenser fan motor connector | 17. Control cable (ATX) |
| 11. Radiator bracket | |




Removal Note
P/S oil pump


1. Remove the bolts shown in the figure and secure the P/S oil reservoir away from the engine.




2. Loosen the pulley nut as shown.
3. Remove the pulley.




4. Remove the bolt shown in the figure.



5. Remove the bolts shown in the figure and remove the P/S oil pump.




6. Position the P/S oil pump away from the engine and secure it with wire.

**A/C compressor (if equipped)**

1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and secure it with wire.



Step 2

Disconnect the harness connectors shown in the figure.



Step 3

Disconnect the hoses shown in the figure.




Removal note
Fuel hose

Warning


- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Plug the disconnected hoses to avoid fuel leakage.

**Heater hose**


Press the heater hose retainer tabs and remove the heater hoses.

Step 4



- 1. Clutch release cylinder (MTX)
Removal Note below
- 2. Transverse member
- 3. Front exhaust pipe
- 4. Shift control rod (MTX)
- 5. Extension bar (MTX)
- 6. Stabilizer control link

- 7. Tie-rod end ball joint
Removal Note page B2-47
- 8. Drive shaft
Removal Note page B2-47
- 9. Joint shaft
Removal Note page B2-47




Removal Note Clutch release cylinder (MTX)

- 1. Remove the bolts and clips as shown.


Caution

- **Bending the pipe can cause kinks or cracks.**

- 2. Remove the release cylinder and position it away from the transaxle with the hose still connected.

**Tie-rod end ball joint**

1. Remove the cotter pin and loosen the nut so that it is flush with the end of the ball joint stud.
2. Separate the knuckle arm and ball joint by using the SST.


**Drive shaft**

1. Remove the bolts and nuts at the left and right lower arm ball joints.


Caution

- The ball joint dust boots and oil seals are damaged easily if this procedure is not done correctly.


2. Pry the lower arms downward to separate them from the knuckles.



3. Separate the drive shafts from the transaxle by prying with a bar inserted between the shaft and the case (Left side).




4. As shown in the figure, insert a pry bar between the drive shaft and the joint shaft and tap on the bar to uncouple them. (Right side)

**Joint shaft**

1. Remove the joint shaft mounting bolts.
2. Remove the joint shaft.

Step 5




- 1. Fuse box
- 2. No.1 engine mount stay bracket
- 3. No.3 engine mount rubber
- 4. No.1 engine mount bolts
- 5. No.4 engine mount rubber and bracket

- 6. Engine mount member
Removal Note below
- 7. Engine and transaxle assembly
Removal Note page B2-49


Removal Note Engine mount member

Caution

- Removing the member without first suspending the engine can cause the engine to tilt or fall and cause injury. Suspend the engine properly before removing the member.




- 1. Suspend the engine by using a chain block.
- 2. Remove the No.2 engine mount nuts.
- 3. Remove the No.5 engine mount rubber bolts and engine mount member bolts and nuts and remove the No.5 engine mount rubber and engine mount member.

**Engine and transaxle assembly**


Slowly lift the engine and transaxle assembly as a unit. Keep the engine from swinging or bumping into components in the engine compartment.

Step 6

(MTX)



(ATX)



















1. Starter
2. No.2 engine mount rubber
3. No.2 engine mount bracket

4. Torque converter mounting nuts (ATX)
5. Transaxle

ENGINE STAND MOUNTING

PREPARATION
SST


| | | | |
|---|---|---|---|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 1A0 Hanger set, engine</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 101 Plate (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 102 Arms (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 103 Hooks (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 104 Nuts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 L010 105 Bolts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 L010 106 Bolts (Part of 49 L010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 E010 1A0 Hanger set, engine</p>  | <p>For disassembly / assembly of engine</p> | <p>49 E010 101 Body (Part of 49 E010 1A0)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 E010 102 Bolt (Part of 49 E010 1A0)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 E010 1A1 Hanger set, engine</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 E010 103 Hanger (Part of 49 E010 1A1)</p>  | <p>For disassembly / assembly of engine</p> | <p>49 E010 102 Bolt (Part of 49 E010 1A1)</p>  | <p>For disassembly / assembly of engine</p> |
| <p>49 E010 104 Bolt (Part of 49 E010 1A1)</p>  | <p>For disassembly / assembly of engine</p> | <p>—</p> | <p>—</p> |




PROCEDURE

When using SST (49 E010 1A0)


1. Remove the right exhaust manifold insulator.
2. Remove the EGR valve bolts.




3. Remove the right exhaust manifold and gasket together with the EGR valve and pipe.



4. Install the **SST** at the positions as shown.




5. Mount the engine on the **SST**.
6. Drain the coolant. (Refer to page B2-53.)




When using SST

(49 E010 1A1 and 49 L010 1A0)


1. Remove the right exhaust manifold insulator.
2. Remove the EGR valve bolts.
3. Remove the right exhaust manifold and gasket together with the EGR valve and pipe.
4. Install the **SST** as shown.




5. Install the **SST** (arms) to the holes as shown, and hand tighten the **SST** (bolts).




6. Assemble the **SST** (bolts, nuts and plate) as shown.



7. Install the **SST** assembled in step 6 to the **SST** installed in step 5.
8. Adjust the **SST** (bolts) so that less than **20 mm {0.79 in}** of thread is exposed.
9. Make the **SST** (plate and arms) parallel by adjusting the **SST** (bolts and nuts).
10. Tighten the **SST** (bolts and nuts) to affix the **SST** firmly.




11. Mount the engine on the **SST**.
12. Drain the coolant. (Refer to below.)



Coolant Draining

1. After installing the engine to the engine stand, disconnect the oil cooler hoses as shown to drain the coolant.





















2. Remove the blind cover and drain the engine coolant (cylinder block, right side).
3. After draining the coolant, install a new gasket and reinstall the blind cover.

Tightening torque:**19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}**

DISASSEMBLY

PREPARATION
SST

| | | | |
|--|---|--|---|
| 49 0636 100B Arm, valve spring lifter  | For removal / installation of valves | 49 L011 0A0B Tool set, piston pin setting  | For removal / installation of piston pins |
| 49 L011 001 Body, support block (Part of 49 L011 0A0B)  | For removal / installation of piston pins | 49 L011 006 Installer, piston pin (Part of 49 L011 0A0B)  | For removal / installation of piston pins |
| 49 E011 002 Screw  | For removal / installation of piston pins | 49 D011 002B Head, support block (Part of 49 L011 0A0B)  | For removal / installation of piston pins |
| 49 E011 001 Guide  | For removal / installation of piston pins | 49 G014 001 Wrench, oil filter  | For removal / installation of oil filter |
| 49 H018 001 Wrench, knock sensor  | For removal of knock sensor | 49 S120 170 Remover, valve seal  | For removal of valve seals |
| 49 E011 1A0 Brake, ring gear  | For prevention of crankshaft rotation | 49 E011 103 Shaft (Part of 49 E011 1A0)  | For prevention of crankshaft rotation |
| 49 E011 104 Collar (Part of 49 E011 1A0)  | For prevention of crankshaft rotation | 49 E011 105 Stopper (Part of 49 E011 1A0)  | For prevention of crankshaft rotation |
| 49 B012 0A2 Pivot  | For removal / installation of valves | 49 B012 012 Body (Part of 49 B012 0A2)  | For removal / installation of valves |

| | | | | | |
|---|---|---|--|--|---|
| 49 B012 013 Foot (Part of 49 B012 0A2) |  | For removal / installation of valves | 49 B012 014 Locknut (Part of 49 B012 0A2) |  | For removal / installation of valves |
|---|---|---|--|--|---|


1. Code or arrange all identical parts (such as HLA, pistons, piston rings, connecting rods, and valve springs) so that they can be reinstalled in the cylinder from which they were removed.
2. Clean the parts by using a steam cleaner. Blow dry with compressed air.

Warning

- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**

AUXILIARY PARTS


1. Drain the engine oil.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



1. A/C compressor bracket (if equipped)
2. Generator
3. Bracket and tensioner
4. Exhaust manifold insulator (LH)
5. Exhaust manifold (LH)
6. Distributor and high-tension lead

7. Intake manifold assembly
8. Engine hanger
9. Spark plug
10. Oil filter

Disassembly Note page B2-58




Disassembly Note

Oil filter

Remove the oil filter by using the SST.


TIMING BELT

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




1. Crankshaft pulley
Disassembly Note page B2-60
2. Water pump pulley
3. Dipstick and pipe
4. Crankshaft position sensor
5. Timing belt cover (LH)
6. Timing belt cover (RH)
7. No.3 engine mount bracket
8. Timing belt
Disassembly Note page B2-60

9. Timing belt auto tensioner
Disassembly Note page B2-60
10. Tensioner pulley
11. No.2 idler pulley
12. No.1 idler pulley
13. Timing belt pulley
Disassembly Note page B2-61



Disassembly Note Crankshaft pulley


1. Hold the flywheel (MTX) or drive plate (ATX) by using the SST.



Caution


- The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.

2. Remove the pulley bolt.
3. Remove the crankshaft pulley.




Timing belt

1. Temporarily install the crankshaft pulley bolt.
2. Turn the crankshaft clockwise to align the timing marks of the pulleys.




3. Mark the timing belt rotation direction for proper reinstallation.



Caution

- When removing the bolt, hold the tensioner so that the bolt holes are aligned, otherwise the threads can be damaged.

4. Remove the auto tensioner bolts in the order shown.
5. Remove the timing belt.

**Timing belt pulley**


1. Remove the timing belt pulley.
2. Remove the timing belt pulley key.

Note


- If necessary, remove the pulley by using a steering wheel puller.

CYLINDER HEAD

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | |
|-----------------------------------|-----------------------------------|
| 1. Cylinder head cover | 10. Cylinder head bolt |
| 2. Camshaft pulley | Disassembly Note page B2-64 |
| Disassembly Note page B2-63 | 11. Cylinder head |
| Inspection page B2-84 | Inspection page B2-72 |
| 3. Seal plate | 12. Cylinder head gasket |
| 4. Water outlet | 13. Valve keeper |
| 5. Camshaft cap | Disassembly Note page B2-64 |
| Disassembly Note page B2-63 | 14. Valve spring seat, upper |
| 6. Blind cap | 15. Valve spring |
| 7. Camshaft | Inspection page B2-76 |
| Inspection page B2-64 | 16. Valve spring seat, lower |
| 8. Camshaft oil seal | 17. Valve |
| 9. HLA | Inspection page B2-73 |
| Disassembly Note page B2-64 | 18. Valve seal |
| Inspection page B2-79 | Disassembly Note page B2-64 |




Disassembly Note Camshaft pulley

1. Hold the camshaft by using a wrench on the cast hexagon of the camshaft as shown.
2. Remove the camshaft pulley bolt.
3. Remove the camshaft pulley.


Camshaft cap

Caution

- When the camshaft lobe is pressing on the HLA, removing the camshaft caps can damage the cylinder head thrust journal support.



1. Loosen the front camshaft cap bolts in five or six steps in the order shown.
2. Remove the front camshaft caps.





3. Loosen the remaining camshaft cap bolts in five or six steps in the order shown.

Caution

- Remove the thrust caps only after removing all camshaft caps. Otherwise, the thrust caps can be damaged.

4. Remove the camshaft caps.
5. Remove the distributor cap. (LH)





Camshaft

Inspect the following when removing the camshaft.

- (1) Camshaft end play (Refer to page B2-79.)
- (2) Camshaft journal oil clearance (Refer to page B2-79.)

HLA

Caution

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.



Note

- Mark the HLA to show their original positions.

1. Remove the HLA from the cylinder head.
2. Store the HLA upside down in an oil-filled container.


Cylinder head bolt

1. Loosen the cylinder head bolts in two or three steps in the order shown.
2. Remove the cylinder head bolts.



Valve keeper

1. Set the SST against the upper valve spring seat as shown.
2. Compress the spring and remove the valve keepers.




Valve seal


Using the SST, remove and discard the valve seal.

CYLINDER BLOCK (EXTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | |
|---|---|
| 1. Clutch cover, clutch disc (MTX) Disassembly Note page B2-66 | 7. Oil pan Disassembly Note page B2-67 |
| 2. Flywheel (MTX) Disassembly Note page B2-66 | 8. Oil strainer |
| 3. Backing plate, drive plate, and adapter (ATX) Disassembly Note page B2-66 | 9. Oil baffle |
| 4. Oil cooler | 10. Water pump |
| 5. Water pipe and thermostat housing Disassembly Note page B2-66 | 11. Oil pump |
| 6. Knock sensor Disassembly Note page B2-67 | 12. Front oil seal Disassembly Note page B2-67 |



Disassembly Note


Clutch cover, clutch disc (MTX)

1. Hold the flywheel by using the **SST**.
2. Remove the clutch cover bolts in two or three steps.
3. Remove the clutch cover.
4. Remove the clutch disc.




Flywheel (MTX)

1. Hold the flywheel by using the **SST**.
2. Remove the flywheel bolts in two or three steps in the order shown.
3. Remove the flywheel.
4. Remove the **SST**.




Backing plate, drive plate, and adapter (ATX)

1. Hold the drive plate by using the **SST**.
2. Remove the drive plate bolts in two or three steps. (Refer to above.)
3. Remove the backing plate, drive plate, and adapter.
4. Remove the **SST**.




Water pipe and thermostat housing


1. Disconnect the clip and separate the knock sensor harness from the water pipe.




2. Remove the water pipe and thermostat housing as an assembly.

**Knock sensor**

Remove the knock sensor by using the SST.

**Oil pan**


1. Remove the oil pan mounting bolts.
2. Separate the oil pan from the lower cylinder block by using a scraper or a separator tool.

**Front oil seal**


Remove the oil seal by using a screwdriver protected with a rag.

CYLINDER BLOCK (INTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | |
|---|--|
| 1. Connecting rod cap Disassembly Note page B2-69 | 6. Piston Inspection page B2-80 |
| 2. Connecting rod bearing Inspection page B2-83 | 7. Lower cylinder block Disassembly Note page B2-70 |
| 3. Piston ring Disassembly Note page B2-69 Inspection page B2-81 | 8. Main bearing and thrust bearing, lower |
| 4. Piston pin Disassembly Note page B2-69 Inspection page B2-81 | 9. Crankshaft Inspection page B2-82 |
| 5. Connecting rod Disassembly Note page B2-69 Inspection page B2-82 | 10. Rear oil seal |
| | 11. Main bearing and thrust bearing, upper |
| | 12. Oil jet Inspection page B2-83 |
| | 13. Cylinder block Inspection page B2-80 |




Disassembly Note
Connecting rod cap

Before removing the connecting rod caps, measure the connecting rod side clearance. (Refer to page B2-94.)




Connecting rod

1. Before removing the connecting rods, measure the connecting rod bearing oil clearance by using Plastigage. (Refer to page B2-93.)




2. Remove the Plastigage from the journals and bearings.
3. Use the handle of a hammer to push the piston and connecting rod assembly through the top of the cylinder block.



Piston ring

Remove the piston rings by using a piston ring expander.




Piston pin


Caution

- The connecting rods must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.


1. Before disassembling the piston and connecting rod, check the oscillation torque as shown. If the large end does not drop by its own weight, replace the piston or the piston pin.




2. Use the **SSTs** shown in the figure and a press.



3. Assemble the **SST** into the piston pin as shown.




4. Verify that the **SST** fits squarely into the piston before pressing.



5. Set the piston and connecting rod on the **SST** as shown.


6. Press out the piston pin.

While removing the piston pin, note the pressing pressure. If it is less than **4,903 N {500 kgf, 1,100 lbf}**, replace the piston pin or the connecting rod.




Lower cylinder block

1. Before removing the lower cylinder block, measure the crankshaft end play. (Refer to page B2-92.)








2. Loosen the lower cylinder block bolts in two or three steps in the order shown.




3. Insert a screwdriver only at the points as shown.
4. Remove the lower cylinder block.

INSPECTION / REPAIR

PREPARATION SST

| | | | |
|--|--|--|--|
| <p>49 B012 005</p> <p>Remover & installer, valve guide</p>  | <p>For removal / installation of valve guide</p> | <p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p>  | <p>For installation of valve guide</p> |
| <p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> | <p>49 L012 003</p> <p>Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> |
| <p>49 L012 004</p> <p>Nut (Part of 49 L012 0A0)</p>  | <p>For installation of valve guide</p> | <p>—</p> | <p>—</p> |

1. Clean all parts, being sure to remove all gasket fragments, dirt, oil, etc.
2. Perform the inspections and repairs in the order specified.




CYLINDER HEAD

1. Inspect the cylinder head for damage, cracks, and leakage of water and oil. Replace if necessary.
2. Using a straightedge, measure the cylinder head for distortion in the six directions as shown.

Distortion: 0.10 mm {0.004 in} max.

3. Inspect for the following and repair or replace.
 - (1) Sunken valve seats
 - (2) Damaged intake and exhaust manifold contact surfaces
 - (3) Excessive camshaft oil clearances and end play




- If the distortion exceeds the specification, grind the cylinder head.

Grinding: 0.15 mm {0.006 in} max.

- If the cylinder head height is not within the specification, replace it.

Height: 133.4—133.6 mm {5.252—5.259 in}



- Using a straightedge, measure the intake and exhaust manifold contact surfaces for distortion in the six directions as shown.

Distortion: 0.10 mm {0.004 in} max.

- If distortion exceeds the specification, grind the surface or replace the cylinder head.

Grinding: 0.15 mm {0.006 in} max.

VALVE MECHANISM

Valve and Valve Guide

- Inspect each valve for the following. Replace or resurface as necessary.


- Damaged or bent stem
- Rough or damaged face
- Damaged or unevenly worn stem tip

- Measure the valve head margin thickness. Replace the valve if necessary.

Margin thickness

IN: 0.9 mm {0.0354 in} min.


EX: 1.0 mm {0.0394 in} min.



- Measure the valve length and replace the valve if necessary.

Length

| | | mm {in} |
|----------|----|---------------|
| Standard | IN | 93.91 {3.697} |
| | EX | 94.99 {3.740} |
| Minimum | IN | 93.41 {3.678} |
| | EX | 94.49 {3.720} |



- Measure the valve stem diameter and replace the valve if necessary.

Diameter


Standard

IN: 5.970—5.985 mm {0.2351—0.2356 in}

EX: 5.965—5.980 mm {0.2349—0.2354 in}

Minimum IN: 5.920 mm {0.2331 in}

EX: 5.915 mm {0.2329 in}




- Measure the valve guide inner diameter and replace the guide if necessary.

Inner diameter

IN: 6.01—6.03 mm {0.2367—0.2374 in}

EX: 6.01—6.03 mm {0.2367—0.2374 in}



- Calculate the valve stem-to-guide clearance. Subtract the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.


Clearance

IN: 0.025—0.060 mm {0.0010—0.0023 in}

EX: 0.030—0.065 mm {0.0012—0.0025 in}

Maximum: 0.20 mm {0.0078 in}

- If the clearance exceeds the maximum, replace the valve and/or valve guide.




- Measure the valve guide projection height (dimension A). Replace the guide if necessary.

Dimension A

IN: 14.7—15.3 mm {0.579—0.602 in}


EX: 12.2—12.8 mm {0.481—0.503 in}




Replacement of valve guide

Note

- The intake and exhaust valve guides are the same.



- Remove the valve guide from the combustion chamber side by using the **SST** and a hammer.




- Assemble the **SST** so that the depth L is as specified.

Depth L


IN: 14.7—15.3 mm {0.579—0.602 in}

EX: 12.2—12.8 mm {0.481—0.503 in}

- Tighten the locknut.




4. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
5. Verify that the valve guide projection height is within the specification. (Refer to page B2-74.)
6. If not within the specification, repeat steps 2-4.




Valve Seat

1. Inspect the contact surface of the valve seat and valve face for the following.
 - (1) Roughness
 - (2) Damage
2. If necessary, resurface the valve seat by using a 45° valve seat cutter and/or resurface the valve face.




3. Apply a thin coat of Prussian blue to the valve face.
4. Check the valve seating by pressing the valve against the seat.
 - (1) If blue does not appear 360° around the valve face, replace the valve.
 - (2) If blue does not appear 360° around the valve seat, resurface the seat.




5. Measure the seat contact width.

Width: 0.8—1.4 mm {0.032—0.055 in}



- (1) If the valve seating position on the valve face is too high, correct the valve seat by using a 75° cutter.
- (2) If the valve seating position of the valve face is too low, correct the valve seat by using a 45° cutter.
6. Seat the valve to the valve seat by using a lapping compound.




7. Check the sinking of the valve seat.
Measure the protruding length (dimension L) of the valve stem.

Dimension L: 41.5 mm {1.634 in}

- (1) If L is as below, it can be used as it is.

41.5—42.0 mm {1.634—1.653 in}




- (2) If L is as below, insert a washer onto the spring seat area so that L will be as specified.

42.1—43.0 mm {1.658—1.692 in}

- (3) If L is more than below, replace the cylinder head.

43.1 mm {1.697 in}



Valve Spring


1. Inspect the valve springs for cracks and damage.
2. Measure the free length of each spring.

Free length

Standard: 46.92 mm {1.847 in}


Minimum:

**38.7 mm {1.524 in} with a set load of
233.0—263.6 N
{23.75—26.88 kgf, 52.25—59.13 lbf}**



3. If not within the specification, measure spring pressure when the spring length is compressed to **35.5 mm {1.398 in}**. Replace if necessary.
4. Measure the out-of-square of the springs. Replace if necessary.

Out-of-square: 1.63 mm {0.0642 in} max.




CAMSHAFT

1. Visually inspect the helical gear and the friction gear.
Replace the camshaft assembly if a problem is found with the helical gear. Replace the friction gear if a problem is found with it.
2. Secure the camshaft cast hexagon in a vise protected with aluminum plates.
3. Loosen the locknut and remove the friction gear.
4. Assemble the friction gear so that the matching marks align.


Tightening torque:

69—78 N·m {7.0—8.0 kgf·m, 51—57 ft·lbf}



5. Set the front and rear journals on V-blocks. Measure the camshaft runout. Replace the camshaft if necessary.

Runout: 0.02 mm {0.0008 in} max.




6. Check the camshaft for wear and damage. Replace it if necessary.
7. Measure the camshaft lobe height at the two points as shown. Replace the camshaft if necessary.

Height

mm {in}

| | | |
|----|----------|-----------------|
| IN | Standard | 43.549 {1.7145} |
| | Minimum | 43.349 {1.7067} |
| EX | Standard | 43.549 {1.7145} |
| | Minimum | 43.349 {1.7067} |




8. Measure the journal diameters in X and Y directions at the two points (A and B) as shown. Replace the camshaft if necessary.

Journal diameter


mm {in}

| Journals | Standard | Minimum |
|------------------------------|----------------------------------|-----------------|
| No.1 (RH EX, LH IN) and No.5 | 25.940—25.960 {1.0213—1.0220} | 25.890 {1.0193} |
| No.1 (RH IN, LH EX) | 29.975—29.995 {1.1802—1.1809} | 29.925 {1.1781} |
| No.2—No.4 | 25.910—25.930 {1.0201—1.0208} | 25.860 {1.0181} |




9. Measure the camshaft oil clearances with the HLA removed.

- (1) Remove all oil, dirt, etc. from the journals and the camshaft saddles.
- (2) Set the camshafts on the cylinder head.




- (3) Position Plastigage atop each journal in the journal axial direction.



Caution

- Install the thrust caps (RH is marked 4, LH is marked A) first. Otherwise, camshaft can be broken or damaged.

- (4) Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the thrust caps fully seated on the cylinder heads.



- (5) Install the camshaft caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the camshaft caps fully seated on the cylinder heads.

- (6) Tighten the bolts in the order shown.


Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}

- (7) Retighten the bolts in the order shown.

Tightening torque:


11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}




- (8) Loosen the camshaft cap bolts in five or six steps in the order shown.


Caution

- Remove the thrust caps only after removing all camshaft caps. Otherwise, the thrust caps can be damaged.



- (9) Remove the camshaft caps.





(10) Measure the oil clearance.

Oil clearance

No.1, No.5: 0.040—0.081 mm {0.0016—0.0031 in}


No.2—No.4: 0.070—0.111 mm {0.0028—0.0043 in}

Maximum

No.1, No.5: 0.120 mm {0.0047 in}

No.2—No.4: 0.150 mm {0.0059 in}


(11) If the oil clearance exceeds the maximum, replace the camshaft or the cylinder head.



10. Measure the camshaft end play. If it exceeds the maximum, replace the camshaft or the cylinder head.

End play: 0.05—0.10 mm {0.0020—0.0039 in}


Maximum: 0.14 mm {0.0056 in}



HLA

1. Measure the HLA bore in X and Y directions at two points (A and B) as shown.

Diameter: 30.000—30.025 mm {1.1811—1.1820 in}



2. Measure the HLA diameter in X and Y directions at two points (A and B) as shown.

Diameter: 29.959—29.975 mm {1.1795—1.1801 in}


3. Calculate the clearance between the HLA diameter and the related HLA bore.

Clearance:

0.025—0.066 mm {0.00099—0.00259 in}

Maximum: 0.180 mm {0.0071 in}


4. If the clearance exceeds the maximum, replace the HLA and/or the cylinder head.



CYLINDER BLOCK

1. Check the cylinder block for the following and repair or replace as necessary.
 - (1) Leakage damage
 - (2) Cracks
 - (3) Scoring of wall
2. Using a straightedge, measure the cylinder block decks for distortion in six directions as shown.

Distortion: 0.15 mm {0.006 in} max.




3. If distortion exceeds the maximum, replace the cylinder block.
4. Measure the cylinder bores in X and Y directions at three points (A, B and C) as shown.

Cylinder bore

mm {in}

| | |
|----------------------|-------------------------------|
| Standard | 84.500—84.522 {3.3268—3.3276} |
| 0.25 {0.01} oversize | 84.750—84.772 {3.3367—3.3374} |
| 0.50 {0.02} oversize | 85.000—85.022 {3.3465—3.3473} |



Cylinder bore


Base the boring diameter on the diameter of an oversize piston. All cylinders must be the same diameter.

- (1) If the cylinder bore exceeds the maximum, rebore the cylinder to oversize.
- (2) If the difference between measurements A and C exceeds the maximum taper, rebore the cylinder to oversize.

Taper: 0.022 mm {0.0009 in} max.

- (3) If the difference between measurements X and Y exceeds the maximum out-of-round, rebore the cylinder to oversize.

Out-of-round: 0.020 mm {0.0008 in} max.



5. If the upper part of a cylinder wall shows uneven wear, remove the ridge by using a ridge reamer.

PISTON, PISTON RING, AND PISTON PIN


Piston


1. Inspect the outer circumferences of all pistons for seizing and scoring. Replace as necessary.
2. Measure the outer diameter of each piston at a right angle (90°) to the piston pin, 16.5 mm {0.65 in} below the oil ring groove lower edge.

Piston diameter

mm {in}

| | |
|----------------------|-------------------------------|
| Standard | 84.437—84.461 {3.3243—3.3252} |
| 0.25 {0.01} oversize | 84.687—84.711 {3.3342—3.3350} |
| 0.50 {0.02} oversize | 84.937—84.961 {3.3440—3.3449} |






3. Measure the piston-to-cylinder clearance.

Clearance: 0.028—0.056 mm {0.0012—0.0022 in}
Maximum: 0.13 mm {0.0051 in}

4. If the clearance exceeds the maximum, replace the piston or rebore the cylinders to fit oversize pistons. If the piston is replaced, the piston rings must also be replaced.




Piston and Piston Rings


1. Measure the piston ring-to-ring land clearance around the entire circumference by using a new piston ring.

Clearance

Top: 0.020—0.065 mm {0.0008—0.0025 in}
Second: 0.030—0.065 mm {0.0012—0.0025 in}
Oil: 0.025—0.052 mm {0.0010—0.0020 in}
Maximum: 0.15 mm {0.006 in}




2. If the clearance exceeds the maximum, replace the piston.
3. Inspect the piston rings for damage, abnormal wear, and breakage. Replace as necessary.
4. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.



5. Measure each piston ring end gap by using a feeler gauge. Replace if necessary.

End gap


Top: 0.15—0.30 mm {0.0060—0.0118 in}
Second: 0.25—0.40 mm {0.010—0.015 in}
Oil rail: 0.20—0.70 mm {0.008—0.027 in}
Maximum: 1.0 mm {0.0394 in}



Piston and Piston pin

1. Measure the piston pin bore diameter in X and Y directions at four points.

Diameter: 19.988—20.000 mm {0.7870—0.7874 in}



2. Measure the piston pin diameter in X and Y directions at four points as shown.


Diameter: 19.974—19.980 mm {0.7864—0.7866 in}

3. Calculate the related piston pin-to-piston clearance.

Clearance: 0.008—0.026 mm {0.0004—0.0010 in}

4. If the clearance exceeds the specification, replace the piston and/or piston pin.

CONNECTING ROD




1. Measure the connecting rod small end bore.

Diameter: 19.943—19.961 mm {0.7852—0.7858 in}

2. Calculate the interference between the small end bore and piston pin.

Interference: 0.013—0.037 mm {0.0006—0.0014 in}

If the connecting rod is replaced, the connecting rod cap and bolts must also be replaced because they are a matched set.




3. Check each connecting rod for bending. Replace the connecting rod if necessary.

Bend: 0.05 mm {0.002 in}/50 mm {1.9685 in}

Length (center to center):


137.80—137.90 mm {5.4252—5.4291 in}



CRANKSHAFT

1. Check the journals and pins for damage, scoring, and oil hole clogging.
2. Set the crankshaft No.1 and No.4 main journals on V-blocks.
3. Measure the crankshaft runout at the No.2 and No.3 main journals. Replace the crankshaft if necessary.

Runout: 0.015 mm {0.0005 in} max.



4. Measure each journal diameter in X and Y directions at two points as shown.

Main journal

Diameter:

61.938—61.955 mm {2.4385—2.4391 in}


Out-of-round: 0.05 mm {0.002 in} max.

Crankpin journal

Diameter:

52.940—52.955 mm {2.0843—2.0848 in}

Out-of-round: 0.05 mm {0.002 in} max.



5. If the diameter is less than the minimum, grind the journals to match undersize bearings.

Undersize bearing: 0.25 mm {0.01 in}

Main journal diameter undersize


mm {in}

| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 61.688—61.705 {2.4287—2.4293} |

Crank pin journal diameter undersize

mm {in}


| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 52.690—52.705 {2.0745—2.0749} |



BEARING

Main Bearing and Connecting Rod Bearing

Check the main bearing and the connecting rod bearings for peeling, scoring, and other damage.




OIL JET

Check that air passes through the oil jet when compressed air is applied to it. If air does not pass through the oil jet, replace it.

Compressed air:

216—274 kPa {2.2—2.8 kgf/cm², 32—39 psi}






TIMING BELT

1. Replace the timing belt if there is any oil or grease on it.
2. Check the timing belt for damage, wear, peeling, cracks, and hardening. Replace it if necessary.

Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.



TIMING BELT AUTO TENSIONER

Caution

- Using cleaning fluids or a steam cleaner to clean the tensioner can dissolve the grease in its sealed bearing.

1. Use a clean, soft rag to wipe the idler contact surface.
2. If the idler does not rotate smoothly, replace it.
3. If there are oil leaks, or if there are scratches or abnormal noise when turning the idler, replace it.
4. Check the tensioner pulley for rough rotation and abnormal noise. Replace it if necessary.
5. Check the auto tensioner for oil leakage. Replace it if necessary.
6. Check the tensioner rod projection $\text{\textcircled{A}}$. Replace the auto tensioner if necessary.

Projection $\text{\textcircled{A}}$ (free length):

14—16 mm {0.56—0.62 in}

PULLEY

Timing Belt Pulley and Camshaft Pulley

















Inspect the teeth of each pulley for wear, deformation, and other damage. Replace as necessary.













TIMING BELT COVER

Inspect the timing belt covers for damage and cracks. Replace as necessary.

ASSEMBLY



PREPARATION
SST

| | | | |
|---|--|---|--|
| <p>49 L011 0A0B</p> <p>Tool set, piston pin setting</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 001</p> <p>Body, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 L011 005</p> <p>Bolt, stopper (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 006</p> <p>Puller & installer (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 001</p> <p>Guide</p>  | <p>For removal / installation of piston pins</p> | <p>49 E011 002</p> <p>Screw</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 D011 002B</p> <p>Head, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 H018 001</p> <p>Wrench, knock sensor</p>  | <p>For installation of knock sensor</p> |
| <p>49 E011 1A0</p> <p>Brake, ring gear</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p>  | <p>For installation of valve seals</p> | <p>49 SE01 310A</p> <p>Centering tool, clutch disc</p>  | <p>For installation of clutch disc</p> |
| <p>49 L012 001</p> <p>Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> | <p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> |

| | | | |
|---|---|---|---|
| <p>49 L012 005</p> <p>Spacer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> | <p>49 0636 100B</p> <p>Arm, valve spring lifter</p>  | <p>For removal / installation of valves</p> |
| <p>49 B012 0A2</p> <p>Pivot</p>  | <p>For removal / installation of valves</p> | <p>49 B012 012</p> <p>Body (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 B012 013</p> <p>Foot (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> | <p>49 B012 014</p> <p>Locknut (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 F401 330B</p> <p>Installer set, bearing</p>  | <p>For installation of camshaft oil seal</p> | <p>49 F401 337A</p> <p>Attachment C (Part of 49 F401 330B)</p>  | <p>For installation of camshaft oil seal</p> |
| <p>49 F401 331</p> <p>Body (Part of 49 F401 330B)</p>  | <p>For installation of camshaft oil seal</p> | <p>49 H010 401</p> <p>Installer, oil seal</p>  | <p>For installation of front oil seal</p> |
| <p>49 G019 017</p> <p>Installer, oil seal</p>  | <p>For installation of rear oil seal</p> | <p>49 G014 001</p> <p>Wrench, oil filter</p>  | <p>For removal / installation of oil filter</p> |


1. Do not reuse gaskets or oil seals.
2. Clean all parts before reinstallation.
3. Apply clean engine oil to all sliding and rotating parts.
4. Replace plain bearings if they are peeled, burned, or otherwise damaged.
5. Tighten all bolts and nuts to the specified torque.

CYLINDER BLOCK (INTERNAL PARTS)
Torque Specifications



Connecting Rod


1. Assemble the **SST** (tool set, piston pin setting) to the piston pin.
2. Apply clean engine oil to the piston pin.




- Set the **SST** (stopper bolt) so that the depth L is as specified.

Depth L: 61.5 mm {2.421 in}

- Tighten the locknut.



- Assemble the piston and the connecting rod.
- Insert the **SST** (tool set, piston pin setting) assembled in step 1 into the piston pin hole.
- Mount the piston and connecting rod onto the **SST** (support block).



- Verify that the **SST** fits squarely into the piston before pressing.
- Press the piston pin into the piston and connecting rod until the **SST** (piston pin guide) contacts the **SST** (stopper bolt).
- While inserting the piston pin, note the pressing force. If it is not within the specification, replace the piston pin and/or the connecting rod.

Pressing force:

3,923—12,748 N {400—1,300 kgf, 880—2,860 lbf}

- Check the connecting rod oscillation torque.
(Refer to page B2-69.)

Piston Ring



Caution


- If reusing an oil ring, it must be reinstalled in the same place and face the same direction as when removed. If this is not done, it can cause premature and uneven wear.

Note


- The upper and lower rails are the same. They can be installed with either face upward.

- Install the three-piece oil rings on the pistons.
 - Apply clean engine oil to the oil ring spacer and rails.
 - Install the oil ring spacer so that the opening faces upward.
 - Install the upper rail and lower rail.
- Verify that the spacer tang separates the rails, and that the rails turn smoothly in both directions.






3. Install the rings with the R marks facing upward.
4. Using a piston ring expander, install the second ring with the scraper face downward.
5. Using a piston ring expander, install the top ring.
6. Apply clean engine oil to the piston rings.



7. Position the end gap of each ring as shown.




Oil jet

1. Apply a thread locking compound to the oil jet threads.
2. Install the oil jets into the upper cylinder block.

Tightening torque:

3.0—4.9 N·m {30—50 kgf·cm, 27—43 in·lbf}



Crankshaft

1. Measure the main bearing oil clearances as described below.


Oil clearance inspection

2. Install the upper main bearings (with oil groove) and the upper thrust bearings.
 - (1) Remove any foreign material and oil from the journals and bearings.
 - (2) Install the upper main bearings and upper thrust bearings.

Note

- No.4 bearing is wider than other bearings.

- (3) Install the lower cylinder block along with the lower main bearings and lower thrust bearings.
- (4) Measure the length of each lower cylinder block bolt. Replace any that exceed the maximum length.



Main bolt (A and B)


Length: 135.7—136.3 mm {5.343—5.366 in}

Maximum: 138.5 mm {5.452 in}

Sub bolt (C)

Length: 119.7—120.3 mm {4.713—4.736 in}

Maximum: 121.0 mm {4.763 in}





- (5) Apply clean engine oil to the bolt threads and seat faces of the lower cylinder block bolts.
- (6) Tighten the bolts in two or three steps in the order shown.

Tightening torque

Main bolts (A), (B): 23.1—25.9 N·m
 {2.35—2.65 kgf·m, 17.0—19.1 ft·lbf}
Sub bolts (C): 18.2—21.0 N·m
 {1.85—2.15 kgf·m, 13.4—15.5 ft·lbf}

Note


- Bolts (A) are marked "4" on the head.
- Bolts (B) are marked "1" on the head.
- Bolts (C) are no marked on the head.




- (7) Put a paint mark on the lower cylinder block next to the (A), (B), (C) bolt flange marks as shown.
- (8) Using the marks as a reference, further tighten the (A), (B), (C) bolts in the order shown.

Main bolt (A) (No.4 journal): 75°—85°
Main bolt (B) (No.1—No.3 journals): 65°—75°
Sub bolt (C): 55°—65°

- (9) Tighten the bolts till the mark on each bolt flange aligns with the corresponding paint mark.




- (10) Further tighten each bolt by performing steps (7), (8).



- (11) After tightening, measure the cylinder block No.1—No.4 journal bore diameter.
- (12) Subtract the main journal diameter from the bore diameter.
- (13) If the oil clearance exceeds the maximum, replace the bearing or grind the crankshaft and install under-size main bearings. (Refer to page B2-83.)

Oil clearance: 0.037—0.057 mm {0.0015—0.0022 in}
Maximum: 0.064 mm {0.0025 in}




**Main journal diameter****Standard:**

61.938—61.955 mm {2.4385—2.4391 in}

0.25 mm {0.01 in} undersize:

61.688—61.705 mm {2.4287—2.4293 in}

- (14) Remove the lower cylinder block in the reverse order of step (6).


**3. Install the lower cylinder block as follows:**

- (1) Install the upper thrust bearings in the upper cylinder block.
- (2) Apply clean engine oil to the main bearings, thrust bearings, and main journals.
- (3) Install the crankshaft in the upper cylinder block.
- (4) Remove any foreign material, oil, and sealant from the contact surfaces of the upper cylinder block and lower cylinder block.
- (5) Apply a continuous bead of silicone sealant to the contact surface as shown.
- (6) Install the lower cylinder block, lower main bearings, and lower thrust bearings within five minutes of applying the sealant.
- (7) Install the lower cylinder block along with the lower main bearings and lower thrust bearings.
- (8) Apply clean engine oil to the threads and seat faces of the lower cylinder block bolts.
- (9) Tighten the main bolts (A), (B) and sub cap bolts (C) as in steps 2—(6)/2—(10).

- (10) Tighten the lower cylinder block bolts in the order shown.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



4. Inspect the crankshaft end play.

End play: 0.08—0.282 mm {0.0032—0.0111 in}
Maximum: 0.32 mm {0.0126 in}

5. If the end play exceeds the maximum, grind the crankshaft and install oversize thrust bearings or replace the crankshaft and thrust bearing.

Thrust bearing width

Standard:

2.000—2.050 mm {0.0788—0.0807 in}



0.25 mm {0.01 in} oversize:

2.125—2.175 mm {0.0837—0.0856 in}

0.50 mm {0.02 in} oversize:

2.250—2.300 mm {0.0886—0.0905 in}

6. Apply clean engine oil to the lip of the new oil seal.
7. Push the oil seal slightly in by hand.
8. Using the SST and a hammer, tap the oil seal in evenly until it is flush with the edge of the rear cover.




Piston and Connecting Rod Assembly

1. Rotate the engine on the engine stand as shown.






Note

- Assembly is easier if the pistons are installed with the crankpin at the BDC position.

2. Remove any foreign material and oil from the connecting rod journals and bearings.
3. Install the upper connecting rod bearings in the connecting rods.
4. Apply clean engine oil to the cylinder walls, pistons, piston rings and connecting rod cap bolts.



5. Check the piston rings for proper end gap positioning.
6. Insert the piston assemblies into the cylinder block with the Ⓛ mark (left bank) and the Ⓜ mark (right bank) facing the front of the engine. Use a piston installer tool to install.



Connecting Rod Cap

1. Measure the connecting rod bearing oil clearances as follows.

- (1) Measure the oil clearance with the connecting rod in BDC position.
- (2) Do not rotate the crankshaft when measuring the oil clearances.

- (3) Position Plastigage atop the journals in the axial direction.
- (4) Remove any foreign material and oil from the lower connecting rod bearing and connecting rod cap.
- (5) Install the connecting rod bearing in the cap.
- (6) Measure the length of connecting rod cap bolt. Replace it if the length exceeds the maximum.

Length: 46.7—47.3 mm {1.84—1.86 in}
Maximum: 48.0 mm {1.89 in}


- (7) Apply clean engine oil to the threads and seat faces of the connecting rod cap bolts.
- (8) Install the connecting rod cap.
- (9) Tighten the connecting rod cap bolts.

Tightening torque:
22.1—26.9 N·m {2.25—2.75 kgf·m, 16.3—19.8 ft·lbf}

- (10) Put a paint mark on each bolt head.
- (11) Using this mark as a reference, tighten the bolts **82.5°—97.5°**.
- (12) Remove the connecting rod cap.
- (13) Measure the Plastigage at each journal at the widest point for the smallest clearance, and the narrowest point for the largest clearance.

Oil clearance: 0.023—0.043 mm {0.0010—0.0016 in}
Maximum: 0.08 mm {0.0031 in}

- (14) If the oil clearance exceeds the maximum, grind the crankshaft and install undersize bearings. (Refer to page B2-83.)





2. Install the connecting rod caps as follows.
 - (1) Remove the Plastigage from the journals and bearings.
 - (2) Apply clean engine oil to the connecting rod bearings.
 - (3) Install the connecting rod bearings and caps.
 - (4) Apply engine oil to the threads and seat faces of the cap bolts and tighten them as in step 1.
 - (5) Verify that the crankshaft rotates smoothly by hand.
3. Measure the connecting rod side clearances.
 - (1) Measure each connecting rod side clearance.

Side clearance: 0.178—0.330 mm {0.0071—0.0129 in}
Maximum: 0.40 mm {0.0157 in}

- (2) If the clearance exceeds the maximum, replace the connecting rod and cap assembly.


CYLINDER BLOCK (EXTERNAL PARTS)

Torque Specifications



Oil Pump


1. Apply clean engine oil to the new oil seal.
2. Install the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using the SST.



4. Remove any dirt or other material from the contact surfaces.
5. Apply a continuous bead of silicone sealant to the contact surface of the oil pump.
6. Apply clean engine oil to a new O-ring and install it into the pump body.

Caution

- **Keep the oil hole free of sealant to prevent engine damage.**



7. Apply clean engine oil to the oil seal lip.
8. Install the oil pump within five minutes of applying the sealant, making sure that the O-ring doesn't come out.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

Bolt length

Ⓐ: 40 mm {1.57 in}

Ⓑ: 25 mm {0.98 in}

9. Cut away the portion of the gasket that projects toward the oil pan.




Water Pump

1. Remove all dirt, grease, and other material from the water pump mounting surface.
2. Install a new rubber seal and the water pump.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




Oil Baffle

1. Remove any dirt or other material from the oil baffle.
2. Install the oil baffle and tighten the bolts gradually in two or three steps in the order shown.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




Oil Strainer

Install a new gasket and the oil strainer onto the oil pump body. Tighten bolts Ⓐ first.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Oil Pan


1. Remove the sealant from the oil pan bolts and bolt holes in the lower cylinder block.

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.




2. Remove any dirt and oil from the contact surfaces.
3. Apply a continuous bead of silicone sealant to the oil pan along the inside of the bolt holes, and overlap the ends.



4. Install the oil pan within five minutes of applying the sealant.

Tightening torque

- Ⓐ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}
- Ⓑ: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Knock Sensor

Install the knock sensor by using the SST.

Tightening torque:

- 20—34 N·m {2.0—3.5 kgf·m, 15—25 ft·lbf}



Water Pipe and Thermostat Housing

1. Install a new gasket and install the water pipe and thermostat housing as an assembly.

Tightening torque:

- 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

2. Secure the knock sensor harness to the water pipe with the clip as shown.


Oil Cooler

1. Install a new gasket and the oil cooler.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

2. Connect the water hoses.




Flywheel (MTX)

1. Set the flywheel onto the crankshaft.
2. Hold the flywheel by using the SST.
3. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}




Clutch Disc and Clutch Cover (MTX)

Install the clutch disc and clutch cover by using the SST. (Refer to section H.)

Tightening torque:

18—26 N·m {1.8—2.7 kgf·m, 14—19 ft·lbf}



Drive Plate (ATX)


Caution

- Verify that the adapter and the backing plate are mounted in the directions shown. Incorrect mounting can damage the engine and transmission.



1. Install the following parts to the crankshaft.
 - (1) Adapter
 - (2) Drive plate
 - (3) Backing plate
2. Hand tighten the lock bolts.
3. Hold the drive plate by using the SST.
4. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}




CYLINDER HEAD Torque Specifications



Valve Seal

The intake and exhaust valve seals are different as shown.


| | Ridge | Color |
|---------|-----------|---------------|
| Intake | No or One | Gray |
| Exhaust | Two | Gray or Green |



1. Assemble the **SST** so that depth L is as specified.

Depth L

IN: 16.3 mm {0.642 in}
EX: 13.8 mm {0.543 in}




2. Slide the valve seal onto the valve guide with the **SST**.
3. Set the **SST** against the valve seal.

Caution


- Using a hammer will damage the valve seal.

4. Using the **SST**, press the valve seal on by hand until the **SST** touches the cylinder head.




Valve and Valve Spring

1. Install the lower spring seat.
2. Install the valve.
3. Install the valve spring with the closer pitch toward the cylinder head.
4. Install the upper spring seat.



5. Compress the valve spring with the **SST**, and install the valve keepers.
6. Remove the **SST**.
7. Tap the end of the valve stem lightly two or three times with a plastic hammer to verify that the keepers are fully seated.
8. Using a flashlight, verify that all valve springs are fully seated in the cylinder head.




Cylinder Head


1. Measure the amount of the oil control plug projection from the deck of the cylinder block.

Projection (A): 13.0—14.0 mm {0.52—0.55 in}

2. Apply clean engine oil to new O-rings and install them to the oil control plugs.




3. Thoroughly remove all dirt, oil, and other material from the decks of the cylinder block.
4. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
5. Place a new cylinder head gasket on the left bank with the L mark.
6. Place a new cylinder head gasket on the right bank with the R mark.




7. Install the cylinder heads to the cylinder block.
8. Tighten the cylinder head bolts as described below.
 - (1) Before installation, measure the length of each bolt. Replace a bolt if it exceeds the maximum length.

Length: 131.2—131.8 mm {5.166—5.188 in}
Maximum: 132.5 mm {5.217 in}




- (2) Apply clean engine oil to the threads and the seat face of each bolt and install them.
- (3) Tighten the bolts in two or three steps in the order shown.

Tightening torque:
23.1—25.9 N·m {2.35—2.65 kgf·m, 17.0—19.1 ft·lbf}




- (4) Put a paint mark on each bolt head.
- (5) Using the marks as a reference, tighten the bolts by turning each **85°—95°** in the sequence shown.
- (6) Further tighten each bolt by turning another **85°—95°**.




9. Connect the water pipe to the water pipe elbow and secure to the cylinder head.

Tightening torque:
7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



HLA

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the positions from which they were removed.
3. Verify that the HLA move smoothly in their bores.




Camshaft

Caution

- Camshafts must be assembled in the following procedure. Otherwise, camshaft can be broken or damaged because there is little camshaft clearance.

1. Apply clean engine oil to the camshaft journals and the supports.
2. Install the camshafts so that the intake camshaft gear mark and exhaust camshaft gear mark align.
3. Remove the oil and dirt from the mating surfaces between the front camshaft cap and the cylinder head, and degrease.
4. Apply a light coat of silicone sealant to the shaded areas shown.


Thickness: $\phi 1.5\text{--}2.5\text{ mm}$ {0.06—0.09 in}



Caution

- Install the thrust caps (RH is marked 4, LH is marked A) first. Otherwise, camshaft can be broken or damaged.


5. Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the thrust caps fully seated on the cylinder heads.




6. Install the camshaft caps onto the cylinder heads. Hand tighten the bolts gradually in five or six steps in the order shown, until the camshaft caps fully seated on the cylinder heads.
7. Tighten the bolts in the order shown.

Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}





8. Retighten the bolts in the order shown.


Tightening torque:

11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}


- 9. Install the distributor cap onto the cylinder head. (LH)
- 10. Tighten the distributor cap bolts.

Tightening torque:


11.3—14.2 N·m {115—145 kgf·cm, 100—125 in·lbf}



- 11. Apply clean engine oil to the lip of the new camshaft oil seal.
- 12. Push the oil seal slightly in by hand.
- 13. Using the **SST** and a hammer, tap the camshaft oil seal in evenly until it is flush with the edge of the camshaft cap.



14. Tap in the new blind cap by using a plastic hammer.




Water Outlet

Install the water outlet with new O-rings.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}






Seal Plate

Install the seal plate.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



Camshaft Pulley

The right and left pulleys are different and must be installed on the same head that they were removed from.

1. Install the RH camshaft pulley so that the "R" mark can be seen and the groove aligns with the camshaft knock pin.


2. Install the LH camshaft pulley so that the "L" mark can be seen and the groove aligns with the camshaft knock pin.

Camshaft Pulley Bolt

1. Apply clean engine oil to the camshaft pulley bolt threads.
2. Hold the camshaft by using a wrench on the cast hexagon as shown, and tighten the camshaft pulley bolt.

Tightening torque:


123—140 N·m {12.5—14.3 kgf·m, 90.5—103 ft·lbf}




Cylinder Head Cover

1. Remove all dirt, old sealant and other material from the cylinder head and cover.
2. Apply silicone sealant to the shaded areas shown.

Thickness: ϕ 1.5—2.5 mm {0.06—0.09 in}



3. Coat a new gasket with silicone sealant.
4. Install the gasket onto the cylinder head cover.



5. Install the cylinder head cover and tighten the bolts in five or six steps in the order shown.


Tightening torque:

5.0—8.8 N·m {50—90 kgf·cm, 44—78 in·lbf}



6. Recheck the torque of the bolts indicated, and tighten them if necessary.

RH: ⑤, ⑥

LH: ⑥, ⑦




TIMING BELT Torque Specification



Timing Belt Pulley


1. Hold the flywheel by using the SST.
2. Install the timing belt pulley key and the timing belt pulley on the crankshaft.
3. Temporarily tighten the timing belt pulley bolt.

**No.2 Idler Pulley**

Install the No.2 idler pulley to the cylinder block.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

**Timing Belt Auto Tensioner**


1. Press in the tensioner rod slowly, using a press or a vise.

Caution

- Do not press the tensioner rod to more than 9,807 N {1,000 kgf, 2,200 lbf}. It will damage the tensioner.



2. Insert a pin to hold the tensioner rod in the body.




3. Install the auto tensioner to the cylinder block and hand tighten the upper tensioner bolt so that the tensioner can move.


Note

- This must be done to reduce the timing belt resistance when the idler pulley is installed.


4. Temporarily install the tensioner pulley.

**Timing Belt**

1. Align the matching marks of the pulleys.




2. Install the timing belt on the pulleys in the order described below.
 - ① Timing belt pulley
 - ② No.2 idler pulley
 - ③ LH camshaft pulley
 - ④ Tensioner pulley
 - ⑤ RH camshaft pulley
3. Verify that there is tension between pulleys ③ and ①, and between pulleys ① and ⑤.



4. Install the No.1 idler pulley while applying the pressure on the timing belt.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



5. Push the auto tensioner in the direction of the arrow and install the lower bolt.
6. Tighten the upper and lower tensioner bolts to the specified torque.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




7. Remove the pin from the auto tensioner, and apply tension to the belt.
8. Tighten the tensioner pulley.

Tightening torque:

38—44 N·m {3.8—4.5 kgf·m, 28—32 ft·lbf}




9. Turn the crankshaft clockwise twice, and align the timing marks.
10. Verify that the timing marks are correctly aligned. If not, repeat the procedure from **Timing Belt Auto Tensioner**. (Refer to page B2-107.)



11. Check the timing belt deflection. If it is incorrect, replace the auto tensioner.

Deflection: 6.0—8.0 mm {0.24—0.31 in}




No.3 engine mount bracket

Install the No.3 engine mount bracket.

Tightening torque:

44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}




Timing Belt Cover

1. Install the right timing belt cover.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



2. Install the left timing belt cover.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Crankshaft Position Sensor

Install the crankshaft position sensor.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Dipstick and Pipe

Install the dipstick and pipe with the clip.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Water Pump Pulley

Install the water pump pulley.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



Crankshaft Pulley

1. Hold the flywheel (MTX) or drive plate (ATX) by using the SST.

2. Remove the crankshaft pulley bolt.


Caution

- Install the crankshaft pulley carefully. The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.



3. Install the crankshaft pulley onto the crankshaft.
4. Apply clean engine oil to the bolt threads.
5. Tighten the crankshaft pulley.

Tightening torque:

157—166 N·m {16.0—17.0 kgf·m, 116—122 ft·lbf}




AUXILIARY PARTS
Torque Specifications



Oil Filter

1. Apply clean engine oil to the rubber seal of the new oil filter.
2. Install the filter and tighten it by hand until the rubber seal contacts the oil cooler.
3. Tighten the filter 1-1/6 turns by using the SST.



Spark Plug


Caution

- To avoid breaking the spark plug, be sure to fit the socket squarely over it.

Install the spark plugs.

Tightening torque:

15—22 N·m {1.5—2.3 kgf·m, 11—16 ft·lbf}




A/C Compressor Bracket (If equipped)

Install the A/C compressor bracket.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m 28—38 ft·lbf}



Engine Hanger

1. Install the front engine hanger and the ground harness.


Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

2. Install the rear engine hanger.

Tightening torque:



38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



Intake Manifold Assembly


1. Install new gaskets and the intake manifold assembly. Hand tighten the bolts and nuts.

2. Connect the stays, bracket, fuel pipe, and hoses in the order shown in the figure.
3. Tighten the intake manifold bolts and nuts in two or three steps.



Distributor


1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply engine oil to the drive blade.
3. Align the groove of the distributor body and shaft gear mark as shown.
4. Install the distributor with the blade fit into the camshaft groove.



5. Hand tighten the distributor mounting bolts.
6. Connect the high-tension leads.

Note

- Adjust the ignition timing after engine installation. (Refer to section G.)




Exhaust Manifold Assembly (Left)

1. Place the new gasket in position.
2. Install the left exhaust manifold.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




Exhaust Manifold Insulator (Left)

Install the left exhaust manifold insulator.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Bracket and Tensioner

1. Install the bracket and tensioner.
2. Hand tighten bolt ①, then bolt ②.
3. Tighten bolt ②, then bolt ① to the specified torque.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



Generator

Install the generator and the bracket.

Tightening torque


Ⓐ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

Ⓑ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

ENGINE STAND DISMOUNTING

PROCEDURE

1. Remove the engine from the engine stand.
2. Remove the **SST** from the engine in the reverse order of installation. (Refer to page B2-52.)



3. Install the new gasket and the right exhaust manifold together with the EGR valve and pipe.


Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

4. Tighten the EGR valve bolts.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



5. Install the right exhaust manifold insulator.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



INSTALLATION

PROCEDURE

Tighten all bolts and nuts to the specified torques.

Step 1

Torque Specifications




No.2 Engine mount rubber and bracket


1. Install the mount rubber bracket.

Tightening torque:

38-51 N-m {3.8-5.3 kgf-m, 28-38 ft-lbf}



2. Install the No.2 engine mount rubber and hand tighten the through bolt.



Starter

Install the starter to the transaxle housing.

Tightening torque:



38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

Step 2

Warning


- A vehicle that is lifted but not securely supported on safety stands is dangerous. It can slip or fall, causing death or serious injury. Never work around or under a lifted vehicle if it is not securely supported on safety stands.

Torque Specifications



Engine and transaxle assembly

1. Suspend the engine and transaxle assembly.
2. Slowly lower the engine and transaxle assembly as a unit. Keep the engine from swinging or bumping into components in the engine compartment.
3. Install the engine and transaxle assembly in the engine compartment.
4. Align the engine mounts with the engine mount member mounting holes.




Engine mount member

Install bolts and nuts (A) as shown and hand tighten nuts (B).

Tightening torque:

67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}




Engine mount

1. Install the No.1 engine mount mounting bolts.

Tightening torque:

67—104 N·m {6.8—10.7 kgf·m, 50—77.3 ft·lbf}




2. Install the No.3 engine mount rubber.

Tightening torque

(A): 75—104 N·m {7.6—10.7 kgf·m, 55—77.3 ft·lbf}

(B): 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}



3. Install the No.4 engine mount bracket.

4. Hand tighten bolts (A).


5. Tighten bolts (B).

6. Tighten bolts (A).

Tightening torque

(A): 59—80 N·m {6.0—8.2 kgf·m, 44—59 ft·lbf}

(B): 59—80 N·m {6.0—8.2 kgf·m, 44—59 ft·lbf}



7. Install the No.4 engine mount rubber.

Tightening torque

(A): 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}


(B): 86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}

8. Remove the chain block from the engine hangers.

9. Tighten the No.2 engine mount rubber mounting bolt. (Refer to page B2-117.)

Tightening torque:

86—116 N·m {8.7—11.9 kgf·m, 63—86.0 ft·lbf}



10. Tighten the No.2 engine mount nuts (B).
(Refer to page B2-119.)

Tightening torque:


75—104 N·m {7.6—10.7 kgf·m, 55—77.3 ft·lbf}

11. Install the No.5 engine mount rubber.

Tightening torque

(A): 55—80 N·m {5.6—8.2 kgf·m, 41—59 ft·lbf}

(B): 44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}





12. Install the No.1 engine mount stay bracket and ground harness.

Tightening torque:

6.9—9.8 N·m {70—100 kgf·cm, 61—86.8 in·lbf}


Step 3 Torque specifications





Drive shaft


1. Apply grease to the ends of the drive shafts.
2. Install new clips with the end gap upward and install the drive shafts.



3. Install the joint shaft.
4. Tighten the bolts in the order shown.

Tightening torque:


43—61 N·m {4.3—6.3 kgf·m, 32—45 ft·lbf}



5. Coat the ball joints with grease.
6. Install the lower arm ball joints to the knuckles and tighten the through bolts.

Tightening torque:

44—58 N·m {4.4—6.0 kgf·m, 32—43 ft·lbf}




Tie-rod end ball joint

1. Install the tie-rod ends to the knuckles and tighten them.

Tightening torque:

43—56 N·m {4.3—5.8 kgf·m, 32—41 ft·lbf}

2. Install new cotter pins.




Stabilizer control link

Install the stabilizer control link.

Tightening torque:

44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}

**Extension bar (MTX)**

Install the extension bar to the transaxle.

Tightening torque:


32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

Shift control rod (MTX)

Install the shift control rod to the transaxle.

Tightening torque:


16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

**Front exhaust pipe**

1. Connect the front exhaust pipe to the exhaust pipe with a new gasket. Hand tighten the new nuts.
2. Install the exhaust pipe to the vehicle body with mount rubbers.
3. Tighten the nuts.

Tightening torque:


64—89 N·m {6.5—9.1 kgf·m, 48—65 ft·lbf}



4. Install the front exhaust pipe with new gaskets.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

**Transverse member**

Install the transverse member.

Tightening torque:

94—126 N·m {9.5—12.9 kgf·m, 69—93.3 ft·lbf}


**Clutch release cylinder (MTX)**

1. Install the clutch release cylinder.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

2. Mount the pipe in the brackets and install the clips.



Fuel filter


Install the harness bracket and the fuel filter.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}


Step 4

Connect the hoses shown in the figure.





Step 5

Connect the harness connectors shown in the figure.



Step 6
Torque Specifications




**A/C compressor**

Install the A/C compressor to the bracket.

Tightening torque:

24—35 N·m {2.4—3.6 kgf·m, 18—26 ft·lbf}


**P/S oil pump and bracket**

1. Install the P/S oil pump.

Tightening torque

Ⓐ: 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}


Ⓑ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




2. Tighten the bolt shown in the figure.

Tightening torque:

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}



3. Connect the P/S pressure switch connector.




4. Install the P/S oil pump pulley to the pump body and hand tighten the nut.

5. Tighten the pulley nut by using a 12 mm {0.47 in} socket wrench through the pulley hole as shown.

Tightening torque:

63—93 N·m {6.4—9.5 kgf·m, 47—68 ft·lbf}




6. Install the P/S oil reservoir and the engine ground.

Tightening torque:

6.9—9.8 N·m {70—100 kgf·cm, 61—86.6 in·lbf}

Drive belt

1. Install the P/S and/or A/C drive belt.
2. Adjust the drive belt deflection. (Refer to page B2-6.)




Radiator and cooling fan assembly

1. Install the radiator.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

2. Connect the oil cooler hoses. (ATX)
3. Connect the upper and lower radiator hoses.




4. Install the cooling fan assembly.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

5. Connect the coolant reservoir hose.
6. Connect the cooling fan motor connector.




Accelerator cable

Inspection / Adjustment

1. Verify that the throttle valve is fully closed.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.0 mm {0.06—0.15 in}

3. If not as specified, turn stopper (B) while pressing lock button (A) to release the lock.
4. Push the spring in direction (C) and adjust the cable free play.
5. Lock (A) after locking stopper (B).



Air cleaner assembly

1. Install the air cleaner assembly.
2. Connect the hoses.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

3. Connect the mass air flow sensor connector.

Fresh-air duct

Install the fresh-air duct.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

Steps After Installation

1. Fill the engine with the specified amount and type of engine oil. (Refer to section D2.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E2.)
3. If the transaxle was drained, fill it with the specified amount and type of transaxle oil. (MTX: Refer to section J, ATX: Refer to section K1.)
4. Install the front wheels.
5. Start the engine and
 - (1) check the engine oil, transaxle oil, and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F2.)
 - (3) check the operation of the emission control system.
6. Turn off the engine and check drive belt deflection. (Refer to page B2-6.)
7. Perform a road test.
8. Recheck the oil and coolant levels.


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

LUBRICATION SYSTEM

(FS)

| | |
|------------------------------------|-------|
| INDEX | D1- 2 |
| OUTLINE | D1- 3 |
| SPECIFICATIONS | D1- 3 |
| TROUBLESHOOTING GUIDE | D1- 3 |
| OIL PRESSURE | D1- 4 |
| PREPARATION | D1- 4 |
| INSPECTION | D1- 4 |
| ENGINE OIL | D1- 6 |
| INSPECTION | D1- 6 |
| REPLACEMENT | D1- 6 |
| OIL FILTER | D1- 7 |
| PREPARATION | D1- 7 |
| REPLACEMENT | D1- 7 |
| OIL PAN | D1- 8 |
| REMOVAL / INSTALLATION | D1- 8 |
| OIL PUMP | D1-11 |
| PREPARATION | D1-11 |
| DISASSEMBLY / ASSEMBLY | D1-11 |
| INSPECTION | D1-12 |

INDEX



ENGINE OIL SPECIFICATION
API SERVICE SG, SH (ECII)
ILSAC
TOTAL CAPACITY
3.7 L {3.9 US qt, 3.3 Imp qt}

- 1. Oil pressure
Inspection page D1-4
- 2. Engine oil
Inspection page D1-6
Replacement page D1-6
- 3. Oil filter
Replacement page D1-7

- 4. Oil pan
Removal / Installation page D1- 8
- 5. Oil pump
Disassembly / Assembly page D1-11
Inspection page D1-12


OUTLINE

SPECIFICATIONS

| Item | | Engine | FS |
|---|--|---------------------------------|-------------------------------------|
| Lubrication system | | | Force-fed type |
| Oil pump | Type | | Trochoid gear |
| | Relief pressure | kPa {kgf/cm ² , psi} | 442—539 {4.5—5.5, 64—78} |
| Oil filter | Type | | Full-flow, paper element |
| | By-pass pressure differential | kPa {kgf/cm ² , psi} | 79—117 {0.8—1.2, 12—17} |
| Oil pressure switch activation pressure | | kPa {kgf/cm ² , psi} | 14.8—27.4 {0.15—0.28, 2.14—3.98} |
| Oil capacity | Total (dry engine) | L {US qt, Imp qt} | 3.7 {3.9, 3.3} |
| | Engine oil replacement | L {US qt, Imp qt} | 3.3 {3.5, 2.9} |
| | Engine oil replacement (with oil filter) | L {US qt, Imp qt} | 3.5 {3.7, 3.1} |
| Engine oil | | | API Service SG, SH (EC II) ILSAC |

D1

Recommended SAE Viscosity



Anticipated ambient temperature range before succeeding oil change, °C {°F}

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Remedy | Page |
|---|--|---|-------|
| Engine hard starting | Improper engine oil | Replace | D1- 6 |
| | Insufficient engine oil | Add oil | D1- 6 |
| Excessive oil consumption | Oil working up or down in cylinder Oil leakage | Refer to section B1 Repair | — |
| Oil pressure drop | Insufficient engine oil | Add oil | D1- 6 |
| | Oil leakage | Repair | — |
| | Worn and/or damaged oil pump rotor | Replace | D1-11 |
| | Worn plunger (inside oil pump) or weak spring | Replace | D1-11 |
| | Clogged oil strainer | Clean | — |
| | Excessive main bearing or connecting rod bearing clearance | Refer to section B1 | — |
| Warning light illuminates while engine is running | Oil pressure drop Malfunction of oil pressure switch | As described above Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual | — |
| | Malfunction of electrical system | Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual | — |


Warning


- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

OIL PRESSURE

PREPARATION


SST

| | | |
|---------------------|---|--------------------------------|
| 49 0187 280 |  | For inspection of oil pressure |
| Gauge, oil pressure | | |




INSPECTION

1. Remove the intake manifold bracket.



2. Remove the oil pressure switch.




3. Screw the **SST** into the oil pressure switch installation hole.
4. Warm up the engine to normal operating temperature.
5. Run the engine at the specified speed, and note the gauge readings.


Note

- Oil pressure varies with oil viscosity and temperature.

Oil pressure: 393—490 kPa
{4.0—5.0 kgf/cm², 57—71 psi}—3,000 rpm



6. If the pressure is not as specified, check for the cause and repair as necessary.
 (Refer to Troubleshooting Guide, page D1-3.)
7. Apply silicone sealant to the oil pressure switch threads as shown.




8. Remove the **SST** and install the oil pressure switch.

Tightening torque:

12—17 N·m {1.2—1.8 kgf·m, 8.7—13.0 ft·lbf}





D1



9. Install the intake manifold bracket.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



ENGINE OIL

INSPECTION

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil as necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.9 Imp qt}.

REPLACEMENT

Warning

- **When the engine and the oil are hot, they can badly burn. Don't burn yourself with either.**

1. Remove the oil filler cap and the oil pan drain plug.
2. Drain the oil into a container.
3. Install the drain plug.

Tightening torque:

30—41 N·m {3.0—4.2 kgf·m, 22—30 ft·lbf}

4. Refill the engine with the specified type and amount of engine oil.

Oil capacity

L {US qt, Imp qt}


| | |
|--|----------------|
| Total (dry engine) | 3.7 {3.9, 3.3} |
| Engine oil replacement | 3.3 {3.5, 2.9} |
| Engine oil replacement (with oil filter) | 3.5 {3.7, 3.1} |

5. Refit the oil filler cap.
6. Run the engine and check for leaks.
7. Check the oil level and add oil if necessary.


OIL FILTER

PREPARATION

SST


| | | |
|---|---|---|
| <p>49 G014 001</p> <p>Oil filter wrench</p> |  | <p>For removal / installation of oil filter</p> |
|---|---|---|

D1



REPLACEMENT

1. Remove the oil filter by using the **SST**.
2. Use a clean rag to wipe off the mounting surface on the engine.
3. Apply clean engine oil to the O-ring of the new filter.



4. Install the oil filter and tighten it by hand until the O-ring contacts the cylinder block.
5. Tighten the filter 1 and 1/6 turns by using the **SST**.

Tightening torque:

14—17 N·m {1.4—1.8 kgf·m, 11—13 ft·lbf}


6. Start the engine and check for leaks.
7. Check the oil level and add if necessary.

Oil filter capacity: 0.2 L {0.2 US qt, 0.2 Imp qt}

OIL PAN






REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine oil. (Refer to page D1-6.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Splash shield
Removal Note page D1-9
Installation Note page D1-9

5. Oil strainer
Removal Note page D1-9
Installation Note page D1-9



Removal Note

Oil pan

1. Remove the oil pan mounting bolts.

Caution

- Pry tools can easily scratch the oil pan upper block and oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.

D1

2. Remove the sealant on the bolt threads.
3. Screw in an oil pan bolt in the weld nut hole to make a small gap between the oil pan upper block and the oil pan.
4. Separate the oil pan from the oil pan upper block by using a scraper or a separator tool.
5. Remove the oil pan.

Oil strainer

1. Remove bolt (B).
2. Remove bolts (A).
3. Remove the oil strainer and gasket.

Installation Note

Oil strainer

1. Install the oil strainer with a new gasket.
2. Tighten the bolts marked (A) first.


Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}


Oil pan

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.



1. Remove all foreign material from the contact surfaces.
2. Apply silicone sealant to the oil pan as shown.



3. Install the oil pan within five minutes of applying the sealant.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}


Steps After Installation

1. Fill with the specified amount and type of engine oil. (Refer to page D1-6.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.
4. Check the oil level and add oil if necessary.

OIL PUMP


PREPARATION

SST


| | | |
|---------------------|---|------------------------------------|
| 49 H010 401 |  | For installation of front oil seal |
| Installer, oil seal | | |

DISASSEMBLY / ASSEMBLY


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <p>1. Oil seal Disassembly Note page D1-12 Assembly Note page D1-13</p> | <p>4. Inner rotor Inspection page D1-12 Assembly Note page D1-13</p> |
| <p>2. Pump cover Disassembly Note page D1-12 Assembly Note page D1-13</p> | <p>5. Snap ring 6. Spring seat 7. Pressure spring Inspection page D1-12</p> |
| <p>3. Outer rotor Inspection page D1-12 Assembly Note page D1-13</p> | <p>8. Control plunger 9. Pump body</p> |

**Disassembly Note****Oil seal**

Remove the oil seal with a screwdriver protected with a rag.


**Pump cover**

1. Remove the pump cover mounting bolts with an impact screwdriver.
2. Remove the pump cover.

**INSPECTION****Pressure spring**

1. Inspect the spring for weakness and damage.
2. Measure the free length. Replace the spring if necessary.

Free length: 46.79 mm {1.842 in}


**Rotor Clearance**

Measure the following clearance. Replace the rotor if necessary.

Inner rotor-to-tooth tip clearance:


0.02—0.18 mm {0.0008—0.0070 in}

Maximum: 0.200 mm {0.0079 in}


**Outer rotor-to-pump body clearance:**

0.113—0.186 mm {0.0045—0.0073 in}


Maximum: 0.210 mm {0.0083 in}

**Side clearance:**

0.035—0.095 mm {0.0014—0.037 in}

Maximum: 0.120 mm {0.0047 in}**Assembly Note****Inner and outer rotor**

1. Apply clean engine oil to the friction surface of the pump body and the rotors.
2. Install the inner and outer rotors into the oil pump body with the marks aligned as shown.


**Pump cover**

1. Install the pump cover.

Tightening torque:

5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}

2. Verify that the inner rotor turns smoothly when turned by hand.

**Oil seal**

1. Apply clean engine oil to the new oil seal.
2. Install the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using the SST.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.


LUBRICATION SYSTEM

(KL)

D2

| | |
|------------------------------------|-------|
| INDEX | D2- 2 |
| OUTLINE | D2- 3 |
| SPECIFICATIONS | D2- 3 |
| TROUBLESHOOTING GUIDE | D2- 3 |
| OIL PRESSURE | D2- 4 |
| PREPARATION | D2- 4 |
| INSPECTION | D2- 4 |
| ENGINE OIL | D2- 5 |
| INSPECTION | D2- 5 |
| REPLACEMENT | D2- 5 |
| OIL FILTER | D2- 6 |
| PREPARATION | D2- 6 |
| REPLACEMENT | D2- 6 |
| OIL COOLER | D2- 7 |
| PREPARATION | D2- 7 |
| REMOVAL / INSTALLATION | D2- 7 |
| OIL PAN | D2- 8 |
| REMOVAL / INSTALLATION | D2- 8 |
| INSPECTION | D2- 9 |
| OIL PUMP | D2-11 |
| PREPARATION | D2-11 |
| DISASSEMBLY / ASSEMBLY | D2-11 |
| INSPECTION | D2-12 |

INDEX



- 1. Oil pressure
Inspection page D2-4
- 2. Engine oil
Inspection page D2-5
Replacement page D2-5
- 3. Oil filter
Replacement page D2-6
- 4. Oil cooler
Removal / Installation page D2-7

- 5. Oil pan
Removal / Installation page D2- 8
Inspection page D2- 9
- 6. Oil pump
Disassembly / Assembly page D2-11
Inspection page D2-12


OUTLINE

SPECIFICATIONS

| Item | | Engine | KL |
|--------------------|--|---------------------------------|-------------------------------------|
| Lubrication system | | | Force-fed type |
| Oil pump | Type | | Trochoid gear |
| | Relief pressure | kPa {kgf/cm ² , psi} | 491—588 {5.0—6.0, 72—85} |
| Oil filter | Type | | Full-flow, paper element |
| | By-pass pressure differential | kPa {kgf/cm ² , psi} | 79—117 {0.8—1.2, 12—17} |
| Oil capacity | Total (dry engine) | L {US qt, Imp qt} | 4.9 {5.2, 4.3} |
| | Engine oil replacement | L {US qt, Imp qt} | 3.7 {3.9, 3.3} |
| | Engine oil replacement (with oil filter) | L {US qt, Imp qt} | 4.0 {4.2, 3.5} |
| Engine oil | | | API Service SG, SH (EC II) ILSAC |

D2

Recommended SAE Viscosity



Anticipated ambient temperature range before succeeding oil change, °C {°F}

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Remedy | Page |
|---|--|---|-------|
| Engine hard starting | Improper engine oil | Replace | D2- 5 |
| | Insufficient engine oil | Add oil | D2- 5 |
| Excessive oil consumption | Oil working up or down in cylinder Oil leakage | Refer to section B2 Repair | — |
| Oil pressure drop | Insufficient engine oil | Add oil | D2- 5 |
| | Oil leakage | Repair | — |
| | Worn and/or damaged oil pump rotor | Replace | D2-11 |
| | Worn plunger (inside oil pump) or weak spring | Replace | D2-11 |
| | Clogged oil strainer | Clean | — |
| | Excessive main bearing or connecting rod bearing clearance | Refer to section B2 | — |
| Warning light illuminates while engine is running | Oil pressure drop Malfunction of oil pressure switch | As described above Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual | — |
| | Malfunction of electrical system | Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual | — |


Warning



- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

OIL PRESSURE

PREPARATION

SST

| | |
|---|---------------------------------------|
| <p>49 0187 280</p> <p>Gauge, oil pressure</p>  | <p>For inspection of oil pressure</p> |
|---|---------------------------------------|



INSPECTION

1. Remove the oil pressure switch.

2. Screw the **SST** into the oil pressure switch installation hole.
3. Warm up the engine to normal operating temperature.
4. Run the engine at the specified speed, and note the gauge readings.


Note

- Oil pressure varies with oil viscosity and temperature.

Oil pressure: 334—490 kPa

{3.4—5.0 kgf/cm², 49—71 psi}—3,000 rpm


5. If the pressure is not as specified, check for the cause and repair as necessary.
(Refer to Troubleshooting Guide, page D2-3.)
6. Apply silicone sealant to the oil pressure switch threads as shown.




7. Remove the **SST** and install the oil pressure switch.

Tightening torque:

12—17 N·m {1.2—1.8 kgf·m, 8.7—13.0 ft·lbf}





ENGINE OIL


INSPECTION

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil as necessary.

D2

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.9 Imp qt}.



REPLACEMENT

Warning

- When the engine and the oil are hot, they can badly burn. Don't burn yourself with either.

1. Remove the oil filler cap and the oil pan drain plug.
2. Drain the oil into a container.
3. Install a new gasket and the drain plug.

Tightening torque:


30—41 N·m {3.0—4.2 kgf·m, 22—30 ft·lbf}

4. Refill the engine with the specified type and amount of engine oil.

Oil capacity

L {US qt, Imp qt}


| | |
|--|----------------|
| Total (dry engine) | 4.9 {5.2, 4.3} |
| Engine oil replacement | 3.7 {3.9, 3.3} |
| Engine oil replacement (with oil filter) | 4.0 {4.2, 3.5} |




5. Refit the oil filler cap.
6. Run the engine and check for leaks.
7. Check the oil level and add oil if necessary.

OIL FILTER

PREPARATION
SST

| | | |
|-----------------------|---|---|
| 49 G014 001 |  | For removal / installation of oil filter |
| Wrench, oil filter | | |

**REPLACEMENT**

1. Remove the oil filter by using the **SST**.
2. Use a clean rag to wipe off the mounting surface on the oil cooler base.
3. Apply clean engine oil to the O-ring of the new filter.
4. Install the oil filter and tighten it by hand until the O-ring contacts the oil cooler base.
5. Tighten the filter 1 and 1/6 turns by using the **SST**.

Tightening torque:

14—17 N·m {1.4—1.8 kgf·m, 11—13 ft·lbf}

6. Start the engine and check for leaks.
7. Check the oil level and add oil if necessary.

Oil filter capacity: 0.3 L {0.3 US qt, 0.3 Imp qt}

OIL COOLER


PREPARATION
SST

| | | |
|--|---|---|
| <p>49 G014 001</p> <p>Wrench, oil filter</p> |  | <p>For removal / installation of oil filter</p> |
|--|---|---|

D2

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E2.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Oil filter Replacement page D2-6 2. Oil cooler hose 3. Oil cooler | <ol style="list-style-type: none"> 4. Oil pressure switch 5. Oil filter body 6. Gasket |
|--|---|


Steps After Installation

1. Fill with the specified amount and type of engine coolant. (Refer to section E2.)
2. Check for leaks.

OIL PAN

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine oil. (Refer to page D2-5.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Splash shield
2. Transverse member
3. Front exhaust pipe

4. Oil pan
Removal Note page D2-9
Inspection page D2-9
Installation Note page D2-9
5. Oil strainer


Removal Note**Oil pan**

1. Remove the oil pan mounting bolts.


Caution

- Pry tools can easily scratch the lower cylinder block and oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.


D2




2. Separate the oil pan from the lower cylinder block by using a scraper or a separator tool.
3. Remove the oil pan.

**INSPECTION****Oil Pan**


Visually check for cracks, deformation and damage. Repair or replace if necessary.

**Installation Note****Oil pan****Caution**


- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.



1. Remove all foreign material from the contact surfaces.



2. Apply silicone sealant to the oil pan flange as shown.



3. Install the oil pan within five minutes of applying the sealant.

Tightening torque

Ⓐ: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lb}


Ⓑ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lb}

Steps After Installation

1. Fill with the specified amount and type of engine oil. (Refer to page D2-5.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.
4. Check the oil level and add oil if necessary.


OIL PUMP

PREPARATION
SST


| | | |
|---|---|---|
| <p>49 H010 401</p> <p>Installer, oil seal</p> |  | <p>For installation of front oil seal</p> |
|---|---|---|

DISASSEMBLY / ASSEMBLY


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Oil seal Disassembly Note page D2-12 Assembly Note page D2-13 2. Pump cover Disassembly Note page D2-12 Assembly Note page D2-13 3. Outer rotor Inspection page D2-12 Assembly Note page D2-13 | <ol style="list-style-type: none"> 4. Inner rotor Inspection page D2-12 Assembly Note page D2-13 5. Blind plug 6. Spring seat 7. Pressure spring Inspection page D2-12 8. Control plunger 9. Pump body |
|---|--|

**Disassembly Note****Oil seal**

Remove the oil seal with a screwdriver protected with a rag.


**Pump cover**

1. Remove the pump cover mounting bolts with an impact screwdriver.
2. Remove the pump cover.

**INSPECTION****Pressure Spring**

1. Inspect the spring for weakness and damage.
2. Measure the spring free length. Replace the spring if necessary.

Free length: 46.79 mm {1.842 in}


**Rotor Clearance**

Measure the following clearances. Replace the rotor if necessary.

Inner rotor-to-tooth tip clearance:


0.02—0.18 mm {0.0008—0.0070 in}

Maximum: 0.20 mm {0.0079 in}


**Outer rotor-to-pump body clearance:**

0.113—0.186 mm {0.0045—0.0073 in}

Maximum: 0.22 mm {0.0087 in}




Side clearance: 0.03—0.09mm {0.0012—0.0035 in}
Maximum: 0.13mm {0.0051 in}



Assembly Note

Inner and outer rotor

1. Apply clean engine oil to the friction surface of the pump body and the rotors.
2. Install the inner and outer rotors into the oil pump body with the marks aligned as shown.




Pump cover

1. Install the pump cover.

Tightening torque:

5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}

2. Verify that the oil pump rotates smoothly when turned by hand.



Oil seal

1. Apply clean engine oil to the new oil seal.
2. Install the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using the SST.


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

COOLING SYSTEM (FS)

E1

| | |
|-------------------------------------|-------|
| INDEX | E1- 2 |
| OUTLINE | E1- 3 |
| SPECIFICATIONS | E1- 3 |
| TROUBLESHOOTING GUIDE | E1- 3 |
| ENGINE COOLANT | E1- 4 |
| PREPARATION | E1- 4 |
| INSPECTION | E1- 4 |
| REPLACEMENT | E1- 5 |
| RADIATOR CAP | E1- 7 |
| PREPARATION | E1- 7 |
| INSPECTION | E1- 7 |
| RADIATOR | E1- 8 |
| REMOVAL / INSTALLATION | E1- 8 |
| INSPECTION | E1- 8 |
| THERMOSTAT | E1- 9 |
| REMOVAL / INSTALLATION | E1- 9 |
| INSPECTION | E1- 9 |
| WATER PUMP | E1-11 |
| REMOVAL / INSTALLATION | E1-11 |
| COOLING FAN MOTOR | E1-12 |
| INSPECTION | E1-12 |
| REPLACEMENT | E1-13 |
| COOLING FAN RELAY | E1-14 |
| REMOVAL | E1-14 |
| INSPECTION | E1-14 |

INDEX



- | | | |
|--------------------------------------|-----------------|--|
| 1. Engine coolant | | |
| Inspection | page E1-4 | |
| Replacement | page E1-5 | |
| 2. Radiator cap | | |
| Inspection | page E1-7 | |
| 3. Radiator | | |
| Removal / Inspection / | | |
| Installation | page E1-8 | |
| 4. Thermostat | | |
| Removal / Inspection / | | |
| Installation | page E1-9 | |
| 5. Water pump | | |
| Removal / Installation | page E1-11 | |
| 6. Cooling fan motor | | |
| Inspection | page E1-12 | |
| Replacement | page E1-13 | |
| 7. Engine coolant temperature sensor | | |
| Removal / Inspection / .. MTX: | section F1 | |
| Installation | ATX: section F3 | |
| 8. Cooling fan relay | | |
| Removal | page E1-14 | |
| Inspection | page E1-14 | |

OUTLINE

SPECIFICATIONS

| Item | | Engine | FS | |
|------------------|----------------------------|---------------------------------|-----------------------------------|------------|
| Cooling system | | | Water-cooled, forced circulation | |
| Coolant capacity | | L {US qt, Imp qt} | 7.0 {7.4, 6.2} | |
| Water pump | Type | | Centrifugal, V-ribbed belt-driven | |
| | Water seal | | Unified mechanical seal | |
| Thermostat | Type | | Wax, bottom-bypass | |
| | Opening temperature | °C {°F} | 80—84 {176—183} | |
| | Full-open temperature | °C {°F} | 95 {203} | |
| | Full-open lift | mm {in} | 8.5 {0.33}min. | |
| Radiator | Type | | Corrugated fin | |
| | Cap valve opening pressure | kPa {kgf/cm ² , psi} | 94—122 {0.95—1.25, 13.6—17.7} | |
| Cooling fan | Type | | Electric | |
| | Blade | Outer diameter | mm {in} | 340 {13.4} |
| | | Number | | 4 |
| | Motor | Current | A | 5.6—7.6 |

E1



TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|--------------------|----------------------------|-------------------|-------|
| Overheating | Coolant level insufficient | Add | E1- 4 |
| | Coolant leakage | Repair or replace | — |
| | Radiator fins clogged | Repair | E1- 8 |
| | Radiator cap malfunction | Replace | E1- 7 |
| | Cooling fan malfunction | Replace | E1-12 |
| | Thermostat malfunction | Replace | E1- 9 |
| | Water passage clogged | Clean | E1- 4 |
| | Water pump malfunction | Replace | E1-11 |
| Corrosion | Impurities in coolant | Replace | E1- 5 |

ENGINE COOLANT

PREPARATION

SST

| | | | |
|--|---|--|---|
| <p>49 9200 145</p> <p>Adapter set, radiator cap tester</p>  | <p>For inspection of cooling system</p> | <p>49 9200 146</p> <p>Adapter A (Part of 49 9200 145)</p>  | <p>For inspection of cooling system</p> |
|--|---|--|---|

INSPECTION

Warning

- Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

Coolant Level (Engine cold)

1. Verify that the coolant level is at the filler neck.
2. Verify that the coolant level on the coolant dipstick is between the F and L marks.
3. Add coolant if necessary.

Note

- The distance between the L and F marks on the dipstick represents 0.55 L {0.58 US qt, 0.48 Imp qt}.

Coolant Quality




1. Verify that there is no buildup of rust or scale around the radiator cap and filler neck.
2. Verify that the coolant is free of oil. Replace the coolant if necessary.


Coolant Leakage

1. Connect a radiator tester and the SST to the radiator filler neck.
2. Apply 123 kPa {1.25 kgf/cm², 17.8 psi} pressure to the system.
3. Verify that the pressure is held. If not, check for coolant leakage.

Caution

- Applying more than 123 kPa {1.25 kgf/cm², 17.8 psi} can damage the hoses, fittings and other components, and cause leaks.





Coolant Protection

Caution


- The engine has aluminum parts that can be damaged by alcohol or methanol antifreeze. Do not use alcohol or methanol in the cooling system. Use only ethylene-glycol-based coolant.
- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.

E1

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.
3. If the coolant protection is not proper, add water or coolant as necessary.

Antifreeze solution mixture percentage

| Coolant protection | Volume percentage | | Gravity at 20°C {68°F} |
|---------------------|-------------------|---------|------------------------|
| | Water | Coolant | |
| Above -16°C {3°F} | 65 | 35 | 1.054 |
| Above -26°C {-15°F} | 55 | 45 | 1.066 |
| Above -40°C {-40°F} | 45 | 55 | 1.078 |



REPLACEMENT

Draining

Warning

- Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

1. Remove the radiator cap and loosen the radiator drain plug.
2. Drain the coolant into a container.
3. Flush the cooling system with water until all traces of color are gone.
4. Let the system drain completely.
5. Tighten the drain plug.

Refilling

Use the proper amount and mixture of ethylene-glycol based coolant. (Refer to Coolant Protection, page E1-5.)

1. Slowly pour the coolant into the radiator up to the coolant filler port.

Filling pace: 1.0 L {1.1 US qt, 0.9 Imp qt}/min. max.

2. Fill the coolant reservoir up to the F mark.
3. Fully install the radiator cap.
4. Start the engine and let it idle until it warms up.
5. If the temperature increases beyond normal, there is excessive air in the system. Stop the engine and allow it to cool; then repeat steps 1—3.
6. Run the engine at 2,200—2,800 rpm for five minutes.
7. Stop the engine and allow it to cool.
8. Repeat steps 1—7; then go to step 9.

Warning

- **Removing the radiator cap or the radiator drain plug while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.**



Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.


9. Remove the radiator cap and verify that the engine coolant level is near the filler neck. If not, repeat steps 1—9.
10. Fill the reservoir up to the F mark.

RADIATOR CAP

PREPARATION
SST

| | | | |
|--|---|---|---|
| <p>49 9200 145</p> <p>Adapter set, radiator cap tester</p>  | <p>For inspection of radiator cap</p> | <p>49 9200 147</p> <p>Adapter B (Part of 49 9200 145)</p>  | <p>For inspection of radiator cap</p> |
|--|---|---|---|

E1

INSPECTION
Radiator Cap Valve

Warning


- Removing the radiator cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

1. Remove all foreign material (such as water residue) from between the radiator cap valve and the valve seat.
2. Attach the radiator cap to a radiator cap tester with the SST. Apply pressure gradually to **94—122 kPa {0.95—1.25 kgf/cm², 13.6—17.7 psi}**.
3. Verify that the pressure is held for at least **10 seconds**.

Negative Pressure Valve


1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage of the contact surfaces and for cracked and deformed seal packing.
3. Replace the radiator cap if necessary.



RADIATOR


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E1-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Fresh-air duct
2. Cooling fan motor connector
3. Condenser fan motor connector
4. Coolant reservoir pipe
5. Radiator hose (upper and lower)
6. Oil cooler hose (ATX)

7. Radiator bracket
8. Radiator
Inspection below
9. Cooling fan and radiator cowling assembly
10. Condenser fan and radiator cowling assembly



INSPECTION

Radiator

Check for the following and repair or replace as necessary.

1. Cracks, damage, and water leakage.
2. Bent fins (Repair with a screwdriver.)
3. Distorted and bent radiator inlet and outlet.


Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E1-6.)
2. Check for leaks.

THERMOSTAT


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E1-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Radiator hose, lower
2. Thermostat cover

3. Thermostat
 Inspection below
 Installation Note page E1-10



INSPECTION


Thermostat

1. Visually check that the thermostat valve is airtight.
2. Place the thermostat and a thermometer in water.
3. Heat the water and check the following.


Initial-opening temperature: 80—84°C {176—183°F}

Full-open temperature: 95°C {203°F}

Full-open lift: 8.5mm {0.33 in} min.




4. If the gasket of the thermostat is damaged, replace the thermostat assembly.



Installation Note Thermostat

1. Verify that the jiggle pin is aligned with the projection of the thermostat gasket as shown.



2. Install the thermostat and gasket into the thermostat housing, aligning the tab to the housing, as shown in the figure.


Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E1-6.)
2. Check for leaks.

WATER PUMP

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the coolant. (Refer to page E1-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




1. Timing belt
Removal / Installation section B1
2. P/S oil pump adjuster

3. Water pump assembly
Inspect for cracks, damaged mounting surface, bearing condition, and leakage
4. Water pump rubber seal

Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E1-6.)
2. Check for leaks.



COOLING FAN MOTOR

INSPECTION


1. Verify that the battery is fully charged.
2. Disconnect the cooling fan motor connector.
3. Connect battery positive voltage and an ammeter to the cooling fan motor connector.
4. Verify that current draw is as specified.

Current: 5.6—7.6A

5. If current is not within the specification or the cooling fan does not turn smoothly, replace the cooling fan motor.

REPLACEMENT

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




1. Fresh-air duct
2. Cooling fan motor connector
3. Radiator cowl

4. Cooling fan blade
5. Cooling fan motor

Steps After Installation


1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E1-6.)
2. Check for leaks.



COOLING FAN RELAY

REMOVAL

1. Disconnect the negative battery cable.
2. Remove the cooling fan relay shown in the figure.



INSPECTION

1. Check continuity of the cooling fan relay as shown.

| Terminal | Continuity |
|----------|------------|
| A—C | No |
| B—D | Yes |

2. Apply battery positive voltage between terminals B and D. Check for continuity between terminals A and C.
3. If not as specified, replace the cooling fan relay.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.


COOLING SYSTEM

(KL)

E2

| | |
|------------------------------------|-------|
| INDEX | E2- 2 |
| OUTLINE | E2- 3 |
| SPECIFICATIONS | E2- 3 |
| TROUBLESHOOTING GUIDE | E2- 3 |
| ENGINE COOLANT | E2- 4 |
| PREPARATION | E2- 4 |
| INSPECTION | E2- 4 |
| REPLACEMENT | E2- 5 |
| RADIATOR CAP | E2- 7 |
| PREPARATION | E2- 7 |
| INSPECTION | E2- 7 |
| RADIATOR | E2- 8 |
| REMOVAL / INSTALLATION | E2- 8 |
| INSPECTION | E2- 8 |
| THERMOSTAT | E2- 9 |
| REMOVAL / INSTALLATION | E2- 9 |
| INSPECTION | E2-10 |
| WATER PUMP | E2-11 |
| REMOVAL / INSTALLATION | E2-11 |
| COOLING FAN MOTOR | E2-12 |
| INSPECTION | E2-12 |
| REPLACEMENT | E2-13 |
| COOLING FAN RELAY | E2-14 |
| REMOVAL | E2-14 |
| INSPECTION | E2-14 |

INDEX



- | | | |
|--------------------------------------|------------|--|
| 1. Engine coolant | | |
| Inspection | page E2- 4 | |
| Replacement | page E2- 5 | |
| 2. Radiator cap | | |
| Inspection | page E2- 7 | |
| 3. Radiator | | |
| Removal / Installation | page E2- 8 | |
| Inspection | page E2- 8 | |
| 4. Thermostat | | |
| Removal / Installation | page E2- 9 | |
| Inspection | page E2-10 | |
| 5. Water pump | | |
| Removal / Installation | page E2-11 | |
| 6. Cooling fan motor | | |
| Inspection | page E2-12 | |
| Replacement | page E2-13 | |
| 7. Engine coolant temperature sensor | | |
| Removal / Inspection / | | |
| Installation | section F2 | |
| 8. Cooling fan relay | | |
| Removal | page E2-14 | |
| Inspection | page E2-14 | |

OUTLINE

SPECIFICATIONS

| Item | | Engine | KL | |
|------------------|----------------------------|---------------------------------|-----------------------------------|---------------------------------|
| Cooling system | | | Water-cooled, forced circulation | |
| Coolant capacity | | L {US qt, Imp qt} | 7.5 {7.9, 6.6} | |
| Water pump | Type | | Centrifugal, V-ribbed belt-driven | |
| | Water seal | | Unified mechanical seal | |
| Thermostat | Type | | Wax, bottom-bypass | |
| | Opening temperature | °C {°F} | 80—84 {176—183} | |
| | Full-open temperature | °C {°F} | 95 {203} | |
| | Full-open lift | mm {in} | 8.5 {0.33} min. | |
| Radiator | Type | | Corrugated fin | |
| | Cap valve opening pressure | kPa {kgf/cm ² , psi} | 74—102 {0.75—1.05, 10.7—14.9} | |
| Cooling fan | Type | | Electric | |
| | Blade | Outer diameter | mm {in} | 340 {13.4} |
| | | Number | | 5 |
| | Motor | Current | A | 8.0—14.0 (Low) 11.5—17.5 (High) |



E2

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|--------------------|----------------------------|-------------------|-------|
| Overheating | Coolant level insufficient | Add | E2- 4 |
| | Coolant leakage | Repair or replace | — |
| | Radiator fins clogged | Repair | E2- 8 |
| | Radiator cap malfunction | Replace | E2- 7 |
| | Cooling fan malfunction | Replace | E2-12 |
| | Thermostat malfunction | Replace | E2- 9 |
| | Water passage clogged | Clean | E2- 4 |
| | Water pump malfunction | Replace | E2-11 |
| Corrosion | Impurities in coolant | Replace coolant | E2- 5 |

ENGINE COOLANT


PREPARATION
SST

| | | | |
|--|---|--|---|
| <p>49 9200 145</p> <p>Adapter set, radiator cap tester</p>  | <p>For inspection of cooling system</p> | <p>49 9200 146</p> <p>Adapter A (Part of 49 9200 145)</p>  | <p>For inspection of cooling system</p> |
|--|---|--|---|

INSPECTION

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

**Coolant Level (Engine cold)**

1. Verify that the coolant level is at the filler neck.
2. Verify that the coolant level on the coolant dipstick is between the F and L marks.
3. Add coolant if necessary.

Note

- The distance between the L and F marks on the dipstick represents 0.5 L {0.5 US qt, 0.4 Imp qt}.

Coolant Quality



1. Verify that there is no buildup of rust or scale around the radiator cap, filler cap or filler neck.
2. Verify that coolant is free of oil. Replace the coolant if necessary.


Coolant Leakage

1. Connect a radiator tester and the SST to the radiator filler neck.
2. Apply 102 kPa {1.05 kgf/cm², 14.9 psi} pressure to the system.
3. Verify that the pressure is held. If not, check for coolant leakage.

Caution

- Applying more than 102 kPa {1.05 kgf/cm², 14.9 psi} can damage the hoses, fittings, and other components, and cause leaks.





Coolant Protection

Caution



- The engine has aluminum parts that can be damaged by alcohol or methanol antifreeze. Do not use alcohol or methanol in the cooling system. Use only ethylene-glycol-based coolant.
- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.
3. If the coolant protection is not proper, add water or coolant as necessary.

E2

Antifreeze solution mixture percentage

| Coolant protection | Volume percentage | | Gravity at 20°C {68°F} |
|---------------------|-------------------|---------|------------------------|
| | Water | Coolant | |
| Above —16°C {3°F} | 65 | 35 | 1.054 |
| Above —26°C {—15°F} | 55 | 45 | 1.066 |
| Above —40°C {—40°F} | 45 | 55 | 1.078 |



**REPLACEMENT
Draining**

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

1. Remove the filler cap and loosen the radiator drain plug.
2. Disconnect the oil cooler hoses.
3. Drain the coolant into a container.
4. Flush the cooling system with water until all traces of color are gone.
5. Let the system drain completely.
6. Tighten the drain plug and connect the oil cooler hoses.

Refilling

Use the proper amount and mixture of ethylene-glycol based coolant. (Refer to Coolant Protection, page E2-5.)

1. Slowly pour the coolant into the radiator up to the coolant filler port.

Filling pace: 1.0 L {1.1 US qt, 0.9 Imp qt}/min. max.

2. Fill the coolant reservoir up to the F mark.
3. Fully install the filler cap.
4. Start the engine and let it idle until it warms up.
5. If the temperature increases beyond normal, there is excessive air in the system. Stop the engine and allow it to cool; then repeat steps 1—3.
6. Run the engine at 2,200—2,800 rpm for five minutes.
7. Stop the engine and allow it to cool.
8. Repeat steps 1—7; then go to step 9.



Warning


- **Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.**

9. Remove the filler cap and verify that the engine coolant level is near the filler neck. If not, repeat steps 1—9.
10. Fill the reservoir up to the F mark.

RADIATOR CAP

PREPARATION
SST

| | | | |
|--|---|---|---|
| <p>49 9200 145</p> <p>Adapter set, radiator cap tester</p>  | <p>For inspection of radiator cap</p> | <p>49 9200 147</p> <p>Adapter B (Part of 49 9200 145)</p>  | <p>For inspection of radiator cap</p> |
|--|---|---|---|



INSPECTION

Radiator Cap Valve

Warning

- Removing the radiator cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.


Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn it, and remove it.

1. Remove all foreign material (such as water residue) from between the radiator cap valve and the valve seat.
2. Attach the radiator cap to a radiator cap tester with the SST. Apply pressure gradually to 74—102 kPa {0.75—1.05 kgf/cm², 10.7—14.9 psi}.
3. Verify that the pressure is held for at least 10 seconds.

Negative Pressure Valve


1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage on the contact surfaces and for cracked or deformed seal packing.
3. Replace the radiator cap if necessary.



RADIATOR


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Fresh-air duct
2. Cooling fan motor connector
3. Condenser fan motor connector
4. Coolant reservoir hose
5. Radiator hose (upper and lower)

6. Radiator bracket
7. Radiator
Inspection below
8. Cooling fan and radiator cowling assembly
9. Condenser fan and radiator cowling assembly



INSPECTION

Radiator

- Check for the following and repair or replace as necessary.
1. Cracks, damage, and water leakage.
 2. Bent fins. (Repair with a screwdriver.)
 3. Distorted and bent radiator inlet and outlet.


Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2-6.)
2. Check for leaks.

THERMOSTAT

REMOVAL / INSTALLATION


1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.



E2

1. Water inlet pipe
2. Engine harness bracket
3. Thermostat cover

4. Thermostat
 Inspection page E2-10
 Installation Note page E2-10

**INSPECTION**


1. Visually check that the thermostat valve is airtight.
2. Place the thermostat and a thermometer in water.
3. Heat the water and check the following.

Initial-opening temperature: 80—84°C {176—183°F}

Full-open temperature: 95°C {203°F}

Full-open lift: 8.5mm {0.33 in} min.

4. If the gasket of the thermostat is damaged, replace the thermostat assembly.

**Installation Note****Thermostat**

Install the thermostat into the cylinder head with the jiggle pin and projection at the top.


Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2-5.)
2. Check for leaks.

WATER PUMP

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




1. Timing belt
Removal / Installation section B2
2. No.3 engine mount bracket

3. Water pump assembly
Inspect for cracks, damaged mounting surface, bearing condition, and leakage
4. Water pump rubber seal

Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2-6.)
2. Check for leaks.




COOLING FAN MOTOR

INSPECTION

1. Verify that the battery is fully charged.
2. Disconnect the cooling fan motor connector.
3. Connect battery positive voltage and an ammeter to the cooling fan motor connector for low-speed inspection.
4. Verify that the current draw is as specified.

Current: 8.0—14.0A




5. Connect battery positive voltage and an ammeter to the cooling fan motor connector for high-speed inspection.
6. Verify that the current draw is as specified.

Current: 11.5—17.5A

7. If current is not within the specification or the cooling fan does not turn smoothly, replace the cooling fan motor.

REPLACEMENT


1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



- | | |
|------------------------------------|----------------------------------|
| 1. Fresh-air duct | 7. Condenser fan motor connector |
| 2. Radiator bracket | 8. Radiator cowl |
| 3. Coolant reservoir hose | 9. Condenser fan |
| 4. Radiator hose (upper and lower) | 10. Cooling fan |
| 5. Radiator | 11. Condenser fan motor |
| 6. Cooling fan motor connector | 12. Cooling fan motor |

Steps After Installation


1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2-6.)
2. Check for leaks.



COOLING FAN RELAY

REMOVAL

1. Disconnect the negative battery cable.
2. Remove the cooling fan relay from the place shown in the figure.



INSPECTION

1. Check continuity of the cooling fan relay as shown.

| Terminal | Continuity |
|----------|------------|
| A—C | No |
| B—D | Yes |

2. Apply battery positive voltage between terminals B and D. Check for continuity between terminals A and C.
3. If not as specified, replace the cooling fan relay.


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

FUEL AND EMISSION CONTROL SYSTEMS (FS MTX)


| | | | |
|---|-------|---|--------|
| OUTLINE | F1- 2 | EGR BOOST SENSOR SWITCHING | |
| SYSTEM DIAGRAM | F1- 2 | CONTROL SYSTEM | F1- 77 |
| VACUUM HOSE ROUTING | | SYSTEM INSPECTION | F1- 77 |
| DIAGRAM | F1- 3 | EGR BOOST SENSOR SOLENOID | |
| WIRING DIAGRAM | F1- 4 | VALVE | F1- 77 |
| SPECIFICATIONS | F1- 6 | POSITIVE CRANKCASE VENTILATION (PCV) | |
| COMPONENT DESCRIPTIONS | F1- 7 | SYSTEM | F1- 78 |
| ENGINE TUNE-UP | F1-10 | DESCRIPTION | F1- 78 |
| PREPARATION | F1-10 | PCV VALVE | F1- 78 |
| ADJUSTMENT | F1-11 | FUEL EVAPORATIVE SYSTEM | F1- 79 |
| ON-BOARD DIAGNOSTIC SYSTEM | F1-14 | DESCRIPTION | F1- 79 |
| PREPARATION | F1-14 | PREPARATION | F1- 80 |
| DIAGNOSTIC TROUBLE CODE | | SYSTEM INSPECTION | F1- 81 |
| NUMBER | F1-15 | PURGE SOLENOID VALVE | F1- 81 |
| INTAKE-AIR SYSTEM | F1-48 | FUEL VAPOR VALVE | F1- 82 |
| COMPONENT PARTS | F1-48 | CHECK VALVE (TWO-WAY) | F1- 82 |
| THROTTLE BODY | F1-49 | CHARCOAL CANISTER | F1- 82 |
| INTAKE MANIFOLD | F1-49 | FUEL-CUT CONTROL SYSTEM | F1- 83 |
| RESONANCE CHAMBER | F1-49 | DESCRIPTION | F1- 83 |
| ACCELERATOR PEDAL | F1-50 | PREPARATION | F1- 84 |
| ACCELERATOR CABLE | F1-50 | SYSTEM INSPECTION | F1- 85 |
| IDLE AIR CONTROL SYSTEM | F1-51 | A/C CUTOFF SYSTEM | F1- 86 |
| DESCRIPTION | F1-51 | DESCRIPTION | F1- 86 |
| PREPARATION | F1-52 | PREPARATION | F1- 87 |
| SYSTEM INSPECTION | F1-53 | SYSTEM INSPECTION | F1- 87 |
| IDLE AIR CONTROL VALVE | F1-54 | DECHOKE CONTROL SYSTEM | F1- 88 |
| AIR VALVE | F1-54 | SYSTEM OPERATION | F1- 88 |
| FUEL SYSTEM | F1-55 | COOLING FAN CONTROL SYSTEM .. | F1- 88 |
| DESCRIPTION | F1-55 | DESCRIPTION | F1- 88 |
| PREPARATION | F1-55 | PREPARATION | F1- 89 |
| SYSTEM INSPECTION | F1-56 | SYSTEM INSPECTION | F1- 90 |
| FUEL TANK | F1-58 | CONTROL SYSTEM | F1- 91 |
| FUEL FILTER | F1-59 | PREPARATION | F1- 91 |
| FUEL PUMP | F1-60 | STRUCTURAL VIEW | F1- 92 |
| FUEL PUMP RELAY | F1-63 | ENGINE CONTROL MODULE | F1- 93 |
| PRESSURE REGULATOR | F1-63 | MASS AIR FLOW SENSOR | F1- 99 |
| FUEL INJECTOR | F1-65 | CAMSHAFT POSITION SENSOR ... | F1-100 |
| PRESSURE REGULATOR CONTROL | | CRANKSHAFT POSITION SENSOR | F1-100 |
| SYSTEM | F1-68 | CLOSED THROTTLE POSITION | |
| DESCRIPTION | F1-68 | SWITCH | F1-101 |
| PREPARATION | F1-69 | THROTTLE POSITION SENSOR ... | F1-101 |
| SYSTEM INSPECTION | F1-70 | ENGINE COOLANT TEMPERATURE | |
| EXHAUST SYSTEM | F1-72 | SENSOR | F1-104 |
| COMPONENT PARTS | F1-72 | INTAKE AIR TEMPERATURE | |
| OUTLINE OF EMISSION CONTROL | | SENSOR | F1-105 |
| SYSTEM | F1-73 | HEATED OXYGEN SENSOR | F1-105 |
| STRUCTURAL VIEW | F1-73 | EGR VALVE POSITION SENSOR ... | F1-106 |
| EXHAUST GAS RECIRCULATION | F1-74 | EGR BOOST SENSOR | F1-107 |
| DESCRIPTION | F1-74 | CLUTCH SWITCH | F1-108 |
| OPERATION | F1-74 | NEUTRAL SWITCH | F1-108 |
| PREPARATION | F1-75 | P/S PRESSURE SWITCH | F1-109 |
| SYSTEM INSPECTION | F1-75 | MAIN RELAY | F1-109 |
| EGR SOLENOID VALVE (VACUUM) .. | F1-76 | TROUBLESHOOTING GUIDE | F1-110 |
| EGR SOLENOID VALVE (VENT) .. | F1-76 | QUICK DIAGNOSIS CHART | F1-110 |
| EGR VALVE | F1-77 | USING THIS SECTION | F1-116 |
| | | DIAGNOSTIC INDEX | F1-118 |
| | | SYMPTOM TROUBLESHOOTING .. | F1-121 |

OUTLINE

SYSTEM DIAGRAM





VACUUM HOSE ROUTING DIAGRAM



F1

WIRING DIAGRAM





F1

SPECIFICATIONS

| Item | | Engine | FS MTX |
|--|------------------------|---------------------------------|--------------------------------------|
| Idle speed | | rpm | 650—750 (700 ± 50) |
| Ignition timing*1 | | BTDC | 11—13° (12 ± 1°) |
| Throttle body | | | |
| Type | | | Horizontal draft |
| Throat diameter | | mm {in} | 55 {2.2} |
| Fuel pump | | | |
| Maximum output pressure | | kPa {kgf/cm ² , psi} | 640 {6.5, 92} |
| Fuel filter | | | |
| Type | Low-pressure side | | Nylon element (in fuel pump) |
| | High-pressure side | | Paper element |
| Pressure regulator | | | |
| Regulating pressure | | kPa {kgf/cm ² , psi} | 260—320 {2.6—3.3, 37—46} |
| Fuel injector | | | |
| Type | | | High-ohmic |
| Type of drive | | | Voltage |
| Resistance | Ω | 20°C {68°F} | 12—16 |
| Volume | ml {cc, fl oz}/15 sec. | | 47—68 {47—68, 1.4—2.0} |
| Idle air control valve | | | |
| Resistance | Ω | 23°C {73°F} | 7.7—9.3 |
| Purge solenoid valve | | | |
| Resistance | Ω | 20°C {68°F} | 30—34 |
| Pressure regulator control solenoid valve | | | |
| Resistance | Ω | 20°C {68°F} | 36—43 |
| EGR solenoid valve (vent and vacuum) | | | |
| Resistance | Ω | 20°C {68°F} | 30—45 |
| Camshaft position sensor | | | |
| Type | | | Hall effect |
| Mass air flow sensor | | | |
| Type | | | Heat resistor |
| Engine coolant temperature sensor | | | |
| Resistance | kΩ | 20°C { 68°F} | 2.20—2.70 |
| | | 80°C {176°F} | 0.29—0.35 |
| Fuel tank | | | |
| Capacity | | L {US gal, Imp gal} | 58.5 {15.5, 12.9} |
| Air cleaner element | | | |
| Element type | | | Oil permeated |
| Fuel | | | |
| Specification | | | Unleaded—(R+M)/2 method 87 or higher |

*1 TEN terminal of data link connector grounded

COMPONENT DESCRIPTIONS

| Component | Function | Remark |
|---|--|--|
| A/C relay | Controls A/C compressor magnetic clutch | — |
| Air cleaner | Filters air entering throttle body | <ul style="list-style-type: none"> • Intake air temperature sensor mounted in air cleaner |
| Air valve | Supplies bypass air into intake manifold (engine cold) | <ul style="list-style-type: none"> • Engine speed increased to shorten warm-up period • Thermowax type • Installed in BAC valve |
| Brake switch | Detects braking; sends signal to ECM | — |
| Bypass air control (BAC) valve | Supplies bypass air into intake manifold | <ul style="list-style-type: none"> • Consists of air valve and idle air control valve |
| Camshaft position sensor [SGC signal, SGT signal] | Detects No.1 cylinder TDC; sends signal to ECM (SGC signal) Detects crank angle at 180° intervals; sends signal to ECM (SGT signal) | <ul style="list-style-type: none"> • Installed in distributor |
| Charcoal canister | Stores fuel tank fumes (engine stopped) | — |
| Check valve (two-way) | Controls pressure in fuel tank | — |
| Closed throttle position switch | Detects idle condition; sends signal to ECM | <ul style="list-style-type: none"> • Installed in throttle body |
| Clutch switch | Detects clutch condition; sends signal to ECM | <ul style="list-style-type: none"> • Switch OFF when clutch pedal released |
| Crankshaft position sensor | Detects crank angle via crankshaft pulley rotation, and sends signal to ECM | <ul style="list-style-type: none"> • NE signal |
| Data link connector | Concentrated service connector terminals for serviceability 1. Initial set 2. Fuel pump check 3. Engine speed output 4. CIS self-diagnosis (serial communication) 5. Supply battery positive voltage 6. Ground | <ul style="list-style-type: none"> • 25-pin (located near battery) 1. TEN terminal 2. F/P terminal 3. IG- terminal 4. KLN terminal 5. +B terminal 6. GND terminal |
| Data link connector-2 | Concentrated service connector terminals for diagnosis of electrical system | <ul style="list-style-type: none"> • For on-board diagnosis and service/inspection |
| EGR boost sensor | Detects EGR pipe pressure or barometric pressure and sends signal to ECM | <ul style="list-style-type: none"> • For EGR check control |
| EGR boost sensor solenoid valve | Supplies/cuts off EGR pipe pressure or barometric pressure to EGR boost sensor | <ul style="list-style-type: none"> • For EGR check control |
| EGR valve | Recirculates portion of exhaust gas | — |
| EGR solenoid valves | Controls vacuum to EGR valve | — |
| EGR valve position sensor | Detects EGR valve position | <ul style="list-style-type: none"> • Installed in EGR valve |

F1

| Component | Function | Remark |
|--|---|--|
| Engine control module | <p>Detects the following:</p> <ol style="list-style-type: none"> 1. A/C operation 2. Air/fuel ratio (oxygen concentration) 3. Braking signal 4. Crankshaft position 5. E/L operation 6. Engine coolant temperature 7. Engine speed 8. Ignition ON signal 9. In-gear condition 10. Intake air amount 11. Intake air temperature 12. No.1 piston TDC (compression stroke) 13. P/S operation 14. Diagnostic test mode signal (ignition timing, idle speed, diagnostic trouble code no.) 15. Throttle valve opening angle 16. Throttle valve closed throttle position 17. Vehicle speed <p>Controls operation of following:</p> <ol style="list-style-type: none"> 1. A/C (cut-off) 2. On-board diagnostic system 3. Fuel injection system 4. Idle speed control 5. Ignition system 6. Purge control system 7. Exhaust gas recirculation 8. Pressure regulator control system 9. Cooling fan control 10. Fuel pump control | <ol style="list-style-type: none"> 1. Air conditioning switch 2. Heated oxygen sensor 3. Brake light switch 4. Crankshaft position sensor (NE signal) 5. Fan switch, cooling fan relay, headlight switch, and rear window defroster switch 6. Engine coolant temperature sensor 7. Camshaft position sensor (SGT signal) 8. Ignition switch 9. Neutral and clutch switch 10. Mass air flow sensor 11. Intake air temperature sensor 12. Camshaft position sensor (SGC signal) 13. P/S pressure switch 14. Data link connector (TEN terminal) 15. Throttle position sensor 16. Closed throttle position switch 17. Vehicle speed sensor <ol style="list-style-type: none"> 1. A/C relay 2. NGS 3. Fuel injector 4. Idle air control valve 5. Ignition control module 6. Purge solenoid valve 7. EGR solenoid valves 8. PRC solenoid valve 9. Cooling fan relay 10. Fuel pump relay |
| Engine coolant temperature sensor | Detects coolant temperature; sends signals to ECM | <ul style="list-style-type: none"> • Installed in engine |
| Fuel filter | Filters particles from fuel | — |
| Fuel injector | Injects fuel into intake port | <ul style="list-style-type: none"> • Controlled by signals from ECM |
| Fuel pump | Provides fuel to fuel injectors | <ul style="list-style-type: none"> • Operates while engine is running • Installed in fuel tank |
| Fuel pump relay | Voltage for fuel pump while engine is running, controlled by ECM | — |
| Fuel vapor valve | Prevents fuel from flowing into charcoal canister | — |
| Heated oxygen sensor | Detects oxygen concentration; sends signal to ECM | <ul style="list-style-type: none"> • Zirconic and platinum coating • With heater |
| Idle air control valve | Supplies bypass air to intake manifold | <ul style="list-style-type: none"> • Controlled by duty signal from ECM • Installed in BAC valve |
| Ignition control module | Receives spark signal from ECM and generates high voltage in ignition coil | <ul style="list-style-type: none"> • Installed in distributor |
| Intake manifold | Supplies intake air to all cylinders | — |
| Intake air temperature sensor | Detects intake air temperature; sends signal to ECM | <ul style="list-style-type: none"> • Installed in air cleaner |









| Component | Function | Remark |
|--------------------------------------|--|---|
| Main relay | Supplies current to output devices and ECM | — |
| Mass air flow sensor | Detects amount of intake air; sends signal to ECM | • Heat resistor type |
| Neutral switch | Detects in-gear condition; sends signal to ECM | • Switch ON in neutral |
| PCV valve | Controls blowby gas introduced into engine | — |
| Pressure regulator | Adjusts fuel pressure supply to fuel injectors | — |
| Pressure regulator valve | Controls vacuum to pressure regulator | — |
| Purge solenoid valve | Controls evaporative fumes from charcoal canister to intake manifold | • Controlled by duty signal from ECM |
| P/S pressure switch | Detects P/S operation; sends signal to ECM | • P/S pressure switch ON when steering wheel turned |
| Resonance chamber | Reduces intake air suction noise and increases engine torque | — |
| Three way catalytic converter | Reduces HC, CO, NOx by chemical reaction | • Monolith type |
| Throttle body | Controls intake air amount | — |
| Throttle position sensor | Detects throttle valve opening angle; sends signal to ECM | • Installed on throttle body |
| Vehicle speed sensor | Detects vehicle speed; sends signal to ECM | • Installed in instrument cluster |

F1

ENGINE TUNE-UP


PREPARATION

SST


| | | | |
|--|---|--|---|
| <p>49 B019 9A0</p> <p>System Selector</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 0A0</p> <p>NGS set</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 010B</p> <p>Program Card</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 008A</p> <p>Instruction Manual</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 002</p> <p>Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 001</p> <p>Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 004</p> <p>NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 006</p> <p>Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |

ADJUSTMENT**Preparation**

1. Warm up the engine to normal operating temperature.
2. Shift the transaxle into Neutral.
3. Turn off all electrical loads.
 - Headlight
 - Blower
 - Rear window defroster
 - Power steering
4. Wait until the cooling fan stops.




5. Connect the **SST** (NGS) to the data link connector-2 and select the "PID/DATA MONITOR AND RECORD" function. (Refer to page F1-94.)

**Ignition Timing**

1. Perform Preparation. (Refer to above.)
2. Verify that the idle speed is within the specification.


Idle speed: 650—750 (700 ± 50) rpm

3. If not within the specification, adjust the idle speed. (Refer to page F1-12.)




4. Connect the **SST** (System Selector) to the data link connector.
5. Set switch A to position 1.
6. Set the test switch to SELF TEST.
7. Verify that the idle speed is within the specification.

Idle speed (SELF TEST MODE): 500—800 rpm



8. Connect a timing light to the high-tension lead of No.1 cylinder.
9. Verify that the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition timing: BTDC 11—13° (12 ± 1°)




10. If the marks are not aligned, loosen the distributor lock bolts and turn the distributor to make the adjustment.
11. Tighten the distributor lock bolts to the specified torque.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

12. Disconnect the **SSTs**.
13. Verify that the ignition timing is within the specification.


Ignition timing: BTDC 6—18°




Idle Speed

1. Perform Preparation. (Refer to page F1-11.)
2. Verify that the idle speed is within the specification.

Idle speed (Neutral): 650—750 (700 ± 50) rpm



3. If not within the specification, connect the **SST** (System Selector) to the data link connector.
4. Set switch A to position 1.
5. Set the test switch to **SELF TEST**.



6. Adjust the idle speed by turning the air adjusting screw.

**Idle speed (SELF TEST MODE):
500—800 rpm**

Caution

- The throttle adjusting screw is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

7. Disconnect the **SSTs**.

Idle-up Speed

1. Perform Preparation. (Refer to page F1-11.)
2. Verify that the idle speed is within the specification.

Specification: 650—750 (700 ± 50) rpm

3. If not within the specification, adjust the idle speed.
4. Check the idle speed with the following load conditions.

| Load condition | Idle speed (rpm) |
|---------------------------------|------------------|
| No load | 650—750 |
| Cooling fan ON | 725—825 |
| Fan switch ON at 3rd or higher | 725—825 |
| Head light switch ON | 725—825 |
| Rear window defroster switch ON | 725—825 |
| P/S ON | 650—750 |
| A/C ON | 725—825 |








Note


- Excludes temporary idle speed drop just after the electrical loads are turned ON.

5. If not as specified with all load conditions, inspect the idle air control valve.
If not as specified with any one of load conditions, check related input switches, harnesses and connectors.

ON-BOARD DIAGNOSTIC SYSTEM

PREPARATION SST


| | | | |
|---|--|---|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For diagnosis of ECM and input/output systems</p> | <p>49 T088 010B Program Card</p>  | <p>For diagnosis of ECM and input/output systems</p> |
| <p>49 T088 008A Instruction Manual</p>  | <p>For diagnosis of ECM and input/output systems</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For diagnosis of ECM and input/output systems</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For diagnosis of ECM and input/output systems</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of ECM and input/output systems</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of ECM and input/output systems</p> | <p>—</p> | <p>—</p> |



DIAGNOSTIC TROUBLE CODE NUMBER

Inspection

1. Connect the **SST** (NGS) to the data link connector-2. (Refer to page F1-94.)
2. Refer to the manufacturer-provided instruction manual for the NGS operation.
3. Select "DIAGNOSTIC TROUBLE CODES" function and press trigger.
4. When "NO CODES RECEIVED/SYSTEM PASSED" is displayed, all systems monitored are judged OK.
5. When any of the diagnostic trouble codes is displayed, carry out troubleshooting according to the code.
6. When "LINK MONITOR ERROR" is displayed, check connection of the NGS.
7. After all problems have been repaired, carry out "After Repair Procedure." (Refer to below.)







After-repair Procedure


1. After repairs, connect the **SST** (NGS) to the data link connector-2. (Refer to page F1-94.)
2. Select "CLEAR" function and erase diagnostic trouble codes from the NGS memory.
3. Perform diagnostic trouble code inspection again and verify that no diagnostic trouble codes are displayed.






Service Code Numbers





| Code No. | Display on the NGS | Condition | Page |
|----------|---------------------------------------|--|-------|
| P0100 | MAF/VAF—CIRCUIT MALFUNCTION | Mass air flow circuit malfunction | F1-18 |
| P0110 | IAT—CIRCUIT MALFUNCTION | Intake air temperature circuit malfunction | F1-19 |
| P0115 | ECT—CIRCUIT MALFUNCTION | Engine coolant temperature circuit malfunction | F1-20 |
| P0120 | TP—CIRCUIT MALFUNCTION | Throttle position circuit malfunction | F1-21 |
| P0125 | EXCESSIVE TIME TO ENTER CLOSED LOOP | Excessive time to enter closed loop fuel control | F1-22 |
| P0130 | O2S 11—CIRCUIT MALFUNCTION | O ₂ sensor circuit malfunction | F1-22 |
| P0134 | O2S 11—CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F1-23 |
| P0135 | O2S 11—HEATER CIRCUIT MALFUNCTION | O ₂ sensor heater circuit malfunction | F1-24 |
| P0140 | O2S 12—CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F1-25 |
| P0170 | BANK1—FUEL TRIM MALFUNCTION | Fuel trim malfunction | F1-26 |
| P0300 | RANDOM MISFIRE DETECTED | Random misfire detected | F1-27 |
| P0301 | CYLINDER 1 MISFIRE DETECTED | Cylinder 1 misfire detected | F1-28 |
| P0302 | CYLINDER 2 MISFIRE DETECTED | Cylinder 2 misfire detected | F1-29 |
| P0303 | CYLINDER 3 MISFIRE DETECTED | Cylinder 3 misfire detected | F1-30 |
| P0304 | CYLINDER 4 MISFIRE DETECTED | Cylinder 4 misfire detected | F1-31 |
| P0335 | CRANKSHAFT POS SENSOR—CKT MALFUNCTION | Crankshaft position sensor circuit malfunction | F1-32 |
| P0340 | CAMSHAFT POS SENSOR—CKT MALFUNCTION | Camshaft position sensor circuit malfunction | F1-32 |
| P0400 | EGR—FLOW MALFUNCTION | Exhaust gas recirculation flow malfunction | F1-33 |
| P0420 | BANK 1 CAT EFFICIENCY BELOW LIMIT | Catalyst system efficiency below threshold | F1-34 |


| Code No. | Display on the NGS | Condition | Page |
|----------|--|---|-------|
| P0440 | EVAP SYSTEM—MALFUNCTION | Evaporative emission control system malfunction | F1-34 |
| P0443 | EVAP SYSTEM—PURGE CTRL VALVE CKT MALF | Evaporative emission control system purge control valve circuit malfunction | F1-35 |
| P0500 | VEHICLE SPEED SENSOR—MALFUNCTION | Vehicle speed sensor malfunction | F1-35 |
| P0505 | IDLE CONTROL SYSTEM MALFUNCTION | Idle air control system malfunction | F1-36 |
| P0510 | CLOSED THROTTLE POS SWITCH—MALFUNCTION | Closed throttle position switch malfunction | F1-37 |
| P0703 | TORQUE CONV/BRAKE SW—MALFUNCTION | Brake switch input malfunction | F1-38 |
| P1000 | MORE DRIVING NEEDED TO COMPLETE TEST | Check of all OBD-II systems is not complete since last memory order | F1-38 |
| P1170 | HO2S 11—INVERSION | Heated oxygen sensor (Front) (Stuck) | F1-39 |
| P1195 | EGRBS—OPEN OR SHORT | EGR boost sensor open or short | F1-40 |
| P1250 | PRC—OPEN OR SHORT | PRC solenoid valve open or short | F1-41 |
| P1345 | SGC SIGNAL—NO SGC SIGNAL | No SGC signal | F1-42 |
| P1402 | EGRS—OPEN OR SHORT | EGR valve position sensor open or short | F1-43 |
| P1485 | EGR (VACUUM)—OPEN OR SHORT | EGR solenoid valve (vacuum) open or short | F1-44 |
| P1486 | EGR (VENT)—OPEN OR SHORT | EGR solenoid valve (vent) open or short | F1-45 |
| P1487 | EGRCHK SOL—OPEN OR SHORT | EGR boost sensor solenoid valve | F1-46 |
| P1608 | PCME (CPU)—MALFUNCTION | ECM malfunction | F1-46 |
| P1794 | BAT—BAT OR CIRCUIT FAIL | Battery or circuit malfunction | F1-47 |
| P1797 | PNS—OPEN OR SHORT | Neutral/clutch switch open or short | F1-47 |

| Diagnostic trouble code No. P0100 | | MAF/VAF—CIRCUIT MALFUNCTION | |
|---|---|--|--|
| Symptom | | Input voltage from mass air flow sensor is below 0.1 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Mass air flow sensor malfunction • Open or short circuit in wiring from main relay terminal F to mass air flow sensor terminal C • Open or short circuit in wiring from ECM terminal 3B to mass air flow sensor terminal B • Open circuit in wiring from ECM terminal 4A to mass air flow sensor terminal A | |
| STEP | INSPECTION | | ACTION |
| 1 | Does mass air flow sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3B voltage OK?  page F1-96 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect mass air flow sensor connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Mass air flow sensor terminal C) |
| 4 | Is there continuity between connector terminal A and ECM terminal 4A? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminal B and ECM terminal 3B? | Yes | Replace mass air flow sensor  page F1-48 |
| | | No | Repair or replace wiring harness |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |




| Diagnostic trouble code No. P0110 | | IAT—CIRCUIT MALFUNCTION | |
|---|---|---|---|
| Symptom | | Input from intake air temperature sensor is below 0.1 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Intake air temperature sensor malfunction • Open or short circuit in wiring from intake air temperature sensor terminal A to ECM terminal 3K • Open or short circuit in wiring from intake air temperature sensor terminal B to ECM terminal 3O | |
| STEP | INSPECTION | | ACTION |
| 1 | Does intake air temperature sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3K voltage OK? 🔗 page F1-97 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect intake air temperature sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 3K — Intake air temperature sensor terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 3O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is intake air temperature sensor OK? 🔗 page F1-105 | Yes | Go to next step |
| | | No | Replace intake air temperature sensor 🔗 page F1-105 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM 🔗 page F1-93 |
| | | No | Intermittent poor connection of harness of connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P0115 | | ECT—CIRCUIT MALFUNCTION | |
|---|--|---|---|
| Symptom | | Input voltage from engine coolant temperature sensor is below 0.2 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Open or short circuit in wiring from engine coolant temperature sensor terminal A to ECM terminal 3G • Open or short circuit in wiring from engine coolant temperature sensor terminal B to ECM terminal 3O | |
| STEP | INSPECTION | ACTION | |
| 1 | Does engine coolant temperature sensor or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3G voltage OK?  page F1-96 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect engine coolant temperature sensor connector. Turn ignition switch ON. Is there 5 V at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 3G — Engine coolant temperature sensor terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 3O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is engine coolant temperature sensor OK?  page F1-104 | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor  page F1-104 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | | | |
|--|---|---|--|
| Diagnostic trouble code No. P0120 | | TP—CIRCUIT MALFUNCTION | |
| Symptom | | Input voltage from throttle position sensor is below 0.1 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Throttle position sensor malfunction • Open or short circuit in wiring from throttle position sensor terminal A to ECM terminal 3I • Open or short circuit in wiring from throttle position sensor terminal B to ECM terminal 3F • Open or short circuit in wiring from throttle position sensor terminal C to ECM terminal 3O | |
| STEP | INSPECTION | ACTION | |
| 1 | Does throttle position sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3F voltage OK?  page F1-96 | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Is voltage increase linear according to throttle valve opening angle? | Yes | Go to step 7 |
| | | No | Replace throttle position sensor  page F1-104 |
| 4 | Disconnect throttle position sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 3I — Throttle position sensor terminal A) |
| 5 | Is there continuity between connector terminal C and ECM terminal 3O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 6 | Is there continuity between connector terminal A and ECM terminal 3I? | Yes | Replace throttle position sensor  page F1-104 |
| | | No | Repair or replace wiring harness |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |




HARNESS SIDE CONNECTOR

| | | | |
|--|---|-----|---|
| Diagnostic trouble code No. P0125 | EXCESSIVE TIME TO ENTER CLOSED LOOP | | |
| Symptom | Engine coolant temperature sensor signal does not rise normally because of engine coolant system malfunction | | |
| Possible cause | <ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Thermostat malfunction • Cooling fan system malfunction • Water pump malfunction • Engine coolant passage clogged or leaks • Engine coolant level and protection | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is electric fan control system OK? | Yes | Go to next step |
| | | No | Repair or replace cooling fan system |
| 2 | Is engine coolant temperature sensor resistance OK?  page F1-104 | Yes | Go to next step |
| | | No | Replace engine cooling temperature sensor |
| 3 | Is cooling system OK?  section E1 | Yes | Go to next step |
| | | No | Repair or replace |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Temporary system malfunction |





* During normal driving


| | | | |
|--|--|-----|--------------------------------------|
| Diagnostic trouble code No. P0130 | HO2S 11—CIRCUIT MALFUNCTION | | |
| Symptom | • Heated oxygen sensor (Front) deterioration | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Front) OK? | Yes | Replace ECM |
| | | No | Replace heated oxygen sensor (Front) |

| | | | |
|--|---|--|--|
| Diagnostic trouble code No. P0134 | | O2S 11—CIRCUIT NO ACTIVITY DETECTED | |
| Symptom | | When heated oxygen sensor (Front) signal does not exceed 0.5 V after engine is started, or stays below 0.5 V for two minutes after engine has reached normal operating temperature and running at 1,500 rpm or over | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal A to ECM terminal 3C • Intake-air system, fuel system, ignition system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Front) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3C voltage OK? ☞ page F1-96 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front) connector. Is there continuity between connector terminal A and ECM terminal 3C? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? Fuel injector ☞ page F1-65 Pressure regulator ☞ page F1-63 Mass air flow sensor ☞ page F1-99 Engine coolant temperature sensor ☞ page F1-104 Spark plug ☞ section G Air suction (Air/Fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front) ☞ page F1-72 |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |










HARNESS SIDE CONNECTOR

| Diagnostic trouble code No. P0135 | | O2S 11—HEATER CIRCUIT MALFUNCTION | |
|---|--|---|---|
| Symptom | | Open or short circuit is observed in heated oxygen sensor heater (Front) system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor heater (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal C to ignition switch • Open or short circuit in wiring from heated oxygen sensor (Front) terminal B to ECM terminal 3M | |
| STEP | INSPECTION | ACTION | |
| 1 | Does heated oxygen sensor (Front) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3M voltage OK?  page F1-97 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front) connector and turn ignition switch to ON. Is there battery positive voltage at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Ignition switch — Heated oxygen sensor (Front) terminal C) |
| 4 | Is there continuity between connector terminal B and ECM terminal 3M? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminals B and C? | Yes | Go to next step |
| | | No | Replace heated oxygen sensor (Front)  page F1-72 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  | | | |
| HARNESS SIDE CONNECTOR | | | |

| | | | |
|---|--|---|--|
| Diagnostic trouble code No. P0140 | | O2S 12—CIRCUIT NO ACTIVITY DETECTED | |
| Symptom | | When heated oxygen sensor (Rear) signal does not exceed 0.5 V after engine is started, or stays below 0.5 V for five minutes after engine has reached normal operating temperature and running at 1,500 rpm or over | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor (Rear) malfunction • Open or short circuit in wiring from heated oxygen sensor (Rear) terminal A to ECM terminal 3D • Open circuit in wiring from heated oxygen sensor (Rear) terminal B to ECM terminal 3O • Intake-air system, fuel system or ignition system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Rear) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3D voltage OK? 🔧 page F1-96 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Rear) connector. Is there continuity between connector terminal B and ECM terminal 3O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between connector terminal A and ECM terminal 3D? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Are following units OK? Fuel injector 🔧 page F1-65 Pressure regulator 🔧 page F1-63 Mass air flow sensor 🔧 page F1-99 Engine coolant temperature sensor 🔧 page F1-104 Spark plug 🔧 section G Air suction (Air/fuel ratio rich) | Yes | Replace heated oxygen sensor (Rear) 🔧 page F1-72 |
| | | No | Repair or replace |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM 🔧 page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P0170 | | BANK1—FUEL TRIM MALFUNCTION | |
|-----------------------------------|---|--|--|
| Symptom | | Air/fuel ratio stays rich or lean longer than specified period because of system malfunction | |
| Possible cause | | <ul style="list-style-type: none"> • Pressure regulator malfunction • Fuel injector malfunction • Fuel pump malfunction • Engine coolant temperature sensor malfunction • Mass air flow sensor malfunction • Heated oxygen sensor malfunction • Throttle position sensor • Closed throttle position switch • Purge solenoid valve malfunction • Leakage in intake-air system • ECM malfunction • Open or short circuit in wiring between ECM terminals 4U, 4V, 4W, 4X to fuel injector • Intake air temperature sensor malfunction • EGR boost sensor malfunction • PCV valve malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there air leakage in intake-air system components? 🔧 page F1-48 | Yes | Repair or replace intake-air system |
| | | No | Go to next step |
| 2 | Is fuel line pressure OK? 🔧 page F1-57 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is fuel pump maximum pressure OK? 🔧 page F1-61 | Yes | Go to next step |
| | | No | Repair or replace fuel pump 🔧 page F1-62 |
| 4 | Is pressure regulator OK? 🔧 page F1-63 | Yes | Go to next step |
| | | No | Replace pressure regulator 🔧 page F1-64 |
| 5 | Is fuel injector OK? 🔧 page F1-65 | Yes | Go to next step |
| | | No | Replace fuel injector 🔧 page F1-65 |
| 6 | Is engine coolant temperature sensor OK? 🔧 page F1-104 | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor 🔧 page F1-104 |
| 7 | Is mass air flow sensor OK? 🔧 page F1-99 | Yes | Go to next step |
| | | No | Replace mass air flow sensor 🔧 page F1-48 |
| 8 | Is throttle position sensor OK? 🔧 page F1-101 | Yes | Go to next step |
| | | No | Adjust throttle position sensor 🔧 page F1-102 |
| 9 | Is closed throttle position switch OK? 🔧 page F1-101 | Yes | Go to next step |
| | | No | Replace throttle body 🔧 page F1-48 |
| 10 | Is intake air temperature sensor OK? 🔧 page F1-105 | Yes | Go to next step |
| | | No | Replace intake air temperature sensor 🔧 page F1-105 |
| 11 | Is EGR boost sensor OK? 🔧 page F1-107 | Yes | Go to next step |
| | | No | Replace EGR boost sensor 🔧 page F1-92 |
| 12 | Is purge solenoid valve OK? 🔧 page F1-81 | Yes | Go to next step |
| | | No | Replace purge solenoid valve 🔧 page F1-81 |
| 13 | Is PCV valve OK? 🔧 page F1-78 | Yes | Go to next step |
| | | No | Replace PCV valve |
| 14 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM 🔧 page F1-93 |
| | | No | Temporary system malfunction |

* During Idling

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0300 | | RANDOM MISFIRE DETECTED | |
| Symptom | | ECM input signal from crankshaft position sensor signal is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system malfunction • Low fuel • Low battery positive voltage • Fuel system malfunction • Insufficient compression • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system OK?  section G | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is crankshaft position sensor air gap correct?  page F1-100 | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor  page F1-101 |
| 3 | Is fuel system OK?  page F1-55 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 4 | Is exhaust gas recirculation control system OK?  page F1-74 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is compression at all cylinders normal?  section B1 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|-----|---|
| Diagnostic trouble code No. P0301 | CYLINDER 1 MISFIRE DETECTED | | |
| Symptom | ECM input signal from crankshaft position sensor signal for cylinder No.1 is irregular | | |
| Possible cause | <ul style="list-style-type: none"> • Ignition system of cylinder No.1 malfunction • Low fuel • Low battery positive voltage • Fuel system malfunction • Insufficient compression in cylinder No.1 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.1 OK? ☞ section G | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is crankshaft position sensor air gap OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor ☞ page F1-101 |
| 3 | Is fuel injector at cylinder No.1 OK? ☞ page F1-65 | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.1 ☞ page F1-65 |
| 4 | Is fuel system OK? ☞ page F1-55 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is exhaust gas recirculation control system OK? ☞ page F1-74 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is compression at cylinder No.1 normal? ☞ section B1 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|-----|---|
| Diagnostic trouble code No. P0302 | CYLINDER 2 MISFIRE DETECTED | | |
| Symptom | ECM input signal from crankshaft position sensor signal for cylinder No.2 is irregular | | |
| Possible cause | <ul style="list-style-type: none"> • Ignition system of cylinder No.2 malfunction • Low fuel • Low battery positive voltage • Fuel system malfunction • Insufficient compression in cylinder No.2 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.2 OK? 🔗 section G | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is crankshaft position sensor air gap OK? 🔗 page F1-100 | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor 🔗 page F1-101 |
| 3 | Is fuel injector at cylinder No.2 OK? 🔗 page F1-65 | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.2 🔗 page F1-65 |
| 4 | Is fuel system OK? 🔗 page F1-55 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is exhaust gas recirculation control system OK? 🔗 page F1-74 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is compression at cylinder No.2 normal? 🔗 section B1 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM 🔗 page F1-93 |
| | | No | Temporary system malfunction |


* During normal driving


| | | | |
|--|--|--|---|
| Diagnostic trouble code No. P0303 | | CYLINDER 3 MISFIRE DETECTED | |
| Symptom | | ECM input signal from crankshaft position sensor signal for cylinder No.3 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.3 malfunction • Low fuel • Low battery positive voltage • Fuel system malfunction • Insufficient compression in cylinder No.3 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Is ignition system of cylinder No.3 OK? ☞ section G | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is crankshaft position sensor air gap OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor ☞ page F1-101 |
| 3 | Is fuel injector at cylinder No.3 OK? ☞ page F1-65 | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.3 ☞ page F1-65 |
| 4 | Is fuel system OK? ☞ page F1-55 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is exhaust gas recirculation control system OK? ☞ page F1-74 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is compression at cylinder No.3 normal? ☞ section B1 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|-----|---|
| Diagnostic trouble code No. P0304 | CYLINDER 4 MISFIRE DETECTED | | |
| Symptom | ECM input signal from crankshaft position sensor signal for cylinder No.4 is irregular | | |
| Possible cause | <ul style="list-style-type: none"> • Ignition system of cylinder No.4 malfunction • Low fuel • Low battery positive voltage • Fuel system malfunction • Insufficient compression in cylinder No.4 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.4 OK? ☞ section G | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is crankshaft position sensor air gap OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor ☞ page F1-101 |
| 3 | Is fuel injector at cylinder No.4 OK? ☞ page F1-65 | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.4 ☞ page F1-65 |
| 4 | Is fuel system OK? ☞ page F1-55 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is exhaust gas recirculation control system OK? ☞ page F1-74 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is compression at cylinder No.4 normal? ☞ section B1 | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Temporary system malfunction |

* During normal driving

| Diagnostic trouble code No. P0335 | | CRANKSHAFT POS SENSOR—CKT MALFUNCTION | |
|--|--|--|--|
| Symptom | | No NE signal input from crankshaft position sensor for 1.5 seconds while engine running | |
| Possible cause | | <ul style="list-style-type: none"> • Crankshaft position sensor malfunction • Open or short circuit in wiring from ECM terminal 4E to crankshaft position sensor terminal B • Open or short circuit in wiring from ECM terminal 4H to crankshaft position sensor terminal A | |
| STEP | INSPECTION | | ACTION |
| 1 | Does crankshaft position sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect crankshaft position sensor connector. Is there continuity between connector terminal B and ECM terminal 4E? Is there continuity between connector terminal A and ECM terminal 4H? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 3 | Is crankshaft position sensor air gap OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Replace crankshaft position sensor or crankshaft pulley ☞ page F1-101 ☞ section B1 |
| 4 | Is crankshaft position sensor OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Replace crankshaft position sensor ☞ page F1-101 |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P0340 | | CAMSHAFT POS SENSOR—CKT MALFUNCTION | |
|---|---|--|--|
| Symptom | | No SGT signal input from camshaft position sensor for 1.5 seconds while engine running | |
| Possible cause | | <ul style="list-style-type: none"> • Camshaft position sensor malfunction • Open or short circuit in wiring from ECM terminal 4F to distributor terminal C • Open or short circuit in wiring from ECM terminal 4A to distributor terminal A | |
| STEP | INSPECTION | | ACTION |
| 1 | Does distributor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect distributor connector. Is there continuity between connector terminal C and ECM terminal 4F? Is there continuity between connector terminal A and ECM terminal 4A? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 3 | Is camshaft position sensor OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Replace distributor ☞ section G |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| | | | |
|--|---|---|---|
| Diagnostic trouble code No. P0400 | | EGR—FLOW MALFUNCTION | |
| Symptom | | Exhaust gas recirculation system does not function normally because of electrical or mechanical trouble | |
| Possible cause | | <ul style="list-style-type: none"> • EGR valve malfunction • EGR boost sensor malfunction • EGR boost sensor solenoid valve malfunction • EGR valve position sensor malfunction • EGR solenoid valve (vacuum, vent) malfunction • Clogs or leakage in piping connecting following units • EGR boost sensor, EGR boost sensor solenoid valve and intake manifold • Air cleaner, EGR solenoid valve (vent) and EGR valve • Intake manifold, EGR solenoid valve (vacuum) and EGR valve • Warm up three way catalytic converter | |
| STEP | INSPECTION | | ACTION |
| 1 | Is diagnostic trouble code for EGR solenoid valve (vacuum, vent), EGR boost sensor solenoid valve or EGR boost sensor displayed? | Yes | Carry out inspection as required according to diagnostic trouble code |
| | | No | Go to next step |
| 2 | Is EGR valve position sensor OK? ☞ page F1-106 | Yes | Go to next step |
| | | No | Repair or replace EGR valve ☞ page F1-77 |
| 3 | Check each hose for damage. Are they OK? • Intake manifold—EGR solenoid valve (vent) • EGR solenoid valve (vent)—EGR solenoid valve (vacuum) • EGR solenoid valve (vacuum)-EGR valve | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 4 | EGR boost sensor OK? ☞ page F1-107 | Yes | Go to next step |
| | | No | Replace EGR boost sensor ☞ page F1-92 |
| 5 | Check each hose for damage. Are they OK? • EGR passage—EGR boost sensor solenoid valve • EGR boost sensor—EGR boost sensor solenoid valve | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Temporary system malfunction |

* During driving when coolant temperature is over 55°C {131°F} and engine speed is over 1,000 rpm [10 km/h {6.2 mph}]





| | | | |
|--|---|--|---|
| Diagnostic trouble code No. P0420 | | BANK1 CAT—EFFICIENCY BELOW LIMIT | |
| Symptom | | <ul style="list-style-type: none"> • Warm up three way catalytic converter deterioration • Leakage in exhaust system | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Rear) OK? ☞ page F1-105 | Yes | Replace warm up three way catalytic converter ☞ page F1-72 |
| | | No | Replace heated oxygen sensor (Rear) ☞ page F1-72 |


| | | | |
|--|---|---|--------------------------------|
| Diagnostic trouble code No. P0440 | | EVAP SYSTEM—MALFUNCTION | |
| Symptom | | Evaporative emission control system does not function normally because of mechanical trouble | |
| Possible cause | | <ul style="list-style-type: none"> • Purge solenoid valve malfunction • Charcoal canister malfunction • Check valve malfunction • Fuel vapor valve malfunction • Clogs or leakage in piping connecting following units • Intake manifold and purge solenoid valve • Purge solenoid valve and charcoal canister • Charcoal canister, check valve, and fuel vapor valve | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ECM terminal 4T voltage OK? | Yes | Go to next step |
| | | No | Inspect purge solenoid valve |
| 2 | Are evaporative emission control system related hose free of clogs and leakage? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 3 | Is charcoal canister OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 4 | Is check valve OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is fuel vapor valve OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace ECM |
| | | No | Temporary system malfunction |




* During driving after engine warm-up

| Diagnostic trouble code No. P0443 | | EVAP SYSTEM—PURGE CTRL VALVE CKT MALF | |
|---|---|--|--|
| Symptom | | Open or short circuit is observed in purge solenoid valve system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Purge solenoid valve malfunction • Open or short circuit in wiring from purge solenoid valve terminal A to main relay terminal F • Open or short circuit in wiring from purge solenoid valve terminal B to ECM terminal 4T | |
| STEP | INSPECTION | ACTION | |
| 1 | Does purge solenoid valve connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4T voltage OK? 🔍 page F1-98 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect purge solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Purge solenoid valve terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4T? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between purge solenoid valve terminals A and B? | Yes | Go to next step |
| | | No | Replace purge solenoid valve |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM 🔍 page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNES SIDE CONNECTOR</p> | | | |


| Diagnostic trouble code No. P0500 | | VEHICLE SPEED SENSOR—MALFUNCTION | |
|--|--|---|--|
| Symptom | | No vehicle speed sensor signal input from vehicle speed sensor while driving | |
| Possible cause | | <ul style="list-style-type: none"> • Speedometer sensor malfunction • Open or short circuit in wiring from ignition switch to speedometer sensor • Open or short circuit in wiring from speedometer sensor to GND • Open or short circuit in wiring from speedometer sensor to vehicle speed sensor • Open or short circuit in wiring from vehicle speed sensor to ECM terminal 1M | |
| STEP | INSPECTION | ACTION | |
| 1 | Does vehicle speed sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 1M voltage OK? 🔍 page F1-96 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is there continuity between vehicle speed sensor terminal and ECM terminal 1M? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between vehicle speed sensor and speedometer sensor terminals? 🔍 Mazda 1996 626/MX-6 BETM | Yes | Go to next step |
| | | No | Repair or replace speedometer sensor and wiring harness 🔍 Mazda 1996 626/MX-6 BETM |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM 🔍 page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |




| Diagnostic trouble code No. P0505 | | IDLE CONTROL SYSTEM MALFUNCTION | |
|---|---|--|---|
| Symptom | | <ul style="list-style-type: none"> • Mechanical trouble is observed in idle air control system • Open or short circuit is observed in idle air control system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Idle air control valve malfunction • Leakage in intake-air system • Open or short circuit in wiring from idle air control valve terminal A to main relay terminal F • Open or short circuit in wiring from idle air control valve terminal B to ECM terminal 4Q | |
| STEP | INSPECTION | ACTION | |
| 1 | Does idle air control valve connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4Q voltage OK?  page F1-98 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect idle air control valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Idle air control valve terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4Q? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between idle air control valve terminals A and B? | Yes | Go to next step |
| | | No | Replace BAC valve  page F1-48 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |





| Diagnostic trouble code No. P0510 | | CLOSED THROTTLE POS—MALFUNCTION | |
|---|---|---|--|
| Symptom | | Input voltage from closed throttle position switch stays 0 V or above 1.2 V for more than 26 seconds after ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Closed throttle position switch malfunction • Open or short circuit in wiring from closed throttle position switch terminal A to ECM terminal 3L | |
| STEP | INSPECTION | | ACTION |
| 1 | Does throttle position sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3L voltage OK? 👉 page F1-97 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is there continuity between connector terminal A and ECM terminal 3L? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is closed throttle position switch OK? 👉 page F1-101 | Yes | Go to next step |
| | | No | Replace closed throttle position switch 👉 page F1-48 |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM 👉 page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| | | | |
|--|--|---|---|
| Diagnostic trouble code No. P0703 | | TORQUE CONV/BRAKE SW—MALFUNCTION | |
| Symptom | | No signal input from brake switch to ECM when brake pedal is kept depressed for more than 26 seconds, or signal input when brake pedal is not depressed | |
| Possible cause | | <ul style="list-style-type: none"> • Brake switch malfunction • Open or short circuit in wiring from ECM terminal 1Q to brake switch terminal • Open or short circuit in wiring from brake switch terminal to battery terminal | |
| STEP | INSPECTION | | ACTION |
| 1 | Does brake switch connector or ECM connector have poor connection? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is ECM terminal 1Q voltage OK?  page F1-96 | Yes | Go to step 4 |
| | | No | Go to next step |
| 3 | Is there continuity between brake switch terminal and ECM terminal 1Q? | Yes | Check for open or short circuit in wiring harness. (Battery — Brake switch) Check brake switch.  Mazda 1996 626/MX-6 BETM |
| | | No | Repair or replace wiring harness |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |





| | | | |
|--|--|--|----------|
| Diagnostic trouble code No. P1000 | | MORE DRIVING NEEDED TO COMPLETE TEST | |
| Possible cause | | Following diagnostic trouble code detection conditions not satisfied | |
| | | Diagnosed circuit | Code No. |
| | | O ₂ sensor circuit malfunction | P0130 |
| | | O ₂ sensor heater circuit malfunction | P0135 |
| | | Fuel trim malfunction | P0170 |
| | | Random misfire detected | P0300 |
| | | Cylinder 1 misfire detected | P0301 |
| | | Cylinder 2 misfire detected | P0302 |
| | | Cylinder 3 misfire detected | P0303 |
| | | Cylinder 4 misfire detected | P0304 |
| Exhaust gas recirculation flow malfunction | P0400 | | |
| Catalyst system efficiency below threshold | P0420 | | |
| Note | | <ul style="list-style-type: none"> • DTC No. P1000 will be deleted while MIL is illuminated | |
| Action | Carry out troubleshooting according to symptom | | |


| Diagnostic trouble code No. P1170 | | HO2S 11—INVERSION | |
|---|--|--|--|
| Symptom | | Heated oxygen sensor (Front) signal remains unchanged for more than 20 seconds after engine is in feedback zone | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor (Front) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front) terminal A to ECM terminal 3C • Intake-air system, fuel system, ignition system malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Does heated oxygen sensor (Front) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3C voltage OK? ☞ page F1-96 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front) connector. Is there continuity between connector terminal A and ECM terminal 3C? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? Fuel injector ☞ page F1-65 Pressure regulator ☞ page F1-63 Mass air flow sensor ☞ page F1-99 Engine coolant temperature sensor ☞ page F1-104 Spark plug ☞ section G Air suction (Air/fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front) ☞ page F1-72 |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P1195 | | EGRBS—OPEN OR SHORT | |
|--|--|--|--|
| Symptom | | Input voltage from EGR boost sensor is below 0.03 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR boost sensor malfunction • Open or short circuit in wiring from ECM terminal 3H to EGR boost sensor terminal B • Open or short circuit in wiring from ECM terminal 3I to EGR boost sensor terminal C • Open circuit in wiring from ECM terminal 3O to EGR boost sensor terminal A | |
| STEP | INSPECTION | | ACTION |
| 1 | Does EGR boost sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3H voltage OK?  page F1-96 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect EGR boost sensor connector. Turn ignition switch to ON. Is there 5V at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 3I — EGR boost sensor terminal C) |
| 4 | Is there continuity between connector terminal A and ECM terminal 3O? | Yes | Replace EGR boost sensor |
| | | No | Repair or replace wiring harness. |
| 5 | Erase diagnostic trouble code from memory. Is same code present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |





| Diagnostic trouble code No. P1250 | | PRC—OPEN OR SHORT | |
|--|---|--|---|
| Symptom | | Open or short circuit is observed in PRC solenoid valve system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • PRC solenoid valve malfunction • Open or short circuit in wiring from PRC solenoid valve terminal A to main relay terminal F • Open or short circuit in wiring from PRC solenoid valve terminal B to ECM terminal 4J | |
| STEP | INSPECTION | ACTION | |
| 1 | Does PRC solenoid valve connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4J voltage OK?  page F1-97 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect PRC solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — PRC solenoid valve terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4J? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between PRC solenoid valve terminals A and B? | Yes | Go to next step |
| | | No | Replace PRC solenoid valve  page F1-64 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |





| Diagnostic trouble code No. P1345 | | SGC SIGNAL—NO SGC SIGNAL | |
|--|--|--|---|
| Symptom | | No SGC signal input from camshaft position sensor while engine rotates five cycles | |
| Possible cause | | <ul style="list-style-type: none"> • Camshaft position sensor malfunction • Open or short circuit in wiring from ECM terminal 4A to distributor terminal A • Open or short circuit in wiring from ECM terminal 4G to distributor terminal D | |
| STEP | INSPECTION | ACTION | |
| 1 | Does camshaft position sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect distributor connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Distributor terminal B) |
| 3 | Is there continuity between connector terminal D and ECM terminal 4G? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is ECM terminal 4G voltage OK? ☞ page F1-97 | Yes | Go to step 6 |
| | | No | Go to next step |
| 5 | Is camshaft position sensor OK? ☞ page F1-100 | Yes | Go to next step |
| | | No | Replace distributor ☞ section G |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ☞ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |





| | | | |
|--|---|---|--|
| Diagnostic trouble code No. P1402 | | EGRS—OPEN OR SHORT | |
| Symptom | | Input voltage from EGR valve position sensor is below 0.2 V or above 4.8 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR valve position sensor malfunction • Open or short circuit in wiring from EGR valve position sensor terminal B to ECM terminal 3I • Open or short circuit in wiring from EGR valve position sensor terminal C to ECM terminal 3J • Open or short circuit in wiring from EGR valve position sensor terminal A to ECM terminal 3O | |
| STEP | INSPECTION | ACTION | |
| 1 | Does EGR valve position sensor connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 3J voltage OK?  page F1-97 | Yes | Go to step 7 |
| | | No | Go to next step |
| 3 | Disconnect EGR valve position sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 3I — EGR valve position sensor terminal B) |
| 4 | Is there continuity between connector terminal C and ECM terminal 3J? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminal A and ECM terminal 3O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 6 | Is resistance of EGR valve position sensor OK?  page F1-106 | Yes | Go to next step |
| | | No | Replace EGR valve  page F1-77 |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |




HARNESS SIDE CONNECTOR

| Diagnostic trouble code No. P1485 | | EGR (VACUUM)—OPEN OR SHORT | |
|--|---|---|--|
| Symptom | | Open or short circuit is observed in EGR solenoid valve (vacuum) system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) malfunction • Open or short circuit in wiring from EGR solenoid valve (vacuum) terminal A to main relay terminal F • Open or short circuit in wiring from EGR solenoid valve (vacuum) terminal B to ECM terminal 4P | |
| STEP | INSPECTION | ACTION | |
| 1 | Does EGR solenoid valve (vacuum) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4P voltage OK?  page F1-98 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect EGR solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — EGR solenoid valve (vacuum) terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4P? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between EGR solenoid valve (vacuum) terminals A and B? | Yes | Go to next step |
| | | No | Replace EGR solenoid valve (vacuum)  page F1-73 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking. | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | | | |
|---|--|---|--|
| Diagnostic trouble code No. P1486 | | EGR (VENT)—OPEN OR SHORT | |
| Symptom | | Open or short circuit is observed in EGR solenoid valve (vent) system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR solenoid valve (vent) malfunction • Open or short circuit in wiring from EGR solenoid valve (vent) terminal A to main relay terminal F • Open or short circuit in wiring from EGR solenoid valve (vent) terminal B to ECM terminal 4O | |
| STEP | INSPECTION | | ACTION |
| 1 | Does EGR solenoid valve (vent) connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4O voltage OK?  page F1-98 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect EGR solenoid valve (vent) connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — EGR solenoid valve (vent) terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between EGR solenoid valve (vent) terminals A and B? | Yes | Go to next step |
| | | No | Replace EGR solenoid valve (vent)  page F1-73 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking. | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P1487 | | EGRCHK SOL—OPEN OR SHORT | |
|---|--|--|--|
| Symptom | | Open or short circuit is observed in EGR boost sensor solenoid valve system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR boost sensor solenoid valve malfunction • Open or short circuit in wiring from EGR boost sensor solenoid valve terminal A to main relay terminal F • Open or short circuit in wiring from EGR boost sensor solenoid valve B to ECM terminal 4L | |
| STEP | INSPECTION | | ACTION |
| 1 | Does EGR boost sensor solenoid valve connector or ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 4L voltage OK?  page F1-98 | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect EGR boost sensor solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness (Main relay terminal F — EGR boost sensor solenoid valve terminal A) |
| 4 | Is there continuity between connector terminal B and ECM terminal 4L? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between EGR boost sensor solenoid valve terminals A and B? | Yes | Go to next step |
| | | No | Replace EGR boost sensor solenoid valve  page F1-77 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM  page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P1608 | | PCME (CPU)—MALFUNCTION | |
|--|------------|--|--|
| Symptom | | ECM does not diagnose output devices | |
| Possible cause | | <ul style="list-style-type: none"> • ECM malfunction • Short circuit in wiring output device | |
| STEP | INSPECTION | | ACTION |
| — | — | | Replace ECM  page F1-93 |

| | | | |
|--|---|---|--|
| Diagnostic trouble code No. P1794 | | BAT—BAT OR CIRCUIT FAIL | |
| Symptom | | Battery positive voltage is not constantly applied to ECM terminal 4B | |
| Possible cause | | <ul style="list-style-type: none"> • Battery malfunction • Open or short circuit in wiring from ECM terminal 4B to battery positive cable • Burnt fuse | |
| STEP | INSPECTION | | ACTION |
| 1 | Is battery fully charged? ➡ section G | Yes | Go to next step |
| | | No | Charge battery ➡ section G |
| 2 | Does battery positive voltage present at ECM terminal 4B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness (ECM terminal 4B — Main relay — Battery) |
| 3 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ➡ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |


| | | | |
|--|---|--|--|
| Diagnostic trouble code No. P1797 | | PNS—OPEN OR SHORT | |
| Symptom | | <ul style="list-style-type: none"> • ECM judges neutral/clutch switch OFF for more than 5 seconds while vehicle stopped and engine running | |
| Possible cause | | <ul style="list-style-type: none"> • Clutch/neutral switch malfunction • ECM malfunction • Open or short circuit in wiring from neutral/clutch switch terminal to ECM terminal 1L | |
| STEP | INSPECTION | | ACTION |
| 1 | Does ECM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is ECM terminal 1L voltage OK? ➡ page F1-95 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is there continuity between neutral/clutch switch terminal and ECM terminal 1L? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is neutral/clutch switch OK? ➡ page F1-108 | Yes | Go to next step |
| | | No | Repair or replace neutral/clutch switch ➡ section K, page F1-108 |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace ECM ➡ page F1-93 |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |

INTAKE-AIR SYSTEM


COMPONENT PARTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect the intake-air system components and repair or replace them as necessary.
3. Install in the reverse order of removal, referring to **Installation note**.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Fresh-air duct Inspect for damage 2. Air cleaner Inspect for excessive dirt and damage 3. Air cleaner element 4. Mass air flow sensor Inspection page F1-99 5. Air hose Inspect for damage 6. Resonance chamber Inspect for damage Installation note page F1-49 | <ol style="list-style-type: none"> 7. Accelerator cable Inspection / Adjustment page F1-50 8. Throttle body Inspection page F1-49 9. BAC valve Inspection page F1-53 10. Fuel distributor 11. Intake manifold bracket 12. Intake manifold Installation note page F1-49 |
|---|--|




THROTTLE BODY

Inspection

1. Check the throttle body for wear, deposits, and coolant leakage.
2. Verify that the throttle valve moves smoothly when the throttle lever is moved from the closed throttle position to the wide open throttle.
3. Replace the throttle body if necessary.

Caution

- Do not remove the thin seal coating from the throttle valve or bore. It is necessary for proper operation.



INTAKE MANIFOLD


Installation note

1. Tighten the bolts in the order shown in the figure.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}


2. Refill the radiator with the specified engine coolant. (Refer to section E.)
3. Check for engine coolant leakage.




RESONANCE CHAMBER

Installation note

1. Slide the hose clamp onto the hose and push it onto resonance chamber.



2. Rotate the hose and hook it securely onto the locating knob.




3. Tighten the hose clamp.


ACCELERATOR PEDAL

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|---|----------------------|
| 1. Accelerator cable Inspection / Adjustment below | 3. Retainer |
| 2. Cruise actuator cable Adjustment ... 1996 626/MX-6 Body Electrical Troubleshooting Manual section Q | 4. Clip |
| | 5. Accelerator pedal |
| | 6. Return spring |
| | 7. Bracket |



ACCELERATOR CABLE Inspection / Adjustment


1. Verify that the throttle valve is in the closed throttle position.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.0 mm {0.06—0.16 in}

3. If not as specified, adjust the cable free play by turning stopper (B) while pressing lock button (A) with the closed throttle position.
4. Reset the cable lock.









IDLE AIR CONTROL SYSTEM



DESCRIPTION



The idle air control system controls the bypass air amount that passes through the throttle body to improve startability, warm-up, idle smoothness, and drivability.

PREPARATION SST

| | | | |
|---|---|--|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of idle air control valve and air valve</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of idle air control valve and air valve</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve and air valve</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve and air valve</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve and air valve</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of idle air control valve and air valve</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve and air valve</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of idle air control valve and air valve</p> |



SYSTEM INSPECTION

Air Valve

1. Verify that the engine coolant temperature is below 20°C {68°F}.
2. Connect the **SST** to the data link connector.
3. Set switch **A** to position 1 and the test switch to SELF TEST.
4. Start the engine.
5. Verify that the idle speed decreases gradually as the engine warms up.

Idle Air Control Valve

1. Start the engine and run it at idle.
2. Disconnect the IAC valve connector and verify that the engine rotation changes.
3. If the engine condition will not change, do as follows.
 - (1) Connect the **SST** to the data link connector-2.
 - (2) Verify that diagnostic trouble code No. P0505 is not displayed. If code No. P0505 is shown, carry out troubleshooting of the code No. P0505.
 - (3) Change the duty value of the IAC valve to 100% by using the simulation function and verify that the idle speed increases.
 - I. If the idle speed increase, replace the ECM. (Refer to page F1-93.)
 - II. If the idle speed does not change, replace the BAC valve. (Refer to page F1-48.)
4. Warm-up the engine to normal operating temperature and run it idle.
5. Turn the electrical load ON and verify that the engine speed is within the specification.

Specification


| Engine condition | Engine speed (rpm) |
|------------------|--------------------|
| No load | 650—750 |
| E/L operated* | 725—825 |
| A/C operated | 725—825 |
| P/S operated | 650—750 |

* Fan switch (ON at 3rd or higher)
 Headlight switch
 Rear window defroster switch
 Cooling fan

Note

- Excludes temporary idle speed drop just after the electrical load are turned on.

6. If not as specified, check the related switches and wiring harnesses.




IDLE AIR CONTROL VALVE

Inspection

1. Disconnect the idle air control valve connector.
2. Measure the resistance of the valve.

Resistance: 7.7—9.3 [at 23°C {73°F}]

3. If not as specified, replace the BAC valve.




AIR VALVE

Inspection

1. Remove the BAC valve. (Refer to page F1-48.)
2. Cool the BAC valve to below 0°C {32°F}.
3. Heat the BAC valve at point (A) by using a blow drier, and verify that part (B) moves in the direction of the arrow in the figure.
4. If not as specified, replace the BAC valve.

FUEL SYSTEM

DESCRIPTION





This system supplies the fuel to the fuel injectors at a constant pressure. Fuel is metered and injected into the intake manifold according to injection control signals from the ECM. The system consists of the fuel tank, fuel pump, fuel filters, pressure regulator, pressure regulator control solenoid valve, fuel injectors, and fuel pump relay.

PREPARATION

SST

| | | |
|--|--|--|
| <p>49 L018 901</p> <p>Injector checker</p> | | <p>For inspection of fuel injector</p> |
|--|--|--|



Fuel Pressure and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.


Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".

Fuel Line Safety Procedures

- Release the fuel pressure before disconnecting a fuel line.
 - Start the engine.
 - Remove the fuel pump relay.
 - After the engine stalls, turn the ignition switch to OFF.
 - Install the fuel pump relay.
- Avoid leakage
 - When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - Plug the hose after removal.
- Use a fuel pressure gauge correctly; install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose to prevent leakage.



Priming Fuel System

After the fuel pressure has been released for repairs or inspection, the system must be primed to avoid excessive cranking when the engine is first started. Follow the steps below.


- Connect the data link connector terminals F/P and GND with a jumper wire.
- Turn the ignition switch to ON for **approx. 10 sec.** and check for fuel leaks.
- Turn the ignition switch to OFF and disconnect the jumper wire.






SYSTEM INSPECTION

Fuel Pressure Hold Inspection

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" above.





1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**

Fuel pressure:

More than 150 kPa {1.5 kgf/cm², 21 psi}

8. If not as specified, perform the following inspections.
 - Fuel pump hold pressure. (Refer to page F1-60.)
 - Pressure regulator hold pressure. (Refer to page F1-64.)
 - Injector fuel leakage. (Refer to page F1-66.)

Fuel Line Pressure Inspection

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.**

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON.
6. Measure the fuel line pressure.

Fuel line pressure:

260—320 kPa {2.6—3.3 kgf/cm², 37—46 psi}

7. If not as specified, perform the following inspections.
 - Fuel pump maximum pressure. (Refer to page F1-61.)
 - Fuel line clogging and restriction.
 - Fuel filter clogging and restriction.
 - Pressure regulator hold pressure. (Refer to page F1-64.)


FUEL TANK

Removal / Inspection / Installation

Warning





- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.

1. Suck up the fuel from the fuel tank. (Refer to **Removal note** on page F1-59.)
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation note**.



- 1. Presilencer
- 2. Insulator
- 3. Connector
- 4. Fuel hoses
Installation note page F1-59

- 5. Evaporative hoses
Installation note page F1-59
- 6. Fuel tank strap
- 7. Fuel tank
Inspect for cracks and corrosion
Removal note page F1-59

**Removal note**

1. Remove the filler cap and insert a hose into the fuel tank through the filler pipe.
2. Start the pump and suck up the fuel into a container.

Note

- For easier work, prepare a hose of the following size.

Outer diameter: 13 mm {0.51 in}

Length: 2160 mm {85.0 in}

Installation note

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings **at least 25 mm {1.0 in}**.
2. Push the fuel filler hoses onto the fuel tank pipes and filler pipes **at least 35 mm {1.4 in}**.

FUEL FILTER**Replacement****Low-pressure side (in-tank filter)**

(Refer to page F1-62.)

High-pressure side

The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

Warning






- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F1-56.**

1. Disconnect and plug the fuel hoses from the fuel filter.
2. Remove the fuel filter and bracket.
3. Install in the reverse order of removal.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

4. Verify that the fuel hoses are pushed fully onto the fuel filter nipples.
5. Secure the fuel hoses with clips.
6. Start the engine and verify that the fuel line joints do not leak.



FUEL PUMP

Inspection

Fuel pump operation

1. Connect the data link connector terminals F/P and GND with a jumper wire as shown.
2. Remove the fuel filler cap.
3. Turn the ignition switch to ON.
4. Listen at the filler inlet for the operational sound of the fuel pump.
5. Install the fuel filler cap.

6. If no sound was heard, measure the voltage between terminal A of the vehicle harness side fuel pump connector and a ground (in the RH trunk compartment trim).

Voltage: B+

7. If the voltage is not correct, check the fuel pump relay and related wiring harness.
8. If the voltage is correct, check for continuity between terminals A and D of the fuel pump side connector (in the RH trunk compartment trim).
9. If there is continuity, check fuel pump ground circuit for open.
10. If there is no continuity, check for continuity between terminals A and D of the fuel pump connector as shown. (Underside of body)
11. If there is continuity, check terminal A and/or D harness between fuel pump connector to vehicle harness.
12. If there is no continuity, remove the fuel tank and replace the fuel pump. (Refer to page F1-62.)


Hold pressure

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F1-56.)

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the fuel filter and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.



4. Connect data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for 10 sec. to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure after 5 min..



Fuel pressure: More than 340 kPa {3.5 kgf/cm², 50 psi}

8. If not as specified, replace the fuel pump.


Fuel pump maximum pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.



1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the fuel filter and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.



4. Connect data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON to operate the fuel pump.
6. Measure the pump maximum pressure.

**Fuel pump maximum pressure:
450—630 kPa {5.0—6.5 kgf/cm², 64—92 psi}**


7. Turn the ignition switch to OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.

Removal / Installation


1. Remove the fuel tank.
2. Remove the fuel pump, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.

Note

- Replace the fuel pump as an assembly.



- | | |
|-------------------|---------------------|
| 1. Fuel hose | 3. Fuel pump |
| 2. Fuel pump ring | 4. Fuel pump gasket |
- Removal / Installation Note below





Removal note

Rotate the fuel pump ring counterclockwise and remove it.

Installation note

Rotate the fuel pump ring clockwise until the flange touches the stopper.






FUEL PUMP RELAY

Inspection

Operation check

Listen for clicking of the fuel pump relay while turning the ignition switch from OFF to START.




Continuity inspection

Check continuity between the terminals of the relay.


B+: Battery positive voltage

| Terminal A—B | Terminal C—D |
|----------------|---------------|
| B+ applied | Continuity |
| B+ not applied | No continuity |



Replacement

1. Remove the relay from main fuse block No.1.
2. Install in the reverse order of removal.



PRESSURE REGULATOR

Inspection

Fuel line pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.


Fuel line pressure:






210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}

6. Disconnect the vacuum hose from the pressure regulator and measure the fuel line pressure.

Fuel line pressure:

260—320 kPa {2.6—3.3 kgf/cm², 37—46 psi}





Hold pressure

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F1-56.)

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F1-56.

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery terminal.

4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for 10 sec. to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Pinch the fuel return hose with a plier.
8. Observe the fuel pressure for 5 min..

Fuel pressure: More than 147 kPa {1.5 kgf/cm², 21 psi}

9. If not as specified, replace the pressure regulator.

Replacement


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F1-56.

1. Disconnect the vacuum hose.
2. Disconnect the fuel return hose.
3. Remove the pressure regulator.
4. Install a new O-ring.
5. Install in the reverse order of removal.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



FUEL INJECTOR

Inspection

Operation check


1. Warm up the engine and let it idle.
2. Listen for the operational sound of each fuel injector with a screwdriver or a sound scope.
3. If no sound is heard, measure the fuel injector resistance. (Refer to page F1-67.)
4. If the fuel injector resistance is OK, check wiring to the fuel injector and the voltages of the ECM terminals 4U, 4V, 4W and 4X. (Refer to page F1-98.)

Removal / Installation

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F1-56.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation note**.




1. Negative battery cable
2. Fuel injector connector
3. Fuel hose
4. Pressure regulator

Inspection page F1-63

5. Fuel distributor
6. Fuel injector
7. Insulator


Installation note page F1-67

**Fuel leakage test**


1. Remove the fuel injectors together with the fuel distributor. (Refer to page F1-65.)
2. Fasten the fuel injectors firmly to the pipe with wire.

Warning

- **Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.**



3. Connect the data link connector terminals F/P and GND with a jumper wire.
4. Turn the ignition switch to ON.




5. Tilt the fuel injectors **approx. 60 degrees** and verify that there is no fuel leaks from the fuel injector nozzles.

Leakage specification

If there is more than one drop per 2 minutes, replace the fuel injector.


6. Turn the ignition switch to OFF and disconnect the jumper wire.

**Volume test**

1. Remove the fuel injectors together with the fuel distributor. (Refer to page F1-65.)
2. Fasten the fuel injectors firmly to the pipe with wire.

Warning

- **Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.**




3. Connect the **SST** to the battery and an fuel injector.
4. Check the injection volume with a graduated container.

Injection volumes:

47—68 ml {47—68 cc, 1.4—2.0 fl oz}/15 sec.

5. If not as specified, replace the fuel injectors.




Installation

Install in the reverse order of removal, referring to **Installation Note**.


Tightening torque

- A: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}
- B: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Installation note

1. Use new fuel injector O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing them.



3. Install new fuel injector insulators.
4. Install the fuel injectors.



Inspection

Fuel injector resistance


1. Disconnect the fuel injector harness.
2. Measure the resistance of the fuel injector.

Resistance: 12—16Ω (at 20°C {68°F})

3. If not as specified, replace the fuel injector.








PRESSURE REGULATOR CONTROL SYSTEM

DESCRIPTION



To prevent vapor lock of the fuel during hot restart idle, vacuum to the pressure regulator is momentarily cut and the fuel injection pressure is increased to slightly more than **284 kPa {2.9 kg/cm², 41.2 psi}**.

**PREPARATION
SST**



| | | | |
|---|-------------------------------------|---|-------------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of PRC system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>—</p> | <p>—</p> |

SYSTEM INSPECTION

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F1-56.

1. Install the fuel pressure gauge.
2. Measure the fuel pressure under the following conditions.

**Specifications**

| | Fuel pressure (kPa { kgf/cm ² }) | | |
|------------------------------|---|--------------------------------------|--------------------------------------|
| | Idling | 210—250 { 2.1—2.6 } | 210—250 { 2.1—2.6 } |
| During 102 sec. of hot start | 260—310 { 2.6—3.2 } | | |
| After 102 sec. of hot start | 210—250 { 2.1—2.6 } | | |
| Judgement | Normal | Not normal (Perform Inspection 1) | Not normal (Perform Inspection 2) |


3. If the fuel pressure is not within the specification, carry out either Inspection 1 or Inspection 2 as required.

Inspection 1


1. Stop the engine.
2. Connect the **SST** to the data link connector-2.
3. Verify that diagnostic trouble code No. P1250 is not displayed. If code No. P1250 is shown, carry out troubleshooting of the code No. P1250. (Refer to page F1-41.)
4. Start the engine and run it at idle.
5. Turn the PRC solenoid valve from OFF to ON by using the “SIMULATION TEST” function and check if the fuel pressure changes.
 - (1) If the pressure changes, check the following.
 - ECM terminal voltage (Refer to page F1-95.)
 - Intake air temperature signal
 - Closed throttle position switch
 - (2) If the pressure does not change, do as follows.
 - I. Stop the engine.
 - II. Turn the ignition switch to ON.
 - III. Turn the PRC solenoid valve from OFF to ON by using the “SIMULATION TEST” function and check if the operation sound of the valve is heard.
 - a. If the operation sound is heard, check the following.
 - Pressure regulator (Refer to page F1-63.)
 - b. If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to page F1-71.)

Inspection 2

1. Stop the engine.
2. Connect the **SST** to the data link connector-2.
3. Verify that diagnostic trouble code No. P1250 is not displayed. If code No. P1250 is shown, carry out troubleshooting of the code No. P1250. (Refer to page F1-41.)
4. By using the "PID/DATA MONITOR AND RECORD" function, verify that the PRC solenoid valve is OFF.
5. If the PRC solenoid valve is ON, check the following.
 - ECM terminal voltage (Refer to page F1-95.)
 - Engine coolant temperature signal
 - Intake air temperature signal
6. Turn the PRC solenoid valve from OFF to ON by using the "SIMULATION TEST" function and check if the operation sound of the valve is heard.
 - (1) If the operation sound of the valve is heard.
 - Loose or damaged vacuum hose between the pressure regulator, PRC solenoid valve, and intake manifold.
 - (2) If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to page F1-71.)

**Solenoid Valve**

1. Remove the solenoid valve.
2. Blow through the solenoid valve from port (A).
3. Verify that air flows from port (B).




4. Apply battery positive voltage to solenoid valve terminal.
5. Blow through the solenoid valve from port (A).
6. Verify that air flows from the valve air filter.
7. If not as specified, replace the solenoid valve.

EXHAUST SYSTEM

COMPONENT PARTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Main silencer Inspect for deterioration and restriction 2. Presilencer Inspect for deterioration and restriction 3. Three way catalytic converter Inspect for deterioration and restriction 4. Heated oxygen sensor (rear) Inspection page F1-106 | <ol style="list-style-type: none"> 5. Front pipe assembly Inspect for deterioration and restriction 6. Warm up three way catalytic converter Inspect for deterioration and restriction 7. Exhaust manifold insulator 8. Heated oxygen sensor (front) Inspection page F1-105 9. Exhaust manifold Inspect for deterioration and cracks |
|---|---|

OUTLINE OF EMISSION CONTROL SYSTEM

STRUCTURAL VIEW

The following systems are employed to reduce CO, HC, and NOx emissions.

1. Exhaust gas recirculation
2. Positive crankcase ventilation (PCV) system
3. Fuel evaporative system
4. Three way catalytic converter




EXHAUST GAS RECIRCULATION

DESCRIPTION

This system recirculates a small amount of exhaust gas into the intake manifold to reduce the combustion temperature and the NOx emissions.

This system consists of the EGR valve, EGR valve position sensor, two duty-solenoid valves, ECM, and input devices.



OPERATION

Cold engine (coolant temperature: below 55°C {131°F})








EGR operation is stopped to improve drivability when the engine is cold.

Warm engine

The ECM controls the EGR solenoid valves (vacuum and vent) to supply EGR gases as described below.


| Operating condition | EGR operation | Remark |
|----------------------|---|--|
| Idle | Stopped | Closed throttle position switch: ON |
| Deceleration | | |
| High speed/Low speed | | Above 4,250/Below 1,000 rpm |
| Heavy load | | — |
| Acceleration | Reduced EGR gas amount | — |
| Warming up | | Coolant temperature: Between 55°C {131°F} and 60°C {140°F} |
| Other | Controls supplied EGR gas amount by using signal from EGR valve position sensor | — |


**PREPARATION
SST**

| | | | |
|---|-------------------------------------|---|-------------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of EGR system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>—</p> | <p>—</p> |

SYSTEM INSPECTION

1. Connect the **SST** to the data link connector-2.
2. Start the engine and let it at idle.
3. Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the "SIMULATION TEST" function. Operate the EGR solenoid valve (vacuum) and check if the engine speed becomes unstable or the engine stalls.
4. If the engine speed will not change, stop the engine and do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Verify that diagnostic trouble code No. P1485, P1486 are not displayed. If code No. P1485, P1486 are shown, carry out troubleshooting of the code No. P1485, P1486. (Refer to page F1-44, 45.)
 - (3) Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the "SIMULATION TEST" function. Operate the EGR solenoid valve (vacuum) and check if operation sound of the valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - EGR valve (Refer to page F1-77.)
 - EGR solenoid valve (vent) (Refer to page F1-76.)
 - II. If the operation sound is not heard, check the following.
 - EGR solenoid valve (vacuum) (Refer to page F1-76.)





EGR SOLENOID VALVE (VACUUM)

Inspection


1. Remove the EGR solenoid valve (vacuum).
2. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vacuum). Verify that air flows as shown below.

Specification

B+: Battery positive voltage

| Terminal A—B | Air flow |
|----------------|----------|
| B+ applied | Yes |
| B+ not applied | No |

3. If not as specified, replace the EGR solenoid valve (vacuum).



EGR SOLENOID VALVE (VENT)

Inspection

1. Remove the EGR solenoid valve (vent).
2. Verify that air flows as shown below.


Specification


| Port | Air flow |
|------|----------|
| A—B | Yes |
| A—C | Yes |
| B—C | Yes |

3. If not as specified, replace the EGR solenoid valve (vent).
4. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vent). Verify that air flows as shown below.

Specification

| Port | Air flow |
|------|----------|
| A—B | Yes |
| A—C | No |
| B—C | No |





EGR VALVE


Inspection

1. Start the engine and let it idle.
2. Connect a vacuum pump as shown and apply vacuum.
3. Verify that the engine runs roughly or stalls at more than the specified vacuum.

Specification:

5.4—7.7 kPa {40—60 mmHg, 1.6—2.3 inHg}


4. If not as specified, replace the EGR valve.



Replacement

Plug the water hoses after disconnecting them.

1. Remove the EGR valve in the sequence shown below.
 - (1) Vacuum hose
 - (2) EGR valve position sensor connector
 - (3) EGR valve and gasket
2. Install a new gasket, and then install the EGR in the reverse order of removal.



EGR BOOST SENSOR SWITCHING CONTROL SYSTEM

SYSTEM INSPECTION


1. Warm up the engine to normal operating temperature and let it at idle.
2. Disconnect the vacuum hose from the EGR boost sensor side of the EGR boost sensor solenoid valve.
3. Put a finger on the port of the EGR boost sensor solenoid valve and verify that no vacuum is felt.

EGR BOOST SENSOR SOLENOID VALVE

Inspection


1. Remove the EGR boost sensor solenoid valve.
2. Blow air into each part and verify that air flows as specified below.

| Ports | Air flow |
|-------|----------|
| A—B | No |
| A—C | No |
| B—C | Yes |



3. If not as specified, replace the EGR boost sensor solenoid valve.
4. Apply battery positive voltage between the terminals of the EGR boost sensor solenoid valve.
5. Blow air into each port and verify that air flows as specified below.

| Ports | Air flow |
|-------|----------|
| A—B | Yes |
| A—C | No |
| B—C | No |





6. If not as specified, replace the EGR boost sensor solenoid valve.

POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM


DESCRIPTION

The PCV valve is operated by the intake manifold vacuum. When the engine is running at idle, the PCV valve is slightly open and a small amount of blowby gas is drawn into the intake manifold to be burned. As the engine speed rises, the PCV valve is opened further, allowing a larger amount of blowby gas to be drawn into the intake manifold.




PCV VALVE Inspection

1. Verify that the engine coolant temperature is below 20°C {68°F}.
2. Start the engine and let it idle.
3. Disconnect the PCV valve with the ventilation hose from the cylinder head cover.
4. Block the PCV valve opening.
5. Verify that vacuum is felt.
6. Remove the PCV valve.
7. Blow through the valve from port (A) and verify that air comes out of port (B).
8. Blow through the valve from port (B) and verify that no air comes out of port (A).
9. Replace the PCV valve if not as specified.



FUEL EVAPORATIVE SYSTEM

DESCRIPTION










The fuel evaporative system consists of the fuel vapor valve, two-way check valve, charcoal canister, purge solenoid valve, ECM, and input devices. The amount of evaporative fumes introduced into the engine and burned is controlled by the solenoid valve to correspond to the engine's operating conditions. To obtain the best engine performance, the purge solenoid valve is controlled by the ECM.



Operation

The purge solenoid valve is controlled by duty signals from the ECM to perform purging of the charcoal canister. Purging is done when these conditions are met:

1. After warm-up (Coolant temperature above 80°C {176°F})
2. Driving in gear
3. Engine speed more than 1,000 rpm
4. Accelerator pedal depressed (closed throttle position switch OFF)
5. Heated oxygen sensor functioning normally



PREPARATION SST

| | | | |
|---|--|--|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION


1. Start and warm up the engine to the normal operating temperature.
2. Let the engine idle.
3. Disconnect the vacuum hose between the purge solenoid valve and the charcoal canister.
4. Put a finger to the purge solenoid valve and verify that there is no vacuum applied.
5. If there is vacuum, do as follows.
 - (1) Connect the **SST** to the data link connector-2.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F1-35.)
6. Reconnect the vacuum hose.
7. Connect the **SST** to the data link connector-2.
8. Increase the duty value of the purge solenoid valve from 0% to 100% by using the "SIMULATION TEST" function. Operate the purge solenoid valve and check if the idle condition changes.
9. If the condition does not change, do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F1-35.)
 - (3) Increase duty value of the purge solenoid valve from 0% to 100% by using the "SIMULATION TEST" function. Operate the purge solenoid valve and check if the operation sound of the valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - II. If the operation sound is not heard, check the following.
 - Purge solenoid valve (Refer to page F1-81.)



PURGE SOLENOID VALVE

Inspection


1. Disconnect the vacuum hoses from the solenoid valve.
2. Verify that no air flows through the valve.
3. Disconnect the solenoid valve connector and supply battery positive voltage as shown in the figure.
4. Verify that air flows through the valve.
5. If not as specified, replace the solenoid valve.




FUEL VAPOR VALVE

Inspection

1. Hold the valve as shown and verify that air flows through the valve from port (A).



2. Invert the valve as shown and verify that no air flows through the valve from port (A).
3. Replace the fuel vapor valve if necessary.




CHECK VALVE (TWO-WAY)

Inspection

1. Remove the valve.
2. Check the operation of the valve by using a vacuum pump.

| | |
|--|-------------|
| Apply approx. 3.5 kPa {26 mmHg, 1.0 inHg} vacuum at port A | Valve opens |
| Apply approx. 5.9 kPa {44 mmHg, 1.7 inHg} vacuum at port B | Valve opens |



CHARCOAL CANISTER

Inspection


1. Visually check for damage.
2. Replace the charcoal canister if necessary.

FUEL-CUT CONTROL SYSTEM












DESCRIPTION




This system is used to improve the fuel economy, to prevent engine bucking during deceleration, and to protect the engine from overrevving.

Deceleration fuel-cut



PREPARATION SST

| | | | |
|---|--|---|--|
| <p>49 9200 162A Engine Signal Monitor</p>  | <p>For inspection of ECM terminal voltage</p> | <p>49 T018 902 Adapter harness</p>  | <p>For inspection of ECM terminal voltage</p> |
| <p>49 F018 903 Sheet</p>  | <p>For inspection of ECM terminal voltage</p> | <p>49 D088 008 Harness adaptor, power</p>  | <p>For inspection of ECM terminal voltage</p> |
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

1. Connect the **SST** (NGS) to the data link connector-2 and select the "PID/DATA MONITOR AND RECORD" function. (Refer to page F1-94.)
2. Connect the **SSTs** (Engine Signal Monitor) to the ECM.
3. Warm up the engine to normal operating temperature and let it idle.

Warning

- Performing this test with the transaxle in any range or position other than neutral can be dangerous. Before performing this test, verify that the transaxle is in neutral.

4. Set the **SST** (Engine Signal Monitor) to the terminals 4U, 4V, 4W and 4X and verify that the green and red lamps flash alternately.

5. Increase the engine speed to **4,000 rpm** and then suddenly release the throttle.
6. Verify that the red indicator lamp illuminates while the engine speed is above **approx. 1,500 rpm** on deceleration.

Caution


- Holding the maximum rpm for more than **3 seconds** can damage the engine.

7. Increase the engine speed and verify that the maximum rpm does not exceed **approx. 6,800 rpm** while the engine is at normal operating temperature.

A/C CUTOFF SYSTEM

DESCRIPTION

An A/C cutoff system is used to improve idle smoothness just after starting the engine and to improve acceleration performance.











Operation

The A/C clutch operation is cancelled under the conditions below.

| Engine condition | Purpose | Cutoff period |
|-----------------------------------|----------------------------|--|
| After engine starting | Improve engine starting | Approx. 4 sec. |
| Throttle valve wide open throttle | Improve drivability | Approx. 5 sec. |
| Coolant temp. above 116°C {241°F} | Prevent engine overheating | Until coolant temp. decrease below 113°C {235°F} |


PREPARATION SST

| | | | |
|--|--------------------------------------|--|--------------------------------------|
| 49 T088 0A0 NGS set  | For inspection of A/C cut off system | 49 T088 010B Program Card  | For inspection of A/C cut off system |
| 49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)  | For inspection of A/C cut off system | 49 T088 001 Control Unit (Part of 49 T088 0A0)  | For inspection of A/C cut off system |
| 49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)  | For inspection of A/C cut off system | 49 T088 008A Instruction Manual  | For inspection of A/C cut off system |
| 49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)  | For inspection of A/C cut off system | — | — |



SYSTEM INSPECTION

1. Position the vehicle on a chassis roller and start the engine.
2. Shift the transaxle into other than Neutral and release the clutch pedal.
3. Turn the A/C switch and the fan switch to on.
4. Fully open the throttle valve. Then, 3—6 seconds after, check if the operation sound of the A/C compressor electromagnetic clutch is heard.
5. If the operation sound is not heard, do as follows.
 - (1) Connect the **SST** to the data link connector-2.
 - (2) Turn the A/C relay from OFF to ON by using the "SIMULATION TEST" function and check for the operation sound of the relay.
 - I. If the operation sound is heard, check the following.
 - ECM terminal voltage (Refer to page F1-95.)
 - Load/no load judgement signal
 - Closed throttle position switch signal
 - II. If the operation sound is not heard, check the following.
 - A/C relay (Refer to Mazda 1996 626/MX-6 BETM.)
 - Open circuit in wiring harnesses and connectors (Main relay — A/C relay — ECM)



DECHOKE CONTROL SYSTEM


SYSTEM OPERATION

1. Turn the ignition switch to START and verify that the fuel injector operating sound is heard.
2. Depress the accelerator pedal fully and turn the ignition switch to START. Verify that no fuel injector operating sound is heard.
3. If operating sound is heard, check the ECM terminal 3B voltage. (Refer to page F1-96.)

COOLING FAN CONTROL SYSTEM

DESCRIPTION









To improve reliability, the cooling fan is controlled by the ECM. This system consists of the cooling fan motor, fan relays, ECM, and input devices.






Cooling fan operation

| Engine condition | Fan relay |
|--|-----------|
| Coolant temperature above 97°C {207°F} | ON |
| Air conditioning switch ON | ON |
| TEN terminal grounded and closed throttle position switch ON | ON |
| ECTS malfunction | ON |

**PREPARATION
SST**

| | | | |
|---|---|---|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of cooling fan control system</p> |















SYSTEM INSPECTION


1. Verify that the engine is cold.
2. Turn the ignition switch to ON.
3. Verify that the cooling fan is not operating.
4. If the cooling fan is operating, do as follows.
 - (1) Connect the **SST** to the data link connector-2.
 - (2) By using the "PID/DATA MONITOR AND RECORD" function, verify that the cooling fan control signal is OFF.
 - I. If the cooling fan control signal is ON, check the following.
 - ECM terminal voltage (Refer to page F1-95.)
 - Engine coolant temperature signal
 - II. If the cooling fan control signal is OFF, check the following.
 - Cooling fan relay (Refer to section E.)
 - Short circuit in wiring harnesses and connectors (Main relay — Fan relay — ECM)
5. Connect the **SST** and set system select switch to 1 and self test switch to SELF TEST.
6. Rotate the throttle link by hand and verify that the cooling fan operates.
7. If the cooling fan does not operate, do as follows.
 - (1) Connect the **SST** to the data link connector-2.
 - (2) Turn the cooling fan relay from OFF to ON by using the "SIMULATION TEST" function and check for the cooling fan operation.
 - I. If the cooling fan operates, check the following.
 - ECM terminal voltage (Refer to page F1-95.)
 - Test mode signal
 - Closed throttle position switch signal
 - II. If the cooling fan does not operate, do as follows.
 - a. Turn the cooling fan relay from OFF to ON by using the "SIMULATION TEST" function. Operate the cooling fan relay and check if the operation sound of the relay is heard.
 - b. If the operation sound is heard, check the following.
 - Wiring harnesses and connectors (Cooling fan relay — Cooling fan motor)
 - Cooling fan motor (Refer to section E.)
 - c. If the operation sound is not heard, check the following.
 - Cooling fan relay (Refer to section E.)
 - Open circuit in wiring harnesses and connectors (Main relay — Cooling fan relay — ECM)

CONTROL SYSTEM

PREPARATION
SST

| | | | |
|---|--|---|--|
| <p>49 9200 162A Monitor, Engine Signal</p>  | <p>For inspection of ECM terminal voltage</p> | <p>49 T018 902 Adapter harness</p>  | <p>For inspection of ECM terminal voltage</p> |
| <p>49 F018 903 Sheet</p>  | <p>For inspection of ECM terminal voltage</p> | <p>49 D088 008 Harness adapter, Power</p>  | <p>For inspection of ECM terminal voltage</p> |
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T018 001 Wrench, O₂ sensor</p>  | <p>For replacement of heated oxygen sensor</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> | <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ECM terminal voltage and input/output devices</p> |

STRUCTURAL VIEW




- | | |
|--|----------------------------------|
| 1. Fuel pump relay | 9. Intake air temperature sensor |
| Inspection page F1- 63 | Inspection page F1-105 |
| Replacement page F1- 63 | Replacement page F1-105 |
| 2. Engine control module | 10. Heated oxygen sensor |
| Removal / Installation page F1- 93 | Inspection page F1-105 |
| Inspection page F1- 93 | 11. EGR valve position sensor |
| 3. Mass air flow sensor | Inspection page F1-106 |
| Inspection page F1- 99 | 12. EGR boost sensor |
| 4. Camshaft position sensor | Inspection page F1-107 |
| Inspection page F1-100 | 13. Clutch switch |
| 5. Crankshaft position sensor | Inspection page F1-108 |
| Inspection page F1-100 | Replacement page F1-108 |
| Replacement page F1-101 | 14. Neutral switch |
| 6. Closed throttle position switch | Inspection page F1-108 |
| Inspection page F1-101 | Replacement page F1-108 |
| 7. Throttle position sensor | 15. P/S pressure switch |
| Inspection page F1-101 | Inspection page F1-109 |
| Adjustment page F1-102 | Replacement page F1-109 |
| Replacement page F1-105 | 16. Main relay |
| 8. Engine coolant temperature sensor | Inspection page F1-109 |
| Removal page F1-104 | |
| Inspection page F1-104 | |
| Installation page F1-105 | |

ENGINE CONTROL MODULE

Removal / Installation




1. Disconnect the battery negative terminal.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Center console

2. ECM connector

3. ECM



Inspection

Caution

- The ECM terminal voltages vary with change in measuring conditions and vehicle conditions. Always carry out a total inspection of the input systems, output systems, and ECM to determine the cause of trouble. Otherwise, a wrong diagnosis will be made.



1. Disconnect the negative battery cable.
2. Remove the center console.
(Refer to Mazda 1996 626/MX-6 BETM.)
3. Disconnect the ECM connector.
4. Connect the **SST** (Adapter Harness) to the ECM connector.
5. Connect the **SSTs** (Monitor, Engine Signal and Harness Adapter, Power) to the **SST** (Adapter Harness). Use connector A of the Adapter harness for ECM terminals 1A through 1V and 3A through 3P. Use connector B for ECM terminals 4A through 4Z.
6. Place the **SST** (Sheet) on the **SST** (Monitor, Engine Signal).
7. Measure the voltage at each ECM terminal by switching the selector switch and the monitor switch.
8. If any incorrect voltage is detected, check related systems, wiring harnesses and connectors referring to the Possible malfunction in the terminal voltage list.

Caution

- Disconnecting the connectors of the ECM and the SST (Adapter Harness) while the battery is connected can damage the ECM and the SST (Monitor, Engine Signal). Disconnect the negative battery cable and the SST (Harness Adapter, Power) before disconnecting the connectors.
- Applying voltage to terminals A and B of the SST (Monitor, Engine Signal) can damage the SST (Monitor, Engine Signal).

Note

- The indicator lights of the SST (Monitor, Engine Signal), provided for confirmation of the voltmeter range, is also used for detection of the pulse such as the fuel injector control signal, which is difficult to detect by using the voltmeter.
- Terminals A and B of the SST (Monitor, Engine Signal) are for connection of an external instrument. By connecting an external instrument such as a circuit tester or an oscilloscope, various inspections in addition to the measurement of the ECM terminal voltages are made possible.



Using SST (NGS)


1. In the passenger compartment, connect the SST to the data link connector-2 as shown in the figure.
2. Referring to the NGS instruction manual, select the "PID/ DATA MONITOR AND RECORD" function.
3. Referring to the 1996 Service Highlight, inspect each ECM input/output signal.

Note

- The "PID/DATA MONITOR AND RECORD" function is to monitor the calculation value of input/output signals in the ECM. Deviation in the value does not always indicate malfunction in the related input/output devices.
 - For inspection of the input/output signals other than in the link monitor table, check voltage at the applicable ECM terminal by using the SST (Monitor, Engine Signal).
4. If normal output signal cannot be detected when all input signals are normal, replace the ECM. (Refer to page F1-93).

Terminal voltage (Reference)

B+: Battery positive voltage
*1: In data link connector



| Terminal | Signal | Connected to | Test condition | Voltage (V) | Possible malfunction | | | |
|----------|--------------------------------|---|--|---|--|--|---------------|---|
| 1A | — | — | — | — | — | | | |
| 1B | Cooling fan control | Cooling fan relay | Cooling fan operating/Terminal TEN ground and throttle valve open | Below 1.0 | • Cooling fan relay (Refer to section E) | | | |
| | | | Cooling fan stop | B+ | | | | |
| 1C | — | — | — | — | — | | | |
| 1D | Diagnostic trouble code output | Data link connector, Data link connector-2 (Terminal KLN) | Carry out inspection according to diagnostic trouble code Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible (Refer to page F1-14) | — | • On-board diagnostic system | | | |
| 1E | MIL | Malfunction indicator light | Light illuminated for 3 sec. after ignition switch OFF→ON | Below 2.5 | | | | |
| | | | Light not illuminated after 3 sec. | B+ | | | | |
| | | | Light illuminated | Below 2.5 | | | | |
| | | | Light not illuminated | B+ | | | | |
| 1F | — | — | — | — | — | | | |
| | | | 1G | A/C control | A/C relay | Ignition switch ON | B+ | • A/C relay (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | | | | Idle | A/C operating | |
| | | A/C stop | B+ | | | | | |
| 1H | Headlight | Headlight switch | Headlight switch OFF | Below 1.0 | • Headlight switch (Refer to Mazda 1996 626/MX-6 BETM) | | | |
| | | | Headlight switch ON | B+ | | | | |
| 1I | Diagnostic test mode | Data link connector (Terminal TEN) | Ignition switch ON | Open terminal TEN*1 | B+ | • ECM terminal 1I – *1TEN harness | | |
| | | | | Short terminal TEN*1 | Below 1.0 | | | |
| 1J | Rear window defroster | Rear window defroster switch | Ignition switch ON | Rear window defroster switch OFF | Below 1.0 | • Rear window defroster switch (Refer to Mazda 1996 626/MX-6 BETM)) | | |
| | | | | Rear window defroster switch ON | B+ | | | |
| 1K | A/C | A/C amplifier | Ignition switch ON | A/C switch and blower switch ON | Below 1.0 | • A/C switch • Refrigerant pressure switch • A/C amplifier (Refer to Mazda 1996 626/MX-6 BETM) | | |
| | | | | A/C switch OFF | B+ | | | |
| 1L | Load/No load distinction | Neutral/clutch switch | Ignition switch ON | Other than neutral position and clutch pedal released | B+ | • Neutral switch (Refer to page F1-108) • Clutch switch (Refer to page F1-108) | | |
| | | | | Neutral position or clutch pedal depressed | Below 1.0 | | | |

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|-------------------------------|---|---------------------------|-------------------------------------|----------------------------|--|
| 1M | Vehicle speed | Vehicle speed sensor | Ignition switch ON | | Below 1.0 or 4.0—5.0 | <ul style="list-style-type: none"> Vehicle speed sensor (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | Driving | | Approx. 3.0 | |
| 1N | DRL (CANADA) | DRL unit | Daytime running light ON | | Below 1.0 | <ul style="list-style-type: none"> DRL unit (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | Daytime running light OFF | | Above 11.0 | |
| 1O | — | — | — | | — | — |
| 1P | Blower | Fan switch | Ignition switch ON | Fan switch OFF, ON at 1st or 2nd | B+ | <ul style="list-style-type: none"> Fan switch (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | | Fan switch ON at 3rd or higher | Below 1.0 | |
| 1Q | Brake | Brake switch | Brake pedal released | | Below 1.0 | <ul style="list-style-type: none"> Brake switch (Refer to section P) |
| | | | Brake pedal depressed | | B+ | |
| 1R | — | — | — | | — | — |
| 1S | — | — | — | | — | — |
| 1T | — | — | — | | — | — |
| 1U | Fuel pump control | Fuel pump relay | Ignition switch ON | | B+ | <ul style="list-style-type: none"> Fuel pump relay (Refer to page F1-63) |
| | | | Cranking | | Below 1.0 | |
| | | | Idle | | | |
| 1V | — | — | — | | — | — |
| 3A | — | — | — | | — | — |
| 3B | Mass air flow sensor (HRP) | Mass air flow sensor | Ignition switch ON | | 1.0—1.5 | <ul style="list-style-type: none"> Mass air flow sensor (Refer to page F1-99) |
| | | | Idle | | 1.5—5.0 | |
| 3C | Heated oxygen sensor (Front) | Heated oxygen sensor (Front) | Idle | After warm up | 0—1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (Front) (Refer to page F1-105) |
| | | | Acceleration | | 0—1.0 | |
| | | | Deceleration | | 0—1.0 | |
| 3D | Heated oxygen sensor (Rear) | Heated oxygen sensor (Rear) | Idle | After warm up | 0—1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (Rear) (Refer to page F1-105) |
| | | | Acceleration | | 0.5—1.0 | |
| | | | Deceleration | | 0—0.5 | |
| 3E | — | — | — | | — | — |
| 3F | Throttle position (TVO) | Throttle position sensor | Ignition switch ON | Closed throttle position | 0.3—0.7 | <ul style="list-style-type: none"> Throttle position sensor (Refer to page F1-101) ECM terminal 3I voltage |
| | | | | Wide open throttle | 3.4—5.3 | |
| 3G | Engine coolant temperature | Engine coolant temperature sensor | Ignition switch ON | Engine coolant temp 20 °C { 68 °F } | Approx. 3.16 | <ul style="list-style-type: none"> Engine coolant temperature sensor (Refer to page F1-104) |
| | | | | After warm up | Below 1.0 | |
| 3H | Barometric pressure/EGR boost | EGR boost sensor | Ignition switch ON | | Approx. 4.5 | <ul style="list-style-type: none"> EGR boost sensor (Refer to page F1-107) |
| | | | Idle | | | |
| 3I | Constant voltage (Vref) | Throttle position sensor EGR valve position sensor | Ignition switch ON | | Approx. 5.0 | <ul style="list-style-type: none"> ECM terminal 4B voltage |


B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|-------------------------------------|---|----------------------|--|--------------------------|---|
| 3J | EGR valve position | EGR valve position sensor | Ignition switch ON | | Approx. 0.8 | <ul style="list-style-type: none"> EGR valve position sensor (Refer to page F1-106) ECM terminal 3I voltage |
| | | | Idle | | | |
| 3K | Intake air temperature | Intake air temperature sensor | Ignition switch ON | Intake air temperature 20 °C { 68 °F } | Approx. 2.76 | <ul style="list-style-type: none"> Intake air temperature sensor (Refer to page F1-105) |
| 3L | Closed throttle position | Closed throttle position switch | Ignition switch ON | Accelerator pedal released | Below 1.0 | <ul style="list-style-type: none"> Closed throttle position switch (Refer to page F1-101) |
| | | | | Accelerator pedal depressed | B+ | |
| 3M | Heated oxygen sensor (Front) heater | Heated oxygen sensor | Constant | | Below 1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (Front) |
| 3N | — | — | — | | — | — |
| 3O | Analogue sensor ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> ECM 3O terminal harness (Open) |
| 3P | Power steering pressure | Power steering pressure switch | Ignition switch ON | | B+ | <ul style="list-style-type: none"> Power steering pressure switch (Refer to page F1-109) |
| | | | Idle | P/S not operating | | |
| | | | | P/S operating | Below 1.0 | |
| 4A | ECM ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> ECM 4A terminal harness (Open) |
| 4B | Power supply | Main relay | Ignition switch | OFF | Below 1.0 | <ul style="list-style-type: none"> Main relay (Refer to page F1-109) |
| | | | | ON | B+ | |
| 4C | Fuel injector ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> ECM 4C terminal harness (Open) |
| 4D | Output device ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> ECM 4D terminal harness (Open) |
| 4E | NE⊖ | Crankshaft position sensor | Ignition switch ON | | Approx. 2.4 | <ul style="list-style-type: none"> Crankshaft position sensor (Refer to page F1-100) |
| | | | Idle | | | |
| 4F | SGT | Camshaft position sensor (In distributor) | Ignition switch ON | | Below 1.0 or Approx. 5.0 | <ul style="list-style-type: none"> Camshaft position sensor (Refer to page F1-100) |
| | | | Idle | | Approx. 2.0 | |
| 4G | SGC | | Ignition switch ON | | Below 1.0 or Approx. 5.0 | |
| | | | Idle | | Approx. 0.9—1.3 | |
| 4H | NE⊕ | Crankshaft position sensor | Ignition switch ON | | Approx. 2.4 | <ul style="list-style-type: none"> Crankshaft position sensor (Refer to page F1-100) |
| | | | Idle | | | |
| 4I | Back-up power supply | Battery | Constant | | B+ | <ul style="list-style-type: none"> ECM 4I terminal — battery harness and connector |
| 4J | Pressure regulator control | PRC solenoid valve | Idle (Hot condition) | | Below 1.0 | <ul style="list-style-type: none"> PRC solenoid valve (Refer to page F1-71) |
| | | | Other | | B+ | |
| 4K | — | — | — | | — | — |

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|------------------------------------|--|--------------------|-------------------------|-------------|---|
| 4L | EGR boost sensor switching control | EGR boost sensor solenoid valve | Ignition switch ON | | B+ | • EGR boost sensor solenoid valve (Refer to page F1-77) |
| | | | Idle | | | |
| 4M | — | — | — | | — | — |
| 4N | IGT | Ignition control module (In distributor) | Ignition switch ON | | Approx. 0 | • Ignition control module (Refer to section G) |
| | | | Idle | | Approx. 0.3 | |
| 4O | EGR control (Vent) | EGR solenoid valve (Vent) | Ignition switch ON | | B+ | • EGR solenoid valve (Vent) (Refer to page F1-76) |
| | | | Idle | | | |
| 4P | EGR control (Vacuum) | EGR solenoid valve (Vacuum) | Ignition switch ON | | B+ | • EGR solenoid valve (Vacuum) (Refer to page F1-76) |
| | | | Idle | | | |
| 4Q | Idle air control | Idle air control valve | Ignition switch ON | | Approx. 0.7 | • Idle air control valve (Refer to page F1-54) |
| | | | Idle | After warm up (No load) | Approx. 10* | |
| 4R | — | — | — | | — | — |
| 4S | — | — | — | | — | — |
| 4T | Purge control | Purge solenoid valve | Ignition switch ON | | B+ | • Purge solenoid valve (Refer to page F1-81) |
| | | | Idle | | | |
| 4U | Fuel injector control | Fuel injector No.1 | Ignition switch ON | | B+ | • Fuel injector (Refer to page F1-65) |
| 4V | | Fuel injector No.2 | Idle | B+* | | |
| 4W | | Fuel injector No.3 | | | | |
| 4X | | Fuel injector No.4 | | | | |
| 4Y | — | — | — | | — | — |
| 4Z | — | — | — | | — | — |

* Engine Signal Monitor: Green and red lights flash



MASS AIR FLOW SENSOR

Inspection


Using the SST (Engine Signal Monitor)

1. Check the mass air flow sensor for damage and cracks.
2. Connect the **SSTs** to the ECM. (Refer to page F1-93.)
3. Measure the voltage at ECM terminal 3B. (Refer to page F1-95.)
4. Verify that the voltage is within the specification.

Specification

| Measuring condition | Voltage (V) |
|---------------------|-------------|
| Ignition switch ON | 1.0—1.5 |
| Idle | 1.5—5.0 |

5. If not as specified, inspect the harness and connector between the mass air flow sensor and the ECM terminal.
6. If there is correct terminal voltage and harness continuity, replace the mass air flow sensor. (Refer to page F1-48.)



Using the SST (NGS)

1. Check the mass air flow sensor for damage and cracks.
2. Connect the **SSTs** to the data link connector-2. (Refer to page F1-94.)
3. Select the “PID/DATA MONITOR AND RECORD” function of the NGS.
4. Select “MAF V” on the NGS display. The NGS measures and shows the voltage.

Specification

| Measuring condition | Voltage (V) |
|---------------------|-------------|
| Ignition switch ON | 1.0—1.5 |
| Idle | 1.5—5.0 |

5. If not as specified, inspect the harness and connector between the mass air flow sensor and the ECM terminal.
6. If there is correct terminal voltage and harness continuity, replace the mass air flow sensor. (Refer to page F1-48.)



Note

- The scan tool shows the mass airflow rate and load value.

Specification

| Engine speed (rpm) | Mass intake airflow amount (g/s) | Engine load calculated value (%) |
|--------------------|----------------------------------|----------------------------------|
| 650—750 (Idle) | 1.9—3.0 | 15.0—19.0 |
| 2,500* | 6.7—9.1 | 14.0—18.0 |

* No load, in neutral or park.



CAMSHAFT POSITION SENSOR

Inspection

1. Remove the distributor. (Refer to section G.)
2. Disconnect the fuel injector connector.
3. Connect the distributor 6-pin connector.

Warning



- Turning the ignition switch to ON with the fuel injector connector still connected will actuate the fuel injector.
- Turning the ignition switch to ON with the distributor 3-pin connector still connected will generate sparks, which can cause electrical shock. Disconnect the connector and avoid it from grounding to the vehicle body.

4. Connect the **SSTs** to the ECM. (Refer to page F2-93.)
5. Turn the ignition switch to ON.
6. Measure the voltage at ECM terminals 4F and 4G.
7. Rotate the distributor drive by hand and check the output signal.

Specification

| ECM terminal | | Signal |
|--------------|-----|----------------------------|
| 4F | SGT | Approx. 5 V (4 pulses/rev) |
| 4G | SGC | Approx. 5 V (1 pulse/rev) |

8. If not as specified, inspect the wiring harness and connector between the distributor and the ECM terminal.
9. If there is correct terminal voltage and harness continuity, replace the distributor. (Refer to section G.)



CRANKSHAFT POSITION SENSOR

Inspection

Resistance

1. Disconnect the crankshaft position sensor connector.
2. Measure the resistance between terminals A and B by using an ohmmeter.

Specification: 520—580 Ω [20°C {68°F}]


3. If not as specified, replace the crankshaft position sensor.

Air gap


1. Measure the air gap between the crankshaft pulley and the crankshaft position sensor by using a feeler gauge.

Specification: 0.5—1.5 mm {0.020—0.059 in}

2. If not as specified, replace the crankshaft pulley or the crankshaft position sensor.

**Replacement**


1. Disconnect the negative battery cable.
2. Remove the crankshaft position sensor.
3. Install in the reverse order of removal.

**CLOSED THROTTLE POSITION SWITCH****Inspection**

1. Disconnect the closed throttle position switch connector.
2. Check continuity between the switch and a ground.

| Throttle valve | Continuity |
|--------------------------|------------|
| Closed throttle position | Yes |
| Open | No |

3. If not as specified, check the condition of the wiring harness of the closed throttle position switch. Replace the closed throttle position switch and the throttle body (as an assembly), if necessary.
(Refer to page F1-48.)

**THROTTLE POSITION SENSOR****Inspection of resistance**

1. Disconnect the throttle position sensor connector.
2. Using an ohmmeter, measure the resistance between throttle position sensor terminals A and C.

Resistance: 4—6 kΩ

3. If not as specified, replace the throttle position sensor.
4. Reconnect the throttle position sensor connector.

Inspection of output voltage**Using the SST (Engine signal monitor)**


1. Connect the SSTs to the ECM as shown.
2. Turn ignition switch to ON.
3. Measure voltage at ECM terminal 3F under the following conditions.


Specification

| Throttle valve condition | Terminal voltage (V) |
|--------------------------|----------------------|
| Closed throttle position | 0.3—0.7 |
| Wide open throttle | 3.4—5.3 |

(The voltage increase is linear according to the throttle valve opening angle)

4. Disconnect the SSTs.
5. If not as specified, adjust the throttle position sensor.





Using the SST (NGS)


1. Connect the **SSTs** to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS.
3. Select "TP V" on the **SST** display.
4. Measure the TPS output voltage under the following conditions.

Specification

| Throttle valve condition | TPS output voltage (V) |
|--------------------------|------------------------|
| Closed throttle position | 0.3—0.7 |
| Wide open throttle | 3.4—5.3 |

(The voltage increase is linear according to the throttle valve opening angle)

5. Disconnect the **SSTs**.
6. If not as specified, adjust the throttle position sensor.



Adjustment

Using the SST (Engine signal monitor)

1. Verify that the throttle valve is fully closed.
2. Connect the **SSTs** to the ECM as shown.
3. Disconnect the throttle position sensor connector.
4. Turn the ignition switch to ON.
5. Using a voltmeter, measure the voltage at connector side terminal A.

Specification: 4.5—5.5 V

6. Reconnect the throttle position sensor connector.
7. Loosen the sensor mounting screws.
8. Adjust the sensor output voltage by rotating the sensor.



Specification (Closed throttle position)

| Connector terminal A voltage (V) | ECM terminal 3F voltage (V) |
|----------------------------------|-----------------------------|
| 4.5—4.9 | 0.4—0.5 |
| 4.9—5.1 | 0.4—0.6 |
| 5.1—5.5 | 0.5—0.6 |

9. Tighten the sensor mounting screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—21 in·lbf}






- Fully open the throttle valve and verify that the ECM terminal voltage are within the specification.

Specification (Wide open throttle)

| Connector terminal A voltage (V) | ECM terminal 3F voltage (V) |
|----------------------------------|-----------------------------|
| 4.5—4.7 | 3.5—4.4 |
| 4.7—4.8 | 3.6—4.5 |
| 4.8—4.9 | 3.7—4.6 |
| 4.9—5.0 | 3.7—4.8 |
| 5.0—5.1 | 3.8—4.9 |
| 5.1—5.3 | 4.0—5.0 |
| 5.3—5.4 | 4.1—5.1 |
| 5.4—5.5 | 4.2—5.2 |

- Disconnect the **SST**.
- If not as specified, replace the throttle position sensor.



Using the SST (NGS)

- Verify that the throttle valve is closed throttle position.
- Connect the **SSTs** to the data link connector-2.
- Disconnect the throttle position sensor connector.
- Turn the ignition switch to ON.
- Using a voltmeter measure the voltage at connector side terminal A.

Specification: 4.5—5.5 V

- Reconnect the throttle position sensor connector.
- Loosen the sensor mounting screws.
- Select the "PID/DATA MONITOR AND RECORD" function of NGS.
- Select "TP V" on the NGS display.
- Adjust the TPS output voltage by rotating the sensor.

Specification (Closed throttle position)

| Connector terminal A voltage (V) | TPS output voltage (V) |
|----------------------------------|------------------------|
| 4.5—4.9 | 0.4—0.5 |
| 4.9—5.1 | 0.4—0.6 |
| 5.1—5.5 | 0.5—0.6 |

- Tighten the sensor mounting screws.

Tightening torque:


1.6—2.6 N·m {16—24 kgf·m, 14—21 in·lbf}

- Wide open throttle and verify that the TPS terminal voltage are within the specification.

Specification (Wide open throttle)


| Connector terminal A voltage (V) | TPS output voltage (V) |
|----------------------------------|------------------------|
| 4.5—4.7 | 3.5—4.4 |
| 4.7—4.8 | 3.6—4.5 |
| 4.8—4.9 | 3.7—4.6 |
| 4.9—5.0 | 3.7—4.8 |
| 5.0—5.1 | 3.8—4.9 |
| 5.1—5.3 | 4.0—5.0 |
| 5.3—5.4 | 4.1—5.1 |
| 5.4—5.5 | 4.2—5.2 |

- Disconnect the **SSTs**.
- If not as specified, replace the throttle position sensor.



Replacement

- Disconnect the air hose. (Refer to page F1-48.)
- Disconnect the throttle position sensor connector.
- Remove the screws.
- Remove the throttle position sensor.
- Install the throttle position sensor.
- Adjust the throttle position sensor output voltage. (Refer to page F1-102.)
- Connect the air hose.



ENGINE COOLANT TEMPERATURE SENSOR

Removal

Note

- The engine coolant temperature sensor is at the rear of the engine.


- Disconnect the engine coolant temperature sensor connector.
- Remove the engine coolant temperature sensor.


Inspection

- Place the sensor in water with a thermometer and heat the water gradually.
- Measure the resistance of the sensor.

| Water temperature | Resistance (kΩ) |
|-------------------|-----------------|
| 20°C { 68°F} | 2.2—2.7 |
| 80°C { 176°F} | 0.29—0.35 |

- If not as specified, replace the engine coolant temperature sensor.






Installation

1. Install a new washer and the engine coolant temperature sensor.

Tightening torque:

25—29 N·m {2.5—3.0 kgf·m, 19—21 ft·lbf}

2. Connect the engine coolant temperature sensor connector.
3. Start the engine and check for coolant leakage.




INTAKE AIR TEMPERATURE SENSOR

Inspection

1. Disconnect the intake air temperature sensor connector.
2. Check the resistance of the sensor.

| Temperature | Resistance |
|----------------|--------------|
| 25°C { 77°F } | 29.7—36.3 kΩ |
| 85°C { 185°F } | 3.3—3.7 kΩ |

3. If not as specified, replace the intake air temperature sensor.




Replacement

1. Disconnect the intake air temperature sensor connector.
2. Remove the sensor.
3. Install the sensor and tighten it to the specified torque.

Tightening torque:

7.9—11.7 N·m {80—120 kgf·cm, 70—104 in·lbf}



HEATED OXYGEN SENSOR

Inspection

Sensor


Using the SST (Engine signal monitor)

1. Warm up the engine to normal operating temperature.
2. Connect the SSTs to the ECM. (Refer to page F1-93.)
3. Measure the voltage at ECM terminals 3C and 3D.

Spcification

| Engine condition | ECM terminal 3C | ECM terminal 3D |
|------------------|-----------------|-----------------|
| Idle | Below 1.0 V | Below 1.0 V |
| Deceleration | 0—1.0 V | 0—0.5 V |
| Acceleration | 0—1.0 V | 0.5—1.0 V |

4. If not as specified, inspect the following.
 - Fuel system
 - On-board diagnostic system (Refer to page F1-14.)
 - Intake-air system
5. If all the systems are OK, replace the heated oxygen sensor. (Refer to page F1-72.)




Using the SST (NGS)

1. Connect the **SSTs** to the data link connector-2. (Refer to page F1-94.)
2. Select the "PID/DATA MONITOR AND RECORD" function of the NGS.
3. Select "FHO2S, RHO2S" on the NGS display. The NGS measures and shows the voltage.

Spcification

| Engine condition | Voltage (FHO2S) | Voltage (RHO2S) |
|------------------|-----------------|-----------------|
| Idle | Below 1.0 V | Below 1.0 V |
| Deceleration | 0—1.0 V | 0—0.5 V |
| Acceleration | 0—1.0 V | 0.5—1.0 V |

4. If not as specified, inspect the following.
 - Fuel system
 - On-board diagnostic system (Refer to page F1-14.)
 - Intake-air system
5. If all the systems are OK, replace the heated oxygen sensor. (Refer to page F1-72.)




Heater

1. Disconnect the heated oxygen sensor connector.
2. Measure the resistance between heated oxygen sensor heater (FRONT B—C, REAR C—D terminals) by using an ohmmeter.

Specification: Approx. 6 Ω [20°C {68°F}]

3. If not as specified, replace the heated oxygen sensor. (Refer to page F1-72.)



EGR VALVE POSITION SENSOR


Inspection of output voltage

Using the SST (Engine signal monitor)

1. Connect the **SST** to the ECM as shown and connect a vacuum pump to the EGR valve.
2. Turn the ignition switch to ON.
3. Measure the voltage at the terminals as shown in the table.

| Terminal | ECM | Vacuum | |
|----------|-----|---------------------------|-----------------------------------|
| | | 0 kPa {0 mmHg, 0 inHg} | 20.0 kPa {150 mmHg, 5.90 inHg} |
| B | 3I | 4.5—5.5 V | |
| A | 3O | 0 V | |
| C | 3J | Approx. 0.8 V | Approx. 4.9 V |

4. If not correct at 3J terminal, check the wiring harness and 3I terminal of the ECM.



Using the SST (NGS)

1. Connect the **SSTs** (NGS) to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS and connect a vacuum pump.
3. Select "EGR" on the NGS display NGS measures and shown in the specification.


Specification

| Vacuum | EGR valve position signal voltage |
|--------------------------------|-----------------------------------|
| 0 kPa {0 mmHg, 0 inHg} | Approx. 0.8 V |
| 20.0 kPa {150 mmHg, 5.90 inHg} | Approx. 4.9 V |

4. If not correct EGR valve position signal voltage, check the wiring harness and 3I terminal of the ECM.


Inspection of resistance

1. Disconnect the EGR valve position sensor connector, and connect an ohmmeter.
2. Disconnect the vacuum hose from the EGR valve, and connect a vacuum pump.
3. Measure the resistance between the terminals as shown while vacuum is applied.



| Terminal | Vacuum | |
|----------|------------------------|--------------------------------|
| | 0 kPa {0 mmHg, 0 inHg} | 20.0 kPa {150 mmHg, 5.90 inHg} |
| A—B | Approx. 2.7 kΩ | |
| A—C | Approx. 0.5 kΩ | Approx. 2.7 kΩ |
| B—C | Approx. 2.4 kΩ | Approx. 0.1 kΩ |

4. If not as specified, replace the EGR valve.



EGR BOOST SENSOR

Inspection

Using the SST (Engine Signal Monitor)

1. Connect the **SSTs** to the ECM as shown.
2. Apply vacuum or pressure to the EGR boost sensor by using a vacuum pump. Measure the ECM terminal 3H.


Specification


| | |
|---------------------------------|---------------|
| 15 kPa {112.5 mmHg, 4.4 inHg} | 0.270—0.330 V |
| 40 kPa {300 mmHg, 11.8 inHg} | 1.395—1.705 V |
| 95 kPa {712.5 mmHg, 28.1 inHg} | 3.870—4.730 V |
| 105 kPa {787.5 mmHg, 31.0 inHg} | 4.320—5.280 V |

3. If not as specified, replace the EGR boost sensor.

Using the SST (NGS)

1. Connect the **SSTs** to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS and connect a vacuum pump.
3. Select "BARO V" on the NGS display. The NGS measures and shows the voltage.






Specification

- 15 kPa {112.5 mmHg, 4.4 inHg}: 0.270—0.330 V
- 40 kPa {300 mmHg, 11.8 inHg}: 1.395—1.705 V
- 95 kPa {712.5 mmHg, 28.1 inHg}: 3.870—4.730 V
- 105 kPa {787.5 mmHg, 31.0 inHg}: 4.320—5.280 V

4. If not as specified, replace the EGR boost sensor.




CLUTCH SWITCH

Inspection

1. Disconnect the clutch switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.


| Pedal | Continuity |
|-----------|------------|
| Depressed | Yes |
| Released | No |

4. If not as specified, replace the clutch switch.



Replacement

1. Disconnect the clutch switch connector.
2. Loosen the locknuts.
3. Remove the clutch switch.
4. Install in the reverse order of removal.
5. Adjust the pedal height. (Refer to section H.)



NEUTRAL SWITCH

Inspection

1. Disconnect the neutral switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

| Transaxle | Continuity |
|------------------------|------------|
| Neutral | Yes |
| Other ranges/positions | No |


4. If not as specified, replace the neutral switch.


Replacement

Replace the neutral switch as shown in the figure.

Tightening torque:

20—29 N·m {2.0—3.0 kgf·m, 15—21 ft·lbf}



**P/S PRESSURE SWITCH****Inspection**


1. Disconnect the P/S pressure switch connector.
2. Connect an ohmmeter to the sensor.
3. Start the engine and run it at idle. Check continuity of the sensor while turning the steering wheel.

| Steering wheel | Continuity |
|----------------|------------|
| Turning | Yes |
| Not turning | No |


4. If not as specified, replace the P/S pressure switch.

Replacement

Replace the P/S pressure switch as shown in the figure.

**Tightening torque:**

17—22 N·m {1.7—2.3 kgf·m, 13—16 ft·lbf}

**MAIN RELAY****Inspection**

1. Verify that the main relay clicks when the ignition switch is turned ON and OFF.
2. Apply battery positive voltage (B+) to terminal E and ground terminal A of the relay.
3. Check continuity of the relay as shown.

B+: Battery positive voltage

| Terminals | B+ not applied | B+ applied |
|-----------|----------------|------------|
| B—F | No continuity | Continuity |

4. If not as specified, replace the main relay.

TROUBLESHOOTING GUIDE

QUICK DIAGNOSIS CHART

This Quick Diagnosis Chart shows the relationship between troubleshooting items and inspection points.

| Item | Possible parts and reference page | Fuel system | | | | | Intake-air system | | Emission control system | | | | | Ignition system | | | | | | | | | | |
|------|-----------------------------------|---------------------------------------|-----------------------|-----------------------|--------------------|-------------|-------------------|-----------------------|-------------------------|---------------------|--------------------------------------|-----------------------|---------------------------------|-------------------------------|------------------|-----------------------|-------------------|-----------|-----------------------|--|--------------------------------|-------------------|------------|-----------------|
| | | F1-65 | F1-60 | F1-63 | F1-63 | F1-59 | F1-48 | F1-13 | F1-49 | F1-48 | F1-76 | F1-81 | F1-77 | F1-72 | F1-82 | F1-82 | F1-82 | F1-78 | section G | | | | | |
| | | Fuel injector | Fuel pump | Fuel pump relay | Pressure regulator | Fuel filter | Air leakage | Idle speed adjustment | Throttle body | Air cleaner element | EGR solenoid valve (vent and vacuum) | Purge solenoid valve | EGR valve, EGR function control | Three way catalytic converter | Fuel vapor valve | Check valve (two-way) | Charcoal canister | PCV valve | Distributor | Ignition control module (in distributor) | Ignition coil (in distributor) | High-tension lead | Spark plug | Ignition timing |
| 1 | Main or other fuse melts | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | <input type="radio"/> | | <input type="radio"/> | | | |
| 2 | Will not crank or cranks slowly | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | <input type="radio"/> | | <input type="radio"/> | | | |
| 3 | Crank normally but will not start | No combustion | | | | | | | | | | | | | | | | | | | | | | |
| 4 | | Partial combustion — when engine cold | | | | | | | | | | | | | | | | | | | | | | |
| 5 | | Partial combustion — after warm-up | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Crank normally but hard to start | Any engine temp. | | | | | | | | | | | | | | | | | | | | | | |
| 7 | | When engine cold | | | | | | | | | | | | | | | | | | | | | | |
| 8 | | After warm-up | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Engine stalls | Idle at any engine temp. | | | | | | | | | | | | | | | | | | | | | | |
| 10 | | During fast idle | | | | | | | | | | | | | | | | | | | | | | |
| 11 | | Idle after warm-up | | | | | | | | | | | | | | | | | | | | | | |
| 12 | | Idle with A/C, P/S, and/or E/L ON | | | | | | | | | | | | | | | | | | | | | | |
| 13 | | Driveaway | | | | | | | | | | | | | | | | | | | | | | |
| 14 | | On acceleration | | | | | | | | | | | | | | | | | | | | | | |
| 15 | | While cruising | | | | | | | | | | | | | | | | | | | | | | |
| 16 | | On deceleration | | | | | | | | | | | | | | | | | | | | | | |
| 17 | Rough idle | Idle at any engine temp. | | | | | | | | | | | | | | | | | | | | | | |
| 18 | | During fast idle | | | | | | | | | | | | | | | | | | | | | | |
| 19 | | Idle after warm-up | | | | | | | | | | | | | | | | | | | | | | |
| 20 | | Idle with A/C, P/S, and/or E/L ON | | | | | | | | | | | | | | | | | | | | | | |
| 21 | | On deceleration | | | | | | | | | | | | | | | | | | | | | | |
| 22 | Poor acceleration | Driveaway | | | | | | | | | | | | | | | | | | | | | | |
| 23 | | On acceleration | | | | | | | | | | | | | | | | | | | | | | |
| 24 | High idle speed after warm-up | | | | | | | <input type="radio"/> | | | | | | | | | | | | | | | | |

* 1996 626/MX-6 Body Electrical Troubleshooting Manual

| Control system | | | | | | | | | | | Possible parts and reference page | | | | | | | | | | | | |
|-----------------------|-----------------------------------|--------------------------|-----------------------|--------------------------|----------------------|-----------------------------|-----------------------|-----------------------|------------------------|-----------------------|-----------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-------------------------|-----------------------|-----------------------|-----------------------|-----------------------------------|---------------------------------------|---|-----------------------------------|
| F1-99 | F1-104 | F1-101 | F1-105 | F1-100 | BETM* | F1-108 | F1-109 | BETM* | F1-54 | F1-93 | BETM* | F1-70 | BETM* | BETM* | section E | BETM* | BETM* | BETM* | F1-109 | section G | Item | | |
| Mass air flow sensor | Engine coolant temperature sensor | Throttle position sensor | Heated oxygen sensor | Camshaft position sensor | Vehicle speed sensor | Clutch and neutral switches | P/S pressure switch | Brake switch | Idle air control valve | ECM | A/C relay | PRC solenoid valve | Blower switch | Condenser fan relay | Cooling fan relay | Air conditioning switch | Headlight switch | Rear window defroster | Main relay | Starter, Starter interlock switch | | | |
| <input type="radio"/> | | | <input type="radio"/> | | | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Main or other fuse melts | 1 | |
| | | | | | | | | | | | | | | | | | | | | <input type="radio"/> | Will not crank or cranks slowly | 2 | |
| | | | | | | | | | | <input type="radio"/> | | | | | | | | | | <input type="radio"/> | No combustion | 3 4 5 | |
| <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | Partial combustion — when engine cold | | Crank normally but will not start |
| | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | Partial combustion — after warm-up | | |
| | <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | Any engine temp. | 6 7 8 | |
| | | | | | | | | | | <input type="radio"/> | | | | | | | | | | | When engine cold | | Crank normally but hard to start |
| | | | | | | | | | | | <input type="radio"/> | | | | | | | | | | After warm-up | | |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | Idle at any engine temp. | 9 10 11 12 13 14 15 16 | |
| | | | | | | | | | | | | | | | | | | | | | During fast idle | | |
| <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | <input type="radio"/> | Idle after warm-up | | |
| | | | | | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | | | | | <input type="radio"/> | <input type="radio"/> | | | Idle with A/C, P/S, and/or E/L ON | | |
| | <input type="radio"/> | | | | | | | | <input type="radio"/> | | | | | | | | | | | | Driveaway | | |
| <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | On acceleration | | |
| <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | <input type="radio"/> | While cruising | | |
| <input type="radio"/> | | | <input type="radio"/> | | | <input type="radio"/> | | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | <input type="radio"/> | On deceleration | | |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | Idle at any engine temp. | 17 18 19 20 21 | |
| | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | During fast idle | | |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | <input type="radio"/> | Idle after warm-up | | |
| | | | | | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | | | | | <input type="radio"/> | <input type="radio"/> | | | Idle with A/C, P/S, and/or E/L ON | | |
| | | | | | | | | | | | | | | | | | | | | | On deceleration | | |
| <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | Driveaway | 22 23 | |
| <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | On acceleration | | |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | High idle speed after warm-up | 24 |

* 1996 626/MX-6 Body Electrical Troubleshooting Manual

| Possible parts and reference page | Fuel system | | | | | Intake-air system | | Emission control system | | | | | | | Ignition system | | | | | | | | |
|--|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-------------------------|-----------------------|--------------------------------------|-----------------------|---------------------------------|-------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|--|--------------------------------|-------------------|-----------------------|-----------------|
| | F1-65 | F1-60 | F1-63 | F1-63 | F1-59 | F1-48 | F1-13 | F1-49 | F1-48 | F1-76 | F1-81 | F1-77 | F1-72 | F1-82 | F1-82 | F1-82 | F1-78 | section G | | | | | |
| Item | Fuel injector | Fuel pump | Fuel pump relay | Pressure regulator | Fuel filter | Air leakage | Idle speed adjustment | Throttle body | Air cleaner element | EGR solenoid valve (vent and vacuum) | Purge solenoid valve | EGR valve, EGR function control | Three way catalytic converter | Fuel vapor valve | Check valve (two-way) | Charcoal canister | PCV valve | Distributor | Ignition control module (in distributor) | Ignition coil (in distributor) | High-tension lead | Spark plug | Ignition timing |
| 25 Idle fluctuates/Idle hunts | <input type="radio"/> | | | | | <input type="radio"/> | | | | | | | | | | | <input type="radio"/> | | | | | <input type="radio"/> | |
| 26 Hesitates/Stumbles on acceleration | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | <input type="radio"/> | | <input type="radio"/> | | | | | | <input type="radio"/> | <input type="radio"/> | | | <input type="radio"/> | |
| 27 Surges while cruising | <input type="radio"/> | | | | | | | | | | | | <input type="radio"/> | | | | | | | | | <input type="radio"/> | |
| 28 Lack of power | <input type="radio"/> | | | | <input type="radio"/> | | | | <input type="radio"/> | | | | <input type="radio"/> | | | | | | <input type="radio"/> | | | | |
| 29 Poor fuel economy | | | | <input type="radio"/> | | <input type="radio"/> | | | | | | | | | | | | <input type="radio"/> | | | | | |
| 30 A/C does not work | | | | | | | | | | | | | | | | | | | | | | | |
| 31 Knocking/Pinging | | | | | | | | | | | | | | | | | | | | | | | |
| 32 Fuel odor | | | | | | | | | | | <input type="radio"/> | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | |
| 33 Exhaust sulfur smell | | | | | | | | | | | | | | | | | | | | | | | |
| 34 High oil consumption | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | |
| 35 NGS displays "LINK COMMUNICATION ERROR" | | | | | | | | | | | | | | | | | | | | | | | |
| 36 MIL never ON | | | | | | | | | | | | | | | | | | | | | | | |

* 1996 626/MX-6 Body Electrical Troubleshooting Manual

| Control system | | | | | | | | | | Possible parts and reference page | | | | | | | | | | | | | |
|----------------------|-----------------------------------|--------------------------|----------------------|--------------------------|----------------------|-----------------------------|---------------------|--------------|------------------------|-----------------------------------|-----|-----------|--------------------|---------------|---------------------|-------------------|-------------------------|------------------|-----------------------|------------|-----------------------------------|---|----|
| Mass air flow sensor | Engine coolant temperature sensor | Throttle position sensor | Heated oxygen sensor | Camshaft position sensor | Vehicle speed sensor | Clutch and neutral switches | P/S pressure switch | Brake switch | Idle air control valve | | ECM | A/C relay | PRC solenoid valve | Blower switch | Condenser fan relay | Cooling fan relay | Air conditioning switch | Headlight switch | Rear window defroster | Main relay | Starter, Starter interlock switch | Item | |
| | | | | | | | | | | | | | | | | | | | | | Idle fluctuates/Idle hunts | 25 | |
| | | | | | | | | | | | | | | | | | | | | | | Hesitates/Stumbles on acceleration | 26 |
| | | | | | | | | | | | | | | | | | | | | | | Surges while cruising | 27 |
| | | | | | | | | | | | | | | | | | | | | | | Lack of power | 28 |
| | | | | | | | | | | | | | | | | | | | | | | Poor fuel economy | 29 |
| | | | | | | | | | | | | | | | | | | | | | | A/C does not work | 30 |
| | | | | | | | | | | | | | | | | | | | | | | Knocking/Pinging | 31 |
| | | | | | | | | | | | | | | | | | | | | | | Fuel odor | 32 |
| | | | | | | | | | | | | | | | | | | | | | | Exhaust sulfur smell | 33 |
| | | | | | | | | | | | | | | | | | | | | | | High oil consumption | 34 |
| | | | | | | | | | | | | | | | | | | | | | | NGS displays "LINK COMMUNICATION ERROR" | 35 |
| | | | | | | | | | | | | | | | | | | | | | | MIL never ON | 36 |

* 1996 626/MX-6 Body Electrical Troubleshooting Manual

| INPUT DEVICE | | OUTPUT DEVICE | | FUEL INJECTION AMOUNT | FUEL INJECTION TIMING | FUEL PUMP RELAY | IGNITION CONTROL MODULE | A/C RELAY (A/C CUT-OFF) | BAC VALVE (IDLE AIR CONTROL VALVE) | COOLING FAN RELAY | PURGE SOLENOID VALVE | EGR SOLENOID VALVE | PRESSURE REGULATOR CONTROL SOLENOID VALVE | SELF-DIAGNOSIS CHECKER (DIAGNOSTIC TROUBLE CODE) AND MALFUNCTION INDICATOR LIGHT (MIL) | SELF-DIAGNOSIS CHECKER (MONITOR LIGHT) |
|------------------------------------|------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|------------------------------------|--------------------------|--------------------------|--------------------------|---|--|--|
| | | FUEL INJECTOR | | | | | | | | | | | | | |
| CAMSHAFT POSITION SENSOR | SGT SIGNAL | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | SGC SIGNAL | | <input type="checkbox"/> | | | | | | | | | | | <input type="checkbox"/> | <input type="checkbox"/> |
| CLOSED THROTTLE POSITION SWITCH | | <input type="checkbox"/> | <input type="checkbox"/> | | | | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | <input type="checkbox"/> |
| THROTTLE POSITION SENSOR | | <input type="checkbox"/> | <input type="checkbox"/> | | | | | <input type="checkbox"/> | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | |
| MASS AIR FLOW SENSOR | | <input type="checkbox"/> | | | | | <input type="checkbox"/> | | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | | <input type="checkbox"/> | |
| ENGINE COOLANT TEMPERATURE SENSOR | | <input type="checkbox"/> | | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | |
| INTAKE AIR TEMPERATURE SENSOR | | <input type="checkbox"/> | | | | | | | <input type="checkbox"/> | | | | <input type="checkbox"/> | <input type="checkbox"/> | |
| HEATED OXYGEN SENSOR | | <input type="checkbox"/> | | | | | | | | | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> |
| AIR CONDITIONING SWITCH | | | | | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | <input type="checkbox"/> |
| P/S PRESSURE SWITCH | | | | | | | | | <input type="checkbox"/> | | | | | | <input type="checkbox"/> |
| BRAKE SWITCH | | | | | | | | | | | | | | | <input type="checkbox"/> |
| E/L SIGNAL* | | | | | | | | | <input type="checkbox"/> | | | | | | <input type="checkbox"/> |
| NEUTRAL AND CLUTCH SWITCHES | | <input type="checkbox"/> | | | | | <input type="checkbox"/> | | <input type="checkbox"/> | | <input type="checkbox"/> | | | | <input type="checkbox"/> |
| DATA LINK CONNECTOR (TEN TERMINAL) | | | | | | | <input type="checkbox"/> | | <input type="checkbox"/> | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| VEHICLE SPEED SENSOR | | | | | | | | | <input type="checkbox"/> | | | | | | |
| DAYTIME RUNNING LIGHT (CANADA) | | | | | | | | | <input type="checkbox"/> | | | | | | |
| EGR VALVE POSITION SENSOR | | | | | | | | | | | | | | <input type="checkbox"/> | |

* E/L SIGNAL: Blower fan control switch at third position or higher, headlights ON, rear window defroster ON or cooling fan ON.

Output devices and engine condition


| ENGINE CONDITION OUTPUT DEVICE | | CRANK- ING (COLD EN- GINE) | WARMING UP (DUR- ING IDLE) | MEDIUM LOAD | | ACCEL- ERA- TION | HEAVY LOAD | DECEL- ERA- TION | IDLE | IG: ON (ENGINE NOT RUN- NING) | REMARK |
|---|-----------------------------|---------------------------------------|---------------------------------------|-------------------------|---------------------|------------------------|-----------------------------|------------------------|---------------------------------------|--|--------|
| | | | | COLD | WARM | | | | | | |
| FUEL INJECTOR | FUEL INJECTION AMOUNT | Rich | | Normal | Rich | | Fuel cut* | Normal | No in- jection | * Engine speed: Above 1,500 rpm | |
| FUEL PUMP RELAY | | ON | | | | | | | OFF | | |
| IGNITION CONTROL MOD- ULE | | Fixed at BTDC 6° | Advanced: depends on engine condition | | | | | | | | |
| PURGE SOLENOID VALVE | | OFF | | ON (Purge) | | | OFF | | | | |
| EGR SOLENOID VALVE (VACUUM) | | OFF | ON* (Fixed) | ON* (Closed loop) | ON* (Fixed) | OFF | | | * Engine speed: 1,000—4,250 rpm | | |
| EGR SOLENOID VALVE (VENT) | | ON (Fixed) | OFF | ON (Closed loop) | OFF | ON | | | | | |
| PRESSURE REGULATOR CONTROL SOLENOID VALVE | | OFF (Vacuum to pressure regulator) | | | | | | ON* | OFF | * During hot start | |
| BAC VALVE | IAC VALVE | ON (Closed loop duty) | ON (Fixed duty) | | | | ON (Closed loop duty) | OFF | | | |
| | AIR VALVE | OPEN | | CLOSED | | | — | | | | |
| A/C RELAY | | OFF (A/C cut) | ON | | OFF (A/C cut) | ON | | OFF | | | |

USING THIS SECTION


Introduction

Most of the fuel and emission control systems are electronically controlled, often making it difficult to diagnose problems, especially intermittent ones. Before undertaking actual checks, take a few minutes to talk with the customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially the intermittent ones. Through a talk with the customer, you will usually find out what the symptoms are and under what conditions they occur.


Work flow



Diagnostic index



Troubleshooting chart

| | | | |
|--|--|-----|---|
| 9 10 11 | ENGINE STALLS | | <ul style="list-style-type: none"> • IDLE AT ANY ENGINE TEMP. • DURING FAST IDLE • IDLE AFTER WARM-UP |
| DESCRIPTION • Engine stops unexpectedly at idle and/or during fast idle operation | | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged ② Fuel pump <ul style="list-style-type: none"> • Maximum pressure low ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection of connector ④ Air leakage in intake-air system ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑦ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑨ BAC valve <ul style="list-style-type: none"> • Air valve stuck | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is there no DTCs displayed on SST with ignition switch ON?  page F1-14 | Yes | No DTCs displayed <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 8 • If symptom occurs at idle after warm-up, go to step 9 |
| | | No | DTC No. displayed Check for cause (Refer to specified check sequence) page F1-16 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Do Engine Signal Monitor lights flash for specified terminals while cranking engine? page F1-93 Terminal: 4U, 4V, 4W, 4X | Yes | Go to next step |
| | | No | Check follows according to results: If light does not flash and 0V indicated for each terminal; <ul style="list-style-type: none"> • Continuity of fuel injector(s) • Continuity between ECM and fuel injector(s) • Condition of injection connector and ECM connector Repair or replace parts and/or wiring harness as necessary |

DESCRIPTION:

This further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "page" mark.

ACTION:

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page specified by the "page" mark.




DIAGNOSTIC INDEX

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|-----------------------------------|--|-----------|
| No. | TROUBLE | | |
| 1 | Main or other fuse melts | — | F1-121 |
| 2 | Will not crank or cranks slowly | Starter does not work Starter cranks engine at slow speed | section G |
| 3 | Crank normally but will not start | No combustion | F1-122 |
| 4 | | Partial combustion — when engine cold | F1-122 |
| 5 | | Partial combustion — when engine warm | F1-124 |
| 6 | Crank normally but hard to start | Any engine temp. | F1-125 |
| 7 | | When engine cold | |
| 8 | | After warm-up | |
| 9 | Engine stalls | Idle at any engine temp. | F1-127 |
| 10 | | During fast idle | |
| 11 | | Idle after warm-up | |
| 12 | | Idle with A/C, P/S, and/or E/L ON | F1-130 |
| 13 | | Driveaway | F1-131 |
| 14 | | On acceleration | F1-132 |
| 15 | | While cruising | |
| 16 | | On deceleration | F1-134 |
| 17 | Rough idle | Idle at any engine temp. | F1-136 |
| 18 | | During fast idle | |
| 19 | | Idle after warm-up | |
| 20 | | Idle with A/C, P/S, and/or E/L ON | F1-139 |
| 21 | | On deceleration | F1-140 |

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|---|---|--------|
| No. | TROUBLE | | |
| 221 | Poor acceleration | Driveaway Engine speed increases normally but vehicle speed slowly increases during driveaway | F1-143 |
| 23 | | On acceleration Engine speed increases normally but vehicle speed slowly increases during acceleration | |
| 24 | High idle speed after warm-up | Idle speed continues at fast idle after warm-up Engine speed returns slowly to idle after accelerator is released | F1-145 |
| 25 | Idle fluctuates/Idle hunts | Engine speed changes back and forth between specified idle speed and higher speed | F1-146 |
| 26 | Hesitates/Stumbles on acceleration | Momentary pause at beginning of acceleration or during acceleration | F1-148 |
| 27 | Surges while cruising | Momentary minor irregularity in engine output at steady vehicle speed | F1-150 |
| 28 | Lack of power | Performance poor under load (i.e., power down when climbing hills) | F1-151 |
| 29 | Poor fuel economy | Fuel economy unsatisfactory | F1-151 |
| 30 | A/C does not work | A/C compressor magnetic clutch does not engage when Air conditioning switch ON | F1-151 |
| 31 | Knocking/Pinging | Noise produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | F1-151 |
| 32 | Fuel odor | Gasoline fuel smell or visible leaks | F1-152 |
| 33 | Exhaust sulfur smell | Rotten egg smell from exhaust | F1-152 |
| 34 | High oil consumption | Oil consumption excessive | F1-152 |
| 35 | NGS displays "LINK COMMUNICATION ERROR" | NGS displays "link communication error" | F1-152 |
| 36 | MIL never ON | NGS indicates Diagnostic Trouble Code No. but MIL never ON | F1-152 |

Description of Drivability Problems

- STUMBLE : Mildly irregular performance during acceleration.
- HESITATION : A dip or flat spot in performance just after the accelerator pedal is depressed.
- SURGE : Continuous irregular performance during cruising.



Fuel Pressure Release and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".


Fuel Line Safety Procedures
















1. Release the fuel pressure before disconnecting a fuel line.
 - (1) Start the engine.
 - (2) Remove the fuel pump relay.
 - (3) After the engine stalls, turn the ignition switch to OFF.
 - (4) Install the fuel pump relay.
2. Avoid leakage.
 - (1) When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - (2) Plug the hose after removal.
3. Install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose.

SYMPTOM TROUBLESHOOTING



| 1 | MAIN OR OTHER FUSE MELTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--------------|---|-------------|---------------------------|-----------|--------------------------|------------|---------------------------------|---------------|---|------------|---|-------|------------------------|-------|----------------------|-------|----------------------|-------|--------------------|-------|--------------------------------------|-------|------------------------|-------|----------------------|-------|----------------------|---------------|--|-------------|---|-------|------------|-------|------------|-------------|--|-------------|---------------------------------------|
| <p>[TROUBLESHOOTING HINTS] Check the condition of the fuse</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>The diagram shows a central fuse box labeled 'FUSE'. Two circular callouts are connected to the fuse box by lines. The left callout shows two wires touching, labeled 'Shorted harness', with an arrow pointing down to the text 'Repair shorted harness and replace fuse'. The right callout shows a wire with a frayed or broken end, labeled 'Deterioration', with an arrow pointing down to the text 'Replace fuse'.</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 35%; text-align: center;">Damaged Fuse</th> <th style="text-align: center;">Related Wiring Harness</th> </tr> </thead> <tbody> <tr> <td>MAIN (100A)</td> <td>Main fuse ————— Generator</td> </tr> <tr> <td>BTN (60A)</td> <td>BTN fuse ————— ROOM fuse</td> </tr> <tr> <td>ROOM (15A)</td> <td>ROOM fuse ————— ECM terminal 4I</td> </tr> <tr> <td>EGI INJ (30A)</td> <td> <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">Main relay</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> </td> </tr> </table> </td> </tr> <tr> <td>EGI INJ (15A)</td> <td> <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">ENGINE fuse</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> </td> </tr> </table> </td> </tr> <tr> <td>METER (15A)</td> <td>METER fuse ————— Data link connector terminal +B</td> </tr> <tr> <td>WIPER (20A)</td> <td>WIPER fuse ————— Heated oxygen sensor</td> </tr> </tbody> </table> | | Damaged Fuse | Related Wiring Harness | MAIN (100A) | Main fuse ————— Generator | BTN (60A) | BTN fuse ————— ROOM fuse | ROOM (15A) | ROOM fuse ————— ECM terminal 4I | EGI INJ (30A) | <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">Main relay</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> </td> </tr> </table> | Main relay | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> | ————— | Fuel injectors | ————— | ECM terminal 4B | ————— | Distributor | ————— | PRC solenoid valve | ————— | EGR solenoid valve (vent and vacuum) | ————— | Idle air control valve | ————— | Purge solenoid valve | ————— | Mass air flow sensor | EGI INJ (15A) | <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">ENGINE fuse</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> </td> </tr> </table> | ENGINE fuse | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> | ————— | Main relay | ————— | Main relay | METER (15A) | METER fuse ————— Data link connector terminal +B | WIPER (20A) | WIPER fuse ————— Heated oxygen sensor |
| Damaged Fuse | Related Wiring Harness | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAIN (100A) | Main fuse ————— Generator | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BTN (60A) | BTN fuse ————— ROOM fuse | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ROOM (15A) | ROOM fuse ————— ECM terminal 4I | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGI INJ (30A) | <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">Main relay</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> </td> </tr> </table> | Main relay | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> | ————— | Fuel injectors | ————— | ECM terminal 4B | ————— | Distributor | ————— | PRC solenoid valve | ————— | EGR solenoid valve (vent and vacuum) | ————— | Idle air control valve | ————— | Purge solenoid valve | ————— | Mass air flow sensor | | | | | | | | | | | | | | | | | | | | | | |
| Main relay | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Fuel injectors</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">ECM terminal 4B</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Distributor</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">PRC solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">EGR solenoid valve (vent and vacuum)</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Idle air control valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Purge solenoid valve</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Mass air flow sensor</td></tr> </table> | ————— | Fuel injectors | ————— | ECM terminal 4B | ————— | Distributor | ————— | PRC solenoid valve | ————— | EGR solenoid valve (vent and vacuum) | ————— | Idle air control valve | ————— | Purge solenoid valve | ————— | Mass air flow sensor | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Fuel injectors | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | ECM terminal 4B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Distributor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | PRC solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | EGR solenoid valve (vent and vacuum) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Idle air control valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Purge solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Mass air flow sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGI INJ (15A) | <table style="width: 100%; border: none;"> <tr> <td style="border: none; width: 40%;">ENGINE fuse</td> <td style="border: none;"> <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> </td> </tr> </table> | ENGINE fuse | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> | ————— | Main relay | ————— | Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENGINE fuse | <table style="width: 100%; border: none;"> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> <tr><td style="border: none;">—————</td><td style="border: none;">Main relay</td></tr> </table> | ————— | Main relay | ————— | Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ————— | Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| METER (15A) | METER fuse ————— Data link connector terminal +B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| WIPER (20A) | WIPER fuse ————— Heated oxygen sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |


| | | |
|---|---|------------------------|
| 3 | CRANKS NORMALLY BUT WILL NOT START | • NO COMBUSTION |
| DESCRIPTION • Starter cranks engine at normal speed but engine shows no indication of firing | | |
| [TROUBLESHOOTING HINTS] | | |
| ① Distributor <ul style="list-style-type: none"> Poor connection of connector Open in ignition coil ➡ section G | | |
| ② Main relay <ul style="list-style-type: none"> Poor connection of connector Malfunction of relay ➡ page F1-109 | | |
| ③ ECM <ul style="list-style-type: none"> No IGT signal output from ECM terminal 4N to ignition control module (in distributor) ➡ section G | | |



| | | | |
|---|--|--|---|
| 4 | CRANKS NORMALLY BUT WILL NOT START | • PARTIAL COMBUSTION — WHEN ENGINE COLD | |
| DESCRIPTION | | | |
| <ul style="list-style-type: none"> Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold at initial starting Engine will not continue running when cold or when ignition switch is returned from STA to IG position Refer to "ENGINE STALLS" if this symptom appears after engine stalls Fuel in tank Battery in normal condition | | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① BAC valve <ul style="list-style-type: none"> Malfunction of air valve Idle air control valve stuck | | | |
| ② Fuel injector <ul style="list-style-type: none"> Poor connection | | | |
| ③ Fuel pump relay <ul style="list-style-type: none"> Poor connection | | | |
| ④ Fuel pump <ul style="list-style-type: none"> Poor connection of connector | | | |
| ⑤ Distributor <ul style="list-style-type: none"> Cap and/or rotor damaged Poor connection of connector | | | |
| ⑥ Mass air flow sensor <ul style="list-style-type: none"> Poor connection of connector | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there no DTCs displayed on SST with ignition switch ON? ➡ page F1-14  | Yes | No DTCs displayed Go to next step |
| | | No | DTC No. displayed Check for cause (Refer to specified check sequence) ➡ page F1-16 "LINK COMMUNICATION ERROR" displays Refer to No.35 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Does engine start when throttle valve held quarter open? | Yes | Check air valve operation ➡ page F1-54 |
| | | No | Go to next step |
| 3 | Do Engine Signal Monitor lights flash for specified terminals while cranking engine? ➡ page F1-93 Terminal: 4U, 4V, 4W, 4X | Yes | Go to next step |
| | | No | Check follows according to results: If light does not flash and 0V indicated for each terminal; <ul style="list-style-type: none"> Continuity of fuel injector Continuity between ECM and fuel injector(s) Condition of fuel injector connector and ECM connector female terminals Repair or replace parts and/or wiring harness as necessary |



| STEP | INSPECTION | | ACTION |
|------|--|------------|---|
| 4 | <p>Connect jumper wire between F/P and GND terminals of data link connector; will engine start?</p>  <p>GND F/P DATA LINK CONNECTOR</p> | <p>Yes</p> | <p>Check follows:</p> <ul style="list-style-type: none"> • 1U terminal voltage at ECM  page F1-93 • Continuity between 1U terminal and fuel pump relay connector terminal • Condition of ECM and fuel pump relay connector female terminals |
| | | <p>No</p> | <p>Check if fuel pump operating sound is heard</p> <ul style="list-style-type: none"> • If yes, go to next step • If no, check fuel pump and wiring harness  page F1-60 |
| 5 | <p>Are mass air flow sensor terminal voltages at ECM correct?</p> <p> page F1-93</p> <p>3B terminal: 1.0—1.5V (Ign. ON) 1.5—5.0V (Engine running)</p> | <p>Yes</p> | <p>Go to next step</p> |
| 6 | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p> page F1-57</p> <p>Fuel line pressure: 260—320 kPa {2.7—3.3 kgf/cm², 37—46 psi}</p>  <p>INSTALL CLAMPS</p> | <p>Yes</p> | <p>Go to next step</p> |
| | | <p>No</p> | <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator  page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure  page F1-61 |
| 7 | <p>Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <p>Yes</p> | <p>Go to next step</p> |
| | | <p>No</p> | <p>Check follows</p> <ul style="list-style-type: none"> • Distributor cap and rotor  section G • High-tension leads  section G |
| 8 | <p>Are fuel injectors OK?</p> <ul style="list-style-type: none"> • No fuel leakage  page F1-66 • Fuel injectors not clogged  page F1-65 | <p>Yes</p> | <p>Go to next step</p> |
| | | <p>No</p> | <p>Replace fuel injector(s)  page F1-65</p> |
| 9 | <p>Try known good ECM; does condition improve?</p> <p> page F1-93</p> | | |













| | | | | |
|---|---|--------------------------------------|---|--|
| 5 | CRANKS NORMALLY BUT WILL NOT START | • PARTIAL COMBUSTION — AFTER WARM-UP | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm • Engine will not continue running when ignition switch is returned from STA to IG position | | | |
| [TROUBLESHOOTING HINTS] | | | | |
| <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; vertical-align: top;"> <ul style="list-style-type: none"> ① Pressure regulator <ul style="list-style-type: none"> • Hold fuel pressure low ② Throttle body <ul style="list-style-type: none"> • Carbon on throttle valve </td> <td style="width: 85%; vertical-align: top; text-align: right;"> <ul style="list-style-type: none"> 🔍 page F1-63 🔍 page F1-49 </td> </tr> </table> | | | <ul style="list-style-type: none"> ① Pressure regulator <ul style="list-style-type: none"> • Hold fuel pressure low ② Throttle body <ul style="list-style-type: none"> • Carbon on throttle valve | <ul style="list-style-type: none"> 🔍 page F1-63 🔍 page F1-49 |
| <ul style="list-style-type: none"> ① Pressure regulator <ul style="list-style-type: none"> • Hold fuel pressure low ② Throttle body <ul style="list-style-type: none"> • Carbon on throttle valve | <ul style="list-style-type: none"> 🔍 page F1-63 🔍 page F1-49 | | | |









| | | | | | | |
|---|---|---|--|---|-----------|---|
| <p>6 7 8</p> | <p>CRANKS NORMALLY BUT HARD TO START</p> | <ul style="list-style-type: none"> • ANY ENGINE TEMP. • WHEN ENGINE COLD • AFTER WARM-UP | | | | |
| <p>DESCRIPTION</p> <ul style="list-style-type: none"> • Starter cranks engine at normal speed but engine requires excessive cranking time before starting • Engine starts after stalling a few times • Battery in normal condition • Engine runs normally at idle (if idle condition not OK, refer to “Rough idle” [Nos. 19—23]) | | | | | | |
| <p>[TROUBLESHOOTING HINTS]</p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) <p>② Fuel pump</p> <ul style="list-style-type: none"> • Malfunction of pump <p>③ Pressure regulator</p> <ul style="list-style-type: none"> • Pressure regulator stuck <p>④ Spark plug</p> <ul style="list-style-type: none"> • Dirty or worn spark plug(s) </td> <td style="vertical-align: top;"> <p>⑤ PRC solenoid valve</p> <ul style="list-style-type: none"> • PRC solenoid valve <p>⑥ Throttle body</p> <ul style="list-style-type: none"> • Carbon on throttle valve <p>⑦ EGR solenoid valve (vacuum or vent)</p> <ul style="list-style-type: none"> • Solenoid valve stuck <p>⑧ EGR control valve</p> <ul style="list-style-type: none"> • EGR control valve stuck </td> </tr> </table> | | | <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) <p>② Fuel pump</p> <ul style="list-style-type: none"> • Malfunction of pump <p>③ Pressure regulator</p> <ul style="list-style-type: none"> • Pressure regulator stuck <p>④ Spark plug</p> <ul style="list-style-type: none"> • Dirty or worn spark plug(s) | <p>⑤ PRC solenoid valve</p> <ul style="list-style-type: none"> • PRC solenoid valve <p>⑥ Throttle body</p> <ul style="list-style-type: none"> • Carbon on throttle valve <p>⑦ EGR solenoid valve (vacuum or vent)</p> <ul style="list-style-type: none"> • Solenoid valve stuck <p>⑧ EGR control valve</p> <ul style="list-style-type: none"> • EGR control valve stuck | | |
| <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) <p>② Fuel pump</p> <ul style="list-style-type: none"> • Malfunction of pump <p>③ Pressure regulator</p> <ul style="list-style-type: none"> • Pressure regulator stuck <p>④ Spark plug</p> <ul style="list-style-type: none"> • Dirty or worn spark plug(s) | <p>⑤ PRC solenoid valve</p> <ul style="list-style-type: none"> • PRC solenoid valve <p>⑥ Throttle body</p> <ul style="list-style-type: none"> • Carbon on throttle valve <p>⑦ EGR solenoid valve (vacuum or vent)</p> <ul style="list-style-type: none"> • Solenoid valve stuck <p>⑧ EGR control valve</p> <ul style="list-style-type: none"> • EGR control valve stuck | | | | | |
| <p>STEP</p> | <p>INSPECTION</p> | <p>ACTION</p> | | | | |
| <p>1</p> | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p>➡ page F1-14</p>  | <table border="0"> <tr> <td style="vertical-align: top;"> <p>Yes</p> </td> <td style="vertical-align: top;"> <p>No DTCs displayed</p> <p>Go to next step</p> </td> </tr> <tr> <td style="vertical-align: top;"> <p>No</p> </td> <td style="vertical-align: top;"> <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➡ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> </td> </tr> </table> | <p>Yes</p> | <p>No DTCs displayed</p> <p>Go to next step</p> | <p>No</p> | <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➡ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> |
| <p>Yes</p> | <p>No DTCs displayed</p> <p>Go to next step</p> | | | | | |
| <p>No</p> | <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➡ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | | | | |
| <p>2</p> | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p>➡ page F1-57</p> <p>Fuel line pressure: 260—320 kPa {2.6—3.3 kgf/cm², 37—46 psi}</p>  | <table border="0"> <tr> <td style="vertical-align: top;"> <p>Yes</p> </td> <td style="vertical-align: top;"> <p>Go to next step</p> </td> </tr> <tr> <td style="vertical-align: top;"> <p>No</p> </td> <td style="vertical-align: top;"> <p>Low pressure</p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ➡ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator <p>If hose not clogged, check fuel pump maximum pressure ➡ page F1-61</p> </td> </tr> </table> | <p>Yes</p> | <p>Go to next step</p> | <p>No</p> | <p>Low pressure</p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ➡ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator <p>If hose not clogged, check fuel pump maximum pressure ➡ page F1-61</p> |
| <p>Yes</p> | <p>Go to next step</p> | | | | | |
| <p>No</p> | <p>Low pressure</p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ➡ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator <p>If hose not clogged, check fuel pump maximum pressure ➡ page F1-61</p> | | | | | |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 3 | Is fuel line pressure held after ignition switch turned OFF? ↳ page F1-56 Fuel line pressure: More than 150 kPa {1.5 kgf/cm², 21 psi} for 5 min. | Yes | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 6 • If symptom occurs when engine cold, go to next step • If symptom occurs after warm-up, go to step 6 |
| | | No | Plug outlet of pressure regulator; is fuel line pressure held after ignition switch turned OFF? ↳ page F1-56 <ul style="list-style-type: none"> • If yes, replace pressure regulator ↳ page F1-64 • If no, check fuel pump hold pressure ↳ page F1-60 If fuel pump OK, check fuel injectors for fuel leakage ↳ page F1-66 |
| 4 | Is inside of throttle body clean? | Yes | Go to next step |
| | | No | Clean throttle body |
| 5 | Disconnect vacuum hose from EGR valve and plug it; does condition improve?  | Yes | Check follows: <ul style="list-style-type: none"> • EGR solenoid valve for sticking • Condition of solenoid valve connector female terminal(s) |
| | | No | Check if EGR valve moves smoothly ↳ page F1-77 <ul style="list-style-type: none"> • If yes, go to next step • If no, replace EGR valve ↳ page F1-77 |
| 6 | Try known good ECM; does condition improve? ↳ page F1-93 | | |










| | | | | | | | | | | | | | | |
|---|---|--|--|---|--|---|--|--|---|---|--|---|--|--|
| <p>9 10 11</p> | <p>ENGINE STALLS</p> | <ul style="list-style-type: none"> • IDLE AT ANY ENGINE TEMP. • DURING FAST IDLE • IDLE AFTER WARM-UP | | | | | | | | | | | | |
| <p>DESCRIPTION • Engine stops unexpectedly at idle and/or during fast idle operation</p> | | | | | | | | | | | | | | |
| <p>[TROUBLESHOOTING HINTS]</p> <table border="0"> <tr> <td data-bbox="196 317 641 394"> <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged </td> <td data-bbox="651 317 1079 394"> <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector </td> <td data-bbox="1089 317 1495 394"> <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck </td> </tr> <tr> <td data-bbox="196 394 641 449"> <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low </td> <td data-bbox="651 394 1079 449"> <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector </td> <td data-bbox="1089 394 1495 449"> <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck </td> </tr> <tr> <td data-bbox="196 449 641 499"> <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector </td> <td data-bbox="651 449 1079 499"> <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector </td> <td></td> </tr> <tr> <td data-bbox="196 499 641 531"> <p>④ Air leakage in intake-air system</p> </td> <td></td> <td></td> </tr> </table> | | | <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged | <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector | <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck | <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low | <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector | <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck | <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector | <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector | | <p>④ Air leakage in intake-air system</p> | | |
| <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged | <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector | <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck | | | | | | | | | | | | |
| <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low | <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector | <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck | | | | | | | | | | | | |
| <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector | <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector | | | | | | | | | | | | | |
| <p>④ Air leakage in intake-air system</p> | | | | | | | | | | | | | | |
| <p>STEP</p> | <p>INSPECTION</p> | <p>ACTION</p> | | | | | | | | | | | | |
| <p>1</p> | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p style="text-align: right;">➤ page F1-14</p>  | <table border="0"> <tr> <td data-bbox="820 569 885 783"> <p>Yes</p> </td> <td data-bbox="885 569 1495 783"> <p>No DTCs displayed</p> <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 8 • If symptom occurs at idle after warm-up, go to step 9 </td> </tr> <tr> <td data-bbox="820 783 885 1018"> <p>No</p> </td> <td data-bbox="885 783 1495 1018"> <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➤ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> </td> </tr> </table> | <p>Yes</p> | <p>No DTCs displayed</p> <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 8 • If symptom occurs at idle after warm-up, go to step 9 | <p>No</p> | <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➤ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | | | | | | | |
| <p>Yes</p> | <p>No DTCs displayed</p> <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 8 • If symptom occurs at idle after warm-up, go to step 9 | | | | | | | | | | | | | |
| <p>No</p> | <p>DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ➤ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | | | | | | | | | | | | |
| <p>2</p> | <p>Do Engine Signal Monitor lights flash for specified terminals while cranking engine?</p> <p style="text-align: right;">➤ page F1-93</p> <p>Terminal: 4U, 4V, 4W, 4X</p> | <table border="0"> <tr> <td data-bbox="820 1018 885 1081"> <p>Yes</p> </td> <td data-bbox="885 1018 1495 1081"> <p>Go to next step</p> </td> </tr> <tr> <td data-bbox="820 1081 885 1249"> <p>No</p> </td> <td data-bbox="885 1081 1495 1249"> <p>Check follows according to results:</p> <p>If light does not flash and 0V indicated for each terminal;</p> <ul style="list-style-type: none"> • Continuity of fuel injector(s) • Continuity between ECM and fuel injector(s) • Condition of injection connector and ECM connector <p>Repair or replace parts and/or wiring harness as necessary</p> </td> </tr> </table> | <p>Yes</p> | <p>Go to next step</p> | <p>No</p> | <p>Check follows according to results:</p> <p>If light does not flash and 0V indicated for each terminal;</p> <ul style="list-style-type: none"> • Continuity of fuel injector(s) • Continuity between ECM and fuel injector(s) • Condition of injection connector and ECM connector <p>Repair or replace parts and/or wiring harness as necessary</p> | | | | | | | | |
| <p>Yes</p> | <p>Go to next step</p> | | | | | | | | | | | | | |
| <p>No</p> | <p>Check follows according to results:</p> <p>If light does not flash and 0V indicated for each terminal;</p> <ul style="list-style-type: none"> • Continuity of fuel injector(s) • Continuity between ECM and fuel injector(s) • Condition of injection connector and ECM connector <p>Repair or replace parts and/or wiring harness as necessary</p> | | | | | | | | | | | | | |
| <p>3</p> | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <table border="0"> <tr> <td data-bbox="820 1249 885 1438"> <p>Yes</p> </td> <td data-bbox="885 1249 1495 1438"> <p>Go to next step</p> </td> </tr> <tr> <td data-bbox="820 1438 885 1646"> <p>No</p> </td> <td data-bbox="885 1438 1495 1646"> <p>Check follows:</p> <ul style="list-style-type: none"> • Distributor cap and rotor ➤ section G • High-tension lead(s) ➤ section G </td> </tr> </table> | <p>Yes</p> | <p>Go to next step</p> | <p>No</p> | <p>Check follows:</p> <ul style="list-style-type: none"> • Distributor cap and rotor ➤ section G • High-tension lead(s) ➤ section G | | | | | | | | |
| <p>Yes</p> | <p>Go to next step</p> | | | | | | | | | | | | | |
| <p>No</p> | <p>Check follows:</p> <ul style="list-style-type: none"> • Distributor cap and rotor ➤ section G • High-tension lead(s) ➤ section G | | | | | | | | | | | | | |





| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 4 | Connect jumper wire between F/P and GND terminal of data link connector; will engine run?  <p style="text-align: center;">DATA LINK CONNECTOR</p> | Yes | Check follows: <ul style="list-style-type: none"> • 1U terminal voltage at ECM ☞ page F1-93 • Continuity between 1U terminal and fuel pump relay connector terminal • Condition of ECM and fuel pump relay connector female terminals |
| | | No | Check if fuel pump operating sound is heard <ul style="list-style-type: none"> • If yes, go to next step • If no, check fuel pump circuit |
| 5 | Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ☞ page F1-57 Fuel line pressure: 260—320 kPa {2.6—3.3 kgf/cm ² , 37—46 psi}  <p style="text-align: center;">INSTALL CLAMPS</p> | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ☞ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure ☞ page F1-61 |
| 6 | Is air leakage felt or heard at intake-air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next step |
| 7 | Is engine compression correct? ☞ section B1 Engine compression (Minimum): 820 kPa (8.4 kgf/cm ² , 120 psi]—300 rpm | Yes | Go to step 9 |
| | | No | Check for cause ☞ section B1 |
| 8 | Does engine start with throttle valve held quarter open? | Yes | Check follows: <ul style="list-style-type: none"> • Operation of air valve ☞ page F1-54 • Operation of EGR valve ☞ page F1-77 |
| | | No | Go to next step |
| 9 | Does following terminal voltage at ECM decrease smoothly? ☞ page F1-93 Terminal 3G voltage: Approx. 0.5—2.5V | Yes | Go to next step |
| | | No | Check follows: <ul style="list-style-type: none"> • Ground of engine coolant temperature sensor • Continuity between engine coolant temperature sensor and ECM connector • Condition of engine coolant temperature sensor and ECM connector female terminals |







| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 10 | <p>Are spark plugs OK?  section G</p>  | Yes | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 14 • If symptom occurs at fast idle operation, go to step 14 • If symptom occurs at idle after warm-up, go to next step |
| | | No | Clean or replace  section G |
| 11 | <p>Is resistance of idle air control valve correct?  page F1-54</p> <p>Resistance: 7.7—9.3Ω [at 20°C {68°F}]</p>  | Yes | Go to next step |
| | | No | Replace BAC valve  page F1-48 |
| 12 | Try a known good BAC valve; does condition improve? | Yes | Replace BAC valve  page F1-48 |
| | | No | Reinstall BAC valve and go to next step |
| 13 | Is front heated oxygen sensor (front) operation OK?  page F1-105 | Yes | Go to next step |
| | | No | <p>Check follows:</p> <ul style="list-style-type: none"> • Poor connection of engine coolant temperature sensor connector |
| 14 | <p>Are fuel injectors OK?</p> <ul style="list-style-type: none"> • No fuel leakage  page F1-66 • Fuel injectors not clogged  page F1-65 | Yes | Go to next step |
| | | No | Replace fuel injector(s)  page F1-65 |
| 15 | Try a known good ECM; does condition improve?  page F1-93 | | |


| 12 | ENGINE STALLS | • IDLE WITH A/C, P/S, AND/OR E/L ON | |
|--|--|-------------------------------------|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle • Idle condition is normal when A/C, P/S, and E/L are OFF | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① E/L switch malfunction</p> <ul style="list-style-type: none"> • Air conditioning switch • Headlight switch • Rear window defroster switch • P/S pressure switch • Blower switch <p>② Idle air control valve</p> <ul style="list-style-type: none"> • Solenoid valve stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Are terminal voltages at ECM connector correct?  page F1-93</p> <ul style="list-style-type: none"> • 1P Fan switch • 1H Headlight switch • 1J Rear window defroster switch • 1K Air conditioning switch • 3P P/S pressure switch | Yes | Go to next step |
| | | No | Check for cause |
| 2 | <p>Is there no DTCs displayed on SST with ignition switch ON?  page F1-14</p>  | Yes | <p>No DTCs displayed Go to next step</p> |
| | | No | <p>DTC No. displayed Check for cause (Refer to specified check sequence)  page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> |
| 3 | <p>Is terminal voltage at ECM connector correct at idle?  page F1-93</p> <p>4Q terminal: idle air control valve</p>  | Yes | Check BAC valve and replace  page F1-54 |
| | | No | Try known good ECM and check if condition improves  page F1-93 |



| 13 | ENGINE STALLS | • DRIVEAWAY | | | | | | | | | |
|--|---|---|--|----|-----------------------------|----|----------------------------------|----------------|--|----------------------|--|
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine stops unexpectedly upon driveaway • Idle condition normal | | | | | | | | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged <p>② Pressure regulator</p> <ul style="list-style-type: none"> • Diaphragm damaged <p>③ Fuel filter</p> <ul style="list-style-type: none"> • Fuel filter clogged <p>④ Distributor</p> <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged <p>⑤ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector | | | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | | | |
| 1 | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p style="text-align: right;">➡ page F1-14</p>  <p style="text-align: center;">49 T088 0A0</p> | <p>Yes</p> <p>No</p> | <p>No DTCs displayed Go to next step</p> <p>DTC No. displayed Check for cause (Refer to specified check sequence) ➡ page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | | | | | | | |
| 2 | <p>Using Engine Signal Monitor, do voltage reading and light operation change as follows upon driveaway? ➡ page F1-93</p> <table border="1" data-bbox="284 1066 795 1255"> <thead> <tr> <th>Terminal</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td>3B</td> <td>Voltage gradually increases</td> </tr> <tr> <td>3G</td> <td>Voltage does not change suddenly</td> </tr> <tr> <td>4U, 4V, 4W, 4X</td> <td>Flashing of green and red lights becomes quicker</td> </tr> </tbody> </table> | Terminal | Condition | 3B | Voltage gradually increases | 3G | Voltage does not change suddenly | 4U, 4V, 4W, 4X | Flashing of green and red lights becomes quicker | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check follows:</p> <ul style="list-style-type: none"> • Condition of female terminals in related connector • Continuity between injector connector and ECM connector |
| Terminal | Condition | | | | | | | | | | |
| 3B | Voltage gradually increases | | | | | | | | | | |
| 3G | Voltage does not change suddenly | | | | | | | | | | |
| 4U, 4V, 4W, 4X | Flashing of green and red lights becomes quicker | | | | | | | | | | |
| 3 | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ➡ page F1-57</p> <p>Fuel line pressure: 260—320 kPa {2.6—3.3 kgf/cm², 37—46 psi}</p>  <p style="text-align: center;">INSTALL CLAMPS</p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ➡ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure ➡ page F1-61 | | | | | | | | |
| 4 | <p>Are fuel injectors OK?</p> <ul style="list-style-type: none"> • No fuel leakage ➡ page F1-66 • Fuel injectors not clogged ➡ page F1-65 | <p>Yes</p> <p>No</p> | <p>Try a known good ECM; does condition improve? ➡ page F1-93</p> <p>Replace fuel injector ➡ page F1-65</p> | | | | | | | | |




| 14 15 | ENGINE STALLS | <ul style="list-style-type: none"> • ON ACCELERATION/WHILE CRUISING |
|---|---|---|
| DESCRIPTION <ul style="list-style-type: none"> • Engine stops unexpectedly at beginning of acceleration or during acceleration • Engine stops unexpectedly while cruising | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection ② Pressure regulator <ul style="list-style-type: none"> • Diaphragm damaged ③ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged ④ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Main relay <ul style="list-style-type: none"> • Poor connection of connector | | |
| STEP | INSPECTION | ACTION |
| 1 | Is there no DTCs displayed on SST with ignition switch ON?  | Yes No DTCs displayed Go to next step No DTC No. displayed Check for cause (Refer to specified check sequence)  page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 2 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes Check spark plugs  section G ⇨ If OK, go to next step ⇨ If not OK, clean or replace spark plug No Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor  section G • High-tension lead(s)  section G • Condition of distributor connector female terminals |
| 3 | Are mass air flow sensor connector terminals and connection good?  page F1-99 | Yes Go to next step No Repair connector terminal(s) |
| 4 | Ground terminal F/P of data link connector with ignition switch ON; is operation sound of fuel pump heard?  | Yes Go to next step No Check as follows: <ul style="list-style-type: none"> • Poor connection of fuel pump relay • Poor connection of fuel pump connector • Melted CIS INJ fuse (30A) Refer to “No.1 — MELTS MAIN OR OTHER FUSE” • Poor connection of main relay • Operation of main relay  page F1-109 |







| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 5 | <p>Is fuel line pressure correct at idle?  page F1-63</p> <p>Fuel line pressure: 210—250 kPa {2.1—2.6 kgf/cm², 30—36 psi}</p>  <p>INSTALL CLAMP</p> | Yes | Go to next step |
| | | No | Check pressure regulator  page F1-63 |
| 6 | <p>Try a known good ECM; does condition improve?  page F1-93</p> | | |


| 16 | ENGINE STALLS | • ON DECELERATION | |
|--|--|-------------------|---|
| DESCRIPTION <ul style="list-style-type: none"> • Engine stops unexpectedly at beginning of deceleration or recovery from deceleration • Exhaust afterburn | | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection ② Idle speed <ul style="list-style-type: none"> • Idle speed too low ③ Distributor <ul style="list-style-type: none"> • Poor connection of connector ④ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ EGR valve <ul style="list-style-type: none"> • Solenoid valve stuck • EGR valve stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up?  <p>page F1-12</p> <p>Idle speed: 500—800 rpm</p> | Yes | Go to step 3 |
| | | No | Remove System Selector and go to next step |
| 2 | Does idle speed drop in following conditions? Condition <ul style="list-style-type: none"> • Electrical load ON • Air conditioner ON • P/S operating | Yes | Check follows; <ul style="list-style-type: none"> • Circuit from idle air control valve to ECM for open and short  page F1-93 • Idle air control valve for sticking  page F1-54 |
| | | No | Adjust idle speed  page F1-12 |
| 3 | Is there no DTCs displayed on SST with ignition switch ON?  <p>page F1-14</p> | Yes | No DTCs displayed Go to next step |
| | | No | DTC No. displayed Check for cause (Refer to specified check sequence)  page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 4 | Are mass air flow sensor connector terminals and connection good? | Yes | Go to next step |
| | | No | Repair connector terminal |
| 5 | Are following terminals and connections good? <ul style="list-style-type: none"> • Distributor connector • Fuel pump connector • Main relay • ECM connector | Yes | Go to next step |
| | | No | Repair connector terminal |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 6 | Disconnect vacuum hose from EGR valve and plug it; does condition improve?  | Yes | Check follows: <ul style="list-style-type: none"> • EGR solenoid valve • Condition of solenoid valve connectors female terminals |
| | | No | Go to next step |
| 7 | Try a known good ECM; does condition improve? page F1-93 | | |


| | | | | |
|---|---|--|---|--|
| 17 18 19 | ROUGH IDLE | <ul style="list-style-type: none"> • IDLE AT ANY ENGINE TEMP./DURING FAST IDLE/ IDLE AFTER WARM-UP | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. • Idle speed too slow and excessive engine shake at any engine temp. • Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up | | | |
| <p>[TROUBLESHOOTING HINTS]</p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector <p>④ Air leakage</p> <ul style="list-style-type: none"> • Leakage in intake-air system <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector </td> <td style="vertical-align: top;"> <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck </td> </tr> </table> | | | <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector <p>④ Air leakage</p> <ul style="list-style-type: none"> • Leakage in intake-air system <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector | <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck |
| <p>① Fuel injector</p> <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged <p>② Fuel pump</p> <ul style="list-style-type: none"> • Maximum pressure low <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> • Poor connection of connector <p>④ Air leakage</p> <ul style="list-style-type: none"> • Leakage in intake-air system <p>⑤ Distributor</p> <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector | <p>⑥ Mass air flow sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑦ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>⑧ EGR valve</p> <ul style="list-style-type: none"> • EGR valve stuck <p>⑨ BAC valve</p> <ul style="list-style-type: none"> • Air valve stuck | | | |
| STEP | INSPECTION | ACTION | | |
| 1 | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p style="text-align: right;">☞ page F1-14</p>  | <p>Yes No DTCs displayed</p> <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 6 • If symptom occurs at idle after warm-up, go to step 7 <p>No DTC No. displayed</p> <p>Check for cause (Refer to specified check sequence) ☞ page F1-16</p> <p>“LINK COMMUNICATION ERROR” displays</p> <p>Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | |
| 2 | <p>Do Engine Signal Monitor lights flash for specified terminals while cranking engine?</p> <p style="text-align: right;">☞ page F1-93</p> <p>Terminal: 4U, 4V, 4W, 4X</p> | <p>Yes Go to next step</p> <p>No Check as follows according to results:</p> <p>Does not flash and 0V indicated for individual terminal(s)</p> <ul style="list-style-type: none"> • Continuity of fuel injector(s) ☞ page F1-65 • Continuity between ECM and fuel injector(s) • Condition of fuel injector connector and ECM connector <p>Repair or replace parts and/or wiring harness as necessary</p> | | |
| 3 | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <p>Yes Go to next step</p> <p>No Check distributor cap and rotor</p> <p>Check follows:</p> <ul style="list-style-type: none"> • Distributor cap and rotor ☞ section G • High-tension lead(s) ☞ section G | | |




| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 4 | Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ↳ page F1-57 Fuel line pressure: 260—320 kPa {2.6—3.3 kgf/cm ² , 37—46 psi}  INSTALL CLAMPS | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ↳ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure ↳ page F1-61 |
| 5 | Is there air leakage at intake air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next step |
| 6 | Is engine compression correct? ↳ section B1 Engine compression (minimum): 820 kPa {8.4 kgf/cm ² , 120 psi} | Yes | Go to next step |
| | | No | Check for cause ↳ section B1 |
| 7 | Connect engine signal monitor to ECM and set to position 3G Does following terminal voltage in ECM increase smoothly? ↳ page F1-93 Terminal 3G voltage: Approx. 0.5—2.5V | Yes | Go to next step |
| | | No | Check as follows: <ul style="list-style-type: none"> • Ground of engine coolant temperature sensor • Continuity between engine coolant temperature sensor and ECM connector • Condition in engine coolant temperature sensor and ECM connector female terminals |
| 8 | Are spark plugs OK? ↳ section G  | Yes | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 12 • If symptom occurs during fast idle operation, go to step 12 • If symptom occurs at idle after warm-up, go to next step |
| | | No | Clean or replace |
| 9 | Is resistance of idle air control valve correct? Resistance: 7.7—9.3Ω [at 20°C {68°F}]  | Yes | Go to next step |
| | | No | Replace BAC valve ↳ page F1-48 |






| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 10 | Try a known good BAC valve; does condition improve? | Yes | Replace BAC valve  page F1-48 |
| | | No | Reinstall BAC valve Go to next step |
| 11 | Are fuel injectors OK? • No fuel fuel leakage  page F1-66 • Fuel injectors not clogged  page F1-65 | Yes | Go to next step |
| | | No | Replace fuel injector(s)  page F1-65 |
| 12 | Is front heated oxygen sensor (front) operation correct?  page F1-106 | Yes | Go to next step |
| | | No | Replace front heated oxygen sensor |
| 13 | Try a known good ECM; does condition improve?  page F1-93 | | |



| | | |
|---|---|---|
| 20 | ROUGH IDLE | <ul style="list-style-type: none"> • IDLE WITH A/C, P/S AND/OR E/L ON |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when A/C, P/S and/or E/L ON | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Idle speed</p> <ul style="list-style-type: none"> • Idle speed too low <p>② E/L signal does not input to ECM</p> <ul style="list-style-type: none"> • Air conditioning switch • Headlight switch • Rear window defroster switch • Blower switch • P/S pressure switch <p>③ Idle air control valve</p> <ul style="list-style-type: none"> • Solenoid valve stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up?</p> <p style="text-align: right;">📖 page F1-12</p> <p>Idle speed: 500—800 rpm</p> | <p>Yes Go to next step</p> <p>No Adjust idle speed and go to next step 📖 page F1-12</p> |
| 2 | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p style="text-align: right;">📖 page F1-14</p>  | <p>Yes No DTCs displayed Go to next step</p> <p>No DTC No. displayed Check for cause (Refer to specified check sequence) 📖 page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> |
| 3 | <p>Are terminal voltages at ECM connector correct?</p> <p style="text-align: right;">📖 page F1-93</p> <ul style="list-style-type: none"> • 1K Air conditioning switch • 1H Headlight switch • 1J Rear window defroster switch • 1P Fan switch • 3P P/S pressure switch | <p>Yes Go to next step</p> <p>No Check for cause 📖 page F1-93</p> |
| 4 | <p>Warm up engine Does idle speed change when idle air control valve connector disconnected?</p> | <p>Yes Go to next step</p> <p>No Check idle air control valve for sticking 📖 page F1-54</p> |
| 5 | <p>Does air conditioner operate continuously with ignition switch ON and A/C switch and blower switch OFF?</p> | <p>Yes Check as follows:</p> <ul style="list-style-type: none"> • Malfunction of A/C relay 📖 1996 626/MX-6 Body Electrical Troubleshooting Manual section G • Wiring harness between A/C relay and ECM terminal 1G for short circuit 📖 page F1-95 <p>No Go to next step</p> |
| 6 | <p>Try a known good ECM; does condition improve?</p> <p style="text-align: right;">📖 page F1-93</p> | |







| 21 | ROUGH IDLE | • ON DECELERATION | | | |
|--|--|---------------------|--|--|--|
| DESCRIPTION <ul style="list-style-type: none"> • Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration • Exhaust afterburn | | | | | |
| [TROUBLESHOOTING HINTS] <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ② Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ③ Idle speed <ul style="list-style-type: none"> • Idle speed too low </td> <td style="width: 50%; vertical-align: top;"> ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑥ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck </td> </tr> </table> | | | | ① Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ② Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ③ Idle speed <ul style="list-style-type: none"> • Idle speed too low | ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑥ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck |
| ① Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ② Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ③ Idle speed <ul style="list-style-type: none"> • Idle speed too low | ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑥ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck | | | | |
| STEP | INSPECTION | ACTION | | | |
| 1 | Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up? ↳ page F1-12 Idle speed: 500—800 rpm  | Yes Go to step 3 | No Remove System Selector and go to next step | | |
| | | 2 | Does idle speed drop in following conditions? Condition: <ul style="list-style-type: none"> • Electrical load ON • Air conditioner ON • P/S operating | Yes Adjust idle speed ↳ page F1-12 | No Check as follows: <ul style="list-style-type: none"> • Wiring harness from idle air control valve to ECM for short and open circuit ↳ page F1-93 • Idle air control valve stuck ↳ page F1-54 |
| 3 | Is there no DTCs displayed on SST with ignition switch ON? ↳ page F1-14 | | | Yes No DTCs displayed Go to next step | No DTC No. displayed Check for cause (Refer to specified check sequence) ↳ page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| | | 4 | Is there fuel leakage from fuel injector nozzles or fuel injector holder? ↳ page F1-65  | Yes Reinstall or replace fuel injector ↳ page F1-65 | No Go to next step |
| 5 | Are mass air flow sensor connector terminal and connection condition good? | | | Yes Go to next step | No Repair connector terminal |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---------------------------|
| 6 | Are following connections good? <ul style="list-style-type: none">• Distributor connector• Fuel pump connector• Main relay• ECM connector | Yes | Go to next step |
| | | No | Repair connector terminal |
| 7 | Try a known good ECM; does condition improve?  page F1-93 | | |




| | | |
|--|--|--|
| 22 23 | POOR ACCELERATION | <ul style="list-style-type: none"> • DRIVEAWAY • ON ACCELERATION |
| DESCRIPTION • Engine speed increases normally but vehicle speed slowly increases during driveaway or acceleration | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ② Pressure regulator <ul style="list-style-type: none"> • Pressure regulator malfunction ③ Fuel filter <ul style="list-style-type: none"> • Clogged filter ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damage ⑤ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p style="text-align: right;">➤ page F1-14</p>  <p style="text-align: center;">DATA LINK CONNECTOR-2</p> <p style="text-align: center;">49 T088 0A0</p> | <p>Yes No DTCs displayed Go to next step</p> <p>No DTC No. displayed Check for cause (Refer to specified check sequence) ➤ page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> |
| 2 | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <p>Yes Check spark plugs ➤ If OK, go to next step ➤ If not OK, clean or replace spark plug</p> <p>No Check follows: <ul style="list-style-type: none"> • Distributor cap and rotor ➤ section G • High-tension lead(s) ➤ section G • Condition of distributor connector female terminals </p> |
| 3 | <p>Is connection of mass air flow sensor connector OK?</p> | <p>Yes Go to next step</p> <p>No Repair terminal</p> |
| 4 | <p>Is intake manifold vacuum correct at idle?</p> <p>Vacuum: More than 60.0 kPa{450 mmHg, 17.7 inHg}</p>  | <p>Yes Go to next step</p> <p>No Check as follows: <ul style="list-style-type: none"> • Intake-air system components and installation • Vacuum hoses for disconnection and damage </p> |








| STEP | INSPECTION | ACTION |
|------|---|--|
| 5 | <p>Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  page F1-63</p> <p>Fuel line pressure: 210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}</p>  <p>INSTALL CLAMPS</p> | <p>Yes: Go to next step</p> <hr/> <p>No: Low pressure Check follows:</p> <ul style="list-style-type: none"> • Fuel filter for clogging • Operation of pressure regulator  page F1-63 • Fuel leakage from fuel injector(s)  page F1-66 |
| 6 | <p>Try a known good ECM; does condition improve?  page F1-93</p> | |




| 24 HIGH IDLE SPEED AFTER WARM-UP | | | |
|--|--|--|--|
| DESCRIPTION | | <ul style="list-style-type: none"> Idle speed continues at fast idle after warm-up Engine speed returns slowly to idle after accelerator is released | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Engine coolant temperature sensor | | ③ BAC valve | |
| <ul style="list-style-type: none"> Poor connection of connector | | <ul style="list-style-type: none"> Idle air control valve or air valve stuck | |
| ② Throttle position sensor | | | |
| <ul style="list-style-type: none"> Poor connection of connector Incorrect adjustment | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there no DTCs displayed on SST with ignition switch ON? ↳ page F1-14  | Yes | No DTCs displayed Go to next step |
| | | No | DTC No. displayed Check for cause (Refer to specified check sequence) ↳ page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 2 | Connect System Selector to the data link connector and set switch (A) to position 1 Does idle speed decrease when test switch is set to SELF-TEST?  | Yes | Check condition of engine coolant temperature sensor and throttle position sensor connector female terminals ⇨ If OK, go to next step ⇨ If not OK, repair the female connector |
| | | No | Check if idle air control valve or air valve stuck ⇨ If OK, go to step 4 ⇨ If not OK, replace BAC valve |
| 3 | Is following terminal voltage at ECM correct? Terminal 3F: 0.3—0.7V (Closed throttle position) 3.4—5.3V (Wide open throttle) | Yes | Go to next step |
| | | No | Replace throttle body ↳ page F1-49 |
| 4 | Try a known good ECM; does condition improve? ↳ page F1-93 | | |

| 25 | <ul style="list-style-type: none"> • IDLE FLUCTUATES • IDLE HUNTS | |
|--|--|---|
| DESCRIPTION • Engine speed changes back and forth between specified idle speed and higher speed | | |
| [TROUBLESHOOTING HINTS] ① PCV valve <ul style="list-style-type: none"> • PCV valve stuck ② Spark plug <ul style="list-style-type: none"> • Spark plug(s) damaged ③ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Is there no DTCs displayed on SST with ignition switch ON?  | Yes No DTCs displayed Go to next step No DTC No. displayed Check for cause (Refer to specified check sequence)  page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 2 | Is following terminal voltage at ECM correct? Terminal 3L: Below 1.0V (accelerator pedal released) B+ (accelerator pedal depressed) | Yes Go to next step No Check follows: <ul style="list-style-type: none"> • Wiring harness from closed throttle position switch to ECM for short and open circuit Replace throttle body if necessary  page F1-49 |
| 3 | Connect System Selector to data link connector and set switch (A) to position 1 Does idle hunting stop when test switch is set to SELF-TEST?  | Yes Check follows: <ul style="list-style-type: none"> • Idle air control valve for sticking • Poor sealing between throttle body and BAC valve No Go to next step |
| 4 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes Check spark plug(s) ⇨ If OK, go to next step ⇨ If not OK, replace spark plug(s) No Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor  section G |

| STEP | INSPECTION | | ACTION |
|------|---|-----|-------------------|
| 5 | Is PCV valve stuck? ☞ page F1-78 | Yes | Replace PCV valve |
| | | No | Go to next step |
| 6 | Try a known good ECM; does condition improve? ☞ page F1-93 | | |

| 26 | <ul style="list-style-type: none"> • HESITATES • STUMBLES ON ACCELERATION | |
|--|---|---|
| <p>DESCRIPTION • Momentary pause at beginning of acceleration or during acceleration</p> | | |
| <p>[TROUBLESHOOTING HINTS]</p> <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ② Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ③ Pressure regulator <ul style="list-style-type: none"> • Pressure regulator stuck ④ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑤ EGR solenoid valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damage ⑦ High-tension lead(s) <ul style="list-style-type: none"> • Lead(s) damaged ⑧ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑨ Throttle position sensor <ul style="list-style-type: none"> • Poor connection of connector | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>Is there no DTCs displayed on SST with ignition switch ON?</p> <p>☞ page F1-14</p>  <p>DATA LINK CONNECTOR-2</p> <p>49 T088 0A0</p> | <p>Yes No DTCs displayed Go to next step</p> <p>No DTC No. displayed Check for cause (Refer to specified check sequence) ☞ page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> |
| 2 | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <p>Yes Go to next step</p> <p>No Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor ☞ section G • High-tension lead(s) ☞ section G • Condition of distributor and ECM connector female terminals </p> |
| 3 | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p>☞ page F1-63</p> <p>Fuel line pressure: 260—320 kPa {2.6—3.3 kgf/cm², 37—46 psi}</p>  <p>INSTALL CLAMPS</p> | <p>Yes Go to next step</p> <p>No Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator ☞ page F1-63 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure ☞ page F1-61 </p> |

| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 4 | Does fuel pressure increase when throttle valve opened? | Yes | Go to next step |
| | | No | Check pressure regulator  page F1-63 |
| 5 | Disconnect vacuum hose from EGR valve and plug it; does condition improve?  | Yes | Check follows: <ul style="list-style-type: none"> • EGR solenoid valve for sticking • Condition of solenoid valve connectors female terminals |
| | | No | Go to next step |
| 6 | Are following terminal voltages at ECM connector correct? Terminal 3B: Approx. 1.0—1.5V (Ign switch ON) Approx. 1.5—5V (Engine running)  page F1-93 | Yes | Go to next step |
| | | No | Check condition of mass air flow sensor and ECM connector female terminals <ul style="list-style-type: none"> • If OK, replace mass air flow sensor • If not OK, repair female terminal |
| 7 | Are following terminal voltages at ECM correct? Terminal 3F: 0.3—0.7V (Closed throttle position) 3.4—5.3V (Wide open throttle) | Yes | Go to next step |
| | | No | Check female terminal condition in throttle position sensor connector and ECM connector <ul style="list-style-type: none"> • If OK, replace throttle position sensor  page F1-104 • If not OK, repair female terminal |
| 8 | Is there fuel leakage from fuel injector(s)? Fuel leakage: Less than 1 drop/2 min.  | Yes | Check follows: <ul style="list-style-type: none"> • Poor installation of fuel injector  page F1-65 |
| | | No | Go to next step |
| 9 | Try a known good ECM; does condition improve?  page F1-93 | | |

| 27 | SURGES WHILE CRUISING | | |
|---|---|---|--|
| DESCRIPTION • Momentary minor irregularity in engine output at steady vehicle speed | | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Fuel injector <ul style="list-style-type: none"> • Poor connection of connector ② Spark plug <ul style="list-style-type: none"> • Spark plug(s) damaged | | ③ Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there no DTCs displayed on SST with ignition switch ON?  page F1-14 | Yes | No DTCs displayed Go to next step |
| | | No | DTC No. displayed Check for cause (Refer to specified check sequence) page F1-16 “LINK COMMUNICATION ERROR” displays Refer to No.35 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 2 | Does mass air flow sensor operate correctly? page F1-99 | Yes | Go to next step |
| | | No | Check follows: <ul style="list-style-type: none"> • Condition of mass air flow sensor and ECM connector female terminals |
| 3 | Does idle become rough when shaking connector of injector?  | Yes | Check follows: <ul style="list-style-type: none"> • Condition of fuel injector and ECM connector female terminals |
| | | No | Go to next step |
| 4 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plug(s) for damage ⇨ If OK, go to next step ⇨ If not OK, replace spark plug(s) |
| | | No | Check follows: <ul style="list-style-type: none"> • Distributor cap and rotor for damage section G |
| 5 | Try a known good ECM; does condition improve? page F1-93 | | |

| | |
|--|----------------------|
| 28 | LACK OF POWER |
| DESCRIPTION • Performance poor under load (i.e., power down when climbing hills) | |
| [TROUBLESHOOTING HINTS] | |
| <ul style="list-style-type: none"> ① Mass air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ② Intake air temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ③ Distributor <ul style="list-style-type: none"> • Damaged distributor cap or rotor ④ Fuel injector <ul style="list-style-type: none"> • Fuel injector harness shorted to ground ⑤ Fuel filter <ul style="list-style-type: none"> • Clogged filter ⑥ Air cleaner element <ul style="list-style-type: none"> • Clogged element ⑦ Three way catalyst <ul style="list-style-type: none"> • Clogged three way catalytic converter | |
| section G | |
| page F1-48 | |
| page F1-72 | |

| | |
|--|--------------------------|
| 29 | POOR FUEL ECONOMY |
| DESCRIPTION • Fuel economy unsatisfactory | |
| [TROUBLESHOOTING HINTS] | |
| <ul style="list-style-type: none"> ① Air leakage <ul style="list-style-type: none"> • Poor installation of air intake hose, throttle body, intake manifold, EGR valve and/or EGR function control • Vacuum hose damaged or disconnected ② Heated oxygen sensor <ul style="list-style-type: none"> • Open in harness ③ Pressure regulator <ul style="list-style-type: none"> • Hold fuel pressure high • Vacuum hose disconnected or damaged | |
| page F1-105 | |
| page F1-64 | |

| | |
|--|--------------------------|
| 30 | A/C DOES NOT WORK |
| DESCRIPTION • A/C compressor magnetic clutch does not engage with air conditioning switch ON | |
| [TROUBLESHOOTING HINTS] | |
| <ul style="list-style-type: none"> ① A/C relay <ul style="list-style-type: none"> • Poor connection of connector • Relay malfunction ② Air conditioning switch <ul style="list-style-type: none"> • Does not send signal to ECM terminal 1K ③ ECM <ul style="list-style-type: none"> • Does not send signal to A/C relay with ignition switch ON | |
| 1996 626/MX-6 Body Electrical Troubleshooting Manual section G | |
| page F1-93 | |
| 1996 626/MX-6 Body Electrical Troubleshooting Manual section G | |

| | |
|--|---|
| 31 | <ul style="list-style-type: none"> • KNOCKING • PINGING |
| DESCRIPTION • Noise produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | |
| [TROUBLESHOOTING HINTS] | |
| <ul style="list-style-type: none"> ① Ignition timing <ul style="list-style-type: none"> • Incorrect ignition timing ② Carbon deposits in cylinder <ul style="list-style-type: none"> • Carbon deposits in cylinder | |
| section B1 | |

| | |
|-------------------------------------|--|
| 32 | FUEL ODOR |
| DESCRIPTION | • Gasoline fuel smell or visible leaks |
| [TROUBLESHOOTING HINTS] | |
| ① Purge solenoid valve | 📖 page F1-81 |
| • Open or short in harness | |
| ② Charcoal canister | |
| • Canister full of fuel and leaking | |

| | |
|--------------------------------|---------------------------------|
| 33 | EXHAUST SULFUR SMELL |
| DESCRIPTION | • Rotten egg smell from exhaust |
| [TROUBLESHOOTING HINTS] | |
| High sulfur content fuel used | |

| | |
|--------------------------------|-----------------------------|
| 34 | HIGH OIL CONSUMPTION |
| DESCRIPTION | • Oil consumption excessive |
| [TROUBLESHOOTING HINTS] | |
| PCV valve | 📖 page F1-78 |
| • PCV valve stuck open | |

| | |
|---|--|
| 35 | NGS DISPLAYS "LINK COMMUNICATION ERROR" |
| DESCRIPTION | • NGS displays "LINK COMMUNICATION ERROR" |
| [TROUBLESHOOTING HINTS] | |
| ① Open or short circuit in wiring between DLC2 KLN terminal and ECM terminal 1D | 📖 page F1-93 |
| ② ECM | |
| • Vref terminal voltage incorrect | |
| • Open or short circuit in wiring between main relay and ECM terminal 4B | |
| • Open circuit in ground terminals of ECM | |

| | |
|--|--------------------------------------|
| 36 | MIL NEVER ON |
| DESCRIPTION | • NGS indicates DTC but MIL never ON |
| [TROUBLESHOOTING HINTS] | |
| ① Wiring harness between ECM 1E terminal and MIL | |
| • Open in harness | |
| ② Light burnt | |


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

FUEL AND EMISSION CONTROL SYSTEMS (KL)


| | | | |
|---|-------|--|--------|
| OUTLINE | F2- 2 | EGR SOLENOID VALVE | F2- 86 |
| SYSTEM DIAGRAM | F2- 2 | EGR VALVE | F2- 88 |
| VACUUM HOSE ROUTING DIAGRAM | F2- 3 | EGR BOOST SENSOR SWITCHING CONTROL SYSTEM | F2- 89 |
| SYSTEM WIRING DIAGRAM | F2- 4 | SYSTEM INSPECTION | F2- 89 |
| SPECIFICATIONS | F2- 6 | EGR BOOST SENSOR SOLENOID VALVE | F2- 89 |
| COMPONENT DESCRIPTIONS | F2- 7 | POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM | F2- 90 |
| ENGINE TUNE-UP | F2-10 | DESCRIPTION | F2- 90 |
| PREPARATION | F2-10 | PCV VALVE | F2- 90 |
| ADJUSTMENT | F2-10 | EVAPORATIVE EMISSION SYSTEM | F2- 91 |
| ON-BOARD DIAGNOSTIC SYSTEM | F2-13 | DESCRIPTION | F2- 91 |
| PREPARATION | F2-13 | PREPARATION | F2- 92 |
| DIAGNOSTIC TROUBLE CODE NUMBER | F2-13 | SYSTEM INSPECTION | F2- 93 |
| INTAKE-AIR SYSTEM | F2-54 | PURGE SOLENOID VALVE | F2- 93 |
| COMPONENT PARTS | F2-54 | FUEL VAPOR VALVE | F2- 94 |
| THROTTLE BODY | F2-55 | CHECK VALVE (TWO-WAY) | F2- 94 |
| ACCELERATOR PEDAL | F2-56 | CHARCOAL CANISTER | F2- 94 |
| ACCELERATOR CABLE | F2-56 | FUEL-CUT CONTROL SYSTEM | F2- 95 |
| AIR INTAKE PIPE/INTAKE MANIFOLD | F2-57 | DESCRIPTION | F2- 95 |
| IDLE AIR CONTROL SYSTEM | F2-58 | PREPARATION | F2- 95 |
| DESCRIPTION | F2-58 | SYSTEM INSPECTION | F2- 96 |
| PREPARATION | F2-59 | A/C CUT OFF SYSTEM | F2- 97 |
| SYSTEM INSPECTION | F2-59 | DESCRIPTION | F2- 97 |
| BAC VALVE | F2-60 | PREPARATION | F2- 98 |
| VARIABLE RESONANCE INDUCTION SYSTEM (VRIS) | F2-61 | SYSTEM INSPECTION | F2- 98 |
| DESCRIPTION | F2-61 | DECHOKE CONTROL SYSTEM | F2- 99 |
| PREPARATION | F2-62 | DESCRIPTION | F2- 99 |
| SYSTEM INSPECTION | F2-63 | SYSTEM INSPECTION | F2- 99 |
| COMPONENT PARTS | F2-64 | ELECTRICAL FAN CONTROL SYSTEM | F2-100 |
| VRIS SHUTTER VALVE ACTUATOR (No.1, No.2) | F2-65 | DESCRIPTION | F2-100 |
| CHECK VALVE | F2-65 | PREPARATION | F2-101 |
| VRIS SOLENOID VALVE (No.1, No.2) | F2-65 | SYSTEM INSPECTION | F2-102 |
| VACUUM CHAMBER | F2-65 | CONTROL SYSTEM | F2-103 |
| FUEL SYSTEM | F2-66 | PREPARATION | F2-103 |
| DESCRIPTION | F2-66 | STRUCTURAL VIEW | F2-104 |
| PREPARATION | F2-67 | POWERTRAIN CONTROL MODULE (PCM) | F2-105 |
| SYSTEM INSPECTION | F2-67 | VOLUME AIR FLOW SENSOR | F2-115 |
| FUEL TANK | F2-69 | CRANKSHAFT POSITION SENSOR | F2-116 |
| FUEL PUMP | F2-71 | CAMSHAFT POSITION SENSOR | F2-117 |
| FUEL FILTER | F2-73 | THROTTLE POSITION SENSOR | F2-117 |
| FUEL INJECTOR | F2-74 | ENGINE COOLANT TEMPERATURE SENSOR | F2-120 |
| PRESSURE REGULATOR | F2-78 | HEATED OXYGEN SENSOR (FRONT, REAR) | F2-121 |
| FUEL PUMP RELAY | F2-78 | KNOCK SENSOR | F2-122 |
| PRESSURE REGULATOR CONTROL SYSTEM | F2-79 | POWER STEERING PRESSURE SWITCH | F2-123 |
| DESCRIPTION | F2-79 | CLUTCH SWITCH | F2-123 |
| PREPARATION | F2-80 | NEUTRAL SWITCH | F2-123 |
| SYSTEM INSPECTION | F2-80 | EGR VALVE POSITION SENSOR | F2-124 |
| PRC SOLENOID VALVE | F2-81 | EGR BOOST SENSOR | F2-124 |
| EXHAUST SYSTEM | F2-82 | MAIN RELAY | F2-125 |
| COMPONENTS PARTS | F2-82 | TROUBLESHOOTING GUIDE | F2-126 |
| OUTLINE OF EMISSION CONTROL SYSTEM | F2-83 | QUICK DIAGNOSIS CHART | F2-126 |
| DESCRIPTION | F2-83 | RELATIONSHIP CHART | F2-130 |
| EXHAUST GAS RECIRCULATION (EGR) CONTROL SYSTEM | F2-84 | USING THIS SECTION | F2-132 |
| DESCRIPTION | F2-84 | DIAGNOSTIC INDEX | F2-134 |
| PREPARATION | F2-85 | SYMPTOM TROUBLESHOOTING | F2-138 |
| SYSTEM INSPECTION | F2-86 | | |

OUTLINE

SYSTEM DIAGRAM





VACUUM HOSE ROUTING DIAGRAM



F2

SYSTEM WIRING DIAGRAM





F2

SPECIFICATIONS

| Item | | Specification | | |
|--|---|---------------------------------------|--------------------------|---------------|
| Idle speed | rpm | 600—700 (650 ± 50) | | |
| Ignition timing* | BTDC | 9°—11° (10° ± 1°) | | |
| Throttle body | | | | |
| Type | | Horizontal draft | | |
| Throat diameter | mm {in} | 60 {2.4} | | |
| Fuel pump | | | | |
| Type | | Impeller (in-tank) | | |
| Maximum output pressure | kPa {kgf/cm ² , psi} | 640 {6.5, 92} | | |
| Fuel filter | | | | |
| Type | Low-pressure side | Nylon element (in fuel pump) | | |
| | High-pressure side | Paper element | | |
| Pressure regulator | | | | |
| Regulating pressure | kPa {kgf/cm ² , psi} | 280 {2.9, 41} | | |
| Fuel injector | | | | |
| Type | | High-ohmic, side-feed | | |
| Type of drive | | Voltage | | |
| Resistance | Ω 20°C {68°F} | 13.8 | | |
| Idle air control valve | | | | |
| Solenoid resistance | Ω 20°C {68°F} | 10.7—12.3 | | |
| Purge solenoid valve | | | | |
| Solenoid resistance | Ω 20°C {68°F} | 30—34 | | |
| Camshaft position sensor (SGC signal) | | | | |
| Type | | Hall effect pick-up | | |
| Volume air flow sensor | | | | |
| Type | | Measuring core type | | |
| Resistance | Ω | E2 ↔ VS | Closed throttle position | 20—600 |
| | | | Wide open throttle | 20—1,000 |
| | E2 ↔ THA (Intake air temperature sensor) | | −20°C {−4°F} | 10,000—20,000 |
| | | | 20°C {68°F} | 2,000—3,000 |
| | | | 60°C {140°F} | 400—700 |
| Engine coolant temperature sensor | | | | |
| Resistance | kΩ | | −20°C {−4°F} | 13.5—16.5 |
| | | | 20°C {68°F} | 2.20—2.70 |
| | | | 80°C {176°F} | 0.29—0.35 |
| | | | 91°C {196°F} | 0.226—0.241 |
| | | | 97°C {207°F} | 0.193—0.205 |
| | | | 108°C {226°F} | 0.145—0.153 |
| | | | 110°C {230°F} | 0.137—0.146 |
| Fuel tank | | | | |
| Capacity | L {US gal, Imp gal} | 58.5 {15.5, 12.9} | | |
| Air cleaner | | | | |
| Element type | | Oil permeated | | |
| Fuel | | | | |
| Specification | | Unleaded— (R+M)/2 method 91 or higher | | |

* TEN terminal of data link connector grounded.

COMPONENT DESCRIPTIONS

| Component | Function | Remark |
|--------------------------------------|--|---|
| A/C relay | Supplies/cuts off battery power to A/C compressor magnetic clutch | <ul style="list-style-type: none"> • Normal open type • Actuated by PCM A/C control signal |
| A/C switch | Detect A/C operation and sends signal to PCM | — |
| Air cleaner | Filters air entering throttle body and reduces air intake noise | <ul style="list-style-type: none"> • Air cleaner element: Wet filter paper |
| BAC valve | Supplies intake air to engine, bypassing throttle valve | <ul style="list-style-type: none"> • Consists of air valve integrated with idle air control valve |
| Battery | Supplies power for engine start, ignition, and operation of electrical devices | — |
| Brake switch | Detects brake pedal operation and sends signal to PCM | — |
| Camshaft position sensor | Detects No.1 cylinder's compression stroke TDC and sends signal to PCM | <ul style="list-style-type: none"> • SGC signal • Installed in distributor |
| Charcoal canister | Stores fuel vapor from fuel tank Draws fresh air through vent cap and purges fuel vapor. Supplies/cuts off fuel vapor to intake manifold via purge solenoid valve | <ul style="list-style-type: none"> • Actuated by PCM purge control signal • For evaporative emission control |
| Check valve | Supplies and maintains intake manifold vacuum in vacuum chamber | <ul style="list-style-type: none"> • For variable resonance induction system (VRIS) |
| | When pressure in fuel tank is positive, supplies fuel vapor to charcoal canister. When pressure is negative, supplies fresh air to tank | <ul style="list-style-type: none"> • Actuated by pressure difference • For evaporative emission control |
| Closed throttle position switch | Detects closed throttle position and sends signal to PCM | <ul style="list-style-type: none"> • Installed in throttle position sensor |
| Condenser fan relay | Supplies/cuts off battery power to condenser fan | <ul style="list-style-type: none"> • Normal open type • Actuated by PCM condenser fan control signal |
| Cooling fan relay | Supplies/cuts off battery power to cooling fan | <ul style="list-style-type: none"> • Normal open type • Actuated by PCM cooling fan control signal |
| Crankshaft position sensor | Detects crank angle in every 60° via crankshaft pulley rotation, and sends signal to PCM | <ul style="list-style-type: none"> • NE signal • PCM converts NE signal (pulse wave) into SGT signal (square wave) |
| Data link connector-2 | Concentrated service connector terminals for diagnosis of electrical system | <ul style="list-style-type: none"> • For on-board diagnosis and service/inspection |
| Distributor | Supplies secondary current to spark plugs | <ul style="list-style-type: none"> • Includes ignition control module and camshaft position sensor • Actuated by PCM IGT signal |
| EGR valve | Supplies/cuts off exhaust gas from exhaust manifold to intake manifold | <ul style="list-style-type: none"> • Includes EGR valve position sensor • For EGR control • Actuated by EGR solenoid valves (vacuum, vent) |
| EGR valve position sensor | Detects EGR valve position and sends signal to PCM | <ul style="list-style-type: none"> • For EGR control • Installed in EGR valve |
| EGR boost sensor | Detects EGR pipe pressure or barometric pressure and sends signal to PCM | — |
| EGR boost sensor solenoid valve | Supplies/cuts off EGR pipe pressure or barometric pressure to EGR boost sensor | <ul style="list-style-type: none"> • For EGR boost sensor switching control |
| EGR solenoid valve (vent and vacuum) | Supplies/cuts off intake manifold vacuum or air from air cleaner to EGR valve | <ul style="list-style-type: none"> • For EGR control • Actuated by PCM EGR control signal |

F2









| Component | Function | Remark |
|-----------------------------------|--|---|
| Engine coolant temperature sensor | Detects engine coolant temperature and sends signal to PCM | — |
| Filler cap | Prevents fuel vapor in fuel tank escaping into atmosphere Depending on vacuum in fuel tank, opens vacuum valve and lets fresh air into tank | — |
| Fresh-air duct | Supplies fresh air to air cleaner | • Equipped with resonance chamber |
| Front fog light switch | Detects front fog light operation and sends signal to PCM (except DRL equipped vehicle) | — |
| Fuel filter (high-pressure side) | Filters fine dirt particles in fuel discharged from fuel pump | — |
| Fuel filter (low-pressure side) | Filters fuel in tank | • Installed in fuel pump assembly |
| Fuel injector | Injects fuel into intake port | • Side feed type • Nozzle: 2 spray ports • Actuated by PCM fuel injection control signal |
| Fuel pump | Supplies/cuts off fuel in tank to fuel injectors | • Actuated by fuel pump relay |
| Fuel pump relay | Supplies/cuts off battery power to fuel pump | • Normal open type • Actuated by PCM fuel pump control signal or by grounding data link connector terminal F/P |
| Fuel tank | Stores fuel | — |
| Fuel vapor valve | Prevents fuel in fuel tank from flowing into charcoal canister when vehicle body tilted | • For evaporative emission control |
| Generator | Charges battery and supplies current to electrical devices | • Includes voltage regulator |
| Heated oxygen sensor | Detects exhaust gas oxygen concentration and sends signal to PCM | • With heater |
| Idle air control valve | Supplies intake air to engine, bypassing throttle valve | • For idle air control • Actuated by PCM idle air control signal |
| Ignition switch | Starts engine and supplies/cuts off current to electrical devices | — |
| Intake air temperature sensor | Detects intake-air temperature and sends signal to PCM | • Installed in volume air flow sensor assembly |
| Main relay | Supplies battery power to electrical devices | • Normal open type • Actuated when ignition switch is at ON or STA position |
| Neutral/clutch switch (MTX) | Detects load/no load condition and sends signal to PCM | — |
| PCV valve | Sends blowby gas in cylinder head into intake manifold | • Actuated by intake manifold vacuum • For blowby gas recirculation |
| Power steering pressure switch | Detects power steering (P/S) operation and sends signal to PCM | — |
| Powertrain control module (PCM) | Controls engine and automatic transaxle operation according to vehicle conditions | • 4-block, 100-pin type |
| PRC solenoid valve | Supplies fresh air or intake manifold vacuum to pressure regulator | • For pressure regulator control • Actuated by PCM pressure regulator control signal |
| Pressure regulator | Adjusts fuel pressure against intake manifold vacuum or atmospheric pressure | • Control pressure: 284 kPa {2.90 kg/cm ² , 41.2 psi} |
| Purge solenoid valve | Supplies/cuts off fuel vapor from charcoal canister to intake manifold | • For purge control • Actuated by PCM purge control signal |
| Rear window defroster switch | Detect electrical load condition of rear window defroster and sends signal to PCM | — |


| Component | Function | Remark |
|--|--|---|
| Refrigerant pressure switch | Detects A/C operation and sends signal to PCM | — |
| Resonance chamber | Reduces intake air pulsation noise | — |
| Starter | Starts engine by rotating flywheel ring gear | — |
| Throttle body | Adjusts intake air amount by varying (non-stage) throttle opening angle in response to accelerator pedal operation | — |
| Throttle position sensor | Detects throttle valve opening angle and sends signal to PCM | <ul style="list-style-type: none"> • Includes closed throttle position switch • Installed in throttle body assembly |
| Transaxle range switch (ATX) | Detects N, P and other ranges and sends signal to PCM | |
| Vacuum chamber | Maintains intake manifold vacuum using check valve, and supplies vacuum | <ul style="list-style-type: none"> • For VRIS control |
| Vehicle speed sensor | Detects pulse signal from speedometer sensor and sends vehicle speed signal to PCM | — |
| Volume air flow sensor | Detects amount of intake air and sends signal to PCM | <ul style="list-style-type: none"> • Measuring core type |
| VRIS shutter valve actuators No.1 & No.2 | Open and close VRIS shutter valves No.1 & No.2 | <ul style="list-style-type: none"> • For VRIS control • Actuated by VRIS solenoid valves No.1 & No.2 |
| VRIS shutter valves No.1 & No.2 | Alter length of intake air pipes | <ul style="list-style-type: none"> • For VRIS control • Actuated by VRIS shutter valve actuators No.1 & No.2 |
| VRIS solenoid valves No.1 & No.2 | Supply fresh air or vacuum chamber vacuum to VRIS shutter valve actuators No.1 & No.2 | <ul style="list-style-type: none"> • For VRIS control • Actuated by PCM VRIS control signal |
| Warm up three way catalytic converter (RH, LH) | Reduces HC, CO, NOx in exhaust gas by chemical reaction | <ul style="list-style-type: none"> • For exhaust gas cleaning |

F2

ENGINE TUNE-UP






PREPARATION SST

| | | | |
|---|---|---|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of ignition timing and idle speed</p> |



ADJUSTMENT Preparation

1. Warm up the engine to normal operating temperature.
2. Shift the selector lever to park/neutral position.
3. Turn off all electrical loads.
 - Headlight
 - Blower motor
 - Rear window defroster
 - A/C
 - Power steering
4. Wait until the cooling fan stops.
5. Connect the **SSTs** (NGS) to the data link connector-2 and select the PID DATA MONITOR AND RECORD function.



Ignition Timing

1. Perform "Preparation". (Refer to page F2-10.)
2. Verify that the idle speed is within the specification.

Specification: 600—700 (650 ± 50) rpm

3. If not as specified, adjust the idle speed. (Refer to below.)
4. Connect the **SST** (system selector) to the data link connector.
5. Set switch (A) to position 1.
6. Set the test switch to SELF TEST.
7. Verify that the idle speed is within the specification.

Specification: 550—750 rpm

8. If not as specified, adjust the idle speed. (Refer to below.)
9. Connect a timing light to the high-tension lead of No. 1 cylinder.
10. Verify that the timing mark (yellow) is within the specification.

Specification: BTDC 9—11° (10 ± 1°)

11. If not as specified, loosen the distributor lock bolts and turn the distributor to make the adjustment.
12. Tighten the distributor lock bolts to the specified torque.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

13. Disconnect the **SSTs**.
14. Verify that the ignition timing is within the specification.

Specification: BTDC 6—18°

Idle Speed

1. Perform "Preparation". (Refer to page F2-10.)
2. Verify that the idle speed is within the specification.

Specification: 600—700 (650 ± 50) rpm

3. If not as specified, connect the **SST** (system selector) to the data link connector.
4. Set switch (A) to position 1.
5. Set the test switch to SELF TEST.


Caution

- The throttle adjusting screw is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

6. Adjust the idle speed by turning the air adjusting screw.

Specification: 600—700 (650 ± 50) rpm

7. Disconnect the **SSTs**.



Idle-up Speed

1. Perform "Preparation". (Refer to page F2-10.)
2. Verify that the idle speed is within the specification.

Specification: 600—700 (650 ± 50) rpm

3. If not as specified, adjust the idle speed. (Refer to page F2-11.)
4. Verify that the idle speed is within the specification with the load condition.

Specification

| Load condition | Idle speed (rpm)*1 |
|----------------|--------------------|
| No load | 600—700 |
| E/L ON*2 | 600—700 |
| A/C ON | 775—875 |
| P/S ON | 600—700 |








*1: Excludes temporary idle speed drop just after the electrical loads are turned on.

- *2:
- Blower motor operating at high speed
 - Headlight switch turned on
 - Rear window defroster switch turned on

5. If not as specified with all load conditions, inspect the idle air control valve.
If not as specified with any one of load conditions, check related input switches, harness and connectors.

ON-BOARD DIAGNOSTIC SYSTEM

PREPARATION
SST



| | | | |
|---|--|--|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For diagnosis of PCM and input/output systems</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For diagnosis of PCM and input/output systems</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For diagnosis of PCM and input/output systems</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of PCM and input/output systems</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of PCM and input/output systems</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For diagnosis of PCM and input/output systems</p> |
| <p>49 T088 010B Program Card</p>  | <p>For diagnosis of PCM and input/output systems</p> | <p>—</p> | <p>—</p> |

DIAGNOSTIC TROUBLE CODE NUMBER Inspection

1. Connect the **SSTs** (NGS) to the data link connector-2. (Refer to page F2-107.)
2. Refer to the manufacturer-provided instruction manual for the NGS operation.
3. Select "DIAGNOSTIC TEST MODE" function and press trigger.
4. When "NO CODES RECEIVED/SYSTEM PASSED" is displayed, all systems monitored are judged OK.
5. When any of the diagnostic trouble codes is displayed, carry out troubleshooting according to the code. (Refer to page F2-14.)
6. When "LINK MONITOR ERROR" is displayed, check connection of the NGS.
7. After all problems have been repaired, carry out "After Repair Procedure." (Refer to below.)

After Repair Procedure

1. After repairs, connect the NGS to the data link connector-2.
2. Select "CLEAR" function and erase diagnostic trouble codes from the NGS memory.
3. Perform diagnostic trouble code inspection again and verify that no diagnostic trouble codes are displayed.





Diagnostic Trouble Code Numbers

| Code No. | Display on the NGS | Condition | Page |
|----------|-------------------------------------|--|-------|
| P0100 | MAF/VAF-CIRCUIT MALFUNCTION | Mass or Volume air flow circuit malfunction | F2-17 |
| P0110 | IAT-CIRCUIT MALFUNCTION | Intake air temperature circuit malfunction | F2-18 |
| P0115 | ECT-CIRCUIT MALFUNCTION | Engine coolant temperature circuit malfunction | F2-19 |
| P0120 | TP-CIRCUIT MALFUNCTION | Throttle position circuit malfunction | F2-20 |
| P0125 | EXCESSIVE TIME TO ENTER CLOSED LOOP | Excessive time to enter closed loop fuel control | F2-21 |
| P0130 | O2S 11-CIRCUIT MALFUNCTION | O ₂ sensor circuit malfunction | F2-21 |
| P0134 | O2S 11-CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F2-22 |
| P0135 | O2S 11-HEATER CIRCUIT MALFUNCTION | O ₂ sensor heater circuit malfunction | F2-23 |
| P0140 | O2S 12-CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F2-24 |
| P0150 | O2S 21-CIRCUIT MALFUNCTION | O ₂ sensor circuit malfunction | F2-24 |
| P0154 | O2S 21-CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F2-25 |
| P0155 | O2S 21-HEATER CIRCUIT MALFUNCTION | O ₂ sensor heater circuit malfunction | F2-26 |
| P0160 | O2S 22-CIRCUIT NO ACTIVITY DETECTED | O ₂ sensor circuit no activity detected | F2-27 |
| P0170 | BANK 1-FUEL TRIM MALFUNCTION | Fuel trim malfunction | F2-28 |
| P0173 | BANK 2-FUEL TRIM MALFUNCTION | Fuel trim malfunction | F2-29 |
| P0300 | RANDOM MISFIRE DETECTED | Random misfire detected | F2-30 |

| Code No. | Display on the NGS | Condition | Page |
|----------|---|---|-------|
| P0301 | CYLINDER 1 MISFIRE DETECTED | Cylinder 1 misfire detected | F2-31 |
| P0302 | CYLINDER 2 MISFIRE DETECTED | Cylinder 2 misfire detected | F2-32 |
| P0303 | CYLINDER 3 MISFIRE DETECTED | Cylinder 3 misfire detected | F2-33 |
| P0304 | CYLINDER 4 MISFIRE DETECTED | Cylinder 4 misfire detected | F2-34 |
| P0305 | CYLINDER 5 MISFIRE DETECTED | Cylinder 5 misfire detected | F2-35 |
| P0306 | CYLINDER 6 MISFIRE DETECTED | Cylinder 6 misfire detected | F2-36 |
| P0325 | KNOCK SENSOR 1-CIRCUIT MALFUNCTION | Knock sensor 1 circuit malfunction | F2-37 |
| P0335 | CRANKSHAFT POS SENSOR-CKT MALFUNCTION | Crankshaft position sensor circuit malfunction | F2-37 |
| P0400 | EGR-FLOW MALFUNCTION | Exhaust gas recirculation flow mal- function | F2-38 |
| P0420 | BANK1 CAT EFFICIENCY BELOW LIMIT | Catalyst system efficiency below threshold | F2-38 |
| P0430 | BANK2 CAT EFFICIENCY BELOW LIMIT | Catalyst system efficiency below threshold | F2-38 |
| P0440 | EVAP SYSTEM-MALFUNCTION | Evaporative emission control system malfunction | F2-39 |
| P0443 | EVAP SYSTEM-PURGE CTRL VALVE CKT MALF | Evaporative emission control system purge control valve circuit malfunc- tion | F2-40 |
| P0505 | IDLE CONTROL SYSTEM-MALFUNCTION | Idle control system malfunction | F2-41 |
| P0510 | CLOSED THROTTLE POS SWITCH-MALFUNCTION | Closed throttle position switch mal- function | F2-42 |
| P0703 | TORQUE CONV/BRAKE SW-MALFUNCTION | Brake switch input malfunction | F2-43 |


| Code No. | Display on the NGS | Condition | Page |
|----------|--------------------------------------|--|-------|
| P1000 | MORE DRIVING NEEDED TO COMPLETE TEST | Check off all OBD-II systems is not complete since last memory clear | F2-44 |
| P1170 | HO2S 11-INVERSION | Heated oxygen sensor (Front RH) (Inversion) | F2-45 |
| P1173 | HO2S 21-INVERSION | Heated oxygen sensor (Front LH) (Inversion) | F2-46 |
| P1195 | EGRBS-OPEN OR SHORT | EGR boost sensor | F2-47 |
| P1196 | STA SW-OPEN OR SHORT | Ignition switch (Start) | F2-47 |
| P1345 | SGC SIGNAL-NO SGC SIGNAL | SGC signal | F2-48 |
| P1402 | EGRS-OPEN OR SHORT | EGR valve position sensor | F2-49 |
| P1521 | VRIS1-OPEN OR SHORT | VRIS solenoid valve No.1 open or short | F2-50 |
| P1522 | VRIS2-OPEN OR SHORT | VRIS solenoid valve No.2 open or short | F2-51 |
| P1609 | PCME (CPU)-MALFUNCTION | PCM's knock control integrated circuit is damaged | F2-52 |
| P1720 | VSS2-NO VSS2 SIGNAL | Speedometer sensor | F2-52 |
| P1794 | BAT-BAT OR CIRCUIT FAIL | Battery | F2-53 |
| P1797 | PNS-OPEN OR SHORT | No P or N range signal or neutral/clutch signal | F2-53 |

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0100 | | MAF/VAF-CIRCUIT MALFUNCTION | |
| Symptom | | Input voltage from volume air flow sensor is below 0.6 V or above 4.9 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Volume air flow sensor malfunction • Open or short circuit in wiring from PCM terminal 3E to volume air flow sensor terminal A • Open or short circuit in wiring from PCM terminal 3A to volume air flow sensor terminal B • Open or short circuit in wiring from PCM terminal 3AB to volume air flow sensor terminal C | |
| STEP | INSPECTION | | ACTION |
| 1 | Does volume air flow sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3E voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect volume air flow sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3A — Volume air flow sensor terminal B) |
| 4 | Is there continuity between connector terminal C and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminal A and PCM terminal 3E? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| | | | |
|---|--|-----|--|
| Diagnostic trouble code No. P0110 | IAT-CIRCUIT MALFUNCTION | | |
| Symptom | Input from intake air temperature sensor is below 0.1 V or above 4.9 V when ignition switch is turned on | | |
| Possible cause | <ul style="list-style-type: none"> • Intake air temperature sensor malfunction • Open or short circuit in wiring from volume air flow sensor terminal E to PCM terminal 3V • Open or short circuit in wiring from volume air flow sensor terminal D to PCM terminal 3AB | | |
| STEP | INSPECTION | | ACTION |
| 1 | Does volume air flow sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3V voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect volume air flow sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal E? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3V — Volume air flow sensor terminal E) |
| 4 | Is there continuity between connector terminal D and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is intake air temperature sensor OK? | Yes | Go to next step |
| | | No | Replace volume air flow sensor |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection or harness of connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | |
|--|--|
| Diagnostic trouble code No. P0115 | ECT-CIRCUIT MALFUNCTION |
| Symptom | Input voltage from engine coolant temperature sensor is below 0.2 V or above 4.9 V when ignition switch is turned on |
| Possible cause | <ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Open or short circuit in wiring from engine coolant temperature sensor terminal A to PCM terminal 3Q • Open or short circuit in wiring from engine coolant temperature sensor terminal B to PCM terminal 3AB |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 1 | Does engine coolant temperature sensor or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3Q voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect engine coolant temperature sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3Q — Engine coolant temperature sensor terminal A) |
| 4 | Is there continuity between connector terminal B and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is engine coolant temperature sensor OK? | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |




HARNESS SIDE CONNECTOR

| Diagnostic trouble code No. P0120 | | TP-CIRCUIT MALFUNCTION | |
|---|--|--|--|
| Symptom | | Input voltage from throttle position sensor is below 0.1 V or above 4.8 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Throttle position sensor malfunction • Open or short circuit in wiring from throttle position sensor terminal B to PCM terminal 3B • Open or short circuit in wiring from throttle position sensor terminal A to PCM terminal 3A • Open or short circuit in wiring from throttle position sensor terminal D to PCM terminal 3AB | |
| STEP | INSPECTION | ACTION | |
| 1 | Does throttle position sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3B voltage OK? | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Is voltage increase linear according to the throttle valve opening angle? | Yes | Go to step 7 |
| | | No | Replace throttle position sensor |
| 4 | Disconnect throttle position sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3A — Throttle position sensor terminal A) |
| 5 | Is there continuity between connector terminal D and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 6 | Is there continuity between connector terminal B and PCM terminal 3B? | Yes | Replace throttle position sensor |
| | | No | Repair or replace wiring harness |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  | | | |
| HARNESS SIDE CONNECTOR | | | |

| | | | |
|--|--|---|---|
| Diagnostic trouble code No. P0125 | | EXCESSIVE TIME TO ENTER CLOSED LOOP | |
| Symptom | | Engine coolant temperature sensor signal does not rise normally because of engine coolant system malfunction | |
| Possible cause | | <ul style="list-style-type: none"> • Engine coolant temperature sensor malfunction • Thermostat malfunction • Engine cooling fan system malfunction • Water pump malfunction • Engine coolant passage clogged and leakage • Engine coolant level and protection | |
| STEP | INSPECTION | | ACTION |
| 1 | Is engine cooling fan system OK? | Yes | Go to next step |
| | | No | Repair or replace engine cooling fan system |
| 2 | Is engine coolant temperature sensor OK? | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor |
| 3 | Is cooling system OK? | Yes | Go to next step |
| | | No | Repair or replace |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |


* During normal driving

| | | | |
|--|--|--|---|
| Diagnostic trouble code No. P0130 | | O2S 11-CIRCUIT MALFUNCTION | |
| Symptom | | <ul style="list-style-type: none"> • Heated oxygen sensor (Front RH) deterioration • Leakage in exhaust system | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Front RH) OK? | Yes | Replace PCM |
| | | No | Repair or replace heated oxygen sensor (Front RH) |

| | | | |
|---|---|--|--|
| Diagnostic trouble code No. P0134 | | O2S 11-CIRCUIT NO ACTIVITY DETECTED | |
| Symptom | | When heated oxygen sensor (Front RH) signal does not exceed 0.5 V after the engine is started, or stays below 0.5 V for two minutes after the engine has reached normal operating temperature and running at 1,500 rpm or over | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor (Front RH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front RH) terminal A to PCM terminal 3I • Intake-air system, fuel system, ignition system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Front RH) connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3I voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front RH) connector. Is there continuity between connector terminal A and PCM terminal 3I? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine coolant temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front RH) |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | |
|--|---|
| Diagnostic trouble code No. P0135 | O2S 11-HEATER CIRCUIT MALFUNCTION |
| Symptom | Open or short circuit is observed in heated oxygen sensor heater (Front RH) system when ignition switch is turned on |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor heater (Front RH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front RH) terminal C to main relay • Open or short circuit in wiring from heated oxygen sensor (Front RH) terminal B to PCM terminal 4E |

| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 1 | Does heated oxygen sensor (Front RH) connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 4E voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front RH) connector and turn ignition switch to ON. Is there battery positive voltage at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Heated oxygen sensor (Front RH) terminal C) |
| 4 | Is there continuity between connector terminal B and PCM terminal 4E? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminals B and C? | Yes | Go to next step |
| | | No | Replace heated oxygen sensor (Front RH) |
| 6 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |




HARNESS SIDE CONNECTOR

| | | | |
|---|---|-----|--|
| Diagnostic trouble code No. P0140 | O2S 12-CIRCUIT NO ACTIVITY DETECTED | | |
| Symptom | When heated oxygen sensor (Rear RH) signal does not exceed 0.5 V after engine is started, or stays below 0.5 V for two minutes after engine has reached normal operating temperature and running at 1,500 rpm or over | | |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor (Rear RH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Rear RH) terminal A to PCM terminal 3D • Open circuit in wiring from heated oxygen sensor (Rear RH) terminal B to PCM terminal 3AB • Intake-air system, fuel system or ignition system malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Rear RH) connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3D voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Rear RH) connector. Is there continuity between connector terminal B and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between connector terminal A and PCM terminal 3D? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine coolant temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich) | Yes | Replace heated oxygen sensor (Rear RH) |
| | | No | Repair or replace |
| 6 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | | | |
|--|--|-----|---|
| Diagnostic trouble code No. P0150 | O2S 21-CIRCUIT MALFUNCTION | | |
| Symptom | <ul style="list-style-type: none"> • Heated oxygen sensor (Front LH) deterioration • Leakage in exhaust system | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Front LH) OK? | Yes | Replace PCM |
| | | No | Repair or replace heated oxygen sensor (Front LH) |

| | |
|--|--|
| Diagnostic trouble code No. P0154 | O2S 21-CIRCUIT NO ACTIVITY DETECTED |
| Symptom | When heated oxygen sensor (Front LH) signal does not exceed 0.5 V after the engine is started, or stays below 0.5 V for two minutes after the engine has reached normal operating temperature and running at 1,500 rpm or over |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor (Front LH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front LH) terminal A to PCM terminal 3M • Intake-air system, fuel system or ignition system malfunction |


| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 1 | Does heated oxygen sensor (Front LH) connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3M voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (front LH) connector. Is there continuity between connector terminal A and PCM terminal 3M? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine coolant temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front LH) |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |



HARNESS SIDE CONNECTOR

| | |
|--|--|
| Diagnostic trouble code No. P0155 | O2S 21-HEATER CIRCUIT MALFUNCTION |
| Symptom | Open or short circuit is observed in heated oxygen sensor heater (Front LH) system when ignition switch is turned on |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor (Front LH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front LH) terminal C to main relay • Open or short circuit in wiring from heated oxygen sensor (Front LH) terminal B to PCM terminal 4I |


| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 1 | Does heated oxygen sensor (Front LH) connector and PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 4I voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front LH) connector and turn ignition switch to ON. Is there battery positive voltage at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Heated oxygen sensor (Front LH) terminal C) |
| 4 | Is there continuity between connector terminal B and PCM terminal 4I? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminals B and C? | Yes | Go to next step |
| | | No | Replace heated oxygen sensor (Front LH) |
| 6 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |



HARNESS SIDE CONNECTOR

| | |
|--|---|
| Diagnostic trouble code No. P0160 | O2S 22-CIRCUIT NO ACTIVITY DETECTED |
| Symptom | When heated oxygen sensor (Rear LH) signal does not exceed 0.5 V after the engine is started, or stays below 0.5 V for two minutes after the engine has reached normal operating temperature and running at 1,500 rpm or over |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor (Rear LH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Rear LH) terminal A to PCM terminal 3H • Open circuit in wiring from heated oxygen sensor (Rear LH) terminal B to PCM terminal 3AB • Intake-air system, fuel system, ignition system malfunction |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 1 | Does heated oxygen sensor (Rear LH) connector and PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3H voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Rear LH) connector. Is there continuity between connector terminal B and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between connector terminal A and PCM terminal 3H? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich) | Yes | Replace heated oxygen sensor (Rear LH) |
| | | No | Repair or replace |
| 6 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |



HARNESS SIDE CONNECTOR

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0170 | | BANK 1-FUEL TRIM MALFUNCTION | |
| Symptom | | Right hand air/fuel ratio stays rich or lean longer than specified period because of system malfunction | |
| Possible cause | | <ul style="list-style-type: none"> • Pressure regulator malfunction • Fuel injector malfunction • Fuel pump malfunction • Engine coolant temperature sensor malfunction • Volume air flow sensor malfunction • Heated oxygen sensor malfunction • Purge solenoid valve malfunction • Leakage in intake-air system • PCM malfunction • Open or short circuit in wiring between PCM terminals 4Q, 4Y, 4AG to fuel injector • Intake air temperature sensor malfunction • EGR boost sensor malfunction • PCV valve malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is there air leakage in intake-air system components? | Yes | Repair or replace intake air device system |
| | | No | Go to next step |
| 2 | Is fuel line pressure OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is fuel pump maximum pressure OK? | Yes | Go to next step |
| | | No | Repair or replace fuel pump |
| 4 | Is pressure regulator OK? | Yes | Go to next step |
| | | No | Repair or replace pressure regulator |
| 5 | Is fuel injector OK? | Yes | Go to next step |
| | | No | Replace fuel injector |
| 6 | Is engine coolant temperature sensor OK? | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor |
| 7 | Is volume air flow sensor OK? | Yes | Go to next step |
| | | No | Replace volume air flow sensor |
| 8 | Is throttle position sensor OK? | Yes | Go to next step |
| | | No | Adjust throttle position sensor |
| 9 | Is closed throttle position switch OK? | Yes | Go to next step |
| | | No | Adjust throttle position sensor |
| 10 | Is intake air temperature sensor OK? | Yes | Go to next step |
| | | No | Replace intake air temperature sensor |
| 11 | Is EGR boost sensor OK? | Yes | Go to next step |
| | | No | Replace EGR boost sensor |
| 12 | Is purge solenoid valve OK? | Yes | Go to next step |
| | | No | Replace PRG solenoid valve |
| 13 | Is PCV valve OK? | Yes | Go to next step |
| | | No | Replace PCV valve |
| 14 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During idling

| | | | |
|--|--|---|--|
| Diagnostic trouble code No. P0173 | | BANK 2-FUEL TRIM MALFUNCTION | |
| Symptom | | Left hand air/fuel ratio stays rich or lean longer than specified period because of system malfunction | |
| Possible cause | | <ul style="list-style-type: none"> • Pressure regulator malfunction • Fuel injector malfunction • Fuel pump malfunction • Engine coolant temperature sensor malfunction • Volume air flow sensor malfunction • Heated oxygen sensor malfunction • Purge solenoid valve malfunction • Leakage in intake-air system • PCM malfunction • Open or short circuit in wiring between PCM terminals 4U, 4AC, 4AK to fuel injector • Intake air temperature sensor malfunction • EGR boost sensor malfunction • PCV valve malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there air leakage in intake-air system components? | Yes | Repair or replace intake air device system |
| | | No | Go to next step |
| 2 | Is fuel line pressure OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is fuel pump maximum pressure OK? | Yes | Go to next step |
| | | No | Repair or replace fuel pump |
| 4 | Is pressure regulator OK? | Yes | Go to next step |
| | | No | Repair or replace pressure regulator |
| 5 | Is fuel injector OK? | Yes | Go to next step |
| | | No | Replace fuel injector |
| 6 | Is engine coolant temperature sensor OK? | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor |
| 7 | Is volume air flow sensor OK? | Yes | Go to next step |
| | | No | Replace volume air flow sensor |
| 8 | Is throttle position sensor OK? | Yes | Go to next step |
| | | No | Adjust throttle position sensor |
| 9 | Is closed throttle position switch OK? | Yes | Go to next step |
| | | No | Adjust throttle position sensor |
| 10 | Is intake air temperature sensor OK? | Yes | Go to next step |
| | | No | Replace intake air temperature sensor |
| 11 | Is EGR boost sensor OK? | Yes | Go to next step |
| | | No | Replace EGR boost sensor |
| 12 | Is purge solenoid valve OK? | Yes | Go to next step |
| | | No | Replace purge solenoid valve |
| 13 | Is PCV valve OK? | Yes | Go to next step |
| | | No | Replace PCV valve |
| 14 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During idling

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0300 | | RANDOM MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is compression at all cylinders normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0301 | | CYLINDER 1 MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.1 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.1 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.1 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.1 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.1 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.1 |
| 5 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.1 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0302 | | CYLINDER 2 MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.2 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.2 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.2 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.2 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.2 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.2 |
| 5 | Is fuel system (RH or LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.2 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0303 | | CYLINDER 3 MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.3 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.3 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.3 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.3 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.3 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.3 |
| 5 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.3 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| Diagnostic trouble code No. P0304 | | CYLINDER 4 MISFIRE DETECTED | |
|--|--|--|--|
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.4 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.4 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.4 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.4 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.4 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.4 |
| 5 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.4 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |


* During normal driving


| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0305 | | CYLINDER 5 MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.5 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.5 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.5 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.5 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.5 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.5 |
| 5 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.5 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| | | | |
|--|--|--|--|
| Diagnostic trouble code No. P0306 | | CYLINDER 6 MISFIRE DETECTED | |
| Symptom | | PCM input signal from crankshaft position sensor signal for cylinder No.6 is irregular | |
| Possible cause | | <ul style="list-style-type: none"> • Ignition system of cylinder No.6 malfunction • Low fuel • Low battery voltage • Fuel system (RH or LH) malfunction • Insufficient compression in cylinder No.6 • Crankshaft position sensor air gap incorrect • Exhaust gas recirculation system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Is ignition system of cylinder No.6 OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 2 | Is ignition timing within specification? | Yes | Go to next step |
| | | No | Adjust ignition timing |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Repair or replace crankshaft position sensor |
| 4 | Is fuel injector at cylinder No.6 OK? | Yes | Go to next step |
| | | No | Repair or replace fuel injector at cylinder No.6 |
| 5 | Is fuel system (RH and LH) OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Is exhaust gas recirculation system OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 7 | Is compression at cylinder No.6 normal? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 8 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During normal driving

| Diagnostic trouble code No. P0325 | | KNOCK SENSOR 1-CIRCUIT MALFUNCTION | |
|---|---|--|--|
| Symptom | | Input voltage from knock sensor is malfunction level preset in PCM when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Knock sensor malfunction • Knock sensor installation incorrect • Open or short circuit in wiring from PCM terminal 3S to knock sensor terminal A | |
| STEP | INSPECTION | ACTION | |
| 1 | Does knock sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect knock sensor connector. Is there continuity between connector A and PCM terminal 3S? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 3 | Is resistance of knock sensor OK? | Yes | Go to next step |
| | | No | Repair or replace knock sensor |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P0335 | | CRANKSHAFT POS SENSOR-CKT MALFUNCTION | |
|---|--|--|--|
| Symptom | | No NE signal input from crankshaft position sensor for 1.5 seconds while engine running | |
| Possible cause | | <ul style="list-style-type: none"> • Crankshaft position sensor malfunction • Open or short circuit in wiring from PCM terminal 4AH to crankshaft position sensor terminal A • Open or short circuit in wiring from PCM terminal 4AL to crankshaft position sensor terminal B | |
| STEP | INSPECTION | ACTION | |
| 1 | Does crankshaft position sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect the crankshaft position sensor connector. Is there continuity between connector terminal B and PCM terminal 4AL? Is there continuity between connector terminal A and PCM terminal 4AH? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 3 | Is crankshaft position sensor air gap OK? | Yes | Go to next step |
| | | No | Replace crankshaft position sensor or crankshaft pulley |
| 4 | Is crankshaft position sensor OK? | Yes | Go to next step |
| | | No | Replace crankshaft position sensor |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | | | |
|--|--|---|---|
| Diagnostic trouble code No. P0400 | | EGR-FLOW MALFUNCTION | |
| Symptom | | Exhaust gas recirculation does not function normally because of electrical or mechanical trouble | |
| Possible cause | | <ul style="list-style-type: none"> • EGR valve malfunction • EGR boost sensor malfunction • EGR boost sensor solenoid valve malfunction • EGR valve position sensor malfunction • EGR solenoid valve (vacuum, vent) malfunction • Clogs or leakage in piping connecting following units <ul style="list-style-type: none"> • EGR boost sensor, EGR boost sensor solenoid valve and intake manifold • Air cleaner, EGR solenoid valve (vent) and EGR valve • Intake manifold, EGR solenoid valve (vacuum) and EGR valve • Warm up three way catalytic converter and EGR valve | |
| STEP | INSPECTION | | ACTION |
| 1 | Is diagnostic trouble code for EGR solenoid valve (vacuum, vent), EGR boost sensor and EGR boost sensor solenoid valve? | Yes | Carry out inspection as required according to diagnostic trouble code |
| | | No | Go to next step |
| 2 | Is EGR valve position sensor OK? | Yes | Go to next step |
| | | No | Repair or replace EGR valve |
| 3 | Check each hose for damage. Are they OK? <ul style="list-style-type: none"> • Intake manifold—EGR solenoid valve (vent) • EGR solenoid valve (vent)—EGR solenoid valve (vacuum) • EGR solenoid valve (vacuum)—EGR valve | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 4 | Is EGR boost sensor OK? | Yes | Go to next step |
| | | No | Replace EGR boost sensor |
| 5 | Check each hose for damage? <ul style="list-style-type: none"> • EGR passage—EGR boost sensor solenoid valve • EGR boost sensor—EGR boost sensor solenoid valve | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |


* During driving when coolant temperature is over 55°C {131°F} and engine speed is over 1,000 rpm (10 km/h {6.2 mph})


| | | | |
|--|---------------------------------------|---|--|
| Diagnostic trouble code No. P0420 | | BANK 1 CAT EFFICIENCY BELOW LIMIT | |
| Symptom | | <ul style="list-style-type: none"> • Warm up three way catalytic converter (RH) deterioration • Leakage in exhaust system | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Rear RH) OK? | Yes | Replace warm up three way catalytic converter (RH) |
| | | No | Replace heated oxygen sensor (Rear RH) |


| | | | |
|--|---------------------------------------|---|--|
| Diagnostic trouble code No. P0430 | | BANK 2 CAT EFFICIENCY BELOW LIMIT | |
| Symptom | | <ul style="list-style-type: none"> • Warm up three way catalytic converter (LH) deterioration • Leakage in exhaust system | |
| STEP | INSPECTION | | ACTION |
| 1 | Is heated oxygen sensor (Rear LH) OK? | Yes | Replace warm up three way catalytic converter (LH) |
| | | No | Replace heated oxygen sensor (Rear LH) |

| | | | |
|--|--|---|--------------------------------|
| Diagnostic trouble code No. P0440 | | EVAP SYSTEM-MALFUNCTION | |
| Symptom | | Evaporative emission control system does not function normally because of mechanical trouble | |
| Possible cause | | <ul style="list-style-type: none"> • Purge solenoid valve malfunction • Charcoal canister malfunction • Check valve malfunction • Fuel vapor valve malfunction • Clogs or leakage in piping connecting following units <ul style="list-style-type: none"> • Intake manifold and purge solenoid valve • Purge solenoid valve and charcoal canister • Charcoal canister, check valve, and fuel vapor valve | |
| STEP | INSPECTION | | ACTION |
| 1 | Is PCM terminal 40 voltage OK? | Yes | Go to next step |
| | | No | Inspect purge solenoid valve |
| 2 | Are evaporative emission control system-related hose free of clogs and leakage? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 3 | Is charcoal canister OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 4 | Is check valve OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 5 | Is fuel vapor valve OK? | Yes | Go to next step |
| | | No | Repair or replace as necessary |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after *rechecking? | Yes | Replace PCM |
| | | No | Temporary system malfunction |

* During driving after engine warm-up


| Diagnostic trouble code No. P0443 | | EVAP SYSTEM-PURGE CTRL VALVE CKT MALF | |
|--|---|--|--|
| Symptom | | Open or short circuit is observed in purge solenoid valve system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Purge solenoid valve malfunction • Open or short circuit in wiring from purge solenoid valve terminal A to main relay terminal F • Open or short circuit in wiring from purge solenoid valve terminal B to PCM terminal 4O | |
| STEP | INSPECTION | | ACTION |
| 1 | Does purge solenoid valve connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 4O voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect purge solenoid valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Purge solenoid valve terminal A) |
| 4 | Is there continuity between connector terminal B and PCM terminal 4O? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between purge solenoid valve terminals A and B? | Yes | Go to next step |
| | | No | Replace purge solenoid valve |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| Diagnostic trouble code No. P0505 | | IDLE CONTROL SYSTEM-MALFUNCTION | |
|---|---|--|--|
| Symptom | | <ul style="list-style-type: none"> • Mechanical trouble is observed in idle air control system • Open or short circuit is observed in idle air control system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Idle air control valve malfunction • Leakage in intake-air system • Open or short circuit in wiring from idle air control valve terminal A to main relay terminal F • Open or short circuit in wiring from idle air control valve terminal B to PCM terminal 4M | |
| STEP | INSPECTION | | ACTION |
| 1 | Does idle air control valve connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 4M voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect idle air control valve connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Idle air control valve terminal A) |
| 4 | Is there continuity between connector terminal B and PCM terminal 4M? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between idle air control valve terminals A and B? | Yes | Go to next step |
| | | No | Replace idle air control valve |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  | | | |
| HARNESS SIDE CONNECTOR | | | |


| | | | |
|--|---|--|--|
| Diagnostic trouble code No. P0510 | | CLOSED THROTTLE POS SWITCH-MALFUNCTION | |
| Symptom | | Input voltage from closed throttle position switch (in throttle position sensor) stays 0 V or above 12 V for more than 33.2 seconds after ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • Closed throttle position switch (in throttle position sensor) malfunction • Throttle position sensor malfunction • Open or short circuit in wiring from throttle position sensor terminal C to PCM terminal 3X • Open or short circuit in wiring from throttle position sensor terminal D to PCM terminal 3AB | |
| STEP | INSPECTION | | ACTION |
| 1 | Does throttle position sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3X voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Is there continuity between connector terminal D and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between connector terminal C and PCM terminal 3X? | Yes | Replace throttle position sensor |
| | | No | Repair or replace wiring harness |
| 5 | Is closed throttle position switch (in throttle position sensor) OK? | Yes | Go to next step |
| | | No | Repair or replace throttle position sensor |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  | | | |
| HARNESS SIDE CONNECTOR | | | |

| | | | |
|--|---|---|---|
| Diagnostic trouble code No. P0703 | | TORQUE CONV/BRAKE SW-MALFUNCTION | |
| Symptom | | No signal input from brake switch to PCM when brake pedal is kept depressed for more than 33 seconds, or signal input when brake pedal is not depressed | |
| Possible cause | | <ul style="list-style-type: none"> • Brake switch malfunction • Open or short circuit in wiring from PCM terminal 10 to brake switch terminal • Open or short circuit in wiring from brake switch terminal to battery terminal | |
| STEP | INSPECTION | | ACTION |
| 1 | Does brake switch connector or PCM connector have poor connection? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is PCM terminal 10 voltage OK? | Yes | Go to step 4 |
| | | No | Go to next step |
| 3 | Is there continuity between brake switch and PCM terminal 10? | Yes | Check for open or short circuit in wiring harness. (Battery — Brake switch) Check brake switch. |
| | | No | Repair or replace wiring harness |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |


| Diagnostic trouble code No. P1000 | MORE DRIVING NEEDED TO COMPLETE TEST | | | | | | | | | | | | | | | | | | | |
|---|--|---|----------|--|-------|---|----------------|--|----------------|-----------------------|-------|------------------|---|--|-------|--|----------------|---|-------|--|
| Possible cause | Following diagnostic trouble code detection conditions not satisfied | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th data-bbox="407 285 1062 317">Diagnosed circuit</th> <th data-bbox="1066 285 1425 317">Code No.</th> </tr> </thead> <tbody> <tr> <td data-bbox="407 323 1062 357">Excessive time to enter closed loop fuel control</td> <td data-bbox="1066 323 1425 357">P0125</td> </tr> <tr> <td data-bbox="407 363 1062 417">O₂ sensor circuit malfunction</td> <td data-bbox="1066 363 1425 417">P0130 P0150</td> </tr> <tr> <td data-bbox="407 424 1062 478">O₂ sensor heater circuit malfunction</td> <td data-bbox="1066 424 1425 478">P0135 P0155</td> </tr> <tr> <td data-bbox="407 485 1062 518">Fuel trim malfunction</td> <td data-bbox="1066 485 1425 518">P0170</td> </tr> <tr> <td data-bbox="407 525 1062 636">Misfire detected</td> <td data-bbox="1066 525 1425 636">P0300, P0301 P0302, P0303 P0304, P0305 P0306</td> </tr> <tr> <td data-bbox="407 642 1062 676">Exhaust gas recirculation flow malfunction</td> <td data-bbox="1066 642 1425 676">P0400</td> </tr> <tr> <td data-bbox="407 682 1062 737">Catalyst system efficiency below threshold</td> <td data-bbox="1066 682 1425 737">P0420 P0430</td> </tr> <tr> <td data-bbox="407 743 1062 777">Evaporative emission control system malfunction</td> <td data-bbox="1066 743 1425 777">P0440</td> </tr> </tbody> </table> | Diagnosed circuit | Code No. | Excessive time to enter closed loop fuel control | P0125 | O ₂ sensor circuit malfunction | P0130 P0150 | O ₂ sensor heater circuit malfunction | P0135 P0155 | Fuel trim malfunction | P0170 | Misfire detected | P0300, P0301 P0302, P0303 P0304, P0305 P0306 | Exhaust gas recirculation flow malfunction | P0400 | Catalyst system efficiency below threshold | P0420 P0430 | Evaporative emission control system malfunction | P0440 | |
| | Diagnosed circuit | Code No. | | | | | | | | | | | | | | | | | | |
| | Excessive time to enter closed loop fuel control | P0125 | | | | | | | | | | | | | | | | | | |
| | O ₂ sensor circuit malfunction | P0130 P0150 | | | | | | | | | | | | | | | | | | |
| | O ₂ sensor heater circuit malfunction | P0135 P0155 | | | | | | | | | | | | | | | | | | |
| | Fuel trim malfunction | P0170 | | | | | | | | | | | | | | | | | | |
| | Misfire detected | P0300, P0301 P0302, P0303 P0304, P0305 P0306 | | | | | | | | | | | | | | | | | | |
| | Exhaust gas recirculation flow malfunction | P0400 | | | | | | | | | | | | | | | | | | |
| | Catalyst system efficiency below threshold | P0420 P0430 | | | | | | | | | | | | | | | | | | |
| Evaporative emission control system malfunction | P0440 | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| ACTION | Carry out troubleshooting according to symptom | | | | | | | | | | | | | | | | | | | |

| | | | |
|---|---|--|--|
| Diagnostic trouble code No. P1170 | | HO2S 11-INVERSION | |
| Symptom | | Heated oxygen sensor (Front RH) signal remains unchanged for more than 20 seconds after engine control has entered feedback zone | |
| Possible cause | | <ul style="list-style-type: none"> • Heated oxygen sensor (Front RH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front RH) terminal A to PCM terminal 3I • Intake-air system, fuel system, ignition system malfunction | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Front RH) connector or PCM connector have poor connection? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is PCM terminal 3I voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front RH) connector. Is there continuity between connector terminal A and PCM terminal 3I? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine coolant temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front RH) |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| | | | |
|---|--|-----|--|
| Diagnostic trouble code No. P1173 | HO2S 21-INVERSION | | |
| Symptom | Heated oxygen sensor (Front LH) signal remains unchanged for more than 20 seconds after engine control has entered feedback zone | | |
| Possible cause | <ul style="list-style-type: none"> • Heated oxygen sensor (Front LH) malfunction • Open or short circuit in wiring from heated oxygen sensor (Front LH) terminal A to PCM terminal 3M • Intake-air system, fuel system, ignition system malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Does heated oxygen sensor (Front LH) connector or PCM connector have poor connection? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is PCM terminal 3M voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect heated oxygen sensor (Front LH) connector. Is there continuity between connector terminal A and PCM terminal 3M? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Are following units OK? <ul style="list-style-type: none"> • Fuel injector • Pressure regulator • Volume air flow sensor • Engine coolant temperature sensor • Spark plug • Air suction (Air/Fuel ratio rich or lean) | Yes | Replace heated oxygen sensor (Front LH) |
| | | No | Repair or replace |
| 5 | Erase diagnostic trouble code from memory. Run the engine at 1,500—2,000 rpm for more than 3 minutes to activate heated oxygen sensor. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P1195 | | EGRBS-OPEN OR SHORT | |
|--|--|---|--|
| Symptom | | Input voltage from EGR boost sensor is malfunction level preset in PCM when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR boost sensor malfunction • Open or short circuit in wiring from PCM terminal 3F to EGR boost sensor terminal B • Open or short circuit in wiring from PCM terminal 3A to EGR boost sensor terminal C • Open circuit in wiring from PCM terminal 3AB to EGR boost sensor terminal A | |
| STEP | INSPECTION | | ACTION |
| 1 | Does EGR boost sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3F voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Disconnect EGR boost sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal C? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3A — EGR boost sensor terminal C) |
| 4 | Is there continuity between connector terminal A and PCM terminal 3AB? | Yes | Replace EGR boost sensor |
| | | No | Repair or replace wiring harness |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |


| Diagnostic trouble code No. P1196 | | STA SW-OPEN OR SHORT | |
|--|---|--|--|
| Symptom | | Input signal from starter to PCM continues for more than 33 seconds | |
| Possible cause | | <ul style="list-style-type: none"> • Starter malfunction • Open or short circuit in wiring from starter terminal S and PCM terminal 1H | |
| STEP | INSPECTION | | ACTION |
| 1 | Does starter connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 1H voltage OK? | Yes | Go to step 4 |
| | | No | Go to next step |
| 3 | Disconnect starter connector. Is there continuity between connector terminal S and PCM terminal 1H? | Yes | Replace starter |
| | | No | Repair or replace |
| 4 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |


| Diagnostic trouble code No. P1345 | | SGC SIGNAL-NO SGC SIGNAL | |
|---|--|--|---|
| Symptom | | No SGC signal input from camshaft position sensor while engine rotates two cycles | |
| Possible cause | | <ul style="list-style-type: none"> • Camshaft position sensor malfunction • Open or short circuit in wiring from distributor 6-pin connector terminal B to main relay terminal F • Open or short circuit in wiring from PCM terminal 4F to distributor 6-pin connector terminal D | |
| STEP | INSPECTION | | ACTION |
| 1 | Does distributor 6-pin connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Disconnect distributor connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — Distributor 6-pin connector terminal B) |
| 3 | Is there continuity between connector terminal D and PCM terminal 4F? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is PCM terminal 4F voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 5 | Is camshaft position sensor OK? | Yes | Go to next step |
| | | No | Replace distributor |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| Diagnostic trouble code No. P1402 | | EGRS-OPEN OR SHORT | |
|--|---|--|---|
| Symptom | | Input voltage from EGR valve position sensor is below 0.2 V or above 4.8 V when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • EGR valve position sensor malfunction • Open or short circuit in wiring from EGR valve position sensor terminal C to PCM terminal 3R • Open or short circuit in wiring from EGR valve position sensor terminal B to PCM terminal 3A • Open or short circuit in wiring from EGR valve position sensor terminal A to PCM terminal 3AB | |
| STEP | INSPECTION | | ACTION |
| 1 | Does EGR valve position sensor connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 3R voltage OK? | Yes | Go to step 7 |
| | | No | Go to next step |
| 3 | Disconnect EGR valve position sensor connector. Turn ignition switch to ON. Is there 5 V at connector terminal B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (PCM terminal 3A — EGR valve position sensor terminal B) |
| 4 | Is there continuity between connector terminal A and PCM terminal 3AB? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between connector terminal C and PCM terminal 3R? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 6 | Is resistance of EGR valve position sensor OK? | Yes | Go to next step |
| | | No | Replace EGR control valve |
| 7 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |



HARNESS SIDE CONNECTOR

| Diagnostic trouble code No. P1521 | | VRIS1-OPEN OR SHORT | |
|---|---|---|--|
| Symptom | | Open or short circuit is observed in VRIS solenoid valve No.1 system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • VRIS solenoid No.1 malfunction • Open or short circuit in wiring from VRIS solenoid valve No.1 terminal B to PCM terminal 1AA • Open or short circuit in wiring from VRIS solenoid valve No.1 terminal A to main relay terminal F | |
| STEP | INSPECTION | ACTION | |
| 1 | Does VRIS solenoid valve No.1 connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 1AA voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect VRIS solenoid valve No.1 connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — VRIS solenoid valve No.1 terminal A) |
| 4 | Is there continuity between connector terminal B and PCM terminal 1AA? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between VRIS solenoid valve No.1 terminals A and B? | Yes | Go to next step |
| | | No | Replace VRIS solenoid valve No.1 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  <p>HARNESS SIDE CONNECTOR</p> | | | |

| | | | |
|---|---|---|--|
| Diagnostic trouble code No. P1522 | | VRIS2-OPEN OR SHORT | |
| Symptom | | Open or short circuit is observed in VRIS solenoid valve No.2 system when ignition switch is turned on | |
| Possible cause | | <ul style="list-style-type: none"> • VRIS solenoid No.2 malfunction • Open or short circuit in wiring from VRIS solenoid valve No.2 terminal B to PCM terminal 1AE • Open or short circuit in wiring from VRIS solenoid valve No.2 terminal A to main relay terminal F | |
| STEP | INSPECTION | ACTION | |
| 1 | Does VRIS solenoid valve No.2 connector or PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 1AE voltage OK? | Yes | Go to step 6 |
| | | No | Go to next step |
| 3 | Disconnect VRIS solenoid valve No.2 connector. Turn ignition switch to ON. Is there battery positive voltage at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (Main relay terminal F — VRIS solenoid valve No.2 terminal A) |
| 4 | Is there continuity between connector terminal B and PCM terminal 1AE? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 5 | Is there continuity between VRIS solenoid valve No.2 terminals A and B? | Yes | Go to next step |
| | | No | Replace VRIS solenoid valve No.2 |
| 6 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |
|  | | | |
| HARNES SIDE CONNECTOR | | | |

| | | | |
|--|---|-----|--|
| Diagnostic trouble code No. P1609 | PCME (CPU)-MALFUNCTION | | |
| Symptom | PCM's knock control integrated circuit is damaged | | |
| Possible cause | PCM's knock control integrated circuit is damaged | | |
| STEP | INSPECTION | | ACTION |
| 1 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |

| | | | |
|--|---|-----|--|
| Diagnostic trouble code No. P1720 | VSS2-NO VSS2 SIGNAL | | |
| Symptom | No vehicle speed sensor signal input from vehicle speed sensor while driving | | |
| Possible cause | <ul style="list-style-type: none"> • Speedometer sensor malfunction • Open or short circuit in wiring from ignition switch to speedometer sensor • Open or short circuit in wiring from speedometer sensor to GND • Open or short circuit in wiring from speedometer sensor to vehicle speed sensor • Open or short circuit in wiring from vehicle speed sensor to PCM terminal 1C | | |
| STEP | INSPECTION | | ACTION |
| 1 | Does vehicle speed sensor connector and PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 1C voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is there continuity between vehicle speed sensor terminal and PCM terminal 1C? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is there continuity between vehicle speed sensor and speedometer sensor terminals? | Yes | Go to next step |
| | | No | Repair or replace speedometer sensor and wiring harness |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |

* During driving after engine warm-up

| | | | |
|--|---|---|--|
| Diagnostic trouble code No. P1794 | | BAT-BAT OR CIRCUIT FAIL | |
| Symptom | | Battery positive voltage is not constantly applied to PCM terminal 4B | |
| Possible cause | | <ul style="list-style-type: none"> • Battery malfunction • Open or short circuit in wiring from PCM terminal 4B to battery positive cable • Burnt fuse | |
| STEP | INSPECTION | | ACTION |
| 1 | Is battery fully charged? | Yes | Go to next step |
| | | No | Charge the battery |
| 2 | Does battery positive voltage present at PCM terminal 4B? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness (PCM terminal 4B — Battery) |
| 3 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |

| | | | |
|--|--|--|---|
| Diagnostic trouble code No. P1797 | | PNS-OPEN OR SHORT | |
| Symptom | | <ul style="list-style-type: none"> • PCM judges N position for more than 33 seconds when shift lever is in D range (ATX) • PCM judges neutral/clutch switch OFF for more than 5 seconds while vehicle stopped and engine running (MTX) | |
| Possible cause | | <ul style="list-style-type: none"> • Transaxle range switch malfunction • Neutral/clutch switch malfunction • Open or short circuit in wiring from transaxle range switch terminal H to PCM terminal 1F | |
| STEP | INSPECTION | | ACTION |
| 1 | Does PCM connector have poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is PCM terminal 1F voltage OK? | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Is there continuity between transaxle range switch terminal H and PCM terminal 1F or neutral/clutch switch terminal and PCM terminal 1F? | Yes | Go to next step |
| | | No | Repair or replace wiring harness |
| 4 | Is transaxle range switch OK? (ATX) Is neutral/clutch switch OK? (MTX) | Yes | Go to next step |
| | | No | Repair or replace transaxle range switch (ATX) Repair or replace neutral/clutch switch (MTX) |
| 5 | Erase diagnostic trouble code from memory. Is same code No. present after rechecking? | Yes | Replace PCM |
| | | No | Intermittent poor connection of harness or connector (Repair connector and/or harness) |

INTAKE-AIR SYSTEM


COMPONENT PARTS

Removal / Inspection / Installation


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|--|--|
| 1. Fresh-air duct Inspect for damage and cracks | 6. Fuel pipe |
| 2. Air cleaner Inspect for damage and cracks | 7. Intake manifold Inspection page F2-57 |
| 3. Volume air flow sensor | 8. Throttle body Inspection page F2-55 |
| 4. Air intake hose Inspect for damage | 9. BAC valve Inspection page F2-60 |
| 5. Accelerator cable Inspection / Adjustment page F2-56 | 10. Air intake pipe Inspection page F2-57 |
| | 11. Fuel distributor |




Removal Note

Fuel hose


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.



Water hose

1. Loosen the drain plug and drain the coolant from the radiator. (Refer to section E2.)
2. Remove the water hose from the BAC valve.
3. After installation of the throttle body, refill the radiator. (Refer to section E2.)




Installation Note

Air intake pipe

1. Apply a small amount of clean engine oil to new O-rings before installing them.
2. Install the air intake pipe.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



THROTTLE BODY


Inspection

1. Check the throttle body for wear, coolant leakage, and deposits.
2. Verify that the throttle valve moves smoothly from closed throttle position to wide open throttle.
3. Replace the throttle body, if necessary.

ACCELERATOR PEDAL


Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.



1. Accelerator cable
Inspection / Adjustment below
2. Cruise actuator cable
3. Retainer
4. Clip

5. Accelerator pedal
Inspect for damage
6. Return spring
7. Bracket




**ACCELERATOR CABLE
Installation / Adjustment**

1. Verify that the throttle valve is closed throttle position.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.5 mm {0.06—0.17 in}

3. If not as specified, turn stopper B while pressing lock button A to release the lock.
4. Push the spring in direction C and adjust the cable free play.
5. Lock stopper A after locking stopper B.


**AIR INTAKE PIPE/INTAKE MANIFOLD****Inspection**

1. Check for damage and cracks.
2. Verify flatness of the air intake pipe and intake manifold contact surface as shown.
3. Replace the air intake pipe and/or intake manifold, if necessary.









IDLE AIR CONTROL SYSTEM

DESCRIPTION

The idle air control system controls the bypass air amount that passes through the throttle body to improve idle stability, warm-up, and drivability. This system consists of the idle air control valve, air valve, PCM, and input devices.




PREPARATION
SST

| | | | |
|---|--|--|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of idle air control system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control system</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of idle air control system</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of idle air control system</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of idle air control system</p> |

SYSTEM INSPECTION




1. Start the engine and run it at idle.
2. Disconnect the IAC valve connector and verify that the engine rotation becomes rough or the engine stalls.
3. If the engine condition will not change, do as follows.
 - (1) Connect the **SSTs**.
 - (2) Verify that diagnostic trouble code No. P0505 is not displayed. If code No. P0505 is shown, carry out troubleshooting of the code No. P0505.
 - (3) Change the duty value of the IAC valve to 100% by using the **SIMULATION TEST** function and verify that the idle speed increases.
 - I. If the idle speed increases, replace the PCM. (Refer to page F2-106.)
 - II. If the idle speed does not change, replace the BAC valve. (Refer to page F2-60.)
4. Warm up the engine to normal operating temperature and run it at idle.
5. Turn the electrical loads on and verify that the engine speed is within the specification.



Engine speed (rpm)

| | |
|--------------|---------|
| No load | 600—700 |
| E/L operated | 600—700 |
| A/C operated | 775—875 |
| P/S operated | 600—700 |

6. If not as specified, check the related switches and wiring harnesses.



BAC VALVE

Inspection

Air valve system inspection

1. Verify that the engine coolant temperature is below 20°C {68°F}.
2. Connect the **SST** to the data link connector.
3. Set the system select to position 1 and test switch to **SELF TEST**.
4. Start the engine.
5. Verify that the idle speed decreases gradually as the engine warms up.

Air valve inspection

1. Remove the BAC valve. (Refer to above.)
2. Circulate water in the BAC valve coolant passage to cool the air valve.
3. Circulate hot water in the BAC valve coolant passage and verify that the air valve operates.
4. If not, replace the BAC valve.

Idle air control valve

1. Remove the throttle body. (Refer to page F2-54.)
2. Measure the resistance of the idle air control valve.

Resistance: 10.7—12.3Ω [at 20°C {68°F}]

3. If not as specified, replace the BAC valve.


Removal / Installation

(Refer to page F2-54.)

VARIABLE RESONANCE INDUCTION SYSTEM (VRIS)

DESCRIPTION








The inside of the dynamic chamber is divided into two sections, interconnected by two shutter valves and connecting pipes for variable resonance induction operation. This system opens and closes the shutter valves according to the engine speed to improve the charging efficiency by utilizing the pressure waves of the intake air. There are two vacuum chambers under the left bank of the intake manifold that are used to supply constant vacuum to the VRIS shutter valve actuators during wide-open throttle operation and other low-vacuum, low-speed situations.





Operation

| Engine speed | rpm | 0—3,250 | 3,250—4,250 | 4,250—6,250 | 6,250—7,500 |
|-------------------------|-----|---------|-------------|-------------|-------------|
| VRIS shutter valve No.1 | | Closed | Open | Open | Closed |
| VRIS shutter valve No.2 | | Closed | Closed | Open | Closed |

PREPARATION SST

| | | | |
|---|-------------------------------|---|-------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of VRIS</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of VRIS</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of VRIS</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of VRIS</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of VRIS</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of VRIS</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of VRIS</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

1. Start the engine.
2. Verify that the rods of the shutter valve actuator 1 and 2 are not pulled.
3. If the rods are pulled, do as follows.
 - (1) Stop the engine.
 - (2) Connect the **SSTs**.
 - (3) Verify that diagnostic trouble code No. P1521 or P1522 is not displayed. If code No. P1521 or P1522 is shown, carry out troubleshooting of the code No. P1521, P1522. (Refer to page F2-13.)
 - (4) If diagnostic trouble codes are not shown, do as follows.
 - I. Start the engine and run it at idle.
 - II. Turn the VRIS solenoid valve from ON to OFF by using the SIMULATION TEST function and check if operation sound of the valve is heard.
 - III. If the operation sound is heard, check the following.
 - Shutter valve actuators (Refer to page F2-65.)
 - IV. If the operation sound is not heard, check the following.
 - VRIS solenoid valve (Refer to page F2-65.)
4. Position the vehicle on a chassis roller and shift the selector lever to D.
5. Check the rod operation under the following conditions.

Rod operation


| Engine speed (rpm) | 0 | 3250 | 4250 | 6250 | 7500 |
|--------------------------|-------------|---------|---------|-------------|------|
| Shutter valve actuator 1 | Not operate | Operate | | Not operate | |
| Shutter valve actuator 2 | Not operate | | Operate | Not operate | |

6. Rod operation is not as specified, do as follows.
 - (1) Stop the engine.
 - (2) Install the **SSTs**.
 - (3) Verify that diagnostic trouble code No. P1521 or P1522 is not displayed. If code No. P1521 or P1522 is shown, carry out troubleshooting of the code No. P1521, P1522. (Refer to page F2-13.)
 - (4) If diagnostic trouble codes are not shown, do as follows.
 - I. Start the engine and run it at idle.
 - II. Turn the VRIS solenoid valve from ON to OFF by using SIMULATION TEST function and check if operation sound of the valve is heard.
 - III. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - Shutter valve actuators (Refer to page F2-65.)
 - Throttle position sensor (Refer to page F2-117.)
 - IV. If the operation sound is not heard, check the following.
 - VRIS solenoid valve (Refer to page F2-65.)

COMPONENT PARTS


Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}


- | | |
|--------------------------------|--|
| 1. VRIS solenoid valve No.1 | 4. Intake manifold (Refer to page F2-49) |
| Inspection page F2-65 | 5. Vacuum chamber |
| 2. VRIS solenoid valve No.2 | Inspection page F2-65 |
| Inspection page F2-65 | 6. Check valve |
| 3. VRIS shutter valve actuator | Inspection page F2-65 |
| Inspection page F2-65 | |



VRIS SHUTTER VALVE ACTUATOR (No.1, No.2)

Inspection


1. Disconnect the vacuum hose from the shutter valve actuator.
2. Connect a vacuum pump to the actuator.
3. Apply vacuum and verify that the rod is pulled into the actuator.



CHECK VALVE

Inspection

1. Remove the check valve.
2. Blow through A and verify that air flows from B.
3. Blow through B and verify that air does not flow from A.




VRIS SOLENOID VALVE (No.1, No.2)

Inspection


1. Disconnect the solenoid valve.
2. Verify that air flow between each port as shown below.

| Port | Airflow |
|------|---------|
| A—B | No |
| A—C | No |
| B—C | Yes |



3. Apply battery positive voltage and a ground to the terminals of the solenoid valve.
4. Verify that air flow between each port as shown below.

| Port | Airflow |
|------|---------|
| A—B | Yes |
| A—C | No |
| B—C | No |



VACUUM CHAMBER


Inspection

1. Visually check the vacuum chambers for clogging, damage, and cracks.
2. Replace if necessary.


FUEL SYSTEM




DESCRIPTION

This system supplies fuel to the fuel injectors at a constant pressure. Fuel is metered and injected into the intake manifold ports according to injection control signals from the PCM. The system consists of the fuel tank, fuel pump, fuel filters, fuel distributor, pressure regulator, fuel injectors, and fuel pump relay.



**PREPARATION
SST**

| | | |
|--|---|---|
| <p>49 E018 9A0 Checker set, injector</p> |  | <p>For inspection of fuel injectors</p> |
|--|---|---|



Fuel Pressure Release and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following “Fuel Line Safety Procedures”.

Fuel Line Safety Procedures

- A. Release the fuel pressure before disconnecting a fuel line.
 1. Start the engine.
 2. Remove the fuel pump relay.
 3. After the engine stalls, turn the ignition switch to OFF.
 4. Install the fuel pump relay.
- B. Avoid leakage.
 1. When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 2. Plug the hose after removal.
- C. Install hose clamps to secure the fuel pressure gauge to fuel filter and the main hose.



SYSTEM INSPECTION

Fuel Pressure Hold Inspection

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” above.

1. Disconnect the negative battery cable.





2. Install a fuel pressure gauge.
3. Connect the negative battery cable.

4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**

Fuel pressure:

More than 150 kPa {1.5 kgf/cm², 21 psi}

8. If not as specified, perform the following inspections.
 - Fuel pump (Refer to page F2-71.)
 - Pressure regulator (Refer to page F2-78.)
 - Fuel injector leakage (Refer to page F2-74.)



Fuel Line Pressure Inspection

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F2-67.**

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch to ON.
6. Measure the fuel line pressure.

Fuel line pressure:

270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

Pressure low — Measure fuel pump maximum pressure. (Refer to Page F2-71.) If as specified, fuel line or fuel filter might be clogged or restricted.

Pressure high — Replace pressure regulator.


FUEL TANK

Removal / Inspection / Installation


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|----------------------------------|------------------|
| 1. Connector | |
| 2. Fuel hoses | |
| Installation Note | page F2-70 |
| 3. Evaporative hoses | |
| Installation Note | page F2-70 |
| 4. Fuel tank strap | |
| Inspect for cracks and corrosion | |
| 5. Fuel tank | |
| 6. Check valve (Two-way) | |
| Inspection | page F2-94 |




Removal Note

Before removing the fuel tank, drain the fuel from the tank.

1. Remove the fuel pump relay.
2. Start the engine.
3. After the engine stalls, turn off the ignition switch.
4. Install the fuel pump relay.



5. Remove the filler cap and insert a hose into the fuel tank through the filler pipe.
6. Start the pump and suck up the fuel into a container.




Note

- For easier work, prepare a hose of following size.



Outer diameter: 13 mm {0.51 in}

Length: 2,160 mm {85.0 in}



Installation Note

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings **at least 25 mm {1.0 in}**.
2. Push the fuel filler hose onto the fuel tank pipe and filler pipe **at least 35 mm {1.4 in}**.



FUEL PUMP

Inspection

Fuel pump maximum pressure

Warning


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F2-67.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the main fuel pipe and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON to operate the fuel pump.
6. Measure the pump maximum pressure.

Fuel pump maximum pressure:

500—630 kPa {5.0—6.5 kgf/cm², 72—92 psi}

7. Turn the ignition switch to OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.




Continuity Inspection


1. Disconnect the fuel tank unit connector.
2. Check for continuity between fuel tank unit connectors Ⓐ and ⓓ.
3. If there is none, replace the fuel pump.

Removal / Installation

1. Remove the fuel tank. (Refer to page F2-69.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of disassembly, referring to **Installation Note**.



- | | |
|-------------------|---------------------|
| 1. Fuel hose | 3. Fuel pump |
| 2. Fuel pump ring | 4. Fuel pump gasket |
- Removal / Installation Note Below




Removal Note

Rotate the fuel pump ring counterclockwise, and remove it.

Installation Note

Rotate the fuel pump ring clockwise until the flange touches the stopper.




FUEL FILTER

Replacement

High pressure side


The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

1. Disconnect the fuel hoses from the fuel filter.
2. Remove the fuel filter and bracket.
3. Install in the reverse order of removal.
4. Verify that the fuel hoses are pushed fully onto the fuel filter nozzles.




1. Negative battery cable
2. Air cleaner

3. Harness
4. Fuel filter (High pressure side)



Low pressure side (in-tank filter)

(Refer to page F2-69.)



FUEL INJECTOR Inspection (On-vehicle)

1. Warm up the engine and let it idle.
2. Listen for operational sound of each fuel injector with a screwdriver or a sound scope.

Note


- The best way to judge the performance of an fuel injector is to compare its sound with the sound of other fuel injectors.

Removal / Installation


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|------------------------------------|------------------------------------|
| 1. Negative battery cable | 7. Insulator |
| 2. Air cleaner housing | 8. Accumulated connector |
| 3. Fuel injector connector | 9. Spacer |
| 4. Fuel hose and fuel pipe | 10. Fuel injector |
| 5. Fuel distributor (RH) | Installation note page F2-75 |
| Installation note page F2-75 | 11. Pressure regulator |
| 6. Fuel distributor (LH) | Inspection page F2-78 |
| Installation note page F2-75 | |



Installation Note
Fuel injector installation


1. Install new O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing them.
3. Verify that the fuel injector holder is clean.
4. Clean the holder with gasoline, if necessary.
5. Install the fuel injector squarely into the distribution pipe while turning it back and forth.



6. Fit the fuel injector tab into the notch in the distribution pipe.
7. Install the harness.


Tightening torque:

2.5—3.5 N·m {25—36 kgf·cm, 22—31 in·lbf}




Fuel leakage test

1. With the fuel injector assembly removed, install the fuel hoses as shown in the figure.








2. Connect the data link connector terminals F/P and GND with a jumper wire.
3. Turn the ignition switch to ON and check for fuel leaks from the fuel distributor.
4. If fuel leaks, check the fuel injector O-rings and fuel distributor for damage.



Fuel distributor installation

1. Install new fuel injector insulators.
2. Install the insulators, making sure that each is pressed in fully, and that it is not twisted or bent. Incorrectly installed insulators can cause rough idle.



Inspection

Note

- It is not necessary to remove the fuel injectors to perform the following procedures.

Injector resistance

1. Disconnect the fuel injector connectors.
2. Measure resistance of the injectors.

| Harness | Terminal | Injector No. |
|------------|----------|--------------|
| Right Bank | a-b | 1 |
| | a-c | 5 |
| | a-d | 3 |
| Left Bank | d-c | 2 |
| | d-b | 4 |
| | d-a | 6 |

Resistance: Approx. 13.8Ω [20°C {68°F}]

3. If not as specified, check continuity of the harness and check for poor connection.
4. If the harness is OK, replace the fuel injector.


Fuel leakage test

1. Remove the fuel distributor assembly from the intake manifold. (Refer to page F2-64.)
2. Connect the fuel hoses.

3. Connect the data link connector terminals F/P and GND by using a jumper wire.
4. Turn the ignition switch to ON and check for fuel leaks from the fuel injectors.

Fuel leakage: Less than 1 drop/2 min.

5. If not as specified, remove the leaking fuel injector and check the O-rings and fuel distributor for damage. Replace as necessary.
6. Install the fuel injector.
7. Turn the ignition switch to ON and check for fuel leaks from fuel injector.
8. If not as specified, replace the fuel injector.




Volume Test

1. Remove the fuel injectors and fuel distributor assembly.
2. Connect the **SST** as shown in the figure.

Warning

- **Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.**





3. Measure the injection volume of each fuel injector by using a graduated container.

Injection volume:

48—56 cm³ {48—56 cc, 2.9—3.4 cu in}/15 sec.

4. If not as specified, replace the fuel injector.



PRESSURE REGULATOR

Inspection

Fuel line pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Start the engine and let it idle.
5. Measure the fuel line pressure.

Fuel line pressure:


210—250 kPa {2.1—2.6 kgf/cm², 30—36 psi}

6. Disconnect the vacuum hose from the pressure regulator and plug it.
7. Measure the fuel line pressure again.

Fuel line pressure:

270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

8. If not as specified, replace the pressure regulator.




FUEL PUMP RELAY

Inspection

Operation check

Listen for clicking of the fuel pump relay while cranking the engine.



Continuity inspection

1. Apply battery positive voltage (B+) and check continuity between terminals of the relay.

B+: Battery positive voltage


| Terminal A—B | Terminal C—D |
|----------------|--------------|
| B+ applied | Yes |
| B+ not applied | No |

2. If not as specified, replace the fuel pump relay.








PRESSURE REGULATOR CONTROL SYSTEM

DESCRIPTION

To prevent percolation of the fuel during hot restart idle, vacuum to the pressure regulator is momentarily cut and the fuel injection pressure is increased to slightly more than **280 kPa {2.9 kgf/cm², 41 psi}**. Pressure in the fuel line at idle is **approx. 230 kPa {2.3 kgf/cm², 33 psi}**.




PREPARATION SST

| | | | |
|--|---|--|---|
| 49 T088 0A0 NGS set  | For inspection of pressure regulator control system | 49 T088 001 Control Unit (Part of 49 T088 0A0)  | For inspection of pressure regulator control system |
| 49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)  | For inspection of pressure regulator control system | 49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)  | For inspection of pressure regulator control system |
| 49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)  | For inspection of pressure regulator control system | 49 T088 008A Instruction Manual  | For inspection of pressure regulator control system |
| 49 T088 010B Program Card  | For inspection of pressure regulator control system | — | — |

SYSTEM INSPECTION

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-67.





1. Install the fuel pressure gauge.
2. Measure the fuel pressure under the following conditions.

Specifications

| | Fuel pressure (kPa { kgf/cm ² }) | | |
|------------------------------|---|--------------------------------------|--------------------------------------|
| | Idling | 210—250 { 2.1—2.6 } | 210—250 { 2.1—2.6 } |
| During 120 sec. of hot start | 260—310 { 2.6—3.2 } | | |
| After 120 sec. of hot start | 210—250 { 2.1—2.6 } | | |
| Judgement | Normal | Not normal (Perform Inspection 1) | Not normal (Perform Inspection 2) |

3. If the fuel pressure is not within the specification, carry out either Inspection 1 or Inspection 2 as required.





Inspection 1

1. Stop the engine.
2. Connect the **SSTs**.
3. Start the engine and run it at idle.
4. Turn the PRC solenoid valve from OFF to ON by using the **SIMULATION TEST** function and check if the fuel pressure changes.
 - (1) If the pressure changes, check the following.
 - PCM terminal voltage (Refer to page F2-106.)
 - Engine coolant temperature signal
 - Intake air temperature signal
 - Closed throttle position signal
 - (2) If the pressure does not change, do as follows.
 - I. Stop the engine.
 - II. Turn the ignition switch to ON.
 - III. Turn the PRC solenoid valve from OFF to ON by using the simulation function and check if the operation sound of the valve is heard.
 - a. If the operation sound is heard, check the following.
 - Pressure regulator (Refer to page F2-78.)
 - b. If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to below.)
 - Wiring between PRC solenoid valve and PCM terminal 1B

Inspection 2

1. Stop the engine.
2. Install the **SSTs**.
3. By using the **PID DATA MONITOR AND RECORD** function, verify that the PRC solenoid valve is OFF.
4. If the PRC solenoid valve is ON, check the following.
 - PCM terminal voltage (Refer to page F2-105.)
 - Engine coolant temperature signal
 - Intake air temperature signal
5. Turn the PRC solenoid valve from OFF to ON by using the **SIMULATION TEST** function and check if the operation sound of the valve is heard.
 - (1) If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose between the pressure regulator, PRC solenoid valve, and intake manifold.
 - (2) If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to below.)
 - Wiring between PRC solenoid valve and PCM terminal 1B



PRC SOLENOID VALVE

1. Remove the solenoid valve.
2. Blow through the solenoid valve from port A.
3. Verify that air flows from port B.
4. Apply battery voltage to solenoid valve terminal.
5. Blow through the solenoid valve from port A.
6. Verify that air flows from the valve air filter.
7. If not as specified, replace the solenoid valve.

EXHAUST SYSTEM


COMPONENTS PARTS

Inspection (On-vehicle)

Start the engine and verify that there is no exhaust gas leakage from the exhaust system components.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Check all parts and repair or replace as necessary.
3. Install in the reverse order of removal.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Main silencer Inspect for deterioration and restriction 2. Pre silencer Inspect for deterioration and restriction 3. Three way catalytic converter Inspect for deterioration and restriction 4. Transverse member | <ol style="list-style-type: none"> 5. Front pipe Inspect for deterioration and cracks 6. Insulator 7. EGR pipe Inspect for deterioration and cracks 8. Warm up three way catalytic converter Inspect for deterioration and cracks |
|---|---|

OUTLINE OF EMISSION CONTROL SYSTEM

DESCRIPTION

To reduce exhaust gas emissions, the positive crankcase ventilation (PCV) system and fuel evaporative system are employed. This system consists of the deceleration control system, fuel evaporative system, EGR function control system, and PCV system.

The purpose of these systems is to reduce CO, HC and NOx emissions.




EXHAUST GAS RECIRCULATION (EGR) CONTROL SYSTEM

DESCRIPTION

This system recirculates a small amount of exhaust gas into the intake manifold to reduce the combustion temperature, and reduce the NOx emissions.

This system consists of the EGR valve, EGR valve position sensor, two solenoid valves, PCM and input devices.



Operation

Cold engine (Coolant temperature below 55°C {131°F})








EGR operation is stopped to improve drivability when the engine temperature is cold.


Warm engine

The PCM controls the solenoid valves (vacuum side and vent side) to supply EGR gases as described below.

| Operating condition | EGR operation | Remark |
|---------------------|------------------------|---|
| Idle | Stopped | Idle switch: ON |
| Deceleration | | |
| High speed | | Above 5,500 rpm |
| Heavy load | | — |
| Acceleration | Reduced EGR gas amount | — |
| Warming up | | Coolant temperature: Between 55°C {131°F} and 60°C {140°F} |
| Other | | Control supply of EGR gas amount by using signal from EGR valve position sensor |


**PREPARATION
SST**

| | | | |
|---|---|--|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of EGR control system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR control system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR control system</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR control system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR control system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of EGR control system</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of EGR control system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

1. Connect the **SSTs**.
2. Start the engine and let it idle.
3. Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the **SIMULATION TEST** function. Operate the EGR solenoid valve (vacuum) and check if the engine speed becomes unstable or the engine stalls.
4. If the engine speed will not change, stop the engine and do as follows.
 - (1) Turn the ignition switch to **ON**.
 - (2) Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the **SIMULATION TEST** function. Operate the EGR solenoid valve (vacuum) and check if operation sound of the solenoid valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - EGR valve (Refer to page F2-88.)
 - EGR solenoid valve (vent) (Refer to page F2-87.)
 - II. If the operation sound is not heard, check the following.
 - EGR solenoid valve (vacuum) (Refer to below.)
 - Wiring between EGR solenoid valve (vacuum) and PCM terminal 4K.



EGR SOLENOID VALVE

Inspection

EGR solenoid valve (vacuum)


1. Remove the EGR solenoid valve (vacuum).
2. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vacuum). Verify that air flows as shown below.

Specification

B+: Battery positive voltage

| Terminal A-B | Air flow |
|----------------|----------|
| B+ applied | Yes |
| B+ not applied | No |

3. If not as specified, replace the EGR solenoid valve (vacuum).




EGR solenoid valve (vent)

1. Remove the EGR solenoid valve (vent).
2. Verify that air flows as shown below.

Specification

| Port | Air flow |
|------|----------|
| A-B | Yes |
| A-C | Yes |
| B-C | Yes |





3. If not as specified, replace the EGR solenoid valve (vent).
4. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vent). Verify that air flows as shown below.

Specification

| Port | Air flow |
|------|----------|
| A-B | Yes |
| A-C | No |
| B-C | No |

5. If not as specified, replace the EGR solenoid valve (vent).



EGR VALVE

Inspection

1. Start the engine and let it idle.
2. Connect a vacuum pump as shown in the figure and apply vacuum.
3. Verify that the engine runs roughly or stalls at more than the specified vacuum.

Specification:

3.4—9.9 kPa {25—75 mmHg, 1.0—2.9 inHg}

4. If not as specified, replace the EGR valve.

Replacement

1. Disconnect the EGR hose.
2. Disconnect the vacuum hose.
3. Disconnect the EGR valve position sensor connector.
4. Remove the EGR valve.
5. Remove the gasket.
6. Install in the reverse order of removal.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·cm, 1.7—2.2 in·lbf}

Note



- If nut A is difficult to remove (stuck), first remove the following and then remove the nut together with the EGR pipe from under the vehicle. (Refer to page F2-82.)

- ① Transverse member
- ② Front pipe
- ③ Insulator
- ④ EGR pipe
- ⑤ Warm up three way catalytic converter

EGR BOOST SENSOR SWITCHING CONTROL SYSTEM

SYSTEM INSPECTION

1. Warm up the engine to normal operating temperature and let it idle.
2. Disconnect the vacuum hose from the EGR boost sensor side of the EGR boost sensor solenoid valve.
3. Put a finger on the port of the EGR boost sensor solenoid valve and verify that no vacuum is felt.
4. If not as specified, check the EGR boost sensor and wiring harnesses and connectors.



EGR BOOST SENSOR SOLENOID VALVE

Inspection

1. Remove the EGR boost sensor solenoid valve.
2. Blow air into each port and verify that air flows as specified below.

| Ports | Air flow |
|-------|----------|
| A—B | No |
| A—C | No |
| B—C | Yes |

3. If not as specified, replace the EGR boost sensor solenoid valve.
4. Apply battery positive voltage between the terminals of the EGR boost sensor solenoid valve.
5. Blow air into each port and verify that air flows as specified below.




| Ports | Air flow |
|-------|----------|
| A—B | Yes |
| A—C | No |
| B—C | No |

6. If not as specified, replace the EGR boost sensor solenoid valve.

POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

DESCRIPTION

The PCV valve is operated by the intake manifold vacuum. When the engine is running at idle, the PCV valve is slightly open and a small amount of blowby gas is drawn into the dynamic chamber to be burned. As the engine speed rises, the PCV valve is opened further, allowing a larger amount of blowby gas to be drawn into the dynamic chamber.




PCV VALVE Inspection

1. Verify that the engine coolant temperature is below 20°C {68°F}.
2. Start the engine and let it idle.
3. Disconnect the PCV valve along with the ventilation hose from the cylinder head cover.
4. Block the PCV valve opening.
5. Verify that vacuum is felt.
6. Remove the PCV valve.
7. Blow through the valve from port A and verify that air comes out of port B.
8. Blow through the valve from port B and verify that no air comes out of port A.
9. Replace the PCV valve if not as specified.

EVAPORATIVE EMISSION SYSTEM

DESCRIPTION










The fuel evaporative system consists of the fuel vapor valve, check valve (two-way), charcoal canister, purge solenoid valve, PCM, and input devices. The amount of evaporative fumes introduced into the engine and burned is controlled by the solenoid valve to correspond to the engine's operating conditions. To provide the best engine performance, the solenoid valve is controlled by the PCM.



Operation

The purge solenoid valve is controlled by duty signals from the PCM to perform purging of the charcoal canister. Purging is done when these conditions are met:


- (1) After warm up
- (2) Driving in gear
- (3) Accelerator pedal depressed (closed throttle position switch OFF)
- (4) Heated oxygen sensor functioning normally

PREPARATION SST


| | | | |
|---|--|---|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of evaporative emission system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of evaporative emission system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of evaporative emission system</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of evaporative emission system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of evaporative emission system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of evaporative emission system</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of evaporative emission system</p> | <p>—</p> | <p>—</p> |

**SYSTEM INSPECTION**

1. Start and warm up the engine to the normal operating temperature.
2. Let the engine idle.
3. Disconnect the vacuum hose between the purge solenoid valve and the charcoal canister.
4. Put a finger to the purge solenoid valve and verify that there is no vacuum applied.
5. If there is vacuum, do as follows.
 - (1) Connect the **SSTs**.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F2-13.)
 - (3) If diagnostic trouble codes are not shown, check the following.
 - Purge solenoid valve (Refer to below.)
6. Reconnect the vacuum hose.
7. Install the **SSTs**.
8. Increase the duty value of the purge solenoid valve from 0% to 100% by using the SIMULATION TEST function. Operate the purge solenoid valve and check if the idle condition changes.
9. If the condition does not change, do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F2-13.)
 - (3) Increase duty value of the purge solenoid valve from 0% to 100% by using the SIMULATION TEST function. Operate the purge solenoid valve and check if the operation sound of the valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - II. If the operation sound is not heard, check the following.
 - Purge solenoid valve (Refer to below.)
1. Warm up the engine to normal operating temperature.
2. Run the engine at idle.
3. Disconnect the vacuum hose from the purge solenoid valve.
4. Check that no vacuum is felt.

**PURGE SOLENOID VALVE****Inspection**

1. Remove the purge solenoid valve.
2. Blow through the purge solenoid valve from hose A and verify that no air flows.




3. Apply battery positive voltage to the purge solenoid valve and verify that air flows through the valve from A to B.
4. If not as specified, replace the purge solenoid valve.


FUEL VAPOR VALVE

Inspection

1. Verify that air flows through the valve from port A when the valve is held as shown in the figure.



2. Verify that no air flows through the valve from port A when the valve is held as shown.
3. If not as specified, replace the fuel vapor valve.




CHECK VALVE (TWO-WAY)

Inspection

1. Remove the valve.
2. Check the operation of the valve by using a vacuum pump.


| | |
|--|---------|
| Apply approx. 4.9 kPa {37 mmHg, 1.5 inHg} vacuum at port A | Airflow |
| Apply approx. 5.9 kPa {44 mmHg, 1.7 inHg} vacuum at port B | Airflow |



CHARCOAL CANISTER

Inspection


1. Remove the charcoal canister.
2. Visually check the charcoal canister for damage and leakage.
3. Blow through each port and verify that air flows.







FUEL-CUT CONTROL SYSTEM


DESCRIPTION

This system is used to improve fuel economy, to prevent engine bucking during deceleration, and to protect the engine from overrevving.




PREPARATION
SST

| | | | |
|---|------------------------------|---|------------------------------|
| <p>49 9200 162A Engine Signal Monitor</p>  | <p>For inspection of PCM</p> | <p>49 T018 906 Adapter harness</p>  | <p>For inspection of PCM</p> |
| <p>49 T018 905 Sheet</p>  | <p>For inspection of PCM</p> | <p>49 D088 008 Harness adapter, power</p>  | <p>For inspection of PCM</p> |




SYSTEM INSPECTION


1. Connect a tachometer to the data link connector terminal IG-.




2. Connect the **SSTs** to the PCM.
3. Warm up the engine to normal operating temperature and let it idle.



4. Set the **SST** to positions 4Q, 4U, 4Y, 4AC, 4AG and 4AK and make sure the green and red lights flash alternately at each position.



5. Increase the engine speed to **4,000 rpm**; then suddenly release the throttle.
6. Verify that the red indicator lamp illuminates while the engine speed is above approximately **1,200 rpm (MTX)/ 1,500 rpm (ATX)** on deceleration.
7. Increase the engine speed and verify that the maximum rpm does not exceed the specification.



Caution


- Holding the maximum rpm for more than 3 seconds can damage the engine.

Specification: Approx. 7,500 rpm

A/C CUT OFF SYSTEM

DESCRIPTION








An A/C cut off system is used to improve idle smoothness immediately after starting the engine and to improve acceleration performance.




Operation

| Engine condition | Purpose | Cut off period |
|--------------------------------------|----------------------------------|---------------------------------------|
| After engine started | Improved idle | Approx. 3 sec. |
| Throttle valve wide open throttle | Improved driveability | Approx. 5 sec. |
| Water temperature over 113°C {236°F} | Prevent engine from over heating | Water temperature under 107°C {225°F} |

PREPARATION SST

| | | | |
|---|---|---|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of A/C cut off system</p> | <p>—</p> | <p>—</p> |





SYSTEM INSPECTION

1. Position the vehicle on a chassis roller and start the engine.
2. (MTX) Shift the transaxle into other than Neutral and release the clutch pedal.
(ATX) Shift the selector lever into other than P and N.
3. Turn the A/C switch and the fan switch on.
4. Fully open the throttle valve. Then, 3—6 seconds after, check if the operation sound of the A/C compressor electromagnetic clutch is heard.
5. If the operation sound is not heard, do as follows.
 - (1) Connect the **SSTs**.
 - (2) Turn the A/C relay from OFF to ON by using the SIMULATION TEST function and check for the operation sound of the relay.
 - I. If the operation sound is heard, check the following.
 - PCM terminal voltage (Refer to page F2-106.)
 - Load/no load distinction signal
 - Closed throttle position signal
 - II. If the operation sound is not heard, check the following.
 - A/C relay (Refer to 1996 Mazda 626/MX-6 BETM.)
 - Open circuit in wiring harnesses and connector (Main relay — A/C relay — PCM)

DECHOKE CONTROL SYSTEM

DESCRIPTION

To facilitate starting the engine when the spark plugs become fouled, such as when the engine is flooded, fuel injection is cut if the throttle valve is held wide open during cranking. This allows the spark plugs to dry and purges excess fuel from the cylinders.




SYSTEM INSPECTION

1. Turn the ignition switch to START and verify that fuel injector operating sound is heard while the engine is cranking.
2. Depress the accelerator pedal fully and turn the ignition switch to START. Verify that no fuel injector operating sound is heard while cranking.
3. If operating sound is heard, check the PCM terminal 1H voltage. (Refer to page F2-106.)









ELECTRICAL FAN CONTROL SYSTEM



DESCRIPTION

To improve idle smoothness and engine reliability, the PCM and the electrical fan control system control the electric fan operation. This system consists of the cooling fan, condenser fan, fan relays, PCM, and input devices.



**PREPARATION
SST**

| | | | |
|---|--|--|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of electrical fan control system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical fan control system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical fan control system</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical fan control system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical fan control system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of electrical fan control system</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of electrical fan control system</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of electrical fan control system</p> |















SYSTEM INSPECTION


1. Verify that the engine is cold.
2. Turn the ignition switch to ON.
3. Verify that the cooling fan is not operating.
4. If the cooling fan is operating, do as follows.
 - (1) Connect the **SSTs**.
 - (2) By using the PID DATA MONITOR AND RECORD function, verify that the cooling fan control signal is OFF.
 - I. If the cooling fan control signal is ON, check the following.
 - PCM terminal voltage (Refer to page F2-105.)
 - Engine coolant temperature signal
 - II. If the cooling fan control signal is OFF, check the following.
 - Fan relay
(Refer to 1996 Mazda 626/MX-6 BETM.)
 - Short circuit in wiring harnesses and connectors (Main relay — Fan relay — PCM)
5. Connect the **SST** and set system select switch to 1 and self test switch to SELF TEST.
6. Depress the accelerator pedal and verify that the cooling fan operates.
7. If the cooling fan does not operate, do as follows.
 - (1) Install the **SSTs**.
 - (2) Turn the fan relay from OFF to ON by using the SIMULATION TEST function and check for the cooling fan operation.
 - I. If the cooling fan operates, check the following.
 - PCM terminal voltage (Refer to page F2-105.)
 - Diagnostic test mode signal
 - Closed throttle position signal
 - II. If the cooling fan does not operate, do as follows.
 - a. Turn the fan relay from OFF to ON by using the simulation function. Operate the fan relay and check if the operation sound of the relay is heard.
 - b. If the operation sound is heard, check the following.
 - Wiring harnesses and connectors (Fan relay — Fan motor)
 - Fan motor (Refer to section E.)
 - c. If the operation sound is not heard, check the following.
 - Fan relay
(Refer to 1996 Mazda 626/MX-6 BETM.)
 - Open circuit in wiring harnesses and connectors (Main relay — Fan relay — PCM)

CONTROL SYSTEM

PREPARATION
SST

| | | | |
|---|--|--|--|
| <p>49 9200 162A</p> <p>Monitor, Engine Signal</p>  | <p>For inspection of PCM terminal voltage</p> | <p>49 T018 906</p> <p>Adapter harness</p>  | <p>For inspection of PCM terminal voltage</p> |
| <p>49 T018 905</p> <p>Sheet</p>  | <p>For inspection of PCM terminal voltage</p> | <p>49 D088 008</p> <p>Harness adapter, Power</p>  | <p>For inspection of PCM terminal voltage</p> |
| <p>49 T088 0A0</p> <p>NGS set</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 001</p> <p>Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 002</p> <p>Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 004</p> <p>NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 006</p> <p>Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 008A</p> <p>Instruction Manual</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 010B</p> <p>Program Card</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 H018 001</p> <p>Knock sensor wrench</p>  | <p>For replacement of knock sensor</p> |


STRUCTURAL VIEW



- | | |
|--|--|
| 1. Powertrain control module (PCM) Removal / Installation page F2-105 Inspection page F2-106 | 8. Knock sensor Inspection page F2-122 Replacement page F2-122 |
| 2. Volume air flow sensor Inspection page F2-115 | 9. P/S pressure switch Inspection page F2-123 |
| 3. Crankshaft position sensor Inspection page F2-116 Replacement page F2-116 | 10. Clutch switch Inspection page F2-123 Replacement page F2-123 |
| 4. Camshaft position sensor Inspection page F2-117 | 11. Neutral switch Inspection page F2-123 |
| 5. Throttle position sensor Inspection page F2-117 Adjustment page F2-118 Replacement page F2-120 | 12. EGR valve position sensor Inspection page F2-124 |
| 6. Engine coolant temperature sensor Inspection page F2-120 | 13. EGR boost sensor Inspection page F2-124 |
| 7. Heated oxygen sensor (front, rear) Inspection page F2-121 | 14. Main relay Inspection page F2-125 |




POWERTRAIN CONTROL MODULE (PCM)**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Negative battery cable
2. Cover
3. Center console (Refer to section S)

4. PCM connector
5. PCM



Inspection

Caution

- The PCM terminal voltages vary with change in measuring conditions and vehicle conditions. Always carry out a total inspection of the input systems, output systems, and PCM to determine the cause of trouble. Otherwise, a wrong diagnosis will be made.



1. Disconnect the negative battery cable.
2. Remove the center console. (Refer to page F2-105.)
3. Disconnect the PCM connector.
4. Connect the **SST** (Adapter harness) to the PCM connector.
5. Connect the **SSTs** (Monitor, Engine Signal and Harness adapter, power) to the **SST** (Adapter harness). Use connector A of the adapter harness for PCM terminals 1A through 1AJ and 2A through 2T, and 3A through 3R. Use connector B for PCM terminals 3S through 3AB and 4A through 4AN.
6. Place the **SST** (Sheet) on the **SST** (Monitor, Engine Signal).
7. Measure the voltage at each PCM terminal by switching the selector switch and the monitor switch.
8. If any incorrect voltage is detected, check related systems, wiring harnesses and connectors referring to the possible malfunction in the terminal voltage list.

Caution

- Disconnecting the connectors of the PCM and the **SST** (Adapter harness) while the battery is connected can damage the PCM and the **SST** (Monitor, Engine Signal). Disconnect the negative battery cable and the **SST** (Harness adapter, power) before disconnecting the connectors.
- Applying voltage to terminals A and B of the **SST** (Monitor, Engine Signal) can damage the **SST** (Monitor, Engine Signal).

Note

- The indicator lights of the **SST** (Monitor, Engine Signal), provided for confirmation of the voltmeter range, is also used for detection of the pulse such as the fuel injector control signal, which is difficult to detect by using the voltmeter.
- Terminals A and B of the **SST** (Monitor, Engine Signal) are for connection of an external instrument. By connecting an external instrument such as a circuit tester or an oscilloscope, various inspections in addition to the measurement of the PCM terminal voltages are made possible.



Using SST (NGS)


1. Connect the SSTs to the data link connector-2 as shown in the figure.
2. Referring to the NGS operational manual, select the PID DATA MONITOR AND RECORD or PID DATA MONITOR function.
3. Referring to the 1996 Service Highlights, inspect each PCM input/output signal.

Note

- The PID DATA MONITOR AND RECORD function is to monitor the calculation value of input/output signals in the PCM. Deviation in the value does not always indicate malfunction in the related input/output devices (sensors and solenoids).
- When normal output signal cannot be detected while all input signals are normal, replace the PCM.

Terminal voltage (Reference)

B+: Battery positive voltage



| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|---------------------------------------|--|---------------------------|--|-------------|--|
| 1A | Cooling fan high speed control | Cooling fan relay No.2, No.3 | Ignition switch ON | Cooling fan high speed operating | Below 1.0 | • Cooling fan relay No.2, No.3 |
| | | | | Cooling fan stop | B+ | |
| 1B | Pressure regulator control | PRC solenoid valve | Idle (Hot start) | | Below 1.0 | • PRC solenoid valve |
| | | | Other | | B+ | |
| 1C | Vehicle speed | Vehicle speed sensor | Ignition switch ON | | 0 or 5.0 | • Vehicle speed sensor |
| | | | Driving | | Approx. 2.5 | |
| 1D | — | — | — | | — | — |
| 1E | Condenser fan high speed control | Condenser fan relay No.2, No.3 | Ignition switch ON | Condenser fan high speed operating | Below 1.0 | • Condenser fan relay No.2, No.3 |
| | | | | Condenser fan stop | B+ | |
| 1F | Load/No load distinction | Neutral/clutch switch (MTX) | Ignition switch ON | Other than neutral and clutch pedal released | B+ | • Neutral/clutch switch |
| | | | | Neutral or clutch pedal depressed | Below 1.0 | |
| | | Transaxle range switch (ATX) | Ignition switch ON | Other than park/neutral position | B+ | • Transaxle range switch |
| | | | | Park/neutral position | Below 1.0 | |
| 1G | DRL (CANADA) | DRL control module | Daytime running light OFF | | Above 11.0 | • DRL control module |
| | | | Daytime running light ON | | Below 1.0 | |
| 1H | Start | Ignition switch (START) | While cranking | | Approx. 10 | • PCM terminal 1H — Ignition switch harness |
| | | | Ignition switch ON | | Below 1.0 | |
| 1I | Cooling fan and condenser fan control | Cooling fan relay No.1, Condenser fan relay No.1 | Ignition switch ON | Cooling fan operating | Below 1.0 | • Cooling fan relay No.1 • Condenser fan relay No.1 |
| | | | | Cooling fan stop | B+ | |
| 1J | — | — | — | | — | — |
| 1K | Blower | Fan switch | Ignition switch ON | Fan switch OFF | B+ | • Fan switch |
| | | | | Fan switch 3rd or higher | Below 1.0 | |
| 1L | Headlight | Headlight switch | Headlight switch OFF | | Below 1.0 | • Headlight switch |
| | | | Headlight switch ON | | B+ | |
| 1M | A/C control | A/C relay | Idle | A/C operating | Below 1.0 | • A/C relay |
| | | | | A/C stop | B+ | |
| 1N | — | — | — | | — | — |
| 1O | Brake | Brake switch | Brake pedal released | | Below 1.0 | • Brake switch |
| | | | Brake pedal depressed | | B+ | |
| 1P | — | — | — | | — | — |
| 1Q | — | — | — | | — | — |
| 1R | — | — | — | | — | — |

B+: Battery positive voltage

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|-----------------------------------|--------------------------------------|---|-----------------------------------|------------------|--|
| 1S | — | — | — | | — | — |
| 1T | — | — | — | | — | — |
| 1U | A/C pressure signal | Refrigerant pressure sw | Idle | A/C switch ON and fan switch max. | Below 1.0 | • Refrigerant pressure switch |
| | | | | A/C stop | B+ | |
| 1V | — | — | — | | — | — |
| 1W | — | — | — | | — | — |
| 1X | Rear window defroster | Rear window defroster relay | Ignition switch ON | Rear window defroster switch OFF | B+ | • Rear window defroster switch |
| | | | | Rear window defroster switch ON | Below 1.0 | |
| 1Y | Diagnostic trouble code input | Data link connector-2 (Terminal KLN) | Carry out inspection according to diagnostic trouble codes Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible | | — | • On-board diagnosis system |
| 1Z | — | — | — | | — | — |
| 1AA | VRIS No.1 control | VRIS solenoid valve No.1 | Ignition switch ON | | B+ | • VRIS solenoid valve No.1 |
| 1AB | — | — | — | | — | — |
| 1AC | — | — | — | | — | — |
| 1AD | — | — | — | | — | — |
| 1AE | VRIS No.2 control | VRIS solenoid valve No.2 | Ignition switch ON | | B+ | • VRIS solenoid valve No.2 |
| 1AF | Fuel pump control | Fuel pump relay | Ignition switch ON | | B+ | • Fuel pump relay |
| | | | Cranking | | Below 1.0 | |
| | | | Idle | | | |
| 1AG | — | — | — | | — | — |
| 1AH | MIL | Malfunction indicator lamp | Malfunction indicator lamp OFF | | B+ | • PCM terminal 1AH — MIL harness |
| | | | Malfunction indicator lamp ON | | Below 1.0—B+ | |
| 1AI | — | — | — | | — | — |
| 1AJ | — | — | — | | — | — |
| 2A | Shift solenoid A (ATX) | Shift solenoid A | Solenoid valve ON | | B+ | • Shift solenoid A • Wiring and/or connector from terminal 2A to shift solenoid A |
| | | | Solenoid valve OFF | | Below 1.0 | |
| 2B | Shift solenoid B (ATX) | Shift solenoid B | Solenoid valve ON | | B+ | • Shift solenoid B • Wiring and/or connector from terminal 2B to shift solenoid B |
| | | | Solenoid valve OFF | | Below 1.0 | |
| 2C | TCC* control solenoid valve (ATX) | TCC control solenoid valve | TCC operation | | B+ | • TCC control solenoid valve • Wiring and/or connector from terminal 2C to TCC control solenoid valve |
| | | | TCC non operation | | Below 1.0 | |
| 2D | TCC* solenoid valve (ATX) | TCC solenoid valve | TCC slip operation→TCC operation | | B+→ Below 1.0 | • TCC solenoid valve • Wiring and/or connector from terminal 2D to TCC solenoid valve |
| | | | TCC non operation | | Below 1.0 | |

*: TCC = Torque converter clutch

B+: Battery positive voltage

| Terminal | Signal | Connected to | Test condition | Voltage (V) | Possible malfunction |
|----------|---|---------------------------|---|-------------|--|
| 2E | O/D OFF indicator light (ATX) | O/D OFF indicator light | O/D OFF mode | Below 1.0 | <ul style="list-style-type: none"> O/D OFF indicator light Wiring and/or connector from terminal 2E to O/D OFF indicator light |
| | | | Except O/D OFF mode | B+ | |
| 2F | Shift solenoid C (ATX) | Shift solenoid C | Solenoid valve ON | B+ | <ul style="list-style-type: none"> Shift solenoid C Wiring and/or connector from terminal 2F to shift solenoid C |
| | | | Solenoid valve OFF | Below 1.0 | |
| 2G | 3-2 timing solenoid valve (ATX) | 3-2 timing solenoid valve | Solenoid valve ON | B+ | <ul style="list-style-type: none"> 3-2 timing solenoid valve Wiring and/or connector from terminal 2G to 3-2 timing solenoid valve |
| | | | Solenoid valve OFF | Below 1.0 | |
| 2H | Pressure control solenoid (ATX) | Pressure control solenoid | Throttle valve closed throttle position | 8.0 | <ul style="list-style-type: none"> Pressure control solenoid Wiring and/or connector from terminal 2H to pressure control solenoid |
| | | | Throttle valve wide open throttle | 1.6 | |
| 2I | Transaxle range switch (D range) (ATX) | Transaxle range switch | D range | B+ | <ul style="list-style-type: none"> Transaxle range switch Wiring and/or connector from terminal 2I to transaxle range switch |
| | | | Other ranges All positions | Below 1.0 | |
| 2J | — | — | — | — | — |
| 2K | Transaxle range switch (R position) (ATX) | Transaxle range switch | R position | B+ | <ul style="list-style-type: none"> Transaxle range switch Wiring and/or connector from terminal 2K to transaxle range switch |
| | | | All ranges Other positions | Below 1.0 | |
| 2L | O/D OFF switch (ATX) | O/D OFF switch | O/D OFF switch released | B+ | <ul style="list-style-type: none"> O/D OFF switch Wiring and/or connector from terminal 2L to O/D OFF switch |
| | | | O/D OFF switch depressed | Below 1.0 | |
| 2M | Transaxle range switch (S range) (ATX) | Transaxle range switch | S range | B+ | <ul style="list-style-type: none"> Transaxle range switch Wiring and/or connector from terminal 2M to transaxle range switch |
| | | | Other ranges All positions | Below 1.0 | |
| 2N | — | — | — | — | — |

B+: Battery positive voltage

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|-------------------------------|---|---|--|-----------------------------|-----------------|--|
| 2O | Transaxle fluid temperature sensor (ATX) | Transaxle fluid temperature sensor | Verify that voltage decreases according to ATF temperature rise For reference, if the ATF is 20°C {68°F} the voltage should be 3.5 V If the ATF is 130°C {260°F} the voltage should be 0.6 V | | Approx. 0.6—4.8 | <ul style="list-style-type: none"> Transaxle fluid temperature sensor Wiring and/or connector from terminal 2O to transaxle fluid temperature sensor |
| 2P | Input/turbine speed sensor (ATX) | Input/turbine speed sensor | Ignition switch ON | | Below 1.0 | <ul style="list-style-type: none"> Input/turbine speed sensor Wiring and/or connector from terminal 2P to input/turbine speed sensor |
| | | | Engine running (P position) | | 0.1—1.0 | |
| 2Q | — | — | — | | — | — |
| 2R | Transaxle range switch (L range) (ATX) | Transaxle range switch | L range | | B+ | <ul style="list-style-type: none"> Transaxle range switch Wiring and/or connector from terminal 2R to transaxle range switch |
| | | | Other ranges All positions | | Below 1.0 | |
| 2S | — | — | — | | — | — |
| 2T | Ground (Input/turbine speed sensor) (ATX) | Input/turbine speed sensor | Constant | | Below 1.0 | — |
| 3A | Constant voltage (Vref) | Throttle position sensor EGR valve position sensor | Ignition switch ON | | Approx. 5.0 | <ul style="list-style-type: none"> PCM terminal 4A voltage |
| 3B | Throttle position sensor | Throttle position sensor | Ignition switch ON | Accelerator pedal released | 0.1—1.1 | <ul style="list-style-type: none"> Throttle position sensor PCM terminal 3A voltage |
| | | | | Accelerator pedal depressed | 2.8—4.5 | |
| 3C | — | — | — | | — | — |
| 3D | Heated oxygen sensor (rear RH) | Heated oxygen sensor (rear RH) | Ignition switch ON | | Below 1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (rear RH) |
| | | | Idle | Engine cold | Approx. 0 | |
| | | | | After warm up | 0.1—0.9 | |
| 3E | Volume air flow sensor | Volume air flow sensor | Ignition switch ON | | Approx. 4 | <ul style="list-style-type: none"> Volume air flow sensor |
| | | | Idle | | Approx. 3 | |
| 3F | EGR boost | EGR boost sensor | Ignition switch ON | | Approx. 4.5 | <ul style="list-style-type: none"> EGR boost sensor |
| | | | Idle | | | |
| 3G | — | — | — | | — | — |
| 3H | Heated oxygen sensor (rear LH) | Heated oxygen sensor (rear LH) | Ignition switch ON | | Below 1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (rear RH) |
| | | | Idle | Engine cold | Approx. 0 | |
| | | | | After warm up | 0.1—0.9 | |
| 3I | Heated oxygen sensor (RH) | Heated oxygen sensor (front RH) | Ignition switch ON | | Below 1.0 | <ul style="list-style-type: none"> Heated oxygen sensor |
| | | | Idle | Engine cold | Below 0.5 | |
| | | | | After warms up | 0.1—0.9 | |
| | | | Acceleration (After warms up) | | 0.5—1.0 | |
| Deceleration (After warms up) | | 0—0.5 | | | | |
| 3J | — | — | — | | — | — |
| 3K | — | — | — | | — | — |
| 3L | — | — | — | | — | — |

B+: Battery positive voltage


| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|--|---|-------------------------------|------------------------------------|------------------|---|
| 3M | Heated oxygen sensor (LH) | Heated oxygen sensor (front LH) | Ignition switch ON | | Below 1.0 | • Heated oxygen sensor |
| | | | Idle | Engine cold | Below 0.5 | |
| | | | | After warms up | 0.1—0.9 | |
| | | | Acceleration (After warms up) | | 0.5—1.0 | |
| | | | Deceleration (After warms up) | | 0—0.5 | |
| 3N | — | — | — | | — | — |
| 3O | — | — | — | | — | — |
| 3P | — | — | — | | — | — |
| 3Q | Engine coolant temperature | Engine coolant temperature sensor | Ignition switch ON | Engine coolant temp 20°C {68°F} | Approx. 3 | • Engine coolant temperature sensor |
| | | | | After warms up | Approx. 0.8 | |
| 3R | EGR valve position | EGR valve position sensor | Ignition switch ON | | Approx. 0.8 | • EGR valve position sensor |
| | | | Driving | | Approx. 2.2—2.7 | |
| 3S | Knock | Knock sensor | Ignition switch ON | | Approx. 0.7 | • Knock sensor |
| 3T | Power steering pressure | Power steering pressure switch | Ignition switch ON | | B+ | • Power steering pressure switch |
| | | | Idle | P/S not operating | | |
| | | | | P/S operating | Below 1.0 | |
| 3U | — | — | — | | — | — |
| 3V | Intake-air temperature | Intake air temperature sensor | Ignition switch ON | Intake-air temperature 20°C {68°F} | Approx. 2 | • Intake air temperature sensor |
| 3W | — | — | — | | — | — |
| 3X | Closed throttle position | Closed throttle position switch (In throttle position sensor) | Ignition switch ON | Accelerator pedal released | Below 1.0 | • Throttle position sensor |
| | | | | Accelerator pedal depressed | B+ | |
| 3Y | — | — | — | | — | — |
| 3Z | — | — | — | | — | — |
| 3AA | — | — | — | | — | — |
| 3AB | Analogue sensor ground | Ground | Constant | | Below 1.0 | • PCM terminal 3AB harness (Open) |
| 4A | Power supply | Main relay (FUEL INJ relay) | Ignition switch OFF | | Below 1.0 | • Main relay |
| | | | Ignition switch ON | | B+ | |
| 4B | Back-up power supply | Battery | Constant | | B+ | • PCM terminal 4B — Battery harness and connector |
| 4C | Power supply (ATX) | Main relay (FUEL INJ relay) | Ignition switch OFF | | Below 1.0 | • Main relay |
| | | | Ignition switch ON | | B+ | |
| 4D | Output device ground | Ground | Constant | | Below 1.0 | • PCM terminal 4D harness (Open) |
| 4E | Heated oxygen sensor (front RH) heater control | Heated oxygen sensor (front RH) | Idle | | Below 1.0 | • Heated oxygen sensor |
| 4F | SGC | Camshaft position sensor (In distributor) | Ignition switch ON | | 0 or Approx. 5.0 | • Camshaft position sensor |
| | | | Idle | | Approx. 2.5 | |

B+: Battery positive voltage

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|--|---------------------------------------|-------------------------|---------------------|-------------|--|
| 4G | EGR vent control | EGR solenoid valve (vent) | Ignition switch ON | | B+ | • EGR solenoid valve (vent) |
| | | | Idle | | | |
| 4H | — | — | — | | — | — |
| 4I | Heated oxygen sensor (front LH) heater control | Heated oxygen sensor (front LH) | Idle | | Below 1.0 | • Heated oxygen sensor |
| 4J | — | — | — | | — | — |
| 4K | EGR vacuum control | EGR solenoid valve (vacuum) | Ignition switch ON | | B+ | • EGR solenoid valve (vacuum) |
| | | | Idle | | | |
| 4L | — | — | — | | — | — |
| 4M | Idle air control | Idle air control valve | Ignition switch ON | | Approx. 6 | • Idle air control valve |
| | | | Idle (After warms up) | | Approx. 10 | |
| 4N | — | — | — | | — | — |
| 4O | Purge control | Purge solenoid valve | Ignition switch ON | | B+ | • Purge solenoid valve |
| | | | Idle | | | |
| 4P | EGR boost sensor switching control | EGR boost sensor solenoid valve | Ignition switch ON | | Below 1.0 | • EGR boost sensor solenoid valve |
| | | | Idle | | | |
| 4Q | Fuel injector control No.1 | Fuel injector (No.1 cylinder) | Ignition switch ON/Idle | | B+ | • Fuel injector |
| 4R | — | — | — | | — | — |
| 4S | IGT control | Ignition control module (Distributor) | Ignition switch ON | | Approx. 0 | • Ignition control module |
| | | | Idle | | Approx. 0.6 | |
| 4T | — | — | — | | — | — |
| 4U | Fuel injector control No.2 | Fuel injector (No.2 cylinder) | Ignition switch ON/Idle | | B+ | • Fuel injector |
| 4V | Diagnostic test mode | Data link connector (Terminal TEN) | Ignition switch ON | Open terminal TEN | B+ | • PCM terminal 11 — Data link connector terminal TEN harness |
| | | | | Terminal TEN ground | Below 1.0 | |
| 4W | — | — | — | | — | — |
| 4X | — | — | — | | — | — |
| 4Y | Fuel injector control No.3 | Fuel injector (No.3 cylinder) | Ignition switch ON/Idle | | B+ | • Fuel injector |
| 4Z | — | — | — | | — | — |
| 4AA | — | — | — | | — | — |
| 4AB | Fuel injector ground | Ground | Constant | | Below 1.0 | • PCM terminal 4AB harness (Open) |
| 4AC | Fuel injector control No.4 | Fuel injector (No.4 cylinder) | Ignition switch ON/Idle | | B+ | • Fuel injector |
| 4AD | — | — | — | | — | — |
| 4AE | — | — | — | | — | — |
| 4AF | PCM ground | Ground | Constant | | Below 1.0 | • PCM terminal 4AF harness (Open) |
| 4AG | Fuel injector control No.5 | Fuel injector (No.5 cylinder) | Ignition switch ON/Idle | | B+ | • Fuel injector |
| 4AH | NE⊕ | Crankshaft position sensor | Ignition switch ON | | 0 | • Crankshaft position sensor |
| | | | Idle | | Approx. 0 | |
| 4AI | — | — | — | | — | — |

B+: Battery positive voltage

| Terminal | Signal | Connected to | Test condition | Voltage (V) | Possible malfunction |
|----------|----------------------------|-------------------------------|-------------------------|-------------|---|
| 4AJ | PCM ground | Ground | Constant | Below 1.0 | <ul style="list-style-type: none"> • PCM terminal 4AJ harness (Open) |
| 4AK | Fuel injector control No.6 | Fuel injector (No.6 cylinder) | Ignition switch ON/Idle | B+ | <ul style="list-style-type: none"> • Fuel injector |
| 4AL | NE \ominus | Crankshaft position sensor | Constant | 0 | <ul style="list-style-type: none"> • Crankshaft position sensor |
| 4AM | — | — | — | — | — |
| 4AN | PCM ground | Ground | Constant | Below 1.0 | <ul style="list-style-type: none"> • PCM terminal 4AN harness (Open) |



VOLUME AIR FLOW SENSOR

Inspection



1. Check the volume air flow sensor body for cracks and damage. Replace as necessary.
2. Verify that the measuring core opens smoothly.
3. Measure resistance of the volume air flow sensor.

| Terminal | Resistance (Ω) | |
|---|--|---|
| $E_2 \leftrightarrow V_s$ | 20—600 (Closed: 20°C {68°F}) 20—1,000 (Open: 20°C {68°F}) | |
| $E_2 \leftrightarrow V_c$ | 200—400 (Closed↔Open: 20°C {68°F}) | |
| $E_2 \leftrightarrow THA$ (intake air temperature sensor) | -20°C {-4°F} 20°C {68°F} 60°C {140°F} | 10,000—20,000 2,000— 3,000 400— 700 |

4. If not as specified, replace the volume air flow sensor.

Using SST (NGS)

1. Check the volume air flow sensor for damage and cracks.
2. Warm up the engine to normal operating temperature.
3. Shift the selector lever to park/neutral position.
4. Trun off all electrical loads.
 - Headlight
 - Blower motor
 - Rear window defroster
 - Power steering
 - A/C
5. Wait until the cooling fan stops.
6. Connect the **SSTs** to the data link connector-2.
7. Select the PID/DATA MONITOR AND RECORD function of the NGS.
8. Select "VAF V" on the NGS display. NGS measures and shows the voltage.



Specifications

| | Ignition switch ON | Idle |
|-------------|--------------------|-----------|
| Voltage (V) | Approx. 4 | Approx. 3 |

9. If not as specified, perform following inspection.
 - Harness continuity
 - Between PCM terminal 3E and volume air flow sensor terminal A
 - Between PCM terminal 3A and volume air flow sensor terminal B
 - Between PCM terminal 3AB and volume air flow sensor terminal C
 - Terminal voltage
 - Volume air flow sensor terminal B voltage: approx. 5 V
10. If there is incorrect terminal voltage or harness continuity, replace the volume air flow sensor. (Refer to page F2-54.)


Note

- The scan tool shows the volume air flow rate and load value.

Specification

| Engine speed (rpm) | Intake mass air flow (g/s) | | Engine load calculated value (%) | |
|--------------------|----------------------------|----------|----------------------------------|-----------|
| | MTX | ATX | MTX | ATX |
| 600—700 (Idle) | 2.9—3.7 | 2.9—4.0 | 19.0—22.0 | 19.0—23.0 |
| Approx. 2,500* | 9.9—12.1 | 9.9—12.7 | 16.0—19.0 | 16.0—20.0 |

* No load, in neutral or park



CRANKSHAFT POSITION SENSOR

Inspection

Resistance



1. Disconnect the crankshaft position sensor connector.
2. Measure the resistance between terminals A and B by using an ohmmeter.

Specification: 520—580 Ω [20°C {68°F}]

3. If not as specified, replace the crankshaft position sensor.


NE signal illustration

- After warm-up idle with no load condition.



Replacement


1. Disconnect the negative battery cable.
2. Remove the idler pulley bracket.
3. Remove the dipstick pipe.
4. Remove the crankshaft position sensor.
5. Install in the reverse order of removal.
6. Adjust the drive belt deflections. (Refer to section B2.)

**CAMSHAFT POSITION SENSOR****Inspection**

1. Remove the distributor. (Refer to section G.)
2. Connect the distributor 6-pin connector.
3. Connect the **SSTs** to the PCM. (Refer to page F2-106.)
4. Turn the ignition switch to ON.
5. Rotate the distributor drive by hand and check the output signal.

Specification

| Signal | Terminal | Voltage |
|--------|----------|---------------------------|
| SGC | 4F | Approx. 5 V (1 pulse/rev) |



6. If not as specified, inspect following.



Harness continuity

- Between PCM terminal 4F and distributor (6-pin) terminal D
- Between PCM terminal 3AB and distributor (6-pin) terminal A
- Between main relay terminal D and distributor (6-pin) B terminal


Terminal voltage




- Distributor (6-pin) terminal B: B+

7. If there is correct terminal voltage and harness continuity, replace the distributor. (Refer to section G.)

**THROTTLE POSITION SENSOR****Inspection****Closed throttle position switch**

1. Verify that the throttle valve is at the closed throttle position.
2. Disconnect the throttle position sensor connector.
3. Check for continuity between throttle position sensor connector terminals C and D by using an ohmmeter.
4. If no continuity, adjust the throttle position sensor.
5. Insert a 0.50 mm {0.020 in} feeler gauge between the throttle adjusting screw (TAS) and the throttle lever. Verify that there is no continuity.
6. If there is continuity, adjust the throttle position sensor. (Refer to page F2-119.)





Throttle position sensor

Using SSTs (engine signal monitor)

1. Remove the PCM. (Refer to page F2-105.)
2. Connect the SSTs to the PCM.
3. Verify that the throttle valve is at the closed throttle position.
4. Turn the ignition switch to ON.
5. Measure the PCM terminal 3B voltage by using a voltmeter.

Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

6. If not as specified, adjust the throttle position sensor.

Using SST (NGS)

1. Connect the SSTs to the data link connector-2.
2. Verify that the throttle valve is at the closed throttle position.
3. Turn the ignition switch to ON.
4. Select the PID/DATA MONITOR AND RECORD function of the NGS.
5. Select "TP V" on the NGS display. NGS measures and shows the voltage.

Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

6. If not as specified, adjust the throttle position sensor. (Refer to page F2-119.)

Adjustment

Caution


- The throttle position sensor is adjusted at the factory before shipment. Unnecessary adjustment will negatively effect the engine performance.
- Adjusting the throttle position sensor by using the throttle adjusting screw (TAS) will negatively effect the engine performance.

Closed throttle position switch

1. Verify that the throttle valve is at the closed throttle position.
2. Disconnect the throttle position sensor connector.
3. Loosen the attaching screws.
4. Insert a feeler gauge between the throttle adjusting screw (TAS) and the throttle lever. Adjust the continuity between the closed throttle position switch terminals C and D by using an ohmmeter.

Specification

| Clearance | Continuity |
|--------------------|------------|
| 0.15 mm {0.006 in} | Yes |
| 0.50 mm {0.020 in} | No |







5. Tighten the attaching screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·m, 14—20 in·lbf}

6. If not adjusted, replace the throttle position sensor.
(Refer to below.)

**Throttle position sensor****Using SSTs (engine signal monitor)**

1. Remove the PCM. (Refer to page F2-105.)
2. Connect the **SSTs** to the PCM.
3. Verify that the throttle valve is at the closed throttle position.
4. Loosen the attaching screws.
5. Turn the ignition switch to ON.
6. Adjust the throttle position sensor so that the PCM terminal 3B voltage is as specified, by using a voltmeter.

Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V

(Verify that the voltage increase is directly proportional to the throttle valve opening angle.)

7. Tighten the attaching screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—20 in·lbf}

8. If not adjusted, inspect the throttle position sensor harness.
9. If harness is OK, replace the throttle position sensor.

Using SST (NGS)

1. Connect the **SSTs** to the data link connector-2.
2. Verify that the throttle valve is at the closed throttle position.
3. Loosen the attaching screws.
4. Turn the ignition switch to ON.
5. Select the PID/DATA MONITOR AND RECORD function of the NGS.
6. Select "TP V" on the NGS display. NGS measures and shows the voltage.

Specification

Closed throttle position: 0.1—1.1 V

Wide open throttle: 2.8—4.5 V


(Verify that the voltage increase is directly proportional to the throttle valve opening angle.)

7. Tighten the attaching screws.

Tightening torque:


1.6—2.3 N·m {16—24 kgf·cm, 14—20 in·lbf}

8. If not adjusted, replace the throttle position sensor.



Replacement

1. Disconnect the throttle position sensor connector.
2. Remove the attaching screws.
3. Remove the throttle position sensor.
4. Verify that the throttle valve is at the closed throttle position.
5. Open the throttle valve slightly and catch the tang of the throttle body on the throttle position sensor plastic tabs. Adjust tang A on throttle body with tab A on throttle position sensor. Note tangs on the throttle body mate with the tab on the throttle position sensor on the side of the tab without a slot.
6. Position the throttle position sensor on the throttle body so that the mounting holes align.
7. Install and hand tighten the attaching screws.
8. Release the throttle.
9. Adjust the throttle position sensor output voltage and closed throttle position switch. (Refer to page F2-118.)



ENGINE COOLANT TEMPERATURE SENSOR

Inspection

1. Remove the engine coolant temperature sensor.
2. Place the sensor in water with a thermometer, and heat the water gradually.
3. Measure the resistance of the sensor by using an ohmmeter.


Spcification






| Temperature (C°{F°}) | Resistance (kΩ) |
|----------------------|-----------------|
| 20 {68} | 2.2—2.7 |
| 80 {176} | 0.29—0.35 |

4. If not as specified, replace the engine coolant temperature sensor.

Tightening torque:

16—23 N·m {1.6—2.4 kgf·m, 12—17 ft·lbf}





HEATED OXYGEN SENSOR (FRONT, REAR)

Inspection

Using the SSTs (engine signal monitor)

1. Remove the PCM. (Refer to page F2-105.)
2. Connect the **SSTs** to the PCM.
3. Warm up the engine to normal operating temperature.
4. Measure the voltage at PCM terminals 3D, 3H, 3I and 3M.

Specification

| Engine condition | PCM terminal voltage (V) | | | |
|------------------|--------------------------|-------|---------|-------|
| | 3I | 3M | 3D | 3H |
| IG-ON | Below 1.0 | | | |
| Idle | Below 1.0 | | | |
| Deceleration | 0—0.5 | 0—1.0 | 0—0.5 | 0—1.0 |
| Acceleration | 0.5—1.0 | 0—1.0 | 0.5—1.0 | 0—1.0 |

5. If not as specified, inspect the following.

- Intake-air system
- Fuel system
- On-board diagnostic system

If these systems are OK, replace the heated oxygen sensor.

Tightening torque:

30—49 N·m {3.0—5.0 kgf·m, 22—36 ft·lbf}

Using the NGS

1. Connect the **SSTs** to the data link connector-2.
2. Select the PID/DATA MONITOR AND RECORD function of NGS.
3. Select "FHO2S R", "RHO2S R", "FHO2S L" and "RHO2S L" on the NGS display. NGS measures and shows the voltage.

Specification

| Engine condition | Voltage (V) | | | |
|------------------|-------------|---------|---------|---------|
| | FHO2S R | RHO2S R | FHO2S L | RHO2S L |
| IG-ON | Below 1.0 | | | |
| Idle | Below 1.0 | | | |
| Deceleration | 0—0.5 | 0—1.0 | 0—0.5 | 0—1.0 |
| Acceleration | 0.5—1.0 | 0—1.0 | 0.5—1.0 | 0—1.0 |

4. If not as specified, inspect the following.

- Intake-air system
- Fuel system
- On-board diagnostic system

If these systems are OK, replace the heated oxygen sensor.

Tightening torque:

30—49 N·m {3.0—5.0 kgf·m, 22—36 ft·lbf}

Heater


1. Disconnect the heated oxygen sensor connector.
2. Measure the resistance between heated oxygen sensor (front) terminals B and C by using an ohmmeter. Measure the resistance between heated oxygen sensor (rear) terminals C and D by using an ohmmeter.

Specification: Approx. 6 Ω (20°C {68°F})

3. If not as specified, replace the heated oxygen sensor.

Tightening torque:

30—49 N·m {3.0—5.0 kgf·m, 22—36 ft·lbf}



KNOCK SENSOR

Inspection

1. Verify that the ignition switch is OFF.
2. Disconnect the knock sensor connector.
3. Measure the resistance between knock sensor terminal A and the knock sensor body by using an ohmmeter.

Specification: Approx. 560 kΩ [20°C {68°F}]


4. If not as specified, replace the knock sensor.
(Refer to below.)

Replacement

Warning


- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F2-67.

1. Disconnect the negative battery cable.
2. Drain the coolant from the radiator. (Refer to section E2.)
3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal, referring to **Installation note**.
5. Refill the radiator with the specified engine coolant.



1. Air hose
2. Intake manifold
Removal Note page F2-123
3. Bypass pipe


4. Water pipe
5. Knock sensor
Removal / Installation Note .. page F2-123



Removal / Installation note

Knock sensor

Use the **SST** to remove and install the knock sensor.



POWER STEERING PRESSURE SWITCH


Inspection

1. Disconnect the P/S pressure switch connector.
2. Start the engine.
3. Check for continuity between P/S pressure switch and a ground by using an ohmmeter.

○—○: Continuity

| Condition | Terminal A | Ground |
|-----------------------------|------------|--------|
| Steering wheel not turned | | |
| Steering wheel being turned | ○—○ | ○—○ |

4. If not as specified, replace the P/S pressure switch. (Refer to section N.)



CLUTCH SWITCH (MTX)

Inspection

1. Disconnect the clutch switch connector.
2. Check for continuity between terminals of the clutch switch by using an ohmmeter.


○—○: Continuity

| Condition \ Terminal | A | B |
|----------------------------|-----|-----|
| Clutch pedal not depressed | | |
| Clutch pedal depressed | ○—○ | ○—○ |

3. If not as specified, replace the clutch switch. (Refer to below.)

Replacement

Replace the clutch switch as shown in the figure.



NEUTRAL SWITCH (MTX)


Inspection

1. Disconnect the neutral switch connector.
2. Check for continuity between terminals of the neutral switch by using an ohmmeter.

○—○: Continuity


| Condition \ Terminal | A | B |
|----------------------|-----|-----|
| Neutral position | ○—○ | ○—○ |
| Others | | |

3. If not as specified, replace the neutral switch.



Tightening torque:

20—29 N·m {2.0—3.0 kgf·m, 15—21 ft·lbf}



EGR VALVE POSITION SENSOR


Inspection

1. Disconnect EGR valve position sensor connector.
2. Disconnect the vacuum hose from the EGR valve and connect the vacuum pump to the EGR valve.
3. Use an ohmmeter to measure the resistance between the terminals as shown in the table.

Specification

| Terminal | Vacuum | |
|----------|---------------------------|-----------------------------------|
| | 0 kPa {0 mmHg, 0 inHg} | 20.0 kPa {150 mmHg, 5.90 inHg} |
| A—B | Approx. 2.7 kΩ | |
| A—C | Approx. 0.5 kΩ | Approx. 2.7 kΩ |
| B—C | Approx. 2.4 kΩ | Approx. 0.1 kΩ |

4. If not as specified, replace the EGR valve.
(Refer to page F2-88.)



EGR BOOST SENSOR

Inspection

1. Warm up the engine to normal operating temperature and let it idle.
2. Verify that the intake air system.
(Refer to page F2-54.)
3. Measure the voltage between terminals A and B by using a voltmeter, from the rear side of the connector.

Specification: Approx. 0.8 V

4. Disconnect the vacuum hose from the EGR boost sensor.
5. Disconnect the vacuum hose from the intake manifold side of the EGR boost sensor solenoid valve and connect the vacuum hose to the EGR boost sensor.
6. Measure the voltage between terminals A and B by using a voltmeter, from the rear side of the connector.


Specification: Approx. 4 V

7. Apply vacuum or pressure to the EGR boost sensor by using a vacuum pump. Measure the voltage between terminals A and B by using a voltmeter, from the rear side of the connector.

Specification

20.0 kPa {150 mmHg, 5.91 inHg}: 0.783—0.849 V
 46.7 kPa {350 mmHg, 13.8 inHg}: 1.772—1.912 V
 101.3 kPa {760 mmHg, 30.0 inHg}: 3.92—4.08 V

8. Turn off the ignition switch.
9. If not as specified, replace the EGR boost sensor.




MAIN RELAY

Inspection

1. Remove the main relay.
2. Check for continuity between terminals of the relay by using an ohmmeter.

○—○: Continuity B+: Battery positive voltage

| Step | Terminal | E | A | B | F |
|------|----------|-----|--------|-----|-----|
| 1 | | ○—○ | ○—○ | | |
| 2 | | B+ | Ground | ○—○ | ○—○ |



3. If not as specified, replace the main relay.

TROUBLESHOOTING GUIDE

QUICK DIAGNOSIS CHART

This Quick Diagnosis Chart shows the relationship between troubleshooting items and inspection points.

| Item | Possible parts and reference page | Fuel system | | | | Intake air system | | | | Evaporative emission system | | | | Ignition system | | | | Control system | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|------------------------------------|---|-------|-------|-------|-------------------|-------|-------|-------|-----------------------------|-------|-------|-------|-----------------|-------|--------|-------|----------------|-------|-------|-------|-----------|---|---|---|--------|--------|--------|--------|--------|--|---|---|---|--|--|--|--|--|--|---|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | F2-74 | F2-71 | F2-78 | F2-78 | F2-73 | F2-54 | F2-11 | F2-55 | F2-54 | F2-65 | F2-65 | F2-86 | F2-86 | F2-93 | F2-124 | F2-88 | F2-94 | F2-94 | F2-94 | F2-90 | section G | | | | F2-115 | F2-120 | F2-117 | F2-121 | F2-117 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Melts main or other fuse | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Will not crank or cranks slowly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Cranks normally but will not start | No combustion | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | | Partial combustion — when engine cold | | | | | | | | | | | | | | | | | | | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | |
| 5 | | Partial combustion — after warm-up | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Cranks normally but hard to start | Any engine temp. | | | | | | | | | | | | | | | | | | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | | When engine cold | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | | After warm-up | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Engine stalls | Idle at any engine temp. | | | | | | | | | | | | | | | | | | | ○ | ○ | ○ | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | | During fast idle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | | Idle after warm-up | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | | Idle with A/C, P/S, and/or E/L ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | | Idle when shifted from N or P to other ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | | Driveaway | | | | | | | | | | | | | | | | | | | ○ | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | | On acceleration | | | | | | | | | | | | | | | | | | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | | While cruising | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 18 | On deceleration | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | |
| 19 | Engine rough | Idle at any engine temp. | | | | | | | | | | | | | | | | | | | ○ | ○ | ○ | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20 | | During fast idle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 21 | | Idle after warm-up | | | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 22 | | Idle with A/C, P/S, and/or E/L ON | | | | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 23 | | Idle when shifted from N or P to other ranges | | | | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 24 | On deceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | Poor acceleration | Driveaway | | | | | | | | | | | | | | | | | | | ○ | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 26 | | On acceleration | | | | | | | | | | | | | | | | | | | ○ | | | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 27 | High idle speed after warm-up | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Control system | | Automatic transaxle system | | Possible parts and reference page | Item |
|---------------------------------|-----------|----------------------------|------------|---|------|
| BETM* | | | section K1 | | |
| Vehicle speed sensor | | | | | |
| Clutch and neutral switches | F2-123 | | | | |
| P/S pressure switch | F2-123 | | | | |
| Brake switch | BETM* | <input type="checkbox"/> | | | |
| Idle air control valve | F2-60 | | | | |
| PCM | F2-105 | <input type="checkbox"/> | | | |
| A/C relay, Condenser fan relay | BETM* | | | | |
| PRC solenoid valve | F2-81 | | | | |
| VRIS solenoid valve (nos. 1, 2) | F2-65 | | | | |
| Fan switch | BETM* | | | | |
| Condenser fan relay | section U | | | | |
| Cooling fan relay | section E | | | | |
| Knock sensor | F2-122 | | | | |
| Air conditioning switch | BETM* | | | | |
| Headlight switch | BETM* | | | | |
| Rear window defroster | BETM* | | | | |
| Main relay | F2-125 | <input type="checkbox"/> | | | |
| Starter | section G | <input type="checkbox"/> | | | |
| Vehicle speed pulse generator | | | | | |
| Transaxle range switch | | | | | |
| O/D off switch | | | | | |
| TCC solenoid valve | | | | | |
| TCC control solenoid valve | | | | | |
| Oil pump | | | | | |
| Control valve body | | | | | |
| Transaxle fluid temperature | | | | | |
| Torque converter | | | | | |
| Reverse clutch | | | | | |
| | | | | | |
| | | | | Melts main or other fuse | 1 |
| | | | | Will not crank or cranks slowly | 2 |
| | | | | No combustion | 3 |
| | | <input type="checkbox"/> | | Partial combustion — when engine cold | 4 |
| | | <input type="checkbox"/> | | Partial combustion — after warm-up | 5 |
| | | | | Any engine temp. | 7 |
| | | | | When engine cold | 8 |
| | | | | After warm-up | 9 |
| | | | | Idle at any engine temp. | 10 |
| | | | | During fast idle | 11 |
| | | | | Idle after warm-up | 12 |
| | | <input type="checkbox"/> | | Idle with A/C, P/S, and/or E/L ON | 13 |
| | | | | Idle when shifted from N or P to other ranges | 14 |
| | | | | Driveaway | 15 |
| | | | | On acceleration | 16 |
| | | | | While cruising | 17 |
| | | <input type="checkbox"/> | | On deceleration | 18 |
| | | | | Idle at any engine temp. | 19 |
| | | | | During fast idle | 20 |
| | | | | Idle after warm-up | 21 |
| | | <input type="checkbox"/> | | Idle with A/C, P/S, and/or E/L ON | 22 |
| | | | | Idle when shifted from N or P to other ranges | 23 |
| | | | | On deceleration | 24 |
| | | | | Driveaway | 25 |
| | | <input type="checkbox"/> | | On acceleration | 26 |
| | | <input type="checkbox"/> | | High idle speed after warm-up | 27 |

* 1996 Mazda 626/MX-6 Body Electrical Troubleshooting Manual

| Item | Possible parts and reference page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|---|-----------|-----------------|--------------------|-------------|-------------|------------|-----------------------------|------------------|----------------|-----------------|-----------------------------|---------------------------|----------------------|---------------------------|-----------|------------------|-----------------------|-------------------|-----------|-------------|--|--------------------------------|-------------------|------------|-----------------|------------------------|-----------------------------------|--------------------------|---|--------------------------|--|---|--|--|--|--|
| | Fuel system | | | Intake air system | | | | Evaporative emission system | | | Ignition system | | Control system | | | | | | | | | | | | | | | | | | | | | | | | |
| | Fuel injector | Fuel pump | Fuel pump relay | Pressure regulator | Fuel filter | Air leakage | Idle speed | Throttle body | Air cleaner body | Vacuum chamber | Check valve | EGR solenoid valve (vacuum) | EGR solenoid valve (vent) | Purge solenoid valve | EGR valve position sensor | EGR valve | Fuel vapor valve | Check valve (two-way) | Charcoal canister | PCV valve | Distributor | Ignition control module (in distributor) | Ignition coil (in distributor) | High-tension lead | Spark plug | Ignition timing | Volume air flow sensor | Engine coolant temperature sensor | Throttle position sensor | Heated oxygen sensor (Front RH or Front LH) | Camshaft position sensor | | | | | | |
| | F2-74 | F2-71 | F2-78 | F2-78 | F2-73 | F2-54 | F2-11 | F2-55 | F2-54 | F2-65 | F2-65 | F2-86 | F2-86 | F2-93 | F2-124 | F2-88 | F2-94 | F2-94 | F2-94 | F2-90 | | | | | | | | | | | | | | | | | |
| 28 | Idle fluctuates/Idle hunts | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 29 | Hesitates/Stumbles on acceleration | ○ | ○ | | | | | | | | | ○ | | | | ○ | | | | | | ○ | | | | | | | | | | | | | | | |
| 30 | Surges while cruising | ○ | | | | | | | | | | | | | | | | | | | | | | | ○ | | | | | | | | | | | | |
| 31 | Lack of power | ○ | | | ○ | | | | ○ | | | | | | | | | | | | | ○ | | | | | ○ | | | | | | | | | | |
| 32 | Poor fuel economy | | | ○ | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | ○ | | | | |
| 33 | A/C does not work | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 34 | Knocking/Pinging | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35 | Fuel odor | | | | | | | | | | | | | ○ | | | | | | | | | | | | | | | | | | | | | | | |
| 36 | Exhaust sulfur smell | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 37 | High oil consumption | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 38 | NGS displays "LINK COMMUNICATION ERROR" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 39 | MIL never ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Control system | | Automatic transaxle system | | Possible parts and reference page | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|-------------------------------|------------|--|------|--|----------------------------|----|------------------------------------|----|-----------------------|----|---------------|----|-------------------|----|-------------------|----|------------------|----|-----------|----|----------------------|----|----------------------|----|---|----|--------------|----|
| Vehicle speed sensor | BETM* | Vehicle speed pulse generator | section K1 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Clutch and neutral switches | F2-123 | Transaxle range switch | | <table border="1"> <thead> <tr> <th>Item</th> <th></th> </tr> </thead> <tbody> <tr> <td>Idle fluctuates/Idle hunts</td> <td>28</td> </tr> <tr> <td>Hesitates/Stumbles on acceleration</td> <td>29</td> </tr> <tr> <td>Surges while cruising</td> <td>30</td> </tr> <tr> <td>Lack of power</td> <td>31</td> </tr> <tr> <td>Poor fuel economy</td> <td>32</td> </tr> <tr> <td>A/C does not work</td> <td>33</td> </tr> <tr> <td>Knocking/Pinging</td> <td>34</td> </tr> <tr> <td>Fuel odor</td> <td>35</td> </tr> <tr> <td>Exhaust sulfur smell</td> <td>36</td> </tr> <tr> <td>High oil consumption</td> <td>37</td> </tr> <tr> <td>NGS displays "LINK COMMUNICATION ERROR"</td> <td>38</td> </tr> <tr> <td>MIL never ON</td> <td>39</td> </tr> </tbody> </table> | Item | | Idle fluctuates/Idle hunts | 28 | Hesitates/Stumbles on acceleration | 29 | Surges while cruising | 30 | Lack of power | 31 | Poor fuel economy | 32 | A/C does not work | 33 | Knocking/Pinging | 34 | Fuel odor | 35 | Exhaust sulfur smell | 36 | High oil consumption | 37 | NGS displays "LINK COMMUNICATION ERROR" | 38 | MIL never ON | 39 |
| Item | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Idle fluctuates/Idle hunts | 28 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Hesitates/Stumbles on acceleration | 29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Surges while cruising | 30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lack of power | 31 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Poor fuel economy | 32 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/C does not work | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Knocking/Pinging | 34 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fuel odor | 35 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Exhaust sulfur smell | 36 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| High oil consumption | 37 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| NGS displays "LINK COMMUNICATION ERROR" | 38 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MIL never ON | 39 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Steering pressure sensor | F2-123 | O/D off switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Brake switch | NETM* | TCC solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Idle air control valve | F2-60 | TCC control solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PCM | F2-105 | Oil pump | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A/C relay, Condenser fan relay | BETM* | Control valve body | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PRC solenoid valve | F2-81 | Transaxle fluid temperature | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VRIIS solenoid valve (nos.1, 2) | F2-65 | Torque converter | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fan switch | BETM* | Reverse clutch | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Condenser fan relay | BETM* | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Cooling fan relay | section E | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Knock sensor | F2-122 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Air conditioning switch | BETM* | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Headlight switch | BETM* | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Rear window defroster | BETM* | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Main relay | F2-125 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Starter | section G | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

* 1996 Mazda 626/MX-6 Body Electrical Troubleshooting Manual

RELATIONSHIP CHART

| INPUT DEVICE | | OUTPUT DEVICE | | FUEL INJECTION AMOUNT | FUEL INJECTION TIMING | FUEL PUMP RELAY | IGNITION CONTROL MODULE | A/C RELAY (A/C CUT-OFF) AND CONDENSER FAN LOW RELAY | CONDENSER FAN HIGH RELAY No.1, No.2 | BAC VALVE (IDLE AIR CONTROL VALVE) | COOLING FAN RELAY No.1 | COOLING FAN RELAY No.2, No.3 | SOLENOID VALVE | | | NGS (DIAGNOSTIC TROUBLE CODE) |
|--|---------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------|-------------------------|---|-------------------------------------|------------------------------------|------------------------|------------------------------|----------------|------------------------------|-------------|-------------------------------|
| | | FUEL INJECTION AMOUNT | FUEL INJECTION TIMING | | | | | | | | | | PURGE CONTROL | VRIS (No.1 AND No.2) CONTROL | EGR CONTROL | |
| CAMSHAFT POSITION SENSOR | SGC SIGNAL | ○ | ○ | ○ | ○ | | | | | | | | | | | ○ |
| CRANKSHAFT POSITION SENSOR (NE SIGNAL) | | ○ | ○ | | ○ | | | | | ○ | | | ○ | ○ | ○ | ○ |
| THROTTLE POSITION SENSOR | CLOSED THROTTLE POSITION SWITCH | ○ | ○ | | ○ | | | | | ○ | ○ | ○ | | ○ | | |
| | THROTTLE POSITION SENSOR | ○ | ○ | | ○ | | ○ | | ○ | ○ | | | ○ | ○ | ○ | ○ |
| VOLUME AIR FLOW SENSOR | | ○ | | | | | ○ | | | | | | ○ | | ○ | ○ |
| ENGINE COOLANT TEMPERATURE SENSOR | | ○ | | | | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | ○ | ○ |
| INTAKE AIR TEMPERATURE SENSOR | | ○ | | | | | | | | ○ | | | ○ | | ○ | ○ |
| HEATED OXYGEN SENSOR | | ○ | | | | | | | | | | | ○ | | | ○ |
| KNOCK SENSOR | | | | | | | ○ | | | | | | | | | ○ |
| AIR CONDITIONING SWITCH | | | | | | | | ○ | ○ | ○ | ○ | | | | | |
| P/S PRESSURE SWITCH | | | | | | | | ○ | | ○ | | | | | | |
| IGNITION SWITCH (START SIGNAL) | | ○ | ○ | ○ | ○ | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| BRAKE SWITCH | | ○ | | | | | | | | | | | | | | |
| TRANSAXLE RANGE SWITCH (ATX) | | ○ | | | ○ | | ○ | | | ○ | | | ○ | | ○ | |
| E/L SIGNAL* | | | | | | | | | | ○ | | | | | | |
| NEUTRAL AND CLUTCH SWITCHES (MTX) | | ○ | | | ○ | | ○ | ○ | | ○ | | | ○ | | ○ | |
| DATA LINK CONNECTOR (TEN TERMINAL) | | | | | | | ○ | | | ○ | ○ | ○ | | | ○ | ○ |
| EGR VALVE POSITION SENSOR | | | | | | | ○ | | | | | | | ○ | | ○ |
| EGR BOOST SENSOR | | ○ | | | | | ○ | | | ○ | | | | | | ○ |
| VEHICLE SPEED SENSOR | | | | | | | | | | ○ | | | ○ | | | |

* E/L SIGNAL: Fan switch third position or higher, headlight ON, rear window defroster ON.

Output devices and engine condition


| ENGINE CONDITION OUTPUT DEVICE | | CRANKING (COLD ENGINE) | WARMING UP (DURING IDLE) | MEDIUM LOAD | | ACCEL- ERA- TION | HEAVY LOAD | DECEL- ERA- TION | IDLE | IG: ON (ENGINE NOT RUN- NING) | REMARK | |
|-----------------------------------|------------------------|------------------------------------|---------------------------------------|-----------------|---------------|------------------------|---------------|------------------------|--------|--|--|------------------------------------|
| | | | | COLD | WARM | | | | | | | |
| FUEL INJECTOR | FUEL INJECTION AMOUNT | Rich | | Normal | | Rich | | Fuel cut* | Normal | No injection | * Engine speed: Above 1,500 rpm (ATX)/1,200 rpm (MTX) | |
| FUEL PUMP RELAY | | ON | | | | | | | OFF | | | |
| IGNITION CONTROL MODULE | | Fixed at BTDC 7° | Advanced: depends on engine condition | | | | | | | | | |
| PURGE SOLENOID VALVE | | OFF | | ON (Purge) | | OFF | | | | | | |
| EGR SOLENOID VALVE (VENT) | | OFF | | ON* | | OFF | | | | | System operates: Amount of EGR changes | |
| EGR SOLENOID VALVE (VACUUM) | | | | | | | | | | | | |
| PRC SOLENOID VALVE | | OFF (Vacuum to pressure regulator) | | | | | | | ON* | OFF | * During hot start only | |
| VRIS SOLENOID VALVE No.1 | | ON | | ON* | | | | | | | OFF | * Engine speed: 3,250—6,250 rpm |
| VRIS SOLENOID VALVE No.2 | | OFF | | ON* | | | | | | | OFF | * Engine speed: 4,250—6,250 rpm |
| BAC VALVE | IDLE AIR CONTROL VALVE | ON (Closed loop duty) | | ON (Fixed duty) | | | | ON (Closed loop duty) | OFF | | | |
| | AIR VALVE | OPEN | | CLOSED | | | | | | | — | |
| A/C RELAY | | OFF (A/C cut) | ON | | OFF (A/C cut) | ON | | | OFF | | | |

USING THIS SECTION


Introduction

Most of the fuel and emission control systems are electronically controlled, often making it difficult to diagnose problems, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially the intermittent ones. Through a talk with the customer, you will usually find out what the symptoms are and under what conditions they occur.

Work flow



Diagnostic index



Troubleshooting chart

| | | | |
|---|---|--|---|
| 13, 14 | ENGINE STALLS | <ul style="list-style-type: none"> • IDLE WITH A/C, P/S, and/or E/L ON • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle • Engine stops unexpectedly when shifted from N or P to other ranges at idle • Idle condition is normal when A/C, P/S, and E/L are OFF and in N and P | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Monitor switch functions (SST)</p> <ul style="list-style-type: none"> • A/C switch • Headlight switch • Rear window defroster <ul style="list-style-type: none"> • Blower switch <p>② Solenoid valve (ISC)</p> <ul style="list-style-type: none"> • Solenoid valve stuck | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are switches correct when checked by using Self-Diagnosis Checker monitor lamp while ignition switch ON? ☞ page F2-44 <ul style="list-style-type: none"> • Blower switch • Headlight switch • Rear window defroster switch • Selector lever | Yes | Go to next step |
| | | No | Lamp not ON/OFF with specified switch Check for cause (Refer to specified check sequence) ☞ page F2-45 |
| 2 | Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? ☞ page F2-18 | Yes | "00" displayed Go to next step |
| | | No | Service Code No. displayed Check for cause (Refer to specified check sequence) ☞ page F2-20 "88" flashes "No. 38 SELF-DIAGNOSIS "88" |

DESCRIPTION:

Further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "☞" mark.

ACTION:

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page specified by the "☞" mark.

DIAGNOSTIC INDEX

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|---|--|----------------------|
| No. | TROUBLE | | |
| 1 | Melts main or other fuse | | F2-138 |
| 2 | Will not crank or cranks slowly | Starter does not work Starter cranks engine at slow speed | section G |
| 3 | Crank normally but will not start | No combustion | F2-139 |
| 4 | | Partial combustion —when engine cold | F2-139 |
| 5 | | Partial combustion —after warm-up | F2-141 |
| 6 | Will start in positions and ranges other than P and N | Engine starts in all positions and ranges | section K1 |
| 7 | Crank normally but hard to start | Any engine temp. | F2-142 |
| 8 | | When engine cold | |
| 9 | | After warm-up | |
| 10 | Engine stalls | Idle at any engine temp. | F2-144 |
| 11 | | During fast idle | |
| 12 | | Idle after warm-up | |
| 13 | | Idle with A/C, P/S, and/or E/L ON | F2-147 section K1 |
| *14 | | Idle when shifted from N or P to other ranges | |
| 15 | | Driveaway | F2-148 |
| 16 | | On acceleration | F2-150 |
| 17 | | While cruising | |
| *18 | | On deceleration | F2-152 section K1 |
| 19 | Engine runs rough | Idle at any engine temp. | F2-154 |
| 20 | | During fast idle | |
| 21 | | Idle after warm-up | |

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|--|--|---|
| No. | TROUBLE | | |
| 22 | Engine runs rough | Idle with A/C, P/S, and/or E/L ON | F2-158 |
| 23 | | Idle when shifted from N or P to other range | |
| *24 | | On deceleration | Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration Exhaust afterburn |
| *25 | Poor acceleration | Driveaway | F2-161 section K1 |
| *26 | | On acceleration | |
| 27 | High idle speed after warm-up | Idle speed continues at fast idle after warm-up Engine returns slowly to idle after accelerator is released | F2-163 |
| 28 | Idle fluctuates/Idle hunts | Engine speed changes back and forth between specified idle speed and higher speed | F2-164 |
| 29 | Hesitates/Stumbles on acceleration | Momentary pause at beginning of acceleration or during acceleration | F2-166 |
| *30 | Surges while cruising | Momentary minor irregularity in engine output at steady vehicle speed | F2-169 section K1 |
| *31 | Lack of power | Performance poor under load (i.e., power down when climbing hills) | F2-170 section K1 |
| *32 | Poor fuel economy | Fuel economy unsatisfactory | F2-170 section K1 |
| 33 | A/C does not work | A/C compressor magnetic clutch does not engage when air conditioning switch ON | F2-170 |
| 34 | Knocking/Pinging | Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | F2-170 |
| 35 | Fuel odor | Gasoline fuel smell or visible leaks | F2-171 |
| 36 | Exhaust sulfur smell | Rotten egg smell from exhaust | F2-171 |
| 37 | High oil consumption | Oil consumption excessive | F2-171 |
| 38 | NGS displays "LINK COMMUNICATION ERROR" | NGS displays "LINK COMMUNICATION ERROR" | F2-171 |
| 39 | MIL never ON | Self-Diagnosis Checker indicates Diagnostic Trouble Code No. of input device but MIL never ON | F2-171 |
| 40 | Vehicle does not move in D, S, L and/or R ranges | No creep at all Vehicle does not move when accelerator pedal depressed after shifted to D, S, L and/or R range | section K1 |
| 41 | Vehicle moves in N range | Vehicle creeps in N range Vehicle moves when accelerator pedal not depressed | section K1 |
| 42 | Vehicle moves in P range | Vehicle rolls in P range, and drivetrain not locked up | section K1 |
| 43 | Excessive creep | Vehicle moves quickly in D, S, L and R ranges (accelerator pedal not depressed) Note • Excessive N to R range and N to D range shift shock felt | section K1 |
| 44 | No shift | Single range shift (1st→2nd, 2nd→3rd or 3rd→O/D) only Sometimes shifts correctly Note • Gear position held in hold mode | section K1 |



| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE | |
|----------------------|-------------------------|---|--|------------|
| No. | TROUBLE | | | |
| 45 | Abnormal shift | Shifts incorrectly (incorrect shift pattern) (ex) Vehicle shifts 1st→O/D directly when accelerating with accelerator pedal depressed slightly | section K1 | |
| 46 | Frequent shifting | Downshift occurs when accelerator depressed slightly in D, S and L ranges (except hold mode) | section K1 | |
| 47 | Shift point high or low | Shift points do not match shift diagram Shifts delayed when accelerating Shifts occur too fast when accelerating and engine speed does not increase | section K1 | |
| 48 | No lockup | No lockup when vehicle speed reaches lockup range | section K1 | |
| 49 | No kickdown | Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range | section K1 | |
| 50 | Engine speed flares up | When accelerating | Engine speed flares up on acceleration | section K1 |
| 51 | | When upshifting and/or downshifting | Engine flares up when accelerator pedal depressed for upshifting Engine flares up suddenly when accelerator pedal depressed for downshifting | section K1 |
| 52 | Engine speed flares up | P, N to R and/or N to D | Strong shift shock felt at idle when shifting from N to D or R range | section K1 |
| 53 | Excessive shift shock | When upshifting and/or downshifting | Excessive shift shock felt when accelerating at upshifting During cruising, excessive shift shock felt when accelerator pedal depressed at downshifting | section K1 |
| 54 | No engine braking | Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in L range at low vehicle speed | section K1 | |
| 55 | No mode change | Mode does not change to/from normal mode in D range Hold mode not selected or not cancelled | section K1 | |
| 56 | Transaxle noise | All ranges | Transaxle noisy in all ranges when vehicle is idling | section K1 |
| 57 | | D, S, L, R ranges | Abnormal noise from transaxle in D, S, L, R | section K1 |
| 58 | Transaxle overheats | ATF smells burnt and/or is discolored | section K1 | |

Description of Drivability Problems


STUMBLE : Mildly irregular performance during acceleration.

HESITATION : A dip or flat spot in performance just after the accelerator pedal is depressed.


SURGE : Continuous irregular performance during cruising.

**Fuel Pressure Release and Servicing Fuel System****Warning**

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

**Fuel Line Safety Procedures**

1. Release the fuel pressure before disconnecting a fuel line.
 - (1) Start the engine.
 - (2) Remove the fuel pump relay.
 - (3) After the engine stalls, turn the ignition switch to OFF.
 - (4) Install the fuel pump relay.
2. Avoid leakage.
 - (1) When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - (2) Plug the hose after removal.
3. Install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose.

**Pinching Hose**


When pinching an air hose or a fuel hose with pliers, wrap the hose with a rag to prevent damage.

SYMPTOM TROUBLESHOOTING

1 **MELTS MAIN OR OTHER FUSE**

[TROUBLESHOOTING HINTS]











Check the condition of the fuse









| Damaged Fuse | Related Wiring Harness | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------|--|-----------------------------|-------|-----------------|-----------------|-------|-----------|------------|-------|----------------|--|-------|-----------------|--|-------|-------------|--|-------|----------------------|--|-------|--------------------|--|-------|--------------------------|--|-------|--------------------------|--|-------|-----------------------------|--|-------|---------------------------|--|-------|------------------------|--|-------|----------------------|
| MAIN (100A) | Main fuse ————— Generator | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BTN (60A) | BTN fuse ————— ROOM fuse | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ROOM (15A) | ROOM fuse ————— PCM terminal 4B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGI INJ (30A) | <table border="0"> <tr> <td>Main relay</td> <td>—————</td> <td>Fuel pump relay</td> </tr> <tr> <td>Fuel pump relay</td> <td>—————</td> <td>Fuel pump</td> </tr> <tr> <td>Main relay</td> <td>—————</td> <td>Fuel injectors</td> </tr> <tr> <td></td> <td>—————</td> <td>PCM terminal 4A</td> </tr> <tr> <td></td> <td>—————</td> <td>Distributor</td> </tr> <tr> <td></td> <td>—————</td> <td>Heated oxygen sensor</td> </tr> <tr> <td></td> <td>—————</td> <td>PRC solenoid valve</td> </tr> <tr> <td></td> <td>—————</td> <td>VRIS solenoid valve No.1</td> </tr> <tr> <td></td> <td>—————</td> <td>VRIS solenoid valve No.2</td> </tr> <tr> <td></td> <td>—————</td> <td>EGR solenoid valve (Vacuum)</td> </tr> <tr> <td></td> <td>—————</td> <td>EGR solenoid valve (Vent)</td> </tr> <tr> <td></td> <td>—————</td> <td>Idle air control valve</td> </tr> <tr> <td></td> <td>—————</td> <td>Purge solenoid valve</td> </tr> </table> | Main relay | ————— | Fuel pump relay | Fuel pump relay | ————— | Fuel pump | Main relay | ————— | Fuel injectors | | ————— | PCM terminal 4A | | ————— | Distributor | | ————— | Heated oxygen sensor | | ————— | PRC solenoid valve | | ————— | VRIS solenoid valve No.1 | | ————— | VRIS solenoid valve No.2 | | ————— | EGR solenoid valve (Vacuum) | | ————— | EGR solenoid valve (Vent) | | ————— | Idle air control valve | | ————— | Purge solenoid valve |
| Main relay | ————— | Fuel pump relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fuel pump relay | ————— | Fuel pump | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Main relay | ————— | Fuel injectors | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | PCM terminal 4A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | Distributor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | Heated oxygen sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | PRC solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | VRIS solenoid valve No.1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | VRIS solenoid valve No.2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | EGR solenoid valve (Vacuum) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | EGR solenoid valve (Vent) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | Idle air control valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | ————— | Purge solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EGI INJ (15A) | ENGINE fuse ————— Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| METER (15A) | METER fuse ————— Data link connector terminal B+ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| | | |
|---|---|---|
| 3 | CRANKS NORMALLY BUT WILL NOT START | • NO COMBUSTION |
| DESCRIPTION • Starter cranks engine at normal speed but engine shows no indication of firing | | |
| [TROUBLESHOOTING HINTS] | | |
| ① Distributor <ul style="list-style-type: none"> • Poor connection of connector • Open in ignition coil ② Main relay <ul style="list-style-type: none"> • Poor connection of connector • Malfunction of relay ③ PCM <ul style="list-style-type: none"> • No IGT signal output from PCM terminal 4S to ignition control module (in distributor) | | |
| | | 🔍 section G 🔍 page F2-125 🔍 page F2-106 |





| | | | |
|--|--|--|---|
| 4 | CRANKS NORMALLY BUT WILL NOT START | • PARTIAL COMBUSTION — WHEN ENGINE COLD | |
| DESCRIPTION | | | |
| <ul style="list-style-type: none"> • Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold at initial starting • Engine will not continue running when cold when ignition switch is returned from STA to ON position • Refer to "ENGINE STALLS" if this symptom appears after engine stall • Fuel in tank • Battery in normal condition | | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① BAC valve <ul style="list-style-type: none"> • Malfunction of air valve • Idle air control valve stuck ② Fuel injector <ul style="list-style-type: none"> • Poor connection ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection ④ Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Volume air flow sensor <ul style="list-style-type: none"> • Measuring core stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON? 🔍 page F2-13 | Yes | "NO CODES RECEIVED" displayed Go to next step |
| | | No | Diagnostic Trouble Code No. Check for cause (Refer to specified check sequence) 🔍 page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Does engine start when throttle valve held quarter open? | Yes | Check air valve operation 🔍 page F2-59 |
| | | No | Go to next step |
| 3 | Do Engine Signal Monitor lights flash for specified terminals while cranking engine? 🔍 pages F2-106 Terminal: 4Q, 4U, 4Y, 4AC, 4AG, 4AK | Yes | Go to next step |
| | | No | Check as follows according to results: Does not flash and 0V indicated for individual terminals <ul style="list-style-type: none"> • Continuity of fuel injector • Continuity between PCM and fuel injector(s) 🔍 page F2-4 • Condition of fuel injector connector and PCM connector female terminals Repair or replace parts and/or wiring harness as necessary |






| STEP | INSPECTION | | ACTION |
|------|---|---|---|
| 4 | Connect jumper wire between F/P and GND terminals of data link connector; will engine start?  | Yes | Check as follows: <ul style="list-style-type: none"> 1AF terminal voltage at PCM  page F2-106 Continuity between 1AF terminal and fuel pump relay connector terminal Condition of PCM and fuel pump relay connector female terminals |
| | No | Check if fuel pump operating sound is heard <ul style="list-style-type: none"> If yes, go to next step If no, check fuel pump and wiring harness  page F2-4 | |
| 5 | Is following terminal voltage at PCM correct?  page F2-106 3E terminal: Approx. 4.0V (ign. ON) | Yes | Go to next step |
| | No | Check as follows: <ul style="list-style-type: none"> Movement of measuring core in volume air flow sensor Ground of volume air flow sensor Continuity between volume air flow sensor and PCM connector Condition of volume air flow sensor and PCM connector female terminals | |
| 6 | Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?  page F2-68 Fuel line pressure: 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi} | Yes | Go to next step |
| | No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> If pressure quickly increases, check pressure regulator  page F2-78 If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure  page F2-71 | |
| 7 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Go to next step |
| | No | Check as follows <ul style="list-style-type: none"> Distributor cap and rotor  section G High-tension leads  section G | |




| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 8 | Are fuel injectors OK? • No fuel leakage  page F2-76 • Fuel injectors not clogged  page F2-74 | Yes | Go to next step |
| | | No | Replace fuel injector(s)  page F2-74 |
| 9 | Try known good PCM; does condition improve?  page F2-106 | | |



| 5 | CRANKS NORMALLY BUT WILL NOT START | • PARTIAL COMBUSTION — AFTER WARM UP |
|---|---|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm • Engine will not continue running when ignition switch is returned from STA to ON position | |
| [TROUBLESHOOTING HINTS] | | |
| ① Pressure regulator <ul style="list-style-type: none"> • Fuel hold pressure low | |  page F2-78 |
| ② Throttle body <ul style="list-style-type: none"> • Carbon on throttle valve | |  page F2-55 |







| | | | | | |
|--|--|---|---|--|--|
| 7 8 9 | CRANKS NORMALLY BUT HARD TO START | <ul style="list-style-type: none"> • ANY ENGINE TEMP. • WHEN ENGINE COLD • AFTER WARM-UP | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Starter cranks engine at normal speed but engine requires excessive cranking time before starting • Engine starts after stalling a few times • Battery in normal condition • Engine runs normally at idle (if idle condition not OK, refer to “Engine runs rough” [Nos. 19, 20, 21, 22 or 23]) | | | | |
| [TROUBLESHOOTING HINTS] | | | | | |
| <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none; vertical-align: top;"> <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) ② Fuel pump <ul style="list-style-type: none"> • Malfunction of pump ③ Pressure regulator <ul style="list-style-type: none"> • Pressure regulator stuck ④ Spark plug <ul style="list-style-type: none"> • Dirty or worn spark plug(s) </td> <td style="width: 50%; border: none; vertical-align: top;"> <ul style="list-style-type: none"> ⑤ PRC solenoid valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ Throttle body <ul style="list-style-type: none"> • Carbon on throttle plate ⑦ EGR solenoid valve (vacuum or vent) <ul style="list-style-type: none"> • Solenoid valve stuck ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck </td> </tr> </table> | | | | <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) ② Fuel pump <ul style="list-style-type: none"> • Malfunction of pump ③ Pressure regulator <ul style="list-style-type: none"> • Pressure regulator stuck ④ Spark plug <ul style="list-style-type: none"> • Dirty or worn spark plug(s) | <ul style="list-style-type: none"> ⑤ PRC solenoid valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ Throttle body <ul style="list-style-type: none"> • Carbon on throttle plate ⑦ EGR solenoid valve (vacuum or vent) <ul style="list-style-type: none"> • Solenoid valve stuck ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck |
| <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) ② Fuel pump <ul style="list-style-type: none"> • Malfunction of pump ③ Pressure regulator <ul style="list-style-type: none"> • Pressure regulator stuck ④ Spark plug <ul style="list-style-type: none"> • Dirty or worn spark plug(s) | <ul style="list-style-type: none"> ⑤ PRC solenoid valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ Throttle body <ul style="list-style-type: none"> • Carbon on throttle plate ⑦ EGR solenoid valve (vacuum or vent) <ul style="list-style-type: none"> • Solenoid valve stuck ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck | | | | |
| STEP | INSPECTION | ACTION | | | |
| 1 | <p>Is “NO CODES RECEIVED” displayed on SST with ignition switch ON?</p> <p style="text-align: right;">🔧 page F2-13</p> | <p>Yes</p> | <p>“NO CODES RECEIVED” displayed Go to next step</p> | | |
| | | <p>No</p> | <p>Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) 🔧 page F2-20</p> <p>“LINK COMMUNICATION ERROR” displays Refer to No.38 “NGS DISPLAYS LINK COMMUNICATION ERROR”</p> | | |
| 2 | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p style="text-align: right;">🔧 page F2-68</p> <p>Fuel line pressure: 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}</p> <div style="text-align: center;">  <p style="font-size: small;">JUMPER WIRE F/P GND DATA LINK CONNECTOR</p> </div> | <p>Yes</p> | <p>Go to next step</p> | | |
| | | <p>No</p> | <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator 🔧 page F2-78 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure 🔧 page F2-71 | | |
| 3 | <p>Is fuel line pressure held after ignition switch turned OFF?</p> <p style="text-align: right;">🔧 page F2-67</p> <p>Fuel line pressure: More than 150 kPa {1.5 kgf/cm², 21 psi} for 5 min.</p> <div style="text-align: center;">  </div> | <p>Yes</p> | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 6 • If symptom occurs when engine cold, go to next step • If symptom occurs after warm-up, go to step 6 | | |
| | | <p>No</p> | <p>Plug outlet of pressure regulator, Is fuel line pressure held after ignition switch turned OFF? 🔧 page F2-67</p> <ul style="list-style-type: none"> • If yes, replace pressure regulator 🔧 page F2-78 • If no, check fuel pump hold pressure 🔧 page F2-67 <p>If fuel pump OK, check fuel injectors for fuel leakage 🔧 page F2-76</p> | | |

| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 4 | Is inside of throttle body clean?  | Yes | Clean throttle body |
| | | No | Go to next step |
| 5 | Disconnect vacuum hose from EGR valve and plug it; does condition improve? | Yes | Check as follows: <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) for sticking • EGR solenoid valve (vent) for sticking • Condition of solenoid valve connector |
| | | No | Check if EGR valve moves smoothly  page F2-88 <ul style="list-style-type: none"> • If yes, go to next step • If no, replace EGR valve  page F2-88 |
| 6 | Try known good PCM; does condition improve?  page F2-106 | | |


| | | |
|--|---|--|
| 10 11 12 | ENGINE STALLS | <ul style="list-style-type: none"> • IDLE AT ANY ENGINE TEMP • DURING FAST IDLE • IDLE AFTER WARM-UP |
| DESCRIPTION • Engine stops unexpectedly at idle and/or during fast idle operation | | |
| [TROUBLESHOOTING HINTS] | | |
| <ul style="list-style-type: none"> ① Injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged ② Fuel pump <ul style="list-style-type: none"> • Maximum pressure low ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection of connector ④ Air leakage in intake-air system ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Volume air flow sensor <ul style="list-style-type: none"> • Measuring core stuck ⑦ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑧ BAC valve <ul style="list-style-type: none"> • Air valve stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | Yes "NO CODES RECEIVED" displayed <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 8 • If symptom occurs at idle after warm-up, go to step 9 |
| | | No Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Do Engine Signal Monitor lights flash for specified terminals while cranking engine? Terminal: 4Q, 4U, 4Y, 4AC, 4AG, 4AK | Yes Go to next step |
| | | No Check as follows according to results: Does not flash and 0V indicated for individual terminal(s) <ul style="list-style-type: none"> • Continuity of fuel injector(s) • Continuity between PCM and fuel injector(s)  page F2-4 • Condition of injection connector and PCM connector Repair or replace parts and/or wiring harness as necessary |
| 3 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes Go to next step |
| | | No Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor  section G • High-tension lead(s) |





| STEP | INSPECTION | ACTION |
|------|--|---|
| 4 | Connect jumper wire between F/P and GND terminal of data link connector; will engine run?  | Yes Check as follows: <ul style="list-style-type: none"> • 1AF terminal voltage at PCM page F2-106 • Continuity between 1AF terminal and fuel pump relay connector terminal • Condition of PCM and fuel pump relay connector female terminals |
| | | No Check if fuel pump operating sound is heard? <ul style="list-style-type: none"> • If yes, go to next step • If no, check fuel pump circuit |
| 5 | Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? page F2-68 Fuel line pressure: 270—310 kPa {2.7—3.2 kgf/cm ² , 39—45 psi}  | Yes Go to next step |
| | | No Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator page F2-78 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure page F2-71 |
| 6 | Is air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes Repair or replace |
| | | No Go to next step |
| 7 | Is engine compression correct? section B2 Engine compression (Minimum): 981 kPa {10.0 kgf/cm ² , 143 psi}/250 rpm | Yes Go to step 9 |
| | | No Check for cause section B2 |
| 8 | Does engine start with throttle valve held quarter open? | Yes Check as follows: <ul style="list-style-type: none"> • Operation of air valve page F2-60 • Operation of EGR valve page F2-88 • Operation of EGR control page F2-86 |
| | | No Go to next step |
| 9 | Does following terminal voltage at PCM increase smoothly? page F2-106 3Q terminal: Engine coolant temperature sensor  | Yes Go to next step |
| | | No Check as follows: <ul style="list-style-type: none"> • Engine coolant temperature sensor resistance • Continuity between engine coolant temperature sensor and PCM connector |










| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 10 | Are spark plugs OK? ➤ section G  | Yes | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 14 • If symptom occurs at fast idle operation, go to step 14 • If symptom occurs at idle after warm-up, go to next step |
| | | No | Clean or replace ➤ section G |
| 11 | Is resistance of idle air control valve correct? ➤ page F2-60 Resistance: 10.7—12.3Ω [at 20°C {68°F}]  | Yes | Go to next step |
| | | No | Replace BAC valve ➤ page F2-60 |
| 12 | Try a known good BAC valve; does condition improve? | Yes | Replace BAC valve ➤ page F2-60 |
| | | No | Reinstall BAC valve and go to next step |
| 13 | Is oxygen sensor operation OK? ➤ page F2-121 | Yes | Go to next step |
| | | No | Check follows: <ul style="list-style-type: none"> • Poor connection of engine coolant temperature sensor connector • Incorrect installation of throttle position sensor |
| 14 | Are fuel injectors OK? <ul style="list-style-type: none"> • No fuel leakage ➤ page F2-76 • Fuel injectors not clogged ➤ page F2-74 | Yes | Go to next step |
| | | No | Replace fuel injector(s) ➤ page F2-74 |
| 15 | Try a known good PCM; does condition improve? ➤ page F2-106 | | |






| | | | |
|---|--|---|---|
| 13 14 | ENGINE STALLS | <ul style="list-style-type: none"> • IDLE WITH A/C, P/S, AND/OR E/L ON • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES | |
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle • Engine stops unexpectedly when shifted from N or P to other ranges at idle <p>Idle condition is normal when A/C, P/S, and E/L are OFF and in N and P</p> | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① E/L signal malfunction</p> <ul style="list-style-type: none"> • Air conditioning switch • Headlight switch • Rear window defroster • Fan switch <p>② Idle air control valve</p> <ul style="list-style-type: none"> • Solenoid valve stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Do following terminal voltages in PCM correct?  page F2-106</p> <ul style="list-style-type: none"> • 1F Transaxle range switch (ATX) • 1G Foglight switch • 1L Headlight switch • 1K Fan switch • 1X Rear window defroster switch • 3T P/S pressure switch | Yes | Go to next step |
| | | No | <p>Check as follows</p> <ul style="list-style-type: none"> • Switch operation • Continuity between switch and PCM terminals |
| 2 | <p>Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13</p> | Yes | <p>"NO CODES RECEIVED" displayed Go to next step</p> |
| | | No | <p>Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13</p> <p>"LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR"</p> |
| 3 | <p>Is terminal voltage at PCM correct at idle?  page F2-106</p> <p>4M terminal: Approx. 6.0V (at idle)</p> | Yes | <p>Check BAC valve and replace if necessary  page F2-60</p> <p>If OK, go to "ENGINE STALLS — IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES" in section K1 of this manual</p> |
| | | No | <p>Try known good PCM and check if condition improves  page F2-106</p> |


| 15 | ENGINE STALLS | • DRIVEAWAY | | | | | | | | | |
|--|---|--|--|----|-----------------------------|----|----------------------------------|---------------------------|--|-----|-----------------|
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine stops unexpectedly upon driveaway • Idle condition normal | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | |
| ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) • Fuel injector(s) clogged | | ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged | | | | | | | | | |
| ② Pressure regulator <ul style="list-style-type: none"> • Diaphragm damaged | | ⑤ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector | | | | | | | | | |
| ③ Fuel filter <ul style="list-style-type: none"> • Fuel filter clogged | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON? <div style="text-align: right;">☞ page F2-13</div> | Yes | "NO CODES RECEIVED" displayed Go to next step | | | | | | | | |
| | | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) <div style="text-align: right;">☞ page F2-13</div> "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" | | | | | | | | |
| 2 | Using Engine Signal Monitor, do voltage reading and light operation change as follows upon driveaway? <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Terminal</th> <th style="text-align: center;">Condition</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">3E</td> <td>Voltage gradually increases</td> </tr> <tr> <td style="text-align: center;">3Q</td> <td>Voltage does not suddenly change</td> </tr> <tr> <td style="text-align: center;">4Q, 4U, 4Y, 4AC, 4AG, 4AK</td> <td>Flashing of green and red lights becomes quicker</td> </tr> </tbody> </table> | Terminal | Condition | 3E | Voltage gradually increases | 3Q | Voltage does not suddenly change | 4Q, 4U, 4Y, 4AC, 4AG, 4AK | Flashing of green and red lights becomes quicker | Yes | Go to next step |
| | | Terminal | Condition | | | | | | | | |
| 3E | Voltage gradually increases | | | | | | | | | | |
| 3Q | Voltage does not suddenly change | | | | | | | | | | |
| 4Q, 4U, 4Y, 4AC, 4AG, 4AK | Flashing of green and red lights becomes quicker | | | | | | | | | | |
| No | Check as follows: <ul style="list-style-type: none"> • Condition of female terminals in related connector • Continuity between injector connector and PCM connector | | | | | | | | | | |
| 3 | Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? <div style="text-align: right;">☞ page F2-68</div> Fuel line pressure: 270—310 kPa {2.7—3.2 kgf/cm ² , 38—46 psi} | Yes | Go to next step | | | | | | | | |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator <div style="text-align: right;">☞ page F2-78</div> • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure <div style="text-align: right;">☞ page F2-71</div> | | | | | | | | |





| STEP | INSPECTION | ACTION |
|------|---|---------------------|
| 4 | Are fuel injectors OK? • No fuel leakage  page F2-76 • Fuel injectors not clogged  page F2-74 | Yes Go to next step |
| | No Replace fuel injector(s)  page F2-74 | |
| 5 | Try a known good PCM; does condition improve?  page F2-106 | |




| | | | |
|---|---|---|--|
| 16 17 | ENGINE STALLS | • ON ACCELERATION/WHILE CRUISING | |
| DESCRIPTION <ul style="list-style-type: none"> • Engine stops unexpectedly at beginning of acceleration or during acceleration • Engine stops unexpectedly while cruising | | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection ② Pressure regulator <ul style="list-style-type: none"> • Diaphragm damaged ③ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged ④ Volume air flow sensor <ul style="list-style-type: none"> • Poor connection of connector • Measuring core stuck ⑤ Main relay <ul style="list-style-type: none"> • Poor connection of connector | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | | Yes: "NO CODES RECEIVED" displayed Go to next step No: Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | | Yes: Check spark plugs  section G ⇨ If OK, go to next step ⇨ If not OK, clean or replace spark plug No: Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor  section G • High-tension lead(s)  section G • Condition of distributor connector female terminals |
| 3 | Are volume air flow sensor connector terminals good? | | Yes: Verify that measuring core of volume air flow sensor moves smoothly <ul style="list-style-type: none"> • If OK, go to next step • If not OK, replace air flow sensor No: Repair connector terminal(s) |
| 4 | Ground terminal F/P of data link connector with ignition switch ON; is operation sound of fuel pump heard?  | | Yes: Go to next step No: Check as follows: <ul style="list-style-type: none"> • Poor connection of fuel pump relay • Poor connection of fuel pump connector • Melted EGI INJ fuse (30A)  page F2-138 Refer to "No.1 — MELTS MAIN OR OTHER FUSE" • Poor connection of main relay • Operation of main relay  page F2-125 |



| STEP | INSPECTION | ACTION |
|------|--|--|
| 5 | <p>Is fuel line pressure correct at idle?  page F2-78</p> <p>Fuel line pressure: 210—250 kPa {2.1—2.6 kgf/cm², 30—36 psi}</p>  <p>Pressure regulator vacuum hose disconnected 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}</p>  | <p>Yes Go to next step</p> <hr/> <p>No Check pressure regulator  page F2-78</p> |
| 6 | <p>Try a known good PCM; does condition improve?  page F2-106</p> | |





| 18 | ENGINE STALLS | • ON DECELERATION | |
|--|---|-------------------|--|
| DESCRIPTION <ul style="list-style-type: none"> • Engine stops unexpectedly at beginning of deceleration or recovery from deceleration • Exhaust afterburn | | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection ② Idle speed <ul style="list-style-type: none"> • Idle speed too low ③ Distributor <ul style="list-style-type: none"> • Poor connection of connector ④ Volume air flow sensor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ EGR valve <ul style="list-style-type: none"> • Solenoid valve stuck • EGR valve stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up? ↳ page F2-11 Idle speed: 600—700 (650 ± 50) rpm  | Yes | Go to step 3 |
| | | No | Remove System Selector and go to next step |
| 2 | Does idle speed drop in following conditions? Condition <ul style="list-style-type: none"> • Electrical loads ON • Air conditioner ON • P/S operating | Yes | Check follows; <ul style="list-style-type: none"> • Circuit from idle air control valve to PCM for open and short ↳ page F2-4 • Idle air control valve for sticking ↳ page F2-60 |
| | | No | Adjust idle speed ↳ page F2-11 |
| 3 | Is “NO CODES RECEIVED” displayed on SST with ignition switch ON? ↳ page F2-13 | Yes | “NO CODES RECEIVED” displayed Go to next step |
| | | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) ↳ page F2-13 “LINK COMMUNICATION ERROR” displays Refer to No.38 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 4 | Are volume air flow sensor connector terminals and connection good? | Yes | Verify that measuring core of volume air flow sensor moves smoothly <ul style="list-style-type: none"> • If OK, go to next step • If not OK, replace air flow sensor |
| | | No | Repair connector terminal |

| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 5 | Connect Engine Signal Monitor to PCM and set to position 3R Does following terminal voltage at PCM increase smoothly when vacuum applied to EGR valve? Terminal 3R voltage:  | Yes | Go to next step |
| | | No | Check EGR valve for sticking  page F2-88 |
| 6 | Are following terminals and connections good? • Distributor connector • Fuel pump connector • Main relay • PCM connector | Yes | Go to "ENGINE STALLS — ON DECELERATION" in section K1 of this manual |
| | | No | Repair connector terminal |



| | | | | | |
|---|---|-----|---|---|---|
| 19 20 21 | ENGINE RUNS ROUGH | | <ul style="list-style-type: none"> • IDLE AT ANY ENGINE TEMP/DURING FAST IDLE/ IDLE AFTER WARM-UP | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. • Idle speed too slow and excessive engine shake at any engine temp. • Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up | | | | |
| [TROUBLESHOOTING HINTS] | | | | | |
| <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged ② Fuel pump <ul style="list-style-type: none"> • Maximum pressure low ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection of connector ④ Air leakage <ul style="list-style-type: none"> • Leakage in intake-air system </td> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Volume airflow sensor <ul style="list-style-type: none"> • Measuring core stuck ⑦ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑨ BAC valve <ul style="list-style-type: none"> • Air valve stuck </td> </tr> </table> | | | | <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged ② Fuel pump <ul style="list-style-type: none"> • Maximum pressure low ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection of connector ④ Air leakage <ul style="list-style-type: none"> • Leakage in intake-air system | <ul style="list-style-type: none"> ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Volume airflow sensor <ul style="list-style-type: none"> • Measuring core stuck ⑦ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑨ BAC valve <ul style="list-style-type: none"> • Air valve stuck |
| <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) • Fuel injector(s) clogged ② Fuel pump <ul style="list-style-type: none"> • Maximum pressure low ③ Fuel pump relay <ul style="list-style-type: none"> • Poor connection of connector ④ Air leakage <ul style="list-style-type: none"> • Leakage in intake-air system | <ul style="list-style-type: none"> ⑤ Distributor <ul style="list-style-type: none"> • Cap and/or rotor damaged • Poor connection of connector ⑥ Volume airflow sensor <ul style="list-style-type: none"> • Measuring core stuck ⑦ Engine coolant temperature sensor <ul style="list-style-type: none"> • Poor connection of connector ⑧ EGR valve <ul style="list-style-type: none"> • EGR valve stuck ⑨ BAC valve <ul style="list-style-type: none"> • Air valve stuck | | | | |
| STEP | INSPECTION | | ACTION | | |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON? <div style="text-align: right;">📖 page F2-13</div> | Yes | "NO CODES RECEIVED" displayed <ul style="list-style-type: none"> • If symptom occurs at idle at any engine temp., go to next step • If symptom occurs during fast idle operation, go to step 9 • If symptom occurs at idle after warm-up, go to step 10 | | |
| | | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) <div style="text-align: right;">📖 page F2-13</div> "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" | | |
| 2 | Do Engine Signal Monitor lights flash for specified terminals while cranking engine? Terminal: 4Q, 4U, 4Y, 4AC, 4AG, 4AK | Yes | Go to next step | | |
| | | No | Check as follows according to results: Does not flash and 0V indicated for individual terminal(s) <ul style="list-style-type: none"> • Continuity of fuel injector(s) 📖 page F2-76 • Continuity between PCM and fuel injector(s) • Condition of injection connector and PCM connector Repair or replace parts and/or wiring harness as necessary | | |

| STEP | INSPECTION | | ACTION |
|------|---|------------|-------------------------------------|
| 3 | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | <p>Yes</p> | <p>Go to next step</p> |
| 4 | <p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p style="text-align: right;">☞ page F2-78</p> <p>Fuel line pressure: 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}</p>  | <p>Yes</p> | <p>Go to next step</p> |
| 5 | <p>Is there air leakage at intake air system components while racing engine to higher speed?</p> | <p>Yes</p> | <p>Repair or replace</p> |
| 6 | <p>Connect Engine Signal Monitor to PCM and set the position 3R Does following terminal voltage at PCM increase smoothly when vacuum applied to EGR control valve?</p> <p>Terminal 3R voltage:</p>  | <p>Yes</p> | <p>Go to next step</p> |
| 7 | <p>Is engine compression correct?</p> <p style="text-align: right;">☞ section B2</p> <p>Engine compression (minimum): 981 kPa {10.0 kgf/cm², 143 psi}/250 rpm</p> | <p>Yes</p> | <p>Go to next step</p> |
| | | <p>No</p> | <p>Check for cause ☞ section B2</p> |








| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 8 | Connect Engine Signal Monitor to PCM and set to position 3E Does following terminal voltage in PCM increase smoothly? ↳ page F2-106 Terminal 3E voltage: Approx. 4V (Ignition SW: ON) | Yes | Go to next step |
| | | No | Check follows: <ul style="list-style-type: none"> • Movement of measuring core in volume air flow sensor • Ground of volume air flow sensor • Continuity between volume air flow sensor and PCM connector • Condition in volume air flow sensor and PCM connector female terminals |
| 9 | Are spark plugs OK? ↳ section G  | Yes | <ul style="list-style-type: none"> • If symptom occurs at any engine temp., go to step 13 • If symptom occurs during fast idle operation, go to step 13 • If symptom occurs at idle after warmup, go to next step |
| | | No | Clean or replace |
| 10 | Is resistance of idle air control valve correct? Resistance: 10.7—12.3Ω [at 20°C {68°F}]  | Yes | Go to next step |
| | | No | Replace BAC valve ↳ page F2-60 |
| 11 | Try a known good BAC valve; does condition improve? | Yes | Replace BAC valve ↳ page F2-60 |
| | | No | Reinstall BAC valve Go to next step |
| 12 | Is heated oxygen sensor operation correct? ↳ page F2-121 | Yes | Go to next step |
| | | No | Check follows: <ul style="list-style-type: none"> • Poor connection of engine coolant temperature sensor connector • Incorrect installation of throttle position sensor |






| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 13 | Are fuel injectors OK? • No fuel leakage  page F2-76 • Fuel injectors not clogged  page F2-74 | Yes | Go to next step |
| | | No | Replace fuel injector  page F2-74 |
| 14 | Try a known good PCM; does condition improve?  page F2-106 | | |






| | | | |
|---|--|-----|--|
| 22 23 | ENGINE RUNS ROUGH | | <ul style="list-style-type: none"> • IDLE WITH A/C, P/S AND/OR E/L ON • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when A/C, P/S and/or E/L ON • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when shifted from P or N to other range | | |
| [TROUBLESHOOTING HINTS] | | | |
| <p>① Idle speed</p> <ul style="list-style-type: none"> • Idle speed too low <p>② E/L signal malfunction</p> <ul style="list-style-type: none"> • Air conditioning switch • Headlight switch • Rear window defroster switch • Fan switch <p>③ Idle air control valve</p> <ul style="list-style-type: none"> • Solenoid valve stuck | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up? 📖 page F2-11 Idle speed: 600—700 (650 ± 50) rpm | Yes | Go to next step |
| | | No | Adjust idle speed and go to next step 📖 page F2-11 |
| 2 | Is “NO CODES RECEIVED” displayed on SST with ignition switch ON? 📖 page F2-13 | Yes | “NO CODES RECEIVED” displayed Go to next step |
| | | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) 📖 page F2-13 “LINK COMMUNICATION ERROR” displays Refer to No.38 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 3 | Do following terminals voltage in PCM correct? 📖 page F2-106 <ul style="list-style-type: none"> • 1F Transaxle range switch (ATX) • 1G Foglight switch • 1L Headlight switch • 1K Fan switch • 1X Rear window defroster switch • 3T P/S pressure switch | Yes | If symptom occurs at idle when shifted from N or P to other range, go to next step |
| | | No | Check as follows: <ul style="list-style-type: none"> • Switch operation • Continuity between switch and PCM terminal After checking, go to step 5 |
| 4 | Warm-up engine Does idle speed change when idle air control valve connector disconnected? | Yes | <ul style="list-style-type: none"> • If symptom occurs at idle with A/C, P/S and/or E/L ON, go to next step • If symptom occurs at idle when shifted from N or P to other range, go to “ENGINE RUNS ROUGH — IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGE” in section K1 of this manual |
| | | No | Check idle air control valve for sticking 📖 page F2-60 |
| 5 | Does air conditioner operate continuously with ignition switch ON and A/C switch and blower switch OFF? | Yes | Check follows: <ul style="list-style-type: none"> • Malfunction of A/C relay 📖 1996 Mazda 626/MX-6 BETM • Wiring harness between A/C relay and PCM terminal 1D for short circuit 📖 page F2-106 |
| | | No | Go to next step |
| 6 | Try a known good PCM; does condition improve? 📖 page F2-106 | | |

| 24 | ENGINE RUNS ROUGH | • ON DECELERATION |
|--|--|---|
| DESCRIPTION <ul style="list-style-type: none"> • Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration • Exhaust afterburn | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ② Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) ③ Idle speed <ul style="list-style-type: none"> • Idle speed too low ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector ⑤ Volume air flow sensor <ul style="list-style-type: none"> • Poor connection of connector • Measuring core stuck ⑥ Idle air control valve <ul style="list-style-type: none"> • Solenoid valve stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Connect System Selector to data link connector and set test switch to SELF TEST; is idle speed correct after warm-up? 🔧 page F2-11 Idle speed: 600—700 (650 ± 50) rpm  | Yes: Go to step 3 No: Remove System Selector and go to next step |
| 2 | Does idle speed drop in following conditions? Condition: <ul style="list-style-type: none"> • Electrical loads ON • Air conditioner ON • P/S operating | Yes: Adjust idle speed 🔧 page F2-11 No: Check as follows: <ul style="list-style-type: none"> • Wiring harness from idle air control valve to PCM for short and open circuit 🔧 page F2-4 • Idle air control valve stuck 🔧 page F2-60 |
| 3 | Is “NO CODES RECEIVED” displayed on SST with ignition switch ON? 🔧 page F2-13 | Yes: “NO CODES RECEIVED” displayed Go to next step No: Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) 🔧 page F2-13 “LINK COMMUNICATION ERROR” displays Refer to No.38 “NGS DISPLAYS LINK COMMUNICATION ERROR” |
| 4 | Is there fuel leakage from fuel injector nozzles or injector holder? 🔧 page F2-75  | Yes: Reinstall or replace fuel injector 🔧 page F2-74 No: Go to next step |
| 5 | Are volume air flow sensor connector terminal and connection good? | Yes: Verify that measuring core of volume air flow sensor moves smoothly <ul style="list-style-type: none"> • If OK, go to next step • If not OK, replace volume air flow sensor No: Repair connector terminal |









| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 6 | Are following connections good? • Distributor connector • Fuel pump connector • Main relay • PCM connector | Yes | Go to next step |
| | | No | Repair connector terminal |
| 7 | Try a known good PCM; does condition improve? ↳ page F2-106 | Yes | Replace PCM |
| | | No | Go to "ENGINE RUNS ROUGH — ON DECELERATION" in section K1 of this manual |






| 25 26 | POOR ACCELERATION | <ul style="list-style-type: none"> • DRIVEAWAY • ON ACCELERATION |
|---|--|--|
| DESCRIPTION • Engine speed increases normally but vehicle speed slowly increases during driveaway or acceleration | | |
| [TROUBLESHOOTING HINTS] ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from fuel injector(s) ② Pressure regulator <ul style="list-style-type: none"> • Pressure regulator malfunction ③ Fuel filter <ul style="list-style-type: none"> • Clogged filter ④ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged ⑤ Volume airflow sensor <ul style="list-style-type: none"> • Poor connection of connector • Measuring core stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | Yes: "NO CODES RECEIVED" displayed Go to next step No: Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes: Check spark plugs ⇨ If OK, go to next step ⇨ If not OK, clean or replace spark plug No: Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor  section G • High-tension lead(s)  section G • Condition of distributor connector female terminals |
| 3 | Does measuring core in volume air flow sensor move smoothly?  page F2-115  | Yes: Check condition of volume air flow sensor connector female terminals ⇨ If OK, go to next step ⇨ If not OK, repair terminal No: Replace volume air flow sensor |
| 4 | Is intake manifold vacuum correct at idle? Vacuum: More than 60.0 kPa{450 mmHg, 17.7 inHg} | Yes: Go to next step No: Check follows: <ul style="list-style-type: none"> • Intake-air system components and installation • Vacuum hoses for disconnection and damage • Shutter valve actuator for damage |























| STEP | INSPECTION | ACTION |
|------|---|---|
| 5 | <p>Is fuel line pressure correct at idle?  page F2-78</p> <p>Fuel line pressure: 210—250 kPa {2.1—2.6 kgf/cm², 30—36 psi}</p>  | <p>Yes Go to next step</p> |
| | | <p>No Low pressure Check follows:</p> <ul style="list-style-type: none"> • Fuel filter for clogging • Operation of pressure regulator  page F2-78 • Fuel leakage from fuel injector(s)  page F2-75 |
| 6 | <p>Try a known good PCM; does condition improve?  page F2-106</p> | <p>Yes Replace PCM</p> |
| | | <p>No Go to "POOR ACCELERATION — DRIVEAWAY/ON ACCELERATION" in section K1 of this manual</p> |


| | | |
|---|--|--|
| 27 | HIGH IDLE SPEED AFTER WARM-UP | |
| DESCRIPTION | <ul style="list-style-type: none"> • Idle speed continues at fast idle after warm-up • Engine returns slowly to idle after accelerator is released | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Engine coolant temperature sensor</p> <ul style="list-style-type: none"> • Poor connection of connector <p>② Throttle position sensor</p> <ul style="list-style-type: none"> • Poor connection of connector • Incorrect adjustment <p>③ BAC valve</p> <ul style="list-style-type: none"> • Idle air control valve or air valve stuck | | |
| STEP | INSPECTION | ACTION |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | Yes "NO CODES RECEIVED" displayed Go to next step No Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Connect System Selector to the data link connector and set system select to position 1 Does idle speed down with the test switch SELF-TEST?  | Yes Check condition of engine coolant temperature sensor and throttle position sensor connector female terminals ⇨ If OK, go to next step ⇨ If not OK, repair female connector No Check if idle air control valve or air valve stuck ⇨ If OK, go to step 4 ⇨ If not OK, replace BAC valve |
| 3 | Is following terminal voltage at PCM correct? Terminal 3B: 0.1—1.1V (throttle valve closed throttle position) 2.8—4.5V (throttle valve wide open throttle) | Yes Go to next step No Adjust or replace throttle position sensor  page F2-117 |
| 4 | Try a known good PCM; does condition improve?  page F2-106 | |





B+: Battery positive voltage


| | | | | | | |
|---|---|--|-----|---|----|---|
| 28 | <ul style="list-style-type: none"> • IDLE FLUCTUATES • IDLE HUNTS | | | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed changes back and forth between specified idle speed and higher speed | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | |
| <ul style="list-style-type: none"> ① PCV valve <ul style="list-style-type: none"> • PCV valve stuck ② Spark plug <ul style="list-style-type: none"> • Spark plug(s) damaged ③ Throttle position sensor <ul style="list-style-type: none"> • Incorrect adjustment ④ Idle air control valve <ul style="list-style-type: none"> • Idle air control valve stuck | | | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | <table border="1"> <tr> <td data-bbox="714 483 787 556">Yes</td> <td data-bbox="787 483 1412 556"> "NO CODES RECEIVED" displayed Go to next step </td> </tr> <tr> <td data-bbox="714 556 787 724">No</td> <td data-bbox="787 556 1412 724"> Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" </td> </tr> </table> | Yes | "NO CODES RECEIVED" displayed Go to next step | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| Yes | "NO CODES RECEIVED" displayed Go to next step | | | | | |
| No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" | | | | | |
| 2 | Is following terminal voltage at PCM correct? Terminal 3X: Below 1.0V (accelerator pedal released) B+ (accelerator pedal depressed) | <table border="1"> <tr> <td data-bbox="714 724 787 987">Yes</td> <td data-bbox="787 724 1412 987"> Go to next step </td> </tr> <tr> <td data-bbox="714 987 787 1249">No</td> <td data-bbox="787 987 1412 1249"> Check follows: <ul style="list-style-type: none"> • Throttle position sensor adjustment  page F2-117 </td> </tr> </table> | Yes | Go to next step | No | Check follows: <ul style="list-style-type: none"> • Throttle position sensor adjustment  page F2-117 |
| Yes | Go to next step | | | | | |
| No | Check follows: <ul style="list-style-type: none"> • Throttle position sensor adjustment  page F2-117 | | | | | |
| 3 | Connect System Selector to data link connector and set system select to position 1 Does idle hunting stop when test switch to SELF-TEST?  | <table border="1"> <tr> <td data-bbox="714 1249 787 1470">Yes</td> <td data-bbox="787 1249 1412 1470"> Check follows: <ul style="list-style-type: none"> • Idle air control valve for sticking • Poor sealing between throttle body and BAC valve </td> </tr> <tr> <td data-bbox="714 1470 787 1661">No</td> <td data-bbox="787 1470 1412 1661"> Go to next step </td> </tr> </table> | Yes | Check follows: <ul style="list-style-type: none"> • Idle air control valve for sticking • Poor sealing between throttle body and BAC valve | No | Go to next step |
| Yes | Check follows: <ul style="list-style-type: none"> • Idle air control valve for sticking • Poor sealing between throttle body and BAC valve | | | | | |
| No | Go to next step | | | | | |

| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 4 | <p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  | Yes | <p>Check spark plug(s) ⇨ If OK, go to next step ⇨ If not OK, replace spark plug(s)</p> |
| | | No | <p>Check as follows: • Distributor cap and rotor for damage  section G</p> |
| 5 | <p>Is PCV valve stuck?</p> <p> page F2-78</p>  | Yes | <p>Replace PCV valve</p> |
| | | No | <p>Go to next step</p> |
| 6 | <p>Try a known good PCM; does condition improve?  page F2-106</p> | | |

| 29 | <ul style="list-style-type: none"> • HESITATES • STUMBLES ON ACCELERATION | | | | | |
|---|--|---|-----|---|----|--|
| DESCRIPTION • Momentary pause at beginning of acceleration or during acceleration | | | | | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Fuel injector <ul style="list-style-type: none"> • Fuel leakage from injector(s) ② Fuel pump <ul style="list-style-type: none"> • Poor connection of connector ③ Pressure regulator <ul style="list-style-type: none"> • Pressure regulator stuck ④ EGR valve <ul style="list-style-type: none"> • EGR control stuck ⑤ EGR solenoid valve (vacuum) <ul style="list-style-type: none"> • Solenoid valve stuck ⑥ Distributor <ul style="list-style-type: none"> • Poor connection of connector • Cap and/or rotor damaged ⑦ High-tension lead(s) <ul style="list-style-type: none"> • Lead(s) damaged ⑧ Volume air flow sensor <ul style="list-style-type: none"> • Poor connection of connector • Measuring core stuck ⑨ Throttle position sensor <ul style="list-style-type: none"> • Poor connection of connector | | | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON?  page F2-13 | <table border="0"> <tr> <td data-bbox="743 613 800 674">Yes</td> <td data-bbox="805 613 1412 674"> "NO CODES RECEIVED" displayed Go to next step </td> </tr> <tr> <td data-bbox="743 680 800 842">No</td> <td data-bbox="805 680 1412 842"> Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" </td> </tr> </table> | Yes | "NO CODES RECEIVED" displayed Go to next step | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| Yes | "NO CODES RECEIVED" displayed Go to next step | | | | | |
| No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence)  page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" | | | | | |
| 2 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | <table border="0"> <tr> <td data-bbox="743 848 800 1024">Yes</td> <td data-bbox="805 848 1412 1024"> Go to next step </td> </tr> <tr> <td data-bbox="743 1031 800 1255">No</td> <td data-bbox="805 1031 1412 1255"> Check follows: <ul style="list-style-type: none"> • Distributor cap and rotor for damage  section G • High-tension lead(s) for damage  section G • Condition of distributor connector female terminals </td> </tr> </table> | Yes | Go to next step | No | Check follows: <ul style="list-style-type: none"> • Distributor cap and rotor for damage  section G • High-tension lead(s) for damage  section G • Condition of distributor connector female terminals |
| Yes | Go to next step | | | | | |
| No | Check follows: <ul style="list-style-type: none"> • Distributor cap and rotor for damage  section G • High-tension lead(s) for damage  section G • Condition of distributor connector female terminals | | | | | |
| 3 | Is fuel line pressure correct at idle?  page F2-78 Fuel line pressure: 210—250 kPa {2.1—2.6 kgf/cm ² , 30—36 psi}  | <table border="0"> <tr> <td data-bbox="743 1262 800 1402">Yes</td> <td data-bbox="805 1262 1412 1402"> Go to next step </td> </tr> <tr> <td data-bbox="743 1409 800 1703">No</td> <td data-bbox="805 1409 1412 1703"> Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator  page F2-78 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure  page F2-71 </td> </tr> </table> | Yes | Go to next step | No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator  page F2-78 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure  page F2-71 |
| Yes | Go to next step | | | | | |
| No | Low pressure Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> • If pressure quickly increases, check pressure regulator  page F2-78 • If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose not clogged, check fuel pump maximum pressure  page F2-71 | | | | | |
| 4 | Does fuel pressure increase when throttle valve opened? | <table border="0"> <tr> <td data-bbox="743 1709 800 1770">Yes</td> <td data-bbox="805 1709 1412 1770"> Go to next step </td> </tr> <tr> <td data-bbox="743 1776 800 1831">No</td> <td data-bbox="805 1776 1412 1831"> Check pressure regulator  page F2-78 </td> </tr> </table> | Yes | Go to next step | No | Check pressure regulator  page F2-78 |
| Yes | Go to next step | | | | | |
| No | Check pressure regulator  page F2-78 | | | | | |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 5 | Disconnect vacuum hose from EGR valve and plug it; does condition improve? | Yes | Check follows: <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) for sticking • EGR solenoid valve (vent) for sticking • Condition of solenoid valve connectors female terminals |
| | | No | Go to next step |
| 6 | Connect Engine Signal Monitor to PCM and set the position 3R. Is following terminal voltage at PCM increase smoothly when vacuum applied to EGR valve? Terminal 3R voltage: | Yes | Go to next step |
| |  | No | Check EGR valve for sticking ➔ page F2-88 |
| 7 | Is following terminal voltage at PCM correct? 3E terminal: Approx. 4V (ignition switch ON) Approx. 2.8V (idle) | Yes | Verify that measuring core of volume air flow sensor moves smoothly <ul style="list-style-type: none"> • If OK, go to next step • If not OK, replace volume air flow sensor |
| | | No | Check condition of volume air flow sensor and PCM connectors female terminals <ul style="list-style-type: none"> • If OK, replace volume air flow sensor • If not OK, repair female terminal |

| STEP | INSPECTION | ACTION |
|------|---|--|
| 8 | Is terminal 3B voltage at PCM correct? 3B terminal: 0.1—1.1V (throttle valve closed throttle position) 2.8—4.5V (throttle valve wide open throttle) | Yes Go to next step |
| | | No Check female terminal condition in throttle position sensor connector and PCM connector <ul style="list-style-type: none"> • If OK, replace throttle position sensor  page F2-117 • If not OK, repair female terminal |
| 9 | Is there fuel leakage from fuel injector(s)? Fuel leakage: Less than 1 drop/2 min.  | Yes Check follows: <ul style="list-style-type: none"> • Poor installation of fuel injector  page F2-74 |
| | | No Go to next step |
| 10 | Try a known good PCM; does condition improve?  page F2-106 | |

| | | | |
|--------------------------------|---|--------------------------------|---|
| 30 | SURGES WHILE CRUISING | | |
| DESCRIPTION | • Momentary minor irregularity in engine output at steady vehicle speed. | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Fuel injector | | ③ Volume air flow sensor | |
| • Poor connection of connector | | • Poor connection of connector | |
| ② Spark plug | | • Measuring core stuck | |
| • Spark plug(s) damaged | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "NO CODES RECEIVED" displayed on SST with ignition switch ON? ➡ page F2-13 | Yes | "NO CODES RECEIVED" displayed Go to next step |
| | | No | Diagnostic Trouble Code No. displayed Check for cause (Refer to specified check sequence) ➡ page F2-13 "LINK COMMUNICATION ERROR" displays Refer to No.38 "NGS DISPLAYS LINK COMMUNICATION ERROR" |
| 2 | Connect Engine Signal Monitor to PCM and set to position 3E Does output voltage of volume air flow sensor gradually increase in conjunction with increase of engine speed? | Yes | Go to next step |
| | | No | Check follows: • Smooth movement of measuring core in volume air flow sensor • Condition of volume air flow sensor and PCM connectors female terminals |
| 3 | Does idle become rough when shaking connector of fuel injector? | Yes | Check as follows: • Condition of fuel injector and PCM connectors female terminals |
| | | No | Go to next step |
| 4 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plug(s) for damage ⇨ If OK, go to next step ⇨ If not OK, replace spark plug(s) |
| | | No | Check follows: • Distributor cap and rotor for damage ➡ section G |
| 5 | Try a known good PCM; does condition improve? ➡ page F2-106 | Yes | Replace PCM |
| | | No | Go to "SURGES WHILE CRUISING" in section K1 of this manual |

| | | |
|---|---|--------------|
| 31 | LACK OF POWER | |
| DESCRIPTION • Performance poor under load (i.e., power down when climbing hills) | | |
| [TROUBLESHOOTING HINTS] | | |
| ① Volume air flow sensor | <ul style="list-style-type: none"> • Open or short circuit in wiring of intake air temperature sensor (Code No.P0110 output) • Poor connection of connector | 📖 page F2-13 |
| ② Distributor | <ul style="list-style-type: none"> • Damaged distributor cap or rotor | 📖 section G |
| ③ Fuel injector | <ul style="list-style-type: none"> • Fuel injector harness shorted to ground | |
| ④ Fuel filter | <ul style="list-style-type: none"> • Clogged filter | |
| ⑤ Air cleaner element | <ul style="list-style-type: none"> • Clogged element | 📖 page F2-54 |
| ⑥ Three way catalytic converter | <ul style="list-style-type: none"> • Clogged three way catalytic converter | 📖 page F2-82 |

| | | |
|--|--|-----------------------------|
| 32 | POOR FUEL ECONOMY | |
| DESCRIPTION • Fuel economy unsatisfactory | | |
| [TROUBLESHOOTING HINTS] | | |
| ① Air leakage | <ul style="list-style-type: none"> • Poor installation of air intake hose, throttle body, intake manifold and/or EGR valve • Vacuum hose damaged or disconnected | 📖 page F2-3 |
| ② Oxygen sensor | <ul style="list-style-type: none"> • Open in harness (Code No.P0130, P0134, P0140, P0150, P0154, P0160 output) | 📖 page F2-13 |
| ③ Pressure regulator | <ul style="list-style-type: none"> • Hold fuel pressure high • Vacuum hose disconnected or damaged | 📖 page F2-67 📖 page F2-3 |

| | | |
|---|---|----------------------------|
| 33 | A/C DOES NOT WORK | |
| DESCRIPTION • A/C compressor magnetic clutch does not engage with air conditioning switch ON | | |
| [TROUBLESHOOTING HINTS] | | |
| ① A/C relay | <ul style="list-style-type: none"> • Poor connection of connector • Relay malfunction | 📖 1996 Mazda 626/MX-6 BETM |
| ② PCM | <ul style="list-style-type: none"> • Does not send signal to A/C relay with ignition switch ON | 📖 page F2-106 |

| | | |
|--|---|--------------|
| 34 | <ul style="list-style-type: none"> • KNOCKING • PINGING | |
| DESCRIPTION • Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | | |
| [TROUBLESHOOTING HINTS] | | |
| Knock sensor | | |
| <ul style="list-style-type: none"> • Open or short in harness (Code No.P0325 output) | | 📖 page F2-13 |

| | |
|--|--|
| 35 | FUEL ODOR |
| DESCRIPTION | • Gasoline fuel smell or visible leaks |
| [TROUBLESHOOTING HINTS] | |
| ① Purge solenoid valve <ul style="list-style-type: none"> • Open or short in harness (Code No.P0443 output) | |
| ① Charcoal canister <ul style="list-style-type: none"> • Canister full of fuel and leaking | |
| 📖 page F2-13 | |

| | |
|--------------------------------|--|
| 36 | EXHAUST SULFUR SMELL |
| DESCRIPTION | • Rotten egg smell (sulfur) from exhaust |
| [TROUBLESHOOTING HINTS] | |
| High sulfur content fuel used | |

| | |
|--|-----------------------------|
| 37 | HIGH OIL CONSUMPTION |
| DESCRIPTION | • Oil consumption excessive |
| [TROUBLESHOOTING HINTS] | |
| PCV valve | |
| <ul style="list-style-type: none"> • PCV valve stuck open | |
| 📖 page F2-90 | |

| | |
|--|--|
| 38 | NGS DISPLAYS "LINK COMMUNICATION ERROR" |
| DESCRIPTION | • NGS displays "LINK COMMUNICATION ERROR" |
| [TROUBLESHOOTING HINTS] | |
| ① Open or short circuit in wiring DLC2 terminal KLN and PCM terminal 1Y | |
| ② PCM | |
| <ul style="list-style-type: none"> • Vref terminal open or short • Open or short circuit in wiring between main relay and PCM terminal 4A • Open circuit in wiring between earth point and PCM ground terminals | |
| 📖 page F2-4 | |

| | |
|---------------------------------|--|
| 39 | MIL NEVER ON |
| DESCRIPTION | • NGS displays diagnostic trouble codes but MIL never ON |
| [TROUBLESHOOTING HINTS] | |
| ① Bulb burnt | |
| ② PCM 1AH terminal circuit open | |


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

FUEL AND EMISSION CONTROL SYSTEMS (FS ATX)


| | | | |
|---------------------------------------|--------|---|--------|
| OUTLINE | F3- 2 | EGR SOLENOID VALVE (VENT) | F3-131 |
| SYSTEM DIAGRAM | F3- 2 | EGR VALVE | F3-132 |
| VACUUM HOSE ROUTING | | EGR BOOST SENSOR SWITCHING | |
| DIAGRAM | F3- 3 | CONTROL SYSTEM | F3-132 |
| WIRING DIAGRAM | F3- 4 | SYSTEM INSPECTION | F3-132 |
| SPECIFICATIONS | F3- 6 | EGR BOOST SENSOR SOLENOID | |
| COMPONENT DESCRIPTIONS | F3- 7 | VALVE | F3-132 |
| ENGINE TUNE-UP | F3- 10 | POSITIVE CRANKCASE VENTILATION (PCV) | |
| PREPARATION | F3- 10 | SYSTEM | F3-133 |
| ADJUSTMENT | F3- 11 | DESCRIPTION | F3-133 |
| ON-BOARD DIAGNOSTIC SYSTEM .. | F3- 13 | PCV VALVE | F3-133 |
| DESCRIPTION | F3- 13 | FUEL EVAPORATIVE SYSTEM | F3-134 |
| PREPARATION | F3- 14 | DESCRIPTION | F3-134 |
| ON-BOARD DIAGNOSTIC TEST | F3- 14 | PREPARATION | F3-135 |
| DIAGNOSTIC TROUBLE CODE | F3- 19 | SYSTEM INSPECTION | F3-136 |
| INTAKE-AIR SYSTEM | F3-102 | PURGE SOLENOID VALVE | F3-137 |
| COMPONENT PARTS | F3-102 | FUEL VAPOR VALVE | F3-137 |
| THROTTLE BODY | F3-103 | CHECK VALVE (TWO-WAY) | F3-137 |
| INTAKE MANIFOLD | F3-103 | CHARCOAL CANISTER | F3-138 |
| RESONANCE CHAMBER | F3-103 | FUEL-CUT CONTROL SYSTEM | F3-139 |
| ACCELERATOR PEDAL | F3-104 | DESCRIPTION | F3-139 |
| ACCELERATOR CABLE | F3-104 | PREPARATION | F3-140 |
| IDLE AIR CONTROL SYSTEM | F3-105 | SYSTEM INSPECTION | F3-141 |
| DESCRIPTION | F3-105 | A/C CUTOFF SYSTEM | F3-142 |
| PREPARATION | F3-106 | DESCRIPTION | F3-142 |
| SYSTEM INSPECTION | F3-107 | PREPARATION | F3-143 |
| IDLE AIR CONTROL VALVE | F3-108 | SYSTEM INSPECTION | F3-143 |
| AIR VALVE | F3-108 | DECHOKE CONTROL SYSTEM | F3-144 |
| FUEL SYSTEM | F3-109 | SYSTEM INSPECTION | F3-144 |
| DESCRIPTION | F3-109 | COOLING FAN CONTROL SYSTEM .. | F3-144 |
| PREPARATION | F3-109 | DESCRIPTION | F3-144 |
| SYSTEM INSPECTION | F3-110 | PREPARATION | F3-145 |
| FUEL TANK | F3-112 | SYSTEM INSPECTION | F3-146 |
| FUEL FILTER | F3-113 | CONTROL SYSTEM | F3-148 |
| FUEL PUMP | F3-114 | PREPARATION | F3-148 |
| FUEL PUMP RELAY | F3-117 | STRUCTURAL VIEW | F3-149 |
| PRESSURE REGULATOR | F3-117 | POWERTRAIN CONTROL MODULE | |
| FUEL INJECTOR | F3-119 | (PCM) | F3-150 |
| PRESSURE REGULATOR CONTROL | | MASS AIR FLOW SENSOR | F3-157 |
| SYSTEM | F3-122 | CAMSHAFT POSITION SENSOR ... | F3-158 |
| DESCRIPTION | F3-122 | CRANKSHAFT POSITION SENSOR | F3-158 |
| PREPARATION | F3-123 | THROTTLE POSITION SENSOR ... | F3-159 |
| SYSTEM INSPECTION | F3-124 | ENGINE COOLANT TEMPERATURE | |
| PRC SOLENOID VALVE | F3-126 | SENSOR | F3-162 |
| EXHAUST SYSTEM | F3-127 | INTAKE AIR TEMPERATURE | |
| COMPONENT PARTS | F3-127 | SENSOR | F3-163 |
| OUTLINE OF EMISSION CONTROL | | HEATED OXYGEN SENSOR | F3-163 |
| SYSTEM | F3-128 | EGR VALVE POSITION SENSOR ... | F3-164 |
| STRUCTURAL VIEW | F3-128 | EGR BOOST SENSOR | F3-165 |
| EXHAUST GAS RECIRCULATION | F3-129 | P/S PRESSURE SWITCH | F3-166 |
| DESCRIPTION | F3-129 | MAIN RELAY | F3-166 |
| OPERATION | F3-129 | TROUBLESHOOTING GUIDE | F3-167 |
| PREPARATION | F3-130 | USING THIS SECTION | F3-167 |
| SYSTEM INSPECTION | F3-130 | DIAGNOSTIC INDEX | F3-169 |
| EGR SOLENOID VALVE (VACUUM) . | F3-131 | SYMPTOM TROUBLESHOOTING .. | F3-171 |

OUTLINE

SYSTEM DIAGRAM





VACUUM HOSE ROUTING DIAGRAM



F3

WIRING DIAGRAM





F3

SPECIFICATIONS

| Item | | Engine/Transaxle | FS ATX |
|--|--------------------|---------------------------------|--------------------------------------|
| Idle speed (Target speed) | | rpm | 650—750 (700 ± 50) |
| Ignition timing (Target timing) | | BTDC | 11—13° (12 ± 1°) |
| Throttle body | | | |
| Type | | | Horizontal draft |
| Throat diameter | | mm {in} | 55 {2.2} |
| Fuel pump | | | |
| Maximum output pressure | | kPa {kgf/cm ² , psi} | 640 {6.5, 92} |
| Fuel filter | | | |
| Type | Low-pressure side | | Nylon element (in fuel pump) |
| | High-pressure side | | Paper element |
| Pressure regulator | | | |
| Regulating pressure | | kPa {kgf/cm ² , psi} | 260—320 {2.6—3.3, 37—46} |
| Fuel injector | | | |
| Type | | | High-ohmic |
| Type of drive | | | Voltage |
| Resistance | | Ω 20°C {68°F} | 12—16 |
| Volume | | ml {cc, fl oz}/15 sec. | 47—68 {47—68, 1.4—2.0} |
| Idle air control valve | | | |
| Resistance | | Ω 23°C {73°F} | 7.7—9.3 |
| Purge solenoid valve | | | |
| Resistance | | Ω 20°C {68°F} | 30—34 |
| Pressure regulator control solenoid valve | | | |
| Resistance | | Ω 20°C {68°F} | 36—43 |
| EGR solenoid valve (vent and vacuum) | | | |
| Resistance | | Ω 20°C {68°F} | 30—45 |
| Camshaft position sensor | | | |
| Type | | | Hall element |
| Mass air flow sensor | | | |
| Type | | | Hot wire |
| Engine coolant temperature sensor | | | |
| Resistance | | kΩ 20°C { 68°F} | 35.473—39.207 |
| | | 60°C {140°F} | 7.171—7.925 |
| Fuel tank | | | |
| Capacity | | L {US gal, Imp gal} | 58.5 {15.5, 12.9} |
| Air cleaner element | | | |
| Element type | | | Oil permeated |
| Fuel | | | |
| Specification | | | Unleaded—(R+M)/2 method 87 or higher |

COMPONENT DESCRIPTIONS

| Component | Function | Remark |
|--|--|--|
| A/C relay | Controls A/C compressor magnetic clutch | — |
| Air cleaner | Filters air entering throttle body | <ul style="list-style-type: none"> • Intake air temperature sensor mounted in air cleaner |
| Air valve | Supplies bypass air into intake manifold (engine cold) | <ul style="list-style-type: none"> • Engine speed increased to shorten warm-up period • Thermowax type • Installed in BAC valve |
| Brake switch | Detects braking; sends signal to PCM | — |
| Bypass air control (BAC) valve | Supplies bypass air into intake manifold | <ul style="list-style-type: none"> • Consists of air valve and idle air control valve |
| Camshaft position sensor [SGC signal] | Detects No.1 cylinder TDC; sends signal to PCM | <ul style="list-style-type: none"> • Installed in distributor |
| Charcoal canister | Stores fuel tank fumes (engine stopped) | — |
| Check valve (two-way) | Controls pressure in fuel tank | — |
| Closed throttle position switch | Detects idle condition; sends signal to PCM | <ul style="list-style-type: none"> • Installed in throttle body |
| Crankshaft position sensor [NE signal] | Detects crank angle via crankshaft pulley rotation, and sends signal to PCM | — |
| Data link connector-2 | Concentrated service connector terminals for diagnosis of electrical system | <ul style="list-style-type: none"> • For on-board diagnosis and service/inspection |
| EGR boost sensor | Detects EGR pipe pressure or barometric pressure and sends signal to PCM | <ul style="list-style-type: none"> • For EGR boost sensor switching control |
| EGR boost sensor solenoid valve | Supplies/cuts off EGR pipe pressure or barometric pressure to EGR boost sensor | <ul style="list-style-type: none"> • For EGR boost sensor switching control |
| EGR valve | Recirculates portion of exhaust gas | — |
| EGR solenoid valves | Controls vacuum to EGR valve | — |
| EGR valve position sensor | Detects EGR valve position | <ul style="list-style-type: none"> • Installed in EGR valve |

F3

| Component | Function | Remark |
|-----------------------------------|---|---|
| Powertrain control module | <p>Detects the following:</p> <ol style="list-style-type: none"> 1. A/C operation 2. Air/fuel ratio (oxygen concentration) 3. Braking signal 4. Crankshaft position 5. E/L operation 6. Engine coolant temperature 7. Ignition ON signal 8. In-gear condition 9. Intake air amount 10. Intake air temperature 11. No.1 piston TDC (compression stroke) 12. P/S operation 13. Throttle valve opening angle 14. Throttle valve closed throttle position 15. Vehicle speed <p>Controls operation of following:</p> <ol style="list-style-type: none"> 1. A/C (cut-off) 2. On-board diagnostic system 3. Fuel injection system 4. Idle speed control 5. Ignition system 6. Purge control system 7. Exhaust gas recirculation 8. Pressure regulator control system 9. Cooling fan control 10. Fuel pump control | <ol style="list-style-type: none"> 1. Air conditioning switch 2. Heated oxygen sensor 3. Brake light switch 4. Crankshaft position and engine speed 5. Fan switch, cooling fan relay, headlight switch, and rear window defroster switch 6. Engine coolant temperature sensor 7. Ignition switch 8. Neutral and clutch switch 9. Mass air flow sensor 10. Intake air temperature sensor 11. Camshaft position sensor (SGC signal) 12. P/S pressure switch 13. Throttle position sensor 14. Closed throttle position switch 15. Vehicle speedometer sensor <ol style="list-style-type: none"> 1. A/C relay 2. NGS 3. Fuel injector 4. Idle air control valve 5. Ignition control module 6. Purge solenoid valve 7. EGR solenoid valves 8. PRC solenoid valve 9. Cooling fan relay 10. Fuel pump relay |
| Engine coolant temperature sensor | Detects engine coolant temperature; sends signals to PCM | <ul style="list-style-type: none"> • Installed in engine |
| Fuel filter | Filters particles from fuel | — |
| Fuel injector | Injects fuel into intake port | <ul style="list-style-type: none"> • Controlled by signals from PCM |
| Fuel pump | Provides fuel to fuel injectors | <ul style="list-style-type: none"> • Operates while engine is running • Installed in fuel tank |
| Fuel pump relay | Voltage for fuel pump while engine is running, controlled by PCM | — |
| Fuel vapor valve | Prevents fuel from flowing into charcoal canister | — |
| Heated oxygen sensor | Detects oxygen concentration; sends signal to PCM | <ul style="list-style-type: none"> • Zirconic and platinum coating • With heater |
| Idle air control valve | Supplies bypass air to intake manifold | <ul style="list-style-type: none"> • Controlled by duty signal from PCM • Installed in BAC valve |
| Intake manifold | Supplies intake air to all cylinders | — |
| Intake air temperature sensor | Detects intake air temperature; sends signal to PCM | <ul style="list-style-type: none"> • Installed in air cleaner |
| Main relay | Supplies current to output devices and PCM | — |
| Mass air flow sensor | Detects amount of intake air; sends signal to PCM | <ul style="list-style-type: none"> • Hot wire type |
| PCV valve | Controls blowby gas introduced into engine | — |








| Component | Function | Remark |
|--------------------------------------|--|---|
| PRC solenoid valve | Controls vacuum to pressure regulator | — |
| Pressure regulator | Adjusts fuel pressure supply to fuel injectors | — |
| Purge solenoid valve | Controls evaporative fumes from charcoal canister to intake manifold | <ul style="list-style-type: none"> Controlled by duty signal from PCM |
| P/S pressure switch | Detects P/S operation; sends signal to PCM | <ul style="list-style-type: none"> P/S pressure switch ON when steering wheel turned |
| Resonance chamber | Reduces intake air suction noise and increases engine torque | — |
| Three way catalytic converter | Reduces HC, CO, NOx by chemical reaction | <ul style="list-style-type: none"> Monolith type |
| Throttle body | Controls intake air amount | — |
| Throttle position sensor | Detects throttle valve opening angle; sends signal to PCM | <ul style="list-style-type: none"> Installed on throttle body |
| Transaxle range switch | Detects in-gear condition; sends signal to PCM | — |
| Vehicle speed sensor | Detects vehicle speed; sends signal to PCM | <ul style="list-style-type: none"> Installed in automatic transaxle |

F3

ENGINE TUNE-UP


PREPARATION

SST

| | | | |
|--|---|--|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of ignition timing and idle speed</p> | <p>—</p> | <p>—</p> |

ADJUSTMENT**Preparation**

1. Warm up the engine to normal operating temperature.
2. Shift the selector lever to P range.
3. Turn off all electrical loads.
 - Headlight
 - Blower
 - Rear window defroster
 - Power steering
4. Wait until the cooling fan stops.



5. Connect the **SST** (NGS) to the data link connector-2 and select the "PID/DATA MONITOR AND RECORD" function. (Refer to page F3-151.)

Ignition Timing

1. Perform Preparation. (Refer to above.)
2. Connect a timing light to the engine.
3. Verify that the ignition timing is within specification.

Specification: BTDC 6—18°

4. If the ignition timing is not within specification, check the installation of distributor. (Refer to section G)

Idle Speed

1. Perform Preparation. (Refer to above.)
2. Using the **SST** (NGS), verify that the idle speed is within the specification.

Idle speed (P range): 650—750 (700 ± 50) rpm

3. If not within the specification, race the engine and operate the A/C with no load.
4. Stop racing and the A/C, and check the idle speed.
5. Idle speed below the specification
 - Disconnect the IAC valve connector and check the engine speed.
 - (1) If the engine speed does not change, inspect the IAC solenoid valve. (Refer to page F3-108.)
 - (2) If the engine speed changes excessively (due to engine stall), inspect the PCM and related wiring harness and connectors.

Idle speed over the specification

- Disconnect the IAC valve connector and check the engine speed.
- (1) If the engine speed does not change, adjust with the air adjusting screw (AAS).

Idle speed (P range): 650—750 (700 ± 50) rpm

- (2) If the engine speed changes excessively, inspect the PCM and related wiring harnesses and connectors.

Caution

- **The throttle adjusting screw is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.**

Idle-up Speed

1. Perform Preparation. (Refer to page F3-11.)
2. Verify that the idle speed is within the specification.

Specification: 650—750 (700 ± 50) rpm

3. If not within the specification, adjust the idle speed.
4. Check the idle speed with the following load conditions.

| Load condition | Idle speed (rpm) |
|---------------------------------|------------------|
| No load | 650—750 |
| Cooling fan ON | 675—775 |
| Fan switch ON at 3rd or higher | 675—775 |
| Head light switch ON | 675—775 |
| Rear window defroster switch ON | 675—775 |
| P/S ON | 650—750 |
| A/C ON | 725—825 |

Note

- Excludes temporary idle speed drop just after the electrical loads are turned ON.
5. If not as specified with all load conditions, inspect the idle air control valve.
If not as specified with any one of load conditions, check related input switches, harnesses and connectors.

ON-BOARD DIAGNOSTIC SYSTEM

DESCRIPTION

Quick Test Description

Quick Test is divided into three special tests: Key On Engine Off Self-Test, Key On Engine Running Self-Test and Continuous Memory DTC access. Quick Test also provides a quick check of the powertrain control system and is usually performed at the start of each diagnostic procedure and at the end of most pinpoint tests for verification of repair and to ensure no other faults exist.

Key On Engine Off Self-Test

Key On Engine Off is a functional test of the powertrain control system performed on demand. A fault has to be present at the time of testing for the Key On Engine Off Self-Test to detect the fault. When a fault is detected, a Diagnostic Trouble Code (DTC) will be output on the data link when requested by a scan tool.

Key On Engine Running Self-Test

Key On Engine Running is a functional test of the powertrain control system performed on demand with the engine running and vehicle stopped. A check of the inputs and outputs is made during operating conditions and at normal temperature. A fault has to be present at the time of testing. When a fault is detected, a Diagnostic Trouble Code (DTC) will be output on the data link when requested by a scan tool.

Continuous Memory DTC Access Self-Test

Continuous Memory DTC access is also a functional test of the powertrain control system. The Continuous Memory self-test is always active. The test consists of all the OBD II monitors and the comprehensive component monitor, and is designed to detect failures contributing to driveability and emission concerns. As part of Quick Test, the technician may perform a specific drive cycle before running Quick Test. This is necessary to detect certain faults not tested during other self-test operations. All self-tests are menu driven in the New Generation Star (NGS) scan tool.

Parameter Identification (PID) Access

The PID mode allows access to certain data values, analog and digital inputs and outputs, calculated values, and system status information.

Brake On/Off Test

On vehicles equipped with Brake On/Off (BOO) input, the brake pedal **MUST** be depressed and released after the Key On Engine Running self-test is initiated.









O/D OFF Switch Test



On vehicles equipped with an O/D OFF switch, the switch **MUST** be cycled after the Key On Engine Running self-test is initiated.

Wiggle/Tap Test

The wiggle/tap test is performed by the technician in an attempt to re-create an intermittent fault.

PREPARATION SST

| | | | |
|---|--|---|--|
| <p>49 UN01 130 104 Pin Breakout Box</p>  | <p>For inspection of PCM terminal voltage</p> | <p>49 T088 0A0 NGS set</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |








ON-BOARD DIAGNOSTIC TEST

New Generation Star (NGS) Hook-up Procedure

Note

- Make sure Key is Off.

1. Insert the vehicle interface module and program card into the **SST** (NGS) control unit.
2. Plug the NGS OBD II adapter into the interface module and the large 5 pin connector into the vehicle data link connector-2 (DLC-2) located under the dash to left of the center console.
3. Plug the (NGS) tester power cable into the cigarette lighter or use a battery hook-up adapter.
4. Listen for a double beep. The **SST** (NGS) is now initialized. Begin the functional test of powertrain control system.



Key On Engine Off Quick-Test Procedure

Note

- Start the engine and bring up to operating temperature before running the Quick-Test.

1. Perform the necessary vehicle preparation and visual inspection (Refer to page F3-10.). Hook-up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selections.
3. Select vehicle year and model.
4. Select diagnostic data link.
5. Select PCM.






6. Select diagnostic test mode.
7. Select key ON engine off on-demand self-test.
8. Turn the key ON. Press start and trigger. Follow the operating procedures from the menu.

Key On Engine Running Quick-Test Procedure

Note

- Start the engine and bring up to normal operating temperature before running the Quick-Test.

1. Perform the necessary vehicle preparation and visual inspection (Refer to page F3-10.). Hook-up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.



6. Select diagnostic test mode.
7. Select key ON engine running on-demand self-test.
8. Start the vehicle. Press start and trigger.
9. Follow the operating instructions from the menu and perform BOO, and O/D OFF switch cycling, if equipped.

Accessing All Continuous Memory DTC's Procedure

Note

- Start the engine and bring up to operating temperature before running the Quick-Test.


1. Perform the necessary vehicle preparation and visual inspection (Refer to page F3-10.). Hook the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection menu.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.
6. Select Diagnostic test mode.
7. Select Retrieve/Clear continuous DTC's.
8. Turn the key ON. Press start.
9. Follow the operating instruction from the menu.

Output Control Test Procedure


Note

- Start the engine and bring up to operating temperature before running the Output Control Test.

1. Perform the necessary vehicle preparation and visual inspection. (Refer to page F3-10.). Hook up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection.
3. Select vehicle year and model.
4. Select diagnostic data link.
5. Select PCM.



6. Select diagnostic test mode.
7. Select active tests.
8. Select output control.
9. Turn the key ON. Press start and trigger. Follow the operating instructions from the menu.



After Repair Procedure


1. Connect the **SST** (NGS) to the Data Link Connector.
2. Select Clear codes function and clear the DTC's.
3. Perform Quick-Test to ensure that the customer's concern has been resolved. If DTC P1000 is present, go to the DTC P1000 chart.

OBD II Drive Cycle

Note

- Only perform this procedure when instructed to do so.

1. Start and warm the engine until the engine coolant temperature is over 82°C {180°F}.
2. Drive the vehicle or let it idle for four minutes.
3. Stop the vehicle and let it idle for 40 seconds.
 - D range
4. Open the throttle 1/4—1/2 and increase the speed to 25 km/h {40 mph} for 10 seconds.
5. Fix the throttle opening and drive the vehicle at 25 km/h {40 mph} for 30 seconds.
6. Stop the vehicle and let it idle for 40 seconds.
 - D range
7. Drive the vehicle at 22 km/h {35 mph} for four minutes.
8. Stop the vehicle and let it idle for 30 seconds.
9. Drive the vehicle at 19 km/h {30 mph} for six minutes.
10. Stop the vehicle and let it idle for 30 seconds.
11. Drive the vehicle at 16—25 km/h {25—40 mph} for three minutes while observing the following condition.
 - a. Stop and idle for 10 seconds at least five times.
 - b. The throttle opening is 1/4—1/2 when accelerating from idle.
 - c. Shift between three different speeds while driving at 16—25 km {25—40 mph}.
12. Drive the vehicle at a constant speed between 16—25 km/h {25—30 mph} for one minute.
13. Within eight seconds, accelerate to 35—37 km/h {55—60 mph}.
14. Drive the vehicle at a constant speed between 35—37 km/h {55—60 mph} for two minutes.




Accessing OBD II PID Mode Procedure

Note

- Start the engine and bring up to operating temperature before running the Quick-Test.




1. Hook-up the **SST** (NGS).
2. Select vehicle and engine selection menu.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.
6. Select PID/DATA MONITOR AND RECORD.
7. Turn the key ON or start the engine.



8. Select the PID values to view and press the trigger.
9. Select start to begin.

Note

- Refer to the manufacturer provided instruction manual for other NGS diagnostic testing procedures.



DIAGNOSTIC TROUBLE CODE

Note

- If the DTC that you want to find is not in the following chart, please refer to the “Diagnostic Trouble Code” chart in section K2.

| No. | Diagnosed Circuit | Condition | Page |
|-------|---|--|-------------|
| P0102 | Mass Air Flow (MAF) Sensor | Circuit low input | F3-21 |
| P0103 | | Circuit high input | F3-24 |
| P0106 | EGR/BARO sensor | Input signal out of self-test range | F3-25 |
| P0107 | | Input signal less than self-test minimum | F3-27 |
| P0108 | | Input signal greater than self-test maximum | F3-28 |
| P0112 | Intake Air Temperature (IAT) sensor | Circuit low input | F3-29, 30 |
| P0113 | | Circuit high input | F3-30, 31 |
| P0117 | Engine Coolant Temperature (ECT) sensor | Circuit low input | F3-30 |
| P0118 | | Circuit high input | F3-30, 31 |
| P0121 | Throttle Position (TP) sensor | In-range operating circuit failure | F3-32 |
| P0122 | | Circuit low input | F3-33 |
| P0123 | | Circuit high input | F3-34 |
| P0125 | Engine Coolant Temperature (ECT) sensor | Insufficient coolant temperature to enter a closed loop fuel control | F3-35 |
| P0131 | Upstream Heated Oxygen Sensor (HO2S 11) | Circuit out of range low voltage | F3-36 |
| P0133 | | Circuit low response | F3-37 |
| P0135 | Upstream Heated Oxygen Sensor Heater (HTR 11) | Circuit malfunction | F3-39 |
| P0136 | Downstream Heated Oxygen Sensor (HO2S 12) | Circuit malfunction | F3-41 |
| P0141 | Downstream Heated Oxygen Sensor Heater (HTR 12) | Circuit malfunction | F3-39 |
| P0171 | Adaptive fuel control system | System too lean | F3-43 |
| P0172 | | System too rich | |
| P0230 | Fuel pump | Circuit malfunction | F3-49, 50 |
| P0300 | Ignition | Random misfire detected | F3-51 |
| P0301 | | Cylinder #1 misfire detected | |
| P0302 | | Cylinder #2 misfire detected | |
| P0303 | | Cylinder #3 misfire detected | |
| P0304 | | Cylinder #4 misfire detected | |
| P0320 | Ignition Engine Speed | Input circuit malfunction | — |
| P0340 | Camshaft Position (CMP) sensor | Circuit malfunction (CID) | F3-54 |
| P0400 | Exhaust Gas Recirculation (EGR) | Flow malfunction | F3-56 |
| P0420 | Catalyst system | Efficiency below threshold | F3-58 |
| P0440 | Evaporative emission control system | Purge control malfunction | F3-62 |
| P0443 | | Purge control solenoid or valve circuit malfunction | F3-64 |
| P0500 | Vehicle Speed Sensor (VSS) | Sensor malfunction | F3-65 |
| P0505 | Idle Air Control (IAC) system | System malfunction | F3-66 |
| P0603 | Powertrain Control Module (PCM) | Keep Alive Memory (KAM) test error | F3-68 |
| P0605 | | Read Only Memory (ROM) test error | Replace PCM |
| P0703 | Brake on/off (BOO) switch | Input malfunction | F3-69 |
| P1000 | OBD-II drive cycle | OBD-II Monitor testing not complete | F3-71 |
| P1001 | Activate Self-Test | Standard Corporate Protocol (SCP) communication error | — |
| P1100 | Mass Air Flow (MAF) sensor | Sensor intermittent | F3-72 |
| P1101 | | Out of Self-Test range | F3-73 |
| P1112 | Intake Air Temperature (IAT) sensor | Sensor intermittent | F3-30 |
| P1116 | Engine Coolant Temperature (ECT) sensor | Out of Self-Test range | F3-76 |
| P1117 | | Sensor intermittent | F3-30 |

| No. | Diagnosed Circuit | Condition | Page |
|-------|---|---|-------------|
| P1120 | Throttle Position (TP) sensor | Out of range low | F3-77 |
| P1121 | | Sensor inconsistent with MAF sensor | F3-78 |
| P1124 | | Sensor out of Self-Test range | F3-79 |
| P1125 | | Circuit intermittent | F3-80 |
| P1127 | Heated Oxygen Sensor Heater (HTR) | Exhaust system too cool | F3-81 |
| P1130 | Upstream Heated Oxygen Sensor (HO2S 11) | Lack of upstream Heated Oxygen Sensor (HO2S 11) switch, adaptive fuel at limit | F3-43 |
| P1131 | | Lack of HO2S 11 switch, sensor indicates lean | |
| P1132 | | Lack of upstream Heated Oxygen Sensor (HO2S 11) switch, sensor indicates rich | |
| P1137 | Downstream Heated Oxygen Sensor (HO2S 12) | Lack of downstream Heated Oxygen Sensor (HO2S 12) switch, sensor indicates lean | F3-41 |
| P1138 | | Lack of HO2S 12 switch, sensor indicates rich | |
| P1235 | Fuel pump | Fuel pump control out of range | F3-49, 50 |
| P1236 | | | |
| P1270 | Over Reving Condition | Engine RPM or vehicle speed limiter reached | F3-82 |
| P1351 | Ignition | Ignition Diagnostic Monitor (IDM) signal out of Self-Test range | — |
| P1359 | Spark output | Circuit malfunction | — |
| P1400 | Differential Pressure Feedback Electronic (DPFE) sensor | Circuit low voltage detected | F3-83 |
| P1401 | | Circuit high voltage detected | F3-84 |
| P1407 | Exhaust Gas Recirculation (EGR) system | No flow detected (valve stuck closed or inoperative) | F3-56 |
| P1408 | | Flow out of Self-Test range | F3-86 |
| P1460 | Wide Open Throttle Air Conditioning Cutoff | Circuit malfunction | F3-89, 90 |
| P1474 | Fan Control (FC) system | Fan control primary circuit malfunction | F3-91 |
| P1500 | Vehicle Speed Sensor (VSS) | Circuit intermittent | F3-92 |
| P1504 | Idle Air Control (IAC) system | Circuit intermittent | F3-66 |
| P1505 | | System at adaptive clip | F3-93 |
| P1506 | | Overspeed error | F3-97 |
| P1507 | | Underspeed error | F3-66 |
| | | | |
| P1605 | Powertrain Control Module (PCM) | Keep Alive Memory (KAM) test error | Replace PCM |
| P1650 | Power Steering Pressure (PSP) switch | Out of Self-Test range | F3-99 |
| P1651 | | Input malfunction | |
| P1703 | Brake on/off (BOO) switch | Out of Self-Test range | F3-100 |

Caution

- Do not disconnect the battery to clear diagnostic trouble codes. This will erase the keep alive memory information which may cause a driveability concern.
- After repairing a failure, perform the After Repair Procedure to verify the fault has been corrected.

| CODE No. | P0102 | |
|---|--|---|
| DESCRIPTION | <ul style="list-style-type: none"> Diagnostic Trouble Code (DTC) P0102 indicates the MAF signal went below 0.39 volts (refer to Voltage to Mass Air Flow Conversion Table) sometime during normal engine operation (Continuous) or during Key On Engine Running (KOER) Self-Test | |
| <p>[Possible Cause]</p> <ul style="list-style-type: none"> Damaged MAF sensor MAF sensor disconnected MAF circuit open VPWR circuit open PWR GND circuit open MAF RTN circuit open MAF circuit shorted to ground Air Intake Leak (near MAF sensor) Throttle Position (TP) system (possible closed throttle indication) Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>CHECK MAF SIGNAL LOW INPUT TO PCM</p> <ul style="list-style-type: none"> Check broken/loose air outlet tube clamps (throttle body and air cleaner assembly ends), cracks/holes in air outlet tube, worn gaskets between MAF sensor and air cleaner assembly. Service as necessary. Start engine and bring to idle. <p>NOTE: If a KOER DTC P0505 is present, go to Diagnostic Trouble Code Charts. If a stabilized idle is not at least 700 rpm, go to TROUBLESHOOTING GUIDE.</p> <ul style="list-style-type: none"> Run engine up 1500 rpm for 5 seconds, then bring it back to idle. Access MAF V PID (MAF PID) with a Scan Tool. Is the MAF V PID (MAF PID) less than 0.39 volts (refer to Voltage to Mass Air Flow Conversion Table)? | <p>Yes</p> <p>The MAF SIG voltage is lower than acceptable minimum. Go to next Step.</p> <p>No</p> <p>For KOER reading between 0.60 and 1.00 volt (refer to Voltage to Mass Air Flow Conversion Table) Go to Step 10. All others: Go to Step 13.</p> |
| 2 | <p>CHECK VPWR CIRCUIT VOLTAGE</p> <ul style="list-style-type: none"> Key off. Disconnect MAF sensor. Key on, engine off. Measure the voltage between VPWR circuit at the MAF sensor vehicle harness connector and the battery negative post. Is the voltage greater than 10.5 volts? | <p>Yes</p> <p>VPWR harness circuit from CCRM to MAF sensor OK. Go to next Step.</p> <p>No</p> <p>Service open VPWR circuit. RESET KAM (REFER to PCM Reset). RETURN Quick Test.</p> |
| 3 | <p>CHECK CONTINUITY OF VPWR CIRCUIT</p> <ul style="list-style-type: none"> Key off. MAF sensor disconnected. Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc, Service as necessary. Install breakout box, leave PCM disconnected. Measure resistance between VPWR circuit at the MAF sensor vehicle harness connector and Test Pin 71 or 97 (VPWR) at the brakeout box. Is resistance less than 5.0 ohms? | <p>Yes</p> <p>VPWR harness circuit to PCM is OK. Go to next Step.</p> <p>No</p> <p>Service open VPWR harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 4 | <p>CHECK MAF CIRCUIT FOR SHORTS TO GROUND AND MAF RTN CIRCUIT</p> <ul style="list-style-type: none"> Key off. MAF sensor disconnected. Breakout box installed, PCM disconnected. Disconnect Scan Tool from Data Link Connector (DLC). Measure the resistance between Test Pin 88 (MAF SIG) and Test Pins 36 (MAF RTN) and 24 or 103 (PWR GND) at the breakout box. Is each resistance greater than 10,000 ohms? | <p>Yes</p> <p>MAF SIG, MAF RTN and GROUND harness circuits to PCM are OK. RECONNECT Scan Tool. Go to next Step.</p> <p>No</p> <p>Service short circuit between MAF SIG and GROUND or MAF RTN. REMOVE brakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| STEP | INSPECTION | ACTION |
|------|---|--|
| 5 | CHECK CONTINUITY OF MAF SIG CIRCUIT <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between MAF circuit at the MAF sensor vehicle harness connector and Test Pin 88 (MAF SIG) at the breakout box. • Is resistance less than 5.0 ohms? | Yes MAF SIG harness circuit to PCM is OK. Go to next Step. |
| | | No SERVICE open in MAF SIG harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 6 | CHECK PWR GND CIRCUIT TO MAF SENSOR <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed. • Key on, engine off. • Measure the voltage between VPWR circuit and PWR GND circuit at the MAF sensor vehicle harness connector. • Is the voltage greater less than 10.5 volts? | Yes PWR GND harness circuit from battery negative post to MAF sensor is OK. Go to Step 8. |
| | | No Go to next Step. |
| 7 | CHECK PWR GND CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed. • Disconnect PCM. • Disconnect Scan Tool from DLC. • Measure the resistance between PWR GND circuit at the MAF sensor vehicle harness connector and battery negative post. • Is resistance less than 10 ohms? | Yes PWR GND harness circuit to MAF sensor is OK. RECONNECT Scan Tools. Go to next Step. |
| | | No SERVICE open in PWR GND harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 8 | CHECK MAF RTN CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed, PCM disconnected. • Measure the resistance between MAF RTN circuit at the MAF sensor vehicle harness connector and Test Pin 36 (MAF RTN) at the breakout box. • Is the resistance less than 5.0 ohms? | Yes MAF RTN harness circuit to PCM is OK. Go to next Step. |
| | | No SERVICE open in MAF RTN harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 9 | CHECK MAF CIRCUIT FOR SHORT TO GROUND IN PCM <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed. • Reconnect PCM to breakout box. • Disconnect Scan Tool from DLC (if applicable). • Measure the resistance between Test Pin 88 (MAF SIG) and Test Pins 36 (MAF RTN) and 24 or 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes RECONNECT Scan Tool. Go to next Step. |
| | | No MAF SIG short to PWR GND or MAF RTN in the PCM. REMOVE breakout box. RECONNECT MAF sensor. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 10 | CHECK MAF CIRCUIT OUTPUT <ul style="list-style-type: none"> • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. <p>NOTE: If a stabilized idle is not at least 700 rpm, go to TROUBLESHOOTING GUIDE.</p> <ul style="list-style-type: none"> • Measure the voltage between Test Pin 88 (MAF SIG) at the breakout box and battery negative post. • Is the voltage at idle between 0.34 and 1.96 volts? | Yes MAF SIG to the PCM is OK. Go to next Step. |
| | | No MAF SIG or PWR GND is open in the MAF sensor, or MAF SIG is shorted to MAF RTN in the MAF sensor. REPLACE MAF sensor. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 11 | VERIFY MAF CIRCUIT INPUT AND OUTPUT • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. • Measure the voltage between Test Pin 88 (MAF SIG) and Test Pin 36 (MAF RTN) at the breakout box. • Is the voltage between 0.34 and 1.96 volts? | Yes | MAF RTN in MAF sensor is OK. Go to next Step. |
| | | No | MAF RTN open in the MAF sensor. REPLACE MAF sensor. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 12 | CHECK MAF CIRCUIT OUTPUT WITH SCAN TOOL • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. • Access MAF PID (MAF V PID) with a Scan Tool at idle. • Is the MAF V PID (MAF PID) between 0.34 and 1.96 volts (refer to Voltage to Mass Air Flow Conversion Table at the beginning of this Test)? | Yes | Unable to identify fault at this time. Check possible intermittent. |
| | | No | MAF SIG or MAF RTN is open or shorted together in the PCM. REPLACE PCM. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 13 | CHECK MAF SENSOR OUTPUT VOLTAGE NOTE: DTC P1101 could be generated by a low charged vehicle battery or the garage exhaust ventilation system. Service the battery as necessary. Then remove ventilation system and properly vent to outside atmosphere. Return KOEO Self-Test. • Key off. • Check that the MAF sensor in corrected. If not, service as necessary. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Scan Tool connected. • Install breakout box, connect PCM to breakout box. • Key on, engine off. • Measure between Test Pin 88 (MAF SIG) and Test Pins 24 or 103 (PWR GND) at the breakout box. • Is the voltage greater than 0.20 volts? | Yes | The MAF SIG voltage is greater than expected. Go to Step 7. |
| | | No | Go to Step 3. |

| | | |
|---|---|---|
| CODE No. | P0103 | |
| DESCRIPTION | <ul style="list-style-type: none"> DTC P0103 indicates that the Mass Air Flow (MAF) sensor signal went above 3.90 volts during normal engine operation (continuous) or during self test | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> Blocked MAF sensor screen Damaged MAF sensor MAF SIG harness short to VPWR Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK MAF SIGNAL HIGH INPUT TO PCM <ul style="list-style-type: none"> Start engine and bring to idle. <p>NOTE: If a KOER DTC P0505 is present, go to Code No. P0505. If stabilized idle is not at least 700 rpm, go directly Symptom flow charts.</p> <ul style="list-style-type: none"> Run throttle up to 1500 rpm for 5 seconds, and bring it back to idle. Access MAF V PID (MAF PID) with a Scan Tool. <p>NOTE: MAF V PID (MAF PID) should be greater than 3.9 volts.</p> | Yes MAF SIG shorted to VPWR in MAF sensor. REMOVE Jumper. REPLACE MAF sensor. RESET KAM (Refer to PCM Reset). RERUN Quick Test. |
| | <ul style="list-style-type: none"> Key off. Disconnect MAF sensor. Jumper PWR GND and SIG RTN pins at the MAF sensor vehicle harness connector. Key on, engine running. Again access MAF V PID with a Scan Tool. Did the MAF V PID (MAF PID) drop from the previous reading below 0.39 volts? | No Power short circuit, but not in MAF sensor. REMOVE Jumper. Go to next Step. |
| 2 | RERUN SELF-TEST WITH MAF SENSOR DISCONNECTED <ul style="list-style-type: none"> Key off. Disconnect MAF sensor. Disconnect Powertrain Control Module (PCM). Inspect for damage or pushed out pins, corrosion loose wires, etc. Service as necessary. Install breakout box, leave PCM disconnected. Key on, engine off. Measure the voltage between Test Pin 88 (MAF SIG) and Test pin 24 on 103 (PWR GND) at breakout box. Is the voltage greater than 105. volts? | Yes SERVICE short between MAF SIG and Power (excluding VREF), in harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (Refer to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 3 | CHECK MAF SIG FOR SHORT TO VPWR <ul style="list-style-type: none"> Key off. MAF sensor disconnected. Disconnect Scan Tool from data link connector. Measure resistance between Test Pin 88 (MAF SIG) and Test Pins 71 or 97 (VPWR) at the breakout box. Is resistance greater than 10,000 ohms? | Yes MAF SIG shorted to power in the PCM. REPLACE damaged PCM. REMOVE breakout box. RECONNECT MAF sensor. RESET KAM (Refer to PCM Reset). RERUN Quick Test. |
| | | No SERVICE short between MAF SIG and VREF in harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (Refer to PCM Reset). RERUN Quick Test. |

NOTE: DTC P0103 could be generated by foreign material blocking the mass air flow sensor screen causing an air flow restriction. If contaminants are found on the screen, check air filter installation in air cleaner tray and proper sealing of air cleaner and air tube before proceeding. Rerun Quick Test after repair.

| | | |
|---|---|--|
| CODE No. | P0106 | |
| DESCRIPTION | • DTC P0106 indicates that the EGR/BARO sensor input signal is out of self-test range | |
| <p>[Possible Cause]</p> <ul style="list-style-type: none"> • Damaged EGR/BARO sensor • Damaged EGRC solenoid valve • Damaged EGRC solenoid valve to EGR/BARO sensor hose • Damaged PCM • Damaged harness connector • Damaged harness | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>CHECK EGR/BARO SENSOR VREF VOLTAGE</p> <ul style="list-style-type: none"> • Key on, engine off. • EGR/BARO sensor disconnected. • Measure voltage between VREF and SIG RTN circuits at the EGR/BARO sensor vehicle harness connector. • Key off. • Is voltage between 4.0 and 6.0 volts? | Yes Go to next Step. |
| | | No REPAIR open in VREF circuit. |
| 2 | <p>CHECK CONTINUITY OF EGR/BARO SENSOR HARNESS CIRCUITS</p> <ul style="list-style-type: none"> • Key off. • EGR/BARO sensor disconnected. • Disconnect the PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between EGR/BARO SIG circuit at the EGR/BARO sensor vehicle harness connector and Test Pin 34 at the breakout box. • Measure the resistance between EGR/BARO SIG RTN circuit at the EGR/BARO sensor vehicle harness connector and Test Pin 91 at the breakout box. • Is each resistance less than 5 ohms? | Yes Go to next Step. |
| | | No Service open in appropriate. EGR/BARO sensor harness circuit. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | <p>CHECK EGR/BARO SENSOR SIG CIRCUITS FOR SHORT TO GROUND AND POWER</p> <ul style="list-style-type: none"> • Key off. • EGR/BARO sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 34 (EGR/BARO SIG) and Test Pins 91 (SIG RTN), 51 (PWR GND) and 103 (PWR GND) at the breakout box. • Measure resistance between Test Pin 34 (EGR/BARO SIG) and Test Pins 71 (VPWR), 90 (VREF) and 97 (VPWR) at the breakout box. • Is resistance greater than 10,000 ohms? | Yes Go to next Step. |
| | | No SERVICE short in EGR/BARO sensor SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | <p>CHECK RESPONSE OF EGR/BARO SENSOR TO MANUALLY APPLIED SIGNAL</p> <ul style="list-style-type: none"> • Key off. • Disconnect hose from EGR check solenoid to EGR/BARO sensor. Inspect for damage, blockage, etc. Service as necessary. • Breakout box installed, PCM connected. • Key on. • Using a hard held pump, slowly apply and maintain 21"-Hg, while measuring the EGR/BARO sensor voltage response at Test Pin 34 (EGR/BARO SIG) of the breakout box. • Is the voltage response between 0.8 and 1.5 volts? | Yes REMOVE the vacuum pump. RECONNECT all components. Go to next Step. |
| | | No REPLACE the EGR/BARO sensor. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | ACTION |
|------|--|---|
| 5 | CHECK VPWR AT EGRC SOLENOID <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Key on, engine idling. • Measure voltage between VPWR circuit and chassis ground at the EGRC solenoid vehicle harness connector. • Is EGRC VPWR voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in EGRC solenoid VPWR circuit. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 6 | CHECK RESISTANCE OF EGRC SOLENOID <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Measure solenoid resistance. • Is resistance between 30 and 70 ohms? | Yes Go to next Step. |
| | | No REPLACE the EGRC solenoid. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 7 | CHECK EGRC SOLENOID CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between Test Pin 98 (EGRC) at the breakout box and the EGRC circuit at the solenoid vehicle harness connector. • Is the resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open in EGRC harness circuit. REMOVE the breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 8 | CHECK EGRC SOLENOID CIRCUIT FOR SHORT TO POWER AND GROUND <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 98 (EGRC) and Test Pins 71, 97 (VPWR) and 90 (VREF) at the breakout box. • Measure resistance between Test Pin 98 (EGRC) and Test Pins 51, 103 (PWR GND) and 91 (SIG RTN) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes REMOVE breakout box. RECONNECT all components. Go to next Step. |
| | | No SERVICE short in EGRC solenoid harness circuit. REMOVE the breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 9 | CHECK EGRC SOLENOID VALVE OPERATION <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Disconnect the vacuum line from the intake manifold vacuum reservoir to the EGRC solenoid at the EGRC solenoid. • Install vacuum pump at the input port of the EGRC solenoid, apply 8 to 10"-Hg of vacuum to the EGRC solenoid. • Disconnect the vacuum line from the EGRC solenoid to EGR/BARO sensor at the EGRC solenoid, install a vacuum gauge at the unattached end of the vacuum line. • Key on. • Momentarily jumper to ground Test Pin 98 (EGRC) at the breakout box and observe the vacuum gauge. • Key off. • Was a vacuum signal indicated by the vacuum gauge? | Yes REPLACE the damaged PCM. REMOVE the breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No REPLACE the damaged EGRC solenoid. REMOVE the breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|--|---|--|
| CODE No. | P0107 | |
| DESCRIPTION | <ul style="list-style-type: none"> DTC P0107 indicates that the EGR/BARO SIG circuit input is less than the self-test minimum | |
| [Possible Cause] <ul style="list-style-type: none"> Damaged EGR/BARO sensor Damaged EGRC solenoid valve Damaged EGRC solenoid valve to EGR/BARO sensor hose Damaged PCM Damaged harness connector Damaged harness | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK EGR/BARO SENSOR VREF VOLTAGE <ul style="list-style-type: none"> Key on, engine off. EGR/BARO sensor disconnected. Measure voltage between VREF circuit and SIG RTN circuit at the EGR/BARO sensor vehicle harness connector. Is voltage between 4.0 and 6.0 volts? | Yes Go to next Step. |
| | | No REPAIR open in VREF circuit. |
| 2 | CHECK CONTINUITY OF EGR/BARO SENSOR SIG CIRCUIT <ul style="list-style-type: none"> Key off. EGR/BARO sensor disconnected. Disconnect the PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. Install breakout box, leave the PCM disconnected. Measure the resistance between EGR/BARO SIG circuit at the EGR/BARO sensor vehicle harness connector and Test Pin 34 at the breakout box. Is resistance less than 5 ohms? | Yes Go to next Step. |
| | | No RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK EGR/BARO SIG CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Key off. EGR/BARO sensor disconnected. Breakout box installed, PCM disconnect. Measure resistance between Test Pin 34 (EGR/BARO SIG) and Test Pins 91 (SIG RTN), 51 (PWR GND) and 103 (PWR GND) at the breakout box. Is resistance greater than 10,000 ohms? | Yes Go to next Step. |
| | | No SERVICE short in EGR/BARO sensor SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK RESPONSE OF EGR/BARO SENSOR TO MANUALLY APPLIED SIGNAL <ul style="list-style-type: none"> Key off. Disconnect hose from EGR check solenoid to EGR/BARO sensor. Inspect for damage, blockage, etc. Service as necessary. Breakout box installed, PCM connected. Key on. Using a hand held pump, slowly apply and maintain 21"-Hg, while measuring the EGR/BARO sensor voltage response at Test Pin 34 (EGR/BARO SIG) of the breakout box. Is the voltage response between 0.8 and 1.5 volts? | Yes REMOVE the vacuum pump. RECONNECT all components. Go to DTC P0106 Troubleshooting Step 5. |
| | | No REPLACE the EGR/BARO sensor. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | | |
|--|--|-----|--|
| CODE No. | P0108 | | |
| DESCRIPTION | • DTC P0108 indicates that the EGR/BARO SIG circuit input is greater than the self-test maximum | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Damaged EGR/BARO sensor • Damaged EGRC solenoid valve • Damaged EGRC solenoid valve to EGR/BARO sensor hose • Damaged PCM • Damaged harness connector • Damaged harness | | | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK EGR/BARO SENSOR VREF VOLTAGE <ul style="list-style-type: none"> • Key on, engine off. • EGR/BARO sensor disconnected. • Measure voltage between VREF circuit and SIG RTN circuit at the EGR/BARO sensor vehicle harness connector. • Is voltage between 4.0 and 6.0 volts? | Yes | Go to next Step. |
| | | No | REPAIR open in VREF circuit. |
| 2 | CHECK CONTINUITY OF EGR/BARO SENSOR SIG CIRCUIT <ul style="list-style-type: none"> • Key off. • EGR/BARO sensor disconnected. • Disconnect the PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave the PCM disconnected. • Measure the resistance between EGR/BARO SIG RTN circuit at the EGR/BARO sensor vehicle harness connector and Test Pin 91 at the breakout box. • Is resistance less than 5 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open in EGR/BARO sensor SIG circuit. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK EGR/BARO SIG CIRCUIT FOR SHORT TO POWER <ul style="list-style-type: none"> • Key off. • EGR/BARO sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 34 (EGR/BARO SIG) and Test Pins 71, 97 (VPWR) and 90 (VREF) at the breakout box. • Is resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | SERVICE short in EGR/BARO sensor SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK RESPONSE OF EGR/BARO SENSOR TO MANUALLY APPLIED SIGNAL <ul style="list-style-type: none"> • Key off. • Disconnect hose from EGR check solenoid to EGR/BARO sensor. Inspect for damage, blockage, etc. Service as necessary. • Breakout box installed, PCM connected. • Key on. • Using a hand held pump, slowly apply and maintain 21"-Hg, while measuring the EGR/BARO sensor voltage response at Test Pin 34 (EGR/BARO SIG) of the breakout box. • Is the voltage response between 0.8 and 1.5 volts? | Yes | REMOVE the vacuum pump. RECONNECT all components. Go to DTC P0106 Troubleshooting Step 5. |
| | | No | REPLACE the EGR/BARO sensor. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|---|---|--|
| CODE No. | P0112, P0177 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0117 (ECT) or P0112 (IAT) indicates that the corresponding sensor's signal is less than the Self-Test minimum. The IAT and ECT sensor minimum is 0.2 volt 121°C {250°F} | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Grounded circuit in harness • Damaged sensor • Damaged Powertrain Control Module (PCM) • Improper harness connection | | |
| STEP | INSPECTION | ACTION |
| 1 | SIMULATE OPPOSITE SIGNAL TO PCM <ul style="list-style-type: none"> • Key off. • Disconnect vehicle harness from suspect sensor. Inspect for damaged or pushed out pins or loose wires, etc. Service as necessary. • Key on. • Is the ECT or IAT PID more than 4.2 volts (less than -40°C {-40°F})? | Yes REPLACE sensor. RECONNECT harness. RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | CHECK VREF CIRCUIT VOLTAGE AT THROTTLE POSITION SENSOR <ul style="list-style-type: none"> • Key off. • Suspect temperature sensor disconnected. • Disconnect TP sensor. • Key on, engine off. • Measure voltage between VREF circuit and SIG RTN circuit at the TP sensor vehicle harness connector. • Is voltage between 4.5 volts and 5.5 volts? | Yes RECONNECT TP sensor. Go to next Step. |
| | | No REPAIR open in VREF circuit. |
| 3 | CHECK TEMPERATURE SENSOR SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • Suspect temperature sensor disconnected. • Disconnect Powertrain Control Module (PCM) Inspect for damaged or pushed out pins, corrosion loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected Measure resistance between Test Pin 7 (ECT) or 25 (IAT) and Test Pins 40, 46 and 60 at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes REPLACE PCM. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No SENSOR short circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|---|--|---|
| CODE No. | P0112, P1112, P0113, P0117, P1117, P0118 | |
| DESCRIPTION | <ul style="list-style-type: none"> Diagnostic Trouble Codes (DTCs) P0112, P1112 or P0113 (IAT DTCs) and P0117, P1117 or P0118 (ECT DTCs) are not received during KOEO and KOER Self-Test, but are output during continuous Memory Self-Test and may be intermittent | |
| [Possible Cause] <ul style="list-style-type: none"> Damaged IAT or ECT sensor Damaged harness Low coolant (ECT) Damaged harness connector Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | <ul style="list-style-type: none"> Key off. Scan Tool connected. Key on. Monitor the ECT or IAT PID. While observing the PID, perform the following: <ul style="list-style-type: none"> Tap on the sensor to simulate road shock Wiggle the sensor connector Is there any change in the temperature reading? | Yes DISCONNECT and INSPECT connectors. If OK, REPLACE the sensor. RESET KAM (Refer to PCM Reset). RERUN Quick test. For Continuous DTCs P1112 and P1117, COMPLETE Comprehensive Component Monitor Drive cycle (Refer to Drive cycles). |
| | | No Go to next Step. |
| 2 | CHECK EEC-V VEHICLE HARNESS <ul style="list-style-type: none"> Still monitoring PID. While observing the appropriate PID, perform the following: <ul style="list-style-type: none"> Hold the vehicle harness close to the sensor connector. Wiggle, shake and bend small section of wiring harness while working toward the PCM Is there any damage in the temperature reading? | Yes ISOLATE fault. SERVICE as necessary. RESET KAM (Refer to PCM Reset). RERUN Quick test. For Continuous DTCs P1112 and P1117, COMPLETE Comprehensive Component Monitor Drive cycle (Refer to Drive cycles). |
| | | No Go to next Step. |
| 3 | CHECK PCM AND VEHICLE HARNESS CONNECTORS <ul style="list-style-type: none"> Key off. Disconnect Powertrain Control Module (PCM) Disconnect sensor connector. Inspect for damage, loose or pushed outpins, loose or poorly crimped wires. Are connectors and terminals OK? | Yes Fault is not present. RESET KAM (Refer to PCM Reset). RERUN Quick test. For Continuous DTCs P1112 and P1117, COMPLETE Comprehensive Component Monitor Drive cycle (Refer to Drive cycles). |
| | | No SERVICE as necessary. RESET KAM (Refer to PCM Reset). RERUN Quick test. For Continuous DTCs P1112 and P1117, COMPLETE Comprehensive Component Monitor Drive cycle (Refer to Drive cycles). |

| | | |
|--|---|--|
| CODE No. | P0113, P0118 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0118 (ECT) or P0113 (IAT) indicates that the corresponding sensor signal is greater than the Self-Test maximum. The maximum for ECT and IAT sensor is 4.6 volt or -50°C {-46°F} | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Open in harness (IAT or ECT) • Damaged sensor • Improper harness connection • Damaged Powertrain Control Module (PCM) | | |
| STEP | INSPECTION | ACTION |
| 1 | <ul style="list-style-type: none"> • Key off. • Disconnect suspect temperature sensor. • Connect a jumper wire between the sensor signal circuit and SIG RTN circuit at the temperature sensor vehicle harness connector. • Scan Tool installed. • Key on. <p>NOTE: If a Scan tool communication problem exists, remove jumper wire immediately and go to Step 3</p> <ul style="list-style-type: none"> • Access ECT or IAT PID. • Is the ECT or IAT PID less than 0.2 volts (greater than 120°C {248°F})? | Yes REPLACE suspect sensor. REMOVE jumper wire. RECONNECT vehicle harness. RERUN Quick Test. |
| | | No REMOVE jumper wire. Go to next Step. |
| 2 | <p>CHECK CONTINUITY OF SENSOR SIGNAL AND SIG RTN CIRCUITS</p> <ul style="list-style-type: none"> • Key off. • Suspect temperature sensor disconnected. • Disconnect Powertrain Control Module (PCM) Inspect for damaged or pushed out pins, corrosion, loose wire, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between sensor signal circuit at the temperature sensor vehicle harness connector and Test Pin 38 (ECT) or 39 (IAT) at the breakout box. • Measure resistance between SIG RTN circuit at the temperature sensor vehicle harness connector and Test Pin 91 (SIG RTN) at the breakout box. • Is each resistance less than 5.0 ohms? | Yes REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 3 | <p>CHECK FOR SENSOR SIGNAL SHORTED TO VREF</p> <ul style="list-style-type: none"> • Key off. • Suspect temperature sensor disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between sensor signal circuit Test Pin 38 (ECT) or 39 (IAT) and VREF at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes REPLACE PCM. RERUN Quick Test. |
| | | No LOCATE and REPAIR short to VREF. RERUN Quick Test. |

| | | |
|--------------------|--|---|
| CODE No. | P0121 | |
| DESCRIPTION | • DTC P0121 indicates an in-range operating TP sensor circuit failure | |
| STEP | INSPECTION | ACTION |
| 1 | DTC P0121 OR UNABLE TO EXIT KOER SELF-TEST (TP IN-RANGE ERROR) <ul style="list-style-type: none"> • Key off. • Start engine, bring to idle (closed throttle position). • Activate Key On Engine Running (KOER) Self-Test with the Scan Tool. • Is DTC P0121 present or does KOER Self-Test fail to terminate? | Yes KEEP engine running at idle. Go to next Step. |
| | | No Go to TROUBLESHOOTING GUIDE, for possible fast idle concerns. |
| 2 | ATTEMPT TO RECREATE DTC P0121 OR DRIVEABILITY SYMPTOM <ul style="list-style-type: none"> • Key on, engine running. • Attempt to take vehicle for a drive, while still in Key On Engine Running Self-Test on Scan Tool. NOTE: If KOER Self-Test terminates when placing the selector in gear (drive or reverse). Go to next Step directly. <ul style="list-style-type: none"> • Turn ignition to the key off position, wait 15 seconds. • Again, start engine. • Activate KOER Self-Test with the Scan Tool. • Is DTC P0121 still present or does KOER Self-Test again fail to terminate? | Yes Go to next Step. |
| | | No RERUN Quick Test. Go to TROUBLESHOOTING GUIDE, for possible fast idle concerns. |
| 3 | CHECK TP CIRCUIT <ul style="list-style-type: none"> • Check for opens in the TP SIG and SIG RTN harness wires between both the TP sensor and the PCM vehicle harness connectors. • Is an open indicated? | Yes SERVICE open in TP SIG or SIG RTN harness circuit. RERUN Quick Test. If a driveability symptom is still present, go to TROUBLESHOOTING GUIDE. |
| | | No REPLACE TP sensor. RERUN Quick Test. If a driveability symptom is still present, go to TROUBLESHOOTING GUIDE. |

| CODE No. | P0122 | | |
|---|---|--------|--|
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0122 indicates Throttle Position (TP) Sensor signal is less than the Self-Test minimum value of 3.43% (0.17 volts) | | |
| <p>[Possible Cause]</p> <ul style="list-style-type: none"> • TP not seated properly (tightened down) • Damaged TP sensor • Open TP SIG or VREF harness • TP SIG harness short to SIG RTN or PWR GND • Damaged Powertrain Control Module (PCM) | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>ATTEMPT TO GENERATED DTC P0123 OR P0121</p> <ul style="list-style-type: none"> • Key off. • Disconnect TP sensor. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Leave TP sensor disconnected. • Jumper VREF circuit to TP circuit at TP sensor vehicle harness connector. • Key on, engine off. <p>NOTE: If any Scan Tool communication problem exists, remove jumper and go directly Step 4</p> <ul style="list-style-type: none"> • Is DTC P0123 or P0121 present (ignore all other DTC's)? | Yes | <p>TP SIG shorted to SIG RTN in TP sensor, or TP SIG or VREF open in TP sensor. REPLACE TP sensor. REMOVE jumper wire. RERUN Quick Test.</p> |
| | | No | <p>VREF or TP SIG open in harness or PCM or TP SIG shorted to SIG RTN (or PWR GND) in harness or PCM. REMOVE jumper wire. Go to next Step.</p> |
| 2 | <p>CHECK VREF CIRCUIT VOLTAGE</p> <ul style="list-style-type: none"> • Key off. • TP sensor disconnected. • Key on engine off. • Measure voltage between VREF circuit and SIG RTN circuit at the TP sensor vehicle harness connector. • Is voltage between 4.0 and 6.0 volts? | Yes | <p>Go to next Step.</p> |
| | | No | <p>KEY off. RECONNECT all components. REPAIR open in VREF circuit.</p> |
| 3 | <p>CHECK TP CIRCUIT CONTINUITY</p> <ul style="list-style-type: none"> • Key off. • TP sensor disconnected. • Disconnect Powertrain Control Module (PCM) Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between TP circuit at the TP sensor vehicle harness connector and Test Pin 89 (TP SIG) at the breakout box. • Is the resistance less than 5.0 ohms? | Yes | <p>TP SIG harness circuit to PCM is OK. Go to next Step.</p> |
| | | No | <p>SERVICE open in TP SIG harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 4 | <p>CHECK TP CIRCUIT FOR SHORTS TO SIG RTN OR PWR GND</p> <ul style="list-style-type: none"> • Key off. • TP sensor disconnected. • PCM disconnected. • Measure resistance between Test Pin 89 (TP SIG) and test Pins 91 (SIG RTN) and 24 or 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | <p>TP SIG open or shorted to SIG RTN (or PWR GND) in the PCM. REPLACE PCM. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | No | <p>SERVICE TP SIG shorted to SIG RTN (or PWR GND) in the harness. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| | | |
|-------------------------|--|---|
| CODE No. | P0123 | |
| DESCRIPTION | <ul style="list-style-type: none"> DTC P0123 indicates Throttle Position (TP) Sensor signal is greater than the Self-Test maximum value of 92.27% (4.60 volts) | |
| [Possible Cause] | <ul style="list-style-type: none"> TP seated properly (tightened down) Damaged TP sensor TP SIG harness short to VREF or VPWR VREF harness short to VPWR Open SIG RTN harness circuit Damaged Powertrain Control Module (PCM) | |
| STEP | INSPECTION | ACTION |
| 1 | ATTEMPT TO GENERATE DTC P0122 <ul style="list-style-type: none"> Key off. Disconnect TP sensor. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. Leave TP sensor disconnected. Key on, engine off. Access TP PID (TPV PID) with the Scan Tool. Is the TP PID (TPV PID) less than 3.43% (0.17 volts)? | Yes TP SIG is either shorted to VREF in TP sensor or SIG RTN is open in the TP sensor or harness. Go to next Step. |
| | | No TP SIG circuit is shorted to VREF or VPWR. Go to Step 3. |
| 2 | CHECK VREF CIRCUIT VOLTAGE <ul style="list-style-type: none"> Key off. TP sensor disconnected. Key on, engine off. Measure voltage between VREF circuit and SIG RTN circuit at the TP sensor vehicle harness connector. Is voltage between 4.0 and 6.0 volts? | Yes TP SIG shorted to VREF on SIG RTN open in the TP sensor. REPLACE TP sensor. RERUN Quick Test. |
| | | No KEY off. RECONNECT all components. REPAIR open in VREF circuit. |
| 3 | CHECK TP SENSOR CIRCUIT FOR SHORTS TO POWER <ul style="list-style-type: none"> Key off. TP sensor disconnected. Disconnect Powertrain Control Module (PCM), Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. Install breakout box, leave PCM disconnected. Measure resistance between Test Pin 89 (TP SIG) and Test Pins 90 (VREF) and 71 or 97 (VPWR) at the breakout box. Is each resistance greater than 10,000 ohms? | Yes TP SIG is shorted to VREF or VPWR in PCM. REPLACE PCM. REMOVE breakout box. RECONNECT TP sensor. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No SERVICE Short circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

NOTE: An intermittent fault can cause a Continuous Memory DTC P0123. If Continuous Memory DTC P0123 still present after Step 1 through Step 3, go to CODE No. P1120 or P1125.

| | | | |
|--|--|-----|---|
| CODE No. | P0125 | | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0125 indicates the ECT sensor has not achieved the required temperature level to enter closed loop operating conditions within a specified amount of time after starting engine. This code will light the MIL | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Insufficient warm up time • Leaky or stuck open thermostat • Low coolant | | | |
| STEP | INSPECTION | | ACTION |
| 1 | DTC P0125 INDICATES EXCESSIVE TIME TO ENTER CLOSED LOOP FUEL CONTROL <ul style="list-style-type: none"> • Check coolant level. • Is the coolant level fill correct? | Yes | Check the thermostat. ➡ section E |
| | | No | FILL to proper level. RESET KAM (Refer to PCM reset). COMPLETE Comprehensive Component. Monitor Drive Cycle (Refer to Drive cycles). |

| | | |
|--|--|---|
| CODE No. | P0131 | |
| DESCRIPTION | • DTC P0131 is set when the HO2S generates a negative voltage | |
| [Possible Cause] | | |
| • Contaminated HO2S (water, fuel, etc) | | • Crossed HO2S signal/signal return wiring |
| STEP | INSPECTION | ACTION |
| 1 | CONTAMINATED HO2S/VOLTAGE SHIFT • Check for water in HO2S connector. • Is there water in the HO2S connector? | Yes REPAIR source of water entry. Dryout connector REPLACE HO2S. RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | VERIFY WIRING IS IN PROPER PIN LOCATION • Key off. • Suspect sensor disconnected. • Install breakout box, leave PCM disconnected. • Use the following list to measure the resistance between the appropriate test pins at the breakout box and the HO2S Signal and Signal RTN at the harness connector(s). – HO2S-11=P0131 – HO2S Signal Test Pin 60 – HO2S Signal RTN Test Pin 91 • Is the resistance less than 5.0 ohms? | Yes REPLACE HO2S. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No REPAIR wiring as necessary. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|-------------------------|---|--|
| CODE No. | P0133 | |
| DESCRIPTION | • DTC P0133 indicate the response rate of HO2S is below some calibrated window | |
| [Possible Cause] | <ul style="list-style-type: none"> • Contaminated HO2S • Exhaust leaks • Shorted/Open wires • Excessive fueling • MAF meter • Air leaks | |
| STEP | INSPECTION | ACTION |
| 1 | HO2S RESPONSE TEST <ul style="list-style-type: none"> • Key off. • Scan Tool connected. • Key on, engine off. • Access Generic OBD II functions and trigger. • Scroll to Oxygen Sensor Test and trigger. • Scroll to Manufacturer Specific Test ID and trigger. • Scroll to Test ID: (41H) and trigger. • Is the measurement for the HO2S fault greater than 0.6 volt? | Yes RESET KAM (Refer to PCM Reset). COMPLETE OBD II drive cycle. REPEAT Test Step. If test results are greater than 0.6 volt; testing is complete. |
| | | No Oxygen sensor test results are out of an acceptable range. Go to next Step. |
| 2 | CHECK FOR SOURCE OF POTENTIAL HO2S CONTAMINATION <ul style="list-style-type: none"> • Investigate the following items as a potential source of HO2S contamination. <ul style="list-style-type: none"> - Use of unapproved silicon sealers - Fuel contaminated by silicon additives - Excessive oil burning (i.e. rings, valve seals and oil overfill) - Glycol (antifreeze) leaking internally in the engine - Lead contaminated fuel - Use of unapproved cleaning agents • Are any of the above conditions present? | Yes REPAIR source of contamination. REPLACE HO2S and oil/filter. RESET KAM (REFER to PCM Repair). COMPLETE a OBD II Drive cycle. |
| | | No Go to next Step. |
| 3 | CHECK FOR UNMETERED AIR LEAKS Fuel calculations can be affected by unmetered air leaks. <ul style="list-style-type: none"> • Carefully inspect the following areas for potential air leaks. <ul style="list-style-type: none"> - Hoses connecting to MAF - Hoses connecting to throttle body - Intake manifold gasket leaks - PCV disconnected - Vacuum lines disconnected - Improperly seated dip stick and tube - Exhaust leaks at flanges and gaskets • Are there any air leaks? | Yes Air leaks located. REPAIR source of air leak. RESET KAM (REFER to PCM Repair). COMPLETE a OBD II drive cycle. |
| | | No Go to next Step. |
| 4 | CHECK OF HO2S CIRCUIT WIRING WITH PCM CONNECTED <ul style="list-style-type: none"> • Key off. • PCM connected. • Suspect HO2S disconnected. • Jumper HO2S Signal to VPWR at the HO2S harness connector. • Scan Tool connected. • Key on, engine off. • Access the correct HO2S PID. <p>NOTE: HO2S displayed as O2S on Scan Tool.</p> <ul style="list-style-type: none"> • Is the voltage greater than 1.50 volts? | Yes HO2S signal circuit is not faulty. REPLACE HO2S. CHANGE oil/filter. RESET KAM (REFER to PCM Reset). COMPLETE a OBD II drive cycle. |
| | | No Go to next Step. |

| STEP | INSPECTION | ACTION |
|------|--|---|
| 5 | CHECK RESISTANCE OF HO2S SIGNAL CIRCUIT <ul style="list-style-type: none"> • Key off. • PCM disconnected, breakout box installed. • Measure the resistance between HO2S Signal Test Pin at the breakout box and the HO2S harness connector. • Measure the resistance between Signal RTN test pin at the breakout box and the HO2S harness connector. <ul style="list-style-type: none"> – HO2S-11 = Sig. Pin 60 – HO2S-11 = Sig. RTN Pin 91 • Is the resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No Resistance is high. SERVICE open circuit. REMOVE breakout box. RECONNECT all components. COMPLETE a OBD II drive cycle. |
| 6 | CHECK FOR SHORT IN HO2S CIRCUIT <ul style="list-style-type: none"> • Key off. • Breakout box installed. PCM disconnected. • Measure the resistance between the HO2S Signal Test Pin at the breakout box and VPWR circuit and HO2S Signal Test Pin and Signal return circuit at the breakout box. <ul style="list-style-type: none"> – HO2S-11 = Sig. Pin 60 – VPWR = 71/97 – Signal RTN = 91 • Is the resistance greater than 10,000 ohms? | Yes REPLACE PCM. COMPLETE a OBD II drive cycle. |
| | | No SERVICE short circuit. REMOVE breakout box. RECONNECT all components. COMPLETE a OBD II drive cycle. |

| | | |
|---|---|---|
| CODE No. | P0135, P0141 | |
| DESCRIPTION | • DTC P0135 and P0141 indicate a short to ground, or open, or short to VPWR in the HO2S heater circuit | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Shorts to B+ in harness or HO2S • Water in connectors • Cut or pulled wires • Disconnected wiring • Open VPWR circuit • Open GND circuit • Low Battery Voltage • Corrosion or poor mating terminals • Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | <p>HO2S HEATER SIGNAL CIRCUIT IS OPEN, SHORTED TO GROUND, SHORTED TO B+ OR EXCESSIVE CURRENT DRAW</p> <p>DTC/HO2S Reference List DTC P0135 = HO2S HTR-11 DTC P0141 = HO2S HTR-12</p> <ul style="list-style-type: none"> • Visually inspect the HO2S circuit for exposed wiring, contamination, corrosion and proper assembly. <p>NOTE: On some applications, a vehicle hoist may be required to access the HO2S harness.</p> <ul style="list-style-type: none"> • Were any concerns found during the visual inspection? | Yes REPAIR any concerns found in the visual inspection. RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | <p>PERFORM KEY ON KOER SELF TEST</p> <ul style="list-style-type: none"> • Key off. • Scan tool connected. • Key on, engine on. • Engine at 2,000 rpm for 10 minutes. • Return to idle. • Activate key on, engine running (KOER) self test. • Are DTCs P0135 or P0141 present? | Yes Go to next Step. |
| | | No Fault may be intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |
| 3 | <p>MONITOR HEATER CURRENT PID'S</p> <ul style="list-style-type: none"> • Key on. • Scan Tool connected. • Access HTR11CM, HTR12CM, PID's and monitor. <p>NOTE: HTR11CM = H02S Heater 11 Current Monitor. This is the test results of the HO2S heater circuit that the EEC performs. The number within the PID indicates the HO2S heater circuit location. The value displayed must be within the acceptable range indicated.</p> <ul style="list-style-type: none"> • Are all PID values between 0.3 and 3.0 amps? | Yes Go to Step 6. |
| | | No HO2S HTR circuit failed EEC Heater Current Monitor Test. Use the PID(s) with the values out of range to determine which HO2S HTR circuit is at fault and Go to next Step. |
| 4 | <p>CHECK FOR VPWR AT THE VEHICLE HO2S HARNESS CONNECTOR</p> <ul style="list-style-type: none"> • Key off. • Disconnect the appropriate HO2S(s). • Inspect both ends of the connector(s) for damaged or pushed out pins, moisture, corrosion, contamination, etc. Service as necessary. • Key on, engine off. • Measure the voltage between VPWR and SIG RTN circuit at the HO2S vehicle harness connector (refer to schematic at the beginning of this pinpoint test). • Is the voltage greater than 10.5 volts? | Yes Go to Step 5. |
| | | No Go to next Step. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 5 | CHECK FOR OPEN VPWR CIRCUIT <ul style="list-style-type: none"> • Key off. • Install breakout box, PCM disconnected. • Suspect sensor disconnected. • Measure the resistance between the VPWR Test Pin at the breakout box and VPWR at the HO2S vehicle harness connector. • Is the resistance less than 4.0 ohms? | Yes | Go to next Step. |
| | | No | CHECK Fuse if fuse is OK, REPAIR open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 6 | CHECK HO2S HEATER RESISTANCE <ul style="list-style-type: none"> • Key off. • HO2S disconnected. • Connect DVOM to HO2S HTR GND and VPWR Test Pins at the HO2S connector, and measure the resistance. • Is the resistance between 3.0 and 30 ohms? | Yes | FOR faults with heater current PID(s) out of range Go to Step 9. ALL others Go to next Step. |
| | | No | REPLACE HO2S. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 7 | CHECK FOR HEATER GND AND VPWR SHORTED TO HO2S CASE <ul style="list-style-type: none"> • Suspect sensor disconnected. • Measure the resistance between the HO2S Heater GND at the HO2S connector and the HO2S case. • Measure the resistance between the HO2S VPWR at the HO2S sensor connector and the HO2S sensor case. • Is the resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | REPLACE HO2S. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 8 | CHECK FOR SHORTS TO OTHER GROUNDS AND VPWR IN THE HO2S HEATER GROUND HARNESS CIRCUITS <ul style="list-style-type: none"> • Key off. • Suspect sensor disconnect. • Disconnect PCM. • Breakout box installed, leave PCM disconnected. • Use the following list to measure the resistance between the appropriate test pins at the breakout box. <ul style="list-style-type: none"> – DTC P0135 = HO2S HTR-11 (HTR GND) Test Pin 93 and Test Pins 24, 76, 103, 91 and 97 – DTC P0141 = HO2S HTR-12 (HTR GND) Test Pin 95 and Test Pins 24, 76, 103, 91 and 97 • Is the resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | REPAIR shorted circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 9 | CHECK FOR OPEN HO2S HEATER GROUND HARNESS CIRCUIT <ul style="list-style-type: none"> • Key off. • Suspect sensor disconnected. • Breakout box installed, PCM disconnected. • Use the following list to measure the resistance between the appropriate test pins at the breakout box and the HO2S HTR GND at the vehicle harness connector. <ul style="list-style-type: none"> – HO2S HTR-11 Test Pin 93 (HTR GND) – HO2S HTR-12 Test Pin 95 (HTR GND) • Is the resistance less than 4.0 ohms? | Yes | Open or shorted or excessive resistance in the HTR circuit or in the PCM. REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No | REPAIR open or cause of excessive resistance in the harness. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|---|---|--|
| CODE No. | P0136, P1137, P1138 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC 0136 indicate the output voltage of the downstream HO2S is less than some calibratable functional window. KOER DTCs P1137 and P1138 can only be retrieved during KOER Self-Test when the fuel control is ramped rich and lean and monitored for a voltage change on the downstream HO2S | |
| <p>[Possible Cause]</p> <ul style="list-style-type: none"> • Wiring Concerns <ul style="list-style-type: none"> – Pinched, shorted, and corroded wiring and pins – Crossed sensor wires • Other Concerns <ul style="list-style-type: none"> – Exhaust leaks – Contaminated or defective sensor | | |
| STEP | INSPECTION | ACTION |
| 1 | DTC 0136 MONITOR DOWNSTREAM HO2S OUTPUT VOLTAGE FOR ACTIVITY. P1137, P1138 LACK OF HO2S SWITCHING • Are any of the above concerns present? | Yes SERVICE as necessary. RESET KAM (Refer to PCM Reset). COMPLETE a HO2S monitor drive cycle (Refer to Drive cycle). RERUN Quick Test. |
| | | No CONTINUOUS DTC's P0136. Go to next Step. All others. Go to Step 28. |
| 2 | CHECK FOR KOER DTCS P1137 or P1138 • Key off. • Scan Tool connected. • Key on, engine idling and stabilized. • Activate KOER Self-Test. • Check for DTCS. • Are DTCs P1137 and P1138 present? | Yes Go to next Step. |
| | | No FOR DTCs P0136. The fault that produced the DTC is an intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |
| 3 | CHECK EXHAUST SYSTEM FOR LEAKS NOTE: Any exhaust leaks between the engine and the end of the catalyst may cause DTC P0136. • Key off. • Place vehicle on a hoist, transmission in park, emergency brake applied, raise vehicle. • Inspect the following: – Exhaust flanges for leaks – HO2S torque – Check for punctures and cracks in catalyst and pipes leading to them • Are there any exhaust leaks? | Yes REPLACE or REPAIR as required. RESET KAM (REFER to PCM Reset). COMPLETE a HO2S Monitor Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. |
| | | No Go to next Step. |
| 4 | CHECK HO2S HARNESS CIRCUIT FOR SHORT TO VPWR AND GROUND • Key off. • Breakout box installed, PCM disconnected. Inspect both ends of connector for damaged or pushed out pins, moisture, corrosion, loose pins, etc. and service as necessary. • HO2S disconnected. • Measure the resistance between HO2S Signal Test Pin and SIG RTN Test Pin at breakout box. • Measure the resistance between HO2S Signal Test Pin and VPWR and VREF Test Pin at the breakout box. • Measure the resistance between HO2S Signal Test Pin and PWR GND Test Pin at the breakout box. HO2S-12 SIG = Test Pin 35 HO2S SIG RTN = Test Pin 91 PWR GND = Test Pins 24, 76 and 103 VPWR = Test Pins 71 and 97 VREF = Test Pin 90 • Is resistance greater than 10,000 ohms? | Yes Go to next Step. |
| | | No SERVICE short in harness. RESET KAM (REFER to PCM Reset). COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. |

| STEP | INSPECTION | | ACTION | | | | | | |
|-------|---|-----------|--|------|-------|---------|-----------|-----|---------------|
| 5 | CHECK CONTINUITY OF HO2S AND HO2S GROUND CIRCUITS <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • Disconnect suspect HO2S from harness. • Measure the resistance between HO2S Signal Test Pin at the breakout box and the HO2S vehicle harness connector. Record readings. • Measure resistance between SIG RTN Test Pin at the breakout box and HO2S SIG RTN vehicle harness connector. Record readings. <ul style="list-style-type: none"> – HO2S-12 SIG = Test Pin 35 – HO2S SIG RTN = Test Pin 91 • Is resistance reading less than 5.0 ohms? | Yes | Go to next Step. | | | | | | |
| | | No | REPAIR open circuit in harness. REMOVE breakout box. RECONNECT all components. COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. | | | | | | |
| 6 | CHECK HO2S CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • PCM connected to vehicle harness. • Suspect HO2S connected to vehicle harness. • Scan Tool connected. • Key on, engine off. • Access the correct HO2S PID. <p>NOTE: HO2S displayed as O2S on Scan Tool.</p> <table border="1" data-bbox="196 814 708 890"> <thead> <tr> <th>DTC</th> <th>HO2S</th> <th>PINS</th> </tr> </thead> <tbody> <tr> <td>P0136</td> <td>HO2S-12</td> <td>35 and 97</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Is the voltage leading operator than 1.5 volts? | DTC | HO2S | PINS | P0136 | HO2S-12 | 35 and 97 | Yes | Go to Step 9. |
| DTC | HO2S | PINS | | | | | | | |
| P0136 | HO2S-12 | 35 and 97 | | | | | | | |
| | | No | Go to next Step. | | | | | | |
| 7 | CHECK CONTINUITY OF HO2S GROUND CIRCUIT IN THE PCM <ul style="list-style-type: none"> • Key off. • PCM connected to breakout box. Vehicle harness disconnected from breakout box. • Measure the resistance between SIG RTN Test Pin and PWR GND Test Pin at the breakout box. • Is the resistance reading less than 5.0 ohms? | Yes | REMOVE breakout box. RECONNECT PCM. Go to next Step. | | | | | | |
| | | No | REPLACE PCM. REMOVE breakout box. RECONNECT all comonents. | | | | | | |
| 8 | APPLY 12 VOLTS TO HO2S CIRCUIT <ul style="list-style-type: none"> • Key off. • HO2S disconnected. • Jumper VPWR to HO2S signal circuit at the vehicle harness connector. • Key on. • Access HO2S PID and Monitor. • Is the PID voltage greater than 1.5 volts? | Yes | REPLACE HO2S. RECONNECT all components. COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. | | | | | | |
| | | No | REPLACE PCM. RECONNECT all components. COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. | | | | | | |
| 9 | CHECK FOR OVER VOLTAGE ON THE HO2S CIRCUIT IN THE PCM <ul style="list-style-type: none"> • Key on. • PCM connected to vehicle harness. • HO2S disconnected. • Inspect both ends of connect for damaged or pushed out pins, moisture, corrosion, Loose pins, etc. and service as necessary. • Measure the voltage between SIG RTN Test Pin at the HO2S vehicle harness connector and battery negative post. • Measure the voltage between HO2S Signal Test Pin at the HO2S vehicle harness connector and battery negative post. • Are the voltage readings greater than 1.5 volts? | Yes | REPLACE PCM. RECONNECT all components. COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. | | | | | | |
| | | No | REPLACE HO2S. RECONNECT all components. COMPLETE a Drive Cycle (REFER to Drive Cycles). RERUN Quick Test. | | | | | | |

| | | | | | |
|--|---|-----|---|---|---|
| CODE No. | DTC P0171, P0172, P1130, P1131, P1132 | | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0171 indicate the fuel/air ratio is too lean. The fuel adaptive system is at the rich correction limit • DTC P0172 indicate the fuel/air ratio is too rich. The fuel adaptive system is at the lean correction limit • DTC P1130 indicate the fuel control system has reached its maximum compensation for lean or rich condition and the HO2S is not switching • DTC P1131 indicate the fuel/air ratio is correcting rich for an overly lean condition. The HO2S voltage is less than 0.45 volts • DTC P1132 indicate the fuel/air ratio is correcting lean for an overly rich condition. The HO2S voltage is greater than 0.45 volts | | | | |
| <p>[Possible Cause]</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>Fuel System</p> <ul style="list-style-type: none"> • Excessive fuel pressure • Leaking fuel injector(s) • Low fuel pressure • Contaminated injector(s) <p>Base Engine</p> <ul style="list-style-type: none"> • Oil over fill • Cam timing • Cylinder compression • Exhaust leaks before or near the HO2S's </td> <td style="width: 50%; vertical-align: top;"> <p>Induction System</p> <ul style="list-style-type: none"> • Air leaks after the MAF sensor • Vacuum leaks • Restricted air inlet • PCV system • Fuel purge system • Improperly seated Dipstick <p>EGR System</p> <ul style="list-style-type: none"> • Leaking gasket • Stuck open EGR valve • Leaking diaphragm </td> </tr> </table> | | | | <p>Fuel System</p> <ul style="list-style-type: none"> • Excessive fuel pressure • Leaking fuel injector(s) • Low fuel pressure • Contaminated injector(s) <p>Base Engine</p> <ul style="list-style-type: none"> • Oil over fill • Cam timing • Cylinder compression • Exhaust leaks before or near the HO2S's | <p>Induction System</p> <ul style="list-style-type: none"> • Air leaks after the MAF sensor • Vacuum leaks • Restricted air inlet • PCV system • Fuel purge system • Improperly seated Dipstick <p>EGR System</p> <ul style="list-style-type: none"> • Leaking gasket • Stuck open EGR valve • Leaking diaphragm |
| <p>Fuel System</p> <ul style="list-style-type: none"> • Excessive fuel pressure • Leaking fuel injector(s) • Low fuel pressure • Contaminated injector(s) <p>Base Engine</p> <ul style="list-style-type: none"> • Oil over fill • Cam timing • Cylinder compression • Exhaust leaks before or near the HO2S's | <p>Induction System</p> <ul style="list-style-type: none"> • Air leaks after the MAF sensor • Vacuum leaks • Restricted air inlet • PCV system • Fuel purge system • Improperly seated Dipstick <p>EGR System</p> <ul style="list-style-type: none"> • Leaking gasket • Stuck open EGR valve • Leaking diaphragm | | | | |
| STEP | INSPECTION | | ACTION | | |
| 1 | <p>Visual checks:</p> <ul style="list-style-type: none"> • Check air intake for leaks, obstructions, and damage. • Check air filter, air filter housing for blockage. • Verify integrity of the PCV system. • Check for vacuum leaks. • Are there any of the above concerns? | Yes | REPAIR as necessary. RERUN Quick Test. | | |
| | | No | Go to next Step. | | |
| 2 | <p>INITIATE KOER SELF-TEST</p> <ul style="list-style-type: none"> • Key off. • Scan Tool connected. • Disconnect Fuel Vapor hose from intake manifold and plug fitting at intake manifold. • Start engine and run at 2,000 rpm for 1 minute and return to idle. • Enter Key On Engine Running (KOER) Self-Test. • Are HO2S DTCs P1131 or P1132 present? | Yes | Go to next Step. | | |
| | | No | <p>For DTC P0171, P0172, P1130 Go to next Step. If DTC P1132 are no longer present. RECONNECT Fuel Vapor line.</p> <p>All others: The fault that produced the DTC is an intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary).</p> | | |
| 3 | <p>CHECK FUEL PRESSURE</p> <p>WARNING: THE FUEL SYSTEM IS PRESSURIZED WHEN THE ENGINE IS NOT RUNNING. TO PREVENT INJURY OR FIRE, USE CAUTION WHEN WORKING ON THE FUEL SYSTEM.</p> <ul style="list-style-type: none"> • Key off. • Install fuel pressure gauge. • Verify vacuum source to fuel pressure regulator. • If engine will start: • Start engine and idle. Record fuel pressure. • Increase engine speed to 2,500 rpm and maintain for one minute. Record fuel pressure. • No Start: • Cycle key on and off several times. Record fuel pressure. • Is the fuel pressure between 35—40 psi (240—280 kPa)? | Yes | Fuel system is capable of required fuel pressure. Go to next Step. | | |
| | | No | Fuel pressure out of specification. | | |
| 4 | <p>CHECK SYSTEM ABILITY TO HOLD FUEL PRESSURE</p> <ul style="list-style-type: none"> • Fuel pressure gauge installed. • Cycle key on and off several times. • Verify there are no external leaks (repair as necessary). • Does the fuel pressure remain within 5 psi of the highest reading after one minute? | Yes | <p>For DTCs P0171, P0172 and P1130 Go to next Step. For No starts: Go to Step 6. For Fuel Control DTC displayed with misfire DTC's. Go to Step 7. All other DTCs: Go to Step 11.</p> | | |
| | | No | Excessive pressure less. | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | |
|------|--|----------|--|---|----|---|-----|---|----|---|-----|-----|--|
| 5 | CHECK SYSTEM ABILITY TO HOLD FUEL PRESSURE WITH KEY ON <ul style="list-style-type: none"> Fuel pressure gauge installed. Cycle key on then off several times. Turn key on and engine off, monitor fuel pressure gauge. Does the fuel pressure remain within 5 psi of the highest reading after 10 seconds? | Yes | For DTCs P0171 and P1130 Go to Step 7. | | | | | | | | | | |
| | | No | For DTC P0172 Go to Step 9. | | | | | | | | | | |
| 6 | CHECK ABILITY OF INJECTOR(S) TO DELIVER FUEL <ul style="list-style-type: none"> Pressure gauge installed. Cycle key several times. Monitor pressure gauge while cranking the engine for at least five seconds. Was there a pressure drop greater than 5 psi (34 kPa)? | Yes | The EEC-V System is not the cause of the no start. REMOVE the fuel pressure gauge. REFER to TROUBLESHOOTING GUIDE for further diagnosis. | | | | | | | | | | |
| | | No | REMOVE fuel pressure gauge. RECONNECT IFS switch. Go to next Step. | | | | | | | | | | |
| 7 | CHECK RESISTANCE OF INJECTOR(S) AND HARNESS <ul style="list-style-type: none"> Key off. Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. <p>NOTE: This erases Continuous Memory DTCs.</p> <ul style="list-style-type: none"> Install breakout box, leave PCM disconnected. <p>NOTE: If a misfire DTC(s) are displayed with the Fuel Control DTC(s), use the misfire DTC(s) to determine the injector circuit(s) requiring testing.</p> <ul style="list-style-type: none"> Measure resistance between suspect injector Test Pin(s) and Test Pin 71 or 97 at the breakout box using the chart below. <table border="1" data-bbox="215 1087 727 1276"> <thead> <tr> <th>Cyl. No.</th> <th>Test Pin</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>75</td> </tr> <tr> <td>2</td> <td>101</td> </tr> <tr> <td>3</td> <td>74</td> </tr> <tr> <td>4</td> <td>100</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance between 11.0—18.0 ohms? | Cyl. No. | Test Pin | 1 | 75 | 2 | 101 | 3 | 74 | 4 | 100 | Yes | Fuel injector and harness resistance is OK. Go to Step 10. |
| | | Cyl. No. | Test Pin | | | | | | | | | | |
| 1 | 75 | | | | | | | | | | | | |
| 2 | 101 | | | | | | | | | | | | |
| 3 | 74 | | | | | | | | | | | | |
| 4 | 100 | | | | | | | | | | | | |
| No | Go to next Step. | | | | | | | | | | | | |
| 8 | CHECK CONTINUITY OF FUEL INJECTOR HARNESS <ul style="list-style-type: none"> Key off. Breakout box installed, PCM disconnected. Disconnect injector harness connector at the suspect injector. Measure the resistance between Test Pin 71 or 97 at the breakout box and the VPWR pin at the injector harness connector. Measure resistance between the Injector Test Pin(s) at the breakout box and the Injector Signal Pin at the injector connector. (Refer to chart in Step 7 for Injector Pin location.) Is each resistance less than 5.0 ohms? | Yes | Go to next Step. | | | | | | | | | | |
| | | No | SERVICE open harness circuit. REMOVE breakout box. RECONNECT PCM and fuel injectors. RERUN Quick Tests. | | | | | | | | | | |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 9 | <p>CHECK INJECTOR HARNESS CIRCUIT FOR SHORT TO POWER OR GROUND</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • Suspect fuel injector harness disconnected. • Measure resistance between the Injector Test Pin(s) and Test Pin 71 or 97, 24, 76 and 103 at the breakout box (refer to chart in Step 7). • Measure the resistance between the Injector Test Pin(s) at the breakout box and chassis ground. • Is each resistance greater than 10,000 ohms? | Yes | Go to Step 10. |
| | | No | <p>SERVICE short circuit. REMOVE breakout box. RECONNECT PCM and all fuel injector(s). RERUN Quick Test.</p> |
| 10 | <p>CHECK INJECTOR DRIVER SIGNAL Requires standrad 12 volt test lamp.</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed. • Connect PCM to breakout box. • Connect test lamp between Test Pin 71 or 97 and each injector Test Pin (refer to chart in Step 7). • Crank or start engine. <p>NOTE: Properly operating system will show a dim glow at idle on the test lamp.</p> <ul style="list-style-type: none"> • Does test lamp have a dim glow while cranking or running engine? | Yes | <p>REMOVE breakout box. RECONNECT PCM. Go to next Step.</p> |
| | | No | <p>No light/Continuous bright light. REPLAE PCM. REMOVE breakout box. RERUN Quick Test.</p> |
| 11 | <p>FLOW TEST FUEL INJECTOR(S) • Is the leakage and flow within specification?</p> | Yes | <p>DTCs P0171 and P0172 The fault that produced the DTC is an intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). DTC P1130 Go to Step 13. All others: Go to next Step.</p> |
| | | No | <p>REPLACE Fuel injector. RERUN Quick Test.</p> |
| 12 | <p>CHECK CYLINDER COMPRESSION</p> <p>NOTE: Use the Misfire DTC(s) displayed on prior DTC retrieval to determine which cylinder(s) to check compression.</p> <ul style="list-style-type: none"> • Check cylinder compression. Refer to Section B1. • Are cylinder compression readings within specification? | Yes | <p>For DTCs P1130 and P1131 Go to next Step. For DTC P1132 Go To Step 19. Misfire DTC's displayed with Fuel Control DTC's Go to DTCs P0300, P0301, P0302, P0303, P0304.</p> |
| | | No | <p>REPAIR as necessary. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 13 | <p>CHECK HO2S INTEGRITY Diagnostic Trouble Code DTC P1131 and/or P1130 indicate HO2S always lean, slow to switch, lack of switching or fuel at adaptive limit. Possible causes: – Moisture inside the HO2S harness connector resulting in a short to ground – HO2S coated with contaminates – HO2S circuit open – HO2S circuit shorted to ground</p> <ul style="list-style-type: none"> • Key off. • Inspect HO2S harness for chafing, burned out wires or other damage and service. • Inspect HO2S and connector for indications of submersions in water, oil, coolant, etc., and service. • Run engine at 2,000 rpm for two minutes. • Key off. • Activate Key On Engine Running (KOER) Self-Test. • Is DTC P1131 present? | Yes | Go to next Step. |
| | | No | <p>HO2S system is OK. Fuel delivery system is OK. Faults may have been repaired while doing inspection. Testing is complete at this time.</p> |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 14 | <p>CHECK HO2S ABILITY TO GENERATE A VOLTAGE GREATER THAN 0.5 VOLT Any vacuum or air leaks in non-EEC areas could cause DTCs P1131 and P1130. Possible causes:</p> <ul style="list-style-type: none"> - Leaking vacuum actuators - Engine sealing - EGR system - PCV system - Unmetered air leaks between throttle body and Mass Air Flow (MAF) sensor assembly - Silicone contaminated HO2S <ul style="list-style-type: none"> • Key off. • Disconnect the suspect HO2S from vehicle harness. • Connect DVOM to the HO2S Signal and HO2S SIG RTN or HO2S GND at the HO2S sensor connector. • DVOM on 20 volt scale. • Run engine at 2,000 rpm for two minutes. • Rerun KOER Self-Test and monitor HO2S voltage. • Does DVOM indicate greater than 0.5 volt during or at the end of Self-Test? | Yes | Go to next Step. |
| | | No | REPLACE HO2S. RERUN Quick Test. |
| 15 | <p>CHECK CONTINUITY OF HO2S AND HO2S GROUND CIRCUITS</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • Disconnect suspect HO2S from harness. Inspect both ends of connector for damaged or pushed out pins, moisture, corrosion, loose pins, etc., and service. • Measure the resistance between HO2S Signal Test Pin at the breakout box and the HO2S vehicle harness connector. Use the Pin assignment below and record the reading. • Measure resistance between SIG RTN test pin at the breakout box and HO2S SIG RTN vehicle harness connector. Record readings. <ul style="list-style-type: none"> - HO2S-11 SIG = Test Pin 60 - HO2S-21 SIG = Test Pin 87 - HO2S SIG RTN = Test Pin 91 • Is the resistance reading less than 5.0 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open circuit. REMOVE breakout box. RECONNECT PCM and HO2S. RERUN Quick Test. |
| 16 | <p>CHECK HO2S CIRCUIT WIRING HARNESS FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • HO2S disconnected. • Measure resistance between the HO2S Signal Test Pin and Test Pins 24, 51, 76, 77 and 103 at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | SERVICE short circuit. REMOVE breakout box. RECONNECT PCM and HO2S. RERUN Quick Test. |
| 17 | <p>CHECK HO2S FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • HO2S connected. • Measure resistance between PWR GND/SIG RTN Test Pin and HO2S Signal Test Pin at the breakout box. <ul style="list-style-type: none"> HO2S-11 SIG = Test Pin 60 HO2S-21 SIG = Test Pin 87 HO2S PWR GND = Test Pin 24, 76 and 103 HO2S SIG RTN = Test Pin 91 • Is resistance greater than 10,000 ohms? | Yes | For DTCs 1130 Go to next Step. For DTCs 1131 Go to Step 23. For KOER DTCs P1131. REMOVE breakout box. RECONNECT HO2S. REPLACE PCM. |
| | | No | REPLACE HO2S. REMOVE breakout box. RECONNECT PCM. RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 18 | CHECK FOR DTCS P1132 AND P1152 WITH P1130 AND P1150 <ul style="list-style-type: none"> • Key off. • Scan Tool connected. • Activate Key On Engine Running (KOER) Self-Test. • Is DTC P1132 present? | Yes | Go to next Step. |
| | | No | The fault that produced the DTC is an intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |
| 19 | CHECK FOR HO2S SIGNAL SHORTED TO POWER Diagnostic Trouble Codes (DTCs) P1132 and/or P1130 indicate HO2S always rich. Possible causes: – Moisture inside the HO2S harness connector resulting in a short to power – HO2S circuit shorted to power DTC P1130, P1132=HO2S-11 <ul style="list-style-type: none"> • Key on, engine off. • Scan Tool connected. • Access the Parameter Identification (PID) for the DTC generated. NOTE: HO2S displayed as O2S on Scan Tool. <ul style="list-style-type: none"> • Is the voltage greater than 1.0 volt and less than 4.0 volts? | Yes | An over voltage condition exists in the HO2S circuit. Go to next Step. |
| | | No | Go to Step 22. |
| 20 | CHECK FOR SHORTS TO VOLTAGE SOURCE IN THE HARNESS CIRCUIT <ul style="list-style-type: none"> • Key off. • Suspect sensor disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Use the following list to measure the resistance between the appropriate test pins at the breakout box. <ul style="list-style-type: none"> – DTC P1130, P1132=HO2S-11 Test Pin 60 and Test Pins 71, 93 and 97 – DTC P1150, P1152=HO2S-21 Test Pin 87 and Test Pins 71, 93 and 97 • Is the resistance greater than 10,000 ohms? | Yes | REMOVE breakout box. RECONNECT PCM. Go to next Step. |
| | | No | REPAIR short to power. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 21 | CHECK FOR HO2S SIGNAL SHORTED TO HO2S HEATER CIRCUIT IN THE SENSOR <ul style="list-style-type: none"> • Key off. • Suspect HO2S sensor disconnected. • Scan Tool connected. • Key on, engine off. • Access HO2S PID corresponding to DTCs received. NOTE: HO2S displayed as O2S on Scan Tool. <ul style="list-style-type: none"> • Is the HO2S voltage less than 0.2 volt? | Yes | REPLACE HO2S. RECONNECT all components. RERUN Quick Test. |
| | | No | REPLACE PCM. RECONNECT all components. RERUN Quick Test. |
| 22 | ATTEMPT TO GENERATE DTCS P1131 AND P1151 <ul style="list-style-type: none"> • Key off. • HO2S disconnected. • Jumper HO2S Signal at the HO2S harness vehicle connector to the battery negative post. • Activate Key On Engine Running (KOER) Self-Test. • Are DTCs P1131 or P1151 present? | Yes | REMOVE jumper. Go to next Step. |
| | | No | REMOVE jumper. RECONNECT HO2S. DISCONNECT PCM. INSPECT both ends of connector for damaged or pushed out pins, moisture, corrosion, loose pins, etc. and service as necessary. If OK, REPLACE PCM. RERUN KOER Self-Test. |

| STEP | INSPECTION | ACTION |
|------|---|--|
| 23 | HO2S CHECK <ul style="list-style-type: none"> • Key off. • Suspect HO2S disconnected. • Connect DVOM to HO2S Signal circuit and HO2S SIG RTN at the HO2s sensor connector. • DVOM on 20 volt scale. • Disconnect vacuum hose from vacuum tree. • Start engine and run at 2,000 rpm. • Does the DVOM indicate less than 0.4 volt within 30 seconds? | Yes RECONNECT vacuum hose and HO2S. Go to next Step. |
| | | No REPLACE HO2S. RECONNECT vacuum hose. RERUN Quick Test. |
| 24 | MONITOR HO2S (PID) FOR NORMAL SWITCHING <ul style="list-style-type: none"> • Key on, engine running. • Engine at operating temperature. • Access suspect HO2S PID using Scan Tool. <p>NOTE: HO2S displayed as O2S on Scan Tool.</p> <ul style="list-style-type: none"> • Access HO2S PID while wiggling, bending, and shaking small sections of the EEC harness from the PCM to the HO2S. • Did the HO2S voltage stay high (greater than 0.45 volt) or low (less than 0.45 volt)? | Yes ISOLATE cause of lack of HO2S switches and service. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 25 | TEST DRIVE WHILE MONITORING HO2S PID FOR NORMAL SWITCHING <p>NOTE: This test step requires an observer to monitor PID for proper operation.</p> <ul style="list-style-type: none"> • Scan Tool still attached. • Access HO2S PID. • While observer views PID, test drive vehicle under different road conditions in an attempt to simulate the original fault. • Does HO2S appear to switch properly? | Yes UNABLE to duplicate fault. CLEAR any DTCs. Testing complete at this time. |
| | | No REPLACE HO2S. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|-------------------------|---|--|
| CODE No. | P0230, P1235, P1236 (KOEO, KOER) | |
| DESCRIPTION | • DTCs P0230, P1235 or P1236 indicate a fuel pump circuit failure | |
| [Possible Cause] | • Open or shorted circuit | |
| • Damaged FPR | | |
| • Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FOR VPWR TO FPR • Disconnect the FPR. • Key on, engine off. • Measure voltage between VPWR circuit at the FPR vehicle harness connector and chassis ground. • Is voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in VPWR circuit between the ignition switch and the FPR. RECONNECT the FPR. RERUN Quick Test. |
| 2 | CHECK FPR • Key off. • FPR disconnected. • Check FPR coil resistance: – Measure resistance between terminals A and B at the FPR – Resistance should be less than 5 ohms • Check FPR for internal shorts. – Measure resistance between terminals C and D at the FPR – Resistance should be greater than 10,000 ohms • Are all resistance checks OK? | Yes Go to next Step. |
| | | No REPLACE FPR. RERUN Quick Test. |
| 3 | CHECK FUEL PUMP CIRCUIT FOR SHORT TO POWER • Key off. • FPR disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Key on, engine off. • Measure voltage between Test Pin 80 (FP) at the breakout box and chassis ground. • Is voltage less than 1.0 volt? | Yes Go to next Step. |
| | | No SERVICE short to power. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 4 | CHECK FUEL PUMP CIRCUIT FOR SHORT TO GROUND • Key off. • Disconnect NGS from DLS. • Breakout box installed, PCM disconnected. • FPR disconnected. • Measure resistance between Test Pin 80 and Test Pins 51 or 103 (PWR GND) and 91 (SIG RTN) at the breakout box. • Is resistance greater than 10,000 ohms? | Yes Go to next Step. |
| | | No SERVICE short circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 5 | CHECK FUEL PUMP CIRCUIT CONTINUITY • Key off. • Breakout box installed, PCM disconnected. • FPR disconnected. • Measure resistance between Fuel Pump circuit at the FPR vehicle harness connector and Test Pin 80 at the breakout box. • Is resistance less than 5.0 ohms? | Yes REPLACE PCM. RECONNECT all components. RERUN Quick Test. |
| | | No SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|---|--|---------------|
| CODE No. | P0230, P1235, P1236 (CONTINUOUS) | |
| DESCRIPTION | • DTCs P0230, P1235 or P1236 indicate a fuel pump circuit failure has occurred during vehicle operation | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Open in VPWR to FPR • Open in Fuel Pump circuit (PCM Pin 80) • Open coil in FPR | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK EEC-V HARNESS <ul style="list-style-type: none"> • NGS connected. • Key on, engine off. Wait 5 seconds. • Access FPA PID. The FPA PID will be off, indicating that the PCM detects VPWR voltage through the FPR coil and FP circuit (Pin 80) to the PCM. • Observe the FPA PID for an indication of a fault while performing the following (the FPA PID will turn on, when an open is detected (this is because the PCM will not detect VPWR voltage on Pin 80 (FP))): <ul style="list-style-type: none"> – Shake, wiggle, bend the fuel pump circuit between the PCM (Pin 80) and the FPR – Shake, wiggle bend the VPWR circuit between the ignition switch and the FPR – Lightly tap the FPR (to simulate road shock) • Key off. • Inspect the PCM and FPR connectors for corrosion, damaged pins, etc. • Is a fault indicated? | Yes |
| | | No |

| | | |
|---|---|---|
| CODE No. | P0300, P0301, P0302, P0303, P0304 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0300 indicates multiple cylinders misfiring, or cannot identify cylinder due to Camshaft Position sensor failure | |
| <p>[Possible Cause]</p> <ul style="list-style-type: none"> • Ignition system • Fuel injection • Fuel pressure • Evaporative system • Canister purge • Base engine • Running out of fuel | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK POSSIBLE CAUSES TO MISFIRE NOTE: Running out of fuel may turn on the MIL and possibly store a Continuous Misfire DTC. <ul style="list-style-type: none"> • Has the vehicle recently run out of fuel? | Yes OBD II system OK. COMPLETE PCM. RESET to clear DTCs. RETURN vehicle to customer. |
| | | No Go to next Step. |
| 2 | CHECK FOR OTHER CONTINUOUS MEMORY (DTCS) Check for other Continuous Memory DTCs which COULD cause the Misfire DTC. Possible causes: – Camshaft Position Sensor (CID) – Octane Adjust (Oct Adj) – Ignition Coil Primary Circuit – Knock Sensor (KS) <ul style="list-style-type: none"> • Are there any other Continuous Memory DTCs present? | Yes ADDRESS the next Continuous DTC. DISREGARD Misfire DTC at this time. Go to DTC charts. |
| | | No Go to next Step. |
| 3 | CHECK FOR ON-DEMAND SELF-TEST DTCS NOTE: CHECK for any Key On Engine off DTCs, which could cause the Misfire DTC. <ul style="list-style-type: none"> • Are any Key On Engine Off DTCs displayed on the Scan Tool? | Yes Go to DTC charts and PROCEED as required. |
| | | No CHECK spark plugs and secondary wires. If OK, Go to next Step. |
| 4 | CHECK FOR KEY ON ENGINE RUNNING DTCS NOTE: Check for any Key On Engine Running DTC's which could cause the misfire DTC's. <ul style="list-style-type: none"> • Are any Key On Engine Running DTC's displayed on the Scan Tool? | Yes If DTC P1131 or P1151 are present, Go to DTC charts and PROCEED as required. |
| | | No Go to next Step. |
| 5 | CHECK RESISTANCE OF INJECTOR(S) AND HARNESS <ul style="list-style-type: none"> • Key off. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires etc. Service as necessary. NOTE: This erases Continuous Memory DTCs. <ul style="list-style-type: none"> • Install breakout box, leave PCM disconnected. • Measure resistance between suspect injector test pin and Test Pin 71 or 97 at the breakout box. • Is the resistance between 11.0–18.0 ohms? | Yes Injector and harness resistance is OK, Go to next Step. |
| | | No Go to DTC P0171, P0172, P1130, P1131, P1132. Step 8 to evaluate fuel injectors. |

| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 6 | <p>CHECK INJECTOR DRIVER SIGNAL</p> <p>NOTE: Requires a standard 12 volt test lamp.</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed. • Connect PCM to breakout box. • Connect Test Lamp between Test Pin 71 or 97 and suspect injector test pin. • Start engine. • Does test lamp have a dim glow while running engine? <p>NOTE: Properly operating system will show a dim glow on the Test Lamp.</p> | Yes | Go to next Step. |
| | | No | No light or bright light. REPLACE PCM. REMOVE breakout box. RERUN Quick Test. |
| 7 | <p>CHECK FUEL PRESSURE</p> <p>WARNING: THE FUEL SYSTEM WILL REMAIN PRESSURIZED WHEN ENGINE IS NOT RUNNING. TO PREVENT INJURY OR FIRE, USE CAUTION WHILE WORKING ON THE FUEL SYSTEM.</p> <ul style="list-style-type: none"> • Key off. • Install fuel pressure gauge. • Start and run engine at idle. Record fuel pressure. • Increase engine speed to 2,500 rpms and maintain for one minute. Note and compare fuel pressure. • Is fuel pressure between 35—40 psi (240—280 kPa)? | Yes | Go to next Step. |
| | | No | CHECK THE FUEL SYSTEM. |
| 8 | <p>CHECK ABILITY OF FUEL SYSTEM TO HOLD FUEL PRESSURE</p> <ul style="list-style-type: none"> • Start and run engine at idle. Note fuel pressure. • Increase engine speed to 2,500 rpms and maintain for one minute. • Visually look for fuel leaking at the injector O-ring, fuel pressure regulator and the fuel lines to the fuel charging assembly. Service as necessary. • Turn engine off. • Key on, engine off. • Does fuel pressure remain at specification within 5 psi for 60 seconds? | Yes | Go to next Step. |
| | | No | CHECK System is at fault. |
| 9 | <p>CHECK FUEL INJECTOR FOR FLOW AND LEAKAGE</p> <ul style="list-style-type: none"> • Verify that the flow rate for each fuel injector is within specification. • Is flow rate for each injector within specification? | Yes | Fuel Delivery System is not considered the likely area to have caused the Misfire DTC. Go to next Step to evaluate the Vacuum System. |
| | | No | REPLACE or CLEAN the defective injector(s) as required. RERUN Quick Test. |
| 10 | <p>CHECK VACUUM SYSTEM</p> <ul style="list-style-type: none"> • Visually inspect all vacuum lines for damage, such as pinched lines, cracks, proper routing and assembly. <p>NOTE: Some vacuum leaks can be found audibly.</p> <ul style="list-style-type: none"> • Is the vehicle vacuum system OK? | Yes | Go to next Step. |
| | | No | SERVICE the vacuum system. RERUN Quick Test. |
| 11 | <p>CHECK EVAPORATIVE EMISSION SYSTEM</p> <p>The Misfire Monitor can be influenced by Evaporative Emission System. The next four steps will evaluate the Evaporative Emission System.</p> <ul style="list-style-type: none"> • Check the carbon canister for fuel saturation. • Is there an excess amount of liquid fuel present in the canister? | Yes | REPLACE carbon canister. RERUN Quick Test. |
| | | No | Go to next Step. CHECK fuel tank vent system. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 12 | PRESSURE TEST EVAPORATIVE SYSTEM • Remove vapor line at canister. • Install a TEE in the line. • Install a pressure gauge to one side of TEE. • Supply air to the other side of TEE, up to a maximum of 75 psi. • Is evaporative emission system holding pressure? | Yes | RECONNECT canister line, Go to next Step. |
| | | No | SERVICE as necessary. RERUN Quick Test. |
| 13 | CHECK VACUUM IN EVAPORATIVE SYSTEM • Check for blockage/restrictions or cut hoses between engine vacuum port and carbon canister. • Check for blockage in fuel tank vent system. • Is there a fault indicated? | Yes | REPLACE damaged vacuum hoses, or REMOVE blockage/restrictions. RERUN Quick Test. |
| | | No | Go to next Step. |
| 14 | CHECK CANISTER PURGE SOLENOID (CANP) This step will verify the mechanical integrity of (CANP). The solenoid and circuit have been checked electrically and reported during KOEO Self-Test. • Key off. • Disconnect (CANP) solenoid. • Connect 12 volt DC power source to solenoid. • CAUTION must be observed for proper pin orientation. • Connect positive power source to VPWR circuit and negative lead to CANP circuit at the CANP solenoid harness connector. • Apply 53 kPa (16 in-Hg) of vacuum to the manifold side of the CANP solenoid. Apply power source. • Does the solenoid open and pass air freely? | Yes | Evaporative System is functioning properly. Go to next Step for Base Engine concerns. |
| | | No | REPLACE Canister Purge solenoid. RERUN Quick Test. |
| 15 | CHECK FOR BASE ENGINE CONCERNS The purpose of this step is to determine if there are any Base Engine concerns that may have caused the Misfire DTC or drive concern. Perform the following tests in order to evaluate Base Engine integrity. • Perform an Engine Compression test. • Perform Dynamic Valve Train analysis. • Check Positive Crankcase Ventilation System. • Check possible leakage points. Refer to section B. • Is any service required? | Yes | SERVICE as necessary. RERUN Quick Test. |
| | | No | The cause of the Misfire DTC is intermittent and diagnosis will be in the Ignition System. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). FOLLOW instructions for using the Ignition Intermittent Analyzer, also known as the DIST tool. |

| | | |
|-------------------------|---|--|
| CODE No. | P0340 | |
| DESCRIPTION | • DTC P0340 Indicates that Self-Test has detected a Camshaft Position (CMP) sensor circuit failure | |
| [Possible Cause] | <ul style="list-style-type: none"> • CID circuit open • CID circuit shorted to GND • CID circuit shorted to PWR • PWR GND open • VPWR open • Damaged CMP Sensor • Damaged PCM | |
| STEP | INSPECTION | ACTION |
| 1 | START ENGINE <ul style="list-style-type: none"> • Start engine. • Will the engine start? | Yes Go to next Step. |
| | | No DTC P0340 is not the cause of the no start. Go to No start symptom. |
| 2 | CLEAR AND ATTEMPT TO RE-GENERATE DTC P0340 <ul style="list-style-type: none"> • Complete PCM Reset to clear DTCs (refer to PCM Reset). • Start engine. • Increase rpm to greater than 1,500 rpm for 10 seconds. Repeat two times. • Key off. • Retrieve all Continuous Memory DTCs. • Is DTC P0340 present? | Yes Go to next Step. |
| | | No The fault that produced DTC P0340 is intermittent. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |
| 3 | CHECK VPWR TO CMP SENSOR <ul style="list-style-type: none"> • Key off. • Disconnect CMP sensor vehicle harness connector. • Key on, engine off. • Measure voltage between VPWR circuit at the CMP vehicle harness connector and battery negative post. • Is voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in VPWR circuit. RECONNECT all components. COMPLETE PCM. Reset to clear DTCs. |
| 4 | CHECK PWR GND TO CMP SENSOR <ul style="list-style-type: none"> • Key off. • CMP sensor disconnected. • Measure resistance between PWR GND circuit at the CMP vehicle harness connector and battery negative post. • Is resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open in PWR GND circuit. COMPLETE PCM. Reset to clear DTCs (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK CONTINUITY TO PCM <ul style="list-style-type: none"> • Key off. • CMP sensor vehicle harness connector disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between CID circuit at the CMP vehicle harness connector and Test Pin 85 (CID) at the breakout box. • Are resistance measurements less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 6 | CHECK CID FOR SHORT TO POWER <ul style="list-style-type: none"> • Key off. • CMP sensor disconnected. • Breakout box installed, PCM disconnected. • Key on, engine off. • Measure voltage between Test Pin 85 (CID) and Test Pins 51 and 103 (PWR GND) at the breakout box. • Is voltage less than 1.0 volt? | Yes Go to next Step. |
| | | No SERVICE CID circuit for short to power. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 7 | CHECK CID FOR SHORT TO GND <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • CMP sensor disconnected. • Measure resistance between Test Pin 85 (CID) and Test Pins 51, 103 (PWR GND) and 91 (SIG RTN). • Is each resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | SERVICE CID circuit for short to GND or SIG RTN. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 8 | CHECK FOR SHORTS IN PCM <ul style="list-style-type: none"> • Key off. • CMP sensor disconnected. • Breakout box installed. • Connect PCM to breakout box. • Measure resistance between Test Pin 85 (CID) and Test Pins 51, 103 (PWR GND), 71, 97 (VPWR), 91 (SIG RTN), and 23 (IGN GND) at the breakout box. • Is each resistance greater than 500 ohms? | Yes | Go to next Step. |
| | | No | REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 9 | CHECK CMP SENSOR OUTPUT <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Reconnect CMP sensor. • DVOM on AC scale (to monitor less than 5.0 volts). • Measure voltage between Test Pin 85 (CID) and Test Pins 51 and 103 (PWR GND) at the breakout box while running engine at varying rpm. • Does AC voltage vary greater than 0.1 volt AC? | Yes | REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No | REPLACE CMP sensor. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|-------------------------|---|--|
| CODE No. | P0400, P1407 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0400 indicates an EGR valve/flow failure • DTC P1407 indicates the EGR valve did not move | |
| [Possible Cause] | <ul style="list-style-type: none"> • Damaged EGRV solenoid • Damaged EGRA solenoid • Damaged EGR valve • Damaged EGR/BP sensor • Damaged EGRC solenoid • Restriction in exhaust system • Damaged PCM • Damaged harness connector • Damaged harness | |
| STEP | INSPECTION | ACTION |
| 1 | OUTPUT ALL DTCs <ul style="list-style-type: none"> • Output all components memory, KOEO and KOER self-test DTCs. • Is P0106, P0107, P0108, P1400, P1401 or P1408 output? NOTE: If any other DTCs are output, record them and address them after completing this troubleshooting. | Yes Go to DTC P0106, P0107, P0108, P1400, P1401 or P1408 troubleshooting. |
| | | No Go to next Step. |
| 2 | CHECK VPWR TO EGRC SOLENOID <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Key on, engine off. • Measure voltage between VPWR circuit and chassis ground at the EGRC solenoid vehicle harness connector. • Is EGRC VPWR voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in EGRC solenoid VPWR circuit. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK RESISTANCE OF EGRC SOLENOID <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Measure solenoid resistance. • Is resistance between 30 and 70 ohms? | Yes Go to next Step. |
| | | No REPLACE the EGRC solenoid. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK EGRC SOLENOID CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between Test Pin 98 (EGRC) at the breakout box and the EGRC circuit at the solenoid vehicle harness connector. • Is the resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open in EGRC harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK EGRC SOLENOID CIRCUIT FOR SHORT TO POWER AND SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • EGRC solenoid disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 98 (EGRC) and Test Pins 71, 97 (VPWR) and 90 (VREF) at the breakout box. • Measure resistance between Test Pin 98 (EGRC) and Test Pins 51, 103 (PWR GND) and 91 (SIG RTN) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes REMOVE breakout box. RECONNECT all components. Go to next Step. |
| | | No SERVICE short in EGRC solenoid harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | ACTION | | | | |
|------|--|--|-----|---|----|---|
| 6 | <p>CHECK OPERATION OF EGRC SOLENOID VALVE</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Disconnect the vacuum line from the EGRC solenoid to the intake manifold vacuum reservoir at the EGRC solenoid. Inspect vacuum line for damage, service as necessary. • Install vacuum pump at the input port of the EGRC solenoid and apply 8 to 10"-Hg of vacuum. • Disconnect the vacuum line from the EGRC solenoid to EGR/BP sensor at the EGR/BP sensor. Inspect vacuum line for damage, service as necessary. • Install a vacuum gauge at the unattached end of the vacuum line. • Key on. • Jumper Test Pin 98 (EGRC) to ground at the breakout box and observe the vacuum gauge. Remove jumper. • Apply 8 to 10"-Hg of vacuum to the EGRC solenoid once again. • Again jumper Test Pin 98 (EGRC) to ground at the breakout box and observe the vacuum gauge. Remove jumper. • Key off. • Was a vacuum signal indicated at any time by the vacuum gauge? | <table border="0" style="width: 100%;"> <tr> <td style="width: 50px; vertical-align: top;">Yes</td> <td>REMOVE the vacuum pump and gauge. RECONNECT all vacuum lines. Intermittent poor connection or component malfunction. (REPAIR or REPLACE as necessary).</td> </tr> <tr> <td style="vertical-align: top;">No</td> <td>REPLACE the damaged EGRC solenoid. REMOVE breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</td> </tr> </table> | Yes | REMOVE the vacuum pump and gauge. RECONNECT all vacuum lines. Intermittent poor connection or component malfunction. (REPAIR or REPLACE as necessary). | No | REPLACE the damaged EGRC solenoid. REMOVE breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| Yes | REMOVE the vacuum pump and gauge. RECONNECT all vacuum lines. Intermittent poor connection or component malfunction. (REPAIR or REPLACE as necessary). | | | | | |
| No | REPLACE the damaged EGRC solenoid. REMOVE breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. | | | | | |

| | | | |
|---|---|-----|--|
| CODE No. | P0420 | | |
| DESCRIPTION | <ul style="list-style-type: none"> Diagnostic Trouble Code (DTC) P0420 indicates that catalyst system efficiency is below the acceptable threshold | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> Use of leaded fuel Oil contamination Cylinder misfiring Damaged HO2S Damaged ECT sensor Downstream HO2S wires improperly connected Fuel pressure too high Damaged exhaust system pipe Damaged exhaust manifold Damaged muffler/tail-pipe assembly Damaged catalytic converter | | | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK FOR MISFIRE MONITOR DTC NOTE 1: Complete the spark timing check in Quick Test before proceeding with this test step. Spark timing retarded below specification may increase exhaust gas temperature and decrease catalyst efficiency overtime. NOTE 2: Be sure customer has not: (1) Refueled vehicle with leaded gasoline. (2) Experienced high vehicle all consumption. NOTE 3: If entering this Pinpoint Test for symptoms only, go immediately to Step 5. NOTE 4: Internal deterioration of a catalytic converter is usually caused by abnormal engine operation upstream of the catalyst. Events that may produce higher than normal temperatures in the catalyst are particularly suspect. For example, misfiring can cause higher than normal catalyst operating temperatures. <ul style="list-style-type: none"> Key on, engine off. Retrieve and record all Continuous Memory DTCs (MIL and non-MIL). Were any of the following misfire monitor DTCs recorded: P0300, P0301, P0302, P0303 and P0304? | Yes | Go to address the misfire monitor DTC. |
| | | No | Go to next Step. |
| 2 | CHECK FOR HO2S MONITOR DTC NOTE 1: Incorrect HO2S signal input (e.g. rich/lean input signal when the engine is operating under lean/rich conditions) may cause an abnormal temperature increase in the catalyst. NOTE 2: Non-California applications will not have an active HO2S monitor. As a result, a Catalyst Efficiency Monitor DTC can be generated for a rear HO2S concern. To check for a rear HO2S concern on these applications, Go to heated oxygen sensor inspection. If any repair actions are necessary, run KOER Self-Test, to verify the repair. If repair actions are not necessary, go to Step 3. <ul style="list-style-type: none"> Were any of the following HO2S monitor DTCs recorded: P0136 and P0141 (rear HO2S)? | Yes | Go to address the HO2S Monitor DTC. |
| | | No | Go to next Step. |
| 3 | CHECK FOR ANY OTHER DTCS NOTE: ECT sensor DTCs can be an indication that the thermostat is not operating correctly or that the coolant level is not filled to specifications, producing above normal operating temperatures. <ul style="list-style-type: none"> Were any of the following ECT sensor DTCs recorded in: P0117, P0118, P0125 and P1117? | Yes | Go to address the ECT sensor DTCs. |
| | | No | Go to next Step. |
| 4 | CHECK FOR ANY OTHER DTCS <ul style="list-style-type: none"> Were any other DTCs recorded in (not including the initial P0420 DTC)? | Yes | Go to address the DTCs. |
| | | No | Go to next Step. |

| STEP | INSPECTION | ACTION |
|------|--|--|
| 5 | <p>CHECK REAR HO2S WIRING</p> <p>NOTE: If the electrical connections of the rear HO2S are interchanged/crossed, the Catalyst Efficiency Monitor Test will be failed.</p> <ul style="list-style-type: none"> Inspect the wiring of each rear HO2S for proper routing and connection. Are the HO2S wires improperly routed? | <p>Yes</p> <p>Correctly route/connect the rear HO2S harness circuit(s). COMPLETE the PCM Reset to clear all DTCs (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | <p>No</p> <p>No EEC-V root causes related to the DTCs or symptoms Go to next Step.</p> |
| 6 | <p>CHECK FUEL PRESSURE</p> <p>WARNING: THE FUEL SYSTEM WILL REMAIN PRESSURIZED WHEN THE ENGINE IS NOT RUNNING. TO PREVENT INJURY OR FIRE, USE CAUTION WHEN WORKING ON THE FUEL SYSTEM.</p> <p>NOTE: Fuel pressures above specification may produce an abnormally rich air/fuel mixture. The rich air/fuel mixture may cause higher than normal catalyst operating temperatures.</p> <ul style="list-style-type: none"> Key off. Inspect the vacuum hose going to the fuel pressure regulator for proper installation, cracks, etc. Service as necessary. Install fuel pressure gauge. Verify vacuum source to fuel pressure regulator. Start and run the engine at idle. Record the fuel pressure. Increase engine speed to 2,500 rpm and maintain for one minute. Record the fuel pressure. Is the fuel pressure between 35 and 40 psi (240—280 kPa)? | <p>Yes</p> <p>Fuel pressure is OK. REMOVE the fuel pressure gauge. Go to next Step.</p> |
| | | <p>No</p> <p>Fuel pressure is out to specification. Inspect the Fuel Delivery Systems. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 7 | <p>CHECK FOR OBVIOUS LEAK SOURCES IN THE EXHAUST SYSTEM</p> <p>NOTE: If a catalyst is in series with a leaking exhaust system, it can fail the Catalyst Efficiency Monitor test.</p> <ul style="list-style-type: none"> Key off. Inspect the following for leaks, cracks, loose connections or punctures: <ul style="list-style-type: none"> Exhaust manifold Front exhaust pipe Rear exhaust pipe Silencer/tail-pipe assembly Are the above components free of cracks and punctures, etc.? | <p>Yes</p> <p>CHECK that the exhaust manifold to catalyst inlet pipe joint is tight. Go to next Step.</p> |
| | | <p>No</p> <p>REPLACE/REPAIR the leak source(s). RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 8 | <p>CHECK FOR OBVIOUS RESTRICTIONS IN THE EXHAUST SYSTEM</p> <ul style="list-style-type: none"> Inspect the following for dents, areas of collapsed material and unusual bending: <ul style="list-style-type: none"> Front exhaust pipe Rear exhaust pipe Silencer/tail-pipe assembly Are the above components free of dents and areas of collapsed material or unusual bending, etc.? | <p>Yes</p> <p>Go to next Step.</p> |
| | | <p>No</p> <p>REPLACE/REPAIR the restricted component(s) as necessary. COMPLETE PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 9 | <p>CHECK MANIFOLD VACUUM FOR INDICATION OF EXCESSIVE EXHAUST SYSTEM RESTRICTION</p> <ul style="list-style-type: none"> • Attach a vacuum gauge to the intake manifold vacuum source. • Install a tachometer. • Observe the vacuum gauge needle while performing the following: <p>NOTE: The vacuum gauge reading may be normal when the engine is first started and idled. However, excessive restriction in the exhaust system will cause the vacuum gauge needle to drop to a low point even while the engine is idled.</p> <ul style="list-style-type: none"> – Start the engine and gradually increase the rpm to 2,000 with the transmission in NEUTRAL • Decrease engine speed to base idle rpm. • Key off. • Did manifold vacuum rise above 16 inches Hg with the engine rpm at 2,000? | Yes | Go to next Step. |
| | | No | <p>Manifold vacuum did not reach an acceptable level. An excessive restriction may be present. Go to Step 11.</p> |
| 10 | <p>CHECK MANIFOLD VACUUM FOR INDICATION OF MODERATE EXHAUST SYSTEM RESTRICTION</p> <ul style="list-style-type: none"> • Vacuum gauge installed. • Tachometer installed. • Key on, engine idling. • Increase the engine speed gradually from base idle rpm to 2,000 rpm with the transmission in NEUTRAL. • Observe the speed the vacuum gauge needle rises, while maintaining the increased engine rpm. <p>NOTE 1: On a non-restricted exhaust system, the vacuum gauge needle will rise quickly to the normal range as the increased rpm is maintained.</p> <p>NOTE 2: On a restricted exhaust system, the vacuum gauge needle will rise slowly to the normal range as the increased rpm is maintained.</p> <p>NOTE 3: The rate of speed the vacuum gauge needle rises to the normal range is slower on a restricted system than on a non-restricted system as the increased rpm is maintained.</p> <ul style="list-style-type: none"> • Decrease engine speed to base idle rpm. • Key off. • Is the rate of speed that the vacuum gauge needle rises back to the normal range (above 16 inches Hg) much slower than that of a non-restricted system? | Yes | <p>A moderate restriction may be present. Go to next Step.</p> |
| | | No | <p>No indications of restrictions or leaks have been detected in the exhaust system. If here because of DTC P0420 the catalytic converter is chemically inactive. REPLACE the catalytic converter, being careful to avoid improper routing of the rear HO2S. COMPLETE PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. REMOVE the vacuum gauge and tachometer. For further diagnosis of symptom (e.g. Lack of Power, Loss of Power, or No Start). REFER to TROUBLESHOOTING GUIDE.</p> |
| 11 | <p>CHECK MANIFOLD VACUUM WITH EXHAUST MANIFOLD DISCONNECTED FOR INDICATION OF A RESTRICTION</p> <ul style="list-style-type: none"> • Key off. • Disconnect exhaust system immediately after the exhaust manifold. • Repeat the vacuum measurement found in Step 10. • Did the vacuum needle QUICKLY rise above 16 inches Hg with the engine rpm at 2,000? <p>NOTE: An intake manifold gasket leak can also cause the vacuum gauge needle to remain well below the normal range.</p> | Yes | <p>The exhaust system restriction is downstream of the exhaust manifold. RECONNECT exhaust system at exhaust manifold Go to next Step.</p> |
| | | No | <p>A restriction is present in the exhaust manifold. REMOVE the vacuum gauge and tachometer. INSPECT each exhaust port for casting flash/restrictions by dropping a length of chain into it. (NOTE: Do not use a wire or lamp to check the ports. The restriction may be large enough for either to pass through, but small enough to cause excessive back pressure at high engine rpm.) REPLACE the exhaust manifold if unable to remove the casting flash/restriction. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| STEP | INSPECTION | ACTION | | | | |
|------|--|---|-----|--|----|---|
| 12 | CHECK MANIFOLD VACUUM WITH SILENCER/ TAIL-PIPE ASSEMBLY DISCONNECTED FOR INDICATION OF A RESTRICTION <ul style="list-style-type: none"> • Key off. • Disconnect silencer/tail-pipe assembly located after the catalytic converter. • Repeat the vacuum measurement found in test Step 10. • Did the vacuum needle QUICKLY rise above 16 inches Hg with the engine rpm at 2,000? | <table border="0" style="width: 100%;"> <tr> <td style="width: 50px; vertical-align: top;">Yes</td> <td> There is a restriction in the silencer/tail-pipe assembly. REPLACE the silencer/tail-pipe assembly. REMOVE the vacuum gauge and tachometer. COMPLETE PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. </td> </tr> <tr> <td style="vertical-align: top;">No</td> <td> There is a restriction in the catalytic converter. REMOVE the vacuum gauge and tachometer. REPLACE the catalytic converter, being careful to avoid improper routing of the rear HO2S and INSPECT the silencer to be certain converter debris has not entered. RECONNECT silencer/tail-pipe assembly. RESET KAM (REFER to PCM Reset). RERUN Quick Test. </td> </tr> </table> | Yes | There is a restriction in the silencer/tail-pipe assembly. REPLACE the silencer/tail-pipe assembly. REMOVE the vacuum gauge and tachometer. COMPLETE PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. | No | There is a restriction in the catalytic converter. REMOVE the vacuum gauge and tachometer. REPLACE the catalytic converter, being careful to avoid improper routing of the rear HO2S and INSPECT the silencer to be certain converter debris has not entered. RECONNECT silencer/tail-pipe assembly. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| Yes | There is a restriction in the silencer/tail-pipe assembly. REPLACE the silencer/tail-pipe assembly. REMOVE the vacuum gauge and tachometer. COMPLETE PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. | | | | | |
| No | There is a restriction in the catalytic converter. REMOVE the vacuum gauge and tachometer. REPLACE the catalytic converter, being careful to avoid improper routing of the rear HO2S and INSPECT the silencer to be certain converter debris has not entered. RECONNECT silencer/tail-pipe assembly. RESET KAM (REFER to PCM Reset). RERUN Quick Test. | | | | | |

| | | | |
|-------------------------|--|-----|--|
| CODE No. | P0440 | | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0440 indicates the Evaporative Emission System purge control has been damaged <p>NOTE: If DTC P0443 was received, it should be addressed before P0440</p> | | |
| [Possible Cause] | <ul style="list-style-type: none"> • Damaged vapor line between EVAP canister purge solenoid and intake manifold vacuum reservoir • Damaged EVAP canister purge solenoid • Damaged vapor line between EVAP canister purge solenoid and charcoal canister • Damaged charcoal canister • Damaged vapor line between charcoal canister and check valve • Damaged check valve • Damaged vapor line between check valve and fuel vapor valves • Damaged PCM | | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK FOR MANIFOLD VACUUM AT EVAP CANISTER PURGE SOLENOID <ul style="list-style-type: none"> • Key off. • Disconnect vapor line between EVAP canister purge solenoid and intake manifold vacuum reservoir at the EVAP canister purge solenoid valve. • Key on, engine idling. • Place a finger over the opening of the unattached vapor line end. • Remove the finger from the vapor line. • Key off. • Was a vacuum signal present? | Yes | RECONNECT the vapor line to the EVAP canister purge solenoid. Go to next Step. |
| | | No | INSPECT the vapor line for damage or disconnect. SERVICE as necessary. If vapor line is OK, check intake manifold vacuum reservoir for blockage. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 2 | CHECK EVAP CANISTER PURGE SOLENOID MECHANICAL OPERATION: DE-ENERGIZED <ul style="list-style-type: none"> • Key off. • Disconnect the vapor line between the EVAP canister purge solenoid and the intake manifold vacuum reservoir at the EVAP canister purge solenoid. • Install vacuum pump at intake manifold side of the EVAP canister purge solenoid. • Disconnect the vapor line between the EVAP canister purge solenoid and the charcoal canister at the EVAP canister purge solenoid. • Install vacuum gauge at the charcoal canister side of the EVAP canister purge solenoid. • Apply 8 in-Hg of vacuum to the EVAP canister purge solenoid while observing the vacuum gauge. • Does the vacuum gauge indicate a vacuum signal is passing through the EVAP canister purge solenoid? | Yes | REMOVE vacuum gauge and pump. REPLACE the EVAP canister purge solenoid. RECONNECT all vapor lines. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Go to next Step. |
| 3 | CHECK EVAP CANISTER PURGE SOLENOID MECHANICAL OPERATION: ENERGIZED <ul style="list-style-type: none"> • Key off. • Install breakout box, leave PCM connected. • Vacuum pump installed at intake manifold side of the EVAP canister purge solenoid with 8 in-Hg applied to the EVAP canister purge solenoid. • Vacuum gauge installed at charcoal canister side of EVAP canister purge solenoid. • Key on. • Momentarily jumper to ground Test Pin 67 (EVAP canister purge solenoid SIG) at the breakout box and observe the vacuum gauge. • Key off. • Was a vacuum signal indicated by the vacuum gauge? | Yes | REMOVE the vacuum gauge and pump from the EVAP canister purge solenoid. RECONNECT vapor line between EVAP canister purge solenoid and intake manifold vacuum reservoir. Go to next Step. |
| | | No | REPLACE the EVAP canister purge solenoid. REMOVE the vacuum gauge and pump from the EVAP canister purge solenoid. RECONNECT all vapor lines. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 4 | <p>CHECK VAPOR LINE: CHARCOAL CANISTER TO EVAP CANISTER PURGE SOLENOID</p> <ul style="list-style-type: none"> • Key off. • Disconnect vapor line between charcoal canister and EVAP canister purge solenoid at both ends. • Inspect vapor line for blockage or obstructions. Service as necessary. • Plug one end of the vapor line and install a vacuum pump at the remaining end. • Apply 16 in-Hg of vacuum with the vacuum pump. • Observe the vacuum display for at least 15 seconds. • Release the vacuum applied by the vacuum pump. • Did the vapor line hold the vacuum? | Yes | <p>REMOVE the plug from the remaining end. RECONNECT the vapor line. Go to next Step.</p> |
| | | No | <p>REPLACE the vapor line. REMOVE the vacuum pump. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 5 | <p>CHECK CHARCOAL CANISTER</p> <ul style="list-style-type: none"> • Check for cracks or other damage to the charcoal canister. • Is the charcoal canister cracked or damaged? | Yes | <p>REPLACE the damaged charcoal canister. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | No | <p>Go to next Step.</p> |
| 6 | <p>CHECK VAPOR LINE: CHECK VALVE TO CHARCOAL CANISTER</p> <ul style="list-style-type: none"> • Key off. • Disconnect vapor line between charcoal canister and check valve at both ends. • Inspect vapor line for blockage or obstruction. Service as necessary. • Plug one end of the vapor line and install a hand held pressure pump with gauge at the remaining end. • Apply 1.0 in-Hg of pressure to the vapor line with the pressure pump. • Observe the pressure gauge on the pump for at least 15 seconds. • Did the vapor line hold a constant pressure? | Yes | <p>REMOVE the pressure pump. REMOVE the plug from the remaining end. RECONNECT the vapor line. Go to next Step.</p> |
| | | No | <p>REPLACE the vapor line. REMOVE the vacuum pump. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| 7 | <p>VERIFY OPERATION OF THE CHECK VALVE</p> <p>NOTE: A properly functioning check valve will allow the passage of fuel vapor in only one direction.</p> <ul style="list-style-type: none"> • Key off. • Disconnect both vapor lines from the check valve. • Apply 1.0 in-Hg of pressure to the charcoal canister side of the check valve while placing a finger near the opening at other end of check valve. • Was air flow detected from the check valve? | Yes | <p>REPLACE the check valve. REMOVE the pressure pump. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | No | <p>RECONNECT all components. Go to next Step.</p> |
| 8 | <p>CHECK VAPOR LINE: CHECK VALVE TO FUEL TANK VALVES</p> <ul style="list-style-type: none"> • Key off. • Disconnect vapor line between check valve and fuel tank at both ends. • Inspect vapor line for blockage or obstruction. Service as necessary. • Plug both ends of the vapor line at the fuel tank and install a hand held pressure pump with gauge at the check valve end. • Apply 1.0 in-Hg of pressure to the vapor line with the pressure pump. • Observe the pressure gauge on the pump for at least 15 seconds. • Did the vapor line hold a constant pressure? | Yes | <p>REMOVE the pressure pump. REMOVE the plugs from the remaining ends. RECONNECT the vapor line. CHECK the fuel vapor valve for sticking.</p> |
| | | No | <p>REPLACE the vapor line. REMOVE the vacuum pump. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| | | | |
|-------------------------|---|-----|---|
| CODE No. | P0443 | | |
| DESCRIPTION | • DTC P0443 indicates a failure in the EVAP canister purge solenoid circuit | | |
| [Possible Cause] | <ul style="list-style-type: none"> • VPWR circuit open • EVAP canister purge solenoid SIG open in harness • EVAP canister purge solenoid SIG circuit short to PWR GND or SIG RTN • Damaged EVAP canister purge solenoid • Damaged PCM | | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK EVAP CANISTER PURGE SOLENOID VPWR <ul style="list-style-type: none"> • Key off. • Disconnect EVAP canister purge solenoid. • Key on, engine off. • Measure voltage between VPWR at the EVAP canister purge solenoid vehicle harness connector and battery ground. • Is voltage greater than 10.5 volts? | Yes | Go to next Step. |
| | | No | SERVICE open in VPWR harness circuit. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 2 | CHECK EVAP CANISTER PURGE SOLENOID RESISTANCE <ul style="list-style-type: none"> • Key off. • EVAP canister purge solenoid disconnected. • Measure resistance between EVAP canister purge solenoid SIG and VPWR circuits at the vehicle harness connector. • Is resistance between 27 and 35 ohms? | Yes | Go to next Step. |
| | | No | REPLACE EVAP canister purge solenoid. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK CONTINUITY OF EVAP CANISTER PURGE SOLENOID SIG CIRCUIT <ul style="list-style-type: none"> • Key off. • EVAP canister purge solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between Test Pin 67 (EVAP canister purge solenoid SIG) at the breakout box and the EVAP canister purge solenoid SIG circuit at the solenoid vehicle harness connector. • Is the resistance less than 5.0 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open in harness circuit. REMOVE breakout box. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK EVAP CANISTER PURGE SOLENOID SIG CIRCUIT FOR SHORT PWR GND <ul style="list-style-type: none"> • Key off. • EVAP canister purge solenoid disconnected. • Breakout box installed. • Disconnect Scan Tool from DLC. • Measure the resistance between Test Pin 67 (EVAP canister purge solenoid SIG) and Test Pins 24 and 103 (PWR GND). • Is each resistance greater than 10,000 ohms? | Yes | REPLACE the damaged PCM. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | SERVICE harness short circuit. REMOVE breakout box. RECONNECT all components. VERIFY a symptom no longer exists. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|-------------------------|--|---|
| CODE No. | P0500 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0500 indicates the VSS input signal has been detected out of Self-Test range | |
| [Possible Cause] | <ul style="list-style-type: none"> • Damaged VSS • Damaged PCM • Open in VSS(+)/VSS(-) harness circuit • Short to GND or SIG RTN in VSS(+)/VSS(-) harness circuit • Short to PWR | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK CONTINUITY OF VSS HARNESS CIRCUIT <ul style="list-style-type: none"> • Key off. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc, Service as necessary. • Install breakout box. PCM disconnected. • Disconnect VSS. • Measure resistance between test pin 58 at the breakout box and VSS (+) circuit at VSS vehicle harness connector. • Measure resistance between test pin 33 at the breakout box VSS (-) circuit at VSS vehicle harness connector. • Is each resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open in harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RUN VSS Drive Cycle to verify repair. |
| 2 | CHECK VSS HARNESS CIRCUITS FOR SHORTS TO SIG RTN AND GROUND <ul style="list-style-type: none"> • Key off. • VSS disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 58 and Test Pins 51, 103, 33, 91 and 71 at breakout box. • Measure resistance between Test Pins 33 and 71 at the breakout box. • Is each resistance greater than 500 ohms? | Yes Go to next Step. |
| | | No SERVICE short circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RUN VSS Drive cycle verify the repair. |
| 3 | CHECK VSS RESISTANCE <ul style="list-style-type: none"> • Key off. • VSS disconnected. • Measure the resistance of the VSS. • Is resistance between 190 and 250 ohms? | Yes REMOVE breakout box. REPLACE PCM. RECONNECT VSS. RUN VSS Drive cycle verify the repair. |
| | | No REPLACE VSS. REMOVE breakout box. RECONNECT PCM. RUN VSS Drive cycle verify the repair. |

| | | |
|---|---|---|
| CODE No. | P0505, P1504, P1507 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0505 indicates that Self-Test has detected an IAC system malfunction • DTC P1504 indicates that Self-Test has detected an IAC circuit malfunction • DTC P1507 indicates that Self-Test has detected an IAC underspeed error | |
| [Possible Cause] <ul style="list-style-type: none"> • IAC circuit open • IAC circuit shorted to PWR • IAC short to GND (P1504) • VPWR circuit open • Air inlet plugged (P0505, P1507) • Air inlet leakage (P1507) • Damaged IAC valve assembly • Damaged Throttle body (P0505, P1507) • Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK VPWR TO IAC SOLENOID <ul style="list-style-type: none"> • Key off. • Disconnect IAC solenoid vehicle harness connector. • Key on. • Measure voltage between VPWR circuit at the IAC solenoid vehicle harness connector and battery ground. • Is voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in VPWR to IAC solenoid. RECONNECT all components. RERUN Quick Test. |
| 2 | CHECK IAC SOLENOID RESISTANCE <ul style="list-style-type: none"> • Key off. • IAC solenoid vehicle harness connector disconnected. • Measure solenoid resistance. NOTE: Due to diode in solenoid, place DVOM (+) lead on VPWR pin and (-) lead on IAC pin. <ul style="list-style-type: none"> • Is resistance between 6.0 and 13.0 ohms? | Yes Go to next Step. |
| | | No REPLACE IAC valve assembly. RECONNECT all components. RERUN Quick Test. |
| 3 | CHECK IAC SOLENOID FOR AN INTERNAL SHORT TO IAC CASE <ul style="list-style-type: none"> • Key off. • IAC solenoid vehicle harness connector disconnected. • Measure resistance from either IAC solenoid pin to IAC valve assembly case. • Is resistance greater than 10,000 ohms? | Yes For DTC P1504 Go to Step 6. All other: Go to next Step. |
| | | No REPLACE IAC valve assembly. RECONNECT all components. RERUN Quick Test. |
| 4 | CHECK AIR INLET FOR PLUGGING <ul style="list-style-type: none"> • Key off. • Inspect the entire inlet air system for debris blockage and other damage. • Remove and inspect the air filter element for excessive dirt. • Is the air inlet system OK? | Yes Go to next Step. |
| | | No SERVICE as necessary. RECONNECT all components. RERUN Quick Test. |
| 5 | CHECK FOR VACUUM LEAKS <ul style="list-style-type: none"> • Key on. • With engine running at idle, listen for vacuum leaks. • Inspect the entire inlet air system from the MAF sensor to the intake manifold for leaks such as: <ul style="list-style-type: none"> – Cracked or punctured inlet air tube – Loose inlet air tube at air cleaner housing or throttle body – IAC valve assembly or gasket seal – EGR valve gasket seal – Vacuum supply connector and hose – PCV connectors and hose • Are any leaks detected in the above areas? | Yes SERVICE as necessary. RECONNECT all components. RERUN Quick Test. |
| | | No Go to next Step. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 6 | CHECK IAC CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • IAC solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between Test Pin 83 (IAC) at the breakout box and IAC circuit at IAC solenoid vehicle harness connector. • Is resistance less than 5.0 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 7 | CHECK IAC CIRCUIT FOR SHORT TO PWR <ul style="list-style-type: none"> • Key off. • Breakout box installed. PCM disconnected. • IAC solenoid disconnected. • Key on, engine off. • Measure voltage between Test Pin 83 (IAC) at the breakout box and chassis ground. • Is voltage less than 1.0 volt? | Yes | Go to next Step. |
| | | No | SERVICE short circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 8 | CHECK IAC CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM disconnected. • IAC solenoid disconnected. • Measure resistance between Test Pin 83 (IAC) and Test Pins 51 and 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | SERVICE short circuit. RECONNECT all components. RERUN Quick Test. |
| 9 | CHECK IAC SIGNAL FROM PCM <ul style="list-style-type: none"> • Key off. • Breakout box installed. • Reconnect PCM to breakout box. • Reconnect IAC solenoid. • Connect DVOM between Test Pin 83 (IAC) and Test Pin 51 (PWR GND) at the breakout box. • Start engine. • Slowly increase rpm to 3,000 rpm. • Is voltage between 3.0 and 11.5 volts? | Yes | For continuous Memory DTCs P1504 and P1507. Go to next Step. INSPECT Throttle body for damage, SERVICE as necessary. If OK, REPLACE IAC valve assembly. RESET KAM (Refer to PCM reset). RERUN Quick Test. |
| | | No | REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 10 | CHECK IAC SYSTEM FOR INTERMITTENT OPEN OR SHORT <ul style="list-style-type: none"> • Key on engine running. • Access IAC and RPM PID switch a NGS. • With engine at normal operating temperature, accessories off and at idle, the IAC duty cycle should be between 20% and 40%. • Observe the IAC and RPM PIDs for an indication of a fault while performing the following at idle: <ul style="list-style-type: none"> – Lightly tap on IAC valve assembly and wiggle harness connector to simulate road shock – Grasp the vehicle harness closest to the IAC valve assembly. Shake and bend a small section of the harness from the IAC to the dash panel and from the dash panel to PCM • Do the IAC or RPM PIDs suddenly change in value indicating a fault? | Yes | ISOLATE fault and SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). |
| | | No | For idle quality, starting, or stalling symptoms currently present: REPLACE IAC valve assembly. RECONNECT all components. RESET KAM (REFER to PCM Reset). All others: Unable to duplicate and/or identify fault at this time. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | |
|-------------------------|--|--|
| CODE No. | P0603, P1605 | |
| DESCRIPTION | • DTC P0603/P1605 indicates the PCM has experienced a power interrupt in KAPWR circuit | |
| [Possible Cause] | <ul style="list-style-type: none"> • Battery terminals corrosion or loose connections • Improper KAPWR circuit wire routing • Harness open in KAPWR circuit • Damaged PCM | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK BATTERY TERMINALS NOTE: If KAPWR is interrupted to the PCM (i.e. when a breakout box is installed or the battery is disconnected), DTC P0603/P1605 may be generated on the first power-up. <ul style="list-style-type: none"> • Inspect the battery cables for loose connections, corrosion, etc. • Are the battery terminal connections in good condition? | Yes Battery terminals are OK? Go to next Step. |
| | | No SERVICE battery terminals as necessary. RERUN Quick Test. |
| 2 | INSPECT ENGINE COMPARTMENT FOR PROPER WIRE ROUTING <ul style="list-style-type: none"> • Inspect EEC-V wiring for proximity to ignition components or wires. • Is wiring too close to ignition components or wires? | Yes REROUTE as necessary. RERUN Quick Test. |
| | | No Engine compartment wire routing is OK. Go to next Step. |
| 3 | CHECK KEEP ALIVE POWER (KAPWR) TO PCM <ul style="list-style-type: none"> • Key off. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure voltage between Test Pin 55 (KAPWR) and Test Pin 51 or 103 (PWR GND) at the breakout box. • While observing DVOM, grasp the EEC-V harness and wiggle, shake or bend a small section while working from the PCM to the dash panel. • Does the DVOM indicate less than 10.5 volts? | Yes ISOLATE and SERVICE open in KAPWR circuit. REMOVE breakout box. RECONNECT the PCM. RERUN Quick Test. |
| | | No No open in KAPWR harness circuit detected. REMOVE breakout box. RECONNECT the PCM. Go to next Step. |
| 4 | CHECK FOR REPEAT OF DTC P0603/P1605 <ul style="list-style-type: none"> • Activate Key On Engine Off Self-Test. • Is DTC P0603/P1605 present? | Yes REPLACE the PCM. RERUN Quick Test. |
| | | No SERVICE other DTCs as necessary. If none, testing is complete. DTC P0603/P1605 was due to previous service action mentioned in the NOTE in Step 1. |

| | | |
|--|---|--|
| CODE No. | P0703 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P0703 indicates that when the brake pedal was depressed and released during Key On Engine Running Self-Test the brake switch signal did not cycle high and low | |
| [Possible Cause] <ul style="list-style-type: none"> • Brake pedal not depressed and released during the Key On Engine Running Self-Test • Brake pedal depressed during entire Key On Engine Running Self-Test • Open to GROUND or POWER • Damaged brake switch • Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | VERIFY BRAKE PEDAL WAS PRESSED <ul style="list-style-type: none"> • Was the brake pedal pressed and released during KOER Self-Test? | Yes Go to next Step. |
| | | No RERUN Key On Engine Running Self-Test. PRESS and RELEASE brake pedal. |
| 2 | CHECK OPERATION OF STOPLIGHTS <ul style="list-style-type: none"> • Key on. • Check stoplight operation. • Does stoplights operate normally? | Yes Go to next Step. |
| | | No If stoplights never on Go to Step 4. If stoplights always on Go to Step 6. |
| 3 | CHECK FOR BOO CIRCUIT CYCLING <ul style="list-style-type: none"> • Key off. • Disconnect PCM Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure voltage between brake switch Test Pin 92 and Test Pins 76 and 77 at the breakout box while depressing and releasing brake. • Does the voltage cycle? | Yes REPLACE PCM. REMOVE breakout box. RERUN Quick Test. |
| | | No SERVICE open in brake switch circuit between PCM and brake switch connection to brake circuit. RERUN Quick Test. |
| 4 | CHECK FOR POWER TO BRAKE SWITCH NOTE: Using a 12V test light, verify integrity of related fuses in fuse panel and check condition of stoplight bulbs before starting this test. <ul style="list-style-type: none"> • Key off. • Disconnect brake switch (located on brake pedal). • Measure B+ input voltage between stoplight switch and chassis ground. • Is voltage greater than 10 volts? | Yes Go to next Step. |
| | | No SERVICE open B+ circuit to brake switch. RECONNECT brake switch connector. RERUN Quick Test. |
| 5 | VERIFY INTEGRITY OF BRAKE SWITCH <ul style="list-style-type: none"> • Brake switch disconnected. • Connect DVOM test probes to brake switch terminals at the brake switch. • DVOM on ohms scale. • Press brake pedal while monitoring reading. • Is the resistance less than 5.0 ohms? | Yes SERVICE open circuit between brake switch and stoplight ground. RECONNECT brake switch. RERUN Quick Test. |
| | | No REPLACE brake switch. RECONNECT brake switch. RERUN Quick Test. |
| 6 | VERIFY BRAKE SWITCH IS NOT ALWAYS CLOSED <ul style="list-style-type: none"> • Key off. • Stoplight switch disconnected. • Key on, engine off. • Are stoplights still on? | Yes Go to next Step. |
| | | No VERIFY proper installation of brake switch. If OK, REPLACE stoplight switch. RECONNECT harness connector. RERUN Quick Test. |
| 7 | CHECK FOR SHORT TO POWER IN PCM <ul style="list-style-type: none"> • Key off. • Stoplight switch disconnected. • Disconnect Powertrain Control Module (PCM). • Key on, engine off. • Are stoplights still on? | Yes Go to next Step. |
| | | No REPLACE PCM. RECONNECT brake switch. RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 8 | CHECK FOR SHORT TO POWER IN SHIFTLOCK ACTUATOR <ul style="list-style-type: none"> • Key off. • PCM disconnected. • Brake switch disconnected. • Disconnect shiftlock actuator, cruise control module and ABS module (if equipped) to isolate brake switch wiring. • Key on, engine off. • Are stoplights still on? | Yes | SERVICE short to power in brake switch/Stoplight circuit. RECONNECT PCM brake switch and accessories. RERUN Quick Test. |
| | | No | SERVICE short in accessories (i.e. shiftlock actuator, ABS module, etc.). RECONNECT all components. RERUN Quick Test. |

| | | | |
|--|--|-----|---|
| CODE No. | P1000 | | |
| DESCRIPTION | <ul style="list-style-type: none"> Diagnostic Trouble Code (DTC) P1000 indicates that not all of the On Board Diagnostic II (OBD II) monitors have completed. In some states, this DTC must be cleared to pass an inspection/maintenance test. The customer should be informed that the law specifies additional city and highway driving must be done to complete the check of the On Board Diagnostic system. This additional driving must occur before the vehicle is tested at the inspection/maintenance station. The amount of driving required varies with individual driving patterns. To complete this requirement in the shortest amount of time, refer to Drive Cycles | | |
| <p>[Possible Cause] DTC P1000 is set by the PCM with any of following conditions</p> <ul style="list-style-type: none"> The vehicle is new from the factory and has not yet been through a complete OBD II Drive Cycle The battery or PCM has been disconnected An OBD II monitor failure had occurred before completion of an OBD II Drive Cycle <ul style="list-style-type: none"> The PCM DTCs have been erased with NGS as part of the normal repair process <p>DTC P1000 may not be removed from the PCM because:</p> <ul style="list-style-type: none"> There is a thermostat stuck open and a DTC is not output There is an open VSS circuit and a DTC is not output | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>CHECK FOR OTHER DTCS This INSPECTION should be used only if a Diagnostic Trouble Code (DTC) P1000 was received in Continuous Memory. Ignore any DTC P1000s in KOEO or KOER. DTC P1000 indicates that all of the OBD II monitors have not yet been successfully tested.</p> <ul style="list-style-type: none"> Were any other DTCs received with the P1000? | Yes | Go to DTC Charts, for SERVICE other DTCs. |
| | | No | No EEC-V system faults have been detected. Go to next Step. |
| 2 | <p>REQUEST TO REMOVE P1000 A complete OBD II Drive Cycle has not yet been performed to remove the DTC P1000 from the PCM.</p> <ul style="list-style-type: none"> Has the customer requested the DTC P1000 be removed from the PCM memory? <p>NOTE: It is not necessary to remove the DTC P1000 from the PCM by driving the vehicle unless it is requested by the customer to pass an inspection/maintenance test.</p> <p>Inform the customer of the need for additional driving when required to pass an inspection/maintenance test.</p> | Yes | PERFORM the OBD II drive cycle. If DTC P1000 is still present, Go to next Step. |
| | | No | No faults in the EEC-V system have been detected. INFORM the customer that if the law in this states requires additional driving in order to remove the DTC P1000 from the PCM memory, it must be performed before an inspection/maintenance test. RETURN other symptoms. |
| 3 | <p>CHECK VSS PID Perform a short road test and look for a change in the VSS PID.</p> <ul style="list-style-type: none"> Was the VSS PID greater than zero MPH/KPH? | Yes | Go to next Step. |
| | | No | SERVICE open VSS circuit. RERUN the OBD II Drive Cycle. RERUN Quick Test. |
| 4 | <p>CHECK ECT TEMPERATURE Drive the vehicle long enough to obtain the highest engine operating temperature and record the ECT temperature PID.</p> <ul style="list-style-type: none"> Was the ECT PID reading greater than 180°F/82°C? | Yes | ADDITIONAL driving is required. PERFORM the OBD II Drive Cycle. RERUN Quick Test. |
| | | No | REPLACE the cooling system thermostat. PERFORM the OBD II Drive Cycle. RERUN Quick Test. |

NOTE: The only way a DTC P1000 can be removed from memory is when all the OBD II monitors have successfully completed during normal vehicle operation.

| | | |
|---|---|---|
| CODE No. | P1100 | |
| DESCRIPTION | <ul style="list-style-type: none"> Continuous Memory DTC P1100 indicates the MAF sensor signal went below 0.39 volts or above 3.90 volts (refer to Voltage to Mass Air Flow Conversion Table at beginning of this Test) sometime during the last 40 warm-up cycles | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> MAF sensor connector with poor continuity MAF harness with poor continuity MAF harness intermittent short MAF sensor internal intermittent open or short | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FOR MAF CIRCUIT INTERMITTENT VOLTAGE INPUT <ul style="list-style-type: none"> Start engine and bring to idle. <p>NOTE: If a stabilized idle is not at least 700 rpm, go to TROUBLESHOOTING GUIDE.</p> <ul style="list-style-type: none"> Scan Tool connected. Run throttle up to 1,500 rpm for 5 seconds, and bring back to idle. Access MAF V PID (MAF PID) for a fault indication while performing the following: <ul style="list-style-type: none"> Lightly tap on MAF sensor and wiggle harness connector to simulate road shock Is the MAF V PID (MAF PID) changing below the minimum 0.39 volts or above a maximum 3.90 volts (refer to Voltage to Mass Air Flow Conversion Table at beginning of this Test)? | Yes |
| | | DISCONNECT and INSPECT the MAF sensor connector. If OK, REPLACE the MAF sensor. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No |
| | | Go to next Step. |
| 2 | CHECK MAF HARNESS TO PCM FOR INTERMITTENT OPENS OR SHORTS <ul style="list-style-type: none"> Key off. Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. Install breakout box, reconnect PCM. Key on, engine off. Connect DVOM between Test Pin 88 (MAF SIG) and Test Pin 36 (MAF RTN) at the breakout box. While viewing DVOM, do the following: <ul style="list-style-type: none"> Grasp the vehicle harness closest to the MAF sensor connector Shake and bend a small section of the harness all the way to the dash panel Wiggle, shake and bend the harness from the dash panel to the PCM Is the voltage changing below the minimum 0.39 volts or above the maximum 3.90 volts? | Yes |
| | | ISOLATE fault and SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No |
| | | Unable to duplicate and/or identify fault at this time. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| CODE No. | P1101 | |
|-------------|--|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Key On Engine Running (KOER) DTC P1101 indicates the MAF signal was not between 0.34 and 1.96 volts during KOER Self-Test | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FOR MAF SENSOR CONTINUOUS MEMORY CODES <ul style="list-style-type: none"> • Drive vehicle for 6 to 10 minutes. • Rerun KOEO and Continuous Memory Self-Test. • Is a Continuous Memory DTC present with the KOER DTC P1101? | Yes For Continuous Memory DTC P0102: Go to address the MAF sensor Monitor DTC. For Continuous Memory DTC P0103: Go to address the MAF sensor Monitor DTC. For all other Continuous Memory DTCs: Go to Powertrain Diagnostic Code Charts. |
| | | No Go to next step. |
| 2 | CHECK MAF SENSOR OUTPUT VOLTAGE <p>NOTE: DTC P1101 could be generated by a low charged vehicle battery or the garage exhaust ventilation system. Service the battery as necessary. Then remove ventilation system and properly vent to outside atmosphere. Rerun KOEO Self-Test.</p> <ul style="list-style-type: none"> • Key off. • Check that the MAF sensor in corrected. If not, service as necessary. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Scan Tool connected. • Install breakout box, connect PCM to breakout box. • Key on, engine off. • Measure between Test Pin 88 (MAF SIG) and Test Pins 24 or 103 (PWR GND) at the breakout box. • Is the voltage greater than 0.20 volts? | Yes The MAF GIG voltage is greater than expected. Go to next Step. |
| | | No Go to Step 9. |
| 3 | CHECK PWR GND CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed. • Disconnect PCM. • Disconnect Scan Tool from DLC. • Measure the resistance between PWR GND circuit at the MAF sensor vehicle harness connector and battery negative post. • Is the resistance less than 10 ohms? | Yes PWR GND harness circuit to MAF sensor is OK. RECONNECT Scan Tool. Go to next Step. |
| | | No SERVICE open in PWR GND harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK MAF RTN CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed, PCM disconnected. • Measure the resistance between MAF RTN circuit at the MAF sensor vehicle harness connector and Test Pin 36 (MAF RTN) at the breakout box. • Is the resistance less than 5.0 ohms? | Yes MAF RTN harness circuit to PCM is OK. Go to next Step. |
| | | No SERVICE open in MAF RTN harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK MAF CIRCUIT FOR SHORT TO GROUND IN PCM <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed. • Reconnect PCM to breakout box. • Disconnect Scan Tool from DLC (if applicable). • Measure the resistance between Test Pin 88 (MAF SIG) and Test Pins 36 (MAF RTN) and 24 or 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes RECONNECT Scan Tool. Go to next Step. |
| | | No MAF SIG shorted to PWR GND or MAF RTN in the PCM. REMOVE breakout box. RECONNECT MAF sensor. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 6 | CHECK MAF CIRCUIT OUTPUT <ul style="list-style-type: none"> • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. NOTE: If a stabilized idle is not at least 700 rpm, go to TROUBLESHOOTING GUIDE. <ul style="list-style-type: none"> • Measure the voltage between Test Pin 88 (MAF SIG) at the breakout box and battery negative post. • Is the voltage at idle between 0.34 and 1.96 volts? | Yes | MAF SIG to the PCM is OK. Go to next Step. |
| | | No | MAF SIG or RWR GND is open in the MAF sensor, or MAF SIG is shorted to MAF RTN in the MAF sensor. REPLACE MAF sensor. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 7 | VERIFY MAF CIRCUIT INPUT AND OUTPUT <ul style="list-style-type: none"> • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. • Measure the voltage between Test Pin 88 (MAF SIG) and Test Pin 36 (MAF RTN) at the breakout box. • Is the voltage between 0.34 and 1.96 volts? | Yes | MAF RTN in MAF sensor is OK. Go to next Step. |
| | | No | MAF RTN open in the MAF sensor. REPLACE MAF sensor. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 8 | CHECK MAF CIRCUIT OUTPUT WITH SCAN TOOL <ul style="list-style-type: none"> • Key off. • MAF sensor connected. • Breakout box installed, PCM connected. • Key on, engine running. • Access MAF V PID (MAF PID) with a Scan Tool at idle. • Is the MAF V PID (MAF PID) between 0.34 and 1.96 volts (refer to Voltage to Mass Air Flow Conversion Table at the beginning of this Test)? | Yes | Unable to identify fault at this time. Check possible intermittent. |
| | | No | MAF SIG or MAF RTN is open or shorted together in the PCM. REPLACE PCM. REMOVE breakout box. RECONNECT PCM. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 9 | CHECK CONTINUITY OF VPWR CIRCUIT <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between VPWR circuit at the MAF sensor vehicle harness connector and Test Pin 71 or 97 (VPWR) at the breakout box. • Is resistance less than 5.0 ohms? | Yes | VPWR harness circuit to PCM is OK. Go to next Step. |
| | | No | Service open in VPWR harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 10 | CHECK MAF CIRCUIT FOR SHORTS TO GROUND AND MAF RTN CIRCUIT <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed, PCM disconnected. • Disconnect Scan Tool from Data Link Connector (DLC). • Measure the resistance between Test Pin 88 (MAF SIG) and Test Pins 36 (MAF RTN) and 24 or 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | MAF SIG, MAF RTN and GROUND harness circuits to PCM are OK. RECONNECT Scan Tool. Go to next Step. |
| | | No | Service short circuit between MAF SIG and GROUND or MAF RTN. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 11 | CHECK CONTINUITY OF MAF SIG CIRCUIT <ul style="list-style-type: none"> • Key off. • MAF sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between MAF circuit at the MAF sensor vehicle harness connector and Test Pin 88 (MAF SIG) at the breakout box. • Is resistance less than 5.0 ohms? | Yes | MAF SIG harness circuit to PCM is OK. Go to next Step. |
| | | No | SERVICE open in MAF SIG harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 12 | CHECK PWR GND CIRCUIT TO MAF SENSOR <ul style="list-style-type: none">• Key off.• MAF sensor disconnected.• Breakout box installed.• PCM connected to breakout box.• Key on, engine off.• Measure the voltage between VPWR circuit and PWR GND circuit at the MAF sensor vehicle harness connector.• Is the voltage greater than 10.5 volts? | Yes | PWR GND harness circuit from battery negative post to MAF sensor is OK. Go to Step 4. |
| | | No | Go to Step 3. |

| | | |
|--|--|--|
| CODE No. | P1116 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1116 (ECT) indicates that the corresponding sensor is out of Self-Test range. Correct range of measure is 0.3 to 3.7 volts | |
| [Possible Cause] <ul style="list-style-type: none"> • Low coolant levele (ECT) • Damaged harness connector • Overheated condition • Poor thermostat operation • Damaged sensor | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK OPERATION, INSTALLATION OF TEMPERATURE SENSOR <ul style="list-style-type: none"> • Run engine at 2,000 rpm until engine temperature becomes stabilized. NO STARTS: <ul style="list-style-type: none"> – Go to Step 3 Vehicle that STALLS: <ul style="list-style-type: none"> – Return to Symptom Flow Chart • Check that upper radiator hose is hot and pressurized. • Rerun Key On Engine Running (KOER) Self-Test. • Is DTC P1116 present? | Yes For symptom of cooling system concern. Do not service DTC P1116, service next DTC. If no other DTC's exists. RETURN to Symptom Flow Charts. All others: Go to next Step. |
| | | No Engine was not at closed loop operating condition. SERVICE other DTC's as necessary. |
| 2 | CHECK VREF CIRCUIT VOLTAGE AT THROTTLE POSITION SENSOR <ul style="list-style-type: none"> • Key off. • Disconnect TP sensor. • Measure voltage between VREF circuit and SIG RTN circuit at the TP sensor vehicle harness connector. • Is voltage between 4.5 volts and 5.5 volts? | Yes There is sufficient VREF voltage. RECONNECT TP sensor. Go to next Step. |
| | | No REPAIR open in VREF circuit. |
| 3 | CHECK RESISTANCE OF TEMPERATURE SENSOR WITH ENGINE OFF <ul style="list-style-type: none"> • Key off. • Disconnect suspect temperature sensor. • Measure resistance between sensor signal circuit and SIG RTN circuit at the temperature sensor. Refer to the corresponding chart at the beginning of this Test for resistance specifications. • Is resistance within specifications | Yes For ECT sensor with a NO START: Do not service DTC P1116 at this time. RETURN to Symptom Flow Charts. All others: Go to next Step. |
| | | No REPLACE suspect sensor. RECONNECT vehicle harness. RERUN Quick Test. |
| 4 | CHECK RESISTANCE OF TEMPERATURE SENSOR WITH ENGINE RUNNING <p>NOTE: Verify that engine is at operating temperature before taking ECT readings.</p> <ul style="list-style-type: none"> • Key off. • Suspect temperature sensor disconnected. • Run engine for two minutes at 2,000 rpm. • Measure resistance between sensor signal circuit and SIG RTN circuit at the temperature sensor. Refer to the chart at the beginning of this Test for resistance specifications. • Is resistance within specification? | Yes REPALCE PCM. RECONNECT vehicle harness. RERUN Quick Test. |
| | | No REPLACE suspect sensor. RECONNECT vehicle harness. RERUN Quick Test. |

NOTE: Engine may have cooled down. Always warm engine before taking ECT sensor resistance measurements. Check for open thermostat.

| | | |
|--|---|--|
| CODE No. | P1120 THROTTLE POSITION SENSOR | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1120 indicates Throttle Position (TP) signal within the Self-Test range but below the closed throttle position range of 3.43 to 9.80% (0.17 to 0.49 volts) | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Frayed wires • Corrosion on TP sensor, PCM or harness connectors • VREF harness open or shorts • Damaged TP sensor • Damaged PCM | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FRAYED TP CIRCUIT WIRES OR CORROSION ON CONNECTORS <ul style="list-style-type: none"> • Do a complete visual inspection of the harness connector at the TP sensor (including pins) for corrosion. • Do a complete visual inspection of the harness wires between the TP sensor and the PCM for insulation fraying and corrosion. • Is a fault present? | Yes SERVICE as necessary. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | CHECK FOR STUCK TP SENSOR <ul style="list-style-type: none"> • Key on, engine off. • Access TP PID (TPV PID) with the Scan Tool. • Slowly move throttle from closed throttle position to wide open throttle position and observe the TP PID (TPV PID). • While opening the throttle, the TP PID (TPV PID) below 9.80% (0.49 volts)? | Yes Go to next Step. |
| | | No Go to Code No. P1120 or P1125. |
| 3 | CHECK VREF CIRCUIT VOLTAGE <ul style="list-style-type: none"> • Key off. • TP sensor disconnected. • Key on, engine off. • Measure voltage between VREF circuit and SIG RTN circuit at the TP sensor vehicle harness connector. • Is the voltage between 4.0 and 6.0 volts? | Yes Go to next Step. |
| | | No Key off. RECONNECT all components. REPAIR open in VREF circuit. |
| 4 | CHECK TP CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • TP sensor disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between TP circuit at the TP sensor vehicle harness connector and Test Pin 89 (TP SIG) at the breakout box. • Is the resistance less than 5.0 ohms? | Yes TP SIG harness circuit to PCM is OK. Go to next Step. |
| | | No SERVICE corrosion or open in TP SIG harness circuit. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK TP SENSOR SIGNAL TO PCM <ul style="list-style-type: none"> • Key off. • Connect PCM to breakout box. • Connect TP sensor. • Start engine and idle for 2 minutes. • Slowly open the throttle from closed position, while doing next step. • Measure the voltage between Test Pin 89 (TP SIG) and Test Pin 91 (SIG RTN) at the breakout box. • Is the voltage at any time between 0.17 to 0.49 volts? | Yes TP sensor is damaged. REPLACE TP sensor. REMOVE breakout box. RERUN Quick Test. |
| | | No RERUN Quick Test. If DTC P1120 is still present, Go to Code No. P1120 or P1125. |

| | | | |
|---|---|-----|---|
| CODE No. | P1121 (Continuous) | | |
| DESCRIPTION | <ul style="list-style-type: none"> Continuous Memory Diagnostic Trouble Code (DTC) P1121 indicates throttle position is inconsistent with MAF sensor | | |
| [Possible Cause] <ul style="list-style-type: none"> Damaged TP sensor TP sensor not seated properly (almost completely detached from throttle body) Air leak between MAF sensor and throttle body | | | |
| STEP | INSPECTION | | ACTION |
| 1 | TP SENSOR AND MAF SENSOR RATIONALITY CHECK <ul style="list-style-type: none"> Attempt to start engine. Does the engine run? | Yes | Go to next Step. |
| | | No | CHECK for major leaks, cracks, and openings between MAF sensor and throttle body. |
| 2 | CHECK MECHANICAL OPERATION OF TP SENSOR <ul style="list-style-type: none"> Key on, engine off. Access TP PID (TPV PID) with the Scan Tool. Slowly move throttle from closed throttle position to wide open throttle position and observe the TP PID (TPV PID) for smooth reading change. While opening and closing the throttle, is there a sudden drop in the TP PID (TPV PID) below 13.23% (0.66 volts) or a sudden jump in the TP PID (TPV PID) above 24.02% (1.20 volts)? | Yes | TP sensor has internal substrate problem. REPLACE TP sensor. RERUN Quick Test. |
| | | No | Go to next Step. |
| 3 | CHECK TP SENSOR SIGNAL HIGH VERSUS THE ENGINE LOAD WHILE DRIVING VEHICLE <ul style="list-style-type: none"> Key on, engine running. Do normal drive, exercising the throttle and TP sensor while accessing PIDS. Access TP PID (TPV PID) and LOAD PID with the Scan Tool and record readings. Is the TP PID (TPV PID) greater than 49.02% (2.44 volts) and the LOAD PID reading less than 25%? | Yes | CHECK for air leaks between the MAF sensor and the throttle body including air noise sounds while engine is running. SERVICE as necessary. If OK, REPLACE the TP sensor. RERUN Quick Test. |
| | | No | Go to next Step. |
| 4 | CHECK TP SENSOR SIGNAL LOW VERSUS THE ENGINE LOAD <ul style="list-style-type: none"> Key on, engine running. NOTE: If the vehicle is a No Start, go to TROUBLESHOOTING GUIDE. <ul style="list-style-type: none"> Access TP PID (TPV PID) and LOAD PID with the Scan Tool and record readings. Is the TP PID (TPV PID) reading less than 4.90% (0.24 volts) and the LOAD PID reading greater than 60%? | Yes | CHECK for TP sensor loosely connected to the throttle body (screws not securely tightened down). SERVICE as necessary. RESET KAM (REFER to PCM Reset). DRIVE vehicle exercising the throttle. RERUN Quick Test. If Continuous Memory P1121 is now present, REPLACE MAF sensor. |
| | | No | Go to next Step. |
| 5 | CHECK TP SENSOR SIGNAL LOW VERSUS THE ENGINE LOAD WHILE DRIVING VEHICLE <ul style="list-style-type: none"> Key on, engine running. Do normal drive, exercising the throttle and TP sensor near higher gears (preferably overdrive) while accessing PIDS. Access TP PID (TPV PID) and LOAD PID with the Scan Tool and record readings. Is the TP PID (TPV PID) reading less than 4.90% (0.24 volts) and the LOAD PID reading greater than 60%? | Yes | CHECK for TP sensor loosely connected to the throttle body (screws not securely tightened down). SERVICE as necessary. RESET KAM (REFER to PCM Reset). DRIVE vehicle exercising the throttle. RERUN Quick Test. If Continuous Memory P1121 is now present, REPLACE MAF sensor. |
| | | No | Unable to identify the fault at this time. If vehicle is still a No start, Go to Troubleshooting. |

| | | | |
|--|---|-----|--|
| CODE No. | P1124 | | |
| DESCRIPTION | <ul style="list-style-type: none"> Throttle Position Sensor's rotational setting are not in the Self-Test range of 13.23 to 24.02% (0.66 to 1.20 volts) | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> Binding or bent throttle linkage TP sensor may not be seated properly (tightened down) Throttle plate below closed Throttle position Throttle plate/screw misadjusted Damaged TP sensor Damaged Powertrain Control Module (PCM) | | | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK FOR OTHER DTCS <ul style="list-style-type: none"> Check for DTC P1400 KOEO or KOER Self-Test. Is KOEO or KOER DTC P1400 present with KOEO DTC P1400? | Yes | PROCEED as directed with DTC P1400. |
| | | No | Go to next Step. |
| 2 | CHECK FOR STUCK THROTTLE PLATE OR LINKAGE <ul style="list-style-type: none"> Visually inspect throttle body and throttle linkage for binding or sticking. Verify the throttle plate and linkage is at closed throttle position. Does throttle move freely and return to closed throttle position? | Yes | Throttle plate and linkage are OK. |
| | | No | SERVICE as necessary. RERUN Quick Test. |

| | | | |
|---|---|---------------|--|
| CODE No. | P1125 (Continuous) | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Continuous Memory DTC P1125 indicates the TP sensor signal went below 9.80% (0.49 volts) or above 92.27% (4.60 volts) same time during the last 80 warm up cycles | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • TP sensor connector with poor continuity • TP harness with poor continuity • TP harness intermittent short • TP sensor internal electrical or substrate open or electrical short | | | |
| STEP | INSPECTION | ACTION | |
| 1 | CHECK FOR TP CIRCUIT INTERMITTENT VOLTAGE INPUT Start engine and bring to idle. Run throttle up to 1,500 rpm for 5 seconds. Key on, engine running. Access TP PID (TPV PID) for a fault indication with a Scan Tool while performing the following: – Lightly tap on TP sensor and wiggle harness connector to simulate road shock <ul style="list-style-type: none"> • Is the TP PID (TPV PID) changing below the minimum 9.80% (0.49 volts) or above the maximum 92.27% (4.60 volts)? | Yes | DISCONNECT and INSPECT the TP sensor connector. If OK, REPLACE the TP sensor. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Go to next Step. |
| 2 | CHECK TP HARNESS TO PCM FOR INTERMITTENT OPENS OR SHORTS <ul style="list-style-type: none"> • Key off. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, reconnect PCM. • Key on, engine off. • Connect DVOM between Test Pin 89 (TP SIG) and Test Pin 91 (SIG RTN) at the breakout box. • While viewing DVOM, do the following: – Grasp the vehicle harness closest to the TP sensor connector – Shake and bend a small section of the harness all the way to the dash panel – Wiggle, shake and bend the harness from the dash panel to the PCM • Is the voltage changing below the minimum 0.49 volts or above the maximum 4.60 volts? | Yes | ISOLATE fault and SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Unable duplicate and/or identify fault at this time. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | | | | | | |
|---|---|--|--|-----|---|----|--|
| CODE No. | P1127 KOER | | | | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1127 indicates the HO2S Heater was not on KOER Self-Test, therefore accurate testing of the HO2S Heater is energized when certain temperature criteria is met. The HO2S Heater energize times are based on exhaust temperature modeling, which allows for upstream heaters being energized independent of the downstream heaters | | | | | | |
| [Possible Cause] | | | | | | | |
| <ul style="list-style-type: none"> • Exhaust system too cool | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | |
| 1 | <ul style="list-style-type: none"> • Key off. • Scan tool connected. • Key on, engine on. • Access HRT 11A, 12A and X1 and Monitor PID's. • Do all PID's Indicate on? | | <table border="0"> <tr> <td align="center">Yes</td> <td>RERUN Quick Test. SERVICE any other DTC.</td> </tr> <tr> <td align="center">No</td> <td>RUN engine until all PID's indicate on. RERUN Quick Test. SERVICE any other DTC's.</td> </tr> </table> | Yes | RERUN Quick Test. SERVICE any other DTC. | No | RUN engine until all PID's indicate on. RERUN Quick Test. SERVICE any other DTC's. |
| Yes | RERUN Quick Test. SERVICE any other DTC. | | | | | | |
| No | RUN engine until all PID's indicate on. RERUN Quick Test. SERVICE any other DTC's. | | | | | | |

| | | | |
|---|---|-----|---|
| CODE No. | P1270 | | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1270 indicates the vehicle has been operated in a manner which caused the engine or vehicle speed to exceed a calibrated limit | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Wheel slippage (water, ice, mud, snow, etc.) • Engine over revved in neutral • Vehicle driven at high rate of speed | | | |
| STEP | INSPECTION | | ACTION |
| 1 | EXCESSIVE ENGINE RPM/VEHICLE SPEED <ul style="list-style-type: none"> • Has the vehicle been operated in any of the above conditions? | Yes | RESET KAM (REFER to PCM Reset). RETURN vehicle to customer with information about DTC P1270. |
| | | No | RESET KAM (REFER to PCM Reset). If there are other driveability concerns, Go to Trouble-shooting. If there are no other symptoms, RETURN vehicle to customer. |

| | | | |
|--|--|-----------------------------|---|
| CODE No. | P1400 | | |
| DESCRIPTION | • DTC P1400 indicates that the EGRP SIG circuit input is less than the Self-Test minimum | | |
| [Possible Cause] | | | |
| • Damaged EGRP sensor/EGR valve assembly | | • Damaged harness connector | |
| • Damaged PCM | | • Damaged harness | |
| STEP | INSPECTION | | ACTION |
| 1 | VERIFY EGRP SIGNAL VOLTAGE • Key on, engine off. • Access EGRV (EGR Valve position sensor input) PID with NGS. • Is EGRV PID less than 0.2 volts? | Yes | Go to Step 6. |
| | | No | Go to next Step. |
| 2 | ATTEMPT TO GENERATE OPPOSITE CODE • Key off. • Disconnect EGRP sensor. • Jumper the VREF circuit to the EGRP sensor SIG circuit at the sensor vehicle harness connector. • Rerun KOEO and KOER self-tests (If the vehicle will not start, immediately remove the jumper wire and proceed to Step 5). • Is DTC P1401 present (ignore all other DTCs)? | Yes | REPLACE the EGRP sensor/EGR valve assembly. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | REMOVE the jumper wire. Go to next Step. |
| 3 | CHECK EGRP SENSOR VREF VOLTAGE • Key on, engine off. • EGRP sensor disconnected. • Measure voltage between VREF circuit and SIG RTN circuit at the EGRP sensor vehicle harness connector. • Is voltage between 4.0 and 6.0 volts? | Yes | Go to next Step. |
| | | No | REPAIR open in VREF circuit. |
| 4 | CHECK CONTINUITY OF EGRP SIG RTN CIRCUIT • Key off. • EGRP sensor disconnected. • Disconnect the PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave the PCM disconnected. • Measure the resistance between EGRP SIG RTN circuit at the EGRP sensor vehicle harness connector and Test Pin 91 at the breakout box. • Is resistance less than 5 ohms? | Yes | Go to next Step. |
| | | No | RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK EGRP SIG CIRCUIT FOR SHORT TO GROUND • Key off. • EGRP sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 65 (EGRP SIG) and Test Pins 91 (SIG RTN), 51 (PWR GND) and 103 (PWR GND) at the breakout box. • Is resistance greater than 10,000 ohms? | Yes | REPLACE damaged PCM. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | SERVICE short in EGRP SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 6 | WIGGLE TEST SENSOR AND HARNESS • Key on, engine off. • Access EGRV PID with NGS. • Observe EGRV PID for an indication of a fault while performing the following: – Lightly tap on EGRP sensor. Wiggle the EGRP sensor connector and vehicle harness between sensor and PCM. A fault is indicated by a sudden change in EGRV PID voltage • Is a fault indicated? | Yes | ISOLATE fault and SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | | |
|--|--|--|---|
| CODE No. | P1401 | | |
| DESCRIPTION | • DTC P1401 indicates the EGRP SIG circuit input is greater than the self-test maximum | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Damaged EGRP sensor/EGR valve assembly • Damaged EGRV solenoid • Damaged PCM | | <ul style="list-style-type: none"> • Damaged harness connector • Damaged harness | |
| STEP | INSPECTION | | ACTION |
| 1 | VERIFY EGRP SIGNAL VOLTAGE <ul style="list-style-type: none"> • Key on, engine off. • Access EGRV (EGR Valve position sensor input) PID with NGS. • Is EGRV PID greater than 4.0? | Yes | Go to DTC P1408 Troubleshooting Step 3. |
| | | No | Go to next Step. |
| 2 | ATTEMPT TO GENERATE OPPOSITE DTC <ul style="list-style-type: none"> • Key off. • Disconnect EGRP sensor. • Connect a jumper wire between the EGRP sensor SIG and SIG RTN circuits at the EGRP sensor vehicle harness connector. • Rerun KOEO and KOER self-tests (If the vehicle will not start, immediately remove the jumper wire and proceed to Step 5). • Is DTC P1400 present (ignore all other DTCs)? | Yes | REMOVE jumper wire. Go to Step 6. |
| | | No | REMOVE jumper wire. Go to next Step. |
| 3 | CHECK CONTINUITY OF EGRP SENSOR SIG CIRCUIT <ul style="list-style-type: none"> • Key off. • EGRP sensor disconnected. • Disconnect the PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave the PCM disconnected. • Measure the resistance between EGRP sensor SIG circuit at the EGRP sensor vehicle harness connector and Test Pin 65 (EGRP SIG) at the breakout box. • Is resistance less than 5 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open in EGRP sensor SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK CONTINUITY OF EGRP SENSOR SIG RTN CIRCUIT <ul style="list-style-type: none"> • Key off. • EGRP sensor disconnected. • PCM disconnected, breakout box installed. • Measure the resistance between EGRP sensor SIG RTN circuit at the EGRP sensor vehicle harness connector and Test Pin 91 (SIG RTN) at the breakout box. • Is resistance less than 5 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open in EGRP sensor SIG RTN circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK EGRP SENSOR SIG CIRCUIT FOR SHORT TO POWER <ul style="list-style-type: none"> • Key off. • EGRP sensor disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 65 (EGRP SIG) and Test Pins 71 (VPWR), 90 (VREF) and 97 (VPWR) at the breakout box. • Is resistance greater than 10,000 ohms? | Yes | REPLACE the damaged PCM. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | SERVICE short to power in EGRP sensor SIG circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 6 | CHECK EGRV SOLENOID CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • EGRV solenoid disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 72 (EGRV) and Test Pins 23, 77 and 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | REMOVE breakout box. RECONNECT all components. Go to next Step. |
| | | No | SERVICE short in EGRV solenoid harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | ACTION |
|------|---|---|
| 7 | <p>CHECK EGRV SOLENOID-VALVE</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Disconnect the vacuum line from the EGRV solenoid to the EGRA solenoid. Install a vacuum gauge at the unattached end of the vacuum line. • Disconnect the vacuum line from the intake manifold vacuum reservoir to the EGRV solenoid. • Install vacuum pump at the input port of the EGRV solenoid and apply 8 to 10^o-Hg of vacuum to the EGRV solenoid while observing the vacuum gauge. • Is a vacuum signal indicated by the vacuum gauge? | <p>Yes</p> <p>REPLACE the damaged EGRV solenoid. REMOVE breakout box. REMOVE vacuum gauge and pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | <p>No</p> <p>Go to next Step.</p> |
| 8 | <p>CHECK PCM CONTROL OF EGRV SOLENOID</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Vacuum gauge installed between the EGRV and EGRA solenoids. • Vacuum pump installed at input port of the EGRV solenoid and apply 8 to 10^o-Hg of vacuum is applied to the EGRV solenoid. • Key on and observe the vacuum gauge. • Is a vacuum signal indicated by the vacuum gauge once the key is on? | <p>Yes</p> <p>REPLACE the damaged PCM. REMOVE breakout box. REMOVE the vacuum gauge and pump. RECONNECT all components. RERUN Quick Test.</p> |
| | | <p>No</p> <p>Go to next Step.</p> |
| 9 | <p>CHECK EGRV SOLENOID ELECTRO-MECHANICAL OPERATION</p> <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Vacuum gauge installed between the EGRV and EGRA solenoids. • Vacuum pump installed at input port of the EGRV solenoid and apply 8 to 10^o-Hg of vacuum is applied to the EGRV solenoid. • Key on. • Momentarily jumper Test Pin 72 (EGRV) to Test Pin 103 (PWR GRND) at the breakout box and observe the vacuum gauge. • Key off. • Was a vacuum signal indicated by the vacuum gauge? | <p>Yes</p> <p>REPLACE the EGRP sensor/EGR valve assembly. REMOVE breakout box. REMOVE the vacuum gauge and pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |
| | | <p>No</p> <p>REPLACE the EGRV solenoid-valve. REMOVE the breakout box. REMOVE the vacuum gauge and pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test.</p> |

| | | |
|-------------------------|--|---|
| CODE No. | P1408 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1408 indicates a lack of EGR valve movement was detected by the EGRP sensor circuit during KOER self-test | |
| [Possible Cause] | <ul style="list-style-type: none"> • Damaged vacuum lines • Damaged EGRA solenoid • Damaged EGR valve • Damaged EGRV solenoid • Damaged PCM • Damaged harness connector • Damaged harness | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FOR VACUUM SIGNAL TO EGR VALVE <ul style="list-style-type: none"> • Key off. • Disconnect vacuum line from the EGRA solenoid to the EGR valve at the EGR valve. • Install vacuum gauge at unattached end of the disconnected vacuum line. • Rerun KOER self-test while observing the vacuum gauge (ignore any DTCs output during KOER). • Key off. • Did the vacuum gauge indicate a vacuum signal was present during part of KOER self-test? | Yes DISCONNECT the vacuum gauge. Go to next Step. |
| | | No DISCONNECT the vacuum gauge. REMOVE and INSPECT the vacuum line. If OK, RECONNECT the vacuum line and go to Step 3, otherwise SERVICE the vacuum line as necessary and RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 2 | CHECK RESPONSE OF EGR VALVE TO MANUALLY APPLIED VACUUM SIGNAL <ul style="list-style-type: none"> • Key off. • Vacuum line from the EGRA solenoid to the EGR valve disconnected at the EGR valve. • Install the breakout box, PCM connected. • Key on. • Using a hand held vacuum pump, slowly apply and remove 7"-Hg of vacuum repeatedly, while measuring the EGRP sensor voltage response at Test Pin 65 (EGRP SIG) of the breakout box. • Based on EGRP sensor voltage, does the EGR valve open and close in as the vacuum signal is applied and removed? | Yes REMOVE the vacuum pump. REMOVE breakout box. REPLACE the damaged PCM. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No REMOVE the vacuum pump. REMOVE breakout box. REPLACE the damaged EGRP sensor/EGR valve assembly. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK FOR VACUUM SIGNAL TO EGRA SOLENOID <ul style="list-style-type: none"> • Key off. • Disconnect vacuum line from the EGRV solenoid to the EGRA solenoid at the EGRA solenoid input port. • Install vacuum gauge at unattached end of the disconnected vacuum line. • Rerun KOER self-test while observing the vacuum gauge (ignore any DTCs output during KOER). • Key off. • Did the vacuum gauge indicate a vacuum signal was present during part of KOER self-test? | Yes REMOVE the vacuum gauge. RECONNECT the vacuum line. Go to next Step. |
| | | No DISCONNECT the vacuum gauge. REMOVE and INSPECT the vacuum line. If OK, RECONNECT the vacuum line and go to Step 9, otherwise SERVICE the vacuum line as necessary and RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK VPWR TO EGRA SOLENOID <ul style="list-style-type: none"> • Key off. • EGRA solenoid disconnected. • Key on, engine off. • Measure voltage between VPWR circuit and chassis ground at the EGRA solenoid vehicle harness connector. • Is EGRA VPWR voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No SERVICE open in EGRA solenoid VPWR circuit. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 5 | CHECK RESISTANCE OF EGRA SOLENOID <ul style="list-style-type: none"> • Key off. • EGRA solenoid disconnected. • Measure solenoid resistance. • Is resistance between 30 and 70 ohms? | Yes Go to next Step. |
| | | No REPLACE the EGRA solenoid. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 6 | CHECK EGRA SOLENOID CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • EGRA solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between Test Pin 68 (EGRA) at the breakout box and the EGRA circuit at the solenoid vehicle harness connector. • Is the resistance less than 5.0 ohms? | Yes | Go to next Step. |
| | | No | SERVICE open in EGRA harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 7 | CHECK EGRA SOLENOID CIRCUIT FOR SHORT TO POWER AND SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • EGRA solenoid disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 68 (EGRA) and Test Pins 71, 97 (VPWR) and 90 (VREF) at the breakout box. • Measure resistance between Test Pin 68 (EGRA) and Test Pins 51, 103 (PWR GND) and 91 (SIG RTN) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | REMOVE breakout box. RECONNECT all components. Go to next Step. |
| | | No | SERVICE short in EGRA solenoid harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 8 | CHECK EGRA SOLENOID VALVE FUNCTION <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Disconnect the vacuum line from the EGRV solenoid to EGRA solenoid at the EGRA solenoid. • Install vacuum pump at the input port of the EGRA solenoid, apply 8 to 10³-Hg of vacuum to the EGRA solenoid. • Disconnect the vacuum line from the EGRA solenoid to EGR valve at the EGR valve, install a vacuum gauge at the unattached end of the vacuum line. • Disconnect the vacuum line from the EGRA solenoid to the air cleaner at the air cleaner, plug the vacuum line at the unattached end. • Key on. • Momentarily jumper to ground Test Pin 68 (EGRA) at the breakout box and observe the vacuum gauge. • Key off. • Was a vacuum signal indicated by the vacuum gauge? | Yes | REPLACE the damaged EGRA solenoid. REMOVE breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No | REPLACE the damaged PCM. REMOVE breakout box. REMOVE the vacuum gauge and vacuum pump. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 9 | CHECK VPWR TO EGRV SOLENOID <ul style="list-style-type: none"> • Key off. • EGRV solenoid disconnected. • Key on, engine off. • Measure voltage between VPWR circuit and chassis ground at the EGRV solenoid vehicle harness connector. • Is EGRV VPWR voltage greater than 10.5 volts? | Yes | Go to next Step. |
| | | No | SERVICE open in EGRV solenoid VPWR circuit. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 10 | CHECK RESISTANCE OF EGRV SOLENOID <ul style="list-style-type: none"> • Key off. • EGRV solenoid disconnected. • Measure solenoid resistance. • Is resistance between 30 and 70 ohms? | Yes | Go to next Step. |
| | | No | REPLACE the EGRV solenoid. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| STEP | INSPECTION | ACTION |
|------|---|---|
| 11 | CHECK EGRV SOLENOID CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • EGRV solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure the resistance between Test Pin 72 (EGRV) at the breakout box and the EGRV circuit at the solenoid vehicle harness connector. • Is resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open in EGRV harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 12 | CHECK EGRV SOLENOID CIRCUIT FOR SHORT TO POWER <ul style="list-style-type: none"> • Key off. • EGRV solenoid disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 72 (EGRV) and Test Pins 71, 97 (VPWR) and 90 (VREF) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes REMOVE breakout box. RECONNECT all components. Go to next Step. |
| | | No SERVICE short in EGRV solenoid harness circuit. REMOVE breakout box. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 13 | CHECK EGRV SOLENOID VALVE FUNCTION <ul style="list-style-type: none"> • Key off. • Breakout box installed, PCM connected. • Disconnect the vacuum line from the intake manifold vacuum reservoir to the EGRV solenoid at the EGRV solenoid. • Install vacuum pump at the input port of the EGRV solenoid and apply 8 to 10³-Hg of vacuum to the EGRV solenoid. • Disconnect the vacuum line from EGRV solenoid to the EGRA solenoid at the EGRA solenoid, install a vacuum gauge at the unattached end of the vacuum line. • Key on. • Momentarily jumper Test Pin 72 (EGRV) to ground at the breakout box and observe the vacuum gauge. • Key off. • Was a vacuum signal indicated by the vacuum gauge? | Yes REPLACE the damaged PCM. REMOVE breakout box. REMOVE the vacuum pump and vacuum gauge. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No REPLACE the damaged EGRV solenoid. REMOVE breakout box. REMOVE the vacuum pump and vacuum gauge. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |

| | | |
|--|--|---|
| CODE No. | P1460 | |
| DESCRIPTION | • KOEO KOER DTC P1460 indicates an A/C relay primary circuit fault | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Open or shorted circuit • Damaged A/C relay | | <ul style="list-style-type: none"> • Damaged Powertrain Control Module (PCM) |
| STEP | INSPECTION | ACTION |
| 1 | <p>CHECK FOR IGN RUN VOLTAGE TO A/C RELAY</p> <p>NOTE: Verify A/C and defrost were off during KOEO/KOER Self-Test.</p> <ul style="list-style-type: none"> • Key off. • Disconnect A/C relay. • Key on. • Measure voltage between IGN RUN circuit at A/C relay vehicle harness connector and chassis ground. • Is voltage greater than 10.5 volts? | Yes Go to next Step. |
| | | No VERIFY condition of related fuses. If OK, SERVICE open circuit. RECONNECT all components. RERUN Quick Test. |
| 2 | <p>CHECK A/C RELAY</p> <ul style="list-style-type: none"> • Key off. • A/C relay disconnected. • Check A/C relay coil resistance: <ul style="list-style-type: none"> – Measure resistance between ACON pin and IGN RUN pin at the A/C relay – Resistance should be between 50 and 100 ohms • Check A/C relay for internal shorts: <ul style="list-style-type: none"> – Measure resistance between ACON pin and the following pins at the A/C relay: B+, power-to-clutch, ground – Resistances should be greater than 10,000 ohms • Are all resistance checks OK? | Yes Go to next Step. |
| | | No REPLACE A/C relay. RECONNECT all components. RERUN Quick Test. |
| 3 | <p>CHECK ACON CIRCUIT FOR SHORT TO POWER</p> <ul style="list-style-type: none"> • Key off. • A/C relay disconnected. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wire, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Key on, engine off. • Measure voltage between Test Pin 69 (ACON) at the breakout box and chassis ground. • Is voltage less than 1.0 volt? | Yes Go to next Step. |
| | | No SERVICE short to power. REMOVE breakout box. RECONNECT all components. |
| 4 | <p>CHECK ACON CIRCUIT FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> • Key off. • A/C relay disconnected. • Disconnect Scan Tool from DLC. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 69 at the breakout box and chassis ground. • Is resistance greater than 10,000 ohms? | Yes Go to next Step. |
| | | No SERVICE short to ground. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 5 | <p>CHECK ACON CIRCUIT CONTINUITY</p> <ul style="list-style-type: none"> • Key off. • A/C relay disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 69 at breakout box and ACON circuit at A/C relay vehicle harness connector. • Is resistance less than 5.0 ohms? | Yes REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| CODE No. | P1460 | | |
|---|--|--------|--|
| DESCRIPTION | • A Continuous Memory DTC P1460 indicates that a ACON circuit failure has occurred during vehicle operation | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Open or short in ACON circuit (PCM pin 69) <li style="margin-left: 300px;">• Open IGN RUN to A/C Relay | | | |
| STEP | INSPECTION | ACTION | |
| 1 | CHECK ACON CIRCUIT FOR INTERMITTENT CONCERNS <ul style="list-style-type: none"> • Key off. • Scan Tool connected. • Disconnect A/C Cycling Switch (Low Pressure (LP) Switch). • Install a jumper wire in the A/C Cycling/LP Switch vehicle harness connector (to complete the circuit). • Key on, engine off. • A/C demand switch on. • Check WAC circuit for open or short to power (this test will check ACON for short to ground) while performing the following (the A/C clutch will click on when a fault is detected): <ul style="list-style-type: none"> – Shake, wiggle, bend the ACON circuit between the PCM (pin 69) and the A/C relay – Lightly tap on the A/C relay (to simulate road shock) • Is a fault indicated? | Yes | ISOLATE fault and SERVICE as necessary. REMOVE jumper wire. RECONNECT all components. COMPLETE PCM Reset to clear DTCs (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Go to next Step. |
| 2 | CHECK ACON CIRCUIT FOR INTERMITTENT CONCERNS <ul style="list-style-type: none"> • Key on, engine off. • Jumper wire installed in A/C Cycling or LP switch. • A/C demand on. • Scan Tool connected. • Access Output Test Mode on Scan Tool. • Turn outputs on (to turn on the A/C clutch). • Check ACON circuit for open or short to power and open in VPWR or IGN RUN circuit while performing the following (the A/C clutch will click off when a fault is detected): <ul style="list-style-type: none"> – Shake, wiggle, bend the ACON circuit between the PCM (pin 69) and the A/C relay – Shake, wiggle, bend the VPWR or IGN RUN circuit to the WAC or A/C relay – Lightly tap on the A/C relay (to simulate road shock) • Key off, A/C off. • Is a fault indicated? | Yes | ISOLATE fault and SERVICE as necessary. REMOVE jumper wire. RECONNECT all components. COMPLETE PCM Reset to clear DTCs (REFER to PCM Reset). RERUN Quick Test. |
| | | No | Unable to duplicate and/or identify fault at this time. REMOVE jumper wire. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | | |
|---|---|---|---|
| CODE No. | P1474 | | |
| DESCRIPTION | • DTC P1474 indicates a Fan Control (FC) primary circuit failure | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> • Open or shorted FC circuit • Open VPWR circuit to FC relay | | <ul style="list-style-type: none"> • Damaged FC relay • Damaged PCM | |
| STEP | INSPECTION | | ACTION |
| 1 | CHECK FOR VPWR TO FAN CONTROL (FC) RELAY <ul style="list-style-type: none"> • Key off. • Disconnect Fan Control relay. • Key on. • Measure voltage between the VPWR circuit at the Fan Control relay vehicle harness connector and the battery negative post. • Is voltage greater than 10.5 volts? | Yes | Go to next Step. |
| | | No | SERVICE open VPWR circuit to Fan Control relay. RECONNECT Fan Control relay. RERUN Quick Test. |
| 2 | CHECK FOR FC CIRCUIT CYCLING <ul style="list-style-type: none"> • Key on, engine off. • Scan Tool connected. • Access Output Test Mode on Scan Tool. • Connect DVOM positive lead to the VPWR circuit and the negative lead to the FC circuit at the FC relay vehicle harness connector. • While observing DVOM, command the cooling fan on and off a couple times. • Does voltage change more than 0.5 volts when the cooling fan output is commanded on and off? | Yes | Key off. REPLACE Fan Control relay. RERUN Quick Test. |
| | | No | Key off. Go to next Step. |
| 3 | CHECK FC CIRCUIT FOR SHORT TO POWER <ul style="list-style-type: none"> • Key off. • FC relay disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Key on, engine off. • Measure voltage between the FC circuit at the FC relay vehicle harness connector and the battery negative post. • Key off. • Was voltage less than 1.0 volt? | Yes | Go to next Step. |
| | | No | SERVICE FC circuit short to power. RECONNECT all components. RERUN Quick Test. |
| 4 | CHECK FC CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • Disconnect Scan Tool from DLC. • FC relay disconnected. • PCM disconnected. • Install breakout box, leave PCM disconnected. • Measure resistance between Test Pin 28 (FC) and Test Pins 51, 103 (PWR GND) and 91 (SIG RTN) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | Go to next Step. |
| | | No | SERVICE FC circuit short to ground. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 5 | CHECK FC CIRCUIT CONTINUITY <ul style="list-style-type: none"> • Key off. • FC relay disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between Test Pin 28 at the breakout box and the FC circuit at the FC relay vehicle harness connector. • Is resistance less than 5.0 ohms? | Yes | REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No | SERVICE open FC circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|---|---|--|
| CODE No. | P1500 | |
| DESCRIPTION | • DTC P1500 indicates the VSS input signal was intermittent | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • Damaged VSS • Damaged PCM • Intermittent VSS connections • Intermittent open in VSS harness circuit(s) • Intermittent short in VSS harness circuit(s) | | |
| STEP | INSPECTION | ACTION |
| 1 | VISUAL INSPECTION <ul style="list-style-type: none"> • Key off. • Visually inspect the VSS and VSS harness circuits for any potential failures. Use the following check list for reference: <ul style="list-style-type: none"> – Loose VSS connector – Pushed out VSS connector pins – Damaged VSS wiring harness insulation – Incorrect harness routing – Incorrect VSS mounting • Did the visual inspection reveal a potential failure? | Yes |
| | | No |
| | | SERVICE fault as necessary. RESET KAM (REFER to PCM Reset). RUN VSS Drive Cycle to verify the repair. |
| | | RECONNECT all components. Unable to duplicate or identify fault at this time. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | |
|--|---|---|
| CODE No. | P1505 | |
| DESCRIPTION | • DTC P1505 indicates the IAC system has reached the adaptive clip | |
| [Possible Cause] <ul style="list-style-type: none"> • Air leaks • Plugged air filter element • Throttle body/linkage binding • Contaminated or damaged IAC valve assembly • Damaged throttle body | | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK INLET AIR CONNECTION <ul style="list-style-type: none"> • Key off. • Inspect the entire inlet air system for leaks such as loose connection at throttle body or air cleaner, cracked or punctured ducting, etc. • Is there a leak or loose connection in the air inlet system? | Yes Service as necessary. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | CHECK FOR A PLUGGED AIR FILTER <ul style="list-style-type: none"> • Key off. • Remove air filter element and check for excessive dirt or moisture. • Is the air filter plugged? | Yes SERVICE as necessary. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 3 | INSPECT THROTTLE BODY AND LINKAGE <ul style="list-style-type: none"> • Key off. • Disconnect accelerator cable and air cleaner tube from throttle body. • Exercise both cable and throttle body linkage separately while checking for binding, interference and full freedom of travel. • Is a fault indicated? | Yes Go to next Step. |
| | | No Go to Step 8. |
| 4 | CHECK ACCELERATOR AND SPEED CONTROL CABLES FOR FREEDOM OF TRAVEL <ul style="list-style-type: none"> • Key off. • Disconnect accelerator cable and speed control cable from throttle body linkage. • Inspect cables for freedom of travel from accelerator pedal/speed control device to throttle body linkage cable connector. • Do cables travel freely? | Yes Go to next Step. |
| | | No SERVICE cable as necessary. |
| 5 | VERIFY THROTTLE RETURN SCREW SETTING <ul style="list-style-type: none"> • Key off. • Cables removed from throttle body linkage. • Remove the clean air tube from the throttle body and verify that there is no foreign material or debris preventing the throttle plate from rotating to the fully closed position. • Verify that the Throttle Return Screw (TRC) is in contact with the throttle linkage lever arm when the throttle is in the closed plate (idle) position. • Does the TRC screw contact lever arm? | Yes Go to Step 7. |
| | | No The following adjustment should be made only in the event TRC screw does not contact the throttle lever arm. Do not adjust TRC screw to try to correct idle quality concerns. 1) PLACE a 0.002 inch feeler gauge between the TRC screw and lever arm. ADJUST TRC screw until it just contacts the feeler gauge. 2) REMOVE the feeler gauge and turn the screw clockwise a half turn. 3) Go to next Step. |
| 6 | VERIFY TP SENSOR IN RANGE <ul style="list-style-type: none"> • Key on, engine off. • Access TP PID with the Scan Tool. • Slowly move throttle from closed to wide open throttle position and observe the TP PID for smooth reading change. • Release throttle and allow to return to fully closed position. • While at closed throttle position, is the TP PID reading between 13% (0.66 volt) and 24% (1.20 volts)? | Yes REMOVE Scan Tool. Go to next Step. |
| | | No REMOVE Scan Tool. REPLACE throttle body assembly. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 7 | <p>CHECK FOR THROTTLE BODY STICKING, BINDING, GRABBING</p> <ul style="list-style-type: none"> • Key off. • Cables removed from throttle body linkage. • Clean air tube removed from throttle body. • Snap throttle from open to closed position several times. • Gently cycle throttle by hand from closed to wide open position. Inspect for freedom of travel particularly during the initial throttle opening. • Check for foreign material or debris in the throttle bore and plate area that can cause sticking or binding. <p>NOTE: Throttle bodies use a special coating/sealant on the throttle bore and plate area to make them tolerant to engine sludge accumulation. Sludge or oil film deposits in this area do not cause a sticking or binding condition and do not require servicing. DO NOT CLEAN THE THROTTLE BORE AND PLATE AREA. CLEANING WILL DAMAGE THE THROTTLE BODY ASSEMBLY.</p> <ul style="list-style-type: none"> • Does the throttle rotate freely without sticking, binding or grabbing condition? | Yes | RECONNECT accelerator cable and clean air tube to the throttle body assembly. REFER to TROUBLESHOOTING GUIDE if the drive symptom persists. |
| | | No | REPLACE throttle body assembly. RECONNECT all components. |
| 8 | <p>CHECK FOR PROPER OPERATION OF RELATED ENGINE SYSTEMS</p> <ul style="list-style-type: none"> • Verify that the following engine systems have been properly diagnosed and corrected before proceeding with the Air Intake system diagnostics: <ul style="list-style-type: none"> – Positive Crankcase Ventilation (PCV) System – Ignition System – Exhaust System – Engine Cooling System (engine coolant temperature is above 180 degrees F) – Incorrect fuel pressure, plugged fuel filter, fuel quality (contamination) • Have the systems been properly checked and are they functioning correctly? | Yes | Go to next Step. |
| | | No | Go to TROUBLESHOOTING GUIDE, with the symptom, for direction. |
| 9 | <p>CHECK FOR VACUUM LEAKS</p> <ul style="list-style-type: none"> • Key on, engine running. • With engine at idle, listen for vacuum leaks. • Inspect the entire inlet air system from the Mass Air Flow (MAF) sensor to the intake manifold for leaks such as: <ul style="list-style-type: none"> – Cracked or punctured inlet air tube – Loose connections on the inlet air tube at the air cleaner housing or throttle body – Idle Air Control (IAC) valve assembly or gasket seal – EGR valve gasket seal leak to intake manifold – Intake manifold assembly or gasket seal – EGR valve diaphragm or control solenoid – Vacuum supply connectors and hose – PCV connectors and hose • Are any leaks detected in the above areas? | Yes | SERVICE as necessary. |
| | | No | Go to next Step. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 10 | <p>CHECK IDLE</p> <ul style="list-style-type: none"> • Key off. • Transmission in Park (wheels blocked and parking brake engaged). • A/C, heater and all accessories are off. • Key on, engine running. • Engine at normal operating temperature and cooling fan off. <p>WARNING: DO NOT UNPLUG COOLING FAN. IT MAY CAUSE ENGINE OVERHEATING.</p> <ul style="list-style-type: none"> • Connect Scan Tool. • Access engine RPM PID. <p>NOTE: Engine idle RPM is controlled by the PCM and cannot be adjusted. The PCM is calibrated to control idle at the speeds listed in the Hot Idle PID Value Table at the beginning of the test. When performing this test, verify the RPM is within the specification. If the engine is allowed to idle for an extended period of time, or if the engine temperature is hot enough to require cooling fan operation, it may be necessary to turn the engine off and repeat this test procedure.</p> <ul style="list-style-type: none"> • Access IAC PID, idle air percent duty cycle. • Do the RPM and IAC PID readings match the values in the Hot Idle PID Value Table at the beginning of the test? | Yes | Go to next Step. |
| | | No | Go to Step 12. |
| 11 | <p>CHECK IDLE CONTROL RESPONSE</p> <ul style="list-style-type: none"> • Transmission still in Park. • A/C, heater and all accessories off. • Engine at normal operating temperature and cooling fan off, but not unplugged. <p>WARNING: DO NOT UNPLUG COOLING FAN. IT MAY CAUSE ENGINE OVERHEATING.</p> <ul style="list-style-type: none"> • Key on, engine running. • Goose throttle and let it return to the idle position. • Does the engine stall or does the RPM fluctuate excessively before returning to the idle speed specified? | Yes | Go to next Step. |
| | | No | Air Intake system is OK. DISCONNECT Scan Tool. Go to TROUBLESHOOTING GUIDE to check other possible causes of the drive symptoms. |
| 12 | <p>CHECK IAC SOLENOID FOR PROPER FUNCTION</p> <ul style="list-style-type: none"> • Transmission still in Park. • A/C, heater and all accessories off. • Engine at normal operating temperature and cooling fan off, but not unplugged. <p>WARNING: DO NOT UNPLUG COOLING FAN. IT MAY CAUSE ENGINE OVERHEATING.</p> <ul style="list-style-type: none"> • Key on, engine running. • Disconnect IAC solenoid vehicle harness connector. • Does the RPM drop or engine stall? | Yes | Fast Idle Symptom: Go to Step 14. All Other Symptom: Go to next Step. |
| | | No | IAC solenoid is defective, REPLACE IAC solenoid only. RESET KAM (REFER to PCM Reset). NOTE: Do not attempt to clean the IAC solenoid. |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 13 | THROTTLE BODY VISUAL/FUNCTIONAL CHECK <ul style="list-style-type: none"> • Key off. • Remove throttle body assembly. • Hold throttle body up to a light source. With the throttle plate closed, no light should be visible between the plate and bore (sludge tolerant coating intact). The hole in the throttle plate (in some applications only) should be visible and unobstructed. • Rotate the throttle lever and allow it to return. It should not stick or bind and should return to the closed plate position (TRC screw contacting lever) freely when released. • Does the throttle body pass these visual/functional checks? | Yes | Throttle body is functioning properly. REINSTALL throttle body assembly. RETURN to TROUBLESHOOTING GUIDE to check other possible causes of symptom. |
| | | No | Throttle body is defective. REPLACE entire throttle body assembly. RESET KAM (REFER to PCM Reset). |
| 14 | CHECK IAC CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key off. • IAC solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between Test Pin 83 (IAC) and Test Pins 51 or 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | REPLACE damaged PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No | SERVICE short circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | |
|-------------------------|--|---|
| CODE No. | DTC P1506 | |
| DESCRIPTION | • DTC P1506 indicates Self-Test has detected an IAC over speed error | |
| [Possible Cause] | <ul style="list-style-type: none"> • IAC circuit short to GND • IAC assembly stuck open • Vacuum leak • Damaged IAC assembly • Damaged throttle body • Damaged PCM | |
| STEP | INSPECTION | ACTION |
| 1 | CHECK FOR VACUUM LEAKS <ul style="list-style-type: none"> • Key on, engine running. • With the engine at idle, listen for vacuum leaks. • Inspect the entire inlet air system from the Mass Air Flow (MAF) sensor to the intake manifold for damage or leaks such as: <ul style="list-style-type: none"> – Cracked or punctured inlet air tube – Loose inlet air tube at the air cleaner housing or throttle body – IAC valve assembly or gasket seal – Intake manifold assembly or gasket seal – EGR valve gasket seal – Vacuum supply connectors and hose – PCV valve connectors and hose • Are any leaks detected in the above areas? | Yes SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| | | No Go to next Step. |
| 2 | CHECK EVAP SYSTEM FOR A STUCK OPEN VALVE OR SOLENOID <ul style="list-style-type: none"> • Key off. • Disconnect hoses at EVAP Canister Purge Valve or solenoid. • Connect a hand vacuum pump to the fuel vapor port to carbon canister at the EVAP Canister Purge Valve or to either port if equipped with a EVAP Canister Purge solenoid. • Apply 16 in-Hg (53 kPa) of vacuum to EVAP Canister Purge Valve or Solenoid. • Does the EVAP Canister Purge Valve or solenoid hold vacuum for 20 seconds? | Yes RECONNECT all components. Go to next Step. |
| | | No REPLACE EVAP Valve or solenoid. RECONNECT all components. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 3 | CHECK IAC SOLENOID FOR PROPER FUNCTION <ul style="list-style-type: none"> • Key on, engine running. • Bring engine to normal operating temperature. • Transmission in Park or Neutral. • Disconnect IAC solenoid vehicle harness connector. • Does the RPM drop or engine stall? | Yes Go to next Step. |
| | | No INSPECT throttle body for damage or defect. SERVICE as necessary. If OK, REPLACE IAC valve assembly. RESET KAM (REFER to PCM Reset). RERUN Quick Test. |
| 4 | CHECK IAC CIRCUIT FOR SHORT TO GND <ul style="list-style-type: none"> • Key off. • IAC solenoid disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Measure resistance between Test Pin 83 (IAC) and Test Pins 51 and 103 (PWR GND) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes For Fast Idle Symptom currently present: REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. All others: RECONNECT all components. Go to next Step. |
| | | No SERVICE short circuit. RECONNECT all components. RERUN Quick Test. |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 5 | CHECK IAC SYSTEM FOR INTERMITTENT OPEN OR SHORT <ul style="list-style-type: none"> • Key on, engine running. • Access IAC and RPM PIDs with a NGS. • With engine at normal operating temperature, accessories off and at idle, the IAC duty cycle should between 20% and 40%. • Observe the IAC and RPM PIDs for an indication of a fault while performing the following at idle: <ul style="list-style-type: none"> – Lightly tap on IAC valve assembly and wiggle harness connector to simulate road shock – Grasp the vehicle harness closest to the IAC valve assembly. Shake and bend a small section of the harness from the IAC to the dash panel and from the dash panel to PCM • Do the IAC or RPM PIDs suddenly change in valve indicating a fault? | Yes | ISOLATE fault and SERVICE as necessary. RECONNECT all components. RESET KAM (REFER to PCM Reset). |
| | | No | For idle quality, starting, or stalling symptoms currently present: REPLACE IAC valve assembly. RECONNECT all components. RESET KAM (REFER to PCM Reset). All othres: Unable to duplicate and/or identify fault at this time. Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |

| | | |
|---|--|---|
| CODE No. | P1650, P1651 | |
| DESCRIPTION | <ul style="list-style-type: none"> • DTC P1651 indicates PSP signal malfunction • DTC P1650 indicates PSP signal out of self-test range | |
| [Possible Cause] | | |
| <ul style="list-style-type: none"> • PSP switch/shorting bar damaged • SIG RTN open or shorted to GND • PCM damaged • PSP signal circuit open or shorted to SIG RTN | | |
| STEP | INSPECTION | ACTION |
| 1 | VERIFY ELECTRICAL FUNCTION <ul style="list-style-type: none"> • Key on, engine running. • View PSP PID with Scan Tool while turning the steering wheel back and forth. • Does the Scan Tool indicate voltage Low/High or High/Low? | Yes Intermittent poor connection or component malfunction (REPAIR or REPLACE as necessary). |
| | | No Go to next Step. |
| 2 | CHECK PSP SWITCH OPERATION <ul style="list-style-type: none"> • Key off. • Install tachometer vehicle harness connector and inspect both ends for damage, Service as necessary. • Disconnect PSP switch. • Jumper PSP circuit at the PSP switch vehicle harness connector. • Does engine rpm increase? | Yes REPLACE PSP switch. VERIFY repair. |
| | | No REMOVE jumper wire. Go to next Step. |
| 3 | CHECK CONTINUITY OF PSP CIRCUITS <ul style="list-style-type: none"> • Key off. • PSP switch disconnected. • Disconnect PCM Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, leave PCM disconnected. • Measure resistance between Test Pin 31 at the breakout box and PSP circuit at the PSP switch vehicle harness connector. • Is each resistance less than 5.0 ohms? | Yes Go to next Step. |
| | | No SERVICE open circuit. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| 4 | CHECK PSP CIRCUIT FOR SHORT <ul style="list-style-type: none"> • Key off. • PSP switch disconnected. • Breakout box installed, leave PCM disconnected. • Measure resistance between Test Pin 31 and Test Pin 91 at the breakout box. • Measure resistance between Test Pin 31 at the breakout box chassis ground. • Is either resistance less than 10,000 ohms? | Yes SERVICE short in harness. REMOVE breakout box. RECONNECT all components. VERIFY repair. |
| | | No Go to next Step. |
| 5 | CHECK PSP SWITCH RESISTANCE <ul style="list-style-type: none"> • Key off. • PSP switch vehicle harness disconnected. • Start engine and let idle in Park/Neutral. • Measure resistance between the PSP switch terminals while turning the steering wheel. • Is the resistance less than 5.0 ohms? | Yes REPLACE PCM. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |
| | | No REPLACE PSP switch. REMOVE breakout box. RECONNECT all components. RERUN Quick Test. |

| | | | |
|--|--|-----|---|
| CODE No. | P1703 | | |
| DESCRIPTION | <ul style="list-style-type: none"> DTC P1703 indicates that during Key On Engine Off (KOEO) Self-Test, voltage was seen on the Brake Switch Test Pin at the PCM | | |
| [Possible Cause] | | | |
| <ul style="list-style-type: none"> Brake pedal pressed and released during the Key On Engine Off Self-Test Brake pedal depressed during entire Key On Engine Running Self-Test BOO Test Pin shorted to B+ Defective brake switch | | | |
| STEP | INSPECTION | | ACTION |
| 1 | VERIFY BRAKE PEDAL WAS PRESSED <ul style="list-style-type: none"> Was the brake pedal pressed and released during KOEO Self-Test? | Yes | RERUN KOEO Self-Test. Avoid pressing brake pedal during Test. |
| | | No | Go to next Step. |
| 2 | CHECK OPERATION OF STOPLIGHTS <ul style="list-style-type: none"> Key on. Check stoplight operation. Does stoplights operate normally? | Yes | Go to next Step. |
| | | No | If stoplights never on Go to Step 4. If stoplights always on Go to Step 6. |
| 3 | CHECK FOR BOO CIRCUIT CYCLING <ul style="list-style-type: none"> Key off. Disconnect PCM Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. Install breakout box, leave PCM disconnected. Measure voltage between brake switch Test Pin 92 and Test Pin 76 and 77 at the breakout box while depressing and releasing brake. Does the voltage cycle? | Yes | REPLACE PCM. REMOVE breakout box. RERUN Self-Test. |
| | | No | SERVICE open in brake switch circuit between PCM and brake switch connection to brake circuit. RERUN Self-Test. |
| 4 | CHECK FOR POWER TO BRAKE SWITCH <p>NOTE: Using a 12V test light, verify integrity of related fuses in fuse panel and check condition of stoplight bulbs before starting this test.</p> <ul style="list-style-type: none"> Key off. Disconnect brake switch (located on brake pedal). Measure B+ input voltage between stoplight switch and chassis ground. Is voltage greater than 10 volts? | Yes | Go to next Step. |
| | | No | SERVICE open B+ circuit to brake switch. RECONNECT brake switch connector. RERUN Quick Test. |
| 5 | VERIFY INTEGRITY OF BRAKE SWITCH <ul style="list-style-type: none"> Brake switch disconnected. Connect DVOM test probes to brake switch terminals at the brake switch. DVOM on ohms scale. Press brake pedal while monitoring reading. Is the resistance less than 5.0 ohms? | Yes | SERVICE open circuit between brake switch and stoplight ground. RECONNECT brake switch. RERUN Quick Test. |
| | | No | REPLACE brake switch. RECONNECT brake switch. RERUN Quick Test. |
| 6 | VERIFY BRAKE SWITCH IS NOT ALWAYS CLOSED <ul style="list-style-type: none"> Key off. Stoplight switch disconnected. Key on, engine off. Are stoplights still on? | Yes | Go to next Step. |
| | | No | VERIFY proper installation of brake switch. If OK. REPLACE stoplight switch. RECONNECT harness connector. RERUN Quick Test. |
| 7 | CHECK FOR SHORT TO POWER IN PCM <ul style="list-style-type: none"> Key off. Stoplight switch disconnected. Disconnect Powertrain Control Module (PCM). Key on, engine off. Are stoplights still on? | Yes | Go to next Step. |
| | | No | REPLACE PCM. RECONNECT all components. RERUN Quick Test. |


| STEP | INSPECTION | | ACTION |
|------|--|---|---|
| 8 | CHECK FOR SHORT TO POWER IN SHIFTLOCK ACTUATOR. • Key off. • PCM disconnected • Brake switch disconnected. • Disconnect shiftlock actuator, cruise control module and ABS module (if equipped) to isolate brake switch wiring. • Key on, engine off. • Are stoplights still on? | Yes | SERVICE short to power in brake switch/Stoplight circuit. RECONNECT PCM brake switch and accessories. RERUN Quick Test. |
| No | | SERVICE short in accessories (i.e. shiftlock actuator, ABS module, etc.). RECONNECT all components. RERUN Quick Test. | |

INTAKE-AIR SYSTEM


COMPONENT PARTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect the intake-air system components and repair or replace them as necessary.
3. Install in the reverse order of removal, referring to **Installation note**.



- | | |
|---|---|
| 1. Fresh-air duct Inspect for damage | 7. Accelerator cable Inspection / Adjustment page F3-104 |
| 2. Air cleaner Inspect for excessive dirt and damage | 8. Throttle body Inspection page F3-103 |
| 3. Air cleaner element | 9. BAC valve Inspection page F3-108 |
| 4. Mass air flow sensor Inspection page F3-157 | 10. Fuel distributor |
| 5. Air hose Inspect for damage | 11. Intake manifold bracket |
| 6. Resonance chamber Inspect for damage Installation note page F3-103 | 12. Intake manifold Installation note page F3-103 |




THROTTLE BODY

Inspection

1. Check the throttle body for wear, deposits, and coolant leakage.
2. Verify that the throttle valve moves smoothly when the throttle lever is moved from the closed throttle position to the wide open throttle.
3. Replace the throttle body if necessary.

Caution

- Do not remove the thin seal coating from the throttle valve or bore. It is necessary for proper operation.



INTAKE MANIFOLD


Installation note

1. Tighten the bolts in the order shown in the figure.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}


2. Refill the radiator with the specified engine coolant. (Refer to section E.)
3. Check for engine coolant leakage.




RESONANCE CHAMBER

Installation note

1. Slide the hose clamp onto the hose and push it onto resonance chamber.



2. Rotate the hose and hook it securely onto the locating knob.




3. Tighten the hose clamp.


ACCELERATOR PEDAL

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|---|----------------------|
| 1. Accelerator cable Inspection / Adjustment below | 3. Retainer |
| 2. Cruise actuator cable Adjustment ... 1996 626/MX-6 Body Electrical Troubleshooting Manual section Q | 4. Clip |
| | 5. Accelerator pedal |
| | 6. Return spring |
| | 7. Bracket |



ACCELERATOR CABLE

Inspection / Adjustment


1. Verify that the throttle valve is in the closed throttle position.
2. Measure the free play of the accelerator cable.

Free play: 1.5—4.0 mm {0.06—0.16 in}

3. If not as specified, adjust the cable free play by turning stopper (B) while pressing lock button (A) with the closed throttle position.
4. Reset the cable lock.








IDLE AIR CONTROL SYSTEM

DESCRIPTION



The idle air control system controls the bypass air amount that passes through the throttle body to improve startability, warm-up, idle smoothness, and drivability.

PREPARATION SST

| | | | |
|---|---|--|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of idle air control valve</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of idle air control valve</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of idle air control valve</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of idle air control valve</p> | <p>—</p> | <p>—</p> |


SYSTEM INSPECTION

Air Valve

Note

- This inspection must be done with the engine cold. Engine coolant below 20°C {68°F}.

1. Start the engine.
2. Verify that the idle speed decreases gradually as the engine warms up.
3. If the engine speed does not decrease inspect the idle air control valve and air valve. (Refer to page F3-108.)



Idle Air Control Valve


1. Start the engine and run it at idle.
2. Disconnect the IAC valve connector and verify that the engine speed changes.
3. If the engine condition will not change, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Select the "SIMULATION TEST" function on the NGS display.
 - (3) Change the duty value of the IAC valve to 100% by using the "SIMULATION TEST" function and verify that the idle speed increases.
 - I. If the idle speed increase, replace the PCM. (Refer to page F3-150.)
 - II. If the idle speed does not change, replace the BAC valve. (Refer to page F3-102.)
4. Warm up the engine to normal operating temperature and run it idle.
5. Turn the electrical load ON and verify that the engine speed is within the specification.

| Load condition | Idle speed (rpm) |
|---------------------------------|------------------|
| No load | 650—750 |
| Cooling fan ON | 675—775 |
| Fan switch ON at 3rd or higher | 675—775 |
| Head light switch ON | 675—775 |
| Rear window defroster switch ON | 675—775 |
| P/S ON | 650—750 |
| A/C ON | 725—825 |

Note

- Excludes temporary idle speed drop just after the electrical loads are turned ON.


6. If not as specified, check the related switches and wiring harnesses.

**IDLE AIR CONTROL VALVE****Inspection**

1. Disconnect the idle air control valve connector.
2. Measure the resistance of the valve.

Resistance: 7.7—9.3 [at 23°C {73°F}]


3. If not as specified, replace the BAC valve.

**AIR VALVE****Inspection**

1. Remove the BAC valve. (Refer to page F3-102.)
2. Cool the BAC valve to below 0°C {32°F}.
3. Heat the BAC valve at point (A) by using a blow drier, and verify that part (B) moves in the direction of the arrow in the figure.
4. If not as specified, replace the BAC valve.

FUEL SYSTEM



DESCRIPTION





This system supplies the fuel to the fuel injectors at a constant pressure. Fuel is metered and injected into the intake manifold according to injection control signals from the PCM. The system consists of the fuel tank, fuel pump, fuel filters, pressure regulator, pressure regulator control solenoid valve, fuel injectors, and fuel pump relay.

PREPARATION

SST

| | | | |
|--|--|--|---|
| <p>49 L018 901</p> <p>Injector checker</p>  | <p>For inspection of fuel injector</p> | <p>49 UN01 130</p> <p>104 Pin Breakout Box</p>  | <p>For inspection of PCM terminal voltage</p> |
|--|--|--|---|



Fuel Pressure and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.


Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".

Fuel Line Safety Procedures

- Release the fuel pressure before disconnecting a fuel line.
 - Start the engine.
 - Remove the fuel pump relay.
 - After the engine stalls, turn the ignition switch to OFF.
 - Install the fuel pump relay.
- Avoid leakage
 - When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - Plug the hose after removal.
- Use a fuel pressure gauge correctly; install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose to prevent leakage.



Priming Fuel System

After the fuel pressure has been released for repairs or inspection, the system must be primed to avoid excessive cranking when the engine is first started. Follow the steps below.


1. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
2. Turn the ignition switch to ON for **approx. 10 sec.** and check for fuel leaks.
3. Turn the ignition switch to OFF and disconnect the jumper wire.


SYSTEM INSPECTION

Fuel Pressure Hold Inspection


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" above.






1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**



Fuel pressure:
More than 150 kPa {1.5 kgf/cm², 21 psi}


8. If not as specified, perform the following inspections.
 - Fuel pump hold pressure. (Refer to page F3-114.)
 - Pressure regulator hold pressure. (Refer to page F3-118.)
 - Injector fuel leakage. (Refer to page F3-120.)



Fuel Line Pressure Inspection


Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F3-110.**



1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
5. Turn the ignition switch to ON.
6. Measure the fuel line pressure.

Fuel line pressure:
260—310 kPa {2.6—3.2 kgf/cm², 37—46 psi}



7. If not as specified, perform the following inspections.
 - Fuel pump maximum pressure. (Refer to page F3-115.)
 - Fuel line clogging and restriction.
 - Fuel filter clogging and restriction.
 - Pressure regulator hold pressure. (Refer to page F3-118.)


FUEL TANK

Removal / Inspection / Installation

Warning





- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F3-110.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.

1. Suck up the fuel from the fuel tank. (Refer to **Removal note** on page F3-113.)
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation note**.



1. Presilencer
2. Insulator
3. Connector
4. Fuel hoses
Installation note page F3-113

5. Evaporative hoses
Installation note page F3-113
6. Fuel tank strap
7. Fuel tank
Inspect for cracks and corrosion
Removal note page F3-113



Removal note

1. Remove the filler cap and insert a hose into the fuel tank through the filler pipe.
2. Start the pump and suck up the fuel into a container.

Note

- For easier work, prepare a hose of the following size.

Outer diameter: 13 mm {0.51 in}

Length: 2160 mm {85.0 in}

Installation note

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings **at least 25 mm {1.0 in}**.
2. Push the fuel filler hoses onto the fuel tank pipes and filler pipes **at least 35 mm {1.4 in}**.

FUEL FILTER

Replacement

Low-pressure side (in-tank filter)

(Refer to page F3-116.)

High-pressure side

The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

Warning






- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F3-110.**

1. Disconnect and plug the fuel hoses from the fuel filter.
2. Remove the fuel filter and bracket.
3. Install in the reverse order of removal.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

4. Verify that the fuel hoses are pushed fully onto the fuel filter nipples.
5. Secure the fuel hoses with clips.
6. Start the engine and verify that the fuel line joints do not leak.



FUEL PUMP

Inspection

Fuel pump operation

1. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
2. Remove the fuel filler cap.
3. Turn the ignition switch to ON.
4. Listen at the filler inlet for the operational sound of the fuel pump.
5. Install the fuel filler cap.

6. If no sound was heard, measure the voltage between terminal A of the vehicle harness side fuel pump connector and a ground (in the RH trunk compartment trim).

Voltage: B+

7. If the voltage is not correct, check the fuel pump relay and related wiring harness.
8. If the voltage is correct, check for continuity between terminals A and D of the fuel pump side connector (in the RH trunk compartment trim).
9. If there is continuity, check fuel pump ground circuit for open.
10. If there is no continuity, check for continuity between terminals A and D of the fuel pump connector as shown. (Underside of body)
11. If there is continuity, check terminal A and/or D harness between fuel pump connector to vehicle harness.
12. If there is no continuity, remove the fuel tank and replace the fuel pump. (Refer to page F3-116.)


Hold pressure

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F3-110.)

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F3-110.**


1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the fuel filter and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.



4. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
5. Turn the ignition switch to ON for **10 sec.** to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure **after 5 min.**

Fuel pressure: More than 340 kPa {3.5 kgf/cm², 50 psi}


8. If not as specified, replace the fuel pump.




Fuel pump maximum pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F3-110.



1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the fuel filter and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.



4. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
5. Turn the ignition switch to ON to operate the fuel pump.
6. Measure the pump maximum pressure.

**Fuel pump maximum pressure:
450—630 kPa {5.0—6.5 kgf/cm², 72—92 psi}**


7. Turn the ignition switch to OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.

Removal / Installation

1. Remove the fuel tank.
2. Remove the fuel pump, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.


Note

- Replace the fuel pump as an assembly.



- | | |
|-------------------|---------------------|
| 1. Fuel hose | 3. Fuel pump |
| 2. Fuel pump ring | 4. Fuel pump gasket |

Removal / Installation Note below





Removal note

Rotate the fuel pump ring counterclockwise and remove it.

Installation note

Rotate the fuel pump ring clockwise until the flange touches the stopper.






FUEL PUMP RELAY

Inspection

Operation check

Listen for clicking of the fuel pump relay while turning the ignition switch from OFF to START.




Continuity inspection

Check continuity between the terminals of the relay.


B+: Battery positive voltage

| Terminal A—B | Terminal C—D |
|----------------|---------------|
| B+ applied | Continuity |
| B+ not applied | No continuity |



Replacement

1. Remove the relay from main fuse block No.1.
2. Install in the reverse order of removal.



PRESSURE REGULATOR

Inspection

Fuel line pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F3-110.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.


Fuel line pressure:






210—260 kPa {2.1—2.6 kgf/cm², 30—37 psi}

6. Disconnect the vacuum hose from the pressure regulator and measure the fuel line pressure.

Fuel line pressure:

260—310 kPa {2.6—3.2 kgf/cm², 37—46 psi}





Hold pressure

Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F3-110.)

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F3-110.

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge between the fuel filter and the main fuel hose. (Install clamps as shown.)
3. Connect the negative battery terminal.

4. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
5. Turn the ignition switch to **ON for 10 sec.** to operate the fuel pump.
6. Turn the ignition switch to **OFF** and disconnect the jumper wire.
7. Pinch the fuel return hose with a plier.
8. Observe the fuel pressure **for 5 min.**

Fuel pressure: More than 147 kPa {1.5 kgf/cm², 21 psi}

9. If not as specified, replace the pressure regulator.

Replacement


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F3-110.

1. Disconnect the vacuum hose.
2. Disconnect the fuel return hose.
3. Remove the pressure regulator.
4. Install a new O-ring.
5. Install in the reverse order of removal.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



FUEL INJECTOR

Inspection

Operation check


1. Warm up the engine and let it idle.
2. Listen for the operational sound of each fuel injector with a screwdriver or a sound scope.
3. If no sound is heard, measure the fuel injector resistance. (Refer to page F3-121.)
4. If the fuel injector resistance is OK, check wiring to the fuel injector and the voltages of the PCM terminals 74, 75, 100 and 101. (Refer to page F3-150.)

Removal / Installation

Warning


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F3-110.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation note**.



1. Negative battery cable
2. Fuel injector connector
3. Fuel hose
4. Pressure regulator
Inspection page F3-117

5. Fuel distributor
Installation note page F3-121
6. Fuel injector
7. Insulator




Fuel leakage test


1. Remove the fuel injectors together with the fuel distributor. (Refer to page F3-119.)
2. Fasten the fuel injectors firmly to the pipe with wire.

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.



3. Connect PCM terminal No.80 and a ground by using a jumper wire and the **SST**.
4. Turn the ignition switch to ON.




5. Tilt the fuel injectors **approx. 60 degrees** and verify that there is no fuel leaks from the fuel injector nozzles.

Leakage specification

If there is more than one drop per 2 minutes, replace the fuel injector.

6. Turn the ignition switch to OFF and disconnect the jumper wire.




Volume test

1. Remove the fuel injectors together with the fuel distributor. (Refer to page F3-119.)
2. Fasten the fuel injectors firmly to the pipe with wire.

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.




3. Connect the **SST** to the battery and an fuel injector.
4. Check the injection volume with a graduated container.

Injection volumes:

47—68 ml {47—68 cc, 1.4—2.0 fl oz}/15 sec.

5. If not as specified, replace the fuel injectors.




Installation

Install in the reverse order of removal, referring to **Installation Note**.


Tightening torque

- A: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}
- B: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




Installation note

1. Use new fuel injector O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing them.



3. Install new fuel injector insulators.
4. Install the fuel injectors.



Inspection

Fuel injector resistance


1. Disconnect the fuel injector harness.
2. Measure the resistance of the fuel injector.

Resistance: 12—16Ω (at 20°C {68°F})

3. If not as specified, replace the fuel injector.








PRESSURE REGULATOR CONTROL SYSTEM


DESCRIPTION



To prevent vapor lock of the fuel during hot restart idle, vacuum to the pressure regulator is momentarily cut and the fuel injection pressure is increased to slightly more than **284 kPa {2.9 kgf/cm², 41.2 psi}**.

**PREPARATION
SST**

| | | | |
|---|-------------------------------------|---|-------------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of PRC system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of PRC system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PRC system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the “Fuel Line Safety Procedures” on page F3-110.

1. Install the fuel pressure gauge.
2. Measure the fuel pressure under the following conditions.


Specifications


| | Fuel pressure (kPa { kgf/cm ² , psi}) | | |
|------------------------------|--|--------------------------------------|--------------------------------------|
| | Idling | 210—260 { 2.1—2.6, 30—37 } | 210—260 { 2.1—2.6, 30—37 } |
| During 120 sec. of hot start | 260—310 { 2.6—3.2 , 37—46} | | |
| After 120 sec. of hot start | 210—260 { 2.1—2.6 , 37—46} | 210—260 { 2.1—2.6, 30—37 } | 260—310 { 2.6—3.2, 37—46 } |
| Judgement | Normal | Not normal (Perform Inspection 1) | Not normal (Perform Inspection 2) |

3. If the fuel pressure is not within the specification, carry out either Inspection 1 or Inspection 2 as required.


Inspection 1

1. Stop the engine.
2. Connect the **SSTs** (NGS) to the data link connector-2.
3. Start the engine and run it at idle.
4. Select the “SIMULATION TEST” function on the NGS display.
 - (1) Turn the PRC solenoid valve from ON to OFF by using the “SIMULATION TEST” function and check if the fuel pressure changes.
 - (2) If the pressure changes, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - Engine coolant temperature signal
 - Intake air temperature signal
 - Throttle valve TVO signal
 - (3) If the pressure does not change, do as follows.
 - I. Stop the engine.
 - II. Turn the ignition switch to ON.
 - III. Turn the PRC solenoid valve from ON to OFF by using the “SIMULATION TEST” function and check if the operation sound of the valve is heard.
 - a. If the operation sound is heard, check the following.
 - Pressure regulator (Refer to page F3-117.)
 - b. If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to page F3-126.)
 - Wiring between PRC solenoid valve and PCM terminal 19



**Inspection 2**


1. Stop the engine.
2. Install the **SSTs** (NGS) to the data link connector-2.
3. Turn the ignition switch to ON.
4. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
5. Select the pressure regulator solenoid valve and verify that the PRC solenoid valve is ON.
6. If the PRC solenoid valve is OFF, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - Engine coolant temperature signal
 - Intake air temperature signal
7. Select the "SIMULATION TEST" function on the NGS display.
8. Turn the PRC solenoid valve from ON to OFF by using the "SIMULATION TEST" function and check if the operation sound of the valve is heard.
 - (1) If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose between the pressure regulator, PRC solenoid valve, and intake manifold
 - (2) If the operation sound is not heard, check the following.
 - PRC solenoid valve (Refer to page F3-126.)
 - Wiring between PRC solenoid valve and PCM terminal 19



PRC SOLENOID VALVE

Inspection

1. Remove the solenoid valve.
2. Blow through the solenoid valve from port (A).
3. Verify that air flows from port (B).




4. Apply battery positive voltage to solenoid valve terminal.
5. Blow through the solenoid valve from port (A).
6. Verify that air flows from the valve air filter.
7. If not as specified, replace the solenoid valve.

EXHAUST SYSTEM

COMPONENT PARTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Main silencer Inspect for deterioration and restriction 2. Presilencer Inspect for deterioration and restriction 3. Three way catalytic converter Inspect for deterioration and restriction 4. Heated oxygen sensor (rear) Inspection page F3-163 | <ol style="list-style-type: none"> 5. Front pipe assembly Inspect for deterioration and restriction 6. Warm up three way catalytic converter Inspect for deterioration and restriction 7. Exhaust manifold insulator 8. Heated oxygen sensor (front) Inspection page F3-163 9. Exhaust manifold Inspect for deterioration and cracks |
|---|---|

OUTLINE OF EMISSION CONTROL SYSTEM

STRUCTURAL VIEW

The following systems are employed to reduce CO, HC, and NOx emissions.

1. Exhaust gas recirculation
2. Positive crankcase ventilation (PCV) system
3. Fuel evaporative system
4. Three way catalytic converter




EXHAUST GAS RECIRCULATION

DESCRIPTION

This system recirculates a small amount of exhaust gas into the intake manifold to reduce the combustion temperature and the NOx emissions.

This system consists of the EGR valve, EGR valve position sensor, two duty-solenoid valves, EGR boost sensor solenoid valve, EGR boost sensor, PCM, and input devices.



OPERATION

The EGR valve position can be precisely varied depending on engine operating conditions. Spark advance can be adjusted to compensate for EGR flow.

Cold engine (coolant temperature: below 26°C {78°F})








EGR operation is stopped to improve drivability when the engine is cold.

Function

EGR operates when the following conditions are met.


| Operating condition |
|--|
| TP, MAF, ECT, IAT or EGR valve position sensor have not failed |
| While not in crank |
| After warm up (warming up) |
| Engine speed above 1,000 rpm |
| Except in heavy load |


PREPARATION SST

| | | | |
|---|-------------------------------------|--|-------------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of EGR system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of EGR system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of EGR system</p> | <p>—</p> | <p>—</p> |

SYSTEM INSPECTION

1. Connect the **SSTs** (NGS) to the data link connector-2.
2. Start the engine and let it at idle.
3. Select the "SIMULATION TEST" function on the NGS display.
4. Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the "SIMULATION TEST" function. Operate the EGR solenoid valve (vacuum) and check if the engine speed becomes unstable or the engine stalls.
5. If the engine speed will not change, stop the engine and do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Select the "SIMULATION TEST" function.
 - (3) Increase the duty value of the EGR solenoid valve (vacuum) from 0% to 100% by using the "SIMULATION TEST" function. Operate the EGR solenoid valve (vacuum) and check if operation sound of the valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - EGR valve (Refer to page F3-132.)
 - EGR solenoid valve (vent) (Refer to page F3-131.)
 - II. If the operation sound is not heard, check the following.
 - EGR solenoid valve (vacuum) (Refer to page F3-131.)
 - Wiring between EGR solenoid valve (vacuum) and PCM terminal 72





EGR SOLENOID VALVE (VACUUM)

Inspection


1. Remove the EGR solenoid valve (vacuum).
2. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vacuum). Verify that air flows as shown below.

Specification

B+: Battery positive voltage

| Terminal A—B | Air flow |
|----------------|----------|
| B+ applied | Yes |
| B+ not applied | No |

3. If not as specified, replace the EGR solenoid valve (vacuum).



EGR SOLENOID VALVE (VENT)


Inspection

1. Remove the EGR solenoid valve (vent).
2. Verify that air flows as shown below.

Specification


| Port | Air flow |
|------|----------|
| A—B | Yes |
| A—C | Yes |
| B—C | Yes |

3. If not as specified, replace the EGR solenoid valve (vent).
4. Apply battery positive voltage to terminal A and ground terminal B of the EGR solenoid valve (vent). Verify that air flows as shown below.



Specification

| Port | Air flow |
|------|----------|
| A—B | Yes |
| A—C | No |
| B—C | No |



EGR VALVE


Inspection

1. Start the engine and let it idle.
2. Connect a vacuum pump as shown and apply vacuum.
3. Verify that the engine runs roughly or stalls at more than the specified vacuum.

Specification:

5.4—7.7 kPa {40—60 mmHg, 1.6—2.3 inHg}


4. If not as specified, replace the EGR valve.



Replacement

Plug the water hoses after disconnecting them.

1. Remove the EGR valve in the sequence shown below.
 - (1) Vacuum hose
 - (2) EGR valve position sensor connector
 - (3) EGR valve and gasket
2. Install a new gasket, and then install the EGR in the reverse order of removal.



EGR BOOST SENSOR SWITCHING CONTROL SYSTEM

SYSTEM INSPECTION

1. Warm up the engine to normal operating temperature and let it at idle.
2. Disconnect the vacuum hose from the EGR boost sensor side of the EGR boost sensor solenoid valve.
3. Put a finger on the port of the EGR boost sensor solenoid valve and verify that no vacuum is felt.

EGR BOOST SENSOR SOLENOID VALVE

Inspection



1. Remove the EGR boost sensor solenoid valve.
2. Blow air into each part and verify that air flows as specified below.

| Ports | Air flow |
|-------|----------|
| A—B | No |
| A—C | No |
| B—C | Yes |

3. If not as specified, replace the EGR boost sensor solenoid valve.
4. Apply battery positive voltage between the terminals of the EGR boost sensor solenoid valve.
5. Blow air into each port and verify that air flows as specified below.

| Ports | Air flow |
|-------|----------|
| A—B | Yes |
| A—C | No |
| B—C | No |



6. If not as specified, replace the EGR boost sensor solenoid valve.



POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM


DESCRIPTION

The PCV valve is operated by the intake manifold vacuum. When the engine is running at idle, the PCV valve is slightly open and a small amount of blowby gas is drawn into the intake manifold to be burned. As the engine speed rises, the PCV valve is opened further, allowing a larger amount of blowby gas to be drawn into the intake manifold.




PCV VALVE Inspection

1. Verify that the engine coolant temperature is below 20°C {68°F}.
2. Start the engine and let it idle.
3. Disconnect the PCV valve with the ventilation hose from the cylinder head cover.
4. Block the PCV valve opening.
5. Verify that vacuum is felt.
6. Remove the PCV valve.
7. Blow through the valve from port (A) and verify that air comes out of port (B).
8. Blow through the valve from port (B) and verify that no air comes out of port (A).
9. Replace the PCV valve if not as specified.



FUEL EVAPORATIVE SYSTEM

DESCRIPTION










The fuel evaporative system consists of the fuel vapor valve, two-way check valve, charcoal canister, purge solenoid valve, PCM, and input devices. The amount of evaporative fumes introduced into the engine and burned is controlled by the solenoid valve to correspond to the engine's operating conditions. To obtain the best engine performance, the purge solenoid valve is controlled by the PCM.



Operation

The purge solenoid valve is controlled by duty signals from the PCM to perform purging of the charcoal canister. Purging is done when these conditions are met:

1. After warm-up
2. Driving in gear
3. Accelerator pedal depressed
4. Heated oxygen sensor functioning normally


**PREPARATION
SST**

| | | | |
|---|--|---|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of fuel evaporative system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of fuel evaporative system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION


1. Start and warm up the engine to the normal operating temperature.
2. Let the engine idle.
3. Disconnect the vacuum hose between the purge solenoid valve and the charcoal canister.
4. Put a finger to the purge solenoid valve and verify that there is no vacuum applied.
5. If there is vacuum, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F3-14.)
 - (3) If diagnostic trouble codes are not shown, check the following.
 - Purge solenoid valve (Refer to page F3-137.)
6. Reconnect the vacuum hose.
7. Connect the **SSTs** (NGS) to the data link connector-2.
8. Select the "SIMULATION TEST" function on the NGS display.
9. Increase the duty value of the purge solenoid valve from 0% to 100% by using the "SIMULATION TEST" function. Operate the purge solenoid valve and check if the idle condition changes.
10. If the condition does not change, do as follows.
 - (1) Turn the ignition switch to ON.
 - (2) Verify that diagnostic trouble code No. P0443 is not displayed. If code No. P0443 is shown, carry out troubleshooting of the code No. P0443. (Refer to page F3-14.)
 - (3) Select the "SIMULATION TEST" function on the NGS display.
 - (4) Increase duty value of the purge solenoid valve from 0% to 100% by using the "SIMULATION TEST" function. Operate the purge solenoid valve and check if the operation sound of the valve is heard.
 - I. If the operation sound is heard, check the following.
 - Loose or damaged vacuum hose
 - II. If the operation sound is not heard, check the following.
 - Purge solenoid valve (Refer to page F3-137.)




PURGE SOLENOID VALVE

Inspection

1. Disconnect the vacuum hoses from the solenoid valve.
2. Verify that no air flows through the valve.




3. Disconnect the solenoid valve connector and supply battery positive voltage as shown in the figure.
4. Verify that air flows through the valve.
5. If not as specified, replace the solenoid valve.




FUEL VAPOR VALVE

Inspection

1. Hold the valve as shown and verify that air flows through the valve from port (A).



2. Invert the valve as shown and verify that no air flows through the valve from port (A).
3. Replace the fuel vapor valve if necessary.




CHECK VALVE (TWO-WAY)

Inspection

1. Remove the valve.
2. Check the operation of the valve by using a vacuum pump.

| | |
|--|-------------|
| Apply approx. 3.5 kPa {26 mmHg, 1.0 inHg} vacuum at port A | Valve opens |
| Apply approx. 5.9 kPa {44 mmHg, 1.7 inHg} vacuum at port B | Valve opens |

**CHARCOAL CANISTER****Inspection**


1. Visually check for damage.
2. Replace the charcoal canister if necessary.

FUEL-CUT CONTROL SYSTEM








DESCRIPTION


This system is used to improve the fuel economy, to prevent engine bucking during deceleration, and to protect the engine from overrevving.

Deceleration fuel-cut



PREPARATION SST

| | | | |
|---|--|---|--|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 010B Program Card</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>—</p> | <p>—</p> |


**SYSTEM INSPECTION**

1. Warm up the engine to normal operating temperature and let it idle.
2. Connect the **SSTs** (NGS) to the data link connector-2.
3. Select the "PID/DATA MONITOR AND RECORD" function on the NGS display. Confirm that the transaxle is in P position.
4. Select the engine revolution and fuel injector on the NGS display.
5. Increase the engine speed to 3,000 rpm, then suddenly release the throttle.
6. Verify that the fuel injection duration is 0 msec while the engine speed is above approx. 2,500 rpm on deceleration.

A/C CUTOFF SYSTEM

DESCRIPTION

An A/C cutoff system is used to improve idle smoothness just after starting the engine and to improve acceleration performance.











Operation

The A/C clutch operation is cancelled under the conditions below.

| Engine condition | Purpose | Cutoff period |
|-----------------------------------|----------------------------|--|
| After engine starting | Improve engine starting | Approx. 4 sec. |
| Wide open throttle | Improve drivability | Approx. 8 sec. |
| Acceleration from idle | | Approx. 2 sec. |
| Coolant temp. above 117°C {242°F} | Prevent engine overheating | Until coolant temp. decrease below 107°C {224°F} |


**PREPARATION
SST**

| | | | |
|---|---|---|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of A/C cut off system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of A/C cut off system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

1. Start the engine and let it idle.
2. Turn the A/C switch and the fan switch ON.
3. Fully open the throttle valve. Then, 3—6 seconds after, check if the operation sound of the A/C compressor electromagnetic clutch is heard.
4. Turn the A/C switch and the fan switch OFF.
5. If the operation sound is not heard, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Select the "SIMULATION TEST" function on the NGS display.
 - (3) Turn the A/C relay from OFF to ON by using the "SIMULATION TEST" function and check for the operation sound of the relay.
 - I. If the operation sound is heard, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - Throttle position sensor TVO signal
 - II. If the operation sound is not heard, check the following.
 - A/C relay (Refer to Mazda 1996 626/MX-6 BETM.)
 - Open circuit in wiring harnesses and connectors (Main relay — A/C relay — PCM)



DECHOKE CONTROL SYSTEM


SYSTEM INSPECTION

1. Turn the ignition switch to START and verify that the fuel injector operating sound is heard.
2. Depress the accelerator pedal fully and turn the ignition switch to START. Verify that no fuel injector operating sound is heard.
3. If operating sound is heard, check the PCM terminal 88 voltage. (Refer to page F3-150.)

COOLING FAN CONTROL SYSTEM

DESCRIPTION








To improve reliability, the cooling fan is controlled by the PCM. This system consists of the cooling fan motor, fan relays, PCM, and input devices.




Cooling fan operation

| Engine condition | Fan relay |
|---|-----------|
| Engine coolant temperature above 97°C {207°F} | ON |
| Air conditioning switch ON | ON |
| Engine coolant temperature sensor malfunction | ON |

**PREPARATION
SST**


| | | | |
|---|---|---|---|
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of cooling fan control system</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of cooling fan control system</p> | <p>—</p> | <p>—</p> |



SYSTEM INSPECTION

Cooling Fan

1. Verify that the engine is cold.
2. Turn the ignition switch to ON.
3. Verify that the cooling fan is not operating.
4. If the cooling fan is operating, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Select the "PID/DATA MONITOR AND RECORD" function on the NGS display.
 - (3) Select the "Cooling Fan" and verify that the cooling fan control signal is OFF.
 - I. If the cooling fan control signal is ON, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - Engine coolant temperature signal
 - II. If the cooling fan control signal is OFF, check the following.
 - Cooling fan relay (Refer to section E1.)
 - Short circuit in wiring harnesses and connectors (Main relay — Cooling fan relay — PCM)
5. Start the engine.
6. Verify that the cooling fan is operating when engine is hot.
7. If the cooling fan does not operate, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Select the "SIMULATION TEST" function.
 - (3) Turn the cooling fan relay from OFF to ON by using the "SIMULATION TEST" function and check for the cooling fan operation.
 - I. If the cooling fan operates, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - Engine coolant temperature signal
 - II. If the cooling fan does not operate, do as follows.
 - a. Select the "SIMULATION TEST" function and turn the cooling fan relay from OFF to ON by using the "SIMULATION TEST" function. Operate the cooling fan relay and check if the operation sound of the relay is heard.
 - b. If the operation sound is heard, check the following.
 - Wiring harnesses and connectors (Cooling fan relay — Cooling fan motor)
 - Cooling fan motor (Refer to section E1.)
 - c. If the operation sound is not heard, check the following.
 - Cooling fan relay (Refer to section E1.)
 - Open circuit in wiring harnesses and connectors (Main relay — Cooling fan relay — PCM)












Condenser Fan relay


1. Verify that the A/C switch and fan switch are OFF.
2. Start the engine and let it idle.
3. Verify that the cooling fan is not operating.
4. If the condenser fan is operating, check the short circuit in wiring between condenser fan relay and PCM terminal 69.
5. Turn the A/C switch and fan switch ON.
6. Verify that the condenser fan is operating.
7. Turn the A/C switch and fan switch off.
8. If the condenser fan does not operate, do as follows.
 - (1) Connect the **SSTs** (NGS) to the data link connector-2.
 - (2) Select the "SIMULATION TEST" function on the NGS display.
 - (3) Turn the condenser fan relay from OFF to ON by using the "SIMULATION TEST" function and check for the condenser fan operation.
 - I. If the condenser fan operates, check the following.
 - PCM terminal voltage (Refer to page F3-150.)
 - A/C signal
 - Blower signal
 - II. If the condenser fan does not operate, do as follows.
 - a. Select the "SIMULATION TEST" function and turn the condenser fan relay from OFF to ON by using the "SIMULATION TEST" function. Operate the condenser fan relay and check if the operation sound of the relay is heard.
 - b. If the operation sound is heard, check the following.
 - Wiring harness and connectors (Condenser fan relay — Condenser fan motor)
 - Condenser fan motor (Refer to Mazda 1996 626/MX-6 BETM.)
 - c. If the operation sound is not heard, check the following.
 - Condenser fan relay (Refer to Mazda 1996 626/MX-6 BETM.)
 - Open circuit in wiring harness and connectors (Main relay — Condenser fan relay — PCM)

CONTROL SYSTEM

PREPARATION SST

| | | | |
|---|--|--|--|
| <p>49 UN01 130 104 Pin Breakout Box</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 0A0 NGS set</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 008A Instruction Manual</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T018 001 Wrench, O₂ sensor</p>  | <p>For replacement of heated oxygen sensor</p> | <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of PCM terminal voltage and input/output devices</p> | <p>—</p> | <p>—</p> |

STRUCTURAL VIEW



- | | | | |
|--------------------------------------|-------------|----------------------------------|-------------|
| 1. Fuel pump relay | | 8. Intake air temperature sensor | |
| Inspection | page F3-117 | Inspection | page F3-163 |
| Replacement | page F3-117 | Replacement | page F3-163 |
| 2. Powertrain control module | | 9. Heated oxygen sensor | |
| Removal / Installation | page F3-150 | Inspection | page F3-163 |
| Inspection | page F3-150 | 10. EGR valve position sensor | |
| 3. Mass air flow sensor | | Inspection | page F3-164 |
| Inspection | page F3-157 | 11. EGR boost sensor | |
| 4. Camshaft position sensor | | Inspection | page F3-165 |
| Inspection | page F3-158 | 12. Transaxle range switch | |
| 5. Crankshaft position sensor | | Inspection | section K2 |
| Inspection | page F3-158 | Replacement | section K2 |
| Replacement | page F3-159 | 13. P/S pressure switch | |
| 6. Throttle position sensor | | Inspection | page F3-166 |
| Inspection | page F3-159 | Replacement | page F3-166 |
| Adjustment | page F3-160 | 14. Main relay | |
| Replacement | page F3-162 | Inspection | page F3-166 |
| 7. Engine coolant temperature sensor | | | |
| Removal | page F3-162 | | |
| Inspection | page F3-162 | | |
| Installation | page F3-163 | | |

POWERTRAIN CONTROL MODULE (PCM)

Removal / Installation


Caution

- Powertrain control module is sensitive to static electrical charges. If exposed to these charges, damage may result.

If service of powertrain control module is required, use the following safeguards to avoid damage to components.

1. Leave the PCM in their original packaging until ready to install in vehicles.
2. Avoid touching PCM connector pins.
3. Avoid laying modules on nonconductive surfaces.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal.




1. Negative battery cable
2. Console

3. PCM connector
4. PCM

Removal Note


- The PCM stores information about vehicle operating conditions and uses this information to compensate for component tolerance. When an emission related component is replaced, Keep Alive Memory (KAM) should be cleared to erase the information stored by the PCM from the original component.




Inspection

Using SST (104 Pin Breakout Box)

1. Disconnect the PCM connectors.
2. Connect the SST to the PCM as shown.
3. Measure the voltage at each terminal.
(Refer to pages F3-152 through F3-156.)
4. If any PCM terminal voltage is incorrect, check the related input or output devices and wiring. If not problem is found, replace the PCM. (Refer to above.)



NGS DISPLAY

**Using SST (NGS)**

1. In the passenger compartment, connect the **SST** to the data link connector-2 as shown in the figure.
2. Referring to the NGS instruction manual, select the "PID/DATA MONITOR AND RECORD" function.
3. Referring to the 1996 Service Highlight, inspect each PCM input/output signal.

Note

- The "PID/DATA MONITOR AND RECORD" function is to monitor the calculation value of input/output signals in the PCM. Deviation in the value does not always indicate malfunction in the related input/output devices.
 - For inspection of the input/output signals other than in the link monitor table, check voltage at the applicable PCM terminal by using the **SST** (104 Pin Breakout Box).
4. If normal output signal cannot be detected when all input signals are normal, replace the PCM.
(Refer to page F3-150.)

Terminal voltage (Reference)

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|--------------------------------|--|--|------------------------------------|-------------|---|
| 1 | Shift solenoid 2 (SS2) | Solenoid body | ON | | B+ | • Solenoid body (Refer to section K2) |
| | | | OFF | | Below 1.0 | |
| 2 | MIL | Malfunction indicator lamp | Malfunction indicator lamp OFF | | B+ | • PCM terminal 2 — MIL |
| | | | Malfunction indicator lamp ON | | Below 1.0 | |
| 3 | — | — | — | | — | — |
| 4 | — | — | — | | — | — |
| 5 | — | — | — | | — | — |
| 6 | — | — | — | | — | — |
| 7 | — | — | — | | — | — |
| 8 | — | — | — | | — | — |
| 9 | — | — | — | | — | — |
| 10 | Blower | Fan switch | Ignition switch ON | Fan switch OFF or ON at 1st or 2nd | 9.6 | • Fan switch (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | | Fan switch ON at 3rd or higher | Below 1.0 | |
| 11 | — | — | — | | — | — |
| 12 | — | — | — | | — | — |
| 13 | — | — | — | | — | — |
| 14 | DRL (CANADA) | DRL unit | Daytime running light ON | | Below 1.0 | • DRL unit (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | Daytime running light OFF | | Above 11.0 | |
| 15 | Diagnostic trouble code output | Data link connector-2 terminal BUS- | Carry out inspection according to diagnostic trouble code Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible (Refer to page F2-55) | | — | • On-board diagnostic system |
| 16 | Diagnostic trouble code input | Data link connector, Data link connector-2 (Terminal BUS+) | Carry out inspection according to diagnostic trouble code Diagnostic trouble code output is a part of serial communication Judgement by terminal voltage is not possible (Refer to page F1-56) | | — | • On-board diagnostic system |
| 17 | — | — | — | | — | — |
| 18 | — | — | — | | — | — |
| 19 | Pressure regulator control | PRC solenoid valve | Idle (Hot condition) | | Below 1.0 | • PRC solenoid valve (Refer to page F3-126) |
| | | | Other | | B+ | |
| 20 | — | — | — | | — | — |
| 21 | NE⊕ | Crankshaft position sensor | Ignition switch ON | | Approx. 1.5 | • Crankshaft position sensor (Refer to page F3-158) |
| | | | Idle | | | |
| 22 | NE⊖ | Crankshaft position sensor | Ignition switch ON | | Approx. 1.5 | • Crankshaft position sensor (Refer to page F3-158) |
| | | | Idle | | | |
| 23 | Ground | Ground | Constant | | Below 1.0 | • PCM 23 terminal harness (Open) |
| 24 | Ground | Ground | Constant | | Below 1.0 | • PCM 24 terminal harness (Open) |
| 25 | — | — | — | | — | — |

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|-------------------------------|--|-----------------------|------------------------------------|-------------|--|
| 26 | IGT | Ignition coil | Ignition switch ON | | B+ | • Ignition coil (Refer to section G) |
| | | | Idle | | B+ | |
| 27 | Shift solenoid 1 (SS1) | Solenoid body | ON | | B+ | • Solenoid body (Refer to section K2) |
| | | | OFF | | Below 1.0 | |
| 28 | — | — | — | | — | — |
| 29 | O/D OFF switch | O/D OFF switch | O/D off switch | Release | B+ | • O/D OFF switch (Refer to section K2) |
| | | | | Push | Below 1.0 | |
| 30 | — | — | — | | — | — |
| 31 | Power steering pressure | Power steering pressure switch | Ignition switch ON | | B+ | • Power steering pressure switch (Refer to page F3-166) |
| | | | Idle | P/S not operating | | |
| | | | | P/S operating | Below 1.0 | |
| 32 | — | — | — | | — | — |
| 33 | Ground | Vehicle speedometer sensor (VSS) (-) | Constant | | Below 1.0 | • Vehicle speedometer sensor (Refer to section K2) |
| 34 | Barometric pressure/EGR boost | EGR boost sensor | Ignition switch ON | | Approx. 4.5 | • EGR boost sensor (Refer to page F3-165) |
| | | | Idle | | | |
| 35 | Heated oxygen sensor (Rear) | Heated oxygen sensor (Rear) | Idle | After warm up | 0—1.0 | • Heated oxygen sensor (Refer to page F3-163) |
| | | | Acceleration | | 0—1.0 | |
| | | | Deceleration | | 0—1.0 | |
| 36 | Ground | Mass air flow sensor | Constant | | Below 1.0 | • Mass air flow sensor (Refer to page F3-157) |
| 37 | Transaxle fluid temperature | Transaxle fluid temperature (TFT) sensor | After warm up (Idle) | | 0.7 | • Transaxle fluid temperature (TFT) sensor (Refer to section K2) |
| 38 | Engine coolant temperature | Engine coolant temperature sensor | Ignition switch ON | Engine coolant temp 20°C {68°F} | Approx. 5.0 | • Engine coolant temperature sensor (Refer to page F3-162) |
| | | | | After warm up | Below 1.0 | |
| 39 | Intake air temperature | Intake air temperature sensor | Ignition switch ON | Intake air temperature 20°C {68°F} | Approx. 2.2 | • Intake air temperature sensor (Refer to page F3-163) |
| 40 | — | — | — | | — | — |
| 41 | A/C | A/C amplifier | Idle | A/C switch and blower switch ON | Below 1.2 | • A/C switch • Refrigerant pressure switch • A/C amplifier (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | | A/C switch OFF | B+ | |
| 42 | — | — | — | | — | — |
| 43 | — | — | — | | — | — |
| 44 | — | — | — | | — | — |
| 45 | Cooling fan control | Cooling fan relay | Cooling fan operating | | Below 1.0 | • Cooling fan relay (Refer to section E1) |
| | | | Cooling fan stops | | B+ | |
| 46 | — | — | — | | — | — |

B+: Battery positive voltage
*1: In data link connector


| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|--|--------------------------------------|---------------------------------------|----------------------------------|--------------|---|
| 47 | — | — | — | | — | — |
| 48 | — | — | — | | — | — |
| 49 | Headlight | Headlight switch | Headlight switch OFF | | Below 1.0 | <ul style="list-style-type: none"> Headlight switch (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | Headlight switch ON | | B+ | |
| 50 | — | — | — | | — | — |
| 51 | Ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> PCM terminal 51 harness (open) |
| 52 | — | — | — | | — | — |
| 53 | — | — | — | | — | — |
| 54 | Torque converter clutch solenoid valve (TCC) | Solenoid body | Torque converter clutch operation | | B+ | <ul style="list-style-type: none"> Solenoid body (Refer to section K2) |
| | | | Torque converter clutch non-operation | | 0 | |
| 55 | Back-up power supply | Battery | Constant | | B+ | <ul style="list-style-type: none"> PCM 55 terminal — Battery harness and connector |
| 56 | — | — | — | | — | — |
| 57 | — | — | — | | — | — |
| 58 | Vehicle speed | Vehicle speedometer sensor (VSS) (+) | Idle (AC range) | | Approx. 0.1 | <ul style="list-style-type: none"> Vehicle speedometer sensor (Refer to section K2) |
| | | | 48 km/h {30 mph} (AC range) | | Approx. 8.0 | |
| | | | 88 km/h {55 mph} (A/C range) | | Approx. 12.7 | |
| 59 | Cruise control | Cruise control unit | Ignition switch ON | | B+ | <ul style="list-style-type: none"> Cruise control system (Refer to Mazda 1996 626/MX-6 BETM) |
| 60 | Heated oxygen sensor (Front) | Heated oxygen sensor (Front) | Idle | After warm up | 0—1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (Refer to page F3-163) |
| | | | Acceleration | | 0.5—1.0 | |
| | | | Deceleration | | 0—0.5 | |
| 61 | — | — | — | | — | — |
| 62 | — | — | — | | — | — |
| 63 | — | — | — | | — | — |
| 64 | Transaxle range | Transaxle range switch | Ignition switch ON | P position | 4.5 | <ul style="list-style-type: none"> Transaxle range switch (Refer to section K2) |
| | | | | R position | 3.7 | |
| | | | | N position | 2.9 | |
| | | | | D range | 2.2 | |
| | | | | S range | 1.4 | |
| | | | | L range | 0.7 | |
| 65 | EGR valve position | EGR valve position sensor | Ignition switch ON | | Approx. 0.7 | <ul style="list-style-type: none"> EGR valve position sensor (Refer to page F3-164) PCM terminal 90 voltage |
| | | | Idle | | | |
| 66 | Rear window defroster | Rear window defroster switch | Ignition switch ON | Rear window defroster switch OFF | B+ | <ul style="list-style-type: none"> Rear window defroster switch (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | | Rear window defroster switch ON | Below 1.0 | |

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|-----------------------------------|---|--------------------|-------------------------|------------------|--|
| 67 | Purge control | Purge solenoid valve | Ignition switch ON | | B+ | • Purge solenoid valve (Refer to page F3-137) |
| | | | Idle | | | |
| 68 | EGR control (Vent) | EGR solenoid valve (Vent) | Ignition switch ON | | B+ | • EGR solenoid valve (Vent) (Refer to page F3-131) |
| | | | Idle | | | |
| 69 | A/C control | A/C relay | Ignition switch ON | | B+ | • A/C relay (Refer to Mazda 1996 626/MX-6 BETM) |
| | | | Idle | A/C operating | Below 1.0 | |
| | | | | A/C stop | B+ | |
| 70 | — | — | — | | — | — |
| 71 | Power supply | Main relay | Ignition switch | OFF | Below 1.0 | • Main relay (Refer to page F3-166) |
| | | | | ON | B+ | |
| 72 | EGR control (Vacuum) | EGR solenoid valve (Vacuum) | Ignition switch ON | | B+ | • EGR solenoid valve (Vacuum) (Refer to page F3-131) |
| | | | Idle | | | |
| 73 | — | — | — | | — | — |
| 74 | Fuel injector control | Fuel injector No.3 | Ignition switch ON | | B+ | • Fuel injector (Refer to page F3-119) |
| 75 | | Fuel injector No.1 | Idle | | B+ | |
| 76 | Ground | Ground | Constant | | Below 1.0 | • PCM 76 terminal harness (Open) |
| 77 | Ground | Ground | Constant | | Below 1.0 | • PCM 77 terminal harness (Open) |
| 78 | — | — | — | | — | — |
| 79 | O/D OFF indicator light | O/D OFF indicator light | Idle | SW OFF | B+ | • O/D off switch (Refer to section K2) |
| | | | | SW ON (O/D OFF) | Below 1.0 | |
| 80 | Fuel pump control | Fuel pump relay | Ignition switch ON | | B+ | • Fuel pump relay (Refer to page F1-117) |
| | | | Cranking | | Below 1.0 | |
| | | | Idle | | | |
| 81 | Electronic pressure control (EPC) | Solenoid body | Idle | | 8.3 | • Solenoid body (Refer to section K2) |
| | | | 48 km/h {30 mph} | | 9.7 | |
| | | | 88 km/h {55 mph} | | 11.1 | |
| 82 | — | — | — | | — | — |
| 83 | Idle air control | Idle air control valve | Ignition switch ON | | B+ | • Idle air control valve (Refer to page F3-108) |
| | | | Idle | After warm up (No load) | Approx. 10 | |
| 84 | Turbine shaft speed (TSS) | Turbine shaft speed (TSS) sensor | Idle | S or L range | 0 | • TSS sensor (Refer to section K2) |
| | | | | D or R range | 0 | |
| | | | | P or N range | 0.6—0.7 | |
| | | | Driving | 48 km/h {30 mph} | 0.8 | |
| | | | | 88 km/h {55 mph} | 11.8 | |
| 85 | SGC | Camshaft position sensor (In distributor) | Ignition switch ON | | 0 or Approx. 5.0 | • Camshaft position sensor (Refer to page F3-158) |
| | | | Idle | | Approx. 6.5 | |
| 86 | — | — | — | | — | — |
| 87 | — | — | — | | — | — |

B+: Battery positive voltage
*1: In data link connector

| Terminal | Signal | Connected to | Test condition | | Voltage (V) | Possible malfunction |
|----------|---|---|-----------------------|--------------------------|-------------|--|
| 88 | Mass air flow sensor (HRP) | Mass air flow sensor | Ignition switch ON | | 0.15—0.20 | <ul style="list-style-type: none"> Mass air flow sensor (Refer to page F3-157) |
| | | | Idle | | 0.6—1.1 | |
| 89 | Throttle position (TVO) | Throttle position sensor | Ignition switch ON | Closed throttle position | 0.3—0.7 | <ul style="list-style-type: none"> Throttle position sensor (Refer to page F3-159) PCM terminal 90 voltage |
| | | | | Wide open throttle | 3.4—5.3 | |
| 90 | Constant voltage (Vref) | Throttle position sensor EGR valve position sensor EGR boost sensor | Ignition switch ON | | Approx. 5.0 | <ul style="list-style-type: none"> PCM terminal 90 voltage |
| 91 | Ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> PCM 91 terminal harness |
| 92 | Brake | Brake switch | Brake pedal released | | Below 1.0 | <ul style="list-style-type: none"> Brake switch (Refer to section P) |
| | | | Brake pedal depressed | | B+ | |
| 93 | Heated oxygen sensor (Front) heater control | Heated oxygen sensor (Front) | Idle | | Below 1.0 | <ul style="list-style-type: none"> Heated oxygen sensor (Front) |
| | | | Ignition switch ON | | B+ | |
| 94 | — | — | — | | — | — |
| 95 | — | — | — | | — | — |
| 96 | — | — | — | | — | — |
| 97 | Power supply | Main relay | Ignition switch | OFF | Below 1.0 | <ul style="list-style-type: none"> Main relay (Refer to page F3-166) |
| | | | | ON | B+ | |
| 98 | EGR boost sensor switching control | EGR boost sensor solenoid valve | Ignition switch ON | | B+ | <ul style="list-style-type: none"> EGR boost sensor solenoid valve (Refer to page F1-132) |
| | | | Idle | | | |
| 99 | — | — | — | | — | — |
| 100 | Fuel injector control | Fuel injector No.4 | Ignition switch ON | | B+ | <ul style="list-style-type: none"> Fuel injector (Refer to page F3-119) |
| 101 | | Fuel injector No.2 | Idle | | B+ | |
| 102 | 3-2 Timing/coasting clutch solenoid (3-2 T/CCS) | Solenoid body | Idle (P/R/N/D range) | | 8.5 | <ul style="list-style-type: none"> Solenoid body (Refer to section K2) |
| | | | Idle (S/L range) | | B+ | |
| 103 | Ground | Ground | Constant | | Below 1.0 | <ul style="list-style-type: none"> PCM 103 terminal harness |
| 104 | — | — | — | | — | — |

**MASS AIR FLOW SENSOR****Inspection****Using the SST (104 Pin Breakout Box)**

1. Check the mass air flow sensor for damage and cracks.
2. Connect the **SSTs** to the PCM. (Refer to page F3-150.)
3. Measure the voltage at PCM terminal 88.
(Refer to page F3-155.)
4. Verify that the voltage is within the specification.

Specification

| Measuring condition | Voltage (V) |
|---------------------|-------------|
| Ignition switch ON | 0.15—0.20 |
| Idle | 0.6—1.1 |

5. If not as specified, inspect the harness and connector between the mass air flow sensor and the PCM terminal.
6. If there is correct terminal voltage and harness continuity, replace the mass air flow sensor.
(Refer to page F3-102.)

Using the SST (NGS)

1. Check the mass air flow sensor for damage and cracks.
2. Connect the **SSTs** to the data link connector-2.
(Refer to page F3-151.)
3. Select the "PID/DATA MONITOR AND RECORD" function of the NGS.
4. Select the mass air flow sensor on the NGS. The NGS measures and shows the voltage.

Specification

| Measuring condition | Voltage (V) |
|---------------------|-------------|
| Ignition switch ON | 0.15—0.20 |
| Idle | 0.6—1.1 |

5. If not as specified, inspect the harness and connector between the mass air flow sensor and the PCM terminal.
6. If there is correct terminal voltage and harness continuity, replace the mass air flow sensor.
(Refer to page F3-102.)

Note

- The scan tool shows the mass airflow rate and load value.



Specification

| Engine speed (rpm) | Mass intake airflow amount (g/s) | Engine load calculated value (%) |
|--------------------|----------------------------------|----------------------------------|
| 650—750 (Idle) | 2.2—3.1 | 18.0—23.0 |
| 2,500* | 8.7—9.8 | 17.0—20.0 |

* No load, in neutral or park.

MAF conversion table

| | | | | | | |
|----------------------------------|------|------|------|------|-------|--------|
| Voltage signal (V) | 0.34 | 0.39 | 0.60 | 1.00 | 1.96 | 3.90 |
| Mass intake airflow amount (g/s) | 0.82 | 0.88 | 1.25 | 3.44 | 14.48 | 135.95 |



CAMSHAFT POSITION SENSOR

Inspection

1. Remove the distributor. (Refer to section G.)
2. Disconnect the fuel injector connector.
3. Connect the distributor 4-pin connector.

Warning



- Turning the ignition switch to ON with the fuel injector connector still connected will actuate the fuel injector.
- Doing this procedure with the high-tension lead (ignition coil side) still connected will generate sparks and cause electrical shock. Disconnect the high-tension lead (ignition coil side) and avoid them from grounded to the vehicle body.

4. Connect the **SSTs** to the PCM. (Refer to page F2-150.)
5. Turn the ignition switch to ON.
6. Measure the voltage at PCM terminal 85.
7. Rotate the distributor drive by hand and check the output signal.

Specification

| PCM terminal | Signal | |
|--------------|--------|---------------------------|
| 85 | SGC | Approx. 5 V (1 pulse/rev) |

8. If not as specified, inspect the wiring harness and connector between the distributor and the PCM terminal.
9. If there is correct terminal voltage and harness continuity, replace the distributor. (Refer to section G.)



CRANKSHAFT POSITION SENSOR

Inspection

Resistance

1. Disconnect the crankshaft position sensor connector.
2. Measure the resistance between terminals A and B by using an ohmmeter.

Specification: 520—580 Ω [20°C {68°F}]


3. If not as specified, replace the crankshaft position sensor.

Air gap

1. Measure the air gap between the crankshaft pulley and the crankshaft position sensor by using a feeler gauge.

Specification: 0.5—1.5 mm {0.020—0.059 in}


2. If not as specified, replace the crankshaft pulley or the crankshaft position sensor.

**Replacement**

1. Disconnect the negative battery cable.
2. Remove the crankshaft position sensor.
3. Install in the reverse order of removal.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

**THROTTLE POSITION SENSOR****Inspection of resistance**


1. Disconnect the throttle position sensor connector.
2. Using an ohmmeter, measure the resistance between throttle position sensor terminals A and C.

Resistance: 4—6 kΩ

3. If not as specified, replace the throttle position sensor.
4. Reconnect the throttle position sensor connector.

Inspection of output voltage**Using the SST (104 Pin Breakout Box)**


1. Connect the **SST** to the PCM as shown.
2. Turn ignition switch to ON.
3. Measure voltage at PCM terminal 89 under the following conditions.

**Specification**

| Throttle valve condition | Terminal voltage (V) |
|--------------------------|----------------------|
| Closed throttle position | 0.3—0.7 |
| Wide open throttle | 3.4—5.3 |

(The voltage increase is linear according to the throttle valve opening angle)

4. Disconnect the **SST**.
5. If not as specified, adjust the throttle position sensor.



Using the SST (NGS)


1. Connect the **SSTs** to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS.
3. Select TPS on the **SST** display.
4. Measure the TPS output voltage under the following conditions.

Specification

| Throttle valve condition | TPS output voltage (V) |
|--------------------------|------------------------|
| Closed throttle position | 0.3—0.7 |
| Wide open throttle | 3.4—5.3 |

(The voltage increase is linear according to the throttle valve opening angle)

5. Disconnect the **SSTs**.
6. If not as specified, adjust the throttle position sensor.



Adjustment

Using the SST (104 Pin Breakout Box)

1. Verify that the throttle valve is fully closed.
2. Connect the **SST** to the PCM as shown.
3. Disconnect the throttle position sensor connector.
4. Turn the ignition switch to ON.
5. Using a voltmeter, measure the voltage at connector side terminal A.

Specification: 4.5—5.5 V

6. Reconnect the throttle position sensor connector.
7. Loosen the sensor mounting screws.
8. Adjust the sensor output voltage by rotating the sensor.


Specification (Closed throttle position)

| Connector terminal A voltage (V) | PCM terminal 89 voltage (V) |
|----------------------------------|-----------------------------|
| 4.5—4.9 | 0.4—0.5 |
| 4.9—5.1 | 0.4—0.6 |
| 5.1—5.5 | 0.5—0.6 |

9. Tighten the sensor mounting screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—21 in·lbf}






10. Fully open the throttle valve and verify that the PCM terminal voltage are within the specification.

Specification (Wide open throttle)

| Connector terminal A voltage (V) | PCM terminal 89 voltage (V) |
|----------------------------------|-----------------------------|
| 4.5—4.7 | 3.5—4.4 |
| 4.7—4.8 | 3.6—4.5 |
| 4.8—4.9 | 3.7—4.6 |
| 4.9—5.0 | 3.7—4.8 |
| 5.0—5.1 | 3.8—4.9 |
| 5.1—5.3 | 4.0—5.0 |
| 5.3—5.4 | 4.1—5.1 |
| 5.4—5.5 | 4.2—5.2 |

11. Disconnect the **SST**.
12. If not as specified, replace the throttle position sensor.



Using the SST (NGS)

1. Verify that the throttle valve is closed throttle position.
2. Connect the **SSTs** to the data link connector-2.
3. Disconnect the throttle position sensor connector.
4. Turn the ignition switch to ON.
5. Using a voltmeter measure the voltage at connector side terminal A.

Specification: 4.5—5.5 V

6. Reconnect the throttle position sensor connector.
7. Loosen the sensor mounting screws.
8. Select the "PID/DATA MONITOR AND RECORD" function of NGS.
9. Select the TPS on the NGS.
10. Adjust the TPS output voltage by rotating the sensor.

Specification (Closed throttle position)

| Connector terminal A voltage (V) | TPS output voltage (V) |
|----------------------------------|------------------------|
| 4.5—4.9 | 0.4—0.5 |
| 4.9—5.1 | 0.4—0.6 |
| 5.1—5.5 | 0.5—0.6 |

11. Tighten the sensor mounting screws.

Tightening torque:


1.6—2.3 N·m {16—24 kgf·cm, 14—21 in·lbf}

- Wide open throttle and verify that the TPS terminal voltage are within the specification.

Specification (Wide open throttle)


| Connector terminal A voltage (V) | TPS output voltage (V) |
|----------------------------------|------------------------|
| 4.5—4.7 | 3.5—4.4 |
| 4.7—4.8 | 3.6—4.5 |
| 4.8—4.9 | 3.7—4.6 |
| 4.9—5.0 | 3.7—4.8 |
| 5.0—5.1 | 3.8—4.9 |
| 5.1—5.3 | 4.0—5.0 |
| 5.3—5.4 | 4.1—5.1 |
| 5.4—5.5 | 4.2—5.2 |

- Disconnect the **SSTs**.
- If not as specified, replace the throttle position sensor.



Replacement

- Disconnect the air hose. (Refer to page F3-102.)
- Disconnect the throttle position sensor connector.
- Remove the screws.
- Remove the throttle position sensor.
- Install the throttle position sensor.
- Adjust the throttle position sensor output voltage. (Refer to page F3-159.)
- Connect the air hose.




ENGINE COOLANT TEMPERATURE SENSOR

Removal

Note

- The engine coolant temperature sensor is at the rear of the engine.

- Disconnect the engine coolant temperature sensor connector.
- Remove the engine coolant temperature sensor.




Inspection

- Place the sensor in water with a thermometer and heat the water gradually.
- Measure the resistance of the sensor.

| Water temperature | Resistance (k Ω) |
|-------------------|--------------------------|
| 20°C { 68°F } | 35.4—39.3 |
| 60°C { 140°F } | 7.1—8.0 |

- If not as specified, replace the engine coolant temperature sensor.


**Installation**

1. Install a new washer and the engine coolant temperature sensor.

Tightening torque:

15.7—23.5 N·m {1.6—2.4 kgf·m, 11.6—17.3 ft·lbf}


2. Connect the engine coolant temperature sensor connector.
3. Start the engine and check for coolant leakage.

**INTAKE AIR TEMPERATURE SENSOR****Inspection**

1. Disconnect the intake air temperature sensor connector.
2. Check the resistance of the sensor.

| Temperature | Resistance |
|--------------|--------------|
| 20°C {68°F} | 35.4—39.3 kΩ |
| 60°C {140°F} | 7.1—8.0 kΩ |


3. If not as specified, replace the intake air temperature sensor.

**Replacement**

1. Disconnect the intake air temperature sensor connector.
2. Remove the sensor.
3. Install the sensor and tighten it to the specified torque.

Tightening torque:

10.8—16.27 N·m {1.1—1.6 kgf·m, 8.0—11.5 ft·lbf}


**HEATED OXYGEN SENSOR****Inspection****Sensor****Using the SST (104 Pin Breakout Box)**

1. Warm up the engine to normal operating temperature.
2. Connect the **SST** to the PCM. (Refer to page F3-150.)
3. Measure the voltage at PCM terminals 35 and 60.

Spcification

| Engine condition | PCM terminal 35 | PCM terminal 60 |
|------------------|-----------------|-----------------|
| Idle | 0—1.0 V | 0—1.0 V |
| Deceleration | 0—1.0 V | 0—0.1 V |
| Acceleration | 0—1.0 V | 0—1.0 V |

4. If not as specified, inspect the following.
 - Fuel system
 - On-board diagnostic system (Refer to page F3-14.)
 - Intake-air system
5. If all the systems are OK, replace the heated oxygen sensor. (Refer to page F3-127.)




Using the SST (NGS)

1. Connect the **SSTs** to the data link connector-2.
(Refer to page F3-151.)
2. Select the "PID/DATA MONITOR AND RECORD" function of the NGS.
3. Select the heated oxygen sensor (front), (rear) on the NGS. The NGS measures and shows the voltage.

Specification

| Engine condition | Voltage Heated oxygen sensor (front) | Voltage Heated oxygen sensor (rear) |
|------------------|--------------------------------------|-------------------------------------|
| Idle | 0—1.0 V | 0—1.0 V |
| Deceleration | 0—0.5 V | 0—1.0 V |
| Acceleration | 0.5—1.0 V | 0—1.0 V |

4. If not as specified, inspect the following.
 - Fuel system
 - On-board diagnostic system (Refer to page F3-14.)
 - Intake-air system
5. If all the systems are OK, replace the heated oxygen sensor. (Refer to page F3-127.)




Heater

1. Disconnect the heated oxygen sensor connector.
2. Measure the resistance between heated oxygen sensor terminals C and D by using an ohmmeter.

Specification: Approx. 6 Ω [20°C {68°F}]

3. If not as specified, replace the heated oxygen sensor. (Refer to page F3-127.)



EGR VALVE POSITION SENSOR


Inspection of output voltage

Using the SST (104 Pin Breakout Box)

1. Connect the **SST** to the PCM as shown and connect a vacuum pump to the EGR valve.
2. Turn the ignition switch to ON.
3. Measure the voltage at the terminals as shown in the table.

| Terminal | PCM | Vacuum | |
|----------|-----|---------------------------|-----------------------------------|
| | | 0 kPa {0 mmHg, 0 inHg} | 20.0 kPa {150 mmHg, 5.90 inHg} |
| B | 90 | 4.5—5.5 V | |
| A | 91 | 0 V | |
| C | 65 | Approx. 0.8 V | Approx. 4.9 V |

4. If not correct at 65 terminal, check the wiring harness and 90 terminal of the PCM.



Using the SST (NGS)

1. Connect the **SSTs** (NGS) to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS and connect a vacuum pump.
3. Select EGR valve position sensor on the NGS. The NGS measures and shown in the specification.


Specification

| Vacuum | EGR valve position signal voltage |
|--------------------------------|-----------------------------------|
| 0 kPa {0 mmHg, 0 inHg} | Approx. 0.8 V |
| 20.0 kPa {150 mmHg, 5.90 inHg} | Approx. 4.9 V |

4. If not correct EGR valve position signal voltage, check the wiring harness and 90 terminal of the PCM.


Inspection of resistance

1. Disconnect the EGR valve position sensor connector, and connect an ohmmeter.
2. Disconnect the vacuum hose from the EGR valve, and connect a vacuum pump.
3. Measure the resistance between the terminals as shown while vacuum is applied.



| Terminal | Vacuum | |
|----------|------------------------|--------------------------------|
| | 0 kPa {0 mmHg, 0 inHg} | 20.0 kPa {150 mmHg, 5.90 inHg} |
| A—B | Approx. 2.7 kΩ | |
| A—C | Approx. 0.5 kΩ | Approx. 2.7 kΩ |
| B—C | Approx. 2.4 kΩ | Approx. 0.1 kΩ |

4. If not as specified, replace the EGR valve.



EGR BOOST SENSOR

Inspection

Using the SST (104 Pin Breakout Box)

1. Connect the **SST** to the PCM as shown.
2. Apply vacuum or pressure to the EGR boost sensor by using a vacuum pump. Measure the PCM terminal 34.


Specification


| | |
|---------------------------------|---------------|
| 15 kPa {112.5 mmHg, 4.4 inHg} | 0.270—0.330 V |
| 40 kPa {300 mmHg, 11.8 inHg} | 1.395—1.705 V |
| 95 kPa {712.5 mmHg, 28.1 inHg} | 3.870—4.730 V |
| 105 kPa {787.5 mmHg, 31.0 inHg} | 4.320—5.280 V |

3. If not as specified, replace the EGR boost sensor.

Using the SST (NGS)

1. Connect the **SSTs** to the data link connector-2.
2. Select the "PID/DATA MONITOR AND RECORD" function of NGS and connect a vacuum pump.
3. Select the EGR boost sensor on the NGS. The NGS measures and shows the voltage.






Specification

- 15 kPa {112.5 mmHg, 4.4 inHg}: 0.270—0.330 V
- 40 kPa {300 mmHg, 11.8 inHg}: 1.395—1.705 V
- 95 kPa {712.5 mmHg, 28.1 inHg}: 3.870—4.730 V
- 105 kPa {787.5 mmHg, 31.0 inHg}: 4.320—5.280 V

4. If not as specified, replace the EGR boost sensor.




P/S PRESSURE SWITCH

Inspection

1. Disconnect the P/S pressure switch connector.
2. Connect an ohmmeter to the sensor.
3. Start the engine and run it at idle. Check continuity of the sensor while turning the steering wheel.

| Steering wheel | Continuity |
|----------------|------------|
| Turning | Yes |
| Not turning | No |

4. If not as specified, replace the P/S pressure switch.




Replacement

Replace the P/S pressure switch as shown in the figure.

Tightening torque:

17—22 N·m {1.7—2.3 kgf·m, 13—16 ft·lbf}



MAIN RELAY

Inspection

1. Verify that the main relay clicks when the ignition switch is turned ON and OFF.
2. Apply battery positive voltage (B+) to terminal E and ground terminal A of the relay.
3. Check continuity of the relay as shown.

B+: Battery positive voltage

| Terminals | B+ not applied | B+ applied |
|-----------|----------------|------------|
| B—F | No continuity | Continuity |

4. If not as specified, replace the main relay.


TROUBLESHOOTING GUIDE

USING THIS SECTION

Introduction

Most of the fuel and emission control systems are electronically controlled, often making it difficult to diagnose problems, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially the intermittent ones. Through a talk with the customer, you will usually find out what the symptoms are and under what conditions they occur.

Work flow



Diagnostic index

No.: Each troubleshooting item is assigned a number.

Troubleshooting Item: There are 30 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

| TROUBLESHOOTING GUIDE | | | F3 |
|-----------------------|---------|-------------|------|
| DIAGNOSTIC INDEX | | | |
| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
| No. | TROUBLE | | |
| | | | |

Description: Describes each troubleshooting item.

Page: Shows the reference page or section

Troubleshooting chart

| | | | |
|--|---|-----|---|
| 13, 14 | ENGINE STALLS | | <ul style="list-style-type: none"> • IDLE WITH A/C, P/S, and/or E/L ON • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES |
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle • Engine stops unexpectedly when shifted from N or P to other ranges at idle • Idle condition is normal when A/C, P/S, and E/L are OFF and in N and P | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Monitor switch functions (SST)</p> <ul style="list-style-type: none"> • A/C switch • Headlight switch • Rear window defroster <ul style="list-style-type: none"> • Blower switch ② Solenoid valve (ISC) • Solenoid valve stuck | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are switches correct when checked by using Self-Diagnosis Checker monitor lamp while ignition switch ON? ⇨ page F2-44 <ul style="list-style-type: none"> • Blower switch • Headlight switch • Rear window defroster switch • Selector lever | Yes | Go to next step |
| | | No | Lamp not ON/OFF with specified switch Check for cause (Refer to specified check sequence) ⇨ page F2-45 |
| 2 | Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? ⇨ page F2-18 | Yes | "00" displayed Go to next step |
| | | No | Service Code No. displayed Check for cause (Refer to specified check sequence) ⇨ page F2-20 "88" flashes "No.38 SELF-DIAGNOSIS CS "88" |

DESCRIPTION:

Further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes and inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "⇨" mark.

ACTION:




This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page specified by the "⇨" mark.

DIAGNOSTIC INDEX

| TROUBLESHOOTING ITEM | | | DESCRIPTION | PAGE |
|----------------------|--|----------------------------------|---|------------|
| No. | TROUBLE | | | |
| 1 | Melts main or other fuse | | — | F3-171 |
| 2 | Will not crank | | Starter does not work | F3-172 |
| 3 | Hard start/long crank/erratic start/erratic crank | | Starter cranks engine at normal speed but engine requires excessive cranking time before starting | F3-173 |
| 4 | Engine stalls | After start At idle | Engine stops unexpectedly at idle and/or after start | F3-175 |
| 5 | Crank normally but will not start | | Starter cranks engine at normal speed but engine will not run | F3-177 |
| 6 | Slow return to idle | | Engine takes more time than normal to return to idle speed | F3-179 |
| 7 | Engine runs rough/rolling idle | At idle | Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake Idle speed too slow and excessive engine shake | F3-180 |
| 8 | Fast idle/runs on | | Engine speed continues at fast idle after warm-up Engine runs after ignition switch is turned off | F3-182 |
| 9 | Low idle/stalls during deceleration | | Engine stops unexpectedly at beginning of deceleration or recovery from deceleration | F3-182 |
| 10 | Engine stalls/quits | Acceleration/cruise | Engine stops unexpectedly at beginning of acceleration or during acceleration Engine stops unexpectedly while cruising | F3-183 |
| | Engine runs | Acceleration/cruise | Engine speed fluctuates during acceleration or cruising | F3-183 |
| | Misses | Acceleration/cruise | Engine misses during acceleration or cruising | F3-183 |
| | Buck/jerk | Acceleration/cruise deceleration | Vehicle bucks/jerks during acceleration, cruising, or deceleration | F3-183 |
| | Hesitation/stumble | Acceleration | Momentary pause at beginning of acceleration, or during acceleration | F3-183 |
| 11 | Surges | Acceleration/cruise | Momentary minor irregularity in engine output | F3-186 |
| 12 | Backfires | Idle/acceleration/deceleration | Sound produced from exhaust system | F3-188 |
| 13 | Lack/loss of power | Acceleration/cruise | Performance poor under load (i.e., power down when climbing hills) | F3-189 |
| 14 | Knocking/pinging | Acceleration/cruise | Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | F3-191 |
| 15 | Poor fuel economy | | Fuel economy unsatisfactory | F3-192 |
| 16 | Emissions compliance | | Fails emissions test | F3-194 |
| 17 | MIL never on | | Malfunction indicator lamp never on | F3-196 |
| 18 | Automatic transaxle concerns | Upshift/downshift/engagement | Automatic transmission concerns not related to engine performance | section K2 |
| 19 | High oil consumption/leaks | | Oil consumption excessive | F3-197 |
| 20 | Cooling system concerns | Overheating | Engine runs at higher than normal temperature/overheats | F3-197 |
| 21 | Cooling system concerns | Runs cold | Engine does not reach normal operating temperature | F3-197 |
| 22 | Exhaust smoke | | Blue, black, or white smoke from exhaust system | F3-198 |
| 23 | Fuel odor (in engine compartment) | | Gasoline fuel smell or visible leaks | F3-199 |
| 24 | Engine noise | | Engine noise from under hood | F3-200 |
| 25 | Vibration concerns (engine) | | Vibration from under hood or driveline | F3-201 |
| 26 | A/C does not work | | A/C compressor magnetic clutch does not engage when A/C is turned on | F3-201 |
| 27 | A/C always on/ A/C compressor runs continuously | | A/C compressor magnetic clutch does not disengage | F3-202 |
| 28 | A/C does not cut off under wide open throttle conditions | | A/C compressor magnetic clutch does not disengage under wide open throttle | F3-202 |
| 29 | Exhaust sulphur smell | | Rotten egg smell (sulphur) from exhaust | F3-203 |
| 30 | Intermittent concerns | | Symptom occurs randomly and is difficult to diagnose | F3-204 |

Description of Drivability Problems

- STUMBLE** : Mildly irregular performance during acceleration.
HESITATION : A dip or flat spot in performance just after the accelerator pedal is depressed.
SURGE : Continuous irregular performance during cruising.



Fuel Pressure Release and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".


Fuel Line Safety Procedures

1. Release the fuel pressure before disconnecting a fuel line.
 - (1) Start the engine.
 - (2) Remove the fuel pump relay.
 - (3) After the engine stalls, turn the ignition switch to OFF.
 - (4) Install the fuel pump relay.
2. Avoid leakage.
 - (1) When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
 - (2) Plug the hose after removal.
3. Install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose.



SYMPTOM TROUBLESHOOTING

| | | |
|---|--------------------------|---|
| 1 | MELTS MAIN OR OTHER FUSE | — |
|---|--------------------------|---|


[TROUBLESHOOTING HINTS]
Check the condition of the fuse




















| Damaged Fuse | Related Wiring Harness | |
|---------------|------------------------|---|
| MAIN (100A) | Main fuse | Generator |
| BTN (60A) | BTN fuse | ROOM fuse |
| ROOM (15A) | ROOM fuse | PCM terminal |
| EGI INJ (30A) | Main relay | <ul style="list-style-type: none"> — Fuel injectors — PCM terminal — Ignition coil — PRC solenoid valve — EGR solenoid valve (vacuum and vent) — Idle air control valve — Purge solenoid valve — Mass air flow sensor |
| ENGINE (15A) | ENGINE fuse | Main relay Fuel pump relay |
| METER (15A) | METER fuse | Transaxle range switch |
| WIPER (20A) | WIPER fuse | Heated oxygen sensor |








| 2 | | WILL NOT CRANK | |
|-------------------------------------|---|----------------|--|
| DESCRIPTION • Starter does not work | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is a clicking sound heard from the starter relay when the ignition switch is turned to START? | Yes | Go to next step |
| | | No | Go to Step 3 |
| 2 | Check the starting system  section G Is the starting system OK? | Yes | Check for seized/hydrolocked engine, flywheel (Refer to section B1) |
| | | No | Service as required (Refer to section G) |
| 3 | Do any other electrical accessories work? | Yes | Go to next Step |
| | | No | Check the charging system (Refer to section G) |
| 4 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 5 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |






| 3 | | | HARD START/LONG CRANK/ERRATIC START/ERRATIC CRANK | |
|-------------|--|-----|---|--|
| DESCRIPTION | <ul style="list-style-type: none"> Starter cranks engine at normal speed but engine requires excessive cranking time before start Battery in normal condition | | | |
| STEP | INSPECTION | | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? 🔧 page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step | |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause (Refer to related chart) | |
| 2 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Is fuel line pressure correct with ignition switch ON? 🔧 page F3-111 Fuel line pressure: 260—310 kPa {2.6—3.2 kgf/cm², 37—46 psi} | Yes | Go to next Step | |
| | | No | Zero or low: <ul style="list-style-type: none"> Check fuel pump circuit 🔧 page F3-117 Check pressure regulator diaphragm High: <ul style="list-style-type: none"> Check pressure regulator for high pressure cause 🔧 page F3-117 Check for clogged fuel return line | |
| 3 | Is fuel line pressure held after ignition switch is turned off? 🔧 page F3-111 Fuel line pressure: More than 150 kPa {1.5 kgf/cm², 21 psi} for 5 min. | Yes | Go to next Step | |
| | | No | Check pressure regulator diaphragm condition If condition is OK, check fuel injector 🔧 page F3-119 If condition is not OK, replace pressure regulator | |
| 4 | Disconnect the vacuum hose from the pressure regulator and plug hose. Start the engine Does the fuel line pressure remain within ± 20 kPa {0.21 kgf/cm ² , 3 psi} while driving vehicle? | Yes | Go to next Step | |
| | | No | Check for clogged fuel filter 🔧 page F3-113 | |
| 5 | Connect the vacuum hose to the pressure regulator. Install a vacuum gauge to the intake manifold. Start the engine. Does fuel pressure gauge reading increase as the vacuum gauge reading decreases and/or does fuel pressure gauge reading decrease as the vacuum gauge reading increases? | Yes | Go to next Step | |
| | | No | Connect vacuum pump to pressure regulator. Start the engine. Check that fuel pressure reading changed as vacuum changes <ul style="list-style-type: none"> If changes, check vacuum line If no change, replace pressure regulator | |
| 6 | Is idle speed correct? 🔧 page F3-11 | Yes | Go to next Step | |
| | | No | Adjust idle speed 🔧 page F3-11 | |
| 7 | Is there a restriction in the exhaust system? | Yes | Check exhaust system 🔧 page F3-127 | |
| | | No | Go to next Step | |
| 8 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step | |
| | | No | Replace PCV valve | |
| 9 | Check for contaminated mass air flow sensor. Is there any contamination? | Yes | Replace the mass air flow sensor | |
| | | No | Go to next Step | |
| 10 | Disconnect vacuum hose from EGR valve and plug it. Does condition improve? | Yes | Check as follows: <ul style="list-style-type: none"> EGR solenoid valve (vacuum) for sticking Condition of EGR solenoid valve (vacuum) connector female terminal(s) | |
| | | No | Check if EGR valve moves smoothly <ul style="list-style-type: none"> If yes, Go to next Step If no, replace EGR valve | |



| STEP | INSPECTION | ACTION |
|------|--|--|
| 11 | Check starting system Is starting system normal?  section G | Yes Verify test results If OK, return to diagnostic index to service any additional symptoms |
| | | No Repair or replace components as required |


| 4 | ENGINE STALLS | | <ul style="list-style-type: none"> • AFTER START • AT IDLE |
|-------------|---|-----|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stops unexpectedly at idle and/or after start | | |
| STEP | INSPECTION | | ACTION |
| 1 | Does the vehicle stall at idle in park/neutral with all accessories off? | Yes | Go to Step 3 |
| | | No | Go to next Step |
| 2 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and/or Key On Engine Running inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to Step 4 |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 3 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to Step 10 |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 4 | Attempt to start engine at part throttle Will engine run smooth at part throttle? | Yes | Check idle air control valve and wiring harness  page F3-108 |
| | | No | Go to next Step |
| 5 | Disconnect vacuum hose from EGR valve and plug it Is drive symptom eliminated? | Yes | Check EGR vent on vacuum hose to EGR valve for obstruction or leak <ul style="list-style-type: none"> • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum line |
| | | No | Go to next Step |
| 6 | Does EGR valve seat properly (fully closed)? | Yes | Go to next Step |
| | | No | Check as follows: <ul style="list-style-type: none"> • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 7 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Is fuel line pressure correct when the ignition switch is cycled ON and OFF?  page F3-111 Fuel line pressure: 260—310 kPa {2.6—3.2 kgf/cm ² , 37—46 psi} | Yes | Go to next Step |
| | | No | Zero or low: <ul style="list-style-type: none"> • Check fuel pump circuit  page F3-117 • Check pressure regulator diaphragm High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause  page F3-117 • Check for clogged fuel return line |
| 8 | Visually look for fuel leakage at fuel injector O-ring, pressure regulator, and fuel line. Service as necessary. Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel pressure remain at specification for 60 seconds?  page F3-111 | Yes | Go to next Step |
| | | No | Check pressure regulator diaphragm condition <ul style="list-style-type: none"> • If condition is OK, check fuel injector  page F3-119 • If condition is not OK, replace pressure regulator |

| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| 9 | Is strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | <ul style="list-style-type: none"> If symptom occurs during parking maneuvers, Go to next Step If symptom occurs during A/C ON, go to Step 11 |
| | | No | Check as follows:  section G <ul style="list-style-type: none"> Distributor cap and rotor High-tension lead(s) Ignition coil |
| 10 | Disconnect the power steering pressure switch Does rpm increase? | Yes | Replace power steering pressure switch |
| | | No | Check for short circuit in wiring harness from power steering pressure switch to PCM |
| 11 | Is there correct voltage at terminal 41 of PCM when the A/C is ON? Specification: Below 1.0 V | Yes | Go to next step  page F3-150 |
| | | No | Check for open circuit in wiring harness from A/C pressure switch to PCM |
| 12 | Is there a restriction in the exhaust system? | Yes | Check exhaust system  page F3-127 |
| | | No | Go to next Step |
| 13 | Is air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next Step |
| 14 | Are spark plugs OK?  section G  | Yes | Go to next Step |
| | | No | Clean or replace  section G |
| 15 | Is engine compression correct?  section B1 | Yes | Go to next Step |
| | | No | Check for cause  section B1 |
| 16 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 5 | CRANKS NORMALLY BUT WILL NOT START | | |
|-------------|---|-----------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Starter cranks engine at normal speed but engine will not run • Refer to "ENGINE STALLS" if this symptom appears after engine stall • Fuel in tank • Battery in normal condition | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection?  page F3-14 | Yes No | Yes Pass diagnostic trouble code displayed Go to next Step No Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Disconnect the throttle position sensor connector Is there correct voltage at terminal of the throttle position sensor connector terminal a (A) with the ignition switch ON? Specification: 4.5—5.5 V | Yes No | Yes Go to next Step No Check voltage at PCM terminals 55, 71, 90, and 97 |
| 3 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes No | Yes Go to Step 5 No Go to next Step |
| 4 | Is a strong blue spark visible at disconnected center high-tension lead from coil while cranking engine?  | Yes No | Yes Check as follows: <ul style="list-style-type: none"> • Ignition control module  section G • Distributor cap • Rotor • High-tension leads No Check the spark output signal and crankshaft position sensor signal at PCM  page F3-150 <ul style="list-style-type: none"> • If OK, go to Step 11 • If not OK, check wiring harness |
| 5 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Is fuel line pressure correct when the ignition switch is cycled ON and OFF 5 times? Fuel line pressure: 260—310 kPa {2.6—3.2 kgf/cm², 37—46 psi} | Yes No | Yes Go to next Step No Check fuel pump  page F3-114 |
| 6 | Visually look for fuel leakage at fuel injector O-ring, pressure regulator, and fuel line. Service as necessary. Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel pressure remain at specification for 60 seconds? | Yes No | Yes Go to next Step No Check pressure regulator diaphragm condition <ul style="list-style-type: none"> • If condition is OK, check fuel injector  page F3-119 • If condition is not OK, replace pressure regulator |

| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 7 | Crank engine for 5 sec. Does pressure drop more than 34 kPa (0.35 kgf/cm ² , 5 psi) by the end of five second crank cycle? | Yes | Go to next Step |
| | | No | Check resistance of fuel injector(s) at PCM connector  page F3-121 <ul style="list-style-type: none"> • If resistance is OK, check as follows: <ul style="list-style-type: none"> • Fuel injector drive signal • Injection flow rate • PCM • If resistance is not OK, check as follows: <ul style="list-style-type: none"> • Open circuit in fuel injector circuit |
| 8 | Does engine start when throttle valve held quarter open? | Yes | Check idle air control valve and wiring harness  page F3-108 |
| | | No | Go to next Step |
| 9 | Disconnect vacuum hose from EGR valve and plug it Is drive symptom eliminated? | Yes | Check EGR vent or vacuum hose to EGR valve for obstruction or leak <ul style="list-style-type: none"> • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum line |
| | | No | Go to next Step |
| 10 | Does EGR valve seat properly (fully closed)? | Yes | Go to next Step |
| | | No | Check as follows: <ul style="list-style-type: none"> • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 11 | Is there a restriction in exhaust system? | Yes | Check exhaust system  page F3-127 |
| | | No | Go to next Step |
| 12 | Is engine compression correct?  section B1 | Yes | Go to next Step |
| | | No | Check for causes  section B1 |
| 13 | Verify test result. If OK, return to diagnostic index to service any additional symptoms | | |


| 6 | | SLOW RETURN TO IDLE | |
|-------------|---|--|--|
| DESCRIPTION | | • Engine takes more time than normal to return to idle speed | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Is the throttle body free of contamination?  page F3-103 | Yes | Go to next Step |
| | | No | Clean or replace the throttle body |
| 3 | Is air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next Step |
| 4 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |





| 7 | ENGINE RUNS ROUGH/ROLLING IDLE | • AT IDLE |
|--------------------|---|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake • Idle speed too slow and excessive engine shake | |
| STEP | INSPECTION | ACTION |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ↳ page F3-14 | Yes Pass diagnostic trouble code displayed Go to next Step |
| | | No Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Start the engine and disconnect the idle air control valve connector Does the rpm drop or does the engine stall? | Yes Go to next Step |
| | | No Check the idle air control valve and wiring harness ↳ page F3-108 |
| 3 | Disconnect the vacuum hose from the EGR valve and plug it Is the drive symptom eliminated? | Yes Check EGR vent or vacuum hose to EGR valve for obstruction or leak <ul style="list-style-type: none"> • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum line |
| | | No Go to next Step |
| 4 | Does EGR valve seat properly? | Yes Go to next Step |
| | | No Check as follows: <ul style="list-style-type: none"> • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 5 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? ↳ page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm ² , 30—37 psi} | Yes Go to next Step |
| | | No Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure ↳ page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause ↳ page F3-117 <ul style="list-style-type: none"> • Check for clogged fuel return line |
| 6 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON? ↳ page F3-118 | Yes Go to next Step |
| | | No Check pressure regulator diaphragm |
| 7 | Run engine at 2000 rpm for two minutes Are there any diagnostic trouble codes? ↳ page F3-14 | Yes Check heated oxygen sensor harness ↳ page F3-163 |
| | | No Check heated oxygen sensor heater harness Go to next Step ↳ page F3-164 |
| 8 | Are spark plugs OK? ↳ section G  | Yes Go to next Step |
| | | No Clean or replace ↳ section G |











| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 9 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step |
| | | No | Replace PCV valve |
| 10 | Start the engine and bring to normal operating temperature. Disconnect hose from remote air cleaner. Place a stiff piece of paper over the hose end Does vacuum hold the paper? | Yes | Go to next Step |
| | | No | Check fuel evaporative system as follows: Disconnect evaporative hose and place a stiff piece of paper over hose Does vacuum hold paper? ➤ page F3-3 <ul style="list-style-type: none"> • If yes, malfunction of fuel evaporative system • If no, check for vacuum leak in PCV system, oil cap, PCV valve, rocker cover for bolt torque/gasket leak |
| 11 | Remove a plug line to charcoal canister. Remove gas cap and install a vacuum pump/gauge gas cap. Apply air pressure Air pressure: 20—27 kPa {0.21—0.28 kgf/cm², 3—4 psi} Is either a vacuum or fuel leak detected? | Yes | Repair or replace |
| | | No | Go to next Step |
| 12 | Check for blockage/restrictions or opens (hoses) between engine vacuum port and charcoal canister. Check for blockage in fuel tank vent system Is a fault detected? | Yes | Replace vacuum hose |
| | | No | Go to next Step |
| 13 | Check purge solenoid valve Is the solenoid valve operating properly? ➤ page F3-137 | Yes | Go to next Step |
| | | No | Repair or replace |
| 14 | Is there a restriction in the exhaust system? | Yes | Check exhaust system ➤ page F3-127 |
| | | No | Go to next Step |
| 15 | Is there air leakage at intake air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next Step |
| 16 | Is engine compression correct? ➤ section B1 | Yes | Go to next Step |
| | | No | Check for cause ➤ section B1 |
| 17 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |


| 8 | | FAST IDLE/RUNS ON | |
|--------------------|---|--|--|
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine speed continues at fast idle after warm-up • Engine runs after ignition switch is turned off | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ↳ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Is there air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes | Repair or replace parts as necessary |
| | | No | Go to next Step |
| 3 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |


| 9 | | LOW IDLE/STALLS DURING DECELERATION | |
|--------------------|--|--|--|
| DESCRIPTION | | • Engine stops unexpectedly at beginning of deceleration or recovery from deceleration | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ↳ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Does idle speed drop in the following conditions? Condition <ul style="list-style-type: none"> • Air conditioner ON | Yes | Check as follows: <ul style="list-style-type: none"> • Circuit from idle air control valve to PCM for open and short ↳ page F3-150 • Idle air control valve for sticking ↳ page F3-107 If OK go to next step |
| | | No | Adjust idle speed ↳ page F3-11 |
| 3 | Check the following: <ul style="list-style-type: none"> • EGR valve • EGR solenoid valve (vacuum) Are any of the components faulty? | Yes | Repair or replace |
| | | No | Go to next Step |
| 4 | Are the following terminals and connections good? <ul style="list-style-type: none"> • Distributor connector • Ignition coil connector • Fuel pump connector • Main relay • PCM connector | Yes | Verify test results. If OK, return to diagnostic index to service any additional symptoms |
| | | No | Repair connector terminal |


| | | | | | | |
|-------------|--|---|-----|---|----|--|
| 10 | ENGINE STALLS/QUITS ENGINE RUNS ROUGH MISSES BUCK/JERK HESITATION/STUMBLE | <ul style="list-style-type: none"> • ACCELERATION/CRUISE • ACCELERATION/CRUISE • ACCELERATION/CRUISE • ACCELERATION/CRUISE/DECELERATION • ACCELERATION | | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stops unexpectedly at beginning of acceleration or during acceleration • Engine stops unexpectedly while cruising • Engine speed fluctuates during acceleration or cruising • Engine misses during acceleration or cruising • Vehicle bucks/jerks during acceleration, cruising, or deceleration • Momentary pause at beginning of acceleration or during acceleration | | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ↳ page F3-14 | <table border="0"> <tr> <td data-bbox="824 506 889 573">Yes</td> <td data-bbox="889 506 1511 573"> Pass diagnostic trouble code displayed Go to next Step </td> </tr> <tr> <td data-bbox="824 573 889 663">No</td> <td data-bbox="889 573 1511 663"> Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause </td> </tr> </table> | Yes | Pass diagnostic trouble code displayed Go to next Step | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| Yes | Pass diagnostic trouble code displayed Go to next Step | | | | | |
| No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause | | | | | |
| 2 | Disconnect vacuum line at EGR valve and plug it Is drive symptom eliminated? | <table border="0"> <tr> <td data-bbox="824 663 889 730">Yes</td> <td data-bbox="889 663 1511 730"> Check as follows: <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) for sticking </td> </tr> <tr> <td data-bbox="824 730 889 793">No</td> <td data-bbox="889 730 1511 793">Go to next Step</td> </tr> </table> | Yes | Check as follows: <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) for sticking | No | Go to next Step |
| Yes | Check as follows: <ul style="list-style-type: none"> • EGR solenoid valve (vacuum) for sticking | | | | | |
| No | Go to next Step | | | | | |
| 3 | Does EGR valve seat properly (fully closed)? | <table border="0"> <tr> <td data-bbox="824 793 889 856">Yes</td> <td data-bbox="889 793 1511 856">Go to next Step</td> </tr> <tr> <td data-bbox="824 856 889 999">No</td> <td data-bbox="889 856 1511 999"> Check as follows: <ul style="list-style-type: none"> • EGR valve operation • EGR valve contamination • EGR solenoid valve (vacuum) • Pressure/vacuum signal hose leak </td> </tr> </table> | Yes | Go to next Step | No | Check as follows: <ul style="list-style-type: none"> • EGR valve operation • EGR valve contamination • EGR solenoid valve (vacuum) • Pressure/vacuum signal hose leak |
| Yes | Go to next Step | | | | | |
| No | Check as follows: <ul style="list-style-type: none"> • EGR valve operation • EGR valve contamination • EGR solenoid valve (vacuum) • Pressure/vacuum signal hose leak | | | | | |
| 4 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? ↳ page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm ² , 30—37 psi} | <table border="0"> <tr> <td data-bbox="824 999 889 1062">Yes</td> <td data-bbox="889 999 1511 1062">Go to next Step</td> </tr> <tr> <td data-bbox="824 1062 889 1255">No</td> <td data-bbox="889 1062 1511 1255"> Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure ↳ page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause ↳ page F3-117 • Check for clogged fuel return line </td> </tr> </table> | Yes | Go to next Step | No | Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure ↳ page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause ↳ page F3-117 • Check for clogged fuel return line |
| Yes | Go to next Step | | | | | |
| No | Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure ↳ page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause ↳ page F3-117 • Check for clogged fuel return line | | | | | |
| 5 | Does fuel pressure remain at specification for 60 seconds? | <table border="0"> <tr> <td data-bbox="824 1255 889 1318">Yes</td> <td data-bbox="889 1255 1511 1318">Go to next Step</td> </tr> <tr> <td data-bbox="824 1318 889 1409">No</td> <td data-bbox="889 1318 1511 1409"> Check pressure regulator diaphragm <ul style="list-style-type: none"> • If condition is OK, check fuel injector ↳ page F3-119 • If condition is not OK, replace pressure regulator </td> </tr> </table> | Yes | Go to next Step | No | Check pressure regulator diaphragm <ul style="list-style-type: none"> • If condition is OK, check fuel injector ↳ page F3-119 • If condition is not OK, replace pressure regulator |
| Yes | Go to next Step | | | | | |
| No | Check pressure regulator diaphragm <ul style="list-style-type: none"> • If condition is OK, check fuel injector ↳ page F3-119 • If condition is not OK, replace pressure regulator | | | | | |
| 6 | Run engine at 2000 rpm for two minutes Are diagnostic trouble codes present? | <table border="0"> <tr> <td data-bbox="824 1409 889 1472">Yes</td> <td data-bbox="889 1409 1511 1472">Check heated oxygen sensor wiring harness</td> </tr> <tr> <td data-bbox="824 1472 889 1566">No</td> <td data-bbox="889 1472 1511 1566"> Check heated oxygen sensor heater ↳ page F3-164 If OK, go to next Step </td> </tr> </table> | Yes | Check heated oxygen sensor wiring harness | No | Check heated oxygen sensor heater ↳ page F3-164 If OK, go to next Step |
| Yes | Check heated oxygen sensor wiring harness | | | | | |
| No | Check heated oxygen sensor heater ↳ page F3-164 If OK, go to next Step | | | | | |
| 7 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | <table border="0"> <tr> <td data-bbox="824 1566 889 1713">Yes</td> <td data-bbox="889 1566 1511 1713"> Check spark plugs ↳ section G <ul style="list-style-type: none"> • If OK, go to next Step • If not OK, clean or replace spark plug </td> </tr> <tr> <td data-bbox="824 1713 889 1902">No</td> <td data-bbox="889 1713 1511 1902"> Check as follows: ↳ section G <ul style="list-style-type: none"> • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals </td> </tr> </table> | Yes | Check spark plugs ↳ section G <ul style="list-style-type: none"> • If OK, go to next Step • If not OK, clean or replace spark plug | No | Check as follows: ↳ section G <ul style="list-style-type: none"> • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals |
| Yes | Check spark plugs ↳ section G <ul style="list-style-type: none"> • If OK, go to next Step • If not OK, clean or replace spark plug | | | | | |
| No | Check as follows: ↳ section G <ul style="list-style-type: none"> • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals | | | | | |


| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 8 | Check that throttle lever is resting on throttle valve stop screw and/or throttle valve orifice plug Are any faults present? | Yes | Adjust as necessary |
| | | No | Go to next Step |
| 9 | Is there air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes | Repair or replace parts as necessary |
| | | No | Go to next Step |
| 10 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step |
| | | No | Replace PCV valve |
| 11 | Start the engine and bring to normal operating temperature. Disconnect hose from remote air cleaner. Place a stiff piece of paper over the hose end Does vacuum hold the paper? | Yes | Go to next Step |
| | | No | Check fuel evaporative system as follows: Disconnect evaporative hose and place a stiff piece of paper over hose Does vacuum hold paper? <ul style="list-style-type: none"> If yes, malfunction of fuel evaporative system  page F3-134 If no, check for vacuum leak in PCV system, oil cap, PCV valve, rocker cover for bolt torque/gasket leak |
| 12 | Is there a restriction in the exhaust system? | Yes | Check exhaust system  page F3-127 |
| | | No | Go to next Step |
| 13 | Remove a plug line to canister. Remove gas cap and install vacuum pump/gauge gas cap. Apply air pressure Air pressure: 20—27 kPa {0.21—0.28 kgf/cm², 3—4 psi} Is either a vacuum or fuel leak detected? | Yes | Repair or replace |
| | | No | Go to next Step |
| 14 | Check for blockage/restrictions or opens (hoses) between engine vacuum port and charcoal canister. Check for blockage in fuel tank vent system Is a fault detected? | Yes | Replace vacuum hose |
| | | No | Go to next Step |
| 15 | Check purge solenoid valve Is the solenoid valve operating properly?  page F3-137 | Yes | Go to next Step |
| | | No | Replace the purge solenoid valve |
| 16 | Measure resistance of the heated oxygen sensor heater Is the resistance within specification? Resistance: Approx. 6 Ω (at 20°C {68°F}) | Yes | Go to next Step |
| | | No | Replace heated oxygen sensor |
| 17 | Measure voltage of heated oxygen sensor heater Is voltage more than 10.5 V? | Yes | Go to section B1 If engine OK, go to next Step |
| | | No | Check heated oxygen sensor heater circuit  page F3-164 |
| 18 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 11 | SURGES | • ACCELERATION/CRUISE | |
|-------------|---|---|--|
| DESCRIPTION | | • Momentary minor irregularity in engine output | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Disconnect the vacuum hose from the EGR valve and plug it Is the drive symptom eliminated? | Yes | Check EGR vent on vacuum hose to EGR valve for obstruction or leak <ul style="list-style-type: none"> • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum line |
| | | No | Go to next Step |
| 3 | Does EGR valve seat properly? | Yes | Go to next Step |
| | | No | Check as follows: <ul style="list-style-type: none"> • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 4 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle?  page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kg/cm ² , 30—37 psi} | Yes | Go to next Step |
| | | No | Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure  page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause  page F3-117 • Check for clogged fuel return line |
| 5 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON?  page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator for high pressure cause  page F3-117 |
| 6 | Run engine at 2000 rpm for two minutes Are there any diagnostic trouble codes?  page F3-14 | Yes | Check heated oxygen sensor wiring harness |
| | | No | Check heated oxygen sensor heater harness Go to next step  page F3-164 |
| 7 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plug(s) for damage <ul style="list-style-type: none"> • If OK, go to next Step • If not OK, replace spark plug(s) |
| | | No | Check as follows: <ul style="list-style-type: none"> • Distributor cap and rotor for damage  section G |
| 8 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step |
| | | No | Replace PCV valve |
| 9 | Check charcoal canister for fuel saturation Is excess amount of liquid fuel present in canister? | Yes | Replace charcoal canister |
| | | No | Check fuel tank vent system Go to next Step |
















| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 10 | Is there a restriction in the exhaust system? | Yes | Check exhaust system  page F3-127 |
| | | No | Go to next Step |
| 11 | Measure resistance of the heated oxygen sensor heater Is the resistance within specification? Resistance: Approx. 6 Ω (at 20°C {68°F}) | Yes | Go to next Step |
| | | No | Replace heated oxygen sensor |
| 12 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |



| 12 | BACKFIRES | • IDLE/ACCELERATION/DECELERATION | |
|-------------|---|--------------------------------------|---|
| DESCRIPTION | | • Sound produced from exhaust system | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? 🔗 page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plugs • If OK, go to next Step • If not OK, clean or replace spark plug 🔗 section G |
| | | No | Check as follows: • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals 🔗 section G |
| 3 | Is engine compression correct? 🔗 section B1 | Yes | Go to next Step |
| | | No | Check for cause 🔗 section B1 |
| 4 | Is there arestriction in the exhaust system? | Yes | Check exhaust system 🔗 page F3-127 |
| | | No | Go to next Step |
| 5 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |


| 13 LACK/LOSS OF POWER | | • ACCELERATION/CRUISE | |
|--|---|-----------------------|--|
| DESCRIPTION • Performance poor under load (i.e., power down when climbing hills) | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? 🔗 page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plugs 🔗 section G <ul style="list-style-type: none"> • If OK, go to next Step • If not OK, clean or replace spark plug |
| | | No | Check as follows: 🔗 section G <ul style="list-style-type: none"> • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals |
| 3 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? 🔗 page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm ² , 30—37 psi} | Yes | Go to next Step |
| | | No | Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure 🔗 page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause 🔗 page F3-117 • Check for clogged fuel return line |
| 4 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON? 🔗 page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator for high pressure cause 🔗 page F3-117 |
| 5 | Is there a restriction in the exhaust system? | Yes | Check exhaust system 🔗 page F3-127 |
| | | No | Go to next Step |
| 6 | Is there air leakage felt or heard at intake air system components while racing engine to higher speed? | Yes | Repair or replace |
| | | No | Go to next Step |
| 7 | Is engine compression correct? 🔗 section B1 | Yes | Go to next Step |
| | | No | Check for cause 🔗 section B1 |
| 8 | Is the brake system functioning properly? 🔗 section P | Yes | Go to next Step |
| | | No | Check for cause 🔗 section P |
| 9 | Disconnect the vacuum hose from the EGR valve and plug it Is the drive symptom eliminated? | Yes | Check EGR vent on vacuum hose to EGR valve for obstruction or leak <ul style="list-style-type: none"> • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum lines |
| | | No | Go to next Step |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 10 | Does EGR valve seat properly? | Yes | Go to next Step |
| | | No | Check as follows: <ul style="list-style-type: none"> • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 11 | Is terminal 41, 69 voltage at PCM correct?  page F3-150 | Yes | Go to next Step |
| | | No | Refer to Mazda 1996 626/MX-6 BETM |
| 12 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 14 KNOCKING/PINGING | | • ACCELERATION/CRUISE | |
|---------------------|---|---|---|
| DESCRIPTION | | • Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | |
| STEP | INSPECTION | ACTION | |
| 1 | Does vehicle overheat when knocking/pinging occurs? | Yes | Inspect cooling system for cause of overheating ➤ section E1 |
| | | No | Go to next Step |
| 2 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ➤ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 3 | Is engine compression correct? ➤ section B1 | Yes | Go to next Step |
| | | No | Check for cause ➤ section B1 |
| 4 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? ➤ page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm², 30—37 psi} | Yes | Go to next Step |
| | | No | Low: • Check pressure regulator diaphragm • Check fuel pump maximum pressure ➤ page F3-115 High: • Check pressure regulator for high pressure cause ➤ page F3-117 • Check for clogged fuel return line |
| 5 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON? ➤ page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator for high pressure cause ➤ page F3-117 |
| 6 | Disconnect the vacuum hose from the EGR valve and plug it Is the drive symptom eliminated? | Yes | Check EGR vent on vacuum hose to EGR valve for obstruction or leak • If OK, replace EGR solenoid valve (vacuum) • If not OK, repair or replace vacuum lines |
| | | No | Go to next Step |
| 7 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 15 | | POOR FUEL ECONOMY | |
|-------------|--|-------------------------------|---|
| DESCRIPTION | | • Fuel economy unsatisfactory | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection?  page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle?  page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm², 30—37 psi} | Yes | Go to next Step |
| | | No | Low: • Check pressure regulator diaphragm • Check fuel pump maximum pressure  page F3-115 High: • Check pressure regulator for high pressure cause  page F3-117 • Check for clogged fuel return line |
| 3 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON?  page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator for high pressure cause  page F3-117 |
| 4 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plugs  section G • If OK, go to next Step • If not OK, clean or replace spark plug |
| | | No | Check as follows:  section G • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals |
| 5 | Is there a restriction in the exhaust system? | Yes | Check exhaust system  page F3-127 |
| | | No | Go to next Step |
| 6 | Does the engine cooling system function properly?  page F3-144  section E1 | Yes | Go to next Step |
| | | No | Check for cause  section E1 |
| 7 | Does EGR valve seat properly (fully closed)? | Yes | Go to next Step |
| | | No | Check as follows: • EGR valve operation • EGR valve contamination • EGR solenoid valve (vacuum) • Pressure/vacuum signal hose leak |
| 8 | Remove the PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step |
| | | No | Replace PCV valve |
| 9 | Is the brake system functioning properly?  section P | Yes | Go to next Step |
| | | No | Check for cause  section P |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 10 | Is engine compression correct?  section B1 | Yes | Go to next Step |
| | | No | Check for cause  section B1 |
| 11 | Check for contaminated mass air flow sensor Is there any contamination? | Yes | Replace the mass air flow sensor |
| | | No | Go to next Step |
| 12 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 16 | | POOR FUEL ECONOMY | |
|-------------|---|-------------------------------|--|
| DESCRIPTION | | • Fuel economy unsatisfactory | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? 🔧 page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plugs • If OK, go to next Step • If not OK, clean or replace spark plug 🔧 section G |
| | | No | Check as follows: • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals 🔧 section G |
| 3 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? 🔧 page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm ² , 30—37 psi} | Yes | Go to next Step |
| | | No | Low: • Check pressure regulator diaphragm • Check fuel pump maximum pressure 🔧 page F3-115 High: • Check pressure regulator for high pressure cause • Check for clogged fuel return line 🔧 page F3-117 |
| 4 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON? 🔧 page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator for high pressure cause 🔧 page F3-117 |
| 5 | Remove the PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next Step |
| | | No | Replace PCV valve |
| 6 | Check charcoal canister for fuel saturation Is excess amount of liquid fuel present in canister? | Yes | Replace charcoal canister |
| | | No | Check fuel tank vent system Go to next Step |
| 7 | Is there a restriction in the exhaust system? | Yes | Check exhaust system 🔧 page F3-127 |
| | | No | Go to next Step |
| 8 | Does EGR valve seat properly? | Yes | Go to next Step |
| | | No | Check as follows: • EGR valve malfunction • EGR flange gasket leaking • EGR valve attaching nuts or bolts loose or missing • EGR valve contamination • EGR solenoid valve (vacuum) malfunction |
| 9 | Is the engine running at the proper operating temperature? | Yes | Go to next Step |
| | | No | Check cooling system or cause 🔧 section E1 |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 10 | Is engine compression correct?  section B1 | Yes | Go to next Step |
| | | No | Check for cause  section B1 |
| 11 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |


| 17 | MIL NEVER ON | | |
|-------------|---|-----|--|
| DESCRIPTION | • Malfunction indicator light never on | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is number 2 fuse burnt? | Yes | Repair wiring harness and replace fuse |
| | | No | Go to next Step |
| 2 | Is there correct voltage at the MIL fuse? Specification: More than 10.5 V | Yes | Go to next Step |
| | | No | Repair open in wiring harness between fuse block and ignition switch |
| 3 | Remove the malfunction indicator lamp bulb Is the voltage correct on the positive side of the malfunction indicator light bulb socket? Specification: More than 10.5 V | Yes | Go to next Step |
| | | No | Repair open in wiring harness between fuse block and malfunction indicator light bulb socket |
| 4 | Apply 12 volts and a ground to the malfunction indicator lamp bulb Does the malfunction indicator light bulb illuminate? | Yes | Go to next Step |
| | | No | Replace malfunction indicator light bulb |
| 5 | Disconnect the PCM. Install SST (104 Pin Breakout Box) to the PCM connector Does continuity exist between malfunction indicator lamp socket and test pin 2? | Yes | Replace PCM |
| | | No | Repair open circuit in wiring harness between PCM and malfunction indicator light socket |

 page F3-150

| 19 | | HIGH OIL CONSUMPTION/LEAKS | |
|-------------|---|-----------------------------|---|
| DESCRIPTION | | • Oil consumption excessive | |
| STEP | INSPECTION | ACTION | |
| 1 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next step |
| | | No | Replace PCV valve |
| 2 | Is blue smoke coming from exhaust? | Yes | Check for cause Mazda 1996 626/MX-6 BETM |
| | | No | Go to next step |
| 3 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 20 | | COOLING SYSTEM CONCERNS | • OVERHEATING |
|-------------|---|---|---------------------------------|
| DESCRIPTION | | • Engine runs at higher than normal temperature/overheats | |
| STEP | INSPECTION | ACTION | |
| 1 | Is drive belt OK? section G | Yes | Go to next step |
| | | No | Replace drive belt section G |
| 2 | Is cooling system operating properly? page F3-144 section E1 | Yes | Go to next step |
| | | No | Check for cause section E1 |
| 3 | Inspect engine block for leaks or blockage Is fault present? section E1 | Yes | Repair or replace |
| | | No | Go to next step |
| 4 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 21 | | COOLING SYSTEM CONCERNS | • RUNS COLD |
|-------------|--|--|-----------------------------------|
| DESCRIPTION | | • Engine does not reach normal operating temperature | |
| STEP | INSPECTION | ACTION | |
| 1 | Is coolant system operating properly? page F3-144 section E1 | Yes | Go to next step |
| | | No | Check for cause section E1 |
| 2 | Is complaint "Lack of passenger compartment heat" and the engine is operating at normal temperature? | Yes | Refer to Mazda 1996 626/MX-6 BETM |
| | | No | Go to next step |
| 3 | Is temperature gauge working properly? | Yes | Go to next step |
| | | No | Refer to Mazda 1996 626/MX-6 BETM |
| 4 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 22 | EXHAUST SMOKE | | |
|-------------|---|--------|--|
| DESCRIPTION | • Blue, black, or white smoke from exhaust system | | |
| STEP | INSPECTION | ACTION | |
| 1 | What is the color of smoke coming from exhaust system? | Blue | Go to next step |
| | | White | Go to step 4 |
| | | Black | Go to step 5 |
| 2 | Remove PCV valve and shake PCV valve Does PCV valve rattle? | Yes | Go to next step |
| | | No | Replace PCV valve |
| 3 | Is engine compression correct? ☞ section B1 | Yes | Verify test results. If OK, return to diagnostic index to service any additional symptoms |
| | | No | Check for cause ☞ section B1 |
| 4 | Does cooling system hold pressure? ☞ section E1 | Yes | Verify test results. If OK, return to diagnostic index to service any additional symptoms |
| | | No | Check for cause ☞ section E1 |
| 5 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ☞ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 6 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? ☞ page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm², 30—37 psi} | Yes | Go to next Step |
| | | No | Low: • Check pressure regulator diaphragm • Check fuel pump maximum pressure ☞ page F3-115 High: • Check pressure regulator for high pressure cause ☞ page F3-117 • Check for clogged fuel return line |
| 7 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned ON? ☞ page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator diaphragm • If OK, check fuel injector ☞ page F3-119 • If not OK, replace pressure regulator |
| 8 | Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?  | Yes | Check spark plugs • If OK, go to next Step • If not OK, clean or replace spark plug ☞ section G |
| | | No | Check as follows: • Distributor • High-tension leads • Ignition coil • Condition of distributor connector female terminals |
| 9 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 23 | FUEL ODOR (IN ENGINE COMPARTMENT) | | |
|-------------|---|--------|--|
| DESCRIPTION | • Gasoline fuel smell or visible leaks | | |
| STEP | INSPECTION | ACTION | |
| 1 | Visually look for fuel leakage at fuel injector O-ring, pressure regulator, and fuel line. Service as necessary. Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds? ↳ page F3-128 Fuel line pressure: 260—310 kPa {2.6—3.2 kgf/cm², 37—46 psi} | Yes | Go to next step |
| | | No | Check pressure regulator diaphragm condition <ul style="list-style-type: none"> • If condition is OK, check fuel injector ↳ page F3-119 • If condition is not OK, replace pressure regulator |
| 2 | Start the engine and bring to normal operating temperature. Disconnect hose from remote air cleaner. Place a stiff piece of paper over the hose end. Does vacuum hold the paper? | Yes | Go to next step |
| | | No | Check fuel evaporative system as follows: Disconnect evaporative hose and place a stiff piece of paper over hose Does vacuum hold the paper? <ul style="list-style-type: none"> • If yes, malfunction of fuel evaporative system ↳ page F3-134 • If no, check for vacuum leak in PCV system, oil cap, PCV valve, rocker cover for bolt torque/gasket leak |
| 3 | Remove a plug line to charcoal canister. Remove gas cap and install a vacuum pump/gauge gas cap. Apply air pressure Air pressure: 20—27 kPa {0.21—0.28 kgf/cm², 3—4 psi} Is either vacuum or fuel leak detected? | Yes | Repair or replace |
| | | No | Go to next step |
| 4 | Check for blockage/restrictions or open (hoses) between engine vacuum port and charcoal canister. Check for blockage in fuel tank vent system Is a fault detected? | Yes | Replace vacuum hose |
| | | No | Go to next step |
| 5 | Check purge solenoid valve Is the solenoid operating properly? ↳ page F3-137 | Yes | Go to next step |
| | | No | Replace the purge solenoid valve |
| 6 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ↳ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 7 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 24 | ENGINE NOISE | | |
|-------------|---|--------|--|
| DESCRIPTION | • Engine noise from under hood | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is a squeal, click or chirp sound present? | Yes | Check as follows: • Engine oil level • Drive belts • Tappets and push rods |
| | | No | Go to next step |
| 2 | Is a rumble or grind sound present? | Yes | Check drive belt |
| | | No | Go to next step |
| 3 | Is a rattle sound present? | Yes | Check location of rattle for loose parts |
| | | No | Go to next step |
| 4 | Is a hiss sound present? | Yes | Check as follows: • Engine cooling system for leaks • Vacuum leaks • Spark plug loose • Intake air system leaks • Fuel evaporative system leaks |
| | | No | Go to next step |
| 5 | Is a snap sound present? | Yes | Check secondary ignition system for shorts |
| | | No | Go to next step |
| 6 | Is a rap or roar sound present? | Yes | Check exhaust system for loose parts |
| | | No | Go to next step |
| 7 | Is a knock sound present? | Yes | Go to the "KNOCKING/PINGING" diagnostic chart |
| | | No | Go to next step |
| 8 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 25 | | VIBRATION CONCERNS (ENGINE) | |
|-------------|--|--|-------------------|
| DESCRIPTION | | • Vibration from under hood or driveline | |
| STEP | INSPECTION | ACTION | |
| 1 | Check the following components for loose attaching bolts or worn parts: <ul style="list-style-type: none"> • Cooling fan • Drive belt and pulleys • Engine mounts Is a fault present? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Check the following system for malfunctioning components: <ul style="list-style-type: none"> • Wheels • Transaxle • Driveline • Suspension Is a fault present? | Yes | Repair or replace |
| | | No | Go to next step |
| 3 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 26 | | A/C DOES NOT WORK | |
|-------------|--|--|--|
| DESCRIPTION | | • A/C compressor magnetic clutch does not engage when A/C is turned on | |
| STEP | INSPECTION | ACTION | |
| 1 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? ➤ page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 2 | Disconnect the A/C compressor connector. Start the engine and turn on the A/C switch After 10 seconds, is there correct voltage at terminal (PU) of the A/C compressor connector? Specification: More than 10.5 V | Yes | Refer to Mazda 1996 626/MX-6 BETM |
| | | No | Go to next step |
| 3 | Check the A/C relay Is the A/C relay OK? | Yes | Repair or replace relation harness. Go to next step |
| | | No | Replace A/C relay |
| 4 | Verify test results. If OK, return to diagnostic index to service any additional symptoms | | |

| 27 | A/C ALWAYS ON/A/C COMPRESSOR RUNS CONTINUOUSLY | | |
|-------------|---|-----|---|
| DESCRIPTION | • A/C compressor magnetic clutch does not disengage | | |
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect the A/C compressor connector Start the engine and turn OFF the Air conditioning switch Is there correct voltage at terminal (PU) of the A/C compressor connector? Specification: Less than 2.0 V | Yes | Refer to Mazda 1996 626/MX-6 BETM |
| | | No | Go to next step |
| 2 | Does the A/C compressor stop when the Air conditioning switch | Yes | Refer to Mazda 1996 626/MX-6 BETM |
| | | No | Go to next step |
| 3 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection? ☞ page F3-14 | Yes | Pass diagnostic trouble code displayed |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble code displayed Check for cause |

| 28 | A/C DOES NOT CUT OFF UNDER WIDE OPEN THROTTLE CONDITIONS | | |
|-------------|---|-----|--|
| DESCRIPTION | • A/C compressor magnetic clutch does not disengage under wide open throttle | | |
| STEP | INSPECTION | | ACTION |
| 1 | Remove the wide open throttle A/C relay Is there correct voltage at battery power terminal of the A/C relay connector with the ignition switch ON? Specification: Less than 10.5 V | Yes | Go to next Step |
| | | No | Repair A/C power circuit |
| 2 | Is the A/C relay OK? ☞ Mazda 1996 626/MX-6 BETM | Yes | Go to next Step |
| | | No | Repair A/C relay |
| 3 | Is there correct voltage at terminal 69 of the PCM? ☞ page F3-150 | Yes | Check wiring harness between A/C relay and PCM for open or short circuit |
| | | No | Replace PCM |

| 29 | EXHAUST SULPHUR SMELL | | |
|-------------|---|--------|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Rotten egg smell (sulphur) from exhaust NOTE: <ul style="list-style-type: none"> • Some slight sulphur smell may be normal. Catalysts with less than 8—16 thousand kilometers (5—10 thousand miles) are more likely to have a sulphur smell concern due to the highly active state of new catalysts. Replacing the catalyst if no catalyst if no problem is found may actually make the symptom worse. | | |
| STEP | INSPECTION | ACTION | |
| 1 | Start engine and run it at idle. Measure fuel line pressure at idle Is fuel line pressure correct at idle? 🔧 page F3-117 Fuel line pressure: 210—260 kPa {2.1—2.6 kgf/cm², 30—37 psi} | Yes | Go to next Step |
| | | No | Low: <ul style="list-style-type: none"> • Check pressure regulator diaphragm • Check fuel pump maximum pressure 🔧 page F3-115 High: <ul style="list-style-type: none"> • Check pressure regulator for high pressure cause 🔧 page F3-117 • Check for clogged fuel return line |
| 2 | Connect PCM terminal No.80 and a ground by using a jumper wire and the SST (104 Pin Breakout Box) Does fuel line pressure remain at specification for 60 seconds when ignition switch is turned on? 🔧 page F3-118 | Yes | Go to next Step |
| | | No | Check pressure regulator diaphragm 🔧 page F3-128 |
| 3 | Is the pass diagnostic trouble code displayed during Key On Engine Off inspection and Key On Engine Running inspection? 🔧 page F3-14 | Yes | Pass diagnostic trouble code displayed Go to next Step |
| | | No | Diagnostic trouble code no. displayed or no diagnostic trouble codes displayed Check for cause |
| 4 | Check charcoal canister for fuel saturation. Is excess amount of liquid fuel present in canister? | Yes | Replace charcoal canister |
| | | No | Check fuel tank vent system If OK, try different brand of fuel to resolve concern If not OK, service fuel tank vent system |

| 30 | INTERMITTENT CONCERNS | | |
|-------------|---|-----|---|
| DESCRIPTION | • Symptom occurs randomly and is difficult to diagnose | | |
| STEP | INSPECTION | | ACTION |
| 1 | Talk to customer. Review the vehicle service history Does the vehicle have a number of previous repairs and components replaced for a certain symptom? | Yes | Go to next step |
| | | No | Go to diagnostic chart for symptom |
| 2 | Is an engine analyzer available? | Yes | Follow the instructions supplied with the engine analyzer to diagnose the concern |
| | | No | Go to next step |
| 3 | Will the engine start? | Yes | Go to next step |
| | | No | Go to "CRANKS NORMALLY BUT WILL NOT START" diagnostic chart |
| 4 | Start the engine and run it at idle. Raise the hood, shake wiring harness and pull wires at connectors for ignition components Does the engine quit? | Yes | Service wiring harness or connector |
| | | No | Go to next step |
| 5 | Run the engine at idle. Close the hood Turn the A/C on, blower on at medium speed, and allow engine to run for 15 minutes Does the engine quit? | Yes | Go to step 9 |
| | | No | Go to next step |
| 6 | Stop the engine. Let the vehicle hot soak for 10 minutes with the hood closed Will the engine restart? | Yes | Go to next step |
| | | No | Go to "CRANKS NORMALLY BUT WILL NOT START" diagnostic chart |
| 7 | Start the engine and run it at idle. Raise the hood, shake wiring harness and pull wires at connectors for ignition components Does the engine quit? | Yes | Service wiring harness or connector |
| | | No | Go to next step |
| 8 | Road test the vehicle Does the engine quit? | Yes | Go to next step |
| | | No | Symptom not duplicated. Return to diagnostic index to service any additional concerns |
| 9 | Raise the hood. Shake wiring harness, pull wires at connectors, separate and reconnect connectors for ignition components Does the engine start? | Yes | Service wiring harness or connector |
| | | No | Go to diagnostic chart No.2, No.3 |


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

ENGINE ELECTRICAL SYSTEM

| | |
|---|------|
| INDEX | G- 2 |
| OUTLINE | G- 4 |
| SPECIFICATIONS | G- 4 |
| TROUBLESHOOTING GUIDE | G- 5 |
| DIAGNOSTIC INDEX | G- 5 |
| SYMPTOM TROUBLESHOOTING | G- 5 |
| CHARGING SYSTEM | G- 7 |
| PREPARATION | G- 7 |
| CIRCUIT DIAGRAM | G- 7 |
| TROUBLESHOOTING | G- 8 |
| BATTERY | G- 9 |
| GENERATOR | G-11 |
| DRIVE BELT | G-13 |
| ELECTRONIC IGNITION SYSTEM | G-15 |
| CIRCUIT DIAGRAM | G-15 |
| TROUBLESHOOTING | G-17 |
| IGNITION TIMING | G-18 |
| SPARK PLUG | G-18 |
| IGNITION COIL | G-19 |
| DISTRIBUTOR | G-21 |
| IGNITION CONTROL MODULE | G-26 |
| HIGH-TENSION LEAD | G-26 |
| STARTING SYSTEM | G-27 |
| CIRCUIT DIAGRAM | G-27 |
| STARTER | G-28 |
| STARTER INTERLOCK SWITCH | G-32 |


INDEX

FS



| | | | |
|------------------------------------|---------|----|--|
| 1. Battery | | | |
| Inspection | page G- | 9 | |
| Recharging | page G- | 10 | |
| 2. Generator | | | |
| Removal / Installation | page G- | 11 | |
| 3. Drive belt | | | |
| Inspection | page G- | 13 | |
| Adjustment | page G- | 14 | |
| Replacement | page G- | 14 | |
| 4. Spark plug | | | |
| Removal / Installation | page G- | 18 | |
| Spark test | page G- | 19 | |
| Inspection | page G- | 19 | |
| 5. Ignition coil | | | |
| Removal / Installation [ATX] ... | page G- | 19 | |
| Inspection | page G- | 19 | |
| Replacement | page G- | 21 | |
| 6. Distributor | | | |
| Spark test | page G- | 21 | |
| Electronic spark advance | | | |
| Inspection | page G- | 21 | |
| Removal / Installation | page G- | 22 | |
| Disassembly / Assembly | page G- | 24 | |
| Inspection | page G- | 25 | |
| 7. Ignition control module [MTX] | | | |
| Inspection | page G- | 26 | |
| Replacement | page G- | 26 | |
| 8. High-tension lead | | | |
| Removal / Installation | page G- | 26 | |
| Inspection | page G- | 26 | |
| 9. Starter | | | |
| Inspection (on vehicle) | page G- | 28 | |
| Removal / Installation | page G- | 28 | |
| Performance inspection | page G- | 31 | |
| 10. Starter interlock switch [MTX] | | | |
| Inspection | page G- | 32 | |

KL



G

| | | |
|------------------------------------|-------|-----------|
| 1. Battery | | |
| Inspection | | page G- 9 |
| Recharging | | page G-10 |
| 2. Generator | | |
| Removal / Installation | | page G-12 |
| 3. Drive belt | | |
| Inspection | | page G-13 |
| Adjustment | | page G-14 |
| Replacement | | page G-14 |
| 4. Spark plug | | |
| Removal / Installation | | page G-18 |
| Spark test | | page G-19 |
| Inspection | | page G-19 |
| 5. Ignition coil | | |
| Inspection | | page G-19 |
| Replacement | | page G-21 |
| 6. Distributor | | |
| Spark test | | page G-21 |
| Electronic spark advance | | |
| Inspection | | page G-21 |
| Removal / Installation | | page G-23 |
| Disassembly / Assembly | | page G-25 |
| Inspection | | page G-25 |
| 7. Ignition control module | | |
| Inspection | | page G-26 |
| Replacement | | page G-26 |
| 8. High-tension lead | | |
| Removal / Installation | | page G-26 |
| Inspection | | page G-26 |
| 9. Starter | | |
| Inspection (on vehicle) | | page G-28 |
| Removal / Installation | | page G-29 |
| Performance inspection | | page G-31 |
| 10. Starter interlock switch [MTX] | | |
| Inspection | | page G-32 |

OUTLINE

SPECIFICATIONS

| Item | | Engine/Transaxle | | FS | | KL | | | | |
|--|---------------------------------|-------------------------------|---------------------------------|--------------------------|--------------------------|-------------|----------------------------------|----------------------------------|----------------------------------|-------------|
| | | | | MTX | ATX | MTX | ATX | | | |
| Battery | Positive voltage | | 12 | | | | | | | |
| | Type and capacity (5-hour rate) | | GROUP 58RG (48AH) | | | | | | | |
| Dark current*1 | | mA | | Max. 20 | | | | | | |
| Generator | Type | | A.C. | | | | | | | |
| | Output | | V-A | | 12-80 | | 12-90 | | | |
| | Regulator type | | Voltage regulator, in generator | | | | | | | |
| | Regulated voltage | | V | | 14.1-14.7 | | | | | |
| | Brush length | | mm {in} | | Standard | | 21.5 {0.85} | | | |
| | | | | | Minimum | | 8.0 {0.32} | | | |
| | Brush spring force | | N {gf, lbf} | | Standard | | 3.14-4.31 {320-440, 0.71-0.96} | | | |
| | | | | | Minimum | | 1.57-2.35 {160-240, 0.36-0.52} | | | |
| | Drive belt deflection | | mm {in}/98 N{10 kgf, 22 lbf} | | New | | 6.5-7.0 {0.26-0.27} | 6.0-7.0 {0.24-0.27} | 5.5-6.5*3 | |
| | | | | | Used | | 7.0-9.0 {0.28-0.35} | 7.0-8.0 {0.28-0.31} | 6.5-7.5*3 | |
| Limit | | | | | 10 {0.39} | 9.0 {0.35} | 8.0 {0.31}*3 | | | |
| Starter | Type | | Coaxial reduction | | | Reduction | | | | |
| | Output | | V-kW | | 12-1.4 | 12-1.7 | 12-1.6 | | | |
| | Brush length | | mm {in} | | Standard | | 17.5 {0.69} | 17.0 {0.67} | | |
| | | | | | Minimum | | 12 {0.48} | | 11.5 {0.45} | |
| | Spring balance | | N {kgf, lbf} | | Standard | | 17.6-23.6 {1.79-2.41, 3.94-5.30} | 16.7-22.5 {1.70-2.30, 3.74-5.06} | 16.3-21.9 {1.66-2.24, 3.66-4.92} | |
| | | | | | Maximum | | 6.9 {0.7, 1.5} | 9.32 {0.95, 2.09} | 8.8 {0.9, 2.0} | |
| | Armature | | Runout | | mm {in} | | Standard | | 0.05 {0.002} | |
| | | | | | | | Maximum | | 0.1 {0.004} | |
| | | | Minimum diameter | | mm {in} | | Standard | | 28.8 {1.14} | 31.4 {1.24} |
| | | | | | | | Minimum | | 0.4-0.6 {0.016-0.023} | |
| Segment groove depth | | mm {in} | | Standard | | 0.2 {0.008} | | | | |
| | | | | Minimum | | 0.2 {0.008} | | | | |
| Distributor | | Camshaft position sensor type | | Hall element | | | | | | |
| | | Spark advance | | Electronic spark advance | | | | | | |
| Ignition timing | | BTDC | | 11-13° | — | 9-11° | | | | |
| • TEN terminal of data link connector grounded [KL and FS (MTX)] | | | | | | | | | | |
| Ignition coil | Resistance [at 20° {68°F}] | | Primary coil winding | | Ω | 0.49-0.73 | 0.4 | 0.49-0.73 | | |
| | | | Secondary coil winding | | kΩ | 20-31 | 8.7 | 20-31 | | |
| Spark plug | Type | | NGK | | BKR5E-11*2 BKR6E-11 | | ZFR5F-11*2 ZFR6F-11 | | | |
| | | | NIPPONDENSO | | K16PR-U11*2 K20PR-U11 | | — | | | |
| Plug gap | | mm {in} | | 1.0-1.1 {0.040-0.043} | | | | | | |
| Firing order | | | | 1-3-4-2 | | 1-2-3-4-5-6 | | | | |

*1 Dark current is the constant flow of current while the ignition is OFF (i.e., audio unit, clock, etc.)

*2 Standard plug




*3 Generator + A/C

TROUBLESHOOTING GUIDE



DIAGNOSTIC INDEX


| No. | Troubleshooting items | Page |
|-----|--|-------|
| 1 | Will not crank—starter motor does not operate | below |
| 2 | Will not crank—starter motor spins | G- 6 |
| 3 | Cranks slowly | G- 6 |
| 4 | Generator warning light illuminates while engine running | G- 6 |
| 5 | Discharged battery | G- 6 |
| 6 | Misfire | G-17 |


SYMPTOM TROUBLESHOOTING



| 1 | | Will not crank — starter motor does not operate | |
|------|---|---|--|
| STEP | INSPECTION | ACTION | |
| 1 | Does engine crank with fully charged battery? | Yes | Check charging system  page G-8 |
| | | No | Go to next step |
| 2 | Is starter interlock switch OK? [MTX] | Yes | Go to next step |
| | | No | Check starter interlock switch  page G-32 |
| 3 | Is battery positive voltage present at terminal B? | Yes | Go to next step |
| | | No | Check wiring harness |
| 4 | Is battery positive voltage present at terminal S with ignition switch in START position? | Yes | <ul style="list-style-type: none"> • Check magnetic switch • Check yoke • Check armature |
| | | No | <ul style="list-style-type: none"> • Check transaxle range switch  section K1 or K2 • Check ignition switch • Check wiring harness |

G

| 2 Will not crank — starter motor spins | | | |
|--|---|---|---|
| STEP | INSPECTION | | ACTION |
| 1 | Is drive pinion pushed out while cranking (Is click heard)? | Yes | Remove starter and check ring gear teeth and starter drive pinion teeth |
| | | No | Check magnetic switch |
| |  FS, KL [MTX] |  KL [ATX] | |


| 3 Cranks slowly | | | |
|-----------------|--|-----|--|
| STEP | INSPECTION | | ACTION |
| 1 | Does engine crank normally with fully charged battery? | Yes | Check charging system  page G-8 |
| | | No | Go to next step |
| 2 | Are starter cable connections loose or corroded? | Yes | Repair connection |
| | | No | Check starter for binding (brush, armature, etc.) |

| 4 Generator warning light illuminates while engine running | | | |
|--|---|-----|--|
| STEP | INSPECTION | | ACTION |
| 1 | Is battery positive voltage correct at idle? Specification: 14.1—14.7V | Yes | Check wiring harness between generator terminal L and generator warning light |
| | | No | Check charging system  page G-8 |


| 5 Discharged battery | | | |
|----------------------|--|-----|--|
| STEP | INSPECTION | | ACTION |
| 1 | Is charging system OK?  page G-8 | Yes | Turn ignition switch OFF and measure dark current as shown  Dark current: 20 mA max. |
| | | No | Repair or replace parts as necessary |

CHARGING SYSTEM

PREPARATION
SST

| | | |
|---|---|---|
| <p>49 9200 020A</p> <p>Tension gauge, V-ribbed belt</p> |  | <p>For inspection of drive belt tension</p> |
|---|---|---|

CIRCUIT DIAGRAM









The generator has an on-board diagnosis system to warn the operator of the following problems in the charging system. If a problem arises, the generator warning light illuminates.

1. Terminal S circuit open
2. No voltage output
3. Field coil circuit open
4. Terminal B circuit open
5. Voltage output too high

TROUBLESHOOTING


B+: Battery positive voltage

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | |
|---|---|-----------|---|----------|---|----|-----------|---|-----------|-----------|---|----|-----------|--|--|
| 1 | Check battery positive voltage; is it correct? Specification: Above 12.4V | Yes | Go to next step | | | | | | | | | | | | |
| | | No | Check battery  page G-9 | | | | | | | | | | | | |
| 2 | Does generator warning light illuminate with ignition switch ON? | Yes | Go to next step | | | | | | | | | | | | |
| | | No | Check warning light bulb and wiring harness (Generator warning light—Terminal L) | | | | | | | | | | | | |
| 3 | Does generator warning light go out after engine started? | Yes | Go to step 5 | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |
| 4 | Is voltage at generator terminals correct? Specifications: | Yes | Check wiring harness (Battery—Terminal B) | | | | | | | | | | | | |
| | | No | <ul style="list-style-type: none"> • Check wiring harness • Replace generator  page G-11 | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Terminal</th> <th>Ign: ON (V)</th> <th>Idle (V)</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>B+</td> <td>14.1—14.7</td> </tr> <tr> <td>L</td> <td>Approx. 1</td> <td>13.2—13.8</td> </tr> <tr> <td>S</td> <td>B+</td> <td>14.1—14.7</td> </tr> </tbody> </table> | | Terminal | Ign: ON (V) | Idle (V) | B | B+ | 14.1—14.7 | L | Approx. 1 | 13.2—13.8 | S | B+ | 14.1—14.7 | | |
| Terminal | Ign: ON (V) | Idle (V) | | | | | | | | | | | | | |
| B | B+ | 14.1—14.7 | | | | | | | | | | | | | |
| L | Approx. 1 | 13.2—13.8 | | | | | | | | | | | | | |
| S | B+ | 14.1—14.7 | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | |
| 5 | 1. Connect an ammeter (90A min.) between terminal B and harness 2. Start engine 3. Turn all electrical loads ON and depress brake pedal 4. Is output current 80A (FS), 90A (KL) or more at 2,500—3,000 rpm? Caution • Grounding terminal B will damage generator internal circuit | Yes | Charging system normal | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | |
| 6 | Is drive belt tension OK?  page G-13 | Yes | Replace generator  page G-11 | | | | | | | | | | | | |
| | | No | <ul style="list-style-type: none"> • Adjust drive belt tension • Replace drive belt | | | | | | | | | | | | |

BATTERY

Inspection

Battery discharge test




Test load

| Battery | Load (A) |
|------------|----------|
| GROUP 58RG | 174 |

Battery positive voltage with load

| Approximate battery temp. | Minimum voltage (V) |
|---------------------------|---------------------|
| 21°C {70°F} | 9.6 |
| 15°C {60°F} | 9.5 |
| 10°C {50°F} | 9.4 |
| 4°C {40°F} | 9.3 |
| -1°C {30°F} | 9.1 |
| -7°C {20°F} | 8.9 |
| -12°C {10°F} | 8.7 |
| -18°C { 0°F} | 8.5 |




Terminal and cable

Removing the label on top of the battery or removing the vent caps will void the battery's warranty.

Note

- Because this is a maintenance-free battery, it is not necessary to check the fluid level.

- Verify that the battery top is clean. If necessary, clean with baking soda and water.
- Verify that cables are in good condition and not frayed or corroded. Repair or replace if necessary.
- Verify that cable clamps are tight.



Recharging

Warning

- Hydrogen gas is produced during normal battery operation. A battery-related explosion can cause serious injury. Keep all flames (including cigarettes), heat, and sparks away from the top and surrounding area of open battery cells.

Caution

- Do not quick charge for over 30 minutes. It will damage the battery.

Place the battery in a pan of water to prevent it from overheating. The water level should come up about 3/4 way on the battery. Keep water off the top of the battery.

Caution

- To prevent damage to electrical components or the battery, turn all accessories off and stop the engine before performing maintenance or recharging the battery.
- When disconnecting the battery, remove the negative cable first and install it last to prevent damage to electrical components or the battery.

Slow charging

Perform a slow charge, referring to the following table.

| Type | Voltage (V) | Hour (H) | Amperage (A) |
|------------|-------------|----------|--------------|
| GROUP 58RG | 11.9—12.0 | 9 | Max. 4.8 |
| | 11.7—11.9 | 10 | |
| | below 11.7 | 12 | |

Quick charging

Remove the battery from the vehicle to perform a quick charge.

| Type | Minutes (M) | Amperage (A) |
|------------|-------------|--------------|
| GROUP 58RG | 30 | 32 |

GENERATOR
Removal / Installation

Caution


- Reversing the battery connections or using high-voltage testers will damage the rectifier.
- Do not start the engine while the connector is disconnected from terminals L and S. It can damage the generator.
- When the battery cables are connected, touching the vehicle body with generator terminal B will generate sparks. This can cause personal injury, fire, and damage to the electrical components. Always disconnect the battery before performing the following operation.

Note

- Battery positive voltage is always present at generator terminal B when the battery is connected.

1. Disconnect the negative battery cable.
2. Remove the warm up three way catalytic converter. (Refer to section F1 or F3.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.

FS



1. Connector
2. Terminal B wire
Inspect for damage and corrosion

3. Drive belt
Adjustment page G-14
4. Generator


KL

Caution

- Reversing the battery connections or using high-voltage testers will damage the rectifier.
- Do not start the engine while the connector is disconnected from terminals L and S. It can damage the generator.
- When the battery cables are connected, touching the vehicle body with generator terminal B will generate sparks. This can cause personal injury, fire, and damage to the electrical components. Always disconnect the battery before performing the following operation.


Note

- Battery positive voltage is always present at generator terminal B when the battery is connected.



- 1. Fresh-air duct
- 2. Generator terminal B wire
Inspect for damage and corrosion
- 3. Connector
- 4. Splash shield


- 5. Drive belt
Adjustment page G-14
- 6. Compressor
- 7. Generator



DRIVE BELT

Inspection

1. Check the drive belts and pulleys for wear, cracks, and damage. Replace if necessary.
2. Measure the drive belt tension by using a tension gauge.
3. Measure the deflection by applying moderate pressure **98 N {10 kgf, 22 lbf}** midway between the pulleys.
4. Adjust the belt if necessary.



Tension

FS


N {kgf, lbf}

| Drive belt | New* | Used | Limit |
|-------------------|-----------------------------|-----------------------------|--------------|
| Generator | 740—830 {75—85, 170—180} | 500—680 {50—70, 110—150} | 390 {40, 88} |
| P/S, P/S + A/C | 590—780 {60—80, 140—170} | 500—680 {50—70, 110—150} | 390 {40, 88} |

KL

N {kgf, lbf}

| Drive belt | New* | Used | Limit |
|--------------------|-----------------------------|-----------------------------|--------------|
| Generator | 690—880 {70—90, 160—190} | 500—680 {50—70, 110—150} | 440 {45, 99} |
| Generator + A/C | 690—880 {70—90, 160—190} | 500—680 {50—70, 110—150} | 440 {45, 99} |
| P/S | 540—680 {55—70, 130—150} | 400—530 {40—55, 88—120} | 340 {35, 77} |




Deflection

FS

mm {in}

| Drive belt | New* | Used | Limit |
|-------------------|------------------------|------------------------|-----------|
| Generator | 6.5—7.0 {0.26—0.27} | 7.0—9.0 {0.28—0.35} | 10 {0.39} |
| P/S, P/S + A/C | 7.5—9.0 {0.30—0.35} | 8.0—9.5 {0.32—0.37} | 11 {0.43} |




KL

mm {in}

| Drive belt | New* | Used | Limit |
|--------------------|------------------------|------------------------|------------|
| Generator | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} |
| Generator + A/C | 5.5—6.5 {0.22—0.25} | 6.5—7.5 {0.26—0.29} | 8.0 {0.31} |
| P/S | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} |

* A belt that has been on a running engine for less than five minutes.

**Adjustment****FS**


1. Loosen the generator mounting bolt and adjusting bolt.
2. Move the generator to set the specified deflection.
3. Tighten all bolts and recheck the tension.

Tightening torque**Mounting bolt:**

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

Adjusting bolt:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

**KL**

1. Loosen tensioner locknut A.
2. Tighten adjuster bolt B.
3. Tighten tensioner locknut A.

Tightening torque**Locknut:**

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

Replacement**FS**

1. Remove the A/C and P/S drive belt if equipped. Refer to section B1.
2. Loosen the generator mounting bolt and adjusting bolt.
3. Remove the generator drive belt.
4. Install the new generator drive belt and adjust it to specifications.
5. Tighten all bolts to the specified torque.

Tightening torque**Mounting bolt:**

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

Adjusting bolt:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

6. Install the A/C and P/S drive belt if equipped, and adjust to specifications. Refer to section B1.

KL


1. Loosen tensioner locknut A.
2. Remove the generator drive belt.
3. Install the new generator drive belt and adjust it to specifications.
4. Tighten tensioner locknut A.

Tightening torque**Locknut:**


32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}

ELECTRONIC IGNITION SYSTEM


CIRCUIT DIAGRAM
FS [MTX]






KL





FS [ATX]



TROUBLESHOOTING
KL, FS (MTX)

| 6 | | Misfire | |
|------|---|---------|---|
| STEP | INSPECTION | ACTION | |
| 1 | Disconnect high-tension lead from spark plug; is there a strong blue spark while cranking engine? ➔ page G-21 | Yes | System normal |
| | | No | Go to next step |
| 2 | Are ECM (PCM) and distributor connectors securely connected? | Yes | Go to next step |
| | | No | Repair or replace |
| 3 | (KL) Is diagnostic trouble code No. 0335 or 1345 also shown? (FS [MTX]) Is diagnostic trouble code No. 0335, 0340 or 1345 also shown?  | Yes | Carry out troubleshooting of corresponding diagnostic trouble code No. |
| | | No | Go to next step |
| 4 | Is battery positive voltage present at terminal A of distributor 3P wire harness with ignition switch in ON position? | Yes | Go to next step |
| | | No | Check wire harness and connector between distributor terminal A and ignition switch |
| 5 | Is ignition coil normal? ➔ page G-19 | Yes | Go to next step |
| | | No | Replace ignition coil |
| 6 | Is battery positive voltage present at terminal ⑥ of distributor 6P wire harness with ignition switch in ON position?  | Yes | Go to next step |
| | | No | Check wire harness and connector between distributor terminal ⑥ and ignition switch |
| 7 | Is approx. 0.6 V present at terminal ⑦ of distributor 6P wire harness while cranking engine?  | Yes | Replace distributor |
| | | No | Go to next step |
| 8 | Is approx. 0.6 V present at ECM (PCM) terminal 4S (KL) or 4N (FS [MTX]) while cranking engine? | Yes | Check wire harness and connector between distributor terminal ⑦ and ECM (PCM) terminal 4S (KL) or 4N (FS [MTX]) |
| | | No | Replace ECM (PCM) |


FS (ATX)

| 6 | | Misfire | |
|------|---|---------|---|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect high-tension lead from spark plug; is there a strong blue spark while cranking engine? | Yes | System normal |
| | | No | Go to next step |
| 2 | Are PCM and IG coil connectors securely connected? | Yes | Go to next step |
| | | No | Repair or replace |
| 3 | Is diagnostic trouble code No. 0335 or 1345 also shown? | Yes | Carry out troubleshooting of corresponding diagnostic trouble code No. |
| | | No | Go to next step |
| 4 | Is battery positive voltage present at terminal A of ignition coil wire harness with ignition switch in ON position?  page G-16 | Yes | Go to next step |
| | | No | Check wire harness and connector between ignition coil terminal A and ignition switch |
| 5 | Is ignition coil normal?  page G-19 | Yes | Go to next step |
| | | No | Replace ignition coil |
| 6 | Is approx. 0.6 V present at PCM terminal 26 while cranking engine? | Yes | Check wire harness and connector between ignition coil terminal C and PCM |
| | | No | Replace PCM |

IGNITION TIMING

Adjustment

Adjust the ignition timing.
(Refer to section F1 or F2.)




SPARK PLUG

Removal / Installation

1. Remove and install the high-tension leads carefully.

Caution

- Pulling on the wire part of the spark plug lead may break it. To remove the lead, pull only on the boot.



- Remove and install the spark plug with a plug socket.

Caution

- To avoid breaking the spark plug, be sure to fit the socket squarely over it.



- Apply anti-seize compound or molybdenum-based lubricant to the spark plug threads.
- Tighten the spark plug to the specified torque.

Tightening torque:

15—22 N·m {1.5—2.3 kgf·m, 11—16 ft·lbf}

Spark test

- Remove the spark plug.
- Connect the spark plug to a high-tension lead.
- Hold the high-tension lead and spark plug with insulated pliers 5—10 mm {0.20—0.39 in} from a ground.
- Crank the engine and verify that there is a strong blue spark. If not, replace the spark plug or high-tension lead as necessary.

**Inspection**


Check the following points. If a problem is found, replace the spark plug.

- Damaged insulation
- Worn electrodes
- Carbon deposits

If cleaning is necessary, use a plug cleaner or a wire brush. Clean the upper insulator, also.

- Damaged gasket
- Burnt

Plug gap: 1.0—1.1 mm {0.040—0.043 in}


**IGNITION COIL****Removal / Installation****(FS [ATX])**

- Disconnect the negative battery cable.
- Disconnect the ignition coil connector and high-tension lead from the ignition coil.
- Disconnect the condenser connector from the condenser.
- Remove the ignition coil.
- Install in the reverse order of removal.

Inspection**Primary coil winding****FS [MTX], KL**


- Disconnect the 3-pin connector from the distributor.
- Use an ohmmeter to measure resistance of the primary coil winding.

Specification: 0.49—0.73 Ω [at 20°C {68°F}]




- If not within the specification, replace the distributor. (Refer to page G-22.)

KL



FS [ATX]


**FS [ATX]**

1. Disconnect the ignition coil connector from the ignition coil.
2. Use an ohmmeter to measure resistance of the primary coil winding.

Specification: Approx. 0.4 Ω [at 20°C {68°F}]

3. If not as specified, replace the ignition coil.
(Refer to page G-19.)

FS [MTX]


**Secondary coil winding****FS [MTX], KL**

1. Disconnect the 3-pin connector from the distributor.
2. Remove the distributor cap.
3. Use an ohmmeter to measure resistance of the secondary coil winding.


Specification: 20—31 k Ω [at 20°C {68°F}]

4. If not within the specification, replace the distributor.
(Refer to page G-22.)

KL



FS [ATX]

**FS [ATX]**


1. Disconnect the high-tension lead from the ignition coil.
2. Use an ohmmeter to measure resistance of the secondary coil winding.

Specification: Approx. 8.7 k Ω [at 20°C {68°F}]


3. If not within the specification, replace the ignition coil.
(Refer to page G-19.)

Replacement

1. Remove and replace the distributor (FS [MTX], KL).
(Refer to page G-22.)
2. Remove and replace the ignition coil. (FS [ATX])
(Refer to page G-19.)
3. Adjust the ignition timing.
(Refer to section F1 or F2.)

**DISTRIBUTOR****Spark Test**


1. Disconnect the high-tension lead from a spark plug.
2. Hold the lead and spark plug with insulated pliers **5—10 mm {0.20—0.39 in}** from a ground.
3. Crank the engine and verify that a strong blue spark is visible.
4. If no spark, refer to page G-17 "No.6 MISFIRE".

**Electronic Spark Advance Inspection**

Verify that the ignition timing advances with engine acceleration.

Note


- The amount of advance depends on various factors and is not specified.




Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the fresh-air duct. (Refer to section F1, F2 or F3.)
3. Remove the air cleaner. (KL) (Refer to section F2.)
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal (KL), referring to **Installation Note (FS)**. (Refer to page G-23.)

FS [MTX]




FS [ATX]



1. High-tension lead
2. Connector


3. Distributor
- Installation Note page G-23

KL



- 1. High-tension lead
- 2. Connector

- 3. Distributor



Installation Note (FS)

1. Verify that the No.1 cylinder is at top dead center and the distributor matching marks are aligned.
2. Install the distributor and connect the high-tension leads and distributor connector.
3. Tighten the locknut or bolts to the specified torque.


Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.

FS [MTX]




FS [ATX]




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Cap 2. Rotor 3. Cover 4. Packing (FS [MTX]) 5. Insulator | <ol style="list-style-type: none"> 6. Distributor (Incorporates camshaft position sensor, ignition control module, and ignition coil) [MTX] (Incorporates camshaft position sensor) [ATX] |
|---|--|

KL



- 1. Cap
- 2. Rotor
- 3. Packing

- 4. Distributor
(Incorporates camshaft position sensor, ignition control module, and ignition coil)



Inspection

Cap and rotor

- 1. Check for corrosion, damage, and cracks.
- 2. Replace if necessary.

IGNITION CONTROL MODULE**Inspection**

1. Measure the voltage of the ECM (FS [MTX]) or PCM (KL) terminals as follows.
(Refer to sections F1 or F2.)

FS [MTX]

- 2F (Ignition control module)


KL

- 1G (Ignition control module)

2. Check the condition of the connector, distributor, ignition coil, and high-tension leads.
3. If all are normal but misfire still occurs, replace the distributor.

Replacement

1. Replace the distributor. (Refer to page G-22.)
2. Adjust the ignition timing. (Refer to sections F1 or F2.)

**HIGH-TENSION LEAD
Removal / Installation****Caution**

- Reinstall the high-tension leads to their original positions. Incorrect installation can damage the leads and cause power loss, and negatively effect electronic components.

Inspection


1. Measure the resistance of the high-tension leads.


Specification: 16 k Ω per 1 m {3.28 ft}

2. If not as specified, replace the high-tension lead set.

STARTING SYSTEM

CIRCUIT DIAGRAM





STARTER

Inspection (on vehicle)

1. Measure the battery positive voltage.


Specification: Above 12.4V

2. Crank the engine and verify that the starter turns smoothly.
3. If the starter does not turn, check the voltage at terminal S.
4. If the voltage is **more than 8V**, remove and inspect the starter. If the voltage is **less than 8V**, check the wiring harness, ignition switch, starter interlock switch [MTX], and transaxle range switch [ATX].

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.


FS



1. Negative battery cable
2. Fresh-air duct
3. Air cleaner
4. Intake manifold bracket

5. Terminal S wire
6. Terminal B wire
7. Starter

KL [MTX]



- 1. Negative battery cable
- 2. Fresh-air duct
- 3. Air cleaner

- 4. Terminal S wire
- 5. Terminal B wire
- 6. Starter

KL [ATX]


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.




Before performing this operation, drain the engine coolant. (Refer to section E2.)

Fuel Line Safety Procedures

1. Start the engine.
2. Remove the fuel pump relay.
3. After the engine stalls, turn the ignition switch to OFF.
4. Install the fuel pump relay.



- | | |
|---------------------------|---------------------------|
| 1. Negative battery cable | 7. Fuel line |
| 2. Fresh-air duct | 8. Selector cable |
| 3. Air cleaner | 9. Cable bracket |
| 4. Accelerator cable | 10. Starter bracket |
| 5. Throttle body | 11. Terminal S and B wire |
| 6. Coolant hose | 12. Starter |



Performance Inspection

Magnetic switch

Disconnect terminal S wire, and perform the following tests. Replace the magnetic switch if necessary.

Pull-in test

Connect battery positive voltage as shown and verify that the pinion is ejected.

Caution

- Applying power continuously for more than 10 seconds will damage the starter.

Hold-in test

After completing the pull-in test, disconnect the wire from terminal M (with pinion ejected) and verify that the pinion does not return.

Adjustment of pinion gap

1. Disconnect the wire from terminal M.
2. Apply battery positive voltage between terminal S and the starter body.
3. Measure the clearance (pinion gap) between the pinion and the stopper.

Caution


- Applying power continuously for more than 10 seconds will damage the starter.

Pinion gap: 0.5—2.0 mm {0.020—0.078 in}

4. If the pinion gap is not within the specification, increase or decrease the number of washers between the magnetic switch and the drive housing.

Note

- The gap becomes smaller as the number of washers is increased.



No load test

1. Connect the starter, battery, voltmeter and ammeter as shown.

Note

- Use fully charged battery.


2. Operate the starter and verify that it turns smoothly.
3. Measure the voltage and current as described below.

Specification


| Engine | V | FS | | KL | |
|---------|---|-----|-----|-----|-----|
| | | MTX | ATX | MTX | ATX |
| Voltage | V | 11 | 11 | 11 | 11 |
| Current | A | 90 | 90 | 90 | 70 |

- If not as specified, repair or replace inner parts as necessary.

STARTER INTERLOCK SWITCH



This system is similar to that of the transaxle range switch on an ATX vehicle. If the clutch pedal is not depressed during starting, battery power will not be supplied to the starter and it will not operate.



Inspection

- Disconnect the starter interlock switch connector.
- Connect a circuit tester to the switch.
- Check the continuity.

| Pedal | Continuity |
|-----------|------------|
| Depressed | Yes |
| Released | No |


- Replace the switch if necessary.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

CLUTCH

- INDEX** H- 2
- OUTLINE** H- 3
 - SPECIFICATIONS H- 3
- TROUBLESHOOTING GUIDE** H- 3
- CLUTCH FLUID** H- 4
 - PREPARATION H- 4
 - INSPECTION H- 4
 - REPLACEMENT H- 4
- CLUTCH PEDAL** H- 5
 - ADJUSTMENT H- 5
 - REMOVAL / INSTALLATION H- 6
 - OVERHAUL H- 7
- CLUTCH MASTER CYLINDER** H- 8
 - PREPARATION H- 8
 - REMOVAL / INSTALLATION H- 8
 - AIR BLEEDING H-10
 - OVERHAUL H-11
- CLUTCH RELEASE CYLINDER** H-13
 - PREPARATION H-13
 - REMOVAL / INSTALLATION H-13
 - OVERHAUL H-14
- CLUTCH UNIT** H-15
 - PREPARATION H-15
 - REMOVAL / INSTALLATION H-16
- CLUTCH COVER** H-18
 - INSPECTION H-18
- CLUTCH DISC** H-19
 - INSPECTION H-19
- CLUTCH RELEASE COLLAR** H-20
 - INSPECTION H-20
- PILOT BEARING** H-20
 - INSPECTION H-20
- FLYWHEEL** H-20
 - INSPECTION H-20

INDEX



- | | | |
|------------------------------|-----------|--|
| 1. Clutch pedal | | |
| Adjustment | page H- 5 | |
| Removal / Installation | page H- 6 | |
| Overhaul | page H- 7 | |
| 2. Clutch master cylinder | | |
| Removal / Installation | page H- 8 | |
| Air bleeding | page H-10 | |
| Overhaul | page H-11 | |
| 3. Clutch release cylinder | | |
| Removal / Installation | page H-13 | |
| Overhaul | page H-14 | |
| 4. Clutch release collar | | |
| Removal / Installation | page H-16 | |
| Inspection | page H-20 | |
| 5. Clutch release fork | | |
| Removal / Installation | page H-16 | |
| 6. Clutch cover | | |
| Removal / Installation | page H-16 | |
| Inspection | page H-18 | |
| 7. Clutch disc | | |
| Removal / Installation | page H-16 | |
| Inspection | page H-19 | |
| 8. Pilot bearing | | |
| Inspection | page H-20 | |
| Removal / Installation | page H-16 | |
| 9. Flywheel | | |
| Removal / Installation | page H-16 | |
| Inspection | page H-20 | |

OUTLINE

SPECIFICATIONS

| Item | | Engine/Transaxle | | FS | | KL | |
|-------------------------|----------------|--------------------------------|--|-----------------------------------|--------------------|----|--|
| | | | | G25M-R | | | |
| Clutch control | | | | Hydraulic | | | |
| Clutch pedal | Type | | | Suspended | | | |
| | Pedal ratio | | | 6.55 | | | |
| | Full stroke | mm {in} | | 135 {5.31} | | | |
| | Height | mm {in} | | 186—211 {7.32—8.31} (with carpet) | | | |
| Clutch disc | Outer diameter | mm {in} | | 225 {8.86} | | | |
| | Inner diameter | mm {in} | | 150 {5.91} | | | |
| | Thickness | Flywheel side mm {in} | | 3.5 {0.14} | | | |
| | | Pressure plate side mm {in} | | 3.8 {0.15} | | | |
| Clutch cover | Type | | | Diaphragm spring | | | |
| | Set load | N {kgf, lbf} | | 4,610 {470, 1,030} | 5,200 {530, 1,170} | | |
| Clutch master cylinder | Inner diameter | mm {in} | | 15.87 {0.6248} | | | |
| Clutch release cylinder | Inner diameter | mm {in} | | 19.05 {0.7500} | | | |
| Clutch fluid | | | | FMVSS116 DOT-3 | | | |

H


TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|--|--|------------------------------|--------------------|
| Slipping | Clutch disc facing worn | Replace | H-16 |
| | Clutch disc facing surface hardened or oiled | Repair or replace | H-16, 19 |
| | Pressure plate damaged | Replace | H-16 |
| | Diaphragm spring damaged or weakened | Replace | H-16 |
| | Insufficient clutch pedal play | Adjust | H- 5 |
| | Clutch pedal sticking | Repair or replace | H- 6 |
| | Flywheel damaged | Repair or replace | H-16, 20 |
| Poor disengagement | Excessive runout or damaged clutch disc | Replace | H-16 |
| | Clutch disc splines rusted or worn | Remove rust or replace | H-16 |
| | Oil on facing | Repair or replace | H-16, 19 |
| | Diaphragm spring weakened | Replace | H-16 |
| | Excessive clutch pedal play | Adjust | H- 5 |
| | Insufficient clutch fluid | Add fluid | H- 4 |
| | Leakage of clutch fluid | Locate and repair or replace | — |
| Vibration of clutch when accelerating | Oil on facing | Repair or replace | H-16, 19 |
| | Torsion rubbers weakened | Replace | H-16 |
| | Clutch disc facing hardened or damaged | Repair or replace | H-16, 19 |
| | Clutch disc facing rivets loose | Replace | H-16 |
| | Pressure plate damaged or has excessive runout | Replace | H-16 |
| | Flywheel surface hardened or damaged | Repair or replace | H-16, 20 |
| | Loose or worn engine mount | Tighten or replace | — |
| Clutch pedal sticking | Pedal shaft not properly lubricated | Lubricate or replace | H- 6 |
| Abnormal noise | Clutch release collar damaged | Replace | H-16 |
| | Poor lubrication of release collar sleeve | Lubricate or replace | H-16 |
| | Torsion rubbers weakened | Replace | H-16 |
| | Excessive crankshaft end play | Repair | Refer to section B |
| | Pilot bearing worn or damaged | Replace | H-16, 20 |
| | Worn pivot points or release fork | Replace | H-16 |

CLUTCH FLUID

PREPARATION

SST

| | | |
|----------------------|---|-------------------------------|
| 49 0259 770B |  | For air bleeding system |
| Wrench, flare nut | | |



INSPECTION

Note

- A common reservoir is used for the clutch and brake system fluids.

1. Verify that the fluid level in the reservoir is between the MAX and MIN marks.
2. If the fluid level is extremely low check the clutch and brake systems for leakage.

REPLACEMENT

Caution



- **Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.**


1. Remove the brake fluid from the reservoir by using a suction pump, and fill the reservoir with new fluid of the specified type.
2. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
3. Insert the other end of the vinyl hose into a clear container.
4. Working with another person, have the person depress the clutch pedal several times, then hold it down.
5. With the clutch pedal depressed, loosen the bleeder screw by using the **SST** to let the fluid escape. Close the bleeder screw.
6. Repeat steps 4 and 5 until only clean fluid is seen. Make sure the reservoir is always 3/4 full or more during this procedure.
7. Modify the bleeder screw tightening torque to allow for a torque wrench-**SST** combination. (Refer to section G1 "Torque Formulas".)
8. Tighten the bleeder screw by using the **SST**.

Tightening torque:

5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}

9. Fill the reservoir to MAX with new fluid of the specified type.
10. Slowly pump the clutch pedal several times. Verify that there is no fluid leakage.
11. Check the operation of the clutch system.
12. Check the operation of the brake system.





CLUTCH PEDAL

ADJUSTMENT

Height

Inspection

1. Measure the distance from the upper surface of the pedal pad to the carpet.

**Pedal height: 186—211 mm {7.32—8.31 in}
(with carpet)**

2. If necessary, adjust the pedal height

Adjustment

1. Loosen locknut (A) and turn adjusting bolt (B) until the height is correct.
2. Tighten locknut (A).

Tightening torque:

13.8—17.6 N·m {140—180 kgf·cm, 122—156 in·lbf}

3. After adjustment, measure the pedal free play.

Free Play

Inspection

1. Depress the clutch pedal by hand until clutch resistance is felt.

Free play: 1—3 mm {0.04—0.12 in}

Total free play: 5—14 mm {0.20—0.55 in}

2. If necessary, adjust the pedal free play.

Adjustment

1. Loosen locknut (C) and turn push rod (D) until the pedal free play is correct.
2. Verify that the disengagement height (from the upper surface of the pedal pad to the carpet) is correct when the pedal is fully depressed.

Minimum disengagement height:

67 mm {2.64 in} (with carpet)

3. Tighten locknut (C).


Tightening torque:

11.8—16.6 N·m {120—170 kgf·cm, 105—147 in·lbf}


4. After adjustment, measure the pedal height.

REMOVAL / INSTALLATION

1. Remove the brake pedal. (Refer to section P.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal.
4. Inspect and adjust the clutch pedal height and free play. (Refer to page H-5.)



- | | |
|----------------------------|---------------------------|
| 1. Nut | 4. Nuts |
| 2. Clutch switch connector | 5. Clutch pedal assembly |
| 3. Clutch switch | Adjustment page H-5 |
| Removal Note below | Overhaul page H-7 |




Removal Note Clutch switch

Turn the clutch switch 90 degrees in either direction and remove from the bracket.

OVERHAUL

1. Disassemble in the order shown in the figure.
2. Apply lithium-based grease to all bushings and pins.
3. Assemble in the reverse order of disassembly.




1. Clip
2. Pin
3. Bushing
4. Nut

5. Push rod
6. Clevis
7. Pedal pad
8. Clutch pedal

CLUTCH MASTER CYLINDER

PREPARATION SST


| | |
|--|--|
| <p>49 0259 770B</p> <p>Wrench, flare nut</p>  | <p>For disconnecting/ connecting clutch pipe</p> |
|--|--|

REMOVAL / INSTALLATION

Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

- Remove in the order shown in the figure, referring to **Removal Note**.
- Install in the reverse order of removal, referring to **Installation Note**.
- After installation, bleed the clutch and the brake system. (Refer to page H-10.)
- Inspect and adjust the clutch pedal height and free play. (Refer to page H-5.)



- Charcoal canister
- Clamp

Removal Note page H-9
 Installation Note page H-9


- Clutch pipe

Removal Note page H-9
 Installation Note page H-9

- Nuts
- Clutch master cylinder

Overhaul page H-11
 Air bleeding page H-10


- Gasket



Removal Note

Clamp

1. Disconnect the hose from the reservoir.
2. Plug the outlet of the reservoir.




49 0259 770B

Clutch pipe

Loosen the clutch pipe by using the SST.

H



49 0259 770B


Installation Note

Clutch pipe

1. Modify the clutch pipe tightening torque to allow for a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the clutch pipe by using the SST.




Tightening torque:

12.8—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}



Clamp

Connect the hose and install the clamp as shown in the figure.



AIR BLEEDING

The clutch hydraulic system must be bled to remove air that enters whenever a hydraulic line is disconnected.

Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
 2. Insert the other end of the vinyl hose into a clear container.
 3. Working with another person, have the person depress the clutch pedal several times, then hold it down.
 4. With the clutch pedal depressed, loosen the bleeder screw by using the **SST** to let fluid and air escape. Close the bleeder screw by using the **SST**.
 5. Repeat steps 3 and 4 until no air bubbles are seen. Make sure the reservoir is always 3/4 full or more during this procedure.
 6. Modify the bleeder screw tightening torque to allow for a torque wrench-**SST** combination. (Refer to section GI "Torque Formulas".)
 7. Tighten the bleeder screw by using the **SST**.
- Tightening torque:**
5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}
8. Fill the reservoir to MAX with new fluid of the specified type.
 9. Slowly pump the clutch pedal several times. Verify that there is no fluid leakage.
 10. Check the operation of the clutch system.
 11. Check the operation of the brake system.

OVERHAUL


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.

Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.

2. Wipe all parts, and clean all ports, passages, and inner parts with compressed air.

3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Clamp

2. Hose

3. Joint

4. Bushing

5. Snap ring

Disassembly Note below

Assembly Note page H-12

6. Piston and secondary cup assembly

Disassembly Note page H-12

Assembly Note page H-12


7. Spacer

8. Primary cup

Inspect for wear and cracks

9. Return spring


10. Master cylinder body



Disassembly Note

Snap ring

While holding the piston down with a cloth-wrapped pin punch, remove the snap ring.




Piston and secondary cup assembly

Warning

- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.


Remove the piston and secondary cup assembly, spacer, and primary cup by applying compressed air through the clutch pipe installation hole.



Assembly Note

Piston and secondary cup assembly

1. Apply new fluid of the specified type to the cylinder bore and all internal parts.
2. Verify that all parts are completely free of dirt, dust, and other small particles.
3. Install the spring, primary cup, spacer, and piston and secondary cup assembly into the master cylinder body.




Snap ring

While holding the piston down with a cloth-wrapped pin punch, install the snap ring.

CLUTCH RELEASE CYLINDER

PREPARATION
SST


| | | |
|-------------------|---|---|
| 49 0259 770B |  | For disconnecting/ connecting clutch pipe |
| Wrench, flare nut | | |

REMOVAL / INSTALLATION


Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, bleed the clutch system. (Refer to page H-10.)




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Clutch pipe Removal Note below Installation Note page H-14 | <ol style="list-style-type: none"> 3. Clutch bracket (FS engine model only) 4. Clutch release cylinder Overhaul page H-14 |
| <ol style="list-style-type: none"> 2. Bolt | |



Removal Note
Clutch pipe

Disconnect the clutch pipe by using the SST, and plug the clutch pipe immediately.



Installation Note

Clutch pipe

1. Modify the clutch pipe tightening torque to allow for a torque wrench-SST combination.
(Refer to section GI "Torque Formulas".)
2. Tighten the clutch pipe by using the SST.

Tightening torque:

12.8—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}


OVERHAUL

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.

2. Wipe all parts, and clean all ports passages, and inner parts with compressed air.
3. Assemble in the reverse order of disassembly.



- | | |
|----------------------------------|--------------------------|
| 1. Boot | 5. Return spring |
| 2. Push rod | 6. Bleeder cap |
| 3. Piston and cup assembly | 7. Bleeder screw |
| Disassembly Note page H-15 | 8. Steel ball |
| 4. Oil seal | 9. Release cylinder body |



Disassembly Note Piston and cup assembly








Warning

- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.

Remove the piston and cup assembly by applying compressed air through the clutch pipe installation hole.

CLUTCH UNIT

PREPARATION SST


| | | | |
|--|--|---|--|
| <p>49 SE01 310A</p> <p>Centering tool, clutch disc</p>  | <p>For support of clutch disc</p> | <p>49 1285 071</p> <p>Puller, bearing</p>  | <p>For removal of pilot bearing</p> |
| <p>49 1285 073</p> <p>Chuck (Part of 49 1285 071)</p>  | <p>For removal of pilot bearing</p> | <p>49 E011 1A0</p> <p>Brake, ring gear</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>—</p> | <p>—</p> |

REMOVAL / INSTALLATION

Note


- The clutch release cylinder can be removed from the transaxle with the clutch pipe connected.

- Remove in the order shown in the figure, referring to **Removal Note**.
- Install in the reverse order of removal, referring to **Installation Note**.




- Clutch release cylinder
- Transaxle
Service section J
- Boot
- Clutch release collar
Inspection page H-20
- Clutch release fork
- Clutch cover
Removal Note page H-17
Inspection page H-18
Installation Note page H-18

- Clutch disc
Removal Note page H-17
Inspection page H-19
Installation Note page H-18
- Pilot bearing
Inspection page H-20
Removal Note page H-17
Installation Note page H-18
- Flywheel
Removal Note page H-17
Inspection page H-20
Installation Note page H-17



Removal Note Clutch cover and clutch disc

1. Install the **SST**.
2. Loosen each bolt one turn at a time in a crisscross pattern until the spring tension is released.
3. Remove the clutch cover and disc.




Pilot bearing

Note


- The pilot bearing does not need to be removed unless you are replacing it.

Use the **SST** to remove the pilot bearing.



Flywheel

1. Hold the flywheel by using the **SST** or equivalent tool.
2. Remove the bolts evenly and gradually in the pattern shown.
3. Remove the flywheel.
4. Inspect for oil leakage from the crankshaft rear oil seal. If there is any such leakage or if the oil seal is damaged, refer to section B and replace the crankshaft oil seal.



Installation Note


Flywheel

Flywheel bolts on FS-engine models require sealant. New bolts have sealant already applied at the factory. However, when reusing bolts, remove all old sealant and then apply new sealant. Remove the old sealant from the bolt holes in the crankshaft, whether using new or reused bolts. These steps help to ensure that engine oil does not leak from the crankshaft bolt holes.

1. Install the flywheel to the crankshaft.
2. Hand-tighten the flywheel installation bolts.
3. Install the **SST** or equivalent tool to the flywheel.
4. Tighten the flywheel installation bolts evenly and gradually in the pattern shown in the figure.

Tightening torque


FS: 97—102 N·m {9.8—10.5 kgf·m, 71—75 ft·lbf}
 KL: 61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}

**Pilot bearing**


Install a new pilot bearing by using a suitable pipe.

Pipe outer diameter: 35.0 mm {1.378 in}

Bearing installation depth: 0—0.4 mm {0—0.016 in}

**Clutch disc**


1. Clean the clutch disc splines and main drive gear splines.
2. Apply organic molybdenum sulfide grease to the splines.
3. Hold the clutch disc in position by using the **SST**.

**Clutch cover**

1. Align the dowel holes with the flywheel dowels and install the clutch cover.
2. Install the **SST** or equivalent tool.
3. Tighten the bolts evenly and gradually in the pattern shown.


Tightening torque:

18—26 N·m {1.8—2.7 kgf·m, 14—19 ft·lbf}

**CLUTCH COVER****INSPECTION**


1. Measure the wear of the diaphragm spring fingers.

Depth: 0.5 mm {0.020 in} max.



2. Measure the flatness of the pressure plate surface by using a straightedge and a feeler gauge as shown in the figure.

Maximum clearance: 0.50 mm {0.020 in}





The KL engine is made of aluminum, so the magnet will not hold the dial indicator to the engine block as it would for the FS engine. Therefore, use the **SST** to hold the dial indicator when checking the runout of the diaphragm spring fingers on the KL engine.

3. Rotate the flywheel and check for misaligned diaphragm spring fingers.

Misalignment: 0.600 mm {0.0236 in} max.


4. Replace the clutch cover if not as specified.



CLUTCH DISC


INSPECTION

1. Inspect the contact surface of the clutch disc for scoring, cracks, burning, and oil contamination.
2. Remove minor scoring or burning by using emery paper. Repair if scoring or burning is major. Replace if cracked or oil-soaked.
3. Inspect for loose facing rivets and dampers. Replace the clutch disc if either is loose.




4. Using vernier calipers, measure the thickness of the lining at a rivet head on both sides. Replace the clutch disc if its thickness is less than minimum.

Thickness: 0.3 mm {0.012 in} min.



5. Measure the clutch disc runout by using a dial indicator. Replace the clutch disc if runout is excessive.

Runout: 0.700 mm {0.0276 in} max.




CLUTCH RELEASE COLLAR

INSPECTION

Caution

- Cleaning the clutch release collar with cleaning fluids or a steam cleaner can wash the grease out of the sealed bearing.

1. Turn the collar while applying force in the axial direction.
2. If the collar sticks or has excessive resistance, replace it.




PILOT BEARING

INSPECTION

Note

- The pilot bearing can be inspected while it is in the flywheel.


1. Turn the bearing while applying force in the axial direction.
2. If the bearing sticks or has excessive resistance, replace it.



FLYWHEEL

INSPECTION

1. Inspect the contact surface for scoring, cracks, and burning.
2. Remove minor scoring or burning by using emery paper. Repair if scoring or burning is major. Replace if cracked.



3. Inspect the ring gear teeth for wear and damage. If necessary, replace the ring gear.
4. Measure the flywheel runout by using a dial indicator. Replace the flywheel if runout is excessive.


Runout: 0.200 mm {0.0079 in} max.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

MANUAL TRANSAXLE (G25M-R)

| | |
|---|------|
| INDEX | J- 2 |
| OUTLINE | J- 3 |
| SPECIFICATIONS | J- 3 |
| STRUCTURAL VIEW | J- 4 |
| POWER FLOW | J- 5 |
| TROUBLESHOOTING GUIDE | J- 6 |
| TRANSAXLE OIL | J- 7 |
| INSPECTION | J- 7 |
| REPLACEMENT | J- 7 |
| OIL SEAL (DIFFERENTIAL) | J- 8 |
| PREPARATION | J- 8 |
| REPLACEMENT | J- 8 |
| OIL SEAL (CHANGE ROD ASSEMBLY) | J- 9 |
| REPLACEMENT | J- 9 |
| TRANSAXLE | J-10 |
| PREPARATION | J-10 |
| REMOVAL | J-12 |
| DISASSEMBLY | J-17 |
| INSPECTION | J-28 |
| ASSEMBLY | J-31 |
| INSTALLATION | J-47 |
| DIFFERENTIAL | J-52 |
| PREPARATION | J-52 |
| PREINSPECTION | J-52 |
| DISASSEMBLY / INSPECTION / ASSEMBLY ... | J-53 |
| SHIFT MECHANISM | J-56 |
| OVERHAUL | J-56 |

INDEX



| | |
|----------------------------|-----------|
| 1. Transaxle | |
| Removal | page J-12 |
| Disassembly | page J-17 |
| Inspection | page J-28 |
| Assembly | page J-31 |
| Installation | page J-47 |
| 2. Differential | |
| Disassembly / Inspection / | |
| Assembly | page J-53 |

| | |
|-----------------------------------|-----------|
| 3. Shift mechanism | |
| Overhaul | page J-56 |
| 4. Transaxle oil | |
| Inspection | page J- 7 |
| Replacement | page J- 7 |
| 5. Oil seal (differential) | |
| Replacement | page J- 8 |
| 6. Oil seal (change rod assembly) | |
| Replacement | page J- 9 |


OUTLINE

SPECIFICATIONS

| Item | | Engine/Transaxle | | FS | KL |
|--------------------|-----------|--|------------|----------------|----|
| | | G25M-R | | | |
| Transaxle control | | Floor shift | | | |
| Synchromesh system | | Forward: Synchromesh Reverse: Selective sliding and synchromesh | | | |
| Gear ratio | 1st | 3.307 | | | |
| | 2nd | 1.833 | | | |
| | 3rd | 1.233 | 1.310 | | |
| | 4th | 0.914 | 1.030 | | |
| | 5th | 0.717 | 0.795 | | |
| | Reverse | 3.166 | | | |
| Final gear ratio | | 4.105 | | | |
| Oil | Grade | API service GL-4 or GL-5 | | | |
| | Viscosity | All season | SAE 75W-90 | | |
| | | Above 10°C {50°F} | SAE 80W-90 | | |
| | Capacity | L {US qt, Imp qt} | | 2.7 {2.9, 2.4} | |


J

STRUCTURAL VIEW




- | | |
|-----------------|--------------------------------------|
| 1. 1st gear | 8. 2nd gear |
| 2. 2nd gear | 9. Secondary 3rd gear |
| 3. 3rd gear | 10. Secondary 4th gear |
| 4. 4th gear | 11. Secondary 5th gear |
| 5. 5th gear | 12. Clutch hub sleeve (Reverse gear) |
| 6. Reverse gear | 13. Reverse idler gear |
| 7. 1st gear | 14. Ring gear |


POWER FLOW




1ST




2ND




3RD



4TH



5TH




REVERSE

J

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|---|---|----------------------------|--------------|
| Shift lever won't shift smoothly or is hard to shift | Seized shift lever ball seat | Replace | J-58 |
| | Seized change control rod joint | Replace | J-58 |
| | Bent change control rod | Replace | J-58 |
| Too much play in shift lever | Worn change control rod bushing | Replace | J-58 |
| | Worn shift lever ball seat | Replace | J-58 |
| Difficult to shift | Bent change control rod | Replace | J-58 |
| | No grease in transaxle control | Lubricate with grease | J-58 |
| | Insufficient oil | Add oil | J- 7 |
| | Deterioration of oil quality | Replace with specified oil | J- 7 |
| | Wear or play of shift fork or shift rod | Replace | J-18 |
| | Worn synchronizer ring | Replace | J-24, 26 |
| | Worn synchronizer cone of gear | Replace | J-24, 26 |
| | Bad contact of synchronizer ring and cone of gear | Replace | J-24, 26 |
| | Excessive longitudinal play of gears | Replace | J-24, 26 |
| | Worn bearing | Replace | J-24, 26 |
| | Worn synchronizer key spring | Replace | J-24, 26 |
| | Excessive primary shaft gear bearing preload | Adjust | J-38 |
| Improperly adjusted change guide plate | Adjust | J-21 | |
| Won't stay in gear | Bent change control rod | Replace | J-58 |
| | Worn change control rod bushing | Replace | J-58 |
| | Improperly installed extension bar | Tighten | J-58 |
| | Worn shift fork | Replace | J-18 |
| | Worn clutch hub | Replace | J-24, 26 |
| | Worn clutch hub sleeve | Replace | J-24, 26 |
| | Worn gear sliding surface of shaft gears | Replace | J-24, 26 |
| | Worn gear sliding surface of gear | Replace | J-24, 26 |
| | Worn steel sliding groove of control end | Replace | J-18 |
| | Weak spring pressing against steel ball | Replace | J-18 |
| | Excessive thrust clearance | Replace | J-18, 24, 26 |
| | Worn bearing | Replace | J-24, 26 |
| | Improperly installed or loose engine mount | Tighten | J-48, 50 |
| Abnormal noise | Insufficient oil | Add oil | J- 7 |
| | Deterioration of oil quality | Replace with specified oil | J- 7 |
| | Worn bearing | Adjust or replace | J-24, 26 |
| | Worn sliding surfaces of gears or shafts | Replace | J-24, 26 |
| | Excessive gear backlash | Replace | J-24, 26 |
| | Damaged gear teeth | Replace | J-24, 26 |
| | Foreign material in gears | Replace | J-24, 26 |
| | Damaged differential gear or excessive backlash | Replace | J-55 |



TRANSAXLE OIL

INSPECTION

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the oil level plug and washer.
3. Verify that the oil level is near the lower edge of the plug port.
4. If the oil level is low, add the specified amount and type of oil through the plug port.

Specified oil

Grade: API service GL-4 or GL-5



Viscosity: All season SAE 75W-90

Above 10°C {50°F} SAE 80W-90

5. Install a new washer and the oil level plug.

Tightening torque:

40—58 N·m {4.0—6.0 kgf·m, 29—43 ft·lbf}




REPLACEMENT

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the drain plug and washer.
3. Drain the oil into a suitable container.
4. Install a new washer and the drain plug.

Tightening torque:

40—58 N·m {4.0—6.0 kgf·m, 29—43 ft·lbf}



5. Remove the oil level plug and washer. Add the specified amount and type of oil through the plug port until the level reaches the lower edge of the port.

Specified oil

Grade: API service GL-4 or GL-5

Viscosity: All season SAE 75W-90

Above 10°C {50°F} SAE 80W-90

Capacity: 2.7 L {2.9 US qt, 2.4 Imp qt}


6. Install a new washer and the oil level plug.


Tightening torque:

40—58 N·m {4.0—6.0 kgf·m, 29—43 ft·lbf}

OIL SEAL (DIFFERENTIAL)


PREPARATION
SST

| | |
|---|-------------------------------------|
| <p>49 B001 795</p> <p>Installer, oil seal</p>  | <p>For Installation of oil seal</p> |
|---|-------------------------------------|




REPLACEMENT


1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the drain plug and washer. (Refer to page J-7.)
3. Drain the oil into a suitable container.
4. Separate the drive shaft and joint shaft from the transaxle. (Refer to pages J-12, 14.)




5. Remove the oil seal.



6. Using the **SST** and a hammer, tap the new oil seal in evenly until the **SST** contacts the transaxle case.
7. Coat the lip of the oil seal with transaxle oil.





8. Insert the drive shaft and joint shaft to the transaxle. (Refer to pages J-47, 49.)
9. Add the specified amount and type of oil. (Refer to page J-7.)



OIL SEAL (CHANGE ROD ASSEMBLY)


REPLACEMENT

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the drain plug and washer. (Refer to page J-7.)
3. Drain the oil into a suitable container.
4. Remove the transverse member.
5. Disconnect the change control rod from the transaxle.
6. Remove the joint and boot from the change rod assembly.
7. Remove the oil seal.



8. Install the new oil seal by using a pipe.
9. Coat the lip of the oil seal with transaxle oil.

Outer diameter of pipe: 26.0 mm {1.02 in}



10. Install the boot and joint to the change rod assembly with the boot draining hole facing downward.

Tightening torque:

13.8—18.6 N·m {140—190 kgf·cm, 122—164 in·lbf}

11. Connect the change control rod.

Tightening torque:


19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

12. Add the specified amount and type of oil.
(Refer to page J-7.)

13. Install the transverse member.

Tightening torque:

















94—131 N·m {9.5—13.4 kgf·m, 69—96 ft·lbf}


















J

TRANSAXLE

PREPARATION
SST


| | | | |
|--|---|--|--|
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 T028 3A0</p> <p>Puller set, ball joint</p>  | <p>For removal of ball joint</p> |
| <p>49 T028 303</p> <p>Body (Part of 49 T028 3A0)</p>  | <p>For removal of ball joint</p> | <p>49 T028 304</p> <p>Attachment (Part of 49 T028 3A0)</p>  | <p>For removal of ball joint</p> |
| <p>49 0107 680A</p> <p>Engine stand</p>  | <p>For disassembly / assembly of transaxle</p> | <p>49 G019 0A0</p> <p>Hanger, transaxle</p>  | <p>For disassembly / assembly of transaxle</p> |
| <p>49 G030 440</p> <p>Holder, primary shaft</p>  | <p>For holding primary shaft</p> | <p>49 FT01 361</p> <p>Remover, bearing</p>  | <p>For removal of bearing race</p> |
| <p>49 B001 795</p> <p>Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 0636 145</p> <p>Puller, fan pulley boss</p>  | <p>For removal of bearing</p> |
| <p>49 G030 370</p> <p>Removing plate</p>  | <p>For removal of secondary 3rd gear and 2nd gear</p> | <p>49 G017 1A0</p> <p>Remover set, bearing</p>  | <p>For removal of bearing</p> |
| <p>49 F401 366A</p> <p>Plate (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> | <p>49 B092 373</p> <p>Attachment G (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> |
| <p>49 B092 374</p> <p>Attachment H (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> | <p>49 0839 425C</p> <p>Puller set, bearing</p>  | <p>For removal of bearing</p> |

| | | | |
|---|--|---|--|
| <p>49 F401 330B</p> <p>Installer set, bearing</p>  | <p>For installation of bearing</p> | <p>49 F401 331</p> <p>Body (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> |
| <p>49 F401 335A</p> <p>Attachment A (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> | <p>49 F401 336B</p> <p>Attachment B (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> |
| <p>49 G030 380D</p> <p>Shim selector set</p>  | <p>For adjustment of bearing preload</p> | <p>49 G030 381</p> <p>Selector $\phi 68$ (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G030 382A</p> <p>Selector $\phi 58$ (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 F401 382A</p> <p>Selector $\phi 52$ (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 F401 384</p> <p>Collar (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 G019 021</p> <p>Bolt set (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 FT01 515A</p> <p>Adapter, preload (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 F401 385</p> <p>Bar (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 B017 102</p> <p>Adapter, preload</p>  | <p>For adjustment of bearing preload</p> | <p>49 G017 202</p> <p>Adapter, preload</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G030 455</p> <p>Holder, diff. side gear</p>  | <p>For holding side gears</p> | <p>—</p> | <p>—</p> |

REMOVAL


1. Disconnect the negative battery cable.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Drain the transaxle oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.

KL ENGINE




- | | |
|--|-------------------------------|
| 1. Battery | 18. Extension bar |
| 2. Battery carrier | 19. Change control rod |
| 3. Fresh air duct | 20. Tie-rod ends |
| 4. Air cleaner housing assembly | Service section N |
| 5. Starter | 21. Stabilizer control links |
| 6. Neutral switch connector | 22. Drive shafts |
| 7. Back-up light switch connector | Removal Note page J-15 |
| 8. Vehicle speedometer sensor (speedometer driven gear) connector | 23. Joint shaft |
| 9. Ground | Service section M |
| 10. Fuel filter mounting nuts | 24. No.5 engine mount |
| 11. Harness bracket | 25. No.1 engine mount bracket |
| 12. Clutch release cylinder | 26. Engine mounting member |
| Removal Note page J-15 | Removal Note page J-16 |
| 13. Oxygen sensor connector | 27. Undercover |
| 14. Wheels and tires | 28. No.4 engine mount |
| 15. Splash shields | 29. Transaxle |
| 16. Transverse member | Removal Note page J-16 |
| 17. Exhaust pipe | 30. No.2 engine mount |

FS ENGINE



- | | |
|---|--|
| 1. Battery | 17. Change control rod |
| 2. Battery carrier | 18. Tie-rod ends Service section N |
| 3. Resonance chamber | 19. Stabilizer control links |
| 4. Fresh air duct | 20. Drive shafts Removal Note below |
| 5. Air cleaner housing assembly | 21. Joint shaft Service section M |
| 6. Neutral switch connector | 22. Starter |
| 7. Back-up light switch connector | 23. No.5 engine mount |
| 8. Vehicle speedometer sensor (speedometer driven gear) connector | 24. No.1 engine mount bracket |
| 9. Ground | 25. Engine mounting member Removal Note below |
| 10. Fuel filter mounting nuts | 26. No.4 engine mount |
| 11. Harness bracket | 27. Transaxle Removal Note page J-16 |
| 12. Clutch release cylinder Removal Note below | 28. No.2 engine mount |
| 13. Wheels and tires | |
| 14. Splash shields | |
| 15. Transverse member | |
| 16. Extension bar | |




Removal Note
Clutch release cylinder

Caution


- **Bending the clutch pipe can cause kinks or cracks.**

1. Remove the bolts and clips shown. (For the FS engine model, remove the clutch bracket.)
2. Put the clutch release cylinder and the clutch pipe in a place where they will not interfere with transaxle removal.




Drive shafts

1. Remove the drive shafts. (Refer to section M.)
2. Suspend the drive shaft with a rope.
3. Install the **SST** into the transaxle to hold the side gears.




Engine mounting member

1. Support the engine by using the **SST**.
2. Remove the engine mounting member.




Transaxle

1. Loosen the **SST** (engine support) and lean the engine toward the transaxle.
2. Support the transaxle on a jack.



3. Remove the transaxle mounting bolts.
4. Remove the transaxle.



DISASSEMBLY

Precaution

1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvent before disassembly.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.


2. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and dry with compressed air.
3. Clean out all holes and passages with compressed air, and check that there are no obstructions.

5th/Reverse Gear and Housing Parts

1. Measure the 5th gear thrust clearance, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | |
|---|---|
| 1. Rear cover | 19. Magnet |
| 2. Locknut (primary shaft) Disassembly Note below | 20. Reverse idler shaft |
| 3. Locknut (secondary shaft) Disassembly Note below | 21. Reverse idler gear Inspection page J-29 |
| 4. Primary reverse synchronizer gear Inspection page J-28 | 22. 5th/reverse shift rod |
| 5. Reverse synchronizer ring Inspection page J-28 | 23. 5th/reverse shift rod end |
| 6. Secondary reverse synchronizer gear Inspection page J-28 | 24. Pin |
| 7. 5th/reverse shift fork | 25. Crank lever shaft |
| 8. 5th/reverse clutch hub assembly Inspection page J-28 | 26. Crank lever assembly |
| 9. 5th synchronizer ring Inspection page J-28 | 27. Shift fork and shift rod assembly Disassembly Note page J-19 |
| 10. 5th gear Preinspection below Inspection page J-28 | 28. Steel ball |
| 11. Gear sleeve | 29. Spring |
| 12. Secondary 5th gear Inspection page J-28 | 30. Primary shaft gear assembly |
| 13. Lock bolt | 31. Secondary shaft gear assembly |
| 14. Guide bolt | 32. Differential assembly |
| 15. Lock bolt, ball, and spring | 33. Clutch housing |
| 16. Back-up light switch | 34. Synchronizer key springs |
| 17. Neutral switch | 35. Clutch hub sleeve |
| 18. Transaxle case assembly | 36. Synchronizer keys |
| | 37. Clutch hub |
| | 38. 3rd/4th shift fork |
| | 39. Interlock sleeve |
| | 40. Control lever |
| | 41. 1st/2nd shift fork |
| | 42. Control rod |
| | 43. Control end |



Preinspection

5th gear thrust clearance

1. Measure the 5th gear thrust clearance by using a dial indicator.

Clearance: 0.100—0.220 mm {0.0039—0.0087 in}


Maximum: 0.270 mm {0.0106 in}


2. If the clearance exceeds the maximum, check the contact surfaces of the 5th gear and the clutch hub. Replace worn or damaged parts.

Disassembly note


Locknut

1. Mount the transaxle on the SST.






2. Lock the primary shaft with the **SST**.
3. Shift to 1st gear to lock the rotation of the primary shaft.
4. Uncrimp the tabs of the locknuts.
5. Remove the locknuts from the primary and secondary shafts.



Shift fork and shift rod assembly

1. Align the ends of the interlock sleeve and of the control lever (arrow). Turn the shift rod counterclockwise.
2. While holding the 1st/2nd shift fork with one hand and the 3rd/4th shift fork with the other, raise them both at the same time and shift each of the clutch hub sleeves.




3. Lift the control end and remove the steel ball, and at the same time, remove the control rod from the clutch housing.
4. Separate the shift rod and shift fork assembly from each of the clutch hub sleeves.

Clutch Housing and Transaxle Case Components


Note

- The oil seals do not need to be removed unless you are replacing them.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | | |
|--|-----------------------------------|-----------|
| 1. Bearing race (primary shaft) | 15. Oil seal (differential) | |
| 2. Oil seal (primary shaft) | Disassembly Note | page J-21 |
| 3. Bearing race (secondary shaft) | 16. Bearing race (differential) | |
| Disassembly Note | Disassembly Note | page J-22 |
| 4. Funnel | 17. Reverse lever shaft | |
| 5. Guide plate assembly | Disassembly Note | page J-22 |
| 6. Change arm | 18. Reverse lever | |
| 7. Roll pin | Inspection | page J-29 |
| Disassembly Note | 19. Drain plug and washer | |
| 8. Change rod assembly | 20. Bearing race (transaxle case) | |
| 9. Boot | Disassembly Note | page J-22 |
| 10. Selector | 21. Adjustment shim(s) | |
| 11. Oil seal (change rod assembly) | 22. Bearing race (differential) | |
| Disassembly Note | Disassembly Note | page J-22 |
| 12. Bleeder cover assembly | 23. Adjustment shim(s) | |
| 13. Bleeder | 24. Oil seal (differential) | |
| 14. Vehicle speedometer sensor (speedometer driven gear) | Disassembly Note | page J-21 |
| Inspection | 25. Oil passage | |
| page J-30 | 26. Joint | |
| | 27. Change rod | |




Disassembly note
Oil seal (primary shaft)

Caution


- The clutch housing is made of aluminum, and is therefore easily dented and scratched by metal tools. When removing the oil seal, keep contact with the clutch housing to a minimum.

Remove the oil seal from the clutch housing as shown in the figure.




Bearing race (secondary shaft)

Remove the bearing race by lifting it and the funnel out together.




Roll pin

Align the groove for removal of the clutch housing pin with the position of the roll pin; then tap the pin out by using a pin punch.




Oil seal (change rod assembly)

Remove the oil seal.




Oil seal (differential)


Remove the oil seal.

**Bearing race (differential)**


1. Install the **SST** onto the differential bearing race, and support the **SST** so that it does not fall.
2. Remove the bearing race by using the **SST**.

**Reverse lever shaft**

1. Remove the roll pin by using pliers.




2. Protect the reverse lever shaft with a rag and use pliers to remove the shaft.

**Bearing race (transaxle case)**


Remove the bearing race by using the **SST**.

Primary Shaft Assembly

1. Measure the thrust clearance of all gears before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



| | |
|---|--|
| <p>1. Bearing (4th gear end) Disassembly Note page J-24 Inspection page J-29</p> <p>2. 4th gear Preinspection page J-24 Inspection page J-28</p> <p>3. 4th synchronizer ring Inspection page J-28</p> <p>4. Retaining ring</p> <p>5. 3rd/4th clutch hub assembly Disassembly Note page J-24 Inspection page J-28</p> <p>6. 3rd synchronizer ring Disassembly Note page J-24 Inspection page J-28</p> | <p>7. 3rd gear Preinspection page J-24 Disassembly Note page J-24 Inspection page J-28</p> <p>8. Bearing (primary shaft end) Disassembly Note page J-24 Inspection page J-29</p> <p>9. Primary shaft gear Inspection page J-29</p> <p>10. Synchronizer key springs</p> <p>11. 3rd/4th clutch hub sleeve</p> <p>12. Synchronizer keys</p> <p>13. 3rd/4th clutch hub</p> |
|---|--|


**Preinspection****3rd gear thrust clearance**

1. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05—0.20 mm {0.002—0.008 in}

Maximum: 0.25 mm {0.010 in}

2. If the clearance exceeds the maximum, check the contact surfaces of the 3rd gear, 2nd gear and 3rd/4th clutch hub. Replace worn and damaged parts.


**4th gear thrust clearance**

1. Measure the clearance between the 4th gear and the ball bearing.


Clearance: 0.17—0.37 mm {0.007—0.015 in}

Maximum: 0.42 mm {0.017 in}


2. If the clearance exceeds the maximum, check the contact surfaces of the 4th gear, ball bearing, and 3rd/4th clutch hub. Replace worn and damaged parts.

**Disassembly note****Bearing (4th gear end)**

1. Support the primary shaft to keep it from falling.
2. Remove the bearing by using the SST.

**3rd/4th clutch hub assembly, 3rd synchronizer ring and 3rd gear**


1. Support the primary shaft to keep it from falling.
2. Remove the 3rd/4th clutch hub assembly, 3rd synchronizer ring, and 3rd gear by using the SST.

**Bearing (primary shaft end)**


Remove the bearing by using the SST.

Secondary Shaft Assembly

1. Measure the thrust clearance of 1st gear and 2nd gear before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



| | | | |
|--------------------------------|-----------------|--------------------------------------|-----------------|
| 1. Bearing | | 9. 1st synchronizer ring | |
| Disassembly Note | page J-26 | Disassembly Note | page J-26 |
| Inspection | page J-29 | Inspection | page J-28 |
| 2. Secondary 4th gear | | 10. 1st gear | |
| Disassembly Note | page J-26 | Preinspection | page J-26 |
| Inspection | page J-28 | Disassembly Note | page J-26 |
| 3. Retaining ring | | Inspection | page J-28 |
| 4. Secondary 3rd gear | | 11. Bearing (secondary shaft end) | |
| Disassembly Note | page J-26 | Disassembly Note | page J-27 |
| Inspection | page J-28 | Inspection | page J-29 |
| 5. 2nd gear | | 12. Secondary shaft gear | |
| Preinspection | page J-26 | Inspection | page J-29 |
| Disassembly Note | page J-26 | 13. Synchronizer key springs | |
| Inspection | page J-28 | 14. Clutch hub sleeve (reverse gear) | |
| 6. 2nd synchronizer ring | | 15. Synchronizer keys | |
| Inspection | page J-28 | 16. 1st/2nd clutch hub | |
| 7. Retaining ring | | | |
| 8. 1st/2nd clutch hub assembly | | | |
| Disassembly Note | page J-26 | | |
| Inspection | page J-28 | | |


**Preinspection****1st gear thrust clearance**

1. Measure the clearance between the 1st gear and the differential drive gear.

Clearance: 0.05—0.28 mm {0.002—0.011 in}

Maximum: 0.33 mm {0.013 in}

2. If the clearance exceeds the maximum, check the contact surfaces of the 1st gear, differential drive gear of the secondary shaft gear, and 1st/2nd clutch hub assembly. Replace worn and damaged parts.


**2nd gear thrust clearance**

1. Measure the clearance between the 2nd gear and secondary 3rd gear.


Clearance: 0.18—0.46 mm {0.007—0.018 in}

Maximum: 0.51 mm {0.020 in}


2. If the clearance exceeds the maximum, check the contact surfaces of the 2nd gear, secondary 3rd gear, and 1st/2nd clutch hub assembly. Replace worn and damaged parts.

**Disassembly note****Bearing and secondary 4th gear**


1. Support the secondary shaft to keep it from falling.
2. Remove the bearing and secondary 4th gear by using the SST.

**Secondary 3rd gear and 2nd gear**

1. Shift the gears to 1st gear.
2. Support the secondary shaft to keep it from falling.
3. Remove the secondary 3rd gear and 2nd gear by using the SST.

**1st/2nd clutch hub assembly, 1st synchronizer ring, and 1st gear**


1. Support the secondary shaft to keep it from falling.
2. Remove the 1st/2nd clutch hub assembly, 1st synchronizer ring, and 1st gear by using a press.

**Bearing (secondary shaft end)**


1. Support the secondary shaft to keep it from falling.
2. Remove the bearing by using the SSTs.

INSPECTION


Inspect all parts and repair or replace as necessary.

**Gears**

1. Inspect the synchronizer cones for wear.
2. Inspect the gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer ring matching teeth for damage and wear.

**Synchronizer Ring**


1. Inspect the synchronizer ring teeth for damage, wear, and cracks.
2. Inspect the tapered surface for wear and cracks.




3. Set the synchronizer ring squarely in the gear.
4. Measure the clearance between the synchronizer ring and the flank surface of the gear all around the circumference.

Standard clearance: 1.50 mm {0.059 in}

Minimum: 0.80 mm {0.031 in}

**Clutch Hub Assembly**

1. Inspect the clutch hub sleeve and hub operation.
2. Inspect the gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer keys for damage, wear, and cracks.




4. Measure the clearance between the hub sleeve and shift fork.

Clearance

mm {in}

| | Standard | Maximum |
|----------|-------------------------|--------------|
| 1st/2nd | 0.10—0.45 {0.004—0.018} | 0.95 {0.037} |
| 3rd/4th | 0.10—0.40 {0.004—0.016} | 0.90 {0.035} |
| 5th/Rev. | 0.10—0.36 {0.004—0.014} | 0.86 {0.034} |




Reverse Idler Gear and Reverse Lever

1. Inspect the gear teeth for damage, wear, and cracks.
2. Measure the clearance between the reverse idler gear bushing and the reverse lever.

Standard clearance:


0.10—0.35 mm {0.004—0.014 in}

Maximum: 0.85 mm {0.033 in}



Bearing

Inspect for damage and rough rotation.




Primary Shaft Gear and Secondary Shaft Gear

1. Inspect the gear contact surface for damage and wear.
2. Inspect the splines for damage and wear.
3. Inspect the gear teeth for damage, wear, and cracks.
4. Inspect the oil passage for blockage.
5. Measure the shaft gear runout.


Primary shaft gear runout:

0.050 mm {0.0020 in} max.



Secondary shaft gear runout:

0.015 mm {0.0006 in} max.





6. Measure the clearance between the shaft and the gears.

Clearance

mm {in}

| | Shaft (Outer dia.) | Gear (Inner dia.) | Sleeve (Outer dia.) | Clearance |
|-----|----------------------------------|----------------------------------|----------------------------------|--------------------------------|
| 1st | 39.445—39.470 {1.5529—1.5539} | 39.500—39.525 {1.5551—1.5561} | — | 0.030—0.080 {0.0012—0.0031} |
| 2nd | 34.945—34.970 {1.3758—1.3768} | 35.000—35.025 {1.3780—1.3789} | — | |
| 3rd | 35.945—35.970 {1.4152—1.4161} | 36.000—36.025 {1.4173—1.4183} | — | |
| 4th | 30.945—30.970 {1.2183—1.2193} | 31.000—31.025 {1.2205—1.2215} | — | |
| 5th | — | 34.000—34.025 {1.3386—1.3396} | 33.945—33.970 {1.3364—1.3374} | |



Vehicle Speedometer Sensor (Speedometer Driven Gear)

1. Inspect the teeth for damage and wear.
2. Inspect the O-ring for damage and wear.


ASSEMBLY

Precaution


1. All O-rings and gaskets must be replaced with the new ones included in the overhaul kit.
2. Verify that all parts are completely cleaned before assembly.
3. Assemble parts within 10 minutes after applying sealant. Allow the sealant to cure for at least 30 minutes after assembly before filling the transaxle with transaxle oil.
4. Bearing races and bearings must be replaced as sets.

Secondary Shaft Assembly

Assemble in the order shown in the figure, referring to **Assembly Note**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. 1st/2nd clutch hub Assembly Note page J-32 2. Synchronizer keys 3. Clutch hub sleeve (reverse gear) 4. Synchronizer key springs 5. Secondary shaft gear 6. Bearing (secondary shaft end) Assembly Note page J-32 7. 1st gear Assembly Note page J-32 8. 1st synchronizer ring Assembly Note page J-32 9. 1st/2nd clutch hub assembly Assembly Note page J-32 | <ol style="list-style-type: none"> 10. Retaining ring 11. 2nd synchronizer ring Assembly Note page J-33 12. 2nd gear Assembly Note page J-33 13. Secondary 3rd gear Assembly Note page J-33 14. Retaining ring 15. Secondary 4th gear Assembly Note page J-33 16. Bearing Assembly Note page J-33 |
|---|--|




Assembly note
Clutch hub

Synchronizer key dimensions

| | mm {in} | | |
|---------------------|--------------|------------|------------|
| | ① | ② | ③ |
| 1st/2nd | 19.0 {0.748} | 4.3 {0.17} | 5.0 {0.20} |
| 3rd/4th 5th/Rev. | 17.0 {0.669} | 4.3 {0.17} | 5.0 {0.20} |




Install the synchronizer keys and springs in the clutch hub.




Bearing (secondary shaft end)

Install the new bearing by using the SST.




1st gear, 1st synchronizer ring and 1st/2nd clutch hub assembly


The 2nd synchronizer ring has teeth missing at three places around its outer edge to help distinguish it from the other synchronizer rings.



1. Assemble the 1st gear, 1st synchronizer ring, and 1st/2nd clutch hub assembly.
2. Align the synchronizer ring grooves and synchronizer keys.




3. Press the 1st/2nd clutch hub assembly on by using the SST.




2nd synchronizer ring, 2nd gear and secondary 3rd gear

1. Install the 2nd synchronizer ring and 2nd gear.
2. Install the secondary 3rd gear by using the SSTs.




Secondary 4th gear and bearing

1. Install the secondary 4th gear and the bearing by using the SST.



2. Measure the clearance between the 1st gear and the differential drive gear.

Clearance: 0.05—0.28 mm {0.002—0.011 in}
Maximum: 0.33 mm {0.013 in}




3. Measure the clearance between the 2nd gear and the secondary 3rd gear.

Clearance: 0.18—0.46 mm {0.007—0.018 in}
Maximum: 0.51 mm {0.020 in}


4. If not as specified, reassemble the secondary shaft assembly.

Primary Shaft Assembly

Assemble in the order shown in the figure, referring to **Assembly Note**.




- | | |
|---|---|
| 1. 3rd/4th clutch hub Assembly Note page J-32 | 9. 3rd/4th clutch hub assembly Assembly Note page J-35 |
| 2. Synchronizer keys | 10. Retaining ring |
| 3. 3rd/4th clutch hub sleeve | 11. 4th synchronizer ring Assembly Note page J-35 |
| 4. Synchronizer key springs | 12. 4th gear Assembly Note page J-35 |
| 5. Primary shaft gear | 13. Bearing Assembly Note page J-35 |
| 6. Bearing (primary shaft end) Assembly Note below | |
| 7. 3rd gear Assembly Note page J-35 | |
| 8. 3rd synchronizer ring Assembly Note page J-35 | |



Assembly note


Bearing (primary shaft end)

Install the new bearing by using the SST.




3rd gear, 3rd synchronizer ring, and 3rd/4th clutch hub assembly

Install the 3rd gear, 3rd synchronizer ring, and 3rd/4th clutch hub assembly by using a press.




4th synchronizer ring, 4th gear, and bearing

1. Install the 4th synchronizer ring, 4th gear, and a new bearing by using the SSTs.



2. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05—0.20 mm {0.002—0.008 in}
Maximum: 0.25 mm {0.010 in}




3. Measure the clearance between the 4th gear and bearing.

Clearance: 0.17—0.37 mm {0.007—0.015 in}
Maximum: 0.42 mm {0.017 in}

4. If not as specified, reassemble the primary shaft assembly.

Clutch Housing and Transaxle Case Components

1. Select the adjustment shim(s), referring to **Bearing Preload Adjustment**.
2. Assemble in the order shown in the figure, referring to **Assembly Note**.
3. Verify that the bearing preload is within specification, referring to **Bearing Preload**.






- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Change rod 2. Joint 3. Oil passage 4. Oil seal (differential) Assembly Note page J-40 5. Adjustment shim(s) Bearing preload adjustment ... page J-37 6. Bearing race (differential) Assembly Note page J-40 7. Adjustment shim(s) Bearing preload adjustment ... page J-37 8. Bearing race (transaxle case) Assembly Note page J-40 9. Drain plug and washer 10. Reverse lever 11. Reverse lever shaft 12. Bearing race (differential) Assembly Note page J-40 13. Oil seal (differential) Assembly Note page J-40 | <ol style="list-style-type: none"> 14. Vehicle speedometer sensor (speedometer driven gear) 15. Bleeder 16. Bleeder cover assembly 17. Oil seal (change rod assembly) Assembly Note page J-41 18. Selector 19. Boot Assembly Note page J-41 20. Change rod assembly 21. Roll pin 22. Change arm 23. Guide plate assembly 24. Funnel 25. Bearing race (secondary shaft) 26. Oil seal (primary shaft) Assembly Note page J-41 27. Bearing race (primary shaft) |
|---|--|

Bearing preload adjustment


When replacing any of the parts listed in the table below, adjust the bearing preload by selecting and installing the proper adjustment shim(s).

| Primary shaft assembly | Secondary shaft assembly | Differential |
|--|--|--|
| <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Primary shaft gear bearing • Primary shaft gear | <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Secondary shaft gear bearing • Secondary shaft gear • Secondary 4th gear | <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Differential side bearing • Ring gear and case assembly |







1. Install the primary and secondary shaft bearing races into the transaxle case (with the shims removed).
2. Mount the clutch housing onto the transaxle hanger, and set the differential bearing race into the clutch housing. Position a piece of pipe against the bearing race and tap it in until it contacts the clutch housing.
3. Set the bearing races into the **SSTs** (selector) as shown in the figure.
4. Turn the selector to eliminate the gap indicated by the arrow.



5. Set the differential assembly into the clutch housing, and set the bearing race and the **SST** (selector) on the differential. Set the assembled selectors for the primary and secondary shaft in the clutch housing. Mount the shaft gear assemblies as shown in the figure.




6. Set the **SST** (collars) in the positions shown in the figure.




7. Install the transaxle case and tighten the **SST** (bolts) to the specified torque.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



8. To seat the bearings, mount the **SST** (bars) on parts **A** and **B** of the selectors, and turn the selectors so the gaps are widened. Then turn the **SST** in the reverse direction until the gaps are eliminated.



9. Manually expand the selector until it no longer turns by hand.
10. Verify that both the primary and secondary shafts turn smoothly.



11. Measure the clearance between the two halves of the **SST** (selector) around the circumference by using a feeler gauge.
12. Take the maximum reading and determine the shim to be used. Use no more than two shims.

<Primary shaft adjustment shim>

- Select the thinner shim from the table to obtain the standard clearance.

Standard clearance: 0—0.05 mm {0—0.002 in}

Example: Reading from step 11 =

0.57 mm {0.022 in}

Shim selection range:

(0.57 mm {0.022 in}—0.05 mm {0.002 in})

—(0.57 mm {0.022 in}—0 mm {0 in})

= 0.52 mm {0.020 in}—0.57 mm {0.022 in}

Shim: 0.55 mm {0.022 in}

| Thickness (Shaft gears) | mm {in} |
|-------------------------|--------------|
| 0.20 {0.008} | 0.50 {0.020} |
| 0.25 {0.010} | 0.55 {0.022} |
| 0.30 {0.012} | 0.60 {0.024} |
| 0.35 {0.014} | 0.65 {0.026} |
| 0.40 {0.016} | 0.70 {0.028} |
| 0.45 {0.018} | |

<Secondary shaft adjustment shim>

- Select the thinner shim from the table to obtain the standard clearance.

Tightening amount: 0.03—0.08 mm {0.001—0.003 in}

Example: Reading from step 11 =

0.57 mm {0.022 in}


Shim selection range:

(0.57 mm {0.022 in} + 0.03 mm {0.001 in})


—(0.57 mm {0.022 in} + 0.08 mm {0.003 in})

= 0.60 mm {0.024 in}—0.65 mm {0.026 in}

Shim: 0.60 mm {0.024 in}




13. Install the **SST** to the differential.



14. Turn the **SST** by using a torque wrench. Adjust the **SST** (selector) with the **SST** (bars) until the specified preload is obtained.

Preload: 0.5 N·m {5.0 kgf·cm, 4.3 in·lbf}




15. Measure the gap between ① and ② around the circumference of the **SST** (selector) by using a feeler gauge.
16. Add **0.15 mm {0.006 in}** to the measured clearance and select a combination of two shims closest in value to that measurement. Use no more than two shims.

| Thickness | mm {in} |
|--------------|--------------|
| 0.10 {0.004} | 0.70 {0.028} |
| 0.20 {0.008} | 0.75 {0.030} |
| 0.25 {0.010} | 0.80 {0.031} |
| 0.30 {0.012} | 0.85 {0.033} |
| 0.35 {0.014} | 0.90 {0.035} |
| 0.40 {0.016} | 0.95 {0.037} |
| 0.45 {0.018} | 1.00 {0.039} |
| 0.50 {0.020} | 1.05 {0.041} |
| 0.55 {0.022} | 1.10 {0.043} |
| 0.60 {0.024} | 1.15 {0.045} |
| 0.65 {0.026} | 1.20 {0.047} |

Example: 0.32 mm {0.013 in}
0.32 mm {0.013 in} + 0.15 mm {0.006 in}
= 0.47 mm {0.019 in}.
Nearest shim (on thick side) to 0.47 mm
{0.019 in} is 0.50 mm {0.020 in}.


17. Remove the transaxle case and the **SSTs**.
18. Remove the selectors, the primary shaft assembly, and the differential.
19. Remove the bearing races.



Assembly note


Oil seal (differential)

1. Using the **SST** and a hammer, tap the new oil seal in evenly until the **SST** contacts the transaxle case.
2. Coat the lip of the oil seal with transaxle oil.




Bearing race (differential)

1. Install the adjustment shim(s) to the differential case.
2. Apply transaxle oil to the bearing race, and install it to the differential case by using a pipe.




Bearing race (transaxle case)

1. Install the adjustment shim(s) to the primary and secondary shaft bearing seats in the transaxle case.
2. Apply transaxle oil to each bearing race, and install them to the transaxle case by using a pipe.


**Oil seal (change rod assembly)**

1. Install the new oil seal by using a pipe.
2. Coat the lip of the oil seal with transaxle oil.


Outer diameter of pipe: 26.0 mm {1.02 in}

**Boot**

Install the boot so that the drain hole is facing downward when mounted on the vehicle.

**Oil seal (primary shaft)**

Apply transaxle oil to the outer circumference of the oil seal, and install it to the transaxle case by using a pipe.


**Bearing preload**

Verify the shaft gears and the differential bearing preloads. Readjust the bearing preloads if they are not within specification.

1. Set the primary shaft gear assembly and the differential into the clutch housing.
2. Install the transaxle case, and tighten to the specified torque.


Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



3. Install the **SST** to the differential.
4. Connect a torque wrench to the **SST** and measure the preload.


Preload: 1.4—1.9 N·m {14—20 kgf·cm, 13—17 in·lbf}



5. Remove the **SST**.
6. With the transaxle facing in the direction shown in the figure, install the **SST** to the primary shaft gear assembly.
7. Connect a torque wrench to the **SST** and measure the preload.

Preload:

0.1—0.2 N·m {1.0—2.5 kgf·cm, 0.9—2.1 in·lbf}



8. Remove the **SST**, transaxle case, primary shaft gear assembly, and differential.
9. Install the secondary shaft gear assembly and transaxle case, and tighten to the specified torque.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

10. Install the **SST** to the secondary shaft gear assembly.
11. Connect a torque wrench to the **SST** and measure the preload.

Preload:


0.2—0.4 N·m {2.0—4.0 kgf·cm, 1.8—3.4 in·lbf}

5th/Reverse Gear and Housing Parts

Assemble in the order shown in the figure, referring to **Assembly Note**.




APPLY SPECIFIED OIL TO INDIVIDUAL PARTS




N-m {kgf-m, ft-lbf}

| | |
|---------------------------------------|---|
| 1. Control rod | 23. Reverse idler gear |
| 2. Control end | Assembly Note page J-45 |
| 3. 1st/2nd shift fork | 24. Reverse idler shaft |
| 4. Control lever | Assembly Note page J-45 |
| 5. Interlock sleeve | 25. Magnet |
| 6. 3rd/4th shift fork | 26. Transaxle case assembly |
| 7. Clutch hub | Assembly Note page J-46 |
| 8. Synchronizer keys | 27. Neutral switch |
| 9. Clutch hub sleeve | 28. Back-up light switch |
| 10. Synchronizer key springs | 29. Lock bolt, ball, and spring |
| 11. Clutch housing | 30. Guide bolt |
| 12. Differential assembly | 31. Lock bolt |
| 13. Secondary shaft gear assembly | 32. Secondary 5th gear |
| Assembly Note below | Assembly Note page J-46 |
| 14. Primary shaft gear assembly | 33. Gear sleeve |
| Assembly Note below | 34. 5th gear |
| 15. Spring | 35. 5th synchronizer ring |
| 16. Steel ball | 36. 5th/reverse clutch hub assembly |
| 17. Shift fork and shift rod assembly | Assembly Note page J-46 |
| Assembly Note below | 37. 5th/reverse shift fork |
| 18. Crank lever assembly | Assembly Note page J-46 |
| Assembly Note page J-45 | 38. Secondary reverse synchronizer gear |
| 19. Crank lever shaft | 39. Reverse synchronizer ring |
| Assembly Note page J-45 | 40. Primary reverse synchronizer gear |
| 20. Pin | 41. Locknut (secondary shaft) |
| 21. 5th/reverse shift rod end | Assembly Note page J-46 |
| Assembly Note page J-45 | 42. Locknut (primary shaft) |
| 22. 5th/reverse shift rod | Assembly Note page J-46 |
| Assembly Note page J-45 | 43. Rear cover |




Assembly note
Primary shaft gear assembly and secondary shaft gear assembly

Install the primary and secondary shaft gear assemblies together.




Shift fork and shift rod assembly


1. Shift to 2nd gear and position the shift fork and shift rod assembly as shown.



2. Insert the spring seat and spring into the reverse lever shaft. Install the steel ball, and place a scraper so that it contacts the steel ball.
3. With the edge of the control end against the scraper, push the control end in the direction of the arrow so that the ball goes into the shaft. This will line up the rod with the shift rod coupling hole in the clutch housing.




4. Set each clutch hub sleeve to the neutral position, and tap the shift rod from above so that the steel ball goes into the center groove (of the three grooves in the control end).
5. Pull up on the ball part of the control end so that the steel ball goes into the detent in the groove.



Crank lever assembly and crank lever shaft

1. Install a new O-ring to the crank lever shaft.
2. Fit the crank lever between the change arm and the control end, and connect the crank lever shaft to the crank lever.
3. Align the pin holes of the crank lever shaft and the clutch housing, and insert a new pin.




5th/reverse shift rod end and 5th/reverse shift rod

1. Install the shift rod ② into the shift rod end ①.
2. Align the mark on the shift rod with the mounting bolt hole in the shift rod end as shown in the figure, and tighten the gate mounting bolt.


Tightening torque:

11.8—13.7 N·m {120—140 kgf·cm, 105—121 in·lbf}



Reverse idler gear and reverse idler shaft

1. Install the reverse idler gear and the reverse idler shaft.
2. Attach the magnet to the clutch housing.
3. Align the end of the interlock sleeve with the control lever (arrow), and at the same time, face the reverse idler shaft screw hole in the direction shown in the figure.




Transaxle case assembly

1. Apply a thin coat of sealant to the contact surfaces of the clutch housing and transaxle case, and tighten the transaxle case installation bolts to the specified torque.

Tightening torque:


38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

2. Insert the **SSTs** through the drive shaft and joint shaft hole.




Secondary 5th gear

Install the secondary 5th gear as shown.



5th/reverse clutch hub assembly and 5th/reverse shift fork

Install the 5th/reverse clutch hub assembly and the 5th/reverse shift fork together.



Locknut

1. Shift to 1st gear.
2. Lock the primary shaft by using the **SST**.
3. Tighten new locknuts onto the primary and secondary shafts.

Tightening torque:

128—196 N·m {13—20 kgf·m, 95—144 ft·lbf}


4. Stake the locknuts.

5. Measure the 5th gear thrust clearance by using a dial indicator.

Clearance: 0.100—0.220 mm {0.0039—0.0087 in}

Maximum: 0.270 mm {0.0106 in}

6. If not as specified, reassemble the transaxle.




INSTALLATION

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Install in the order shown in the figure, referring to **Installation Note**.
3. Add the specified amount and type of transaxle oil. (Refer to page J-7.)
4. Warm up the engine and transaxle, inspect for oil leakage, and check transaxle operation.

KL ENGINE

7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}




N·m {kgf·m, ft·lbf}

- | | | | |
|---|-----------|---|-----------|
| 1. No.2 engine mount Installation Note | page J-50 | 14. Exhaust pipe | |
| 2. Transaxle Installation Note | page J-50 | 15. Transverse member | |
| 3. Undercover | | 16. Splash shields | |
| 4. No.4 engine mount | | 17. Wheels and tires | |
| 5. No.1 engine mount bracket Installation Note | page J-50 | 18. Clutch release cylinder | |
| 6. Engine mounting member Installation Note | page J-51 | 19. Oxygen sensor connector | |
| 7. No.5 engine mount | | 20. Harness bracket Installation Note | page J-51 |
| 8. Joint shaft Service | section M | 21. Fuel filter mount nuts | |
| 9. Drive shafts Installation Note | page J-51 | 22. Ground | |
| 10. Stabilizer control link | | 23. Vehicle speedometer sensor (speedometer driven gear) connector | |
| 11. Tie-rod ends Service | section N | 24. Back-up light switch connector | |
| 12. Change control rod | | 25. Neutral switch connector | |
| 13. Extension bar | | 26. Starter | |
| | | 27. Air cleaner housing assembly | |
| | | 28. Fresh air duct | |
| | | 29. Battery carrier | |
| | | 30. Battery | |


FS ENGINE

7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}



N·m {kgf·m, ft·lbf}

- | | |
|--|--|
| 1. No.2 engine mount Installation Note below | 13. Extension bar |
| 2. Transaxle Installation Note below | 14. Transverse member |
| 3. No.4 engine mount | 15. Splash shields |
| 4. No.1 engine mount bracket Installation Note below | 16. Wheels and tires |
| 5. Engine mounting member Installation Note page J-51 | 17. Clutch release cylinder |
| 6. No.5 engine mount | 18. Harness bracket Installation Note page J-51 |
| 7. Starter | 19. Fuel filter mount bolts |
| 8. Joint shaft Service section M | 20. Ground |
| 9. Drive shafts Installation Note page J-51 | 21. Vehicle speedometer sensor (speedometer driven gear) connector |
| 10. Stabilizer control link | 22. Back-up light switch connector |
| 11. Tie-rod ends Service section N | 23. Park/neutral switch connector |
| 12. Change control rod | 24. Air cleaner housing assembly |
| | 25. Fresh air duct |
| | 26. Resonance chamber |
| | 27. Battery carrier |
| | 28. Battery |



Installation Note

No.2 engine mount

1. Install the No.2 engine mount bracket to the transaxle.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

2. Hand-tighten the engine mount nut.

Transaxle

1. Set the transaxle on a jack and lift it into place.
2. Install the transaxle mounting bolts.

Tightening torque

KL: 68—99 N·m {6.9—10.1 kgf·m, 50—73 ft·lbf}

FS: 90—116 N·m {9.1—11.9 kgf·m, 66—86 ft·lbf}

3. Hand-tighten the No.4 engine mount bolts and nuts.

No.1 engine mount



Caution


- **Align the transaxle bolt holes and the engine mount exactly. Any misalignment can result in bolts and bolt holes becoming damaged or stripped during installation.**

1. Use the **SST** (engine support) to make sure the transaxle bolt holes and No.1 engine mount meet evenly.
2. Set the 3 bolts in the holes, and tighten them to the specified torque.

Tightening torque:


75—104 N·m {6.8—10.7 kgf·m, 55—77.3 ft·lbf}





Engine mounting member

1. Install the engine mount bushings as shown in the figure.
2. Install the engine mounting member, making sure that the No.1 engine mount stud bolts pass through the mounting member installation hole.



3. Install the bolts and nuts as shown.

Tightening torque


A: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

B: 75—104 N·m {7.6—10.7 kgf·m, 55—77 ft·lbf}

4. Tighten the No.2 engine mount rubber nut.

Tightening torque:

86—116 N·m {8.7—11.9 kgf·m, 63—86 ft·lbf}




5. Tighten the No.4 engine mount bolts and nuts.

Tightening torque:


67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

6. Remove the **SST** (engine support).



Drive shafts

1. Remove the **SST** from the transaxle case.
2. Install the drive shafts. (Refer to section M.)



Harness bracket

Install the harness bracket as shown in the figure.






After warming up the engine, do the following.


- Check the amount of oil. (Refer to page J-7.)
- Conduct a road test and verify the following.

1. There is no abnormal noise in each shift position.
2. Smooth shift change is possible.
3. Transaxle does not jump out of gear.
4. Speedometer operates correctly.
5. Back-up lights operate correctly.

DIFFERENTIAL

**PREPARATION
SST**

| | | | |
|---|---|--|------------------------------------|
| <p>49 G017 1A0 Remove set, bearing</p>  | <p>For removal of bearing</p> | <p>49 F401 366A Plate (Part of 49 G017 1A0)</p>  | <p>For removal of side bearing</p> |
| <p>49 B092 375 Attachment J (Part of 49 G017 1A0)</p>  | <p>For removal of side bearing</p> | <p>49 0839 425C Puller set, bearing</p>  | <p>For removal of side bearing</p> |
| <p>49 G030 338 Attachment E</p>  | <p>For installation of side bearing</p> | <p>—</p> | <p>—</p> |



PREINSPECTION

Backlash of Side Gear and Pinion Gear

Measure the backlash by the following procedure.

1. Install the left drive shaft and the joint shaft in the differential assembly.
2. Support the drive shaft and the joint shaft on V-blocks.
3. Measure the backlash of both pinion gears.

Backlash: 0.050—0.150 mm {0.0020—0.059 in}


4. If not as specified, replace parts as necessary.

DISASSEMBLY / INSPECTION / ASSEMBLY


Note

- The bearings do not need to be removed unless you are replacing them.

1. Before disassembly, inspect the backlash of the side gears and pinion gears, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.
4. Measure the backlash after assembly, referring to **Backlash of Side Gear and Pinion Gear**.




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Roll pin Assembly Note page J-55 2. Pinion shaft 3. Pinion gear Preinspection above Inspection of backlash page J-55 4. Thrust washer 5. Side gear Preinspection above Inspection of backlash page J-55 6. Thrust washer | <ol style="list-style-type: none"> 7. Bearing (side opposite ring gear) Disassembly Note page J-54 Inspection page J-54 Assembly Note page J-55 8. Speedometer drive gear 9. Bearing (ring gear side) Disassembly Note page J-54 Inspection page J-54 Assembly Note page J-54 10. Ring gear and gear case assembly Inspection page J-54 |
|--|---|



Disassembly Note


Bearing (side opposite ring gear)

While supporting the gear case, remove the bearing by using the SST.



Bearing (ring gear side)


Remove the bearing by using the SST.



Inspection


Ring gear and gear case assembly

Inspect the ring gear for wear and cracks. Refer to page J-38 for bearing preload adjustment if the ring gear and gear case assembly is being replaced.



Bearing


Inspect for wear and rough rotation. If replacing the bearing, replace the bearing and race as an assembly.




Assembly Note

Bearing (ring gear side)


Install the new bearing by using the SST.

**Bearing (side opposite ring gear)**

1. Install the speedometer drive gear.
2. Install the new bearing by using the **SST**.

**Roll pin**

Install the new roll pin with the split facing as shown.

**Backlash of Side Gear and Pinion Gear**

Measure the backlash by the following procedure.

1. Install the left drive shaft and the joint shaft in the differential assembly.
2. Support the drive shaft and the joint shaft on V-blocks.
3. Measure the backlash of both pinion gears.


Backlash: 0.050—0.150 mm {0.0020—0.059 in}

4. If not as specified, replace parts as necessary.


SHIFT MECHANISM

OVERHAUL

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|------------------------|--------------------------|
| 1. Shift lever knob | 17. Assist boot |
| 2. Front console | 18. Mounting rubber boot |
| 3. Insulator | 19. Retaining ring |
| 4. Transverse member | 20. O-ring |
| 5. Exhaust pipe | 21. Upper ball seat |
| 6. Nut | 22. Boot |
| 7. Bolt | 23. Lower ball seat |
| 8. Nut | 24. Gear shift lever |
| 9. Bolt | 25. Pipe |
| 10. Change control rod | 26. Bushing |
| 11. Bushings | 27. Extension bar |
| 12. Bushings | 28. Nut |
| 13. Nut | 29. Bolt |
| 14. Washer | 30. Rubber mount |
| 15. Washer | 31. Base plate |
| 16. Nuts (base plate) | |
- Assembly Note below



Assembly Note

Nuts (base plate)

1. Install the base plate to the floor; then install the extension bar onto the transaxle.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

2. Tighten the base plate nuts to the specified torque.

Tightening torque:


9.8—14.7 N·m {100—150 kgf·cm, 87—130 in·lbf}

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

AUTOMATIC TRANSAXLE (GF4A-EL)

| | | | |
|--|-------|---|--------|
| INDEX | K1- 2 | 2-4 BRAKE BAND (DISASSEMBLY / INSPECTION / ASSEMBLY) | K1- 87 |
| OUTLINE | K1- 4 | IDLER GEAR | K1- 90 |
| SPECIFICATIONS | K1- 4 | OUTPUT GEAR | K1- 93 |
| CROSS-SECTIONAL VIEW | K1- 5 | BEARING COVER ASSEMBLY | K1- 95 |
| POWER FLOW DIAGRAM | K1- 6 | OIL SEAL (TRANSAXLE) | K1- 96 |
| OPERATION OF COMPONENTS | K1- 7 | CONTROL VALVE BODY (DISASSEMBLY / INSPECTION) | K1- 97 |
| FLUID PASSAGE LOCATIONS | K1- 8 | PREMAIN CONTROL VALVE BODY .. | K1-104 |
| MECHANICAL SYSTEM TEST | K1-10 | MAIN CONTROL VALVE BODY | K1-108 |
| PREPARATION | K1-10 | REAR CONTROL VALVE BODY | K1-112 |
| MECHANICAL SYSTEM TEST PREPARATION | K1-10 | CONTROL VALVE BODY (ASSEMBLY) | K1-115 |
| LINE PRESSURE TEST | K1-11 | CONTROL VALVE BODY (ON-VEHICLE REMOVAL / INSTALLATION) | K1-125 |
| STALL TEST | K1-12 | DIFFERENTIAL | K1-127 |
| TIME LAG TEST | K1-13 | BEARING PRELOAD | K1-131 |
| ROAD TEST | K1-15 | TRANSAXLE UNIT (ASSEMBLY) | K1-137 |
| ROAD TEST PREPARATION | K1-15 | TRANSAXLE UNIT (INSTALLATION) .. | K1-154 |
| SHIFT DIAGRAM | K1-15 | OIL COOLER | K1-161 |
| D RANGE TEST | K1-15 | OIL COOLER | K1-161 |
| 2 RANGE TEST | K1-17 | DRIVE PLATE | K1-163 |
| 1 RANGE TEST | K1-17 | PREPARATION | K1-163 |
| P POSITION TEST | K1-17 | DRIVE PLATE | K1-163 |
| AUTOMATIC TRANSAXLE FLUID (ATF) .. | K1-18 | SHIFT MECHANISM | K1-165 |
| ATF | K1-18 | SHIFT-LOCK SYSTEM COMPONENTS | K1-165 |
| ELECTRICAL SIGNAL INSPECTION | K1-20 | SHIFT-LOCK | K1-167 |
| PREPARATION | K1-20 | EMERGENCY OVERRIDE KEY CYLINDER | K1-167 |
| ELECTRICAL SIGNAL INSPECTION ... | K1-21 | KEY INTERLOCK | K1-167 |
| ELECTRICAL SYSTEM COMPONENTS .. | K1-28 | P POSITION SWITCH | K1-168 |
| PREPARATION | K1-28 | SHIFT-LOCK ACTUATOR | K1-169 |
| O/D OFF SWITCH | K1-28 | SELECTOR LEVER | K1-170 |
| TRANSAXLE RANGE SWITCH | K1-29 | ON-BOARD DIAGNOSTIC SYSTEM | K1-177 |
| TRANSAXLE FLUID TEMPERATURE SENSOR | K1-31 | PREPARATION | K1-177 |
| INPUT/TURBINE SPEED SENSOR | K1-32 | DIAGNOSTIC TROUBLE CODE | K1-177 |
| VEHICLE SPEEDOMETER SENSOR .. | K1-33 | TROUBLESHOOTING GUIDE | K1-195 |
| BRAKE SWITCH | K1-34 | GENERAL NOTES | K1-195 |
| SOLENOID VALVES | K1-35 | QUICK DIAGNOSIS CHART | K1-196 |
| O/D OFF INDICATOR LIGHT | K1-37 | OUTLINE | K1-196 |
| POWERTRAIN CONTROL MODULE ... | K1-38 | QUICK DIAGNOSIS CHART (I) | K1-196 |
| TRANSAXLE | K1-39 | QUICK DIAGNOSIS CHART (II) | K1-198 |
| TRANSAXLE UNIT (REMOVAL) | K1-39 | SYMPTOM TROUBLESHOOTING | K1-200 |
| TRANSAXLE UNIT (DISASSEMBLY) ... | K1-45 | USING THIS SECTION | K1-200 |
| TORQUE CONVERTER | K1-58 | DIAGNOSTIC INDEX | K1-202 |
| 2-3 ACCUMULATOR | K1-59 | SYMPTOM TROUBLESHOOTING CHART | K1-205 |
| OIL PUMP | K1-61 | SERVICE POINTS | K1-232 |
| CLUTCH ASSEMBLY | K1-64 | OUTLINE | K1-232 |
| SMALL SUN GEAR AND ONE-WAY CLUTCH 1 | K1-74 | ELECTRICAL DIAGNOSIS SUPPORT . | K1-235 |
| ONE-WAY CLUTCH 2 AND CARRIER HUB ASSEMBLY | K1-77 | HYDRAULIC CIRCUIT | K1-239 |
| 3-4 CLUTCH | K1-79 | | |
| LOW AND REVERSE BRAKE | K1-83 | | |

INDEX




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Data link connector 2 <ul style="list-style-type: none"> On-board diagnostic system . page K1-177 2. ATF <ul style="list-style-type: none"> Inspection page K1- 18 3. O/D OFF switch <ul style="list-style-type: none"> Inspection page K1- 28 Replacement page K1- 29 4. Transaxle range switch <ul style="list-style-type: none"> Inspection page K1- 29 Replacement page K1- 30 Adjustment page K1- 31 5. Transaxle fluid temperature sensor <ul style="list-style-type: none"> Inspection page K1- 31 Replacement page K1- 32 6. Input/turbine speed sensor <ul style="list-style-type: none"> Inspection page K1- 32 Replacement page K1- 33 7. Vehicle speedometer sensor <ul style="list-style-type: none"> Inspection page K1- 33 8. Brake switch <ul style="list-style-type: none"> Inspection page K1- 34 9. Solenoid valves <ul style="list-style-type: none"> Inspection page K1- 35 Replacement page K1- 37 10. O/D OFF indicator light <ul style="list-style-type: none"> Inspection page K1- 37 11. Powertrain control module <ul style="list-style-type: none"> Service section F2 | <ul style="list-style-type: none"> 12. Transaxle <ul style="list-style-type: none"> Removal page K1- 39 Disassembly page K1- 45 Assembly page K1-137 Installation page K1-154 13. 2-4 brake band <ul style="list-style-type: none"> Disassembly / Inspection / <ul style="list-style-type: none"> Assembly page K1- 87 14. Oil seal <ul style="list-style-type: none"> On-vehicle replacement page K1- 96 15. Control valve body <ul style="list-style-type: none"> Disassembly / Inspection page K1- 97 Assembly page K1-115 On-vehicle removal page K1-125 On-vehicle installation page K1-125 16. Oil cooler <ul style="list-style-type: none"> Removal / Installation page K1-161 17. Drive plate <ul style="list-style-type: none"> Removal / Installation page K1-163 18. Selector lever <ul style="list-style-type: none"> Inspection page K1-170 Adjustment page K1-170 Removal / Inspection / <ul style="list-style-type: none"> Installation page K1-172 Disassembly / Inspection / <ul style="list-style-type: none"> Assembly page K1-175 |
|---|--|

OUTLINE

SPECIFICATIONS


| Item | Transaxle/Engine | | GF4A-EL |
|--|-----------------------|-------------------|-----------------------|
| | | | KL |
| Transaxle control | | | Floor shift |
| Torque converter clutch mechanism | | | Equipped |
| Gear ratio | First gear | | 2.800 |
| | Second gear | | 1.540 |
| | Third gear | | 1.000 |
| | Fourth gear | | 0.700 |
| | Reverse | | 2.333 |
| Final gear ratio | | | 4.157 |
| Automatic transaxle fluid (ATF) | Type | | M-III or Dexron®II |
| | Capacity | L {US qt, Imp qt} | 8.8 {9.3, 7.7} |
| Torque converter stall torque ratio | | | 2.05 |
| Number of drive/driven plates | Forward clutch | | 3/3 |
| | Coasting clutch | | 2/3 |
| | 3-4 clutch | | 4/4 |
| | Reverse clutch | | 2/2 |
| | Low and reverse brake | | 4/4 |
| Band servo (piston outer dia./retainer inner dia.) mm {in} | | | 78.0/40.0 {3.07/1.57} |
| Number of planetary gear teeth | Large sun gear | | 36 |
| | Small sun gear | | 30 |
| | Long pinion gear | | 24 |
| | Short pinion gear | | 22 |
| | Internal gear | | 84 |
| Number of output gear teeth | | | 19 |
| Number of idler gear teeth | | | 42 |
| Number of ring gear teeth | | | 79 |

CROSS-SECTIONAL VIEW




K1

POWER FLOW DIAGRAM



- | | | |
|---------------------|---------------------------------------|-----------------------|
| 1. Crankshaft | 10. Reverse clutch | 16. Small sun gear |
| 2. Drive plate | 11. 2-4 brake band | 17. Long pinion gear |
| 3. Torque converter | 12. Low and reverse brake | 18. Short pinion gear |
| 4. Turbine shaft | 13. One-way clutch 1 (Sprag type) | 19. Internal gear |
| 5. Oil pump shaft | 14. One-way clutch 2 (Roller type) | 20. Parking gear |
| 6. Oil pump | 15. Large sun gear | 21. Output gear |
| 7. Forward clutch | | 22. Idler gear |
| 8. Coasting clutch | | 23. Ring gear |
| 9. 3-4 clutch | | |



OPERATION OF COMPONENTS


| Position/ Range | Mode | Gear | | Engine braking effect | Forward clutch | Coasting clutch | 3-4 clutch | Reverse clutch | 2-4 brake | | Low and reverse brake | One-way clutch 1 (Sprag type) | One-way clutch 2 (Roller type) | |
|--------------------|--|----------------|-------------------------------------|--------------------------|----------------|-----------------|------------|----------------|-----------|----------|--------------------------|----------------------------------|-----------------------------------|--|
| | | | | | | | | | Applied | Released | | | | |
| P | — | — | | — | | | | | | | | | | |
| R | — | Reverse | Below approx. 4 km/h {2.5 mph} | Yes | | | | ○ | | | ○ | | | |
| | | | Above approx. 5 km/h {3 mph} | Yes | | | | ○ | | | ○ | | | |
| | | — | Above approx. 30 km/h {19 mph} | No | | | | ○ | | | | | | |
| N | — | — | Below approx. 4 km/h {2.5 mph} | — | | | | | | | | | | |
| | | | Above approx. 5 km/h {3 mph} | — | | | | | | | | | | |
| D | ☆ O/D OFF SW OFF POWER/ NORMAL | First gear | | No | ○ | | | | | | | ○ | ○ | |
| | | Second gear | | No | ○ | | | | ○ | | | | ○ | |
| | | Third gear | | Yes | ○ | ○ | ○ | | ⊗ | ○ | | | ○ | |
| | | Fourth gear | | Yes | ○ | | ○ | | ○ | | | | ⊙ | |
| | ☆ O/D OFF SW ON POWER/ NORMAL | Second gear | Below approx. 14 km/h {8.7 mph} | Yes | ○ | ○ | | | ○ | | | | ○ | |
| | | | Above approx. 17 km/h {10.5 mph} | No | ○ | | | | ○ | | | | ○ | |
| | | Third gear | | Yes | ○ | ○ | ○ | | ⊗ | ○ | | | ○ | |
| *Fourth gear | | Yes | ○ | | ○ | | ○ | | | | ⊙ | | | |
| 2 | — | Second gear | | Yes | ○ | ○ | | ○ | | | | ○ | | |
| | | *Third gear | | Yes | ○ | ○ | ○ | | ⊗ | ○ | | | ○ | |
| | | *Fourth gear | | Yes | ○ | | ○ | | ○ | | | | ⊙ | |
| 1 | — | First gear | | Yes | ○ | ○ | | | | | ○ | ○ | ○ | |
| | | *Second gear | | Yes | ○ | ○ | | | ○ | | | | ○ | |

K1


- Operating.
- ⊗ Operating but not contributing to the power transmission.
- ⊙ POWER is not transmitted.
- * Engine overspeed protection.
- ☆ The powertrain control module automatically switches between POWER and NORMAL modes corresponding to the speed at which the accelerator pedal is depressed.

FLUID PASSAGE LOCATIONS

Transaxle Case




Clutch Housing




K1

Oil Pump







Turbine Shaft



MECHANICAL SYSTEM TEST


PREPARATION SST

| | | | |
|---|------------------------------|--|------------------------------|
| <p>49 0378 400B</p> <p>Gauge set, oil pressure</p>  | <p>For oil pressure test</p> | <p>49 B019 901</p> <p>Oil pressure gauge</p>  | <p>For oil pressure test</p> |
| <p>49 B019 902</p> <p>Oil pressure gauge (Part of 49 0378 400B)</p>  | <p>For oil pressure test</p> | <p>49 B019 903</p> <p>Hose (Part of 49 0378 400B)</p>  | <p>For oil pressure test</p> |

MECHANICAL SYSTEM TEST PREPARATION

1. Engage the parking brake and use wheel chocks at the front and rear of the wheels.
2. Check the engine coolant. (Refer to section E2.)
3. Check the engine oil. (Refer to section B2.)
4. Check the ATF levels. (Refer to page K1-18.)
5. Check the idle speed and ignition timing in P position. (Refer to section F2.)

LINE PRESSURE TEST
Procedure



1. Start the engine.
2. Shift the selector lever to D range and read the line pressure at idle.
3. Connect the **SST** (49 B019 902) to the line pressure inspection port.

Caution

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transaxle could be damaged. Therefore, do step 5 and 6 within 5 seconds of each other.

Warning

- Slight variations in line pressure data are due to changes in ATF temperature, which are brought about by line pressure control.
The following line pressure data is for ATF temperature of 80°C {176°F}.

4. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.
5. Read the line pressure as soon as the engine speed becomes constant, then release the accelerator pedal.
6. Shift the selector to N position and let the engine at idle for 1 minute or more to cool the ATF.
7. Read the line pressure at idle and at the engine stall speed for each range in the same manner.

Specified line pressure:

| Position/ Range | Line pressure kPa {kgf/cm ² , psi} | |
|--------------------|---|----------------------------------|
| | Idle | Stall |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} |

8. Install a new square head plug in the inspection port.


Tightening torque: 5.0—9.8 N·m {50—100 kgf·cm, 44—86.7 in·lbf}

Evaluation of Line Pressure Test

| Line pressure | Possible cause |
|--------------------------------|--|
| Low pressure in every position | Worn oil pump Oil leaking from oil pump, control valve body, and/or transaxle case Pressure regulator valve sticking Pressure control solenoid malfunction Pressure modulator valve sticking Solenoid reducing valve sticking |
| Low pressure in D and 2 only | Oil leaking from hydraulic circuit of forward clutch |
| Low pressure in 1 and R only | Oil leaking from hydraulic circuit of low and reverse brake |
| Low pressure in R only | Oil leaking from hydraulic circuit of reverse clutch |
| Higher than specification | Pressure control solenoid malfunction Pressure regulator valve sticking Pressure modulator valve sticking Solenoid reducing valve sticking |

STALL TEST

Procedure



1. Start the engine.
2. Shift the selector lever to D range.

Caution

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transaxle could be damaged. Therefore, do steps 4 and 5 within 5 seconds of each other.


3. Firmly depress the brake pedal with the left foot, and gently depress the accelerator pedal with the right.
4. When the engine speed no longer increases, quickly read the engine speed and release the accelerator.
5. Shift the selector to N position and let the engine idle for 1 minute or more to cool the ATF.
6. Perform stall tests for the remaining ranges in the same manner.
 - (1) D range
 - (2) 2 range
 - (3) 1 range

Engine stall speed: 2,270—2,500 rpm

Evaluation of Stall Test

| Condition | | Possible cause | |
|-----------------------------|---|--|---|
| Above specification | In all ranges and R position | Insufficient line pressure | Worn oil pump |
| | | | Oil leaking from oil pump, control valve, and/or transaxle case |
| | | | Pressure regulator valve sticking |
| | | | Pressure control solenoid malfunction |
| | | | Pressure modulator valve sticking |
| | In forward ranges | Forward clutch slipping One-way clutch 1 slipping | |
| In D range | One-way clutch 2 slipping | | |
| In D (O/D OFF) and 2 ranges | 2-4 brake band slipping | | |
| In 1 range and R position | Low and reverse brake slipping | | |
| In R position | Low and reverse brake slipping Reverse clutch slipping Perform road test to determine whether problem is low and reverse brake or reverse clutch a) Engine breaking felt in 1 range ... Reverse clutch b) Engine breaking not felt in 1 range ... Low and reverse brake | | |
| Below specification | | Engine out of tune | |
| | | One-way clutch slipping within torque converter | |

TIME LAG TEST
Procedure



1. Start the engine.
2. Shift from N position to D range.
3. Use a stopwatch to measure the time it takes from shifting until shock is felt.
4. Shift the selector to N position and run the engine at idle speed for at least one (1) minute.
5. Do the time lag test for the following shifts in the same manner. Make three measurements for each test and average the results.
6. Perform the test for the following shifts in the same manner.
 - (1) N position → D range
 - (2) N position → D range (O/D OFF mode)
 - (3) N position → R position

Time lag: N position → D range below approx. 0.9 second
N position → R position . . . below approx. 1.1 second

Evaluation of Time Lag Test


| Condition | | Possible Cause |
|-----------------------|-------------------------|---|
| N → D shift | More than specification | Insufficient line pressure Forward clutch slipping One-way clutch 1 slipping One-way clutch 2 slipping |
| N → D (O/D OFF) shift | More than specification | Insufficient line pressure Forward clutch slipping 2-4 brake band slipping One-way clutch 1 slipping |
| N → R shift | More than specification | Insufficient line pressure Low and reverse brake slipping Reverse clutch slipping |

ROAD TEST

ROAD TEST PREPARATION

1. Before testing, check and correct the engine coolant, engine oil, and ATF levels as necessary.
2. Warm the engine thoroughly to raise the ATF temperature to operating level (60—70°C {140—158°F}).
3. Check the idle speed and ignition timing in P position. (Refer to section F2.)

SHIFT DIAGRAM



D RANGE TEST

D range (Except O/D OFF Mode)

Note

- The POWER mode and the NORMAL mode are automatically selected by the powertrain control module.

1. Shift the selector lever to D range.
2. Accelerate the vehicle with half- and wide open throttle.
3. Verify that 1→2, 2→3, and 3→4 upshifts and downshifts are obtained. The shift points must be as shown in the D range shift diagram.
4. Drive the vehicle in fourth, third, and second gears and verify that kickdown occurs for 4→3, 4→2, 4→1, 3→2, 3→1, 2→1, and that the shift points are as shown in the D range shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in fourth and third gears.
6. Drive the vehicle and verify that torque converter clutch operation is obtained. (only for NORMAL mode)

D range (O/D OFF Mode)

1. Shift the selector lever to D range and select the O/D OFF mode.
2. Accelerate the vehicle with half- and wide open throttle.
3. Verify that 1→2 and 2→3 upshifts and downshifts are obtained. The shift points must be as shown in the D range O/D OFF shift diagram.
4. Drive the vehicle in third and second gears and verify that kickdown occurs for 3→2, 3→1, 2→1, and that the shift points are as shown in the D range O/D OFF shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in third gear.
6. Drive the vehicle and verify that torque converter clutch operation is obtained. (only for NORMAL mode)

Noise and vibration

Drive the vehicle in second gear (O/D OFF) and listen closely for any out of the ordinary noise or vibration. The torque converter, drive shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift point

| Range/Mode | | Throttle condition (throttle position sensor voltage) | Shift | Vehicle speed km/h {mph} | Turbine speed (rpm) | | |
|--------------------------------|---|---|-----------------------------------|-----------------------------------|--------------------------------|----------------|-------------|
| D | O/D OFF switch OFF | POWER | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 57—63 {36—39} | 6,050—6,600 | |
| | | | | D ₂ →D ₃ | 99—107 {62—66} | 5,750—6,200 | |
| | | | | D ₃ →D ₄ | 162—172 {101—106} | 6,100—6,500 | |
| | | | Half throttle | D ₁ →D ₂ | 39—49 {25—30} | 4,150—5,150 | |
| | | | | D ₂ →D ₃ | 69—87 {43—53} | 4,050—5,000 | |
| | | | | D ₃ →D ₄ | 114—138 {71—85} | 4,300—5,150 | |
| | | Closed throttle position (0.1—1.1 V) | D ₄ →D ₁ | 11—17 {7—10} | 300—400 | | |
| | | Kickdown | D ₄ →D ₃ | 135—145 {84—89} | 3,600—3,800 | | |
| | | | D ₃ →D ₂ | 86—94 {54—58} | 3,250—3,500 | | |
| | | | D ₂ →D ₁ | 37—43 {23—26} | 2,150—2,450 | | |
| | | | NORMAL | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 57—63 {36—39} | 6,050—6,600 |
| | | | | | D ₂ →D ₃ | 99—107 {62—66} | 5,750—6,200 |
| | D ₃ →D ₄ | | | | 162—172 {101—106} | 6,100—6,500 | |
| | TCC ON (D ₄) | 162—172 {101—106} | | 6,100—6,500 | | | |
| | Half throttle | D ₁ →D ₂ | | 32—40 {20—24} | 3,400—4,200 | | |
| | | D ₂ →D ₃ | | 53—69 {33—42} | 3,100—4,000 | | |
| | | D ₃ →D ₄ | 92—119 {58—73} | 3,500—4,450 | | | |
| | | TCC ON (D ₄) | 124—148 {77—91} | 3,300—3,900 | | | |
| | Closed throttle position (0.1—1.1 V) | D ₄ →D ₁ | 11—17 {7—10} | 300—400 | | | |
| | Kickdown | D ₄ →D ₃ | 135—145 {84—89} | 3,600—3,800 | | | |
| | | D ₃ →D ₂ | 86—94 {54—58} | 3,250—3,500 | | | |
| | | D ₂ →D ₁ | 37—43 {23—26} | 2,150—2,450 | | | |
| | | O/D OFF switch ON | POWER | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 57—63 {36—39} | 6,050—6,600 |
| | | | | | D ₂ →D ₃ | 99—107 {62—66} | 5,750—6,200 |
| D ₃ →D ₄ | | | | | 162—172 {101—106} | 6,100—6,500 | |
| Half throttle | D ₁ →D ₂ | | | 39—49 {25—30} | 4,150—5,150 | | |
| | D ₂ →D ₃ | | | 69—87 {43—53} | 4,050—5,000 | | |
| | D ₃ →D ₁ | | | 11—17 {7—10} | 450—600 | | |
| Kickdown | D ₃ →D ₂ | | 86—94 {54—58} | 3,250—3,500 | | | |
| | D ₂ →D ₁ | | 37—43 {23—26} | 2,150—2,450 | | | |
| | NORMAL | | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 57—63 {36—39} | 6,050—6,600 | |
| | | | | D ₂ →D ₃ | 99—107 {62—66} | 5,750—6,200 | |
| | | | | D ₃ →D ₄ | 162—172 {101—106} | 6,100—6,500 | |
| | | | Half throttle | D ₁ →D ₂ | 32—41 {20—25} | 3,400—4,300 | |
| D ₂ →D ₃ | | 53—69 {33—42} | | 3,100—4,000 | | | |
| D ₃ →D ₁ | | 11—17 {7—10} | | 450—600 | | | |
| Kickdown | D ₃ →D ₂ | 86—94 {54—58} | 3,250—3,500 | | | | |
| | D ₂ →D ₁ | 37—43 {23—26} | 2,150—2,450 | | | | |

2 RANGE TEST

1. Shift the selector lever to 2 range.
2. Accelerate the vehicle with half- and wide open throttle, and verify that second gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.

Noise and vibration

Drive the vehicle in second gear and listen closely for any out of the ordinary noise or vibration. The torque converter, drive shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift point

| Range | Throttle condition (throttle position sensor voltage) | Shift | Vehicle speed km/h {mph} | Turbine speed (rpm) |
|-------|---|---|-----------------------------|---------------------|
| 2 | — | TCC ON (S ₃) | 105—115 {66—71} | 4,000—4,300 |
| | | D ₄ (S ₄)→S ₃ | 162—168 {101—104} | 4,300—4,400 |
| | | S ₃ →S ₂ | 98—104 {61—64} | 3,700—3,900 |

1 RANGE TEST

1. Shift the selector lever to 1 range.
2. Accelerate the vehicle with half- and wide open throttle, and verify that first gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.

Noise and vibration

Drive the vehicle in second gear and listen closely for any out of the ordinary noise or vibration. The torque converter, drive shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

Shift point





| Range | Throttle condition (throttle position sensor voltage) | Shift | Vehicle speed km/h {mph} | Turbine speed (rpm) |
|-------|---|--------------------------------|-----------------------------|---------------------|
| 1 | — | L ₂ →L ₁ | 43—49 {27—30} | 2,500—2,800 |

P POSITION TEST

Shift into P position on a gentle slope, release the brake, and verify that the vehicle does not roll.

Evaluation

| Condition | Possible Cause |
|-----------------------------------|---|
| No 1–2 up- or downshift | Stuck shift solenoid A Stuck 1–2 shift valve |
| No 2–3 up- or downshift | Stuck shift solenoid B Stuck 2–3 shift valve |
| No 3–4 up- or downshift | Stuck shift solenoid C Stuck 3–4 shift valve |
| TCC non operation shift | Stuck torque converter clutch control solenoid valve Stuck torque converter clutch control valve |
| Incorrect shift point | Misadjusted throttle position sensor Stuck shift valves |
| Excessive shift shock or slippage | Stuck accumulators Stuck or no one-way check orifice Worn clutches, brakes, or one-way clutch |
| No engine braking effect | Worn clutches or brakes |



AUTOMATIC TRANSAXLE FLUID (ATF)

ATF Inspection Level

1. Park the vehicle on level ground.
2. Apply the parking brake and position wheel chocks securely to prevent the vehicle from rolling.
3. Warm up the engine until the ATF reaches **60—70°C {140—158°F}**.
4. While depressing the brake pedal, shift the selector lever to each range (P—1), pausing momentarily in each range.
5. Shift back to P position.

Note

- In some cases it may be necessary to inspect the ATF in the cool range **15—25°C {59—77°F}** before warming up the engine.
6. Ensure that the ATF level is in the HOT (65°C) range. Add ATF to the specification, if necessary.

ATF type: Dexron® II or M-III

Condition


Determine whether the transaxle should be disassembled by noting:

1. If the ATF is muddy or varnished.
2. If the ATF smells strange or unusual.

Fluid leaks

















Check for ATF leaks of the transaxle at the points shown below and repair or replace as necessary.





1. Gaskets, O-rings, and plugs.
2. Oil hoses, oil pipes, and connections.
3. Oil cooler.



ELECTRICAL SIGNAL INSPECTION

PREPARATION SST


| | | | |
|---|--|--|--|
| <p>49 G019 901 EC-AT Tester</p>  | <p>For inspection of electrical signal</p> | <p>49 H019 902 Adapter</p>  | <p>For inspection of electrical signal</p> |
| <p>49 B019 9A1 Adapter</p>  | <p>For inspection of electrical signal</p> | <p>49 T019 904 Adapter Harness</p>  | <p>For inspection of electrical signal</p> |
| <p>49 G019 921 Panel</p>  | <p>For inspection of electrical signal</p> | <p>49 G019 901B EC-AT Tester</p>  | <p>For inspection of electrical signal</p> |
| <p>49 G019 920 Panel</p>  | <p>For inspection of electrical signal</p> | <p>49 G019 901C EC-AT Tester</p>  | <p>For inspection of electrical signal</p> |
| <p>49 T019 905 Adapter Harness</p>  | <p>For inspection of electrical signal</p> | <p>49 T019 906 Panel</p>  | <p>For inspection of electrical signal</p> |
| <p>49 G019 929 Power Harness</p>  | <p>For inspection of electrical signal</p> | <p>49 D088 008 Harness Adapter Power</p>  | <p>For inspection of electrical signal</p> |
| <p>49 T088 0A0 NGS set</p>  | <p>For inspection of electrical signal</p> | <p>49 T088 010B Program Card</p>  | <p>For inspection of electrical signal</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical signal</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical signal</p> |

| | | | |
|---|--|--|--|
| <p>49 T088 004</p> <p>NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical signal</p> | <p>49 T088 009</p> <p>Case (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical signal</p> |
| <p>49 T088 006</p> <p>Battery Hook up Adapter (Part of 49 T088 0A0)</p>  | <p>For inspection of electrical signal</p> | <p>49 T088 008</p> <p>Instruction Manual</p>  | <p>For inspection of electrical signal</p> |


ELECTRICAL SIGNAL INSPECTION

Assembly of SST


EC-AT tester (49 G019 901), adapter (49 H019 902) and adapter (49 B019 9A1)






EC-AT tester (49 G019 901B) and adapter (49 B019 9A1)



EC-AT tester (49 G019 901C)



NGS




Inspection Procedure

Caution

- Do not connect the NGS to the data link connector 2 when EC-AT tester is connected to the power-train control module. Doing so can cause incorrect test results.


When using the EC-AT tester (49 G019 901C)

1. Assemble the SST. (Refer to page K1-22.)
2. Turn the EC-AT tester select switch to the ▲ mark on the panel.
3. Turn the ignition switch and the EC-AT tester main switch to ON.
4. Check indication of the respective light or digital display in each condition, referring to the indication table on the following page.




When using the EC-AT tester (49 G019 901B)

1. Assemble the **SST**. (Refer to page K1-22.)
2. Set the EC-AT selector switch to position 3.
3. Set the EC-AT tester vehicle switch to 626/MX-6 position.
4. Set the EC-AT tester select switch to position A.
5. Turn the ignition switch and the EC-AT tester main switch to ON.
6. Check indication of the respective light or digital display in each condition, referring to the indication table on the following page.



When using the EC-AT tester (49 G019 901) and adapter unit (49 H019 902)

1. Assemble the **SST**. (Refer to page K1-21.)
2. Set the EC-AT selector switch to position 3.
3. Set the adapter unit vehicle switch to 626/MX-6 position.
4. Set the adapter unit select switch to position A.
5. Turn the ignition switch and the EC-AT tester main switch to ON.
6. Check indication of the respective light or digital display in each condition, referring to the indication table on the following page.



When using the NGS

1. Assemble the **SST (NGS)**. (Refer to page K1-23.)
2. Select the PID/DATA MONITOR AND RECORD function. (Refer to section F2.)

Indication Table
Indication table of light and digital display
EC-AT tester (49 G019 901)

| Item | | Indication | Condition | Possible cause |
|---|------------------------------|----------------------|------------------------------------|---|
| Input (Light) | | | | |
| Transaxle range switch (INHIBITOR SW) | P, N | ON | P or N position | Transaxle range switch or wiring |
| | | OFF | R position, all ranges | |
| | D | ON | D range | |
| | | OFF | Other ranges, all positions | |
| | 2 (S) | ON | 2 range | |
| | | OFF | Other ranges, all positions | |
| | 1 (L) | ON | 1 range | |
| | | OFF | Other ranges, all positions | |
| O/D OFF switch (HOLD switch) | | ON | O/D OFF switch depressed | O/D OFF switch or wiring |
| | | OFF | O/D OFF switch released | |
| Closed throttle position switch (IDLE SW) | | ON | Closed throttle position | Closed throttle position switch or wiring |
| | | OFF | Other positions | |
| Brake switch (BRAKE LIGHT SW) | | ON | Brake pedal depressed | Brake switch or wiring |
| | | OFF | Brake pedal released | |
| Input (Digital Display) | | | | |
| Throttle position sensor voltage (THROTTLE SENSOR V.) | | PCM terminal voltage | Constant | Throttle position sensor or wiring |
| VEHICLE SPEED | km/h | Vehicle speed | Vehicle moving | Vehicle speed sensor, vehicle speedometer sensor or wiring |
| DRUM SPEED | rpm | Drum speed | All the time | Input/turbine speed sensor or wiring |
| Output (Light) | | | | |
| SOLENOID VALVE | Shift solenoid A (1-2) | ON | 2GR, 3GR or 4GR | Powertrain control module, shift solenoid A or wiring |
| | | OFF | 1GR | |
| | Shift solenoid B (2-3) | ON | 1GR or 2GR | Powertrain control module, shift solenoid B or wiring |
| | | OFF | 3GR or 4GR | |
| | Shift solenoid C (3-4) | ON | 1GR, 2GR or 4GR | Powertrain control module, shift solenoid C or wiring |
| | | OFF | 3GR | |
| | TCC control (LOCKUP CONTROL) | ON | TCC operation | Powertrain control module, TCC control solenoid valve or wiring |
| | | OFF | TCC non-operation | |
| | 3-2 TIMING | ON | 1→2, 2→3, 3→4, 3→2, 3→1, 2→1 shift | Powertrain control module, 3-2 timing solenoid valve or wiring |
| | | OFF | Other than above | |
| O/D OFF indicator light (HOLD INDICATOR) | | ON | O/D OFF mode | Powertrain control module, O/D OFF indicator light or wiring |
| | | OFF | Except O/D OFF mode | |
| Output (Digital Display) | | | | |
| GEAR | 1 | First gear | — | |
| | 2 | Second gear | | |
| | 3 | Third gear | | |
| | 4 | Fourth gear | | |

EC-AT tester (49 G019 901B)

| Item | | Indication | Condition | Possible cause |
|---|------------------------------|----------------------|------------------------------------|---|
| Input (Light) | | | | |
| Transaxle range switch (INHIBITOR SW) | P, N | ON | P or N position | Transaxle range switch or wiring |
| | | OFF | R position, all ranges | |
| | D | ON | D range | |
| | | OFF | Other ranges, all positions | |
| | 2 (S) | ON | 2 range | |
| | | OFF | Other ranges, all positions | |
| | 1 (L) | ON | 1 range | |
| | | OFF | Other ranges, all positions | |
| O/D OFF switch (HOLD switch) | | ON | O/D OFF switch depressed | O/D OFF switch or wiring |
| | | OFF | O/D OFF switch released | |
| Closed throttle position switch (IDLE SW) | | ON | Closed throttle position | Closed throttle position switch or wiring |
| | | OFF | Other positions | |
| Brake switch (BRAKE LIGHT SW) | | ON | Brake pedal depressed | Brake switch or wiring |
| | | OFF | Brake pedal released | |
| Input (Digital Display) | | | | |
| Throttle position sensor voltage (THROTTLE SENSOR V.) | | PCM terminal voltage | Constant | Throttle position sensor or wiring |
| Vehicle speed | | Vehicle speed | Vehicle moving | Vehicle speed sensor, vehicle speedometer sensor or wiring |
| Turbine speed | | Drum speed | All the time | Input/turbine speed sensor or wiring |
| Output (Light) | | | | |
| SOLENOID VALVE | Shift solenoid A (1-2) | ON | 2GR, 3GR or 4GR | Powertrain control module, shift solenoid A or wiring |
| | | OFF | 1GR | |
| | Shift solenoid B (2-3) | ON | 1GR or 2GR | Powertrain control module, shift solenoid B or wiring |
| | | OFF | 3GR or 4GR | |
| | Shift solenoid C (3-4) | ON | 1GR, 2GR or 4GR | Powertrain control module, shift solenoid C or wiring |
| | | OFF | 3GR | |
| | TCC control (LOCKUP CONTROL) | ON | TCC operation | Powertrain control module, TCC control solenoid valve or wiring |
| | | OFF | TCC non-operation | |
| | 3-2 TIMING | ON | 1→2, 2→3, 3→4, 3→2, 3→1, 2→1 shift | Powertrain control module, 3-2 timing solenoid valve or wiring |
| | | OFF | Other than above | |
| HOLD indicator light (HOLD INDICATOR) | | ON | O/D OFF mode | Powertrain control module, O/D OFF indicator light or wiring |
| | | OFF | Except O/D OFF mode | |
| Output (Digital Display) | | | | |
| GEAR | 1 | | First gear | — |
| | 2 | | Second gear | |
| | 3 | | Third gear | |
| | 4 | | Fourth gear | |


EC-AT tester (49 G019 901C)


| Item | | Indication | Condition | Possible cause |
|---|------------------|--|---|---|
| Input (Light) | | | | |
| Transaxle range switch | P/N | ON | P or N position | Transaxle range switch or wiring |
| | | OFF | R position, all ranges | |
| | R | ON | R position | |
| | | OFF | Other positions, all ranges | |
| | D | ON | D range | |
| | | OFF | Other ranges, all positions | |
| | 2 (S) | ON | 2 range | |
| | | OFF | Other ranges, all positions | |
| | 1 (L) | ON | 1 range | |
| | | OFF | Other ranges, all positions | |
| HOLD/O/D OFF switch | | Bright | O/D OFF switch depressed | O/D OFF switch or wiring |
| | | Dim | O/D OFF switch released | |
| Brake switch | | ON | Brake pedal depressed | Brake switch or wiring |
| | | OFF | Brake pedal released | |
| Closed throttle position switch | | ON | Closed throttle position | Closed throttle position switch or wiring |
| | | OFF | Other position | |
| 4GR INHIBIT SIGNAL | | ON | RESUME/ACCEL switch OFF and vehicle speed kept at preset speed | ASC control module or wiring |
| | | OFF | RESUME/ACCEL switch ON or vehicle speed 8km/h {5 mph} lower than preset speed | |
| Input (Digital Display) | | | | |
| Throttle position sensor | (V) | PCM terminal voltage | Constant | Throttle position sensor or wiring |
| Vehicle speed | (km/h) | Vehicle speed | Vehicle moving | Vehicle speed sensor, vehicle speedometer sensor or wiring |
| Turbine speed | (rpm) | Drum speed | All the time | Input/turbine speed sensor or wiring |
| Transaxle fluid temperature sensor (TFT SENSOR) | (V) | PCM terminal voltage | ATF temperature | Transaxle fluid temperature sensor or wiring |
| Output (Light) | | | | |
| SOLENOID VALVE | Shift solenoid A | ON | 2GR, 3GR or 4GR | Powertrain control module, shift solenoid A or wiring |
| | | OFF | 1GR | |
| | Shift solenoid B | ON | 1GR or 2GR | Powertrain control module, shift solenoid B or wiring |
| | | OFF | 3GR or 4GR | |
| | Shift solenoid C | ON | 1GR, 2GR or 4GR | Powertrain control module, shift solenoid C or wiring |
| | | OFF | 3GR | |
| | TCC control | ON | TCC operation | Powertrain control module, TCC control solenoid valve or wiring |
| | | OFF | TCC non-operation | |
| | 3-2 timing | ON | 1→2, 2→3, 3→4, 3→2, 3→1, 2→1 shift | Powertrain control module, 3-2 timing solenoid valve or wiring |
| | | OFF | Other than above | |
| | TCC | Bright | IG SW ON | Powertrain control module, TCC solenoid valve or wiring |
| | | Dim | TCC slip operation | |
| Pressure control | ON (Bright↔Dim) | While driving (Accelerator pedal released↔depressed) | Powertrain control module, pressure control solenoid wiring | |
| HOLD/O/D OFF INDICATOR LIGHT | | ON | O/D OFF mode | Powertrain control module, O/D OFF indicator light or wiring |
| | | OFF | Except O/D OFF mode | |
| Output (Digital Display) | | | | |
| Gear Position | 1 | First gear | — | |
| | 2 | Second gear | | |
| | 3 | Third gear | | |
| | 4 | Fourth gear | | |

ELECTRICAL SYSTEM COMPONENTS

PREPARATION

SST

| | |
|--|---|
| <p>49 G019 031</p> <p>Wrench</p>  | <p>For disassembly / assembly of transaxle fluid temperature sensor</p> |
|--|---|




O/D OFF SWITCH

Inspection

Inspection of operation

1. Turn the ignition switch from OFF to ON.
2. Verify that the O/D OFF indicator is not illuminated. Depress the O/D OFF switch and verify that the O/D OFF indicator light illuminates.
3. If not as specified, check the terminal voltage of the O/D OFF switch.



Inspection of voltage


1. Remove the front console.
2. Turn the ignition switch to ON.
3. Measure voltage at the O/D OFF switch connector terminals.

B+: Battery positive voltage

| Position | | Connector terminal | |
|-----------|-----|--------------------|---|
| | | A | B |
| Normal | (V) | B+ | 0 |
| Depressed | (V) | 0 | 0 |

(V): Voltage

4. If not as specified, check the continuity of the O/D OFF switch.

**Inspection of continuity**

1. Disconnect the negative battery cable.
2. Disconnect the O/D OFF switch connector.
3. Check continuity of the switch.

| Position | Terminal | |
|-----------|----------|-----|
| | A | B |
| Normal | | |
| Depressed | ○—○ | ○—○ |

○—○: Continuity

4. If not as specified, replace the selector lever knob assembly. (Refer to below.)
5. If the switch is OK, check the wiring harness. (O/D OFF switch—powertrain control module, O/D OFF switch—Body ground.)
6. Install the front console.
7. Connect the negative battery cable.


Replacement

1. Disconnect the negative battery cable.
2. Remove the front console.
3. Remove the indicator panel installation screws.
4. Disconnect the connector and remove the O/D OFF switch terminals.
5. Remove the selector lever knob assembly.
6. Install a new selector lever knob assembly.


Tightening torque:

2.0—2.9 N·m {20—30 kgf·cm, 18—26 in·lbf}

7. Install the O/D OFF switch terminals and connect the connector.
8. Install the indicator panel installation screws. (Refer to page K1-171.)
9. Install the front console.
10. Connect the negative battery cable.

**TRANSAXLE RANGE SWITCH****Inspection****Inspection of operation**

1. Verify that the starter operates only with the ignition switch at the START position and the selector lever in P and N positions.
2. Verify that the back-up lights illuminate when shifted to R position with the ignition switch in the ON position.
3. Check the transaxle range switch if not as specified.



Inspection of continuity

1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh-air duct, and air cleaner assembly.
3. Disconnect the transaxle range switch connector.
4. Check continuity of the transaxle range switch.

| Position/ Range | Connector terminal | | | | | | | | |
|--------------------|--------------------|---|---|---|---|---|---|---|---|
| | A | B | C | D | E | F | G | H | I |
| P | ○ | | | | ○ | | | | |
| R | ○ | | | ○ | | | | | |
| N | ○ | | | | | | | ○ | |
| D | ○ | ○ | | | | | | | |
| 2 | ○ | | | | | | ○ | | |
| 1 | ○ | | ○ | | | | | | |

○—○: Continuity

5. If not as specified, replace or adjust the transaxle range switch.
6. Connect the transaxle range switch connector.
7. Install the resonance chamber, fresh-air duct, and air cleaner assembly.
8. Connect the negative battery cable.

Replacement

1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh-air duct, and air cleaner assembly.
3. Disconnect the transaxle range switch connector.
4. Remove the clip.
5. Remove the selector cable in the order shown in the figure.
 - ① Disconnect the selector cable from the manual shaft lever.
 - ② Pull out the selector cable from the cable bracket and remove it.
6. Remove the manual shaft nut.
7. Remove the lock-washer and lever.
8. Remove the transaxle range switch.
9. Rotate the manual shaft to N position.
10. Turn the transaxle range switch so that the neutral mark is in line with the flat, straight surfaces on either side of the manual shaft.
11. Hand tighten the transaxle range switch bolts.
12. Verify that there is continuity between terminals A and H of the transaxle range switch connector.
13. Tighten the transaxle range switch mounting bolts.




Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

14. Install the lever and spring washer.
15. Tighten the manual shaft nut by using a torque wrench.


Tightening torque:

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}





16. Verify that the selector lever range position and transaxle range switch are aligned; then connect the selector cable and install a new spring pin and clip.
17. Check continuity of the transaxle range switch. (Refer to page K1-30.)
18. Connect the transaxle range switch connector.
19. Install the air cleaner assembly, fresh-air duct, and resonance chamber.
20. Connect the negative battery cable.
21. Check operation of the transaxle range switch. (Refer to page K1-29.)




Adjustment


1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh-air duct, and air cleaner assembly.
3. Remove the spring pin and clip and disconnect the selector cable.
4. Rotate the manual shaft to N position.
5. Disconnect the transaxle range switch connector.
6. Loosen the transaxle range switch mounting bolts.
7. Connect an ohmmeter between terminals (A) and (H).
8. Adjust the switch to the point where there is continuity between the terminals.
9. Tighten the transaxle range switch mounting bolts.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



10. Verify that the selector lever range position and transaxle range switch are aligned.
11. Connect the transaxle range switch connector.
12. Connect the selector cable and install a new spring pin and clip.
13. Install the air cleaner assembly, fresh-air duct, and resonance chamber.




TRANSAXLE FLUID TEMPERATURE SENSOR


Inspection

1. Refer to "Replacement" below for removal of the transaxle fluid temperature sensor.
2. Place the transaxle fluid temperature sensor in ATF with a thermometer as shown and heat the ATF gradually.
3. Measure resistance between the terminals of the transaxle fluid temperature sensor.

| ATF temperature °C {°F} | Resistance (kΩ) |
|-------------------------|-----------------|
| -20 {-4} | 13.47—17.17 |
| 0 {32} | 5.445—6.678 |
| 20 {68} | 2.441—2.894 |
| 40 {104} | 1.193—1.374 |
| 60 {140} | 0.6284—0.7048 |
| 80 {176} | 0.3527—0.3865 |
| 100 {212} | 0.2091—0.2245 |
| 120 {248} | 0.1301—0.1372 |
| 130 {266} | 0.1044—0.1090 |



4. If not correct, replace the transaxle fluid temperature sensor.
5. Refer to "Replacement" for installation of the transaxle fluid temperature sensor.




Replacement

1. Remove the control valve body cover. (Refer to page K1-125.)
2. Disconnect the transaxle fluid temperature sensor connector.
3. Remove the transaxle fluid temperature sensor by using the **SST**.
4. Install a new transaxle fluid temperature sensor by using the **SST**.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

5. Connect the transaxle fluid temperature sensor connector.
6. Install the control valve body cover. (Refer to page K1-125.)
7. Carry out the line pressure test. (Refer to page K1-11.)



INPUT/TURBINE SPEED SENSOR

Inspection

Inspection of resistance

1. Refer to "Replacement" below for disconnection of the input/turbine speed sensor connector.
2. Measure resistance between the terminals of the input/turbine speed sensor.


Resistance: 253—604 Ω


(ATF temperature: -40—160°C {-40—320°F})

3. If not correct, replace the input/turbine speed sensor.
4. Refer to "Replacement" for connection of the input/turbine speed sensor connector.

Inspection of wave form

1. Connect the oscilloscope to the powertrain control module at terminals 2P and 2T.
2. Inspect the wave form as shown in the figure.






Replacement

1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh-air duct, and air cleaner assembly.
3. Remove the fuel filter mounting nuts.
4. Disconnect the input/turbine speed sensor connector.
5. Remove the input/turbine speed sensor.
6. Apply ATF to a new O-ring and install it on a new input/turbine speed sensor.
7. Install the input/turbine speed sensor.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

8. Connect the input/turbine speed sensor connector.
9. Install the fuel filter mounting nuts.
10. Install the resonance chamber, fresh-air duct, and air cleaner assembly.
11. Connect the negative battery cable.




VEHICLE SPEEDOMETER SENSOR

Inspection

Inspection of voltage

1. Remove the vehicle speedometer sensor.




2. Measure the voltage between terminals of the vehicle speedometer sensor while rotating the driven gear.


| Meter needle | Action |
|-------------------------|---|
| Moves slightly under 5V | Repair wiring harness (Instrument cluster—Vehicle speedometer sensor) |
| Does not move | Replace vehicle speedometer sensor |

3. Install the vehicle speedometer sensor.

Inspection of wave form

1. Connect the oscilloscope to the powertrain control module at terminal 1C.
2. Inspect the wave form as shown in the figure.






Replacement

1. Disconnect the negative battery cable.
2. Remove the air cleaner assembly, battery and battery carrier.
3. Disconnect the vehicle speedometer sensor connector.
4. Remove the vehicle speedometer sensor.
5. Apply ATF to a new O-ring and install it on a new vehicle speedometer sensor.
6. Install the vehicle speedometer sensor.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}

7. Connect the vehicle speedometer sensor connector.
8. Install the battery, battery carrier, and air cleaner assembly.
9. Connect the negative battery cable.



BRAKE SWITCH

Inspection


Inspection of voltage

1. Turn the ignition switch to ON.
2. Measure voltage at the brake switch connector.

B+: Battery positive voltage

| Condition | Connector terminal (V) | |
|-----------------|------------------------|---|
| | A | B |
| Pedal depressed | B+ | 0 |
| Pedal released | 0 | 0 |

(V): Voltage



3. If not as specified, check the wiring harness (Stop fuse—Brake switch, Brake switch—Powertrain control module) and the continuity of the switch.


Inspection of continuity

1. Disconnect the negative battery cable.
2. Disconnect the brake switch connector.
3. Check continuity between terminals A and B of the switch.

| Condition | Terminal | |
|-----------------|----------|---|
| | A | B |
| Pedal depressed | | |
| Pedal released | ○ | ○ |

○—○: Continuity

4. If not as specified, replace the brake switch.
5. Connect the brake switch connector.
6. Connect the negative battery cable.



SOLENOID VALVES

Inspection

Inspection of resistance

1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh-air duct and air cleaner assembly.
3. Disconnect the solenoid valve connector.
4. Measure the resistance between terminals A through G and a ground.




ATF temperature: -40—160°C (-40—320°F)

| Terminal | Solenoid valve | Resistance (Ω) |
|----------|---------------------------------|----------------|
| A | Shift solenoid A | 11—27 |
| B | Shift solenoid B | 11—27 |
| C | Shift solenoid C | 11—27 |
| D | Torque converter clutch control | 11—27 |
| E | 3-2 timing | 11—27 |
| F | Torque converter clutch | 9—18 |
| G | Pressure control | 9—18 |

5. If not correct, check the wiring harness or replace the solenoid valve(s), if necessary.
6. Connect the solenoid valve connector.
7. Install the resonance chamber, fresh-air duct and air cleaner assembly.
8. Connect the negative battery cable.



Inspection of wave form

1. Connect the oscilloscope to the powertrain control module at terminals 2D and 2H.
2. Inspect the wave form as shown in the figure.



Inspection of operation

1. Disconnect the negative battery cable.
2. Disconnect the solenoid valve connector.
3. Apply battery voltage to each terminal of A—G.
4. Verify that each control valve operates with a “click”.
5. If the “click” is not heard, replace the solenoid valve.



Inspection of output duty Pressure control solenoid

1. Connect the (+) terminal of a dwell meter to terminal 2H at the powertrain control module and the (-) terminal to a ground.
Set the dwell meter selector to the 4 cylinder position.
2. Engage the parking brake and use wheel chocks at the front and rear of the wheels.
3. Start the engine.
4. Depress the brake pedal firmly.
5. Shift the selector lever to D range.

Note

- The dwell meter indicates the OFF duty ratio.

6. Check the duty ratio by depressing and releasing the accelerator pedal.


| Throttle opening | Duty ratio (ON %) |
|--------------------------------|-------------------|
| Closed throttle position (0/8) | Approx. 67 |
| Wide open throttle (8/8) | Approx. 23 |

Note

- The relationship between the dwell angle (°) and duty ratio (%) is as follows:

| | | | | | | |
|-----------------|---|----|----|----|----|-----|
| Dwell angle (°) | 0 | 18 | 36 | 54 | 72 | 90 |
| Duty ratio (%) | 0 | 20 | 40 | 60 | 80 | 100 |

7. Depress the accelerator pedal slowly and verify that the duty ratio changes as shown in the graph.
8. If not as specified, check the powertrain control module (Refer to section F2.) and pressure control solenoid. (Refer to page K1-35.)



Torque converter clutch solenoid

1. Connect the (+) terminal of a dwell meter to terminal 2D of the powertrain control module and the (-) terminal to a ground.
2. Drive the vehicle.

Note

- The dwell meter indicates the OFF duty ratio.


3. Check the duty ratio in the torque converter clutch condition.

| Condition | Duty ratio (ON %) |
|---|--------------------|
| Slip TCC operation | Approx. 65 |
| Except slip TCC operation | 0 |
| TCC operation ↔ Slip TCC operation ↔ Complete TCC | Approx. 0 ↔ 65 ↔ 0 |

Note

- See above note for dwell and duty relationship.

4. If not as specified, check the powertrain control module. (Refer to section F2.), and torque converter clutch solenoid valve. (Refer to page K1-35.)


**Replacement**

1. Remove the control valve body. (Refer to page K1-125.)
2. Remove the solenoid valve(s).
3. Apply ATF to a new O-ring and install it on the solenoid valve.
4. Install the solenoid valve in the control valve body.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}

5. Install the control valve body. (Refer to page K1-125.)
6. Carry out the time lag test and line pressure test. (Refer to page K1-10.)
7. Carry out the road test. (Refer to page K1-15.)


**O/D OFF INDICATOR LIGHT****Inspection****Inspection of operation**

1. Turn the ignition switch from OFF to ON.

Note

- The O/D OFF indicator light will flash if a malfunction exists in any of the EC-AT system components.


2. Verify that the O/D OFF indicator light is not illuminated.
3. Depress the switch and verify that the O/D OFF indicator illuminates.
4. If the O/D OFF switch function is not as specified, after checking the O/D OFF switch (Refer to page K1-28.), check the terminal voltage of the O/D OFF indicator light.

**Inspection of voltage**

1. Remove the instrument cluster. (Refer to Body Electrical Troubleshooting segment section C1.)
2. Turn the ignition switch to ON.
3. Measure voltage between terminal 2G and a ground.

B+: Battery positive voltage

| Voltage | Action |
|---------|---|
| B+ | Go to next step |
| Other | <ul style="list-style-type: none"> • Replace METER fuse • Repair wiring harness (METER fuse—Instrument cluster) |



Inspection of continuity


1. Disconnect the negative battery cable.
2. Disconnect the instrument cluster connector.
3. Check continuity between terminal 1N and powertrain control module terminal 1B.

| Terminals | Continuity |
|-----------|------------|
| 1N—1B | Yes |

4. If not correct, check the wiring harness (instrument cluster—powertrain control module).
5. If correct, go to the next step.
6. Check continuity between terminals 2G and 1N.

| Terminals | Continuity |
|-----------|------------|
| 2G—1N | Yes |

7. If not correct, replace the instrument cluster or bulb.
8. Install the instrument cluster. (Refer to Body Electrical Troubleshooting segment section C1.)
9. Connect the negative battery cable.



POWERTRAIN CONTROL MODULE Inspection

Note









- As the powertrain control module is integrated, refer to section F2 for the terminal voltage.

TRANSAXLE

TRANSAXLE UNIT (REMOVAL)

Preparation

SST


| | | | |
|---|-----------------------------------|---|-----------------------------------|
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G030 455</p> <p>Holder, diff. side gear</p>  | <p>For holding side gear</p> |
| <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 T028 3A0</p> <p>Puller, ball joint</p>  | <p>For removal of tie rod end</p> |
| <p>49 T028 303</p> <p>Body (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> | <p>49 T028 304</p> <p>Attachment (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> |


Removal

The oil pan could contain small chips, shavings, and other particles helpful in checking the condition of the transaxle and diagnosing certain problems.


To ensure that all foreign particles stay in the oil pan, make sure that the transaxle is never tipped completely over while the oil pan is still installed.

1. Disconnect the negative battery cable.
2. Raise the vehicle on a vehicle hoist.
3. Drain the ATF into a container.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. After removal, remove the oil pan to check the condition of the transaxle.






- | | |
|--|-------------------------------|
| 1. Battery | 23. Transverse member |
| 2. Battery carrier | 24. Exhaust pipe |
| 3. Fresh-air duct | 25. Lower arm |
| 4. Air cleaner assembly | Removal Note page K1-42 |
| 5. Clip | 26. Tie-rod end |
| 6. Selector cable | Removal Note page K1-42 |
| Removal Note page K1-42 | 27. Stabilizer control link |
| 7. Bolt | 28. Drive shaft |
| 8. Transaxle range switch connector | Removal Note page K1-42 |
| 9. Solenoid valve connector | 29. Joint shaft |
| 10. Harness bracket | 30. No.5 engine mount rubber |
| 11. Ground | 31. No.1 engine mount bolts |
| 12. Nut | 32. Engine mounting member |
| 13. Fuel filter mounting bolts | Removal Note page K1-43 |
| 14. Vehicle speedometer sensor connector | 33. Drive shaft |
| 15. Input/turbine speed sensor connector | Removal Note page K1-42 |
| 16. Ground | 34. Undercover |
| 17. Bolt | 35. Torque converter nuts |
| 18. Engine mount stay | Removal Note page K1-43 |
| 19. Starter | 36. No.4 engine mount |
| 20. Oil hose | 37. Transaxle |
| 21. Wheel and tire | Removal Note page K1-44 |
| 22. Splash shield | 38. No.2 engine mount |



Removal note


Selector cable

1. Disconnect the selector cable from the manual shaft lever.
2. Pull out the selector cable from the cable bracket and remove it.




Lower arm

1. Remove the clinch bolt from the lower arm ball joint.



2. Wrap a rag around the ball joint dust boot.
3. Pry the lower arm out of the knuckle.




Tie-rod end

Caution


- The sharp edges of the SST can slice the tie-rod end dust boot. Install the SST so that the sharp edges are between the dust boot and the knuckle.

1. Remove the cotter pin and nut.
2. Disconnect the tie-rod end from the knuckle by using the SST.




Drive shaft

1. Remove the clip.
2. Remove the ABS wheel-speed sensor harness mounting nuts.




3. Separate the drive shaft (right side) from the joint shaft by using a brass bar and a hammer.



Caution

- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when removing the drive shaft from the transaxle.

4. Separate the left-side drive shaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle, as shown in the figure.
5. Suspend the drive shaft with a rope.




6. Install the **SST** into the transaxle to hold the side gear.




Engine mounting member

1. Support the engine by using the **SST** before removing the engine mounting member.
2. Remove the engine mounting member.




Torque converter nuts

- Hold the drive plate and remove the torque converter nuts.

**Transaxle**

1. Loosen the **SST** (engine support) and lean the engine toward the transaxle.













2. Support the transaxle on a jack.

3. Remove the transaxle mounting bolts.

4. Remove the transaxle.

TRANSAXLE UNIT (DISASSEMBLY)

**Preparation
SST**

| | | | |
|---|--|---|--|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly of transaxle</p> | <p>49 G019 0A0 Hanger, transaxle</p>  | <p>For disassembly of transaxle</p> |
| <p>49 G019 001 Body (Part of 49 G019 0A0)</p>  | <p>For disassembly of transaxle</p> | <p>49 G019 002 Stay (Part of 49 G019 0A0)</p>  | <p>For disassembly of transaxle</p> |
| <p>49 G019 003 Bolt set (Part of 49 G019 0A0)</p>  | <p>For disassembly of transaxle</p> | <p>49 G019 0A7A Compressor set, return spring</p>  | <p>For disassembly of low and reverse brake piston</p> |
| <p>49 G019 028 Bolt (Part of 49 G019 0A7A)</p>  | <p>For disassembly of low and reverse brake piston</p> | <p>49 G019 029 Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly of low and reverse brake piston</p> |
| <p>49 G019 030 Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly of servo</p> | <p>49 FT01 361 Remover, bearing</p>  | <p>For removal of bearing race</p> |

Disassembly

Precaution


General notes:

1. Disassemble the transaxle in a clean area (dustproof work space) to prevent entry of dust into the mechanisms.
2. Inspect the individual transaxle components in accordance with the QUICK DIAGNOSIS CHART during disassembly. (Refer to page K1-196.)
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts look alike; arrange them so that they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when a clutch or brake band is burnt or when the ATF has deteriorated.

Cleaning notes:


1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents before disassembly.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and verify that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

Components




- | | |
|---|--|
| 1. Torque converter Inspection page K1-58 | 9. Oil strainer |
| 2. Oil pump shaft | 10. Control valve body cover |
| 3. ATF dipstick and oil filler tube | 11. Coupler assembly |
| 4. Input/turbine speed sensor Inspection page K1-33 | 12. Control valve body Disassembly / Inspection page K1- 97 Assembly page K1-115 On-vehicle removal / installation page K1-125 |
| 5. Transaxle range switch Inspection page K1-30 Adjustment page K1-32 | 13. Oil pump Disassembly / Inspection / Assembly page K1- 61 |
| 6. Breather hose | |
| 7. Oil pipe | |
| 8. Oil pan | |

Components (Cont'd)




- | | |
|---|---|
| <ul style="list-style-type: none"> 1. Piston stem 2. Snap ring 3. Clutch assembly Preinspection page K1-65 Disassembly / Inspection / Assembly page K1-66 4. 2-4 brake band Disassembly / Inspection / Assembly page K1-88 5. Small sun gear and one-way clutch 1 Preinspection page K1-74 Disassembly / Inspection / Assembly page K1-74 6. Anchor strut and shaft | <ul style="list-style-type: none"> 7. Band servo 8. One-way clutch 2 and carrier hub assembly Preinspection page K1-77 Disassembly / Inspection / Assembly page K1-77 9. Friction plate 10. Snap ring 11. Internal gear 12. 3-4 clutch Preinspection page K1-79 Disassembly / Inspection / Assembly page K1-80 13. Turbine shaft |
|---|---|

Components (Cont'd)




- | | |
|------------------------------------|---|
| 1. Transaxle case | 4. Plug, packing, spring, and detent ball |
| 2. Output shell | 5. Bracket |
| 3. Low and reverse brake | 6. Manual shaft and manual plate |
| Preinspection page K1-83 | 7. Actuator support |
| Disassembly / Inspection / | 8. Parking assist lever |
| Assembly page K1-84 | 9. Parking pawl |

Components (Cont'd)




- | | |
|---|---|
| <p>1. Differential Preinspection page K1-127 Disassembly / Inspection / Assembly page K1-128</p> <p>2. 2-3 accumulator Disassembly / Inspection / Assembly page K1- 59</p> <p>3. Orifice check valve spring Inspection page K1- 59</p> <p>4. Orifice check valve</p> <p>5. Roll pin</p> <p>6. Baffle plate</p> <p>7. Bearing housing</p> <p>8. Idler gear Disassembly / Inspection / Assembly page K1- 90</p> | <p>9. Output gear Disassembly / Inspection / Assembly page K1- 93</p> <p>10. Bearing cover assembly Disassembly / Inspection / Assembly page K1- 95</p> <p>11. Bearing race</p> <p>12. Adjustment shim (bearing preload) Adjustment page K1-131</p> <p>13. Oil seal On-vehicle replacement page K1- 96</p> <p>14. Converter housing</p> |
|---|---|




Disassembly procedure

Note


- The oil pan could contain small chips, shavings, and other particles helpful in checking the condition of the transaxle and diagnosing certain problems. To ensure that all foreign particles stay in the oil pan, make sure that the transaxle is never tipped completely over while the oil pan is still installed.
- Remove the torque converter, and immediately turn it so that the hole faces upward. This will help to keep any remaining fluid from spilling.




1. Remove the torque converter from the converter housing.
2. Pull out the oil pump shaft by hand.




3. Remove the ATF dipstick and oil filler tube.
4. Remove the O-ring from the oil filler tube.
5. Remove the breather hose.



6. Assemble the **SST**.




7. Attach suitable hangers to the oil pump as shown.




Warning


- Although the stand has a self-locking brake system, there is a possibility that the brake may not hold when the transaxle is held in a lopsided position on the stand. This would cause the transmission to turn suddenly, causing serious injury. Never keep the transaxle tilted to one side. Always hold the rotating handle firmly when turning the transaxle.




8. Lift the transaxle and mount it on the SST.



9. Remove the input/turbine speed sensor, and transaxle range switch.
10. Remove the O-ring from the input/turbine speed sensor.




11. Remove the connector bolt.
12. Remove the packings, oil pipe, spring, and steel ball.




13. Remove the oil pan and gasket. Examine any material found in the pan or on the magnet to determine the condition of the transaxle.

| | |
|----------------------------------|--------------------------------------|
| Clutch facing material | Drive plate and brake band wear |
| Steel (magnetic) | Bearing, gear, and driven plate wear |
| Aluminum (nonmagnetic) . . | Bushing of cast aluminum part wear |


If large amounts of material are found, replace the torque converter and carefully check the transaxle for the cause.



14. Remove the oil strainer and O-ring.




15. Remove the control valve body cover and gasket.



16. Disconnect the solenoid connectors and transaxle fluid temperature sensor connector.


17. Remove the coupler assembly.

18. Remove the O-ring from the coupler assembly.




19. Loosen the indicated bolts evenly and gradually.


20. Remove the control valve body as an assembly.




21. Remove the oil pump and gasket.




22. Remove the clutch assembly.
(1) Remove the turbine shaft snap ring.




- (2) Pull the reverse and forward drum and remove the clutch assembly.




23. Remove the small sun gear and one-way clutch 1.




24. Remove the 2-4 brake band, and hold it together with a piece of wire as shown the figure.




25. Pull the anchor shaft while holding the anchor strut, then remove the strut.




26. Remove the piston stem from the band servo.




27. Remove the band servo.
 (1) Remove the snap ring by using the **SST**.
 (2) Remove the band servo and spring.




28. Remove the one-way clutch 2 and carrier hub assembly.
 (1) Remove the snap ring.




(2) Remove the one-way clutch 2 together with the carrier hub assembly.
 (3) Remove the friction plate.



29. Remove the internal gear.
 (1) Remove the snap ring.




(2) Remove the internal gear from the output shell.




30. Remove the 3-4 clutch assembly.

(1) Remove the O-ring from the turbine shaft at the converter housing side.




(2) Pull out the turbine shaft to remove the 3-4 clutch assembly.


(3) Remove the 3-4 clutch assembly.




31. Remove the bolts, and remove the transaxle case by tapping lightly with a plastic hammer.




32. Remove the output shell from the output gear.




33. Remove the manual shaft and manual plate.
 (1) Remove the plug, packing, spring, and detent ball.




- (2) Remove the bracket.




- (3) Loosen the nut and pull out the manual shaft.
 (4) Remove the nut, washer, spacer, and manual plate.




34. Remove the actuator support.




35. Remove the snap ring and remove the parking assist lever.




36. Remove the parking pawl.
- (1) Remove the snap ring.
 - (2) Pull the parking shaft, and remove the spring and parking pawl.




37. Remove the differential assembly.




38. Remove the 2-3 accumulator.
39. Remove the orifice check valve spring and orifice check valve.




40. Remove the bearing housing.
- (1) Remove the bolt indicated in the figure for access to the roll pin.
 - (2) Remove the roll pin by using a pin punch.
 - (3) Remove the baffle plate.
 - (4) Remove the bearing housing by tapping lightly with a plastic hammer.




41. Remove the idler gear and output gear by tapping out from the torque converter side.
- Support the idler gear and output gear with one hand to keep them from falling.




42. Remove the bearing cover assembly.
 - (1) Remove the converter housing from the **SST** (trans-axle hanger).
 - (2) Remove the bearing cover bolts.



- (3) Press the bearing cover assembly out of the converter housing by using a pipe (**approx. 80 mm {3.1 in} dia**). Support the bearing cover with one hand to keep them from falling.



43. Press out the bearing races by using the **SST**.



TORQUE CONVERTER

The torque converter is welded together and cannot be disassembled.

Inspection

1. Check the outer part of the converter for damage or cracks, and replace if necessary.
2. Check whether there is any rust on the pilot hub of the converter or on the boss. If there is any, remove it completely.
3. Measure the bushing of the converter boss. Replace the converter assembly if the bushing is excessively worn.


Bushing inner diameter

Standard: 53.030 mm {2.0878 in}

Maximum: 53.075 mm {2.0896 in}

Wash Inside of Converter


1. Drain any ATF remaining in the converter.
2. Pour in ATF (**approx. 0.5 L {0.5 US qt, 0.4 Imp qt}**).
3. Shake the converter to clean the inside. Pour out the ATF.
4. Pour in ATF again.
5. Shake the converter to clean the inside. Pour out the ATF.




2-3 ACCUMULATOR

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|---------------------------|-------------------------------|
| 1. Snap ring | 5. 2-3 accumulator piston |
| 2. Stopper plug | 6. 2-3 accumulator body |
| 3. O-ring | 7. Orifice check valve spring |
| 4. 2-3 accumulator spring | 8. Orifice check valve |
| Inspection | Inspection |
| below | below |



Inspection


2-3 accumulator spring

1. Measure the spring free length.

Specification

| Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|---------------------------|------------------------|--------------|--------------------------|
| 11.5 {0.453} | 77.7 {3.059} | 23.3 | 1.4 {0.055} |

2. If not as specified, replace the 2-3 accumulator spring.




Orifice check valve spring

1. Measure the spring free length.

Specification

| Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|---------------------------|------------------------|--------------|--------------------------|
| 8.0 {0.315} | 13.0 {0.512} | 3.5 | 0.4 {0.016} |

2. If not as specified, replace the orifice check valve spring.

**Assembly procedure**


1. Apply ATF to the large and small seal rings and install them onto the accumulator piston.

Seal ring inner diameter

Large seal ring: 23.6 mm {0.929 in}

Small seal ring: 14.6 mm {0.575 in}


2. Install the 2-3 accumulator piston.



3. Install the spring to the piston.
4. Install the stopper plug.
 - (1) Apply ATF to the O-ring and install it onto the stopper plug.

O-ring inner diameter: 23.7 mm {0.933 in}

- (2) Install the stopper plug.




5. Install the stopper plug into the accumulator body by applying even pressure to the perimeter of the stopper plug and accumulator piston.
6. Install the snap ring while holding in the stopper plug.


OIL PUMP

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|-----------------------------------|-----------------------------|
| 1. Bearing race | 7. Plug |
| 2. Seal ring | 8. Packing |
| 3. Oil pump cover | 9. Spring |
| Disassembly Note below | Inspection page K1-62 |
| 4. Oil pump flange | 10. Spool |
| 5. Inner rotor | Inspection page K1-62 |
| Disassembly Note page K1-62 | 11. Oil pipe |
| Inspection page K1-62 | 12. Packing |
| 6. Outer rotor | 13. Oil pump housing |
| Disassembly Note page K1-62 | Inspection page K1-62 |
| Inspection page K1-62 | |




Disassembly note
Oil pump cover

1. Loosen the mounting bolts evenly in the order shown.
2. Remove the oil pump cover from the oil pump housing.



Inner rotor, outer rotor

Mark the outer and inner rotors without scratching or denting them, and remove them from the oil pump housing.



Inspection

Oil pump housing, outer rotor, inner rotor

1. Measure the clearance between the end of the oil pump housing and the outer rotor and inner rotor at four places along their circumferences.

Clearance

Standard: 0.02—0.04 mm {0.0008—0.0015 in}

Maximum: 0.05 mm {0.0019 in}

2. If not as specified, replace the pump assembly.


3. Measure the clearance between the oil pump boss and the inner rotor.

Oil clearance

Standard: 0.040—0.115 mm {0.0016—0.0045 in}

Maximum: 0.125 mm {0.0049 in}

4. If not within the specification, replace the oil pump assembly.




Spring

1. Measure the spring free length.

Specification

| Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|---------------------------|------------------------|--------------|--------------------------|
| 13.0 {0.512} | 53.0 {2.087} | 12.0 | 1.2 {0.047} |

2. If not as specified, replace the spring.



Spool


1. Measure the spool diameter.


Outer diameter

Standard: 13.970—13.980 mm {0.5500—0.5503 in}

Minimum: 13.970 mm {0.5500 in}

2. If not as specified, replace the oil pump assembly.




**Assembly procedure**

1. Install a new packing and the oil pipe.

Tightening torque:


16—23 N·m {1.6—2.4 kgf·m, 12—17 ft·lbf}




2. Apply ATF to the spool.
3. Install the spool and spring into the oil pump housing.
4. Verify that the spool moves smoothly.
5. Install a new packing and the plug.

Tightening torque:

32—47 N·m {3.2—4.8 kgf·m, 24—34 ft·lbf}




6. Apply ATF to the outer and inner rotors and oil pump flange.
7. Align the marks and install the outer and inner rotors.
8. Install the oil pump flange.




9. Mount the oil pump cover onto the oil pump housing.
10. Tighten the bolts evenly and gradually in the order shown.

Tightening torque:

8.1—10.9 N·m {82—112 kgf·cm, 72—97 in·lbf}




11. Install the oil pump shaft and verify smooth oil pump operation.



12. Apply petroleum jelly to the new seal rings and install them onto the oil pump cover.

Seal ring inner diameter: 55.9 mm {2.20 in}









13. Apply petroleum jelly to the bearing race and secure it onto the oil pump cover.


Bearing race outer diameter: 88.0 mm {3.46 in}

CLUTCH ASSEMBLY

Preparation


SST

| | | | |
|---|---|---|---|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> | <p>49 G019 024</p> <p>Body A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of reverse clutch</p> |
| <p>49 G019 025</p> <p>Body B (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch</p> | <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> |
| <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> | <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> |

**Preinspection****Reverse, forward, coasting clutch operation**

1. Set the clutch assemblies onto the oil pump.
2. Check the clutch operation by applying compressed air through the fluid passages as shown.


Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.

**Clutch clearance****Reverse clutch**

1. Measure the clearance between the retaining plate and the drive plate. Make several measurements and calculate the average value.

Clearance: 1.5—1.8 mm {0.059—0.071 in}


2. If not as specified, replace parts as necessary.
3. Select and install the correct snap ring when assembling.

**Forward clutch**

1. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value.

Clearance: 1.0—1.2 mm {0.039—0.047 in}

2. If not as specified, replace parts as necessary.
3. Select and install the correct snap ring when assembling.

**Coasting clutch**


1. Remove the snap ring, retaining plate, drive plates, driven plates and dished plate of the forward clutch.
2. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value.

Clearance: 1.0—1.2 mm {0.039—0.047 in}


3. If not as specified, replace parts as necessary.
4. Select and install the correct snap ring when assembling.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|-----------------------------------|-----------------------------------|
| 1. Thrust bearing | 14. Outer seal |
| 2. Snap ring | 15. Inner seal |
| 3. Retaining plate | 16. Outer seal |
| 4. Drive and driven plates | 17. Seal rings |
| Inspection page K1-68 | |
| 5. Dished plate | |
| —Coasting clutch— | |
| 6. Snap ring | 18. Snap ring |
| 7. Retaining plate | 19. Retaining plate |
| 8. Drive and driven plates | 20. Drive and driven plates |
| Inspection page K1-68 | Inspection page K1-68 |
| 9. Dished plate | 21. Snap ring |
| 10. Snap ring | Disassembly Note page K1-67 |
| Disassembly Note page K1-67 | 22. Return spring stopper |
| 11. Spring and retainer assembly | 23. Piston return spring |
| Inspection page K1-68 | 24. Reverse piston |
| 12. Coasting clutch drum | Disassembly Note page K1-68 |
| Disassembly Note page K1-67 | Inspection page K1-69 |
| 13. Coasting piston | 25. Seal rings (inner and outer) |
| Disassembly Note page K1-67 | 26. Reverse and forward drum |
| Inspection page K1-68 | |




Disassembly note
Snap ring (Coasting clutch)

Caution

- Depress the piston return spring only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.


1. Install the **SST** in the coasting clutch drum as shown.
2. Compress the spring and retainer assembly.
3. Remove the snap ring.
4. Remove the **SST**, and remove the spring and retainer assembly.



Coasting clutch drum

1. Set the reverse and forward drum onto the oil pump.
2. Remove the coasting clutch drum from the reverse and forward drum by applying compressed air through the fluid passage.


Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.



Coasting piston

Remove the coasting clutch piston from the coasting clutch drum by applying compressed air through the fluid passage.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.




Snap ring (Reverse clutch)


Caution

- Depress the piston return spring only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.


1. Install the **SST** in the reverse and forward drum as shown.
2. Compress the piston return spring.



3. Remove one end of the snap ring from the groove with snap ring pliers.




4. Remove the **SST** from the reverse and forward drum.
5. Remove the snap ring by using a screw driver.



Reverse piston

1. Place the reverse and forward drum on the oil pump.
2. Remove the reverse piston by applying compressed air through the fluid passage.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.




Inspection Drive plates

1. Measure the facing thickness in three places and calculate the average value.

Standard: 1.6 mm {0.063 in}

Minimum: 1.4 mm {0.055 in}

2. If not within the specification, replace the drive plates.




Spring and retainer assembly

1. Measure the free length of the spring assembly and check for deformation.

Free length: 20.6 mm {0.811 in}

2. If not within the specification, replace the spring and retainer assembly.




Coasting piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is airflow when applying compressed air through the oil hole on the return spring side.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.


3. Replace the coasting piston if damaged or malfunctioning.

**Reverse piston**

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is airflow when applying compressed air through the oil hole on the return spring side.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.

3. Replace the reverse piston if damaged or malfunctioning.


**Assembly procedure****Reverse clutch**

1. Install the reverse piston.
 - (1) Apply ATF to the inner and outer faces of the seals and install them to the reverse piston.


Seal ring inner diameter

Inner seal: 160.5 mm {6.319 in}


Outer seal: 188.0 mm {7.402 in}




- (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the reverse and forward drum.
- (3) Install the reverse piston by pushing evenly around the circumference, being careful not to damage the seal rings.



2. Install the piston return spring with the tabs facing upward away from the reverse piston.
3. Install the return spring stopper with the step facing upward.



4. Install the snap ring half-way down the reverse and forward drum as shown.




5. Install the **SST** on the reverse and forward drum.

Caution

- **Depress the piston return spring only enough to install the snap ring. Overpressing will damage the retainer assembly edges.**

6. Compress the piston return spring assembly.
7. Install the snap ring by using a screwdriver.
8. Remove the **SST**.




9. Install the drive and driven plates in the following order. Driven-Drive-Driven-Drive.
10. Install the retaining plate.
11. Install the snap ring by using a screwdriver.
12. Measure the reverse clutch clearance.
 - (1) Measure the clearance between the retaining plate and the drive plate.
 - (2) If the clearance is not within the specification, adjust it by selecting a proper snap ring from below.

Reverse clutch clearance:

1.5—1.8 mm {0.059—0.071 in}

Snap ring sizes

| | | | mm {in} |
|-------------|-------------|-------------|---------|
| 2.0 {0.079} | 2.2 {0.087} | 2.4 {0.094} | |
| 2.6 {0.102} | 2.8 {0.110} | — | |



Coasting clutch



1. Install the coasting clutch drum.
 - (1) Apply ATF to the inner and outer faces of the seals, and install them onto the coasting clutch drum.


Seal ring inner diameter

Inner seal: 71.02 mm {2.796 in}

Outer seal: 137.0 mm {5.394 in}


- (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the reverse and forward drum.
- (3) Install the coasting clutch drum into the reverse and forward drum as shown.






2. Install the coasting piston.
 (1) Apply ATF to the inner and outer faces of the seals and install them onto the coasting piston.


Seal ring inner diameter
Outer seal: 122.0 mm {4.803 in}




- (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the coasting clutch drum.



- (3) Install the coasting piston by pushing evenly around the circumference being careful not to damage the outer seal.



3. Install the spring and retainer assembly.




4. Install the **SST** in the coasting clutch.

Caution


- Depress the piston return spring only enough to install the snap ring. Overpressing will damage the retainer assembly edges.

5. Compress the spring and retainer assembly.
 6. Install the snap ring.
 7. Remove the **SST**.




8. Install the dished plate with the dished side upward.
9. Install the drive and driven plates in the following order.
Driven-Drive-Driven-Driven-Drive
10. Install the retaining plate.
11. Install the coasting clutch snap ring in the direction shown in the figure.
12. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within specification, adjust it by selecting a proper snap ring from below.

Coasting clutch clearance:
1.0—1.2 mm {0.039—0.047 in}




Snap ring sizes

| | | | mm {in} |
|--------------|--------------|--------------|---------|
| 1.50 {0.059} | 1.65 {0.065} | 1.80 {0.071} | |
| 1.95 {0.077} | 2.10 {0.083} | 2.25 {0.089} | |




Forward clutch

1. Install the dished plate with the dished side downward.
2. Install the drive and driven plates in the following order.
Driven-Drive-Driven-Drive-Driven-Drive.




3. Install the retaining plate.
4. Install the snap ring in the direction shown in the figure.



5. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within specification, adjust it by selecting a proper snap ring from below.

Forward clutch clearance:

1.0—1.2 mm {0.039—0.047 in}




Snap ring sizes

| | | | mm {in} |
|--------------|--------------|--------------|---------|
| 2.00 {0.079} | 2.15 {0.085} | 2.30 {0.091} | |
| 2.45 {0.097} | 2.60 {0.102} | 2.75 {0.108} | |

6. Check the clutch operation as follows.
 - (1) Set the clutch assembly onto the oil pump.
 - (2) Check the clutch operation by applying compressed air through the fluid passages shown.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.


7. Apply petroleum jelly to the thrust bearings, and secure them on the reverse and forward drum.



Thrust bearing outer diameter

Oil pump side: 86.0 mm {3.39 in}

**Small sun gear and one-way clutch side:
56.1 mm {2.21 in}**



SMALL SUN GEAR AND ONE-WAY CLUTCH 1


Preinspection

One-way clutch 1 operation


While holding the one-way clutch outer race, verify that the one-way clutch inner race rotates smoothly when turned counterclockwise and locks when turned clockwise. If not as specified, replace the one-way clutch 1.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Thrust bearing 2. Snap ring 3. One-way clutch inner race 4. Thrust bearing 5. Snap ring 6. Small sun gear Inspection page K1-75 | <ol style="list-style-type: none"> 7. Sun gear drum Inspection page K1-75 8. Thrust bearing 9. One-way clutch outer race 10. One-way clutch 1 |
|---|---|

**Inspection****Small sun gear, sun gear drum**


1. Measure the small sun gear and sun gear drum inner diameters.

Inner diameter


Small sun gear: 24.0 mm {0.945 in} max.

Sun gear drum: 33.4 mm {1.31 in} max.

2. If not within the specification, replace the small sun gear or sun gear drum.


**Assembly procedure**

1. Install the small sun gear into the sun gear drum.
2. Install a new snap ring.




3. Apply petroleum jelly to the thrust bearing and secure it to the one-way clutch inner race.

Thrust bearing outer diameter: 62.5 mm {2.46 in}




4. Verify that the spring cage of the one-way clutch faces toward the outer race as shown.
5. Apply petroleum jelly to the thrust bearing and secure it to the one-way clutch 1.


Thrust bearing outer diameter: 62.5 mm {2.46 in}




6. Apply ATF to the one-way clutch and one-way clutch outer race.
7. Install the one-way clutch inner race into the one-way clutch outer race by turning the inner race counterclockwise. If the one-way clutch inner race turns or locks in both directions, replace the one-way clutch 1.
8. Apply ATF to the one-way clutch inner race.
9. Hold the one-way clutch outer race. Verify that the inner race rotates smoothly in the counterclockwise direction only. If the one-way clutch inner race turns only clockwise, the spring cage could be installed upside down.




10. Align the splines of the one-way clutch inner race with the splines on the small sun gear hub as shown in the figure.



11. Install a new snap ring.




12. Verify that when the small sun gear is held, the one-way clutch outer race turns smoothly and only clockwise.



13. Apply petroleum jelly to the thrust bearing and secure it to the sun gear drum.

Thrust bearing outer diameter: 72.0 mm {2.83 in}




ONE-WAY CLUTCH 2 AND CARRIER HUB ASSEMBLY Preinspection


While holding the one-way clutch inner race, verify that the one-way clutch rotates smoothly when turned clockwise and locks when turned counterclockwise. If not as specified, replace the one-way clutch 2.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. One-way clutch 2 Inspection below 2. Bearing race 3. Snap ring | <ol style="list-style-type: none"> 4. Carrier hub assembly Inspection page K1-78 5. Inner race (low and reverse hub) |
|---|--|



Inspection One-way clutch 2

1. Inspect for detached rollers, damage, or wear.
2. Install the inner race into the one-way clutch 2, and verify that the one-way clutch 2 turns smoothly and only clockwise. If the one-way clutch 2 turns or locks in both directions, replace the one-way clutch 2. If the one-way clutch 2 turns only counterclockwise, it is installed upside down.




Carrier hub assembly

Check for the following and repair or replace as necessary.

- (1) Damaged or worn gear and operation.
- (2) Clearance between pinion washers and planetary carrier.


Clearance: 0.2—0.7 mm {0.008—0.027 in}

- (3) Replace the carrier hub assembly if necessary.




Assembly procedure

1. Install the carrier hub assembly to the inner race.



2. Install the snap ring.









3. Apply petroleum jelly to the bearing races and the thrust bearing.
4. Install the tabs of the bearing races into the alignment holes on each side of the one-way clutch/carrier hub assembly.
5. Install the thrust bearing to the sun gear drum side of the one-way clutch and carrier hub assembly.


Bearing race outer diameter

Sun gear drum side: 72.0 mm {2.83 in}

3-4 clutch side: 57.0 mm {2.24 in}

**3-4 CLUTCH
Preparation
SST**

| | | | |
|---|---|--|---|
| <p>49 G019 0A7A Compressor set, return spring</p>  | <p>For disassembly / assembly of 3-4 clutch</p> | <p>49 G019 025 Body B (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of 3-4 clutch</p> |
| <p>49 G019 026 Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of 3-4 clutch</p> | <p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of 3-4 clutch</p> |
| <p>49 G019 029 Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of 3-4 clutch</p> | <p>49 G019 012 Leak checker</p>  | <p>For clutch operation inspection</p> |




Preinspection

3-4 clutch operation

1. Remove the thrust bearing.
2. Install the **SST** to the 3-4 clutch.
3. Check the 3-4 clutch operation by applying compressed air as shown.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.




Clearance

1. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within specification, replace parts as necessary.
2. Select and install the correct retaining plate when assembling.


Clearance: 1.3—1.5 mm {0.051—0.059 in}

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|------------------------------|-----------------------------------|
| 1. Thrust bearing | 8. 3-4 clutch piston |
| 2. Snap ring | Disassembly Note page K1-81 |
| 3. Retaining plate | Inspection page K1-81 |
| 4. Drive and driven plates | 9. Outer seal |
| Inspection page K1-81 | 10. Inner seal |
| 5. Snap ring | 11. 3-4 clutch drum |
| Disassembly Note below | 12. Thrust bearing |
| 6. Spring retainer | |
| 7. Return spring | |
| Inspection page K1-81 | |



Disassembly note Snap ring


1. Install the **SST** to the 3-4 clutch as shown.
2. Compress the spring retainer and return spring.
3. Remove the snap ring.
4. Remove the **SST**, then remove the spring retainer and return spring.



3-4 clutch piston

Remove the 3-4 clutch piston by using the SST and compressed air.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.



Inspection


Drive plates

1. Measure the facing thickness in three places, and calculate the average value.

Standard: 1.6 mm {0.063 in}

Minimum: 1.4 mm {0.055 in}

2. If not within the specification, replace the drive plates.




Return spring

1. Measure the spring free length.

Specifications

| Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|---------------------------|------------------------|--------------|--------------------------|
| 83.3 {3.28} | 38.7 {1.52} | 1.0 | 5.5 {0.22} |

2. If not within the specification, replace the spring.




3-4 clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is airflow when applying compressed air through the oil hole on the return spring side.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.

3. Replace the 3-4 clutch piston if damaged or malfunctioning.




Assembly procedure

1. Install the 3-4 clutch piston.
 - (1) Apply ATF to the inner and outer seals, and install them onto the 3-4 clutch piston.
 - (2) Install the piston by pushing evenly around the circumference, being careful not to damage the seal rings.

Seal ring inner diameter

Inner seal: 59.0 mm {2.32 in}


Outer seal: 105.5 mm {4.154 in}




2. Install the return spring and spring retainer.
3. Install the **SST** to the 3-4 clutch as shown.

Caution

- Depress the return spring only enough to install the snap ring. Overpressing will damage the retainer assembly edges.



4. Compress the return spring and spring retainer.
5. Install the snap ring. Do not align the snap ring end gap with the return spring stopper.
6. Remove the **SST**.
7. Install the drive and driven plates in the following order. Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive.
8. Install the retaining plate.





9. Install the snap ring. Do not align the snap ring end gap with the return spring stopper.
10. Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within the specification, adjust it by selecting a proper retaining plate from below.

3-4 clutch clearance: 1.3—1.5 mm {0.051—0.059 in}


Retaining plate

| | | mm {in} |
|--------------|--------------|--------------|
| 3.8 {0.15} | 3.91 {0.154} | 4.04 {0.159} |
| 4.17 {0.164} | 4.3 {0.169} | 4.43 {0.174} |
| 4.56 {0.18} | 4.69 {0.185} | 4.8 {0.189} |



11. Install the **SST** as shown, and check clutch operation by applying compressed air.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.



- Apply petroleum jelly to the thrust bearings and secure them to both sides of the 3-4 clutch drum.

Thrust bearing outer diameter

Carrier hub side: 56.0 mm {2.20 in}






Bearing race outer diameter


Output shell side: 72.0 mm {2.83 in}

LOW AND REVERSE BRAKE

Preparation

SST

| | | | |
|--|--|--|--|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly / assembly of low and reverse brake</p> | <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of low and reverse brake</p> |
| <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of low and reverse brake</p> | <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of low and reverse brake</p> |
| <p>49 G019 024</p> <p>Body A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of low and reverse brake</p> | <p>—</p> | <p>—</p> |




Preinspection

Low and reverse brake operation

Check the low and reverse brake operation by applying compressed air as shown.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.



Low and reverse brake clearance

- Measure the clearance between the retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within the specification, replace parts as necessary.


Low and reverse brake clearance:

1.5—1.8 mm {0.059—0.071 in}


- Select and install the correct retaining plate when assembling.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Snap ring 2. Retaining plate 3. Drive and driven plates Inspection page K1-85 4. Dished plate 5. Snap ring Disassembly Note page K1-85 | <ol style="list-style-type: none"> 6. Spring and retainer assembly Inspection page K1-85 7. Low and reverse brake piston Disassembly Note page K1-85 8. Outer seal 9. Inner seal 10. Transaxle case |
|---|--|

**Disassembly note****Snap ring**

1. Install the **SST** in the transaxle case as shown.

Caution


- Depress the return spring only enough to install the snap ring. Overpressing will damage the retainer assembly edges.

2. Compress the spring and retainer assembly.
3. Remove the snap ring.
4. Remove the **SST** and remove the spring and retainer assembly.

Low and reverse brake piston

Remove the low and reverse brake piston by applying compressed air through the fluid passage.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.


**Inspection****Drive plates**

1. Measure the facing thickness in three places, and calculate the average value.

Standard: 1.6 mm {0.063 in}

Minimum: 1.4 mm {0.055 in}


2. If not within the specification, replace the drive plates.

**Spring and retainer assembly**

1. Measure the free length of each spring and check for deformation.

Free length: 18.07 mm {0.711 in}

2. If not within the specification, replace the spring and retainer assembly.

**Assembly procedure**


1. Install the low and reverse brake piston.
 - (1) Apply ATF to the new inner and outer seals, and install them onto the low and reverse brake piston.


Seal ring inner diameter

Inner seal: 156.5 mm {6.161 in}


Outer seal: 188.0 mm {7.402 in}

- (2) Face the outer seal lip toward the inside by gently rolling it down around the circumference for easier installation into the case.






- (3) Install the low and reverse brake piston by pushing evenly around the circumference, being careful not to damage the outer seal.



2. Install the spring and retainer assembly.




3. Install the **SST** in the transaxle case as shown.


Caution

- **Depress the spring and retainer assembly only enough to install the snap ring. Overpressing will damage the retainer assembly edges.**


4. Compress the spring and retainer assembly.



5. Install the snap ring.
 6. Remove the **SST**.
 7. Install the dished plate as shown in the figure.
 8. Install the drive and driven plates in the following order.
 Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive




9. Install the retaining plate.
 10. Install the snap ring.



11. Measure the clearance between the low and reverse retaining plate and the snap ring. Make several measurements and calculate the average value. If the clearance is not within the specification, adjust by selecting a proper retaining plate from below.

Low and reverse brake clearance:
 1.5—1.8 mm {0.059—0.071 in}



Retaining plate sizes

| mm {in} | | |
|-------------|-------------|-------------|
| 7.0 {0.276} | 7.2 {0.283} | 7.4 {0.291} |
| 7.6 {0.299} | — | — |





12. Check the low and reverse brake operation by applying compressed air through the fluid passage as shown in the figure.

Air pressure: 390 kPa {4.0 kgf/cm², 57 psi} max.

2-4 BRAKE BAND (DISASSEMBLY / INSPECTION / ASSEMBLY)


Preparation

SST


| | | | |
|--|---------------------------------------|--|---------------------------------------|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For assembly of 2-4 brake band</p> | <p>49 G019 028</p> <p>Bolt (Part of 49 G019 0A7A)</p>  | <p>For assembly of 2-4 brake band</p> |
| <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7A)</p>  | <p>For assembly of 2-4 brake band</p> | <p>49 G019 030</p> <p>Plate (Part of 49 G019 0A7A)</p>  | <p>For assembly of 2-4 brake band</p> |

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|--------------------------------|-----------------------------|
| 1. Nut | 6. Servo return spring |
| 2. Washer | Inspection below |
| 3. Piston stem | 7. D-ring |
| 4. Servo retainer | 8. O-ring |
| Assembly Note page K1-89 | 9. Band strut |
| 5. Band servo piston | 10. 2-4 brake band |
| Assembly Note page K1-89 | Inspection page K1-89 |




Inspection Servo return spring

1. Measure the spring free length.

Specifications


| Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|---------------------------|------------------------|--------------|--------------------------|
| 27.7 {1.09} | 43.25 {1.703} | 4.5 | 3.2 {0.13} |

2. If not within the specification, replace the spring.



2-4 brake band

1. Remove the 2-4 brake band, and hold it together with a wire as shown in the figure.
2. Check the 2-4 brake band for wear and burning.
3. Replace the 2-4 brake band if damage of malfunction.



Assembly note

Servo retainer, band servo piston

Install the servo into the transaxle case.

- (1) Apply ATF to a new D-ring and install it onto the band servo piston.


D-ring inner diameter

Small D-ring: 29.4 mm {1.16 in}


Large D-ring: 65.9 mm {2.59 in}

- (2) Assemble the servo piston and servo retainer.
- (3) Apply ATF to new O-rings and install them onto the servo retainer.

O-ring inner diameter: 72.9 mm {2.87 in}



- (4) Install the servo return spring and servo retainer assembly into the transaxle case.
- (5) Press the servo retainer assembly by using the **SST**.
- (6) Install the snap ring.








- (7) Install the piston stem, washer, and nut to the band servo piston.

Note


- Refer to page K1-151 to adjust the brake band during transaxle assembly.

IDLER GEAR Preparation SST


| | | | |
|--|---------------------------------------|---|----------------------------------|
| 49 FT01 439 Holder, idler gear shaft  | For removal / installation of locknut | 49 G019 013 Remover, bearing  | For removal of bearing race |
| 49 F027 0A1 Installer set, bearing  | For installation of bearing race | 49 F027 007 Attachment 72 (Part of 49 F027 0A1)  | For installation of bearing race |
| 49 0180 510B Preload attachment  | For adjustment of bearing preload | — | — |

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|---|--|
| 1. Locknut Disassembly Note page K1-91 | 6. Idler gear shaft |
| 2. Bearing | 7. Bearing race Disassembly Note page K1-91 |
| 3. Spacer | 8. Bearing race Disassembly Note page K1-91 |
| 4. Idler gear | 9. O-ring |
| 5. Bearing | |

**Disassembly note****Locknut**


1. Secure the **SST** and the idler gear assembly in a vise.
2. Remove the locknut.

**Bearing race**


Remove the bearing race from the idler gear by using the **SST**.

**Assembly procedure**

1. Press the new bearing race in by using the **SST**.



2. Install the bearing onto the idler gear shaft, then install the idler gear, spacer, and bearing.




3. Secure the **SST** and the idler gear assembly in a vise.
4. Install the locknut.

Tightening torque:


128—176 N·m {13.0—18.0 kgf·m, 95—130 ft·lbf}

5. Apply ATF to a new O-ring and install it onto the idler gear shaft.

O-ring inner diameter: 33.0 mm {1.30 in}



6. Secure the idler gear in a vise.
7. Use the **SST** to measure the bearing preload at the point that the idler shaft starts to turn.




Preload:

0.03—0.88 N·m {0.3—9.0 kgf·cm, 0.3—7.8 in·lbf}

Pull scale reading:

0.3—8.8 N {0.03—0.90 kgf, 0.07—1.98 lbf}







8. If the specified preload cannot be obtained within the specified tightening torque, adjust by selecting the proper adjustment spacers from below. A thicker spacer reduces the preload, and a thinner spacer increases the preload.

| Thickness of shim mm {in} | | | |
|---------------------------|---------------|---------------|---------------|
| 4.540 {0.179} | 4.575 {0.180} | 4.610 {0.181} | 4.645 {0.183} |
| 4.680 {0.184} | 4.715 {0.186} | 4.750 {0.187} | 4.785 {0.188} |
| 4.820 {0.190} | 4.855 {0.191} | 4.890 {0.193} | 4.925 {0.194} |
| 4.960 {0.195} | 4.995 {0.197} | 5.030 {0.198} | 5.065 {0.199} |
| 5.100 {0.201} | 5.135 {0.202} | 5.170 {0.204} | 5.205 {0.205} |
| 5.240 {0.206} | 5.275 {0.208} | 5.310 {0.209} | |

OUTPUT GEAR


Preparation

SST

| | | | |
|---|-------------------------------|---|------------------------------------|
| <p>49 G017 1A0 Remover set, bearing</p>  | <p>For removal of bearing</p> | <p>49 F401 366A Plate (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> |
| <p>49 G019 022 Attachment K</p>  | <p>For removal of bearing</p> | <p>49 G019 011 Installer, bearing</p>  | <p>For installation of bearing</p> |


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



1. Seal ring
2. Output gear


3. Bearing
Disassembly Note below



Disassembly note


Bearing

Remove the bearings from the output gear by using the SST.



Assembly procedure

1. Press the new bearings onto the output gear by using the SST.




2. Apply ATF to new seal rings and assemble them to each side of the output gear.

Seal ring outer diameter: 36.9 mm {1.45 in}

BEARING COVER ASSEMBLY


Preparation

SST


| | | |
|---|---|-------------------------------------|
| <p>49 G019 017</p> <p>Installer, oil seal</p> |  | <p>For installation of oil seal</p> |
|---|---|-------------------------------------|

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|-----------------|------------------|
| 1. Oil seal | 3. O-ring |
| 2. Bearing race | 4. Bearing cover |
- Disassembly Note below



Disassembly note

Bearing race


Remove the bearing race by using a pin punch and a hammer.



Assembly procedure

1. Press the new bearing race into the bearing cover.
2. Apply ATF to a new O-ring and install it onto the bearing cover.




O-ring inner diameter: 85.1 mm {3.35 in}




3. Press a new oil seal into the bearing cover by using the **SST**.

OIL SEAL (TRANSAXLE)

Preparation


| | | | |
|--|-------------------------------------|--|-------------------------------------|
| <p>49 G030 795</p> <p>Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 G030 796</p> <p>Body (Part of 49 G030 795)</p>  | <p>For installation of oil seal</p> |
| <p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p>  | <p>For installation of oil seal</p> | <p>—</p> | <p>—</p> |



On-vehicle Replacement

1. Remove the drive shaft and joint shaft.
(Refer to page K1–39.)
2. Remove the oil seal by using a screwdriver.
3. Tap the new oil seal into the transaxle case by using the **SST**.
4. Install the drive shaft and joint shaft.
(Refer to page K1–154.)
5. Using the **SST** and a hammer, tap the new oil seal in evenly until the **SST** contacts the transaxle case.
6. Coat the lip of the oil seal with transaxle oil.

CONTROL VALVE BODY (DISASSEMBLY / INSPECTION)**Preparation****SST**

| | | |
|-------------|---|---|
| 49 G019 031 |  | For removal of transaxle fluid temperature sensor |
| Wrench | | |

Disassembly / Inspection

Caution


- Denting or scratching these precisely machined components will reduce the ability of the transaxle to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.

1. Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.
2. Neatly arrange the removed parts to avoid confusing the similar parts.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.


3. Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.




- | | |
|---|--------------------------------|
| 1. Transaxle fluid temperature sensor | 8. Front/premain front gasket |
| 2. Pressure control solenoid | 9. Premain separator plate |
| Inspection page K1-35 | 10. Front/premain rear gasket |
| 3. Torque converter clutch solenoid valve | 11. Rubber balls |
| Inspection page K1-35 | 12. Premain control valve body |
| 4. 3-2 timing solenoid valve | Disassembly / Inspection / |
| Inspection page K1-35 | Assembly page K1-104 |
| 5. Shift solenoid A | 13. Jet orifice and nut |
| Inspection page K1-35 | 14. Rubber ball |
| 6. Torque converter clutch control solenoid valve | 15. Oil strainer |
| Inspection page K1-35 | 16. Premain/main front gasket |
| 7. Front control valve body | 17. Main separator plate |




- | | |
|-------------------------------|-----------------------------|
| 18. Pre-main/main rear gasket | 26. Main/rear rear gasket |
| 19. Rubber ball | 27. Rear separator plate |
| 20. Oil strainer | 28. Main/rear front gasket |
| 21. Oil pipe assembly | 29. Rubber ball |
| 22. Oil baffle | 30. Oil strainer |
| 23. Shift solenoid B | 31. Rubber ball |
| Inspection page K1- 35 | 32. Oil strainer |
| 24. Shift solenoid C | 33. Main control valve body |
| Inspection page K1- 35 | Disassembly / Inspection / |
| 25. Rear control valve body | Assembly page K1-108 |
| Disassembly / Inspection / | |
| Assembly page K1-112 | |

**Disassembly procedure**


1. Remove the transaxle fluid temperature sensor by using the SST.




2. Remove the shift solenoid A and pressure control, torque converter clutch, 3-2 timing, and torque converter clutch control solenoid valves.
3. Remove the O-rings from the solenoid valves.




4. Remove the bolts indicated and remove the front control valve body and premain separator plate and gaskets.




5. Remove the front/premain gaskets and separator plate from the front control body.




6. Remove the rubber ball from the front control valve body.



7. Remove the rubber ball from the premain control valve body.




8. Remove the bolts and remove the premain control valve body and the main separator plate and gaskets.




9. Remove the premain/main gaskets and separator from the premain control valve body.


10. Remove the jet orifices and nuts from the main separator plate.




11. Remove the rubber balls and oil strainer from the premain control valve body.




12. Remove the rubber balls and oil strainer from the main control valve body.



13. Turn the assembly over and remove the oil pipe, oil baffle, shift solenoid B and C.




14. Remove the bolts shown in the figure and remove the rear separator plate and gaskets.



15. Remove the main/rear gaskets and separator from the rear control valve body.

16. Remove the rubber balls and oil strainers from the rear control valve body.



17. Remove the rubber balls and oil strainers from the main control valve body.

MEMO

PREMAIN CONTROL VALVE BODY

Disassembly / Inspection / Assembly

Caution

- Denting or scratching these precisely machined components will reduce the ability of the transaxle to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.

Note


- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.

2. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | | | |
|---|-------|---|-------|
| 1. Spring retainer | | 16. Bypass spring | |
| 2. Pressure modifier accumulator spring | | Inspection | below |
| Inspection | below | 17. Bolts | |
| 3. Pressure modifier accumulator valve | | 18. 1-2 accumulator plate | |
| 4. Stop pin | | 19. 1-2 accumulator gasket | |
| 5. Stop plug | | 20. 1-2 accumulator spring (small, large) | |
| 6. 3-2 timing valve | | Inspection | below |
| 7. 3-2 timing spring | | 21. 1-2 accumulator piston and seal rings | |
| Inspection | below | 22. Bolts | |
| 8. Stop pin | | 23. N-R accumulator plate | |
| 9. Stop plug | | 24. N-R accumulator gasket | |
| 10. Cut back valve A | | 25. N-D accumulator spring | |
| 11. Cut back valve B | | Inspection | below |
| 12. Cut back spring | | 26. N-D accumulator piston and seal ring | |
| Inspection | below | 27. N-R accumulator piston and seal ring | |
| 13. Stop pin | | 28. N-R accumulator spring (small, large) | |
| 14. Stop plug | | Inspection | below |
| 15. Bypass valve | | | |



Inspection


1. Measure the spring free length.
2. If not within the specifications, replace the spring.

| Spring | Item | Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} | Identification color |
|--------------------------------------|-------|---------------------------|------------------------|--------------|--------------------------|-------------------------|
| Pressure modifier accumulator spring | | 8.2 {0.32} | 38.2 {1.50} | 16.5 | 1.2 {0.047} | Light green |
| 3-2 timing spring | | 8.25 {0.325} | 35.4 {1.394} | 12.5 | 0.85 {0.033} | Light blue |
| Cut back spring | | 8.2 {0.32} | 29.8 {1.17} | 7.4 | 0.6 {0.02} | Purple |
| Bypass spring | | 6.3 {0.25} | 29.5 {1.16} | 11.7 | 0.6 {0.02} | Dark green |
| 1-2 accumulator spring | Small | 14.8 {0.583} | 81.6 {3.213} | 17.7 | 1.7 {0.067} | Gray |
| | Large | 20.2 {0.795} | 81.6 {3.213} | 12.5 | 2.3 {0.091} | Dark green |
| N-D accumulator spring | | 9.8 {0.39} | 52.9 {2.08} | 12.0 | 1.0 {0.039} | White |
| N-R accumulator spring | Small | 7.2 {0.28} | 60.1 {2.37} | 26.2 | 1.0 {0.039} | — |
| | Large | 11.2 {0.441} | 56.0 {2.20} | 15.2 | 1.6 {0.063} | — |



Assembly procedure


1. Apply ATF to the seal rings, and install them to the N-D accumulator piston.
2. Insert the piston and N-D accumulator spring.
3. Apply ATF to the seal rings, and install them to the N-R accumulator piston.
4. Insert the piston and N-R accumulator spring.




5. Insert the N-R accumulator gasket plate.
6. Tighten the plate bolt.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}




7. Apply ATF to the seal rings, and install them onto the 1-2 accumulator piston.
8. Install the piston and 1-2 accumulator spring.



9. Install the 1-2 accumulator gasket and plate.
10. Tighten the plate bolt.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}



11. Install the bypass valve spring, bypass valve, stop plug, and stop pin.
12. Install the cut back spring, cut back valve B, cut back valve A, stop plug, and stop pin.
13. Install the 3-2 timing spring, 3-2 timing valve, stop plug, and stop pin.

Install the pressure modifier accumulator valve, pressure modifier accumulator spring, and spring retainer.

MEMO

MAIN CONTROL VALVE BODY**Disassembly / Inspection / Assembly****Caution**

- **Denting or scratching these precisely machined components will reduce the ability of the transaxle to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.**

Note


- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.


Warning

- **Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.**

2. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | | | |
|-----------------------------|-------|---|-------|
| 1. Spring retainer | | 19. Stop pin | |
| 2. Converter relief spring | | 20. Stop plug | |
| Inspection | below | 21. Pressure modifier spring | |
| 3. Converter relief valve | | Inspection | below |
| 4. Stop pin | | 22. Pressure modifier valve | |
| 5. Stop plug | | 23. Stop pin | |
| 6. Solenoid reducing spring | | 24. Stop plug | |
| Inspection | below | 25. Coast timing spring | |
| 7. Solenoid reducing valve | | Inspection | below |
| 8. Spring retainer | | 26. Coast timing valve | |
| 9. Low-reducing spring | | 27. Stop pin | |
| Inspection | below | 28. Stop plug | |
| 10. Low-reducing valve | | 29. Torque converter clutch shift valve A | |
| 11. Stop pin | | 30. Torque converter clutch shift valve B | |
| 12. Stop plug | | 31. Torque converter clutch shift spring | |
| 13. 1-2 shift valve | | Inspection | below |
| 14. 1-2 shift spring | | 32. Stop pin | |
| Inspection | below | 33. Stop plug | |
| 15. Stop pin | | 34. 3-4 shift valve | |
| 16. Stop plug | | 35. 3-4 shift spring | |
| 17. 2-3 shift valve | | Inspection | below |
| 18. 2-3 shift spring | | | |
| Inspection | below | | |



Inspection


1. Measure the spring free length.
2. If not within the specifications, replace the spring.

| Spring | Item | Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} | Identification color |
|--------------------------------------|------|---------------------------|------------------------|--------------|--------------------------|-------------------------|
| Converter relief spring | | 7.4 {0.29} | 32.3 {1.27} | 13.5 | 1.1 {0.043} | — |
| Solenoid reducing spring | | 8.0 {0.31} | 39.7 {1.56} | 12.0 | 0.9 {0.03} | Red |
| Low reducing spring | | 8.7 {0.34} | 38.3 {1.51} | 12.5 | 0.9 {0.03} | Yellow |
| 1-2 shift spring | | 7.4 {0.29} | 36.6 {1.44} | 12.0 | 0.8 {0.031} | Purple |
| 2-3 shift spring | | 7.4 {0.29} | 36.6 {1.44} | 12.0 | 0.8 {0.031} | Purple |
| Coast timing spring | | 6.2 {0.24} | 28.0 {1.10} | 16.0 | 0.6 {0.02} | Light blue |
| Torque converter clutch shift spring | | 6.0 {0.24} | 40.0 {1.57} | 13.8 | 0.5 {0.02} | White |
| 3-4 shift spring | | 7.4 {0.29} | 36.6 {1.44} | 12.0 | 0.8 {0.031} | Purple |
| Pressure modifier spring | | 5.0 {0.20} | 19.0 {0.75} | 12.7 | 0.6 {0.02} | — |




Assembly procedure


1. Install the 3-4 shift spring, 3-4 shift valve, stop plug, and stop pin.
2. Install the torque converter clutch shift spring, torque converter clutch shift valve B, torque converter clutch shift valve A, stop plug, and stop pin.



3. Install the coast timing valve, coast timing spring, stop plug, and stop pin.
4. Install the pressure modifier valve, pressure modifier spring, stop plug, and stop pin.



5. Install the 1-2 shift spring, 1-2 shift valve, stop plug, and stop pin.
6. Install the 2-3 shift spring, 2-3 shift valve, stop plug, and stop pin.



7. Install the low-reducing valve, low-reducing spring, spring retainer.
8. Install the solenoid reducing valve, stop plug, and stop pin.
9. Install the converter relief valve, converter relief spring, and spring retainer.

MEMO

REAR CONTROL VALVE BODY

Disassembly / Inspection / Assembly

Caution

- Denting or scratching these precisely machined components will reduce the ability of the transaxle to shift properly. When handling these components or the valve body that contains them, be careful not drop or hit them.

Note


- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.

2. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | | | |
|-----------------------------------|-------|--|-------|
| 1. Manual valve | | 9. Torque converter clutch control plug | |
| 2. Stop pin | | 10. Torque converter clutch control valve | |
| 3. Pressure regulator plug sleeve | | 11. Torque converter clutch control spring | |
| 4. Pressure regulator plug | | Inspection | below |
| 5. Pressure regulator spring seat | | 12. Stop pin | |
| 6. Pressure regulator spring | | 13. 2-3 timing plug | |
| Inspection | below | 14. 2-3 timing spring | |
| 7. Pressure regulator valve | | Inspection | below |
| 8. Stop pin | | 15. 2-3 timing valve | |



Inspection


1. Measure the spring free length.
2. If not within the specifications, replace the spring.

| Spring | Item | Outer diameter mm {in} | Free length mm {in} | No. of coils | Wire diameter mm {in} | Identification color |
|--|------|---------------------------|------------------------|--------------|--------------------------|-------------------------|
| Pressure regulator spring | | 12.0 {0.472} | 33.9 {1.33} | 7.0 | 1.1 {0.043} | — |
| Torque converter clutch control spring | | 5.8 {0.23} | 33.1 {1.30} | 12.6 | 0.55 {0.022} | White |
| 2-3 timing spring | | 4.7 {0.19} | 22.3 {0.878} | 14.0 | 0.65 {0.026} | White |




Assembly procedure


1. Install the 2-3 timing valve, 2-3 timing spring, 2-3 timing plug, and stop pin.



2. Install the torque converter clutch control spring, torque converter clutch control valve, torque converter clutch control plug, and stop pin.



3. Install the pressure regulator valve, pressure regulator spring, pressure regulator spring seat, pressure regulator plug, pressure regulator plug sleeve, and stop pin.




4. Install the manual valve.

CONTROL VALVE BODY (ASSEMBLY)**Preparation****SST**


49 G019 031

Wrench

For
Installation of
transaxle fluid
temperature
sensor


Assembly

1. Verify that all parts are clean and free of dust or other small particles.
2. Apply ATF to all O-rings and gaskets.
3. Assemble in the order shown in the figure, referring to **Assembly Procedure**.



N-m {kgf-cm, in-lbf}

- | | |
|---|--|
| 1. Main control valve body | 9. Rear control valve body |
| 2. Oil strainer | Bolt installation position page K1-120 |
| Installation position page K1-118 | 10. Shift solenoid C |
| 3. Rubber ball | 11. Shift solenoid B |
| Installation position page K1-118 | 12. Oil baffle |
| 4. Oil strainer | 13. Oil pipe assembly |
| Installation position page K1-118 | 14. Oil strainer |
| 5. Rubber ball | Installation position page K1-118 |
| Installation position page K1-118 | 15. Rubber ball |
| 6. Main/rear front gasket | Installation position page K1-118 |
| 7. Rear separator plate | 16. Premain/main rear gasket |
| 8. Main/rear rear gasket | |




N-m {kgf-cm, in-lbf}


- | | |
|---|---|
| <ul style="list-style-type: none"> 17. Main separator plate 18. Pre-main/main front gasket 19. Oil strainer Installation position page K1-118 20. Rubber ball Installation position page K1-118 21. Jet orifice and nut 22. Pre-main control valve body Bolt installation position page K1-120 23. Rubber ball Installation position page K1-118 | <ul style="list-style-type: none"> 24. Front/pre-main rear gasket 25. Pre-main separator plate 26. Front/pre-main front gasket 27. Front control valve body Bolt installation position page K1-120 28. Torque converter clutch control solenoid valve 29. Shift solenoid A 30. 3-2 timing solenoid valve 31. Torque converter clutch solenoid valve 32. Pressure control solenoid 33. Transaxle fluid temperature sensor |
|---|---|

Rubber ball, oil strainer installation positions


FRONT CONTROL VALVE BODY



PREMAIN CONTROL VALVE BODY
(MAIN CONTROL VALVE BODY SIDE)




(FRONT CONTROL VALVE BODY SIDE)




MAIN CONTROL VALVE BODY


(REAR CONTROL VALVE BODY SIDE)




(PREMAIN CONTROL VALVE BODY SIDE)




REAR CONTROL VALVE BODY




Bolt installation positions and external parts locations




| Identification mark | Bolt | Length mm {in} | Tightening torque N·m {kgf·cm, in·lbf} |
|---------------------|------|----------------|--|
| L | | 50 {2.0} | 6.5—7.8 {66—80, 58—69} |
| G | | 40 {1.6} | |
| F | | 30 {1.2} | |
| K | | 20 {0.79} | |
| E | | 12 {0.47} | |
| I | | 16 {0.63} | |

**Assembly procedure**


1. Install the oil strainers and rubber balls into the main control valve body.
(Refer to Installation position, page K1-118.)




2. Install the oil strainers and rubber balls into the rear control valve body.
(Refer to Installation position, page K1-118.)




3. Set the new main/rear front gasket, rear separator plate, and new main/rear rear gasket on the rear control valve body. Refer to the figure to distinguish the two gaskets.




4. Set the rear control valve body onto the main control valve body.
5. Install and hand tighten the bolts shown. Each type of bolt has a different letter on its head. Match the bolt letter with the letter stamped next to its installation hole on the valve body. Refer to page K1-120 for bolt installation position and description.



6. Install the oil strainer and rubber balls into the main control valve body.
(Refer to Installation position, page K1-118.)




7. Install the oil strainer and rubber balls into the premain control valve body.
(Refer to Installation position, page K1-118.)




8. Install the jet orifices and nuts to the main separator plate.

Tightening torque:


1.7—2.2 N·m {17—23 kgf·cm, 15—19 in·lbf}




9. Set a new premain/main rear gasket, main separator plate, and new premain/main front gasket on the premain control valve body. Refer to the figure to distinguish the two gaskets.




10. Set the premain control valve body onto the main control valve body.
11. Install and hand tighten the bolts shown in the figure. Each type of bolt has a different letter on its head. Match the bolt letter with the letter stamped next to its installation hole on the valve body. Refer to page K1-120 for bolt installation position and description.




12. Install the rubber ball into the premain control valve body. (Refer to Installation position, page K1-118.)




13. Install the rubber ball into the front control valve body. (Refer to Installation position, page K1-118.)




14. Set a new front/premain rear gasket, premain separator plate, and new front/premain front gasket on the front control valve body. Refer to the figure to distinguish the two gaskets.



15. Set the front control valve body onto the premain control valve body.
 16. Install and hand tighten the bolts shown. Each type of bolt has a different letter on its head. Match the bolt letter with the letter stamped next to its installation hole on the valve body. Refer to page K1-120 for bolt installation position and description.




17. Install four control valve body bolts as shown for alignment.



18. Tighten the mounting bolts.
 (1) Tighten the front control body.


Tightening torque:
 6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}



(2) Tighten the rear control valve body.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}




19. Apply ATF to new O-rings and install them onto the sole-noid valves.

20. Install the solenoid valves.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}




21. Apply ATF to new O-rings and install them onto the oil pipe assembly.

22. Install the oil pipe assembly.

Tightening torque:


6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}



23. Install the oil baffle.

Tightening torque:

6.5—7.8 N·m {66—80 kgf·cm, 58—69 in·lbf}



24. Install the transaxle fluid temperature sensor by using the SST.



Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}


CONTROL VALVE BODY (ON-VEHICLE REMOVAL / INSTALLATION)

On-vehicle Removal


1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents.
2. Disconnect the negative battery cable.
3. Drain the ATF and engine coolant into separate containers.
4. Remove the splash shield.
5. Remove the oil cooler hose and radiator hose.
6. Remove the control valve body cover and gasket.



7. Disconnect the solenoid connectors and transaxle fluid temperature sensor connector.




8. Remove the control valve body assembly.



On-vehicle Installation

1. Align the manual plate and the manual valve.




2. Install the control valve body assembly.

Tightening torque:

10.8—14.7 N·m {110—150 kgf·cm, 95.5—130 in·lbf}


3. Match the harness colors and connect the solenoid connectors and transaxle fluid temperature sensor connector.




4. Install a new gasket and the control valve body cover.

Tightening torque:

8.4—10.7 N·m {85—110 kgf·cm, 74—95.4 in·lbf}






**Caution**


- If reusing the hose clamp, position it in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a tight fit.



5. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.
6. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
7. Verify that the hose clamp does not interfere with any other parts.
8. Slide the radiator hose onto the radiator pipe until it is fully seated.
9. Install the hose clamp on the hose.
10. Squeeze it lightly with large pliers to ensure a good fit.
11. Install the splash shield.
12. Fill the radiator and reservoir with the specified amount and type of engine coolant. (Refer to sections E1, E2.)
13. Connect the negative battery cable.
14. Fill the transaxle with the specified ATF. (Refer to page K1-18.)
15. Check for leakage of ATF from the oil pan or the oil hose connecting points. (Refer to page K1-18.)
16. Carry out the mechanical system test. (Refer to page K1-10.)
17. Carry out the road test. (Refer to page K1-15.)

**DIFFERENTIAL
Preparation
SST**

| | | | |
|---|--|--|--|
| <p>49 0839 425C Puller set, bearing</p>  | <p>For removal of bearing</p> | <p>49 F401 366A Plate</p>  | <p>For removal of bearing</p> |
| <p>49 B092 371 Attachment E</p>  | <p>For removal of bearing</p> | <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of bearing</p> |
| <p>49 F401 337A Attachment C (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> | <p>—</p> | <p>—</p> |



Preinspection

Backlash of side gear and pinion gear

1. Before disassembly, measure the backlash of the side gears.

Backlash

Standard : 0.05—0.15 mm {0.0020—0.0059 in}
Maximum : 0.50 mm {0.020 in}


2. If the backlash exceeds the maximum, replace worn and damaged parts.

Disassembly / Inspection / Assembly


Note

- The bearings do not need to be removed unless you are replacing them.

- Disassemble in the order shown in the figure, referring to **Disassembly Note**.
- Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|---|--|
| 1. Side gear Preinspection page K1-127 | 7. Bearing Disassembly Note page K1-129 |
| 2. Thrust washer | 8. Speedometer drive gear |
| 3. Roll pin Disassembly Note below | 9. Bearing Disassembly Note page K1-129 |
| 4. Pinion shaft | 10. Gear case |
| 5. Pinion gear | 11. Ring gear |
| 6. Thrust washer | |




Disassembly note

Roll pin


- Place the gear case in a vise.
- Insert a **2.0 mm {0.079 in}** punch into the roll pin hole from the ring gear side, and remove the roll pin by using a hammer.

**Bearing**

1. Remove the bearing (speedometer drive gear side) from the gear case by using the **SST**.




2. Remove the bearing (ring gear side) by using a combination of parts from the **SST**.

**Assembly procedure**


1. Install the ring gear to the gear case.

Tightening torque:

79—93 N·m {8.0—9.5 kgf·m, 58—68 ft·lbf}




2. Set the speedometer drive gear onto the gear case assembly.




3. Install the new bearings and bearing races by using the **SST**.


- (1) Press the new bearing (speedometer drive gear side) onto the gear case by using the **SST**.
- (2) Press on the other new bearing (ring gear side) in the same manner.




4. Apply ATF to the thrust washers and pinion shaft.
5. Install the pinion gears and thrust washers into the gear case.
6. Install the pinion shaft.



7. Install the roll pin, and crimp it to prevent it from coming out of the gear case.



8. Apply ATF to the thrust washers.
9. Install the thrust washers and side gears into the gear case, then turn the side gears and align them with the drive shaft holes.



10. Measure the backlash of the side gears as follows:
 - (1) Install the left and right drive shafts in the differential assembly.
 - (2) Support the drive shafts on V-blocks.
 - (3) Measure the backlash of both side gears.

Backlash

Standard : 0.05—0.15 mm {0.0020—0.0059 in}




Maximum : 0.50 mm {0.020 in}

11. If the backlash exceeds the maximum, rebuild or replace the differential assembly.

BEARING PRELOAD

Procedure

1. Use the **SSTs** shown below to measure and adjust the output gear bearing preload.




- (1) Align the bearing cover with guide bolts as shown.
- (2) Press in the bearing cover by using the **SST**.
- (3) Remove the guide bolts and install the bearing cover installation bolts.


Tightening torque:

10.8—13.7 N·m {110—140 kgf·cm, 95.5—121 in·lbf}


- (4) Mount the converter housing onto the **SST** (transaxle hanger).
- (5) Remove the bearing race and adjustment shims from the bearing housing using a pin punch and a hammer.
- (6) Set the output gear into the converter housing.



- (7) Install the bearing race removed in step (5) to the selector, and install the selector and bearing race to the output gear.
- (8) Turn the selector to eliminate the gap indicated by the arrow.




- (9) Set the four **SSTs** on the converter housing in the positions shown.




- (10) Set the bearing housing on the **SSTs** (selector) and install the four **SSTs** (bolts). Tighten the bolts to the specified torque.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}



- (11) Turn the **SST** (selector) to increase the clearance (arrow) with the **SST** (bars) until it no longer turns.
- (12) Turn the selector in the opposite direction until the preload is eliminated (gap is reduced).




- (13) Mount the **SST** and a pull scale or a torque wrench on the output gear.
- (14) Adjust the clearance of the **SST** (selector) to obtain the specified preload/pull scale reading.


Preload: 1.1—1.9 N·m {11—20 kgf·cm, 10—17 in·lbf}

Reading on pull scale:

11—19 N {1.1—2.0 kgf, 2.5—4.4 lbf}




(15) Measure the bearing preload at the point that the output gear starts to turn.




(16) Measure the gap around the circumference of the **SST** (selector) by using a feeler gauge.

(17) Take the maximum reading and determine the shim to be used. Use no more than one shim.




| Thickness of shim mm {in} | | |
|---------------------------|----------------|----------------|
| 0.350 {0.0138} | 0.375 {0.0148} | 0.400 {0.0157} |
| 0.425 {0.0167} | 0.450 {0.0177} | 0.475 {0.0187} |
| 0.500 {0.0197} | 0.525 {0.0207} | 0.550 {0.0217} |
| 0.575 {0.0226} | 0.600 {0.0236} | 0.625 {0.0246} |
| 0.650 {0.0256} | 0.675 {0.0266} | 0.700 {0.0276} |
| 0.725 {0.0285} | 0.750 {0.0295} | 0.775 {0.0305} |
| 0.800 {0.0315} | 0.825 {0.0325} | 0.850 {0.0335} |
| 0.875 {0.0344} | 0.900 {0.0354} | 0.925 {0.0364} |
| 0.950 {0.0374} | 0.975 {0.0384} | 1.000 {0.0394} |
| 1.025 {0.0404} | 1.050 {0.0413} | 1.075 {0.0423} |
| 1.100 {0.0433} | 1.125 {0.0443} | 1.150 {0.0453} |
| 1.175 {0.0463} | 1.200 {0.0472} | 1.225 {0.0482} |
| 1.250 {0.0492} | 1.275 {0.0502} | 1.300 {0.0512} |
| 1.325 {0.0522} | 1.350 {0.0531} | 1.375 {0.0541} |
| 1.400 {0.0551} | | |



(18) Remove the bearing housing and the **SST**.

(19) Install the required shim and press the bearing race into the bearing housing by using the **SST**.

(20) Install the bearing housing.



Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

(21) Check that the preload/pull scale reading is within the specification. If not, return to step (5).



Preload: 1.1—1.9 N·m {11—20 kgf·cm, 10—17 in·lbf}

Reading on pull scale:


11—19 N {1.1—2.0 kgf, 2.5—4.4 lbf}

(22) Remove the bearing housing and output gear assembly.


2. Use the **SSTs** shown below to measure and adjust the differential side bearing preload.




- (1) Remove the bearing race and adjustment shims from the transaxle case. (Refer to page K1-58.)
- (2) Install the bearing race into the converter housing by using a pipe and a hammer.




- (3) Set the differential assembly into the converter housing.
- (4) Turn the selector to eliminate the gap indicated by the arrow.
- (5) Install the bearing race removed in step (1) into the **SST** and set them onto the differential assembly.



(6) Install the **SSTs** as shown in the figure.




(7) Set the six **SSTs** in the positions shown.




- (8) Set the transaxle case on the **SSTs** (selectors).
- (9) Tighten the **SSTs** (bolts) to the specified torque.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}







- (10) Turn the **SST** (selector) to increase the clearance (arrow) by using the **SST** (bars), until it no longer turns.
- (11) Turn the selector in the opposite direction until the preload is eliminated (gap is reduced).



- (12) Insert the **SST** through the oil seal hole of the transaxle case and attach it to the pinion shaft.
- (13) Mount the **SST** and a pull scale or a torque wrench to the **SST**.
- (14) Measure the bearing preload at the point that the differential starts to turn.
- (15) Adjust the clearance of the **SST** (selector) to obtain the specified preload/pull scale reading.

Preload: 0.49 N·m {5.0 kgf·cm, 4.3 in·lbf}

Reading on pull scale: 4.9 N {0.5 kgf, 1.1 lbf}



- (16) Measure the gap between A and B around the circumference of the **SST** (selector) by using a feeler gauge.
- (17) Select a maximum of three adjustment shims to equal the measurement clearance plus **0.3 mm {0.012 in}**.

| Thickness of shim mm {in} | | | |
|---------------------------|--------------|--------------|--------------|
| 0.10 {0.004} | 0.15 {0.006} | 0.20 {0.008} | 0.25 {0.010} |
| 0.30 {0.012} | 0.35 {0.014} | 0.40 {0.016} | 0.45 {0.018} |
| 0.50 {0.020} | 0.55 {0.022} | 0.60 {0.024} | 0.65 {0.026} |
| 0.70 {0.028} | 0.75 {0.030} | 0.80 {0.031} | 0.85 {0.033} |
| 0.90 {0.035} | 0.95 {0.037} | 1.00 {0.039} | 1.05 {0.041} |
| 1.10 {0.043} | 1.15 {0.045} | 1.20 {0.047} | |

- (18) Remove the transaxle case and **SST** (selector).
- (19) Install the required shim(s) and tap the bearing race into the transaxle case.

- (20) Install the transaxle case.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

- (21) Check that the preload is within the specification. If not, return to step (1).

Preload: 3.0—3.9 N·m {30—40 kgf·cm, 27—34 in·lbf}

















Reading on pull scale:

30—39 N {3.0—4.0 kgf, 6.6—8.8 lbf}

- (22) Remove the transaxle case.

TRANSAXLE UNIT (ASSEMBLY)

**Preparation
SST**


| | | | |
|---|---|--|---|
| <p>49 0107 680A Engine stand</p>  | <p>For assembly of transaxle</p> | <p>49 G019 0A0 Hanger, transaxle</p>  | <p>For assembly of transaxle</p> |
| <p>49 G019 001 Body (Part of 49 G019 0A0)</p>  | <p>For assembly of transaxle</p> | <p>49 G019 002 Stay (Part of 49 G019 0A0)</p>  | <p>For assembly of transaxle</p> |
| <p>49 G019 003 Bolt set (Part of 49 G019 0A0)</p>  | <p>For assembly of transaxle</p> | <p>49 G019 0A7A Compressor set, return spring</p>  | <p>For assembly of low and reverse brake piston</p> |
| <p>49 G019 028 Bolt (Part of 49 G019 0A7A)</p>  | <p>For assembly of low and reverse brake piston</p> | <p>49 G019 029 Nut (Part of 49 G019 0A7A)</p>  | <p>For assembly of low and reverse brake piston</p> |
| <p>49 G019 030 Plate (Part of 49 G019 0A7A)</p>  | <p>For assembly of band servo</p> | <p>49 G019 0A2 Holder, turbine shaft</p>  | <p>For holding turbine shaft</p> |
| <p>49 G019 014 Stay (Part of 49 G019 0A2)</p>  | <p>For holding turbine shaft</p> | <p>49 G019 015 Adaptor (Part of 49 G019 0A2)</p>  | <p>For holding turbine shaft</p> |
| <p>49 G019 016 Bolt (Part of 49 G019 0A2)</p>  | <p>For holding turbine shaft</p> | <p>49 G030 455 Holder, differential side gear</p>  | <p>For holding differential side gear</p> |
| <p>49 G019 017 Installer, oil seal</p>  | <p>For installation of bearing cover</p> | <p>49 F027 007 Attachment φ72</p>  | <p>For installation of bearing rece</p> |

Assembly

Precaution

1. Select the adjustment shim(s), referring to **Bearing Preload**.
2. If the drive plates or 2–4 brake band are replaced with new ones, soak the new part in ATF for at least two hours before installation.
3. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, and sliding parts.
4. All O-rings, seals, and gaskets must be replaced with the new ones included in the overhaul kit.
5. Use petroleum jelly, not grease, during reassembly.
6. When it is necessary to replace a bushing, replace the subassembly that includes the bushing.
7. Assemble the housing within 10 minutes after applying sealant, and allow it to cure at least 30 minutes after assembly before filling the transaxle with ATF.

Bearing and race locations




Outer diameter of bearing and race

| | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|---------|-------------|--------------|--------------|--------------|-------------|-------------|-------------|
| Bearing | mm {in} | 86.0 {3.39} | *56.1 {2.21} | *62.5 {2.46} | *62.5 {2.46} | 72.0 {2.83} | 56.0 {2.20} | 71.0 {2.80} |
| Race | mm {in} | 88.0 {3.46} | — | — | — | 72.0 {2.83} | 57.0 {2.24} | 72.0 {2.83} |


* One-piece units

Components



- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Converter housing 2. O-ring 3. Oil seal 4. Adjustment shim 5. Bearing race 6. Bearing cover assembly 7. Output gear 8. Idler gear | <ul style="list-style-type: none"> 9. Bearing housing 10. Baffle plate 11. Roll pin 12. Orifice check valve 13. Orifice check valve spring 14. 2-3 accumulator 15. Differential |
|---|--|


Components (Cont'd)



1. Parking pawl
2. Parking assist lever
3. Actuator support
4. Manual shaft and manual plate
5. Bracket


6. Plug, packing, spring, and detent ball
7. Low and reverse brake
8. Output shell
9. Transaxle case

Components (Cont'd)



- | | |
|--|---|
| 1. Turbine shaft | 8. Anchor strut and shaft |
| 2. 3-4 clutch | 9. 2-4 brake band |
| 3. Internal gear | 10. Small sun gear and one-way clutch 1 |
| 4. Snap ring | 11. Clutch assembly |
| 5. Friction plate | 12. Snap ring |
| 6. One-way clutch 2 and carrier hub assembly | 13. Piston stem |


Components (cont'd)



N-m {kgf-m, ft-lbf}

1. Oil pump
2. Control valve body
3. Coupler assembly
4. Control valve body cover
5. Oil strainer
6. Oil pan
7. Oil pipe


8. Breather hose
9. Transaxle range switch
10. Input/turbine speed sensor
11. ATF dipstick and oil filler tube
12. Oil pump shaft
13. Torque converter

**Assembly procedure**


1. Remove any old locking compound from the bolt holes.
2. Align the bearing cover with guide bolts as shown and press it in. Install and tighten the new mounting bolts.

Tightening torque:


10.8—13.7 N·m {110—140 kgf·cm, 96—121 in·lbf}




3. Press the bearing race into the converter housing.




4. Assemble the SST.



5. Install the idler gear and output gear by tapping in with a plastic hammer.




6. Install the selected shim(s) and bearing race into the bearing housing by using the SST.




7. Install the bearing housing.
 (1) Install the bearing housing and tighten the bolts evenly and gradually.

Tightening torque:

26—30 N·m {2.6—3.1 kgf·m, 19—22 ft·lbf}




- (2) Align the slot of the idler shaft with the mark on the bearing housing.
 (3) Tap a new roll pin in by using a pin punch and a hammer.




8. Install the 2-3 accumulator piston.
 (1) Install the orifice check valve spring and orifice check valve.
 (2) Apply ATF to new O-rings and install them into the 2-3 accumulator.
 (3) Install the 2-3 accumulator piston.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}




9. Install the bearing race into the bearing housing.
 10. Install the differential.
 11. Install the selected shim(s) and bearing race into the transaxle case.



12. Install the parking pawl.
 (1) Install the parking pawl and shaft.
 (2) Install the spring and snap ring.




13. Install the parking assist lever and snap ring.



14. Install the actuator support.

Tightening torque:

10.8—13.7 N·m {110—140 kgf·cm, 96—121 in·lbf}




15. Install the manual shaft and manual plate.

- (1) Install the manual plate, spacer, washer, and nut.
- (2) Tighten the nut to the specified torque.

Tightening torque:


42—54 N·m {4.2—5.6 kgf·m, 31—40 ft·lbf}



- (3) Install the bracket.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}




- (4) Install the detent ball, spring, washer and plug.
Tighten the plug.

Tightening torque:


11.8—17.6 N·m {120—180 kgf·cm, 105—156 in·lbf}

- (5) Move the manual shaft and verify that the parking pawl operates correctly.



16. Install the output shell to the output gear, and install the bearing race onto the output shell.


Thrust bearing outer diameter: 71.0 mm {2.80 in}



17. Apply a light coat of silicone sealant to the contact surfaces of the converter housing and the transaxle case.
 18. Install new O-rings into the converter housing.
 19. Install the transaxle case on the converter housing, and tighten the bolts evenly and gradually.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}




20. Install the No.1 engine mount.

Tightening torque:


68—77 N·m {6.9—7.9 kgf·m, 50—57 ft·lbf}


21. Install the **SST** into the differential side gears.




22. Install the **SSTs** to hold the turbine shaft.

23. Install the turbine shaft and 3-4 clutch assembly.
 (1) Assemble the turbine shaft and 3-4 clutch assembly.







- (2) Verify that the thrust bearing and race are properly installed.
- (3) Install the turbine shaft and 3-4 clutch assembly into the transaxle case.




- 24. Adjust the **SST** position so that it contacts and holds the turbine shaft.




- 25. Install the internal gear.
 - (1) Install the internal gear to the output shell.
 - (2) Install the snap ring.




- 26. Install the carrier hub assembly.
 - (1) Verify that the thrust bearing and bearing race are installed in the correct position.




- (2) Hold the turbine shaft with one hand to prevent it from rotating.
- (3) Install the carrier hub assembly into the 3-4 clutch drum by rotating it.




27. Install the friction plate.




28. Install the one-way clutch 2.
 (1) Hold the one-way clutch 2 horizontally.
 (2) Install it by turning the carrier hub assembly counter-clockwise.
 (3) Install the snap ring.




29. Install the band servo to the transaxle case.
 (1) Install the servo return spring and band servo.
 (2) Compress the servo by using the **SST**.
 (3) Install the snap ring.
 (4) Remove the **SST**.




30. Install the piston stem.
 31. Hand tighten the piston stem by hand.




32. Install the anchor strut.




33. Install the 2-4 brake band in the transaxle case, and interlock it to the anchor strut as shown.




34. Install the small sun gear and one-way clutch 1.
 (1) Verify that the thrust bearing and bearing race are installed in the correct position.




(2) Install the small sun gear and one-way clutch 1 assembly by rotating it.



35. Install the clutch assembly.
 (1) Verify that the thrust bearing is installed in the correct position.




(2) Install the clutch assembly by rotating it.




- (3) Measure the height difference between the reverse and forward drum and the transaxle case. If not within the specification, reassemble beginning with step 22.


Height difference:
0.7—1.9 mm {0.028—0.075 in} max.




36. Install the new snap ring into the bottom ring groove of the turbine shaft.



37. Use the following procedure to adjust the total end play and select a suitable bearing race.
- (1) Set the thrust bearing onto the clutch assembly.




- (2) Remove the bearing race and the oil pump gasket.
- (3) Set the thickest bearing race (**2.2 mm {0.087 in}**) onto the oil pump.
- (4) Set the oil pump onto the clutch assembly.



- (5) Measure clearance A between the transaxle case and the oil pump. Make several measurements and calculate the average value.
- (6) Select a suitable bearing race from the chart below.

| Clearance A | mm {in} | Select this bearing race | mm {in} |
|-------------|---------------|--------------------------|---------|
| 0.91—1.10 | {0.036—0.043} | 1.2 | {0.047} |
| 0.71—0.90 | {0.028—0.035} | 1.4 | {0.055} |
| 0.51—0.70 | {0.020—0.028} | 1.6 | {0.063} |
| 0.31—0.50 | {0.012—0.020} | 1.8 | {0.071} |
| 0.11—0.30 | {0.004—0.011} | 2.0 | {0.079} |
| 0—0.10 | {0—0.003} | 2.2 | {0.087} |




- (7) Remove the oil pump.
- (8) Place the selected bearing race and a new gasket onto the oil pump.
- (9) Install the oil pump onto the clutch assembly, and tighten the bolts evenly and gradually.

Tightening torque:

19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

- (10) Install the oil pipe.




38. Adjust the 2-4 brake band.

- (1) Loosen the locknut and tighten the piston stem to the specified torque.

Tightening torque:

11.8—14.7 N·m {120—150 kgf·cm, 105—130 in·lbf}

- (2) Install a dial indicator and magnetic base to the oil pump. Set the dial indicator against the piston stem.



- (3) Loosen the piston stem to the specification by applying compressed air through the fluid passage (2-4 brake engagement).

Air pressure: 390—400 kPa {3.9—4.1 kgf/cm²}


Stroke: 1.2—1.4 mm {0.0473—0.0551 in}

- (4) Hold the piston stem and tighten the locknut to the specified torque.


Tightening torque:

25—39 N·m {2.5—4.0 kgf·m, 19—28 ft·lbf}

39. Install a new O-ring and oil strainer to the transaxle.

**Tightening torque:**

7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}




40. Install the magnets inside the oil pan in the positions shown in the figure.

41. Install a new gasket and the oil pan.

Tightening torque:


8.4—10.7 N·m {85—110 kgf·cm, 74—95 in·lbf}




42. Align the manual valve with the pin on the manual plate.
43. Install the control valve body into the transaxle case, and tighten the bolts evenly and gradually.

Tightening torque:

10.8—14.7 N·m {110—150 kgf·cm, 96—130 in·lbf}




44. Install a new O-ring to the coupler assembly.
45. Install the coupler assembly.
46. Match the harness colors, and connect the solenoid connectors and transaxle fluid temperature sensor connector.



47. Install a new gasket and control valve body cover, and tighten the bolts evenly and gradually.

Tightening torque:


8.4—10.7 N·m {85—110 kgf·cm, 74—95 in·lbf}



48. Install the steel ball, spring, oil pipe, and packing.
49. Install the connecting bolt.

Tightening torque:


11.8—17.6 N·m {120—180 kgf·cm, 105—156 in·lbf}



50. Install the input/turbine speed sensor.

Tightening torque:


5.4—7.8 N·m {55—80 kgf·cm, 48—69 in·lbf}



51. Install the transaxle range switch.
52. Adjust the transaxle range switch.
 - (1) Connect an ohmmeter between terminals (A) and (H).
 - (2) Rotate the manual shaft fully counterclockwise, then return it two notches to the N position.
 - (3) Adjust the switch to the point where there is continuity between the terminals.
 - (4) Tighten the switch.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95 in·lbf}




53. Remove the transaxle from the SST (transaxle hanger).
54. Install the ATF dipstick and oil filler tube along with a new O-ring to the transaxle case.

Tightening torque:

6.9—9.8 N·m {70—100 kgf·cm, 61—86 in·lbf}




55. Install the oil pump shaft.
56. Install a new O-ring onto the turbine shaft.



57. If the torque converter is completely empty, hold it upright, and fill it with 2.0 L {2.1 US qt, 1.8 Imp qt} of ATF. If the torque converter has not been completely drained, add the same amount of ATF that was drained out.

ATF type: Dexron®II or M-III

58. Carefully install the torque converter to the torque converter housing. Rotate the torque converter to align the splines.








59. To ensure that the torque converter is installed accurately, measure distance A between the end of the torque converter and the face of the converter housing.

Distance A: 14.0 mm {0.551 in}

TRANSAXLE UNIT (INSTALLATION)

Preparation

SST

| | | | |
|--|---|--|----------------------------------|
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G030 455</p> <p>Holder, differential side gear</p>  | <p>For holding differential side gear</p> | <p>—</p> | <p>—</p> |


Installation

1. Install in the order shown in the figure, referring to **Installation Note**.
2. Fill the transaxle with the specified ATF after installation. (Refer to page K1-18.)
3. Check for leakage of ATF from all connecting points. (Refer to page K1-18.)
4. Connect the negative battery cable.
5. Check operation of the transaxle range switch. (Refer to page K1-28.)
6. Check operation of the selector lever. (Refer to page K1-170.)
7. Carry out the mechanical system test. (Refer to page K1-10.)


| Service item | Test item | Line pressure test | Stall test | Time lag test |
|---------------------------------|-----------|--------------------|------------|---------------|
| Automatic transaxle replacement | | ○ | | |
| Automatic transaxle overhaul | | ○ | ○ | ○ |
| Torque converter replacement | | ○ | ○ | |
| Oil pump replacement | | ○ | | |
| Clutch system replacement | | ○ | | |
| Differential replacement | | ○ | | |

○: Test to be performed after work

8. Carry out the road test. (Refer to page K1-15.)




- | | |
|--|--|
| 1. No.2 engine mount | 18. Oil hose |
| 2. Transaxle Installation Note page K1-157 | 19. Starter |
| 3. Torque converter nut | 20. Engine mount stay Installation Note page K1-159 |
| 4. Undercover | 21. Bolt |
| 5. No.4 engine mount | 22. Ground |
| 6. No.1 engine mount bolt Installation Note page K1-157 | 23. Input/turbine speed sensor connector |
| 7. Engine mounting member Installation Note page K1-157 | 24. Vehicle speedometer sensor connector |
| 8. No.5 engine mount rubber | 25. Fuel filter mounting bolts |
| 9. Joint shaft Installation Note page K1-158 | 26. Nut |
| 10. Drive shaft Installation section M | 27. Ground |
| 11. Lower arm Installation Note page K1-158 | 28. Harness bracket |
| 12. Stabilizer control link | 29. Solenoid valve connector |
| 13. Tie-rod end Installation Note page K1-159 | 30. Transaxle range switch connector |
| 14. Exhaust pipe | 31. Bolt |
| 15. Transverse member | 32. Selector cable Installation Note page K1-160 |
| 16. Splash shield | 33. Clip |
| 17. Wheel and tire | 34. Air cleaner assembly |
| | 35. Fresh-air duct |
| | 36. Battery carrier |
| | 37. Battery |



Installation note

Transaxle

1. Set the transaxle on a jack and lift it into place.



2. Install the transaxle mounting bolts.

Tightening torque:


68—99 N·m {6.9—10.1 kgf·m, 50.0—73.0 ft·lbf}

3. Install the torque converter nuts.

Tightening torque:

38—60 N·m {3.8—6.2 kgf·m, 28—45 ft·lbf}

4. Hand tighten No.4 engine mount nuts.



No.1 engine mount bolt


Caution

- Align the transaxle bolt holes and the engine mount exactly. Any misalignment can result in boltes and bolt holes becoming damaged or stripped during installation.

1. Use the SST (engine support) to make sure the transaxle bolt holes and No.1 engine mount align.
2. Tighten the bolts to the specified torque.


Tightening torque:

75—104 N·m {7.6—10.7 kgf·m, 55—77 ft·lbf}



Engine mounting member

1. Install the engine mount bushings as shown in the figure.
2. Install the engine mounting member, marking sure that the No.2 engine mount stud bolts pass through the mounting member installation hole.




3. Install the bolts and nuts (A) as shown.

Tightening torque

A: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

4. Loosely tighten the nuts (B) as shown.




5. Tighten No.4 engine mount nuts.

Tightening torque:

67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}


6. Remove the SST (engine support).



7. Tighten the nuts ② as shown.


Tightening torque

B: 75—104 N·m {7.6—10.7 kgf·m, 55.0—77.3 ft·lbf}



Joint shaft


1. Remove the SST from the transaxle case.



2. Verify that there is no damage to the oil seal.
3. Install the joint shaft to transaxle.

Tightening torque:

43—61 N·m {4.3—6.3 kgf·m, 32—45 ft·lbf}




Lower arm

1. Connect the lower arm to the knuckle and tighten the clinch bolt.

Tightening torque:

44—58 N·m {4.4—6.0 kgf·m, 32—43 ft·lbf}




2. Install the ABS wheel-speed sensor harness mounting nuts.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 69.5—95.4 in·lbf}

3. Install the clip.




Tie rod end

1. Install the locknut.

Tightening torque:

43—56 N·m {4.3—5.8 kgf·m, 32—41 ft·lbf}


2. Secure the locknut by using a new cotter pin.




Oil hose

Caution

- If reusing the hose clamp, position it in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a tight fit.




1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.



Engine mount stay

Install the engine mount stay as shown.



Selector cable


1. Install the selector cable to the cable bracket.
2. Install the clip to the selector cable.
3. Connect the selector cable to the manual shaft lever.

OIL COOLER

OIL COOLER

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add ATF to the specified level.
5. Connect the negative battery cable.
6. Inspect for oil leakage from the oil pipes and oil hoses.
7. Inspect the ATF level and condition. (Refer to page K1-18.)
8. Carry out the line pressure test. (Refer to page K1-11.)
9. Carry out the road test. (Refer to page K1-15.)




N-m {kgf-m, ft-lbf}

- 1. Connector bolts
- 2. Washers
- 3. Oil hose

- 4. Oil pipe
- 5. Radiator

Installation Note page K1-162


Service section E2



Installation note
Oil hose

Caution

- If reusing the hose clamp, position it in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a tight fit.







1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.

DRIVE PLATE

PREPARATION


SST

| | | | |
|---|--------------------------------|--|--------------------------------|
| <p>49 E011 1A0 Brake set, ring gear</p>  | <p>For holding drive plate</p> | <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> |


DRIVE PLATE

Removal / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|-------------------------------------|------------------|
| 1. Drive plate mounting bolts | 2. Backing plate |
| Removal Note page K1-164 | 3. Drive plate |
| Installation Note page K1-164 | 4. Adapter |

**Removal note****Drive plate mounting bolts**

1. Set the **SST** or equivalent against the drive plate.
2. Remove the bolts and the drive plate.

**Installation note****Drive plate mounting bolts**


1. Set the **SST** or equivalent against the drive plate.
2. Tighten the drive plate mounting bolts in two or three steps in the order shown.

Tightening torque:

61—67 N·m {6.2—6.9 kgf·m, 45—49 ft·lbf}

SHIFT MECHANISM




SHIFT-LOCK SYSTEM COMPONENTS



Troubleshooting Diagnosis chart

| Problem | Possible cause | Action | Page |
|---|---|--|---|
| Selector lever cannot be moved from P position with brake pedal depressed and ignition switch ON | MAIN 100A fuse burned | Replace | *section Z1 |
| | IG KEY 40A fuse burned | Replace | *section Z1 |
| | BTN 60A fuse burned | Replace | *section Z1 |
| | IG1 system malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection • METER 15A fuse burned | Repair or replace Connect firmly Replace | *section Z1 *section Z1 *section Z1 |
| | Ignition switch malfunction | Inspect and replace | *section Z4 |
| | Stoptlight system malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection • STOP 20A fuse burned | Repair or replace Connect firmly Replace | *section Z1 *section Z1 *section Z1 |
| | Brake switch remains OFF | Adjust or replace | section P |
| | P position switch system malfunction <ul style="list-style-type: none"> • Wire harness broken (poor ground) • Poor connection | Repair or replace Connect firmly | *section Z1 *section Z1 |
| | P position switch remains OFF | Inspect | K1-168 |
| | Shift-lock actuator malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection • Shift-lock actuator malfunction | Repair or replace Connect firmly Replace | *section Z1 *section Z1 K1-169 |
| | Misadjustment of selector lever | Adjust or repair | K1-170 |
| Selector lever can be moved from P position with ignition switch ON, but without brake pedal depressed | BTN 60A fuse burned | Replace | *section Z1 |
| | STOP 20A fuse burned | Replace | *section Z1 |
| | Brake switch remains ON | Adjust or replace | section P |
| | Shift-lock actuator malfunction | Inspect and replace | K1-169 |
| | Misadjustment of selector lever | Adjust or repair | K1-170 |
| Selector lever can be moved from P position with ignition switch OFF and brake pedal depressed | BTN 60A fuse burned | Replace | *section Z1 |
| | STOP 20A fuse burned | Replace | *section Z1 |
| | Ignition switch malfunction | Inspect and replace | *section Z4 |
| | Shift-lock actuator malfunction | Inspect and replace | K1-169 |
| | Misadjustment of selector lever | Adjust or repair | K1-170 |
| Shift-lock actuator operation heard when brake pedal depressed with ignition switch ON in other than P position | P position switch remains ON | Inspect | K1-168 |
| | Misadjustment of selector lever | Adjust or repair | K1-170 |
| Selector lever remains locked when emergency override key cylinder operated | Emergency override key cylinder not fully turned | Turn fully and hold emergency override key cylinder, move selector lever | — |
| | Broken emergency override key cylinder | Replace | K1-175 |
| | Misadjustment of indicator panel | Adjust | K1-171 |
| Ignition key can be turned to lock position with selector lever in other than P position | Interlock cable malfunction <ul style="list-style-type: none"> • Disconnected • Kinked • Stuck • Spring damage | Inspect and replace | K1-172 |
| | Key cylinder malfunction | Replace | section N |
| Ignition key cannot be turned to lock position with selector lever in P position | Interlock cable malfunction <ul style="list-style-type: none"> • Disconnected • Kinked • Stuck • Spring damaged | Inspect and replace | K1-172 |
| | Key cylinder malfunction | Replace | section N |

* Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual.

**SHIFT-LOCK****Inspection**




1. Turn the ignition switch to ON (engine off).
2. Verify that the selector lever is in P position.
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P position.
4. Depress the brake pedal and verify that the selector lever can be shifted from P position.
5. If not as specified, check the P position switch continuity and/or shift-lock actuator terminal voltage and continuity. (Refer to pages K1-168, 169.)

EMERGENCY OVERRIDE KEY CYLINDER**Inspection**

1. Turn the ignition switch to OFF.
2. Verify that the selector lever is in P position.
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P position.
4. Insert the ignition key into the emergency override key cylinder beside the selector lever, turn the ignition key counterclockwise and hold it. Verify that the selector lever can be shifted from P position.
5. If not as specified, replace the emergency override key cylinder.

KEY INTERLOCK**Inspection**

1. Turn the ignition switch to ON (engine off).
2. Shift the selector lever to R position.
3. Verify that the ignition key cannot be turned to LOCK position.
4. Shift the selector lever to P position and release the selector lever push button.
5. Verify that the ignition key can be turned to LOCK position.
6. If not as specified, inspect and repair as necessary, referring to Troubleshooting. (Refer to page K1-166.)



P POSITION SWITCH


Inspection

1. Disconnect the negative battery cable.
2. Remove the front console. (Refer to page K1-172.)
3. Remove the indicator screws and lift up the indicator panel.
4. Disconnect the P position switch connector.

5. Check continuity between the terminals.

| Position/Range | Selector lever release button | Continuity |
|----------------|-------------------------------|------------|
| P | Released | Yes |
| | Depressed | No |
| Except P | — | No |

6. If not as specified, replace the selector lever assembly.
7. Install and adjust the indicator panel.
(Refer to page K1-171.)
8. Install the front console. (Refer to page K1-172.)
9. Connect the negative battery cable.
10. Check for correct operation of the shift-lock system.
(Refer to page K1-167.)




SHIFT-LOCK ACTUATOR

Inspection


1. Remove the front console. (Refer to page K1-172.)
2. Shift the selector lever to P position.
3. Turn the ignition switch to ON (engine off), and check terminal voltages and continuity, referring to the chart below. When checking continuity between terminal b (harness side) and ground, disconnect connector B.

B+: Battery positive voltage

| Connector | Terminal | ⊖ probe connected to | Condition | Measurement value |
|-----------|------------------|----------------------|---|-------------------|
| A | a | B—b | P position, selector lever release button not depressed | 0 Ω |
| A | b | B—b | Constant | 0 Ω |
| B | a | B—b | Brake pedal released → depressed | 0V → B+ |
| B | b (harness side) | Body | Constant | 0 Ω |
| B | c | B—b | Ignition switch ON | B+ |
| B | d | B—b | Ignition switch OFF | B+ |









4. If not as specified, repair the wire harness and/or replace the shift-lock actuator.
5. Install the front console. (Refer to page K1-172.)
6. Verify correct operation of the shift-lock system. (Refer to page K1-167.)



Replacement

1. Disconnect the negative battery cable.
2. Remove the front console. (Refer to page K1-172.)
3. Remove the indicator screws and lift up the indicator panel.
4. Disconnect the shift-lock actuator connector.
5. Disconnect the P position switch connector.
6. Remove the shift-lock actuator.
7. Install the new shift-lock actuator.
8. Connect the P position switch connector.
9. Connect the shift-lock actuator connector.
10. Install and adjust the indicator panel. (Refer to page K1-171.)
11. Install the front console. (Refer to page K1-172.)
12. Connect the negative battery cable.
13. Verify correct operation of the shift-lock system. (Refer to page K1-167.)







SELECTOR LEVER

Inspection

1. Turn the ignition switch to ON (engine off).
2. With the brake pedal depressed, verify that there is a "click" at each range when shifted in the pattern shown.
3. Verify that the selector lever can only be shifted as shown.
4. Verify that there is a "click" at each range when shifted from P position → 1 range.
5. Verify that the positions of the selector lever and the indicator are aligned.
6. If not as specified, adjust the indicator panel.
(Refer to page K1-171.)
7. If not as specified, adjust the transaxle range switch.
(Refer to page K1-29.)
8. Verify that the vehicle operates in selected range.

Adjustment Selector lever

1. Remove the front console. (Refer to page K1-172.)
2. Shift the selector lever to P position.
3. Remove the indicator screws and lift up the indicator panel.
4. Slide the lock cover.
5. Disconnect the set button.
6. Push the selector lever to adjust P position.
7. Connect the set button.
8. Slide the lock cover and lock the set button.
9. Install and adjust the indicator panel.
(Refer to page K1-171.)
10. Install the front console. (Refer to page K-172.)
11. Verify correct operation of the selector lever.
(Refer to above.)

**Indicator panel**

1. Loosen the indicator panel screws.
2. Shift the selector lever to P position.
3. Align the alignment screws in the slider with the holes in the indicator panel. Install heavy-gauge wire to hold the slider.

4. Tighten the indicator panel screws in the order shown in the figure.


Tightening torque:

2.0—2.9 N·m {20—30 kgf·cm, 18—26 in·lbf}


5. Remove the wire.
6. Verify that the selector lever properly aligns with the indicator in each range.

Removal / Inspection / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the shift-lock, emergency override button, and key interlock operations.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Steering column cover 2. Front console 3. Side wall 4. Indicator panel Removal Note page K1-173 Installation Note page K1-174 5. Clip 6. Selector lever Removal Note page K1-173 Installation Note page K1-174 Inspection page K1-170 Disassembly / Inspection / Assembly page K1-175 | <ol style="list-style-type: none"> 7. Insulator 8. Clip 9. Selector cable Removal Note page K1-173 Installation Note page K1-173 10. Interlock cable |
|---|--|




Removal note
Indicator panel

Remove the indicator screws and lift up the indicator panel.




Selector lever

1. Slide the lock cover.
2. Disconnect the set button.
3. Pull out the selector cable from the selector lever.
4. Remove the interlock cable from the selector lever.
5. Remove the selector lever.



Selector cable


1. Disconnect the selector cable from the manual shaft lever.
2. Pull out the selector cable from the cable bracket and remove it.



Installation note

Selector cable

1. Install the selector cable to the cable bracket.
2. Install the clip to the selector cable.
3. Connect the selector cable to the manual shaft lever.




Selector lever

1. Install the selector lever.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}


2. Install the selector cable to the selector lever.
3. Push the selector lever adjust P position.
4. Connect the set button.
5. Slide the lock cover and lock the set button.



6. Install the interlock cable to the selector lever.


Tightening torque:

9.8—14.7 N·m {100—150 kgf·cm, 87—130 in·lbf}



Indicator panel

1. Shift the selector lever to P position.
2. Align the alignment screws in the slider with the holes in the indicator panel. Install heavy-gauge wire to hold the slider.



3. Tighten the indicator panel screws in the order shown in the figure.


Tightening torque:

2.0—2.9 N·m {20—30 kgf·cm, 18—26 in·lbf}


4. Remove the wire.
5. Verify that the selector lever properly aligns with the indicator in each range.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly.











- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Connector pin Disassembly Note page K1-176 2. Screws 3. Selector lever knob 4. Cover 5. Indicator panel | <ol style="list-style-type: none"> 6. Emergency override key cylinder 7. Position indicator light 8. Shift-lock actuator Inspection page K1-169 9. Selector lever |
|--|---|


**Disassembly note****Connector pin**

1. Insert a thin piece of metal from the terminal side of the connector, and pry up the terminal locking top.
2. Pull the terminal out of the connector.

ON-BOARD DIAGNOSTIC SYSTEM

PREPARATION
SST




| | | | |
|---|-------------------------------|---|-------------------------------|
| <p>49 T088 0A0 NGS set</p>  | <p>For diagnosis of EC-AT</p> | <p>49 T088 010B Program Card</p>  | <p>For diagnosis of EC-AT</p> |
| <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For diagnosis of EC-AT</p> | <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For diagnosis of EC-AT</p> |
| <p>49 T088 004 NGS OBDII Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of EC-AT</p> | <p>49 T088 009 Case (Part of 49 T088 0A0)</p>  | <p>For diagnosis of EC-AT</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis of EC-AT</p> | <p>49 T088 008 Instruction Manual</p>  | <p>For diagnosis of EC-AT</p> |



DIAGNOSTIC TROUBLE CODE

Inspection Procedure

1. Connect the **SST** (NGS) to the data link connector 2 and battery.
2. Turn the ignition switch to ON.
3. Check the diagnostic trouble code(s), referring to the **SST** (NGS). (Refer to section F2.)
4. If a diagnostic trouble code(s) is displayed, check for the cause by using the number on the diagnostic trouble code table. (Repair as necessary.)
5. Following repairs, do the After-Repair procedure to verify that there are no remaining codes.



After-Repair Procedure

1. Cancel the diagnostic trouble code memory by using the **SST (NGS)**. (Refer to section F2.)
2. Remove the **SST (NGS)** from the data link connector 2.

3. Drive the vehicle at 50 km/h {31 mph}, and depress the accelerator pedal fully to activate kickdown. Stop the vehicle gradually.

4. Connect the **SST (NGS)** to the data link connector 2 and battery.
5. Turn the ignition switch to ON.
6. Verify that no diagnostic trouble codes are displayed. (Refer to section F2.)
7. Remove the **SST** from the data link connector 2.

Troubleshooting

If a diagnostic trouble code is shown on the **SST**, check for the cause by using the chart related to the code shown.

Diagnostic trouble code

| Code No. | Display on the NGS | Condition | Page |
|----------|---|---|--------|
| P0705 | TRANS RANGE SENSOR — CKT MALFUNCTION | Transmission Range Sensor Circuit Malfunction (PRNDL Input) | K1-180 |
| P0710 | TRANS FLUID TEMP SENS — CKT MALFUNCTION | Transmission Fluid Temperature Sensor Circuit Malfunction | K1-181 |
| P0715 | INPUT/TSS CIRCUIT MALFUNCTION | Input/Turbine Speed Sensor Circuit Malfunction | K1-182 |
| P0731 | GEAR 1 INCORRECT RATIO | Gear 1 Incorrect Ratio | K1-183 |
| P0732 | GEAR 2 INCORRECT RATIO | Gear 2 Incorrect Ratio | K1-184 |
| P0733 | GEAR 3 INCORRECT RATIO | Gear 3 Incorrect Ratio | K1-185 |
| P0734 | GEAR 4 INCORRECT RATIO | Gear 4 Incorrect Ratio | K1-186 |
| P0740 | TORQUE CONV CLUTCH SYS — MALFUNCTION | Torque Converter Clutch System Malfunction | K1-187 |
| P0745 | PRESSURE CTRL SOLENOID — MALFUNCTION | Pressure Control Solenoid Malfunction | K1-188 |
| P0750 | SHIFT SOLENOID A — MALFUNCTION | Shift Solenoid A Malfunction | K1-189 |
| P0755 | SHIFT SOLENOID B — MALFUNCTION | Shift Solenoid B Malfunction | K1-190 |
| P0760 | SHIFT SOLENOID C — MALFUNCTION | Shift Solenoid C Malfunction | K1-191 |
| P1743 | SOLENOID TCC — OPEN OR SHORT | Torque converter clutch control solenoid valve | K1-192 |
| P1744 | SOLENOID TCC — OPEN OR SHORT | Torque converter clutch solenoid valve | K1-193 |
| P1765 | 3-2 TIMING SOL. V — OPEN OR SHORT | 3-2 timing solenoid valve | K1-194 |

| DIAGNOSTIC TROUBLE CODE P0705 | | TRANS RANGE SENSOR—CKT MALFUNCTION (Transmission Range Sensor Circuit Malfunction (PRNDL Input)) | | | | |
|-------------------------------|--|--|---|------|------------|-----------------------------|
| DETAILS | | No input signal or input of two or more signals from transaxle range switch | | | | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • Transaxle range switch malfunction • Damaged wiring or connectors between transaxle range switch and powertrain control module • Powertrain control module malfunction | | | | |
| STEP | INSPECTION | ACTION | | | | |
| 1 | Are powertrain control module and transaxle range switch connections at the connector and connector pins OK? | Yes | Go to next step | | | |
| | | No | Repair or replace connector(s) Inspection step 6 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart | | | |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect the EC-AT tester to powertrain control module • Are transaxle range switch range and EC-AT tester display correct? ⓘ page K1-20 | Yes | Go to step 6 | | | |
| | | | | Item | Indication | Condition |
| | | | | P/N | ON | P or N position |
| | | | | | OFF | R position, all ranges |
| | | | | R | ON | R position |
| | | | | | OFF | Other position, all ranges |
| | | | | D | ON | D range |
| | | | | | OFF | Other ranges, all positions |
| | | | | 2 | ON | 2 range |
| | | | | | OFF | Other ranges, all positions |
| 1 | ON | 1 range | | | | |
| | OFF | Other ranges, all positions | | | | |
| 3 | Check for continuity between terminals of transaxle range switch and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transaxle range switch and powertrain control module connectors • Is there continuity between the terminals? | Yes | Go to next step | | | |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 6 • When No, go to next step | | | |
| 4 | Check for continuity between terminal of the transaxle range switch as follows <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transaxle range switch connector • Is there continuity between the terminals? | Yes | Go to next step | | | |
| | | No | Repair or adjust the transaxle range switch Go to step 2 ⓘ page K1-29 <ul style="list-style-type: none"> • When Yes, go to step 6 • When No, go to next step | | | |
| 5 | Check for continuity between terminal of transaxle range switch and main relay <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transaxle range switch and main relay • Is there continuity between the terminals? | Yes | Go to next step | | | |
| | | No | Repair or replace connectors and wiring | | | |
| 6 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ⓘ page K1-178 | Yes | Replace the powertrain control module ⓘ section F2 | | | |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further | | | |

| DIAGNOSTIC TROUBLE CODE P0710 | | TRANS FLUID TEMP SENS—CKT MALFUNCTION (Transmission Fluid Temperature Sensor Circuit Malfunction) | |
|-------------------------------|--|--|---|
| DETAILS | | Powertrain control module input voltage is less than 0.09V or over 5.0V | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • Transaxle fluid temperature sensor malfunction • Damaged wiring or connectors between transaxle fluid temperature sensor and powertrain control module • Powertrain control module malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Are powertrain control module and transaxle fluid temperature sensor connections at the connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector Inspection step 6 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is transaxle fluid temperature sensor voltage correct? Voltage ATF temp. 20°C {68°F}: Approx. 3.5V 40°C {104°F}: Approx. 2.7V 80°C {176°F}: Approx. 1.3V ↳ page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of transaxle fluid temperature sensor and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transaxle fluid temperature sensor and powertrain control module connectors • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance between transaxle fluid temperature sensor terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect transaxle fluid temperature sensor connector • Is resistance between terminals correct? Resistance ATF temp. 20°C {68°F}: 2.495—2.717 kΩ 40°C {104°F}: 1.191—1.278 kΩ 80°C {176°F}: 0.3492—0.3655 kΩ ↳ page K1-31 | Yes | Go to next step |
| | | No | Replace transaxle fluid temperature sensor ↳ page K1-31 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ↳ page K1-178 | Yes | Replace the powertrain control module ↳ section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P0715 | | INPUT/TSS CIRCUIT MALFUNCTION (Input/Turbine Speed Sensor Circuit Malfunction) | |
|-------------------------------|--|---|--|
| DETAILS | | Signal from input/turbine speed sensor is not input to powertrain control module when vehicle is moving | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • Input/turbine speed sensor malfunction • Damaged harness or connectors between input/turbine speed sensor and powertrain control module • Powertrain control module malfunction | |
| STEP | INSPECTION | ACTION | |
| 1 | Are powertrain control module and input/turbine speed sensor connection at the connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector Inspection step 6 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is speed indicated on EC-AT tester after engine is started and vehicle is idling? 🔍 page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of input/turbine speed sensor and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect input/turbine speed sensor and powertrain control module connectors • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance between input/turbine speed sensor terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect input/turbine speed sensor connector • Is resistance between terminals correct? Resistance: 253—604 Ω 🔍 page K1-31 | Yes | Go to next step |
| | | No | Replace the input/turbine speed sensor 🔍 page K1-31 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 🔍 page K1-178 | Yes | Replace the powertrain control module 🔍 section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |






| DIAGNOSTIC TROUBLE CODE P0731 | | GEAR 1 INCORRECT RATIO (Gear 1 Incorrect Ratio) | |
|-------------------------------|--|--|---|
| DETAILS | | Powertrain control module outputs solenoid pattern of first gear when gear ratio is other than first gear | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • ATF level low • Solenoid valve malfunction • Line pressure low | <ul style="list-style-type: none"> • Control valve stuck • Powertrain control module malfunction |
| STEP | INSPECTION | ACTION | |
| 1 | Is diagnostic trouble code P0750, P0755, or P0760 indicated? ☞ page K1-177 | Yes | Refer to flowchart for diagnostic trouble code P0750, P0755, or P0760 and perform troubleshooting ☞ page K1-189, 190, 191 |
| | | No | Go to next step |
| 2 | Are amount and condition (color) of ATF OK? Check for ATF leakage at transaxle connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-18 | Yes | Go to next step |
| | | No | Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle when pressure is less than specification, go to step 3 • If ATF color is ③ or ④, replace ATF |
| 3 | Is turbine speed OK under following conditions? • EC-AT tester connected to powertrain control module • Throttle is 2/8 open, and vehicle speed is 20 km/h {12 mph} in D range (O/D OFF SW OFF) Turbine speed: Approx. 2,100 rpm ☞ page K1-20 | Yes | Go to step 8 |
| | | No | Above specification: Go to next step Below specification: Go to step 6 |
| 4 | Check line pressure in D range (O/D OFF SW OFF) • Is line pressure OK? Line pressure when in D range (O/D OFF SW OFF) Idling: 420–530 kPa {4.2–5.5 kgf/cm ² , 60–78 psi} Stalled: 1,100–1,170 kPa {11.2–12.0 kgf/cm ² , 160–170 psi} ☞ page K1-11 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • Line pressure is low only when in D or 2 range: ATF leakage in forward clutch circuit |
| 5 | Check stall speed in D range (O/D OFF SW OFF) • Is stall speed OK? Stall speed when in D range (O/D OFF SW OFF): 2,270–2,500 rpm ☞ page K1-12 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • High in all range: Shifting of forward clutch, one-way clutch 1 • High in D range: Shifting of one-way clutch 2 |
| 6 | Inspect operation of shift solenoid A, B, C • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-35 | Yes | Go to next step |
| | | No | Replace shift solenoid A, B, or C ☞ page K1-35 Go to step 3 • When Yes, go to step 8 • When No, go to next step |
| 7 | Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK? | Yes | Go to next step |
| | | No | Repair or replace control valve and replace return spring |
| 8 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-178 | Yes | Replace powertrain control module ☞ section F2 |
| | | No | Problem is a temporary slip of clutch, and should be investigated further |






| DIAGNOSTIC TROUBLE CODE P0732 | | GEAR 2 INCORRECT RATIO (Gear 2 Incorrect Ratio) | |
|-------------------------------|---|--|---|
| DETAILS | Powertrain control module output solenoid pattern of second gear when gear ratio is other than second gear | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • ATF level low • Forward clutch slippage • 2-4 brake band slippage • Solenoid valve malfunction • Line pressure low • One-way clutch 1 slippage • Control valve stuck • Powertrain control module malfunction | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is diagnostic trouble code P0750, P0755, or P0760 indicated? ☞ page K1-177 | Yes | Refer to flowchart for diagnostic trouble code P0750, P0755, or P0760 and perform troubleshooting ☞ page K1-189, 190, 191 |
| | | No | Go to next step |
| 2 | Are amount and condition (color) of ATF OK? Check for ATF leakage at transaxle connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-18 | Yes | Go to next step |
| | | No | Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle when pressure is less than specification, go to step 4 • If ATF color is ③ or ④, replace ATF |
| 3 | Is turbine speed OK under following conditions? • EC-AT tester connected to powertrain control module • Throttle is 2/8 open, and vehicle speed is 20 km/h {12 mph} is 2 range Turbine speed: Approx. 1,100 rpm ☞ page K1-20 | Yes | Go to step 8 |
| | | No | Above specification: Go to next step Below specification: Go to step 6 |
| 4 | Check line pressure in D, 2 range • Is line pressure OK? Line pressure when in D, 2 range Idling: 420—530 kPa {4.2—5.5 kgf/cm ² , 60—78 psi} Stalled: 1,100—1,170 kPa {11.2—12.0 kgf/cm ² , 160—170 psi} ☞ page K1-11 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • ATF leakage in 2-4 brake band circuit • ATF leakage in forward clutch circuit |
| 5 | Check stall speed in D, 2 range • Is stall speed OK? Stall speed when in D, 2 range: 2,270—2,500 rpm ☞ page K1-12 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • 2-4 brake band slipping • Forward clutch slipping |
| 6 | Inspect operation of shift solenoid A, B, C • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-29 | Yes | Go to next step |
| | | No | Replace shift solenoid A, B, or C ☞ page K1-29 Go to step 3 • When Yes, go to step 8 • When No, go to next step |
| 7 | Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK? | Yes | Go to next step |
| | | No | Repair or replace control valve and replace return spring |
| 8 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-178 | Yes | Replace the powertrain control module ☞ section F2 |
| | | No | Problem is a temporary slip of clutch, and should be investigated further |






| DIAGNOSTIC TROUBLE CODE P0733 | | GEAR 3 INCORRECT RATIO (Gear 3 Incorrect Ratio) | |
|-------------------------------|---|---|---|
| DETAILS | | Powertrain control module output solenoid pattern of third gear when gear ratio is other than third gear | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • ATF level low • Forward clutch slippage • 3–4 clutch slippage • Solenoid valve malfunction | <ul style="list-style-type: none"> • Line pressure low • One-way clutch 1 slippage • Control valve stuck • Powertrain control module malfunction |
| STEP | INSPECTION | ACTION | |
| 1 | Is diagnostic trouble code P0750, P0755, or P0760 indicated? page K1-177 | Yes | Refer to flowchart for diagnostic trouble code P0750, P0755, or P0760 and perform troubleshooting page K1-189, 190, 191 |
| | | No | Go to next step |
| 2 | Are amount and condition (color) of ATF OK? Check for ATF leakage at transaxle connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF page K1-18 | Yes | Go to next step |
| | | No | Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle when pressure is less than specification, go to step 4 • If ATF color is ③ or ④, replace ATF |
| 3 | Is turbine speed OK under following conditions? • Solenoid connector disconnected • EC-AT tester connected to powertrain control module • Throttle is 2/8 open, and vehicle speed is 20 km/h {12 mph} in third gear in D range Turbine speed: Approx. 800 rpm page K1-20 | Yes | Go to step 8 |
| | | No | Above specification: Go to next step Below specification: Go to step 6 |
| 4 | Check line pressure when solenoid connector is disconnected • Solenoid connector disconnected • Is line pressure OK? Line pressure when third gear in D range Stalled: 844–902 kPa {8.6–9.2 kgf/cm ² , 123–130 psi} page K1-11 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • ATF leakage in 3–4 clutch |
| 5 | Check stall speed when solenoid connector is disconnected • Solenoid connector disconnected • Is stall speed OK? Stall speed when third gear in D range: 2,270–2,500 rpm page K1-12 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • 3–4 clutch slipping |
| 6 | Inspect operation of shift solenoid A, B, C • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? page K1-29 | Yes | Go to next step |
| | | No | Replace shift solenoid A, B, or C page K1-29 Go to step 3 • When Yes, go to step 8 • When No, go to next step |
| 7 | Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK? | Yes | Go to next step |
| | | No | Repair or replace control valve and replace return spring |
| 8 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown page K1-178 | Yes | Replace powertrain control module section F2 |
| | | No | Problem is a temporary slip of clutch, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P0734 | | GEAR 4 INCORRECT RATIO (Gear 4 Incorrect Ratio) | |
|-------------------------------|--|--|--|
| DETAILS | | Powertrain control module output solenoid pattern of fourth gear when gear ratio is other than fourth gear | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • ATF level low • 2–4 brake band slippage • Control valve stuck • Powertrain control module malfunction | <ul style="list-style-type: none"> • Line pressure low • 3–4 clutch slippage • Solenoid valve malfunction |
| STEP | INSPECTION | ACTION | |
| 1 | Is diagnostic trouble code P0750, P0755, or P0760 indicated? 📖 page K1–177 | Yes | Refer to flowchart for diagnostic trouble code P0750, P0755, or P0760 and perform troubleshooting 📖 page K1–189, 190, 191 |
| | | No | Go to next step |
| 2 | Are amount and condition (color) of ATF OK? Check for ATF leakage at transaxle connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF 📖 page K1–18 | Yes | Go to next step |
| | | No | Adjust ATF amount or replace ATF if necessary • If ATF color is ②, measure line pressure at idle when pressure is less than specification, repair or replace any defective parts • If ATF color is ③ or ④, replace ATF |
| 3 | Is diagnostic trouble code P0732 (Gear 2 incorrect ratio) indicated? 📖 page K1–177 | Yes | Refer to flowchart for diagnostic trouble code P0732 (Gear 2 incorrect ratio), and perform troubleshooting 📖 page K1–184 |
| | | No | Go to next step |
| 4 | Is diagnostic trouble code P0733 (Gear 3 incorrect ratio) indicated? 📖 page K1–177 | Yes | Refer to flowchart for diagnostic trouble code P0733 (Gear 3 incorrect ratio), and perform troubleshooting 📖 page K1–185 |
| | | No | Go to next step |
| 5 | Inspect operation of shift solenoid A, B, C • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? 📖 page K1–35 | Yes | Go to next step |
| | | No | Replace shift solenoid A, B, or C 📖 page K1–35 Inspection step 7 • Yes: Go to next step • No: End of flowchart |
| 6 | Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK? | Yes | Go to next step |
| | | No | Repair or replace control valve and replace return spring |
| 7 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 📖 page K1–178 | Yes | Replace powertrain control module 📖 section F2 |
| | | No | Problem is a temporary slip of clutch, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P0740 | | TORQUE CONV CLUTCH SYS—MALFUNCTION (Torque Converter Clutch System Malfunction) | |
|-------------------------------|--|--|---|
| DETAILS | | Powertrain control module outputs torque converter clutch signal, but no torque converter clutch obtained | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • ATF level low • Torque converter clutch slippage • Torque converter clutch solenoid valve malfunction • Powertrain control module malfunction | <ul style="list-style-type: none"> • Line pressure low • Control valve stuck • Torque converter clutch control solenoid valve malfunction |
| STEP | INSPECTION | ACTION | |
| 1 | Are amount and condition (color) of ATF OK? Check for ATF leakage at transaxle connection and gasket Color ① Transparent red: Normal ② Black: Defective part in powertrain ③ Light red: Water mixed in fluid ④ Reddish brown: Deteriorated ATF ☞ page K1-18 | Yes | Go to next step |
| | | No | Adjust ATF amount or replace ATF if necessary • If ATF color is ②, disassemble transaxle and repair or replace any defective parts as necessary • If ATF color is ③ or ④, replace ATF |
| 2 | Check line pressure in D range (O/D OFF SW OFF) • Is line pressure OK? Line pressure when in D range (O/D OFF SW OFF) Idling: 420—530 kPa {4.2—5.5 kgf/cm ² , 60—78 psi} Stalled: 1,100—1,170 kPa {11.2—12.0 kgf/cm ² , 160—170 psi} ☞ page K1-11 | Yes | Go to next step |
| | | No | Repair or replace any defective parts • ATF leakage in transaxle case, oil pump, control valve |
| 3 | Inspect operation of solenoid valve • Disconnect negative battery cable • Disconnect solenoid connector • Is it operating OK? ☞ page K1-35 | Yes | Go to next step |
| | | No | Replace torque converter clutch solenoid valve or torque converter clutch control solenoid valve ☞ page K1-35 |
| 4 | Check operation of each valve and inspect return spring • Is each valve operating OK and is return spring OK? | Yes | Go to next step |
| | | No | Repair or replace control valve and replace return spring |
| 5 | Check difference between engine speed and turbine speed during torque converter clutch operation in fourth gear • Connect EC-AT tester to powertrain control module • Check difference between engine speed and turbine speed during torque converter clutch operation in fourth gear Is there a difference between engine speed and turbine speed? ☞ page K1-20 | Yes | Replace torque converter |
| | | No | Go to next step |
| 6 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ☞ page K1-178 | Yes | Replace powertrain control module ☞ section F2 |
| | | No | Problem is a temporary slip of clutch, and should be investigated further |






| DIAGNOSTIC TROUBLE CODE P0745 | | PRESSURE CTRL SOLENOID—MALFUNCTION (Pressure Control Solenoid Malfunction) | |
|-------------------------------|---|---|--|
| DETAILS | <ul style="list-style-type: none"> • Damaged wiring or connectors between pressure control solenoid and powertrain control module • Short or open circuit in pressure control solenoid • Short or open circuit in powertrain control module internal transistors | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • Damaged wiring or connectors between pressure control solenoid and powertrain control module • Short or open circuit in pressure control solenoid • Short or open circuit in powertrain control module internal transistors | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and pressure control solenoid connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 5 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Does indication on EC-AT tester display change according to throttle opening angle? Indication Pressure control solenoid: Light (Wide open throttle)—Dark (Closed throttle position)  page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of pressure control solenoid and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connectors • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance between pressure control solenoid terminals <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance between terminals correct? Resistance: 9—18 Ω  page K1-35 | Yes | Go to next step |
| | | No | Replace pressure control solenoid  page K1-35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-178 | Yes | Replace the powertrain control module  section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| | | | |
|--------------------------------------|--|--|--|
| DIAGNOSTIC TROUBLE CODE P0750 | | SHIFT SOLENOID A—MALFUNCTION (Shift Solenoid A Malfunction) | |
| DETAILS | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid A and powertrain control module • Short or open circuit in shift solenoid A • Short or open circuit in powertrain control module internal transistor | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid A and powertrain control module • Short or open circuit in shift solenoid A • Short or open circuit in powertrain control module internal transistor | | |
| STEP | INSPECTION | ACTION | |
| 1 | Are powertrain control module and shift solenoid A connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 6 • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display • Connect EC-AT tester to powertrain control module • Is light for shift solenoid A normally off and illuminated when valve is on?  page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of shift solenoid A and powertrain control module • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 • When Yes , go to step 6 • When No , go to next step |
| 4 | Measure resistance at shift solenoid A terminal • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 11—27 Ω  page K1-35 | Yes | Go to next step |
| | | No | Replace shift solenoid A  page K1-35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-178 | Yes | Replace powertrain control module  section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P0755 | | SHIFT SOLENOID B—MALFUNCTION (Shift Solenoid B Malfunction) | |
|-------------------------------|---|--|---|
| DETAILS | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid B and powertrain control module • Short or open circuit in shift solenoid B • Short or open circuit in powertrain control module internal transistors | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid B and powertrain control module • Short or open circuit in shift solenoid B • Short or open circuit in powertrain control module internal transistors | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and shift solenoid B connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 6 • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is light for shift solenoid B normally off and illuminated when valve is on?  page K1–20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of shift solenoid B and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 • When Yes , go to step 5 • When No , go to next step |
| 4 | Measure resistance at shift solenoid B terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 11—27 Ω  page K1–35 | Yes | Go to next step |
| | | No | Replace shift solenoid B  page K1–35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1–178 | Yes | Replace powertrain control module  section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P0760 | | SHIFT SOLENOID C—MALFUNCTION (Shift Solenoid C Malfunction) | |
|-------------------------------|---|--|---|
| DETAILS | | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid C and powertrain control module • Short or open circuit in shift solenoid C • Short or open circuit in powertrain control module internal transistor | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • Damaged wiring or connectors between shift solenoid C and powertrain control module • Short or open circuit in shift solenoid C • Short or open circuit in powertrain control module internal transistor | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and shift solenoid C connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 5 • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is light for shift solenoid C normally off and illuminated when valve is on? 🔍 page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of shift solenoid C and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance at shift solenoid C terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 11—27 Ω 🔍 page K1-35 | Yes | Go to next step |
| | | No | Replace shift solenoid C 🔍 page K1-35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 🔍 page K1-178 | Yes | Replace powertrain control module 🔍 section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P1743 | | SOLENOID TCC—OPEN OR SHORT (Torque converter clutch control solenoid valve) | |
|-------------------------------|---|---|--|
| DETAILS | | <ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch control solenoid valve and powertrain control module • Short or open circuit in torque converter clutch control solenoid valve • Short or open circuit in powertrain control module internal transistors | |
| POSSIBLE CAUSE | | <ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch control solenoid valve and powertrain control module • Short or open circuit in torque converter clutch control solenoid valve • Short or open circuit in powertrain control module internal transistor | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and torque converter clutch control solenoid valve connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 5 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is light for torque converter clutch control solenoid valve normally off and illuminated when valve is on? ⚙️ page K1–20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of torque converter clutch control solenoid valve and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance at torque converter clutch control solenoid valve terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 11—27 Ω ⚙️ page K1–35 | Yes | Go to next step |
| | | No | Replace torque converter clutch control solenoid valve ⚙️ page K1–35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown ⚙️ page K1–178 | Yes | Replace powertrain control module ⚙️ section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |


| DIAGNOSTIC TROUBLE CODE P1744 | | SOLENOID TCC—OPEN OR SHORT (Torque converter clutch solenoid valve) | |
|-------------------------------|--|--|--|
| DETAILS | <ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch solenoid valve and powertrain control module • Short or open circuit in torque converter clutch solenoid valve • Short or open circuit in powertrain control module internal transistor | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • Damaged wiring or connectors between torque converter clutch solenoid valve and powertrain control module • Short or open circuit in torque converter clutch solenoid valve • Short or open circuit in powertrain control module internal transistor | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and torque converter clutch solenoid valve connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 5 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Does indication on EC-AT tester display change when torque converter clutch slip operation occur? Indication Light (torque converter clutch slip operation)—Dark (torque converter clutch operation)  page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminal of torque converter clutch solenoid valve and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance at torque converter clutch solenoid valve terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 9—18 Ω  page K1-35 | Yes | Go to next step |
| | | No | Replace torque converter clutch solenoid valve  page K1-35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown  page K1-178 | Yes | Replace powertrain control module  section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

| DIAGNOSTIC TROUBLE CODE P1765 | | 3-2 TIMING SOL. V—OPEN OR SHORT (3-2 timing solenoid valve) | |
|-------------------------------|--|--|--|
| DETAILS | <ul style="list-style-type: none"> • Damaged wiring or connectors between 3-2 timing solenoid valve and powertrain control module • Short or open circuit in 3-2 timing solenoid valve • Short or open circuit in powertrain control module internal transistors | | |
| POSSIBLE CAUSE | <ul style="list-style-type: none"> • Damaged wiring or connectors between 3-2 timing solenoid valve and powertrain control module • Short or open circuit in 3-2 timing solenoid valve • Short or open circuit in powertrain control module internal transistors | | |
| STEP | INSPECTION | | ACTION |
| 1 | Are powertrain control module and 3-2 timing solenoid valve connections at connector and connector pins OK? | Yes | Go to next step |
| | | No | Repair or replace connector(s) Inspection step 5 <ul style="list-style-type: none"> • Yes: Go to next step • No: End of flowchart |
| 2 | Check EC-AT tester display <ul style="list-style-type: none"> • Connect EC-AT tester to powertrain control module • Is light for 3-2 timing solenoid valve normally off and illuminated when valve is on? 🔍 page K1-20 | Yes | Go to step 5 |
| | | No | Go to next step |
| 3 | Check for continuity between terminals of 3-2 timing solenoid valve and powertrain control module <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector and powertrain control module connector • Is there continuity between terminals? | Yes | Go to next step |
| | | No | Repair or replace connectors and wiring Go to step 2 <ul style="list-style-type: none"> • When Yes, go to step 5 • When No, go to next step |
| 4 | Measure resistance at 3-2 timing solenoid valve terminal <ul style="list-style-type: none"> • Disconnect negative battery cable • Disconnect solenoid connector • Is resistance correct? Resistance: 11—27 Ω 🔍 page K1-35 | Yes | Go to next step |
| | | No | Replace 3-2 timing solenoid valve 🔍 page K1-35 |
| 5 | After diagnostic trouble code has been cleared, re-check if diagnostic trouble code is shown 🔍 page K1-178 | Yes | Replace powertrain control module 🔍 section F2 |
| | | No | Problem is a temporary poor connection of wiring or connectors, and should be investigated further |

TROUBLESHOOTING GUIDE


GENERAL NOTES

A problem with the EC-AT may be caused by the engine, the EC-AT powertrain, the hydraulic control system, or the electronic control system; therefore, when troubleshooting, begin with those points which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.




Step 1: On-board diagnostic system inspection

Check for diagnostic trouble code(s) memorized in the powertrain control module with the NGS. (Refer to page K1-177.)



Step 2: Mechanical system test

Check the engine stall speed, time lag, and line pressure. (Refer to page K1-10.)



Step 3: Road test

Check the shift point, shift schedule, and shift shock. (Refer to page K1-15.)

QUICK DIAGNOSIS CHART

OUTLINE

The Quick Diagnosis Chart shows various problems and the various components that might be the cause of the problem.

1. Components indicated in the "On-board diagnosis" line of the QUICK DIAGNOSIS CHART (I) are diagnosed by the powertrain control module on-board diagnostic system. NGS can be used for easy retrieval of the diagnostic trouble code numbers.
2. Components indicated in the "Adjustment" line of the QUICK DIAGNOSIS CHART (I) indicate that there is a possibility that the problem may be the result of an incorrect adjustment. Check the adjustment of each component, and readjust if necessary.
3. Components indicated in the "Stall test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the stall test.
4. Components indicated in the "Time lag test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the time lag test.
5. Components indicated in the "Line pressure test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the line pressure test.
6. Components indicated in the "Road test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the road test.
7. QUICK DIAGNOSIS CHART (II) shows the relationship between the troubleshooting item and inspection point.

QUICK DIAGNOSIS CHART (I)

| Possible parts and reference page | Preliminary | | Emission control system | | | | | | | | | | | | | | Electronic system | | | | | | | | | | | | |
|-----------------------------------|-------------------------|-----------------------|--------------------------------|------------|---------------|--------------------|-----------|-------------|----------------------|---|---------------------------------------|------------|---------------|--|--------------------------------|------------|-------------------|------------|-----------|--------------------|-------------|---------------------|------------|----------------|------------------------|--------------------------|---------------------------------|----------------------------|----------------------------|
| | K1-18 | K1-170 | section F2 | K1-12 | K1-13 | K1-11 | K1-15 | section F2 | section F2 | section F2 | section F2 | section F2 | section F2 | section G | section G | section G | section F2 | section F2 | section G | section F2 | section F2 | section F2 | section B2 | K1-28 | K1-29 | section F2 | section F2 | K1-32 | K1-33 |
| Item | ATF level and condition | Selector lever | Idle speed and ignition timing | Stall test | Time lag test | Line pressure test | Road test | Air leakage | Mass air flow sensor | Engine coolant temperature sensor (EGT) | Oxygen sensor (right side, left side) | IAC valve | Fuel injector | Ignition control module (in distributor) | Ignition coil (in distributor) | Spark plug | Fuel pump | Main relay | Generator | Pressure regulator | Fuel filter | Air cleaner element | Camshaft | O/D OFF switch | Transaxle range switch | Throttle position sensor | Closed throttle position switch | Input/turbine speed sensor | Vehicle speedometer sensor |
| On-board diagnosis | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Adjustment | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | |
| Stall test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Time lag test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Line pressure test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Road test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

QUICK DIAGNOSIS CHART (I)

| Electronic system | | Hydraulic control system | Powertrain | Possible parts and reference page |
|-----------------------|--|--------------------------|------------|-----------------------------------|
| | Brake switch | | | |
| <input type="radio"/> | Transaxle fluid temperature sensor | | | |
| | Barometric pressure sensor | | | |
| <input type="radio"/> | Shift solenoid A | | | |
| <input type="radio"/> | Shift solenoid B | | | |
| <input type="radio"/> | Shift solenoid C | | | |
| <input type="radio"/> | Torque converter clutch control solenoid valve | | | |
| <input type="radio"/> | 3-2 timing solenoid valve | | | |
| <input type="radio"/> | Torque converter clutch solenoid valve | | | |
| <input type="radio"/> | Pressure control solenoid | | | |
| | Powertrain control module | | | |
| | Oil pump | | | |
| | Control valve body | | | |
| | 1-2 accumulator | | | |
| | 2-3 accumulator | | | |
| | N-D accumulator | | | |
| | N-R accumulator | | | |
| | Torque converter | | | |
| | Forward clutch | | | |
| | Coasting clutch | | | |
| | Reverse clutch | | | |
| | 3-4 clutch | | | |
| | 2-4 brake band | | | |
| | Low and reverse brake | | | |
| | One-way clutch 1 (sprag type) | | | |
| | One-way clutch 2 (roller type) | | | |
| | Planetary gear | | | |
| | Parking mechanism | | | |
| | Differential | | | |
| | | | | On-board diagnosis |
| | | | | Adjustment |
| | | | | Stall test |
| | | | | Time lag test |
| | | | | Line pressure test |
| | | | | Road test |

QUICK DIAGNOSIS CHART (II)

| Item | Possible parts and reference page | Preliminary | | | | | | | Emission control system | | | | | | | | | | Electronic system | | | | | | | | | | |
|------|---|---|--------|------------|-------|-------|-------|-------|-------------------------|------------|------------|------------|------------|------------|-----------|-----------|-----------|------------|-------------------|-----------|------------|------------|------------|-------|-------|------------|------------|-------|-------|
| | | K1-18 | K1-170 | section F2 | K1-12 | K1-13 | K1-11 | K1-15 | section F2 | section F2 | section F2 | section F2 | section F2 | section F2 | section G | section G | section G | section F2 | section F2 | section G | section F2 | section F2 | section F2 | K1-28 | K1-29 | section F2 | section F2 | K1-32 | K1-33 |
| | | ATF level and condition | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Selector lever | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Idle speed and ignition timing | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Stall test | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Time lag test | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Line pressure test | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Road test | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Air leakage | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Mass air flow sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Engine coolant temperature sensor (EGI) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Oxygen sensor (right side, left side) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | IAC valve | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Fuel injector | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Ignition control module (in distributor) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Ignition coil (in distributor) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Spark plug | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Fuel pump | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Main relay | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Generator | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Pressure regulator | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Fuel filter | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Air cleaner element | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | O/D OFF switch | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Transaxle range switch | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Throttle position sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Closed throttle position switch | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Vehicle speedometer sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Will start in positions and ranges other than P and N | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Engine stalls | Idle when shifted from N or P to other ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 18 | | On deceleration | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 24 | Engine runs rough | On deceleration | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | Poor acceleration | Driveaway | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 26 | | On acceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | Surges while cruising | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | Lack of power | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 32 | Poor fuel economy | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 40 | Vehicle does not move in D, 2, 1 ranges and/or R position | | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 41 | Vehicle moves in N position | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 42 | Vehicle moves in P position | | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 43 | Excessive creep | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 44 | No shift | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 | Abnormal shift | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 46 | Frequent shifting | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 47 | Shift point high or low | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 48 | TCC non operation | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 49 | No kickdown | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 50 | Engine speed flares up | When accelerating | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 51 | | When upshifting and/or downshifting | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 52 | Excessive shift shock | P, N to R and/or N to D | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 53 | | When upshifting and/or downshifting | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 54 | No engine braking | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 55 | No mode changes | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 56 | Transaxle noise | All ranges | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 57 | | D, 2, 1, ranges and R position | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 58 | Transaxle overheats | | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | |

QUICK DIAGNOSIS CHART (II)

| Electronic system | | | Hydraulic control system | | | Powertrain | | | Possible parts and reference page | | |
|-------------------|---------------------|-----------|--------------------------|---------------------|-----------|------------|---------------------|-----------|-----------------------------------|---|-----------|
| Item | Failure Description | Diagnosis | Item | Failure Description | Diagnosis | Item | Failure Description | Diagnosis | Item | Failure Description | Diagnosis |
| | | | | | | | | | | Will start in positions and ranges other than P and N | 6 |
| | | | | | | | | | | Idle when shifted from N or P to other ranges | 14 |
| | | | | | | | | | | On deceleration | 18 |
| | | | | | | | | | | On deceleration | 24 |
| | | | | | | | | | | Driveaway | 25 |
| | | | | | | | | | | On acceleration | 26 |
| | | | | | | | | | | Surges while cruising | 30 |
| | | | | | | | | | | Lack of power | 31 |
| | | | | | | | | | | Poor fuel economy | 32 |
| | | | | | | | | | | Vehicle does not move in D, 2, 1 ranges and/or R position | 40 |
| | | | | | | | | | | Vehicle moves in N position | 41 |
| | | | | | | | | | | Vehicle moves in P position | 42 |
| | | | | | | | | | | Excessive creep | 43 |
| | | | | | | | | | | No shift | 44 |
| | | | | | | | | | | Abnormal shift | 45 |
| | | | | | | | | | | Frequent shifting | 46 |
| | | | | | | | | | | Shift point high or low | 47 |
| | | | | | | | | | | TCC non operation | 48 |
| | | | | | | | | | | No kickdown | 49 |
| | | | | | | | | | | When accelerating | 50 |
| | | | | | | | | | | When upshifting and/or downshifting | 51 |
| | | | | | | | | | | P, N to R and/or N to D | 52 |
| | | | | | | | | | | When upshifting and/or downshifting | 53 |
| | | | | | | | | | | No engine braking | 54 |
| | | | | | | | | | | No mode changes | 55 |
| | | | | | | | | | | All ranges | 56 |
| | | | | | | | | | | D, 2, 1, ranges and R position | 57 |
| | | | | | | | | | | Transaxle noise | 57 |
| | | | | | | | | | | Transaxle overheats | 58 |


SYMPTOM TROUBLESHOOTING

USING THIS SECTION

Introduction

Most of the automatic transaxle control system is electronically controlled, often making it difficult to diagnose problems in the system, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer is often a good source of information on such problems, especially intermittent ones. Through talks with the customer, one can find out what the symptoms are and under what conditions they occur.

Work Flow



Diagnosis Index

No.:
Each troubleshooting item is assigned a number

Troubleshooting Item:
There are 58 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

| DIAGNOSTIC INDEX | | | DESCRIPTION | PAGE |
|------------------|---|--|---|------------|
| No. | TROUBLE | | | |
| 1 | Melts main or other fuse | | Starter does not work | section F2 |
| 2 | Will not crank or cranks slowly | | Starter cranks engine at slow speed | section F2 |
| 3 | | No combustion | Starter cranks engine at normal speed but engine shows no indication of firing | section F2 |
| 4 | Canks normally but will not start | Partial combustion — when engine cold | Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting | section F2 |
| 5 | | Partial combustion — when engine warm | Engine will not continue running when cold when ignition switch is returned from STA to IG position | |
| 6 | | Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm | Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm | section F2 |
| 6 | Will start in positions and ranges other than P and N | | Engine starts in all positions and ranges | K1-201 |
| 7 | | Any engine temp. | Starter cranks engine at normal speed but engine requires excessive cranking time before starting at any engine temperature | section F2 |
| 8 | Canks normally but hard to start | When engine cold | Engine starts after stalling a few times at any engine temperature | |
| 9 | | After warm-up | Starter cranks engine at normal speed but engine requires excessive cranking time before starting after warm-up | |
| 10 | | Idle at any engine temp. | Starter cranks engine at normal speed but engine requires excessive cranking time before starting when engine is cold | section F2 |
| 11 | | During fast idle | Engine starts after stalling a few times when engine is cold | section F2 |
| 12 | | Idle after warm-up | Engine stops unexpectedly at any engine temp. | section F2 |
| 13 | | Idle with A/C, P/S, and/or E/L ON | Engine stops unexpectedly during fast idle operation | section F2 |
| 14 | Engine stalls | Idle when shifted from N or P to other position all ranges | Engine stops unexpectedly at idle after warm-up | section F2 |
| 15 | | Driveway | Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle | section F2 |
| 16 | | On acceleration | Engine stops unexpectedly upon driveway | section F2 |
| 17 | | While cruising | Engine stops unexpectedly at beginning of acceleration or during acceleration | section F2 |
| 18 | | On deceleration | Engine stops unexpectedly while cruising | section F2 |
| 19 | Engine rough | Idle at any engine temp. | Engine stops unexpectedly at beginning of deceleration or recovery from deceleration without afterburn | section F2 |
| 20 | | During fast idle | Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. | K1-203 |
| 21 | | Idle after warm-up | Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. | section F2 |
| | | | Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up | section F2 |
| | | | Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up | section F2 |

Description:
Describes each troubleshooting item.

Page:
Shows the reference page or section

Troubleshooting chart

| | | | |
|---|---|---|---|
| 14 | ENGINE STALLS | • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES | |
| DESCRIPTION • Engine stops unexpectedly when shifted from N or P to other ranges at idle | | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Engine idle speed low | | ③ Shift solenoid A and/or torque converter clutch control solenoid valve worn | |
| ② Control valve stuck (pressure regulator valve, converter relief valve, solenoid reducing valve, torque converter clutch shift valve and/or torque converter clutch control valve) | | ④ Transaxle range switch worn or misadjusted | |
| STEP | INSPECTION | ACTION | |
| 1 | Are ignition timing and idle speed OK? ⓘ section F2 | Yes | Go to next step |
| | | No | Adjust ignition timing and/or idle speed ⓘ section F2 |
| 2 | Is problem corrected when 10 pin connector of solenoid valve is disconnected? | Yes | Go to next step |
| | | No | Overhaul control valve body and repair or replace parts as necessary If large amounts of material are found, overhaul and repair or replace parts as necessary |

DESCRIPTION:

Further describes the symptom. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page shown by the “ⓘ” mark.

ACTION

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page shown by the “ⓘ” mark.

DIAGNOSTIC INDEX

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|---|---|----------------------|
| No. | TROUBLE | | |
| 1 | Burnt main or other fuse | | section F2 |
| 2 | Will not crank or cranks slowly | Starter does not work Starter cranks engine at slow speed | section F2 |
| 3 | Crank normally but will not start | No combustion Starter cranks engine at normal speed but engine shows no indication of firing | section F2 |
| 4 | | Partial combustion — when engine cold Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting Engine will not continue running when cold when ignition switch is returned from STA to ON position | section F2 |
| 5 | | Partial combustion — when engine warm Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm Engine will not continue running when warm when ignition switch is returned from STA to ON position | section F2 |
| 6 | Will start in positions and ranges other than P and N | Engine starts in all positions and ranges | K1–205 |
| 7 | Crank normally but hard to start | Any engine temp. Starter cranks engine at normal speed but engine requires excessive cranking time before starting at any engine temperature Engine starts after stalling a few times at any engine temperature | section F2 |
| 8 | | When engine cold Starter cranks engine at normal speed but engine requires excessive cranking time before starting when engine is cold Engine starts after stalling a few times when engine is cold | section F2 |
| 9 | | After warm-up Starter cranks engine at normal speed but engine requires excessive cranking time before starting after warm-up | section F2 |
| 10 | Engine stalls | Idle at any engine temp. Engine stops unexpectedly at any engine temp. | section F2 |
| 11 | | During fast idle Engine stops unexpectedly during fast-idle operation | section F2 |
| 12 | | Idle after warm-up Engine stops unexpectedly at idle after warm-up | section F2 |
| 13 | | Idle with A/C, P/S, and/or E/L ON Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle | section F2 |
| *14 | | Idle when shifted from N or P to other position and all ranges Engine stops unexpectedly when shifted from N or P to other ranges at idle | section F2 K1–205 |
| 15 | | Driveaway Engine stops unexpectedly upon driveaway | section F2 |
| 16 | | On acceleration Engine stops unexpectedly at beginning of acceleration or during acceleration | section F2 |
| 17 | | While cruising Engine stops unexpectedly while cruising | section F2 |
| *18 | | On deceleration Engine stops unexpectedly at beginning of deceleration or recovery from deceleration exhaust afterburn | section F2 K1–207 |
| 19 | Engine rough | Idle at any engine temp. Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. Idle speed too slow and excessive engine shake at any engine temp. | section F2 |
| 20 | | During fast idle Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up | section F2 |
| 21 | | Idle after warm-up Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up | section F2 |

* Refer to section F2 before referring to K1 section.

| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE |
|----------------------|---|--|----------------------|
| No. | TROUBLE | | |
| 22 | Idle with A/C, P/S, and/or E/L ON | Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when A/C, P/S, and/or E/L ON | section F2 |
| 23 | Engine runs rough | Idle when shifted from N or P to other range | section F2 |
| *24 | | On deceleration | section F2 K1-208 |
| *25 | Poor acceleration | Driveaway | section F2 K1-209 |
| *26 | | On acceleration | |
| 27 | High idle speed after warm-up | Idle speed continues at fast idle after warm-up, engine returns slowly to idle after accelerator is released | section F2 |
| 28 | Idle fluctuates/Idle hunts | Engine speed changes back and forth between specified idle speed and higher speed | section F2 |
| 29 | Hesitates/Stumbles on acceleration | Momentary pause at beginning of acceleration or during acceleration | section F2 |
| *30 | Surges while cruising | Momentary minor irregularity in engine output at steady vehicle speed | section F2 K1-211 |
| *31 | Lack of power | Performance poor under load (i.e., power down when climbing hills) | section F2 K1-212 |
| *32 | Poor fuel economy | Fuel economy unsatisfactory | section F2 K1-212 |
| 33 | A/C does not work | A/C compressor magnetic clutch does not engage when A/C switch ON | section F2 |
| 34 | Knocking/Pinging | Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber) | section F2 |
| 35 | Fuel odor | Gasoline fuel smell or visible leaks | section F2 |
| 36 | Exhaust sulfur smell | Rotten egg smell from exhaust | section F2 |
| 37 | High oil consumption | Oil consumption excessive | section F2 |
| 38 | NGS displays "LINK COMMUNICATION ERROR" | NGS displays "LINK COMMUNICATION ERROR" with ignition switch ON | section F2 |
| 39 | MIL never ON | Self-Diagnosis Checker indicates diagnostic trouble code No. of input device but MIL never ON | section F2 |
| 40 | Vehicle does not move in D, 2, 1 ranges and/or R position | No creep at all Vehicle does not move when accelerator pedal depressed after shifted to D, 2, 1 ranges and/or R position | K1-212 |
| 41 | Vehicle moves in N position | Vehicle creeps in N position Vehicle moves when accelerator pedal not depressed | K1-212 |
| 42 | Vehicle moves in P position | Vehicle rolls in P position, and drivetrain TCC non operation | K1-212 |
| 43 | Excessive creep | Vehicle moves quickly in D, 2, 1 ranges and R position (accelerator pedal not depressed) Excessive N to R position and N to D range shift shock felt | K1-212 |
| 44 | No shift | Single range shift (1→2, 2→3, or 3→4) only Sometimes shifts correctly With gear position in O/D OFF mode: Shifts single ranges only (1-2, 2-3, or 3-4) Shifts incorrectly at times | K1-213 |

* Refer to section F2 before referring to K1 section.






| TROUBLESHOOTING ITEM | | DESCRIPTION | PAGE | |
|----------------------|-------------------------|---|--|--------|
| No. | TROUBLE | | | |
| 45 | Abnormal shift | Shifts incorrectly (incorrect shift pattern) (ex) Vehicle shifts 1→4 directly when accelerating with accelerator pedal depressed slightly | K1-215 | |
| 46 | Frequent shifting | Downshift occurs when accelerator depressed slightly in D (except O/D OFF mode), 2 and 1 ranges | K1-217 | |
| 47 | Shift point high or low | Shift points do not match shift diagram Shifts delayed when accelerating Shifts occur too fast when accelerating and engine speed does not increase | K1-218 | |
| 48 | TCC non operation | TCC non operation when vehicle speed reaches TCC operation range | K1-220 | |
| 49 | No kickdown | Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range | K1-220 | |
| 50 | Engine speed flares up | When accelerating | Engine speed flares up on acceleration | K1-220 |
| 51 | | When upshifting and/or downshifting | Engine flares up when accelerator pedal depressed for upshifting Engine flares up suddenly when accelerator pedal depressed for downshifting | K1-221 |
| 52 | Excessive shift shock | P, N to R and/or N to D | Strong shift shock felt at idle when shifting from N position to D range or R position | K1-223 |
| 53 | | When upshifting and/or downshifting | Excessive shift shock felt when accelerating at upshifting During cruising, excessive shift shock felt when accelerator pedal depressed at downshifting | K1-226 |
| 54 | No engine braking | Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in 1 range at low vehicle speed | K1-229 | |
| 55 | No mode change | Mode does not change to/from normal mode in D range O/D OFF mode not selected or not cancelled | K1-231 | |
| 56 | Transaxle noise | All ranges | Transaxle noisy in all ranges when vehicle is idling | K1-231 |
| 57 | | D, 2, 1 ranges, R position | Abnormal noise from transaxle in D, 2, 1, R | K1-231 |
| 58 | Transaxle overheats | ATF smells burnt and/or is discolored | K1-231 | |




SYMPTOM TROUBLESHOOTING CHART







| | |
|--|--|
| 6 | WILL START IN POSITIONS AND RANGES OTHER THAN P AND N |
| DESCRIPTION | • Engine starts in all positions and ranges |
| [TROUBLESHOOTING HINTS] Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Selector lever installation or adjustment incorrect | 👉 page K1-170 |
| ② Transaxle range switch worn or misadjusted | 👉 page K1-29 |






| 14 | ENGINE STALLS | • IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|--|------------|------|-------|-----------|------|----|---|-------|--------------------|---|---|---|--------------|------------|----|-------------|----|---|-------|--------------------|---|---|---|-------------------|------------|----|---------------|----------|----------|----|------------------|----|--|
| DESCRIPTION | • Engine stops unexpectedly when shifted from N or P to other ranges at idle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ① Engine idle speed low | ③ Shift solenoid A and/or torque converter clutch control solenoid valve worn | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ② Control valve stuck (pressure regulator valve, converter relief valve, solenoid reducing valve, torque converter clutch shift valve and/or torque converter clutch control valve) | ④ Transaxle range switch worn or misadjusted | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Are ignition timing and idle speed OK? 👉 section F2 | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Adjust ignition timing and/or idle speed 👉 section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Is problem corrected when 10-pin connector of solenoid valve is disconnected? | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Overhaul control valve body and repair or replace parts as necessary If large amounts of material are found, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | If resistance not OK, check for malfunctioning parts and wiring • Shift solenoid A 👉 page K1-35 • Torque converter clutch control solenoid valve 👉 page K1-35 If resistance OK but voltage not, replace powertrain control module 👉 section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">2A</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">11—27</td> <td>Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td>Solenoid OFF</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3" style="text-align: center;">2C</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">11—27</td> <td>Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td>TCC non operation</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">B+</td> <td>TCC operation</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2A</td> <td style="text-align: center;">Shift solenoid A</td> </tr> <tr> <td style="text-align: center;">2C</td> <td style="text-align: center;">Torque converter clutch control solenoid valve</td> </tr> </tbody> </table> | | | | Term. | Unit | Spec. | Condition | Page | 2A | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2C | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | TCC non operation | section F2 | B+ | TCC operation | Terminal | Function | 2A | Shift solenoid A | 2C | Torque converter clutch control solenoid valve |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2C | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | TCC non operation | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | TCC operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Shift solenoid A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2C | Torque converter clutch control solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------|---|--------|----------------------------|------------|-----------|------|----|---|---|-------------------|------------|----|----------------------------|----|---|----|------------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----------|----------|----------------|------------------------|---|-----|---|----|--|
| 4 | <p>Are measurements at powertrain control module terminals OK?</p> <p>B+: Battery positive voltage</p> <table border="1" data-bbox="196 260 711 735"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td rowspan="2">V</td> <td>0</td> <td>P and N positions</td> <td rowspan="8">section F2</td> </tr> <tr> <td>B+</td> <td>Other position, all ranges</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>B+</td> <td>R position</td> </tr> <tr> <td>0</td> <td>Other position, all ranges</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> <tr> <td rowspan="2">2M</td> <td rowspan="2">V</td> <td>B+</td> <td>2 range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> <tr> <td rowspan="2">2R</td> <td rowspan="2">V</td> <td>B+</td> <td>1 range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> <table border="1" data-bbox="196 812 711 884"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1F,2K,2I,2M,2R</td> <td>Transaxle range switch</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 1F | V | 0 | P and N positions | section F2 | B+ | Other position, all ranges | 2K | V | B+ | R position | 0 | Other position, all ranges | 2I | V | B+ | D range | 0 | Other range, all positions | 2M | V | B+ | 2 range | 0 | Other range, all positions | 2R | V | B+ | 1 range | 0 | Other range, all positions | Terminal | Function | 1F,2K,2I,2M,2R | Transaxle range switch | <table border="1"> <tr> <td data-bbox="805 170 812 541">Yes</td> <td data-bbox="812 170 1421 541"> Replace powertrain control module ↳ section F2 </td> </tr> <tr> <td data-bbox="805 541 812 911">No</td> <td data-bbox="812 541 1421 911"> Check transaxle range switch ↳ page K1-29 </td> </tr> </table> | Yes | Replace powertrain control module ↳ section F2 | No | Check transaxle range switch ↳ page K1-29 |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F | V | 0 | P and N positions | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Other position, all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2K | V | B+ | R position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other position, all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2I | V | B+ | D range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2M | V | B+ | 2 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R | V | B+ | 1 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F,2K,2I,2M,2R | Transaxle range switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Yes | Replace powertrain control module ↳ section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | Check transaxle range switch ↳ page K1-29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 18 | ENGINE STALLS | • ON DECELERATION | | | | | | | | | |
|---|--|--|------|-------|---------|-----------------------------|-------------------------------------|---|----------------------------------|-------------------------------------|--|
| DESCRIPTION • Engine stalls when brake pedal depressed while driving at low speed or stopping | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | |
| ① ATF level low | | ② Control valve stuck | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | |
| 1 | Is ATF level OK?  page K1-18 Level: Between notches on dipstick | Yes Go to next step | | | | | | | | | |
| | | No Adjust ATF level  page K1-18 | | | | | | | | | |
| 2 | Is line pressure OK?  page K1-11 Specified line pressure kPa {kgf/cm ² , psi} | Yes Go to No.18 "ENGINE STALLS ON DECELERATION"  section F2 | | | | | | | | | |
| | | No Replace control valve body assembly  page K1-125 If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Position/Range</th> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D, 2, 1</td> <td>420—530 {4.2—5.5, 60—78}</td> <td>1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td>R</td> <td>730—1,010 {7.4—10.3, 110—146}</td> <td>1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Position/Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | |
| Position/Range | Idle | Stall | | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | |

| 24 | ENGINE RUNS ROUGH | • ON DECELERATION | |
|-------------------------|---|-------------------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration • Exhaust afterburn | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① ATF level low | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is ATF level OK?  page K1-18 Level: Between notches on dipstick | Yes | Go to No.24 "ENGINE RUNS ROUGH ON DECELERATION"  section F2 |
| | | No | Adjust ATF level  page K1-18 |

| 25, 26 | POOR ACCELERATION | <ul style="list-style-type: none"> • DRIVEAWAY • ON ACCELERATION | | | | | | | | | | | | | | | | | |
|--|--|--|---|------------|-------------|-----------------------------|-------------------------------------|---|----------------------------------|-------------------------------------|-----|-----------------|---|-------------------|------------|----|---------------|-----|---|
| DESCRIPTION • Engine speed increases normally but vehicle speed slowly increases during acceleration | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] ① Transaxle range switch worn or misadjusted ② Torque converter clutch control solenoid valve worn ③ Line pressure low ④ Powertrain slippage ⑤ Control valve stuck (pressure regulator valve, pressure modifier valve, solenoid reducing valve) ⑥ Engine power low ⑦ Powertrain control module malfunction | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | |
| 1 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON?  page K1-177 | Yes | Go to next step | | | | | | | | | | | | | | | | |
| | | No | Diagnostic trouble code(s) displayed • Check for cause of code(s)  page K1-177 | | | | | | | | | | | | | | | | |
| 2 | Is line pressure OK?  page K1-11 Specified line pressure kPa {kgf/cm², psi} <table border="1" data-bbox="280 1041 792 1220"> <thead> <tr> <th>Position/Range</th> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D, 2, 1</td> <td>420—530 {4.2—5.5, 60—78}</td> <td>1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td>R</td> <td>730—1,010 {7.4—10.3, 110—146}</td> <td>1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Position/Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | Yes | Go to next step | | | | | | | |
| Position/Range | Idle | Stall | | | | | | | | | | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | | | | | | | | | |
| | | No | Replace control valve body assembly  page K1-125 If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | |
| 3 | Is engine stall speed OK?  page K1-12 rpm <table border="1" data-bbox="280 1398 792 1472"> <thead> <tr> <th>Engine</th> <th>Engine stall speed</th> </tr> </thead> <tbody> <tr> <td>KL</td> <td>2,270—2,500</td> </tr> </tbody> </table> | Engine | Engine stall speed | KL | 2,270—2,500 | Yes | Go to step 5 | | | | | | | | | | | | |
| Engine | Engine stall speed | | | | | | | | | | | | | | | | | | |
| KL | 2,270—2,500 | | | | | | | | | | | | | | | | | | |
| | | No | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | |
| 4 | Are resistance and output duty of torque converter clutch control solenoid valve at powertrain control module OK? B+: Battery positive voltage <table border="1" data-bbox="280 1650 792 1776"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2C</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>TCC non operation</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>TCC operation</td> </tr> </tbody> </table> Unit: Ω → Resistance V → Voltage | Term. | Unit | Spec. | Condition | Page | 2C | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | TCC non operation | section F2 | B+ | TCC operation | Yes | Overhaul transaxle and repair or replace parts as necessary |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | |
| 2C | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | |
| | V | 0 | TCC non operation | section F2 | | | | | | | | | | | | | | | |
| | | B+ | TCC operation | | | | | | | | | | | | | | | | |
| | | No | If resistance not OK, check torque converter clutch control solenoid valve and wiring  page K1-35 If resistance OK but voltage is not, go to next step | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------|---|----------------|---|------------|--------------------|---------|--------------------|---------|--------------------|-------------------|-----------------|-----|----------------------------|----|---|----|------------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----------|----------|----------------|------------------------|-----|-----------------|
| 5 | Disconnect solenoid 10-pin connector; is vehicle driven as follows? <table border="1"> <thead> <tr> <th>Position/Range</th> <th>Gear position</th> </tr> </thead> <tbody> <tr> <td>D range</td> <td>Third gear (fixed)</td> </tr> <tr> <td>2 range</td> <td>Third gear (fixed)</td> </tr> <tr> <td>1 range</td> <td>First gear (fixed)</td> </tr> <tr> <td>R position</td> <td>Reverse (fixed)</td> </tr> </tbody> </table> | Position/Range | Gear position | D range | Third gear (fixed) | 2 range | Third gear (fixed) | 1 range | First gear (fixed) | R position | Reverse (fixed) | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Position/Range | Gear position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D range | Third gear (fixed) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 range | Third gear (fixed) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 range | First gear (fixed) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R position | Reverse (fixed) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | Replace control valve body assembly  page K1-125 If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Drive vehicle in D, 2 and 1 ranges; does vehicle start from stop in first gear? Is engine speed (drum rpm) at 20 km/h {12 mph} and throttle opening OK? Engine speed: Approx. 2,100 rpm Throttle opening: 4/8 | Yes | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td rowspan="2">V</td> <td>0</td> <td>P and N positions</td> <td rowspan="10">section F2</td> </tr> <tr> <td>B+</td> <td>Other position, all ranges</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>B+</td> <td>R position</td> </tr> <tr> <td>0</td> <td>Other position, all ranges</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> <tr> <td rowspan="2">2M</td> <td rowspan="2">V</td> <td>B+</td> <td>2 range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> <tr> <td rowspan="2">2R</td> <td rowspan="2">V</td> <td>B+</td> <td>1 range</td> </tr> <tr> <td>0</td> <td>Other range, all positions</td> </tr> </tbody> </table> Unit: V → Voltage <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1F,2K,2I,2M,2R</td> <td>Transaxle range switch</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 1F | V | 0 | P and N positions | section F2 | B+ | Other position, all ranges | 2K | V | B+ | R position | 0 | Other position, all ranges | 2I | V | B+ | D range | 0 | Other range, all positions | 2M | V | B+ | 2 range | 0 | Other range, all positions | 2R | V | B+ | 1 range | 0 | Other range, all positions | Terminal | Function | 1F,2K,2I,2M,2R | Transaxle range switch | Yes | Go to next step |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F | V | 0 | P and N positions | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Other position, all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2K | V | B+ | R position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other position, all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2I | V | B+ | D range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2M | V | B+ | 2 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R | V | B+ | 1 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other range, all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F,2K,2I,2M,2R | Transaxle range switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | Check transaxle range switch and wiring If problem remains, return to step 5  page K1-29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Replace with known good powertrain control module; is problem corrected?  section F2 | Yes | Replace powertrain control module  section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Replace torque convertor  page K1-58 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 30 | SURGES WHILE CRUISING | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---|---|----------------|--|-------|-----------|---------|-------------|------------------|----------------------|-------------------------------------|------------|-------------|----------------------------|---------------------|----------------------|---------|---|------------|---------|-----------------------------------|----------|----------|----|---------------------------|----|--------------------------|----|
| DESCRIPTION • Momentary minor irregularity in engine output at steady vehicle speed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ① Input/turbine speed sensor malfunction | | ④ Engine speed input signal malfunction | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ② Control valve stuck | | ⑤ Powertrain control module malfunction | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ③ Throttle position sensor malfunction or misadjusted | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | | | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Is resistance of input/turbine speed sensor at powertrain control module OK? | | | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Term.</th> <th style="width: 15%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 55%;">Condition</th> </tr> </thead> <tbody> <tr> <td>2P↔2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign:OFF)</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Terminal</th> <th style="width: 70%;">Function</th> </tr> </thead> <tbody> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> </tbody> </table> | | | Term. | Unit | Spec. | Condition | 2P↔2T | Ω | 253—604 | Constant (Ign:OFF) | Terminal | Function | 2P | Input/turbine speed sensor | 2T | Ground (input) | No | Check input/turbine speed sensor and wiring 👉 page K1-32 | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P↔2T | Ω | 253—604 | Constant (Ign:OFF) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Is line pressure OK? 👉 page K1-11 | | | Yes | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p>Specified line pressure kPa {kgf/cm², psi}</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Position/Range</th> <th style="width: 35%;">Idle</th> <th style="width: 50%;">Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2">D, 2, 1</td> <td>420—530</td> <td>1,100—1,170</td> </tr> <tr> <td>{4.2—5.5, 60—78}</td> <td>{11.2—12.0, 160—170}</td> </tr> <tr> <td>R</td> <td>730—1,010</td> <td>1,910—2,020</td> </tr> <tr> <td></td> <td>{7.4—10.3, 110—146}</td> <td>{19.4—20.7, 276—294}</td> </tr> </tbody> </table> | | | Position/Range | Idle | Stall | D, 2, 1 | 420—530 | 1,100—1,170 | {4.2—5.5, 60—78} | {11.2—12.0, 160—170} | R | 730—1,010 | 1,910—2,020 | | {7.4—10.3, 110—146} | {19.4—20.7, 276—294} | No | Go to next step | | | | | | | | | | |
| Position/Range | Idle | Stall | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D, 2, 1 | 420—530 | 1,100—1,170 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | {4.2—5.5, 60—78} | {11.2—12.0, 160—170} | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | 730—1,010 | 1,910—2,020 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | {7.4—10.3, 110—146} | {19.4—20.7, 276—294} | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Are measurements at powertrain control module terminals OK? | | | Yes | Check for malfunctioning parts and wiring • Engine speed input signal 👉 section F2 • Throttle position sensor 👉 section F2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 10%;">Spec.</th> <th style="width: 40%;">Condition</th> <th style="width: 30%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">4F</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0 or 4.5—5.5</td> <td>Engine stopped (ignition switch ON)</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">2.0—3.0</td> <td>Engine running at idle</td> </tr> <tr> <td rowspan="2" style="text-align: center;">3B</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Terminal</th> <th style="width: 70%;">Function</th> </tr> </thead> <tbody> <tr> <td>4F</td> <td>Engine speed input signal</td> </tr> <tr> <td>3B</td> <td>Throttle position sensor</td> </tr> </tbody> </table> | | | Term. | Unit | Spec. | Condition | Page | 4F | V | 0 or 4.5—5.5 | Engine stopped (ignition switch ON) | section F2 | 2.0—3.0 | Engine running at idle | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | Terminal | Function | 4F | Engine speed input signal | 3B | Throttle position sensor | No |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4F | V | 0 or 4.5—5.5 | Engine stopped (ignition switch ON) | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2.0—3.0 | Engine running at idle | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4F | Engine speed input signal | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | Throttle position sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | |
|---|--|
| 31 | LACK OF POWER |
| DESCRIPTION | <ul style="list-style-type: none"> • Performance poor under load (i.e., power down when climbing hills) |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Torque converter worn | 👉 page K1-58 |
| ② Powertrain burned (reverse clutch) | 👉 page K1-64 |





| | |
|--|---|
| 32 | POOR FUEL ECONOMY |
| DESCRIPTION | <ul style="list-style-type: none"> • Fuel economy unsatisfactory |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Torque converter clutch solenoid valve worn | 👉 page K1-35 |
| ② Torque converter clutch control solenoid valve worn | 👉 page K1-35 |

| | |
|--|--|
| 40 | VEHICLE DOES NOT MOVE IN D, 2, 1 RANGES, AND/OR R POSITION |
| DESCRIPTION | <ul style="list-style-type: none"> • No creep at all • Vehicle does not move when accelerator pedal depressed after shifted to D, 2, 1 ranges, and/or R position |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | |
| ① ATF level low | 👉 page K1-18 |
| ② Selector lever installation or adjustment incorrect | 👉 page K1-170 |
| ③ Line pressure low | 👉 page K1-11 |
| ④ Powertrain slippage (forward clutch, coasting clutch, 3-4 clutch, 2-4 brake band, one-way clutch 1, 2, or planetary gear) | 👉 page K1-45 |
| ⑤ Control valve stuck (manual valve, solenoid reducing valve) | 👉 page K1-125 |
| ⑥ Pressure control solenoid and/or shift solenoid A worn | 👉 page K1-35 |
| ⑦ Parking mechanism worn | 👉 page K1-45 |
| ⑧ Powertrain control module malfunction | 👉 section F2 |

| | |
|---|--|
| 41 | VEHICLE MOVES IN N POSITION |
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle creeps in N position • Vehicle moves when accelerator pedal not depressed |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Selector lever installation or adjustment incorrect | 👉 page K1-176 |
| ② Powertrain burnt (forward clutch, coasting clutch) | 👉 page K1-45 |
| ③ Control valve stuck (manual valve) | 👉 page K1-125 |

| | |
|---|---|
| 42 | VEHICLE MOVES IN P POSITION |
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle rolls in P position, and drivetrain TCC non operation |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Selector lever installation or adjustment incorrect | 👉 page K1-170 |
| ② Parking mechanism worn | 👉 page K1-45 |

| | |
|--|--|
| 43 | EXCESSIVE CREEP |
| DESCRIPTION | <ul style="list-style-type: none"> • Vehicle moves quickly in D, 2, 1 ranges, and R position (accelerator pedal not depressed) • Excessive N to R position and N to D range shift shock felt |
| [TROUBLESHOOTING HINTS] | |
| Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | |
| ① Engine idle speed misadjusted | 👉 section F2 |
| ② Line pressure at idle high | 👉 page K1-11 |
| ③ Closed throttle position switch malfunction | 👉 section F2 |
| ④ Powertrain control module malfunction | 👉 section F2 |

| 44 | NO SHIFT | | | | | | | | | | | | |
|---|--|--|---|---------|--------------------|---------|--------------------|---------|--------------------|------------|-----------------|-----|-----------------|
| DESCRIPTION | <ul style="list-style-type: none"> • With gear position in O/D OFF mode: Shifts in single ranges only (1–2, 2–3, or 3–4) Shifts incorrectly at times | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Shift solenoid A, B, C worn ③ Control valve stuck ④ O/D OFF switch malfunction | | <ul style="list-style-type: none"> ⑤ Input/turbine speed sensor malfunction ⑥ Vehicle speedometer sensor malfunction ⑦ Poor ground ⑧ Powertrain control module malfunction | | | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | | | | | |
| 1 | Are ATF level and condition OK?  page K1–18 | Yes | Go to next step | | | | | | | | | | |
| | | No | Problem within transaxle Go to next step, and check for the main cause. When problem is found and corrected, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | |
| 2 | Does NGS display “SYSTEM PASSED (NO DTCS AVAILABLE)” with ignition switch ON?  page K1–177 | Yes | Go to next step | | | | | | | | | | |
| | | No | Diagnostic trouble code(s) displayed • Check for cause of code(s)  page K1–177 | | | | | | | | | | |
| 3 | Disconnect solenoid 10-pin connector; is vehicle driven as follows? <table border="1" data-bbox="280 1367 792 1524"> <thead> <tr> <th>Position/Range</th> <th>Gear position</th> </tr> </thead> <tbody> <tr> <td>D range</td> <td>Third gear (fixed)</td> </tr> <tr> <td>2 range</td> <td>Third gear (fixed)</td> </tr> <tr> <td>1 range</td> <td>First gear (fixed)</td> </tr> <tr> <td>R position</td> <td>Reverse (fixed)</td> </tr> </tbody> </table> | Position/Range | Gear position | D range | Third gear (fixed) | 2 range | Third gear (fixed) | 1 range | First gear (fixed) | R position | Reverse (fixed) | Yes | Go to next step |
| Position/Range | Gear position | | | | | | | | | | | | |
| D range | Third gear (fixed) | | | | | | | | | | | | |
| 2 range | Third gear (fixed) | | | | | | | | | | | | |
| 1 range | First gear (fixed) | | | | | | | | | | | | |
| R position | Reverse (fixed) | | | | | | | | | | | | |
| | | No | Replace control valve body assembly  page K1–125 If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | |
| 4 | Drive vehicle in D, 2 and 1 ranges; does vehicle start from stop in first gear? Is engine speed (drum rpm) at 20 km/h {12 mph} and throttle opening OK? Engine speed: Approx. 2,100 rpm Throttle opening: 4/8 | Yes | Go to step 6 | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | |






| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|--|--------------|---|---------|-----------|------|----|----------|-------|--------------------|---------|----|-----------------|--------------|---------|----------|-------------|---------------------|----|----------|-------|--------------------|-----------------|---------|---------|----------------|---------|----------|-------------|----|----------------|----------|----------------------------|--------------------|----------------------------|----|----------------|--------------|-----------------|----|-------------|----|----------|----------|----|------------------|----|------------------|----|------------------|-----|---|
| 5 | <p>Are measurements at powertrain control module terminals OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2A</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td>section</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> <td>F2</td> </tr> <tr> <td rowspan="3">2B</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td>section</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> <td>F2</td> </tr> <tr> <td rowspan="3">2F</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td>section</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> <td>F2</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>Shift solenoid A</td> </tr> <tr> <td>2B</td> <td>Shift solenoid B</td> </tr> <tr> <td>2F</td> <td>Shift solenoid C</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2A | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section | B+ | Solenoid ON | F2 | 2B | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section | B+ | Solenoid ON | F2 | 2F | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section | B+ | Solenoid ON | F2 | Terminal | Function | 2A | Shift solenoid A | 2B | Shift solenoid B | 2F | Shift solenoid C | Yes | <p>Replace control valve body assembly</p> <p>If problem remains, overhaul transaxle and repair or replace parts as necessary</p> |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Shift solenoid A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Shift solenoid B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Shift solenoid C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | <p>If resistance not OK, check for malfunctioning parts and wiring</p> <ul style="list-style-type: none"> • Shift solenoid A ☞ page K1-35 • Shift solenoid B ☞ page K1-35 • Shift solenoid C ☞ page K1-35 <p>If resistance OK but voltage is not, go to next step</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | <p>Are measurements at powertrain control module terminals OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2L</td> <td rowspan="2">V</td> <td>0</td> <td>Switch depressed</td> <td>section</td> </tr> <tr> <td>B+</td> <td>Switch released</td> <td>F2</td> </tr> <tr> <td>2P↔2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">1C</td> <td rowspan="2">V</td> <td>0 or 4.0—5.0</td> <td>Vehicle stopped</td> <td>section</td> </tr> <tr> <td>2.0—3.0</td> <td>Vehicle moving</td> <td>F2</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1L</td> <td>O/D OFF switch</td> </tr> <tr> <td>1C</td> <td>Vehicle speedometer sensor</td> </tr> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2L | V | 0 | Switch depressed | section | B+ | Switch released | F2 | 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section | 2.0—3.0 | Vehicle moving | F2 | Terminal | Function | 1L | O/D OFF switch | 1C | Vehicle speedometer sensor | 2P | Input/turbine speed sensor | 2T | Ground (input) | Yes | Go to next step | | | | | | | | | | | | | |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2L | V | 0 | Switch depressed | section | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Switch released | F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2.0—3.0 | Vehicle moving | F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1L | O/D OFF switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1C | Vehicle speedometer sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | <p>Check for malfunctioning parts and wiring</p> <ul style="list-style-type: none"> • O/D OFF switch ☞ page K1-28 • Input/turbine speed sensor ☞ page K1-32 • Vehicle speedometer sensor ☞ page K1-33 <p>If problem remains, return to step 3</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | <p>Is voltage between 4AF terminal of powertrain control module and transaxle case OK?</p> <p>Specified voltage: 0 V</p> | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | <p>Problem in ground circuit</p> <p>Repair wiring or replace connector</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | <p>Replace with known good powertrain control module; is problem corrected?</p> <p style="text-align: right;">☞ section F2</p> | Yes | <p>Replace powertrain control module</p> <p style="text-align: right;">☞ section F2</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 45 | ABNORMAL SHIFT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|--|--|---------------|-------|-----------|------|----|---|-------|--------------------|---|---|---|--------------|---------------|----|-------------|----|---|-------|--------------------|---|---|---|--------------|---------------|----|-------------|----|---|-------|--------------------|---|---|---|--------------|---------------|----|-------------|----------|----------|----|------------------|----|------------------|----|------------------|
| DESCRIPTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <ul style="list-style-type: none"> • Shifts incorrectly (incorrect shift pattern) (Ex) Vehicle shifts 1 → 4 directly when accelerating with accelerator pedal depressed slightly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Shift solenoid A, B, C worn ③ Poor ground ④ Throttle position sensor malfunction or misadjusted | | <ul style="list-style-type: none"> ⑤ Input/turbine speed sensor malfunction ⑥ Transaxle range switch worn ⑦ Powertrain control module malfunction ⑧ Stuck control valves | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Are ATF level and condition OK? page K1-18 | | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | No | | Problem within transaxle Go to next step, and check for the main cause. When the problem is found and corrected, overhaul the transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? page K1-177 | | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | No | | Diagnostic trouble code(s) displayed <ul style="list-style-type: none"> • Check for cause of code(s) page K1-177 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage | | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Term.</th> <th style="text-align: center;">Unit</th> <th style="text-align: center;">Spec.</th> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">2A</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">11—27</td> <td style="text-align: center;">Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td style="text-align: center;">Solenoid OFF</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">B+</td> <td style="text-align: center;">Solenoid ON</td> </tr> <tr> <td rowspan="3" style="text-align: center;">2B</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">11—27</td> <td style="text-align: center;">Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td style="text-align: center;">Solenoid OFF</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">B+</td> <td style="text-align: center;">Solenoid ON</td> </tr> <tr> <td rowspan="3" style="text-align: center;">2F</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">11—27</td> <td style="text-align: center;">Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td style="text-align: center;">Solenoid OFF</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">B+</td> <td style="text-align: center;">Solenoid ON</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Terminal</th> <th style="text-align: center;">Function</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2A</td> <td style="text-align: center;">Shift solenoid A</td> </tr> <tr> <td style="text-align: center;">2B</td> <td style="text-align: center;">Shift solenoid B</td> </tr> <tr> <td style="text-align: center;">2F</td> <td style="text-align: center;">Shift solenoid C</td> </tr> </tbody> </table> | | Term. | Unit | Spec. | Condition | Page | 2A | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2B | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2F | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | Terminal | Function | 2A | Shift solenoid A | 2B | Shift solenoid B | 2F | Shift solenoid C |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Shift solenoid A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Shift solenoid B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Shift solenoid C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|---------|--|------------|-----------|------|----|---|---------|---|------------|---------|-----------------------------------|-------|---|---------|---------------------|---|----|---|---|-------------------|------------|----|----------------------------|----|---|----|------------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|--|--|
| 4 | Is voltage between 4AF terminal of powertrain control module and transaxle case OK? Specified voltage: 0 V | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Problem in ground circuit Check for wiring | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Check for malfunctioning parts and wiring <ul style="list-style-type: none"> • Throttle position sensor section F2 • Input/turbine speed sensor page K1-32 • Transaxle range switch page K1-29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">3B</td> <td rowspan="2">V</td> <td>0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> <tr> <td>2P↔2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">1F</td> <td rowspan="2">V</td> <td>0</td> <td>P and N positions</td> <td rowspan="8">section F2</td> </tr> <tr> <td>B+</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>B+</td> <td>R position</td> </tr> <tr> <td>0</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2M</td> <td rowspan="2">V</td> <td>B+</td> <td>2 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2R</td> <td rowspan="2">V</td> <td>B+</td> <td>1 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> | | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | 1F | V | 0 | P and N positions | section F2 | B+ | Other positions all ranges | 2K | V | B+ | R position | 0 | Other positions all ranges | 2I | V | B+ | D range | 0 | Other ranges all positions | 2M | V | B+ | 2 range | 0 | Other ranges all positions | 2R | V | B+ | 1 range | 0 | Other ranges all positions | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F | V | 0 | P and N positions | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2K | V | B+ | R position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2I | V | B+ | D range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2M | V | B+ | 2 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R | V | B+ | 1 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Replace with known good powertrain control module; is problem corrected? section F2 | Yes | Replace powertrain control module section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 46 | FREQUENT SHIFTING | | | | | | | | | | | | | | | |
|--|---|--|---|---|------|-------|-----------|------|----|---|--------------|---|------------|---------|-----------------------------------|--|
| DESCRIPTION • Downshift occurs when accelerator depressed slightly in D (except O/D OFF mode), 2 and 1 ranges | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | |
| ① Poor ground | | ④ Vehicle speedometer sensor malfunction | | | | | | | | | | | | | | |
| ② Throttle position sensor malfunction or misadjusted | | ⑤ Powertrain burnt (2–4 brake band) | | | | | | | | | | | | | | |
| ③ Powertrain control module malfunction | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | | | ACTION | | | | | | | | | | | | |
| 1 | Are there any diagnostic trouble code(s) displayed on the NGS when ignition switch is ON? 🔧 page K1-177 | | | Yes Diagnostic trouble code(s) displayed • Check for cause of code(s) 🔧 page K1-177 No Go to next step | | | | | | | | | | | | |
| 2 | Is voltage between 4AF terminal of powertrain control module and transaxle case OK? Specified voltage: 0 V | | | Yes Go to next step No Problem in ground circuit Repair wiring or replace connector | | | | | | | | | | | | |
| 3 | Is input voltage of throttle position sensor at powertrain control module OK? B+: Battery positive voltage <table border="1" data-bbox="282 1024 794 1178"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">3B</td> <td rowspan="2">V</td> <td>0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage | | | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | Yes Go to next step No Check throttle position sensor and wiring 🔧 section F2 |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | |
| 4 | Is input voltage of vehicle speedometer sensor at powertrain control module OK? B+: Battery positive voltage <table border="1" data-bbox="282 1377 794 1472"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1C</td> <td rowspan="2">V</td> <td>0 or 4.0—5.0</td> <td>Vehicle stopped</td> <td rowspan="2">section F2</td> </tr> <tr> <td>2.0—3.0</td> <td>Vehicle moving</td> </tr> </tbody> </table> Unit: V → Voltage | | | Term. | Unit | Spec. | Condition | Page | 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section F2 | 2.0—3.0 | Vehicle moving | Yes Go to next step No Check vehicle speedometer sensor and wiring 🔧 page K1-33 |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | |
| 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section F2 | | | | | | | | | | | | |
| | | 2.0—3.0 | Vehicle moving | | | | | | | | | | | | | |
| 5 | Replace with known good powertrain control module; is problem corrected? 🔧 section F2 | | | Yes Replace powertrain control module 🔧 section F2 No Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | |

| 47 | SHIFT POINT HIGH OR LOW | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|---|---------------|---|-------|-----------|------|----|---|---------|---|------------|---------|-----------------------------------|------------|---|------------|------------|-----------------------------------|-----|-----------------|
| DESCRIPTION | <ul style="list-style-type: none"> • Shift points do not match shift diagram • Shifts delayed when accelerating • Shifts occur too fast when accelerating and engine speed does not increase | | | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | | | | | | |
| ① Pressure control solenoid worn | | ④ Input/turbine speed sensor malfunction | | | | | | | | | | | | | | | | | | | | |
| ② Throttle position sensor malfunction or misadjusted | | ⑤ Vehicle speedometer sensor malfunction | | | | | | | | | | | | | | | | | | | | |
| ③ Transaxle fluid temperature sensor malfunction | | ⑥ Transaxle range switch malfunction | | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | | | ACTION | | | | | | | | | | | | | | | | | | |
| 1 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? ☞ page K1-177 | | | Yes | Go to next step | | | | | | | | | | | | | | | | | |
| | | | | No | Diagnostic trouble code(s) displayed • Check for cause of code(s) ☞ page K1-177 | | | | | | | | | | | | | | | | | |
| 2 | Are resistance and output duty of pressure control solenoid at powertrain control module OK? <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Term.</th> <th style="text-align: center;">Unit</th> <th style="text-align: center;">Spec.</th> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Page</th> </tr> </thead> <tbody> <tr> <td></td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">9—18</td> <td>Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">2H</td> <td rowspan="2" style="text-align: center;">%</td> <td style="text-align: center;">Approx. 67</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">Approx. 23</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: Ω → Resistance % → ON duty | | | Term. | Unit | Spec. | Condition | Page | | Ω | 9—18 | Constant (Ign:OFF) | — | 2H | % | Approx. 67 | Throttle valve closed throttle position | section F2 | Approx. 23 | Throttle valve wide open throttle | Yes | Go to next step |
| | | | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | |
| | Ω | 9—18 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | |
| 2H | % | Approx. 67 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | |
| | | Approx. 23 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | |
| No | If resistance not OK, check pressure control solenoid and wiring ☞ page K1-35 If resistance OK but duty is not, go to next step | | | | | | | | | | | | | | | | | | | | | |
| 3 | Is input voltage of throttle position sensor at powertrain control module OK? B+: Battery positive voltage <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Term.</th> <th style="text-align: center;">Unit</th> <th style="text-align: center;">Spec.</th> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">3B</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage | | | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | Yes | Go to next step | | | | | |
| | | | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | |
| No | Check throttle position sensor and wiring ☞ section F2 | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------|--|-------------------------------------|-------------------------------|---------------|-----------|-----------------------------|-------------------------------------|---|----------------------------------|-------------------------------------|---|---|----------------------------|--------------|-----------------|---------------|------------------------------------|----------------|----------------|---|---|-------------------|----|-------------------------------|----|---|----|------------|---|-------------------------------|----|---|----|---------|---|-------------------------------|----|---|----|---------|---|-------------------------------|----|---|----|---------|---|-------------------------------|----------|----------|----|----------------------------|-------------|------------------------|----|----------------------------|----|----------------|---|---|
| 4 | <p>Is input voltage of transaxle fluid temperature sensor at powertrain control module OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1" data-bbox="277 296 792 451"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">20++4D</td> <td rowspan="2">V</td> <td>Approx. 3.5</td> <td>ATF temp. 20°C {68°F}</td> <td rowspan="2">section F2</td> </tr> <tr> <td>Approx. 0.6</td> <td>ATF temp. 130°C {266°F}</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> <table border="1" data-bbox="277 512 792 651"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>20</td> <td>Transaxle fluid temperature sensor</td> </tr> <tr> <td>4D</td> <td>Ground (input)</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 20++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | Approx. 0.6 | ATF temp. 130°C {266°F} | Terminal | Function | 20 | Transaxle fluid temperature sensor | 4D | Ground (input) | <p>Yes</p> <p>Go to next step</p> <p>No</p> | <p>Go to next step</p> <p>Check transaxle fluid temperature sensor and wiring  page K1-31</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 0.6 | ATF temp. 130°C {266°F} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20 | Transaxle fluid temperature sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4D | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | <p>Are measurements at powertrain control module terminals OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1" data-bbox="277 779 792 1388"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td>2P++2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">1C</td> <td rowspan="2">V</td> <td>0 or 4.0—5.0</td> <td>Vehicle stopped</td> <td rowspan="10">section F2</td> </tr> <tr> <td>2.0—3.0</td> <td>Vehicle moving</td> </tr> <tr> <td rowspan="2">1F</td> <td rowspan="2">V</td> <td>0</td> <td>P and N positions</td> </tr> <tr> <td>B+</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>B+</td> <td>R position</td> </tr> <tr> <td>0</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2M</td> <td rowspan="2">V</td> <td>B+</td> <td>2 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2R</td> <td rowspan="2">V</td> <td>B+</td> <td>1 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1" data-bbox="277 1478 792 1644"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1C</td> <td>Vehicle speedometer sensor</td> </tr> <tr> <td>1F,2K,2I,2M</td> <td>Transaxle range switch</td> </tr> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2P++2T | Ω | 253—604 | Constant (Ign: OFF) | — | 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section F2 | 2.0—3.0 | Vehicle moving | 1F | V | 0 | P and N positions | B+ | Other positions all ranges | 2K | V | B+ | R position | 0 | Other positions all ranges | 2I | V | B+ | D range | 0 | Other ranges all positions | 2M | V | B+ | 2 range | 0 | Other ranges all positions | 2R | V | B+ | 1 range | 0 | Other ranges all positions | Terminal | Function | 1C | Vehicle speedometer sensor | 1F,2K,2I,2M | Transaxle range switch | 2P | Input/turbine speed sensor | 2T | Ground (input) | <p>Yes</p> <p>Go to next step</p> <p>No</p> | <p>Go to next step</p> <p>Check for malfunctioning parts and wiring  page K1-32  page K1-33  page K1-29</p> |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P++2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1C | V | 0 or 4.0—5.0 | Vehicle stopped | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2.0—3.0 | Vehicle moving | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F | V | 0 | P and N positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2K | V | B+ | R position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2I | V | B+ | D range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2M | V | B+ | 2 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R | V | B+ | 1 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1C | Vehicle speedometer sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F,2K,2I,2M | Transaxle range switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | <p>Is line pressure OK?</p> <p style="text-align: right;"> page K1-11</p> <p>Specified line pressure kPa {kgf/cm², psi}</p> <table border="1" data-bbox="277 1787 792 1946"> <thead> <tr> <th>Range</th> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D, 2, 1</td> <td>420—530 {4.2—5.5, 60—78}</td> <td>1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td>R</td> <td>730—1,010 {7.4—10.3, 110—146}</td> <td>1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | <p>Yes</p> <p>Go to next step</p> <p>No</p> | <p>Go to next step</p> <p>Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Range | Idle | Stall | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | | |
|--|--|------------------------------|
| 48 | TCC NON OPERATION | |
| DESCRIPTION | • TCC non operation when vehicle speed reaches torque converter clutch range | |
| [TROUBLESHOOTING HINTS] Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | | |
| ① ATF level low | | ☞ page K1-18 |
| ② Shift solenoid A, B, C, torque converter clutch control, 3-2 timing, torque converter clutch and/or pressure control solenoid worn | | ☞ page K1-35 ☞ page K1-28 |
| ③ O/D OFF switch worn | | ☞ page K1-29 |
| ④ Transaxle range switch worn or misadjusted | | ☞ page K1-34 |
| ⑤ Brake switch malfunction | | |
| ⑥ Control valve stuck (torque converter clutch shift valve, torque converter clutch control valve, solenoid reducing valve) | | ☞ page K1-125 |
| ⑦ Transaxle fluid temperature sensor malfunction | | ☞ page K1-31 |
| ⑧ Throttle position sensor malfunction or misadjusted | | ☞ section F2 |
| ⑨ Input/turbine speed sensor malfunction | | ☞ page K1-32 |
| ⑩ Vehicle speedometer sensor malfunction | | ☞ page K1-33 |
| ⑪ Powertrain control module malfunction | | ☞ section F2 |
| ⑫ Torque converter worn | | ☞ page K1-58 |





| | | |
|--|---|---------------|
| 49 | NO KICKDOWN | |
| DESCRIPTION | • Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range | |
| [TROUBLESHOOTING HINTS] Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | | |
| ① Throttle position sensor malfunction or misadjusted | | ☞ section F2 |
| ② O/D OFF switch worn | | ☞ page K1-28 |
| ③ Transaxle range switch worn or misadjusted | | ☞ page K1-29 |
| ④ Pressure control solenoid worn | | ☞ page K1-35 |
| ⑤ Control valve stuck (pressure regulator valve, pressure modifier valve, solenoid reducing valve) | | ☞ page K1-125 |
| ⑥ Powertrain control module malfunction | | ☞ section F2 |






| | | |
|--|--|----------------------------|
| 50 | ENGINE SPEED FLARES UP | • WHEN ACCELERATING |
| DESCRIPTION | • Engine speed flares up on acceleration | |
| [TROUBLESHOOTING HINTS] Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | | |
| ① ATF level low | | ☞ page K1-18 |
| ② Selector lever installation or adjustment incorrect | | ☞ page K1-170 |
| ③ Throttle position sensor malfunction or misadjusted | | ☞ section F2 |
| ④ Line pressure low | | ☞ page K1-11 |
| ⑤ Powertrain slippage (forward clutch, 3-4 clutch, 2-4 brake band, one-way clutch 1, 2, planetary gear) | | ☞ page K1-45 |
| ⑥ Control valve stuck (pressure regulator valve, solenoid reducing valve) | | ☞ page K1-125 |
| ⑦ Pressure control solenoid worn | | ☞ page K1-35 |
| ⑧ Transaxle fluid temperature sensor malfunction | | ☞ page K1-31 |
| ⑨ Powertrain control module malfunction | | ☞ section F2 |

| 51 | ENGINE SPEED FLARES UP | • WHEN UPSHIFTING AND/OR DOWNSHIFTING | | | | | | | | | | |
|--|--|---|--|-------|---------|-----------------------------|-------------------------------------|---|----------------------------------|-------------------------------------|-----|---|
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine flares up when accelerator pedal depressed for upshifting • Engine flares up suddenly when accelerator pedal depressed for downshifting | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Selector lever installation or adjustment incorrect ③ Throttle position sensor malfunction or misadjusted ④ Line pressure low ⑤ Powertrain slippage (forward clutch, coasting clutch, 3-4 clutch, 2-4 brake band, one-way clutch 1, 2, planetary gear) | | <ul style="list-style-type: none"> ⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, solenoid reducing valve) ⑦ Pressure control solenoid worn ⑧ 3-2 timing solenoid valve worn ⑨ Input/turbine speed sensor malfunction ⑩ Transaxle fluid temperature sensor malfunction ⑪ Powertrain control module malfunction | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | |
| 1 | Are ATF level and condition OK? page K1-18 | Yes | Go to next step | | | | | | | | | |
| | | No | Problem within transaxle. Go to next step, and check for main cause. When problem is found and corrected, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | |
| 2 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? page K1-177 | Yes | Go to next step | | | | | | | | | |
| | | No | Diagnostic trouble code(s) displayed • Check for cause of code(s) page K1-177 | | | | | | | | | |
| 3 | Is line pressure OK? page K1-11 Specified line pressure kPa {kgf/cm², psi} <table border="1" style="margin-top: 10px; width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Position/Range</th> <th style="text-align: center;">Idle</th> <th style="text-align: center;">Stall</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">D, 2, 1</td> <td style="text-align: center;">420—530 {4.2—5.5, 60—78}</td> <td style="text-align: center;">1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td style="text-align: center;">R</td> <td style="text-align: center;">730—1,010 {7.4—10.3, 110—146}</td> <td style="text-align: center;">1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Position/Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | Yes | Overhaul transaxle and repair or replace parts as necessary |
| | | Position/Range | Idle | Stall | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | | |
| | | No | Check selector lever operation page K1-170 ⇨ If OK, go to next step ⇨ If not OK, adjust, repair, or replace selector lever page K1-170 | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|--|---|---|------------|-----------|------|--------|----------|---------|---|------------|---------|-----------------------------------|---|-----------------------|------------|-----------------------------------|--|----------|----------|----|----------------------------|----|----------------|----|------------------------------------|----|----------------|
| 4 | Are resistance and output duty of pressure control solenoid valve at powertrain control module OK? | Yes Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2H</td> <td>Ω</td> <td>9—18</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 67</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>Approx. 23</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance % → ON duty</p> | Term. | Unit | Spec. | Condition | Page | 2H | Ω | 9—18 | Constant (Ign:OFF) | — | % | Approx. 67 | Throttle valve closed throttle position | section F2 | Approx. 23 | Throttle valve wide open throttle | No If resistance not OK, check pressure control solenoid and wiring page K1-35 If resistance OK but duty is not, go to next step | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | |
| 2H | Ω | 9—18 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | |
| | % | Approx. 67 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 23 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Are resistance and output voltage of 3-2 timing solenoid valve at powertrain control module OK? | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p>B+: Battery positive voltage</p> <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2G</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Other than above</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>1→2, 2→3, 3→4, 3→2, 2→1 shift</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> | Term. | Unit | Spec. | Condition | Page | 2G | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Other than above | section F2 | B+ | 1→2, 2→3, 3→4, 3→2, 2→1 shift | No If resistance not OK, check 3-2 timing solenoid valve and wiring page K1-35 If resistance OK but voltage is not, go to next step | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | |
| 2G | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Other than above | section F2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | 1→2, 2→3, 3→4, 3→2, 2→1 shift | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Is input voltage of throttle position sensor at powertrain control module OK? | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">3B</td> <td rowspan="2">V</td> <td>0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | No Check throttle position sensor and wiring section F2 | | | | | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Are measurements at powertrain control module terminals OK? | Yes Replace powertrain control module section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td>2R++2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">2O++4D</td> <td rowspan="2">V</td> <td>Approx. 3.5</td> <td>ATF temp. 20°C {68°F}</td> <td rowspan="2">section F2</td> </tr> <tr> <td>Approx. 0.6</td> <td>ATF temp. 130°C {266°F}</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> <tr> <td>2O</td> <td>Transaxle fluid temperature sensor</td> </tr> <tr> <td>4D</td> <td>Ground (input)</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2R++2T | Ω | 253—604 | Constant (Ign: OFF) | — | 2O++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | Approx. 0.6 | ATF temp. 130°C {266°F} | Terminal | Function | 2P | Input/turbine speed sensor | 2T | Ground (input) | 2O | Transaxle fluid temperature sensor | 4D | Ground (input) |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R++2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | |
| 2O++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 0.6 | ATF temp. 130°C {266°F} | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2O | Transaxle fluid temperature sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4D | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| 52 | EXCESSIVE SHIFT SHOCK | • P, N TO R AND/OR N TO D | | | | | | | | | | | | | | | | | | |
|---|---|-------------------------------------|---|------------|---|--|-------------------------------------|---|----------------------------------|-------------------------------------|-----|-----------------|------------|---|------------|------------|-----------------------------------|-----|---|--|
| DESCRIPTION • Strong shift shock felt at idle when shifting from N position to D range or R position | | | | | | | | | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | | | | |
| <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;"> ① Idle speed high ② Throttle position sensor malfunction or misadjusted ③ Line pressure high ④ Control valve stuck (pressure regulator valve, cutback valve, solenoid reducing valve) ⑤ Powertrain slippage ⑥ Pressure control solenoid worn </td> <td style="width: 50%; border: none;"> ⑦ Shift solenoid A, B and/or C worn ⑧ Transaxle fluid temperature sensor malfunction ⑨ N-D, or N-R accumulator worn ⑩ Input/turbine speed sensor malfunction ⑪ Transaxle range switch worn or misadjusted ⑫ Powertrain control module malfunction </td> </tr> </table> | | | | | ① Idle speed high ② Throttle position sensor malfunction or misadjusted ③ Line pressure high ④ Control valve stuck (pressure regulator valve, cutback valve, solenoid reducing valve) ⑤ Powertrain slippage ⑥ Pressure control solenoid worn | ⑦ Shift solenoid A, B and/or C worn ⑧ Transaxle fluid temperature sensor malfunction ⑨ N-D, or N-R accumulator worn ⑩ Input/turbine speed sensor malfunction ⑪ Transaxle range switch worn or misadjusted ⑫ Powertrain control module malfunction | | | | | | | | | | | | | | |
| ① Idle speed high ② Throttle position sensor malfunction or misadjusted ③ Line pressure high ④ Control valve stuck (pressure regulator valve, cutback valve, solenoid reducing valve) ⑤ Powertrain slippage ⑥ Pressure control solenoid worn | ⑦ Shift solenoid A, B and/or C worn ⑧ Transaxle fluid temperature sensor malfunction ⑨ N-D, or N-R accumulator worn ⑩ Input/turbine speed sensor malfunction ⑪ Transaxle range switch worn or misadjusted ⑫ Powertrain control module malfunction | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | |
| 1 | Are ignition timing and idle speed OK? ↳ section F2 | Yes | Go to next step | | | | | | | | | | | | | | | | | |
| | | No | Adjust ignition timing and/or idle speed ↳ section F2 | | | | | | | | | | | | | | | | | |
| 2 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? ↳ page K1-177 | Yes | Go to next step | | | | | | | | | | | | | | | | | |
| | | No | Diagnostic trouble code(s) displayed • Check for cause of code(s) ↳ page K1-177 | | | | | | | | | | | | | | | | | |
| 3 | Is line pressure OK? ↳ page K1-11 Specified line pressure kPa {kgf/cm², psi} <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Position/Range</th> <th style="text-align: center;">Idle</th> <th style="text-align: center;">Stall</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">D, 2, 1</td> <td style="text-align: center;">420—530 {4.2—5.5, 60—78}</td> <td style="text-align: center;">1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td style="text-align: center;">R</td> <td style="text-align: center;">730—1,010 {7.4—10.3, 110—146}</td> <td style="text-align: center;">1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Position/Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | Yes | Go to next step | | | | | | | | |
| | | Position/Range | Idle | Stall | | | | | | | | | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | | | | | | | | | | |
| No | Go to step 5 | | | | | | | | | | | | | | | | | | | |
| 4 | Is engine stall speed OK? ↳ page K1-12 <div style="text-align: right;">rpm</div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Engine</th> <th style="text-align: center;">Engine stall speed</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">KL</td> <td style="text-align: center;">2,270—2,500</td> </tr> </tbody> </table> | Engine | Engine stall speed | KL | 2,270—2,500 | Yes | Go to step 8 | | | | | | | | | | | | | |
| | | Engine | Engine stall speed | | | | | | | | | | | | | | | | | |
| KL | 2,270—2,500 | | | | | | | | | | | | | | | | | | | |
| No | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | |
| 5 | Are resistance and output duty of pressure control solenoid at powertrain control module OK? <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Term.</th> <th style="text-align: center;">Unit</th> <th style="text-align: center;">Spec.</th> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">2H</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">9—18</td> <td style="text-align: center;">Constant (Ign:OFF)</td> <td style="text-align: center;">—</td> </tr> <tr> <td rowspan="2" style="text-align: center;">%</td> <td style="text-align: center;">Approx. 67</td> <td style="text-align: center;">Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">section F2</td> </tr> <tr> <td style="text-align: center;">Approx. 23</td> <td style="text-align: center;">Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: Ω → Resistance % → ON duty | Term. | Unit | Spec. | Condition | Page | 2H | Ω | 9—18 | Constant (Ign:OFF) | — | % | Approx. 67 | Throttle valve closed throttle position | section F2 | Approx. 23 | Throttle valve wide open throttle | Yes | Overhaul transaxle and repair or replace parts as necessary | |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | |
| 2H | Ω | 9—18 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | |
| | % | Approx. 67 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | |
| | | Approx. 23 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | |
| No | If resistance not OK, check pressure control solenoid and wiring ↳ page K1-35 If resistance OK but duty is not, go to next step | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|---|----------------|---|------------|-----------|------|----|---|---------|---|------------|---------|-----------------------------------|--------------|-----------------|----|-------------|----|---|-------|--------------------|---|---|---|--------------|------------|----------------|-------------|----|---|-------|--------------------|---|---|---|--------------|------------|----|-------------|----------|----------|----|------------------|----|------------------|----|------------------|-----|--|
| 6 | Is input voltage of throttle position sensor at powertrain control module OK? <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">3B</td> <td rowspan="2">V</td> <td>0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | Yes | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Check throttle position sensor and wiring  section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2A</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3">2B</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>V_B</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3">2F</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> </tbody> </table> Unit: Ω → Resistance V → Voltage <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>Shift solenoid A</td> </tr> <tr> <td>2B</td> <td>Shift solenoid B</td> </tr> <tr> <td>2F</td> <td>Shift solenoid C</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2A | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2B | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | V _B | Solenoid ON | 2F | Ω | 11—27 | Constant (Ign:OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | Terminal | Function | 2A | Shift solenoid A | 2B | Shift solenoid B | 2F | Shift solenoid C | Yes | Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary |
| | | Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | V _B | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Ω | 11—27 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Shift solenoid A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Shift solenoid B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Shift solenoid C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | If resistance not OK, check for malfunctioning parts and wiring • Shift solenoid A  page K1-35 • Shift solenoid B  page K1-35 • Shift solenoid C  page K1-35 If resistance OK but voltage is not, go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------|---|---|----------------------------|------------|-----------|------|-------|---|---------|---------------------|---|-------|---|-------------|-----------------------|------------|-------------|-------------------------|----|---|---|-------------------|----|----------------------------|----|---|----|------------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----|---|----|---------|---|----------------------------|----------|----------|----------------|------------------------|----|------------------------------------|----|----------------|----|----------------------------|----|----------------|--|
| 8 | <p>Are measurements at powertrain control module terminals OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1" data-bbox="280 268 794 951"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td>2P↔2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">2O↔4D</td> <td rowspan="2">V</td> <td>Approx. 3.5</td> <td>ATF temp. 20°C {68°F}</td> <td rowspan="10">section F2</td> </tr> <tr> <td>Approx. 0.6</td> <td>ATF temp. 130°C {266°F}</td> </tr> <tr> <td rowspan="2">1F</td> <td rowspan="2">V</td> <td>0</td> <td>P and N positions</td> </tr> <tr> <td>B+</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>B+</td> <td>R position</td> </tr> <tr> <td>0</td> <td>Other positions all ranges</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2M</td> <td rowspan="2">V</td> <td>B+</td> <td>2 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> <tr> <td rowspan="2">2R</td> <td rowspan="2">V</td> <td>B+</td> <td>1 range</td> </tr> <tr> <td>0</td> <td>Other ranges all positions</td> </tr> </tbody> </table> <p>Unit: V → Voltage Ω → Resistance</p> <table border="1" data-bbox="280 1024 794 1276"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1F,2F,2I,2M,2R</td> <td>Transaxle range switch</td> </tr> <tr> <td>2O</td> <td>Transaxle fluid temperature sensor</td> </tr> <tr> <td>4D</td> <td>Ground (input)</td> </tr> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | 2O↔4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | Approx. 0.6 | ATF temp. 130°C {266°F} | 1F | V | 0 | P and N positions | B+ | Other positions all ranges | 2K | V | B+ | R position | 0 | Other positions all ranges | 2I | V | B+ | D range | 0 | Other ranges all positions | 2M | V | B+ | 2 range | 0 | Other ranges all positions | 2R | V | B+ | 1 range | 0 | Other ranges all positions | Terminal | Function | 1F,2F,2I,2M,2R | Transaxle range switch | 2O | Transaxle fluid temperature sensor | 4D | Ground (input) | 2P | Input/turbine speed sensor | 2T | Ground (input) | <p>Yes Go to next step</p> <p>No Check for malfunctioning parts and wiring</p> <ul style="list-style-type: none"> • Transaxle fluid temperature sensor  page K1-31 • Input/turbine speed sensor  page K1-32 • Transaxle range switch  page K1-29 |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P↔2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2O↔4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 0.6 | ATF temp. 130°C {266°F} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F | V | 0 | P and N positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2K | V | B+ | R position | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other positions all ranges | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2I | V | B+ | D range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2M | V | B+ | 2 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2R | V | B+ | 1 range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other ranges all positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1F,2F,2I,2M,2R | Transaxle range switch | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2O | Transaxle fluid temperature sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4D | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | <p>Replace with known good powertrain control module; is problem corrected?</p> <p style="text-align: right;"> section F2</p> | <p>Yes Replace powertrain control module  section F2</p> <p>No Overhaul transaxle and repair or replace parts as necessary</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 53 | EXCESSIVE SHIFT SHOCK | • WHEN UPSHIFTING AND/OR DOWNSHIFTING | | | | | | | | | | |
|--|--|---------------------------------------|---|-------|-------------|-----------------------------|-------------------------------------|---|----------------------------------|-------------------------------------|-----|-----------------|
| DESCRIPTION | | | | | | | | | | | | |
| <ul style="list-style-type: none"> • Excessive shift shock felt when accelerating at upshifting • During cruising, excessive shift shock felt when accelerator pedal depressed at downshifting | | | | | | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Throttle position sensor malfunction or misadjusted ③ Line pressure high ④ Powertrain slippage ⑤ Control valve stuck (pressure regulator valve, solenoid reducing valve, pressure modifier valve) ⑥ Shift solenoid A, B, C, 3-2 timing, and/or pressure control solenoid worn ⑦ Input/turbine speed sensor malfunction ⑧ Transaxle fluid temperature sensor malfunction ⑨ Barometric pressure sensor malfunction | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | |
| 1 | Are ATF level and condition OK? page K1-18 | Yes | Go to next step | | | | | | | | | |
| | | No | Problem within transaxle Go to next step, and check for main cause. When problem is found and corrected, overhaul transaxle and repair or replace parts as necessary | | | | | | | | | |
| 2 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? page K1-177 | Yes | Go to next step | | | | | | | | | |
| | | No | Diagnostic trouble code(s) displayed Check for cause of code(s) page K1-177 | | | | | | | | | |
| 3 | Is line pressure OK? page K1-11 Specified line pressure kPa {kgf/cm², psi} <table border="1" style="margin-top: 10px;"> <thead> <tr> <th>Position/Range</th> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td>D, 2, 1</td> <td>420—530 {4.2—5.5, 60—78}</td> <td>1,100—1,170 {11.2—12.0, 160—170}</td> </tr> <tr> <td>R</td> <td>730—1,010 {7.4—10.3, 110—146}</td> <td>1,910—2,020 {19.4—20.7, 276—294}</td> </tr> </tbody> </table> | Position/Range | Idle | Stall | D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | Yes | Go to next step |
| | | Position/Range | Idle | Stall | | | | | | | | |
| D, 2, 1 | 420—530 {4.2—5.5, 60—78} | 1,100—1,170 {11.2—12.0, 160—170} | | | | | | | | | | |
| R | 730—1,010 {7.4—10.3, 110—146} | 1,910—2,020 {19.4—20.7, 276—294} | | | | | | | | | | |
| No | Go to step 5 | | | | | | | | | | | |
| 4 | Is engine stall speed OK? page K1-12 rpm | Yes | Go to step 7 | | | | | | | | | |
| | | No | Overhaul transaxle and repair or replace part as necessary | | | | | | | | | |
| <table border="1" style="margin-top: 10px;"> <thead> <tr> <th>Engine</th> <th>Engine stall speed</th> </tr> </thead> <tbody> <tr> <td>KL</td> <td>2,270—2,500</td> </tr> </tbody> </table> | | Engine | Engine stall speed | KL | 2,270—2,500 | | | | | | | |
| Engine | Engine stall speed | | | | | | | | | | | |
| KL | 2,270—2,500 | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|--|--|---|------------|-----------|------|----|----------|---------|---|------------|---------|-----------------------------------|---|------------|----|-------------|------------|-----------------------------------|---|---------------------|---|---|---|--------------|------------|----|-------------|----|----------|-------|---------------------|---|---|---|--------------|------------|----|-------------|----|---|----|-------------------------------|------------|---|------------------|----------|----------|----|------------------|----|------------------|----|------------------|----|---------------------------|
| 5 | Are resistance and output duty of pressure control solenoid valve at powertrain control module OK? | Yes Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2H</td> <td>Ω</td> <td>9—18</td> <td>Constant (Ign:OFF)</td> <td>—</td> </tr> <tr> <td>%</td> <td>Approx. 67</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td></td> <td></td> <td>Approx. 23</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance % → ON duty</p> | Term. | Unit | Spec. | Condition | Page | 2H | Ω | 9—18 | Constant (Ign:OFF) | — | % | Approx. 67 | Throttle valve closed throttle position | section F2 | | | Approx. 23 | Throttle valve wide open throttle | No If resistance not OK, check pressure control solenoid valve and wiring page K1-35 If resistance OK but duty is not, go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2H | Ω | 9—18 | Constant (Ign:OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | % | Approx. 67 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 23 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Is input voltage of throttle position sensor at powertrain control module OK? | Yes Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">3B</td> <td rowspan="2">V</td> <td>0.1—1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">section F2</td> </tr> <tr> <td>3.1—4.4</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> | Term. | Unit | Spec. | Condition | Page | 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | 3.1—4.4 | Throttle valve wide open throttle | No Check throttle position sensor and wiring section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3B | V | 0.1—1.1 | Throttle valve closed throttle position | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3.1—4.4 | Throttle valve wide open throttle | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Are measurements at powertrain control module terminals OK? | Yes Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2A</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3">2B</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3">2F</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="3">2G</td> <td rowspan="2">V</td> <td>B+</td> <td>1→2, 2→3, 3→4, 3→2, 2→1 shift</td> <td rowspan="2">section F2</td> </tr> <tr> <td>0</td> <td>Other than above</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2A</td> <td>Shift solenoid A</td> </tr> <tr> <td>2B</td> <td>Shift solenoid B</td> </tr> <tr> <td>2F</td> <td>Shift solenoid C</td> </tr> <tr> <td>2G</td> <td>3-2 timing solenoid valve</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2A | Ω | 11—27 | Constant (Ign: OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2B | Ω | 11—27 | Constant (Ign: OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2F | Ω | 11—27 | Constant (Ign: OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2G | V | B+ | 1→2, 2→3, 3→4, 3→2, 2→1 shift | section F2 | 0 | Other than above | Terminal | Function | 2A | Shift solenoid A | 2B | Shift solenoid B | 2F | Shift solenoid C | 2G | 3-2 timing solenoid valve |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Ω | 11—27 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Ω | 11—27 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Ω | 11—27 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | B+ | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2G | V | B+ | 1→2, 2→3, 3→4, 3→2, 2→1 shift | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Other than above | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2A | Shift solenoid A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Shift solenoid B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Shift solenoid C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2G | 3-2 timing solenoid valve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | | | | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|---|-------------------|--|------------|---|------|-------|-----------|------|--------|---|---------|---------------------|---|--------|---|-------------|-----------------------|------------|-------------|-------------------------|----|---|-------------------|--|-------------------|--|----------|----------|----|----------------------------|----|----------------------------|----|----------------|----|------------------------------------|----|----------------|
| 8 | Are measurements at powertrain control module terminals OK? B+: Battery positive voltage | | | | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" data-bbox="196 268 716 751"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td>2P++2T</td> <td>Ω</td> <td>253—604</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">20++4D</td> <td rowspan="2">V</td> <td>Approx. 3.5</td> <td>ATF temp. 20°C {68°F}</td> <td rowspan="4">section F2</td> </tr> <tr> <td>Approx. 0.6</td> <td>ATF temp. 130°C {266°F}</td> </tr> <tr> <td rowspan="2">3F</td> <td rowspan="2">V</td> <td>Below approx. 3.5</td> <td>Atmospheric pressure more than 89.6 kPa {672 mmHg, 26.5 inHg} (below approx. 1,500 m {4,921 ft})</td> </tr> <tr> <td>Above approx. 3.5</td> <td>Atmospheric pressure less than 89.6 kPa {672 mmHg, 26.5 inHg} (above approx. 1,500 m {4,921 ft})</td> </tr> </tbody> </table> <p data-bbox="191 768 422 821">Unit: Ω → Resistance V → Voltage</p> <table border="1" data-bbox="196 846 711 1073"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>3F</td> <td>Barometric pressure sensor</td> </tr> <tr> <td>2P</td> <td>Input/turbine speed sensor</td> </tr> <tr> <td>2T</td> <td>Ground (input)</td> </tr> <tr> <td>2O</td> <td>Transaxle fluid temperature sensor</td> </tr> <tr> <td>4D</td> <td>Ground (input)</td> </tr> </tbody> </table> | | | | Term. | Unit | Spec. | Condition | Page | 2P++2T | Ω | 253—604 | Constant (Ign: OFF) | — | 20++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | Approx. 0.6 | ATF temp. 130°C {266°F} | 3F | V | Below approx. 3.5 | Atmospheric pressure more than 89.6 kPa {672 mmHg, 26.5 inHg} (below approx. 1,500 m {4,921 ft}) | Above approx. 3.5 | Atmospheric pressure less than 89.6 kPa {672 mmHg, 26.5 inHg} (above approx. 1,500 m {4,921 ft}) | Terminal | Function | 3F | Barometric pressure sensor | 2P | Input/turbine speed sensor | 2T | Ground (input) | 2O | Transaxle fluid temperature sensor | 4D | Ground (input) |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P++2T | Ω | 253—604 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20++4D | V | Approx. 3.5 | ATF temp. 20°C {68°F} | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Approx. 0.6 | ATF temp. 130°C {266°F} | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3F | V | Below approx. 3.5 | Atmospheric pressure more than 89.6 kPa {672 mmHg, 26.5 inHg} (below approx. 1,500 m {4,921 ft}) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Above approx. 3.5 | Atmospheric pressure less than 89.6 kPa {672 mmHg, 26.5 inHg} (above approx. 1,500 m {4,921 ft}) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3F | Barometric pressure sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2P | Input/turbine speed sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2O | Transaxle fluid temperature sensor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4D | Ground (input) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Replace with known good powertrain control module; is problem corrected? | | | | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| |  section F2 | | | | Replace powertrain control module  section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | No | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | Overhaul transaxle and repair or replace parts as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | | | | | | | |
|--|--|---|---|----|-------------|-----|-----------------|
| 54 | NO ENGINE BRAKING | | | | | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed • Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in 1 range at low vehicle speed | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | |
| <ul style="list-style-type: none"> ① ATF level low ② Powertrain slippage ③ Control valve stuck (pressure regulator valve, solenoid reducing valve, pressure modifier valve) | | <ul style="list-style-type: none"> ④ IAC valve worn ⑤ Shift solenoid B and/or C worn ⑥ Powertrain control module malfunction | | | | | |
| STEP | INSPECTION | ACTION | | | | | |
| 1 | Are ATF level and condition OK? page K1-18 | Yes | Go to next step | | | | |
| | | No | Problem within transaxle Go to next step, and check for main cause. When problem is found and corrected, overhaul transaxle and repair or replace parts as necessary | | | | |
| 2 | Does NGS display "SYSTEM PASSED (NO DTCS AVAILABLE)" with ignition switch ON? page K1-177 | Yes | Go to next step | | | | |
| | | No | Diagnostic trouble code(s) displayed <ul style="list-style-type: none"> • Check for cause of code(s) page K1-177 | | | | |
| 3 | Is there slippage when accelerating or shifting? | Yes | Go to No.50 "ENGINE SPEED FLARES UP—WHEN ACCELERATING" or No.51 "ENGINE SPEED FLARES UP—WHEN UPSHIFTING AND/OR DOWNSHIFTING" page K1-220 | | | | |
| | | No | Go to next step | | | | |
| 4 | Is engine braking felt in 1 range? page K1-15 | Yes | Go to next step | | | | |
| | | No | Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary | | | | |
| 5 | Is engine stall speed OK? page K1-12 <div style="text-align: right;">rpm</div> <table border="1" style="width: 100%; margin-top: 5px;"> <tr> <td style="text-align: center;">Engine</td> <td style="text-align: center;">Engine stall speed</td> </tr> <tr> <td style="text-align: center;">KL</td> <td style="text-align: center;">2,270—2,500</td> </tr> </table> | Engine | Engine stall speed | KL | 2,270—2,500 | Yes | Go to next step |
| | | Engine | Engine stall speed | | | | |
| KL | 2,270—2,500 | | | | | | |
| | | No | Overhaul transaxle and repair or replace part as necessary | | | | |
| 6 | Does IAC valve operate correctly? section F2 | Yes | Go to next step | | | | |
| | | No | Replace IAC valve section F2 | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|---|-------------|---------------------|------------|-----------|------|----|---|-------|---------------------|---|---|---|--------------|------------|----|-------------|----|---|-------|---------------------|---|---|---|--------------|------------|----|-------------|----------|----------|----|------------------|----|------------------|---|
| 7 | <p>Are measurements at powertrain control module terminals OK?</p> <p style="text-align: center;">B+: Battery positive voltage</p> <table border="1" data-bbox="207 283 722 499"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2B</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> <tr> <td rowspan="2">2F</td> <td>Ω</td> <td>11—27</td> <td>Constant (Ign: OFF)</td> <td>—</td> </tr> <tr> <td rowspan="2">V</td> <td>0</td> <td>Solenoid OFF</td> <td rowspan="2">section F2</td> </tr> <tr> <td>B+</td> <td>Solenoid ON</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1" data-bbox="207 598 722 709"> <thead> <tr> <th>Terminal</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2B</td> <td>Shift solenoid B</td> </tr> <tr> <td>2F</td> <td>Shift solenoid C</td> </tr> </tbody> </table> | Term. | Unit | Spec. | Condition | Page | 2B | Ω | 11—27 | Constant (Ign: OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | 2F | Ω | 11—27 | Constant (Ign: OFF) | — | V | 0 | Solenoid OFF | section F2 | B+ | Solenoid ON | Terminal | Function | 2B | Shift solenoid B | 2F | Shift solenoid C | <p>Yes</p> <p>Replace control valve body assembly If problem remains, overhaul transaxle and repair or replace parts as necessary</p> <hr/> <p>No</p> <p>If resistance not OK, check for malfunctioning parts and wiring</p> <ul style="list-style-type: none"> • Shift solenoid B ☞ page K1-35 • Shift solenoid C ☞ page K1-35 <p>If resistance OK but voltage is not, replace powertrain control module</p> |
| Term. | Unit | Spec. | Condition | Page | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Ω | 11—27 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B+ | | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Ω | 11—27 | Constant (Ign: OFF) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | V | 0 | Solenoid OFF | section F2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B+ | | Solenoid ON | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2B | Shift solenoid B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2F | Shift solenoid C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | | |
|--|-----------------------|---|
| 55 | NO MODE CHANGE | |
| DESCRIPTION | | <ul style="list-style-type: none"> • Mode does not change to/from normal mode in D range • O/D OFF mode not selected or not cancelled |
| [TROUBLESHOOTING HINTS] | | |
| Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | | |
| <ol style="list-style-type: none"> ① Throttle position sensor malfunction or misadjusted ② Powertrain control module malfunction | | <ul style="list-style-type: none"> section F2 section F2 |

| | | |
|---|------------------------|--|
| 56 | TRANSAXLE NOISE | • ALL RANGES |
| DESCRIPTION | | <ul style="list-style-type: none"> • Transaxle noisy in all ranges when vehicle is idling |
| [TROUBLESHOOTING HINTS] | | |
| Inspect parts; repair, adjust, or replace malfunctioning parts as necessary | | |
| <ol style="list-style-type: none"> ① ATF level low ② Powertrain burnt | | <ul style="list-style-type: none"> page K1-18 page K1-45 |

| | | |
|--|------------------------|--|
| 57 | TRANSAXLE NOISE | • D, 2, 1 RANGES, R POSITION |
| DESCRIPTION | | <ul style="list-style-type: none"> • Abnormal noise from transaxle in D, 2, 1, R |
| [TROUBLESHOOTING HINTS] | | |
| Inspect parts; repair, adjust, or replace malfunctioning parts as necessary | | |
| <ol style="list-style-type: none"> ① ATF level low ② Torque converter worn | | <ul style="list-style-type: none"> page K1-18 page K1-58 |

| | | |
|---|----------------------------|--|
| 58 | TRANSAXLE OVERHEATS | |
| DESCRIPTION | | <ul style="list-style-type: none"> • ATF smells burnt and/or is discolored |
| [TROUBLESHOOTING HINTS] | | |
| Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary | | |
| <ol style="list-style-type: none"> ① ATF level low ② Powertrain burnt (forward clutch, reverse clutch, low and reverse brake, one-way clutch 1, 2) ③ Torque converter clutch piston burnt ④ Shift solenoid A, B, C, torque converter clutch control, 3-2 timing, torque converter clutch, and/or pressure control solenoid worn ⑤ Throttle position sensor malfunction or misadjusted ⑥ Input/turbine speed sensor malfunction ⑦ Vehicle speedometer sensor malfunction ⑧ Transaxle fluid temperature sensor malfunction ⑨ Powertrain control module ⑩ Oil cooler circuit malfunction | | <ul style="list-style-type: none"> page K1-18 page K1-48 page K1-58 page K1-35 section F2 page K1-32 page K1-33 page K1-31 section F2 page K1-18 |

SERVICE POINTS

OUTLINE

O/D OFF Switch

- If there is an open or short circuit in the O/D OFF switch or harness, selection to/from O/D OFF mode is not possible.

Transaxle Range Switch

- If there is an open or short circuit in the transaxle range switch or harness, diagnostic trouble code P0705 is displayed by the on-board diagnostic system, and O/D OFF mode is canceled.
- If a malfunction occurs in the wiring of the transaxle range switch, the powertrain control module cannot determine the range position, and shifting may be abnormal in D, 2, and 1 ranges. There may not be a shift to fourth gear.

Throttle Position Sensor

- If there is an open or short circuit in the throttle position sensor or harness, diagnostic trouble code P0120 is displayed by the on-board diagnostic system, and O/D OFF mode is canceled.
- If a malfunction occurs in the throttle position sensor, the powertrain control module judges the throttle opening to be at a constant 4/8 stroke.

Closed Throttle Position Switch

- If there is an open circuit in the closed throttle position switch or harness, the powertrain control module does not correct throttle characteristics. In case of misadjustment of throttle position sensor, torque converter clutch operation is not canceled when cruising (closed throttle position) and vehicle jolts when accelerator pedal is depressed or released.
- If there is a short circuit in the closed throttle position switch or harness, the line pressure will be low (does not match throttle characteristics) and the transaxle may slip when shifting.

Input/Turbine Speed Sensor

- If there is no input signal from the input/turbine speed sensor, diagnostic trouble code P0715 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the input/turbine speed sensor, shifting is made based on signals from speedometer.
- If a malfunction occurs in the input/turbine speed sensor and vehicle speedometer sensor at the same time, shift solenoid A, B and C go to OFF, and D and 2 ranges go to third gear position. 1 range goes to first gear position, and torque converter clutch operation is inhibited.

Vehicle Speedometer Sensor

- If there is no input signal from the vehicle speedometer sensor, diagnostic trouble code P0500 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the vehicle speedometer sensor, shifting is made normal based on signals from input/turbine speed sensor.

Brake Switch

- If there is an open circuit in the brake switch or harness, torque converter clutch operation is not canceled when brake pedal is pressed.
- If there is a short circuit in the brake switch or harness, torque converter clutch operation and slip torque converter clutch operation is inhibited, but slip torque converter clutch functions when coasting.

Transaxle Fluid Temperature Sensor

- If there is an open or short circuit in the transaxle fluid temperature sensor or harness, diagnostic trouble code P0710 is displayed by the on-board diagnostic system but O/D OFF mode operates normally.
- If a malfunction occurs in the transaxle fluid temperature sensor, shift shock will be strong.
- The O/D OFF indicator light does not flash if there is an open and short circuit in the transaxle fluid temperature sensor or harness; however the diagnostic trouble code No. is memorized in the powertrain control module.

Fourth Gear Inhibit Signal (ASC Signal)

- If there is an open circuit in the fourth gear inhibit circuit, there is no input signal from the cruise control unit and acceleration feeling (driving performance) will deteriorate when the vehicle speed drops 8 km/h {5 mph} below the set speed or RESUME/ACCEL switch is operated during cruise control operation.
- If there is a short in the fourth gear inhibit signal circuit, there is no shift to fourth gear.

Engine Speed Input Signal

- If there is no input signal from the engine speed input signal, diagnostic trouble code P0335 is displayed by the on-board diagnosis function, and O/D OFF mode is canceled.

Barometric Pressure Sensor

- If there is an open or short circuit in the barometric pressure sensor circuit, the line pressure is not controlled correctly at high altitude and shift shock will be strong.

Shift Solenoid A

- If there is an open or short circuit in the shift solenoid A or harness, diagnostic trouble code P0750 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the shift solenoid A, the solenoid valve turns OFF and torque converter clutch operation is canceled.

Shift Solenoid B

- If there is an open or short circuit in the shift solenoid B or harness, diagnostic trouble code P0755 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the shift solenoid B, the solenoid valve turns OFF and torque converter clutch operation is canceled.

Shift Solenoid C

- If there is an open or short circuit in the shift solenoid C or harness, diagnostic trouble code P0760 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the shift solenoid C, the solenoid valve turns OFF and torque converter clutch operation is canceled.

Torque Converter Clutch Control Solenoid Valve

- If there is an open or short circuit in the torque converter clutch control solenoid valve or harness, diagnostic trouble code P1743 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the torque converter clutch control solenoid valve, the solenoid valve turns OFF and torque converter clutch operation is canceled.

3–2 Timing Solenoid Valve

- If there is an open or short circuit in the 3–2 timing solenoid valve or harness, diagnostic trouble code P1765 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the 3–2 timing solenoid valve, the solenoid valve turns OFF and torque converter clutch operation is canceled.

Torque Converter Clutch Solenoid Valve

- If there is an open or short circuit in the torque converter clutch solenoid valve or harness, diagnostic trouble code P1744 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the torque converter clutch solenoid valve, the solenoid valve turns OFF and torque converter clutch operation is canceled.

Pressure Control Solenoid

- If there is an open or short circuit in the pressure control solenoid or harness, diagnostic trouble code P0745 is displayed by the on-board diagnostic system and O/D OFF mode is canceled.
- If a malfunction occurs in the pressure control solenoid, line pressure is set at maximum to make driving possible.
- If a malfunction occurs in pressure control solenoid, torque converter clutch operation is canceled.

O/D OFF Indicator Light

- If there is an open circuit in the O/D OFF indicator light harness or the bulb is burnt out, the light will not illuminate.
- If there is a short circuit in the O/D OFF indicator light harness, the light will remain illuminated.

ELECTRICAL DIAGNOSIS SUPPORT
O/D OFF Switch

| Circuit | Condition | | |
|--|--|--|---|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2L terminal — O/D OFF switch | Mode does not change when O/D OFF switch is operated | Mode does not change when O/D OFF switch is operated | Mode may not change when O/D OFF switch is operated |
| O/D OFF switch — ground | | No symptom | |

Transaxle Range Switch

Note

- If fuse burnt out while driving, powertrain control module judges condition as the R position.
- When ignition switch is turned from OFF to ON after fuse burnt out, powertrain control module judges condition as the R position.

R Position Switch

| Circuit | Condition | | |
|---|--------------|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2K terminal — R position switch | No symptom | Meter 15 A fuse burns out when R position is selected | No symptom |
| R position switch — battery | | Fuse burns out | |

1 Range Switch

| Circuit | Condition | | |
|--|--|--|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2R terminal — 1 range switch | First gear is fixed in 1 range (solenoid pattern same as R position) | Meter 15 A fuse burns out when 1 range is selected | No symptom |
| 1 range switch — battery | | Fuse burns out | |

2 Range Switch

| Circuit | Condition | | |
|--|--|--|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2M terminal — 2 range switch | Third gear is fixed in 2 range (solenoid pattern same as R position) | Meter 15 A fuse burns out when 2 range is selected | No symptom |
| 2 range switch — battery | | Fuse burns out | |

D Range Switch

| Circuit | Condition | | |
|--|--|--|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2I terminal — D range switch | Third gear is fixed in D range (solenoid pattern same as R position) | Meter 15 A fuse burns out when D range is selected | No symptom |
| D range switch — battery | | Fuse burns out | |

P, N Position Switch

| Circuit | Condition | | |
|--|--------------------------|--|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 1F terminal — P, N position switch | No symptom | Meter 15 A fuse burns out when ignition switch turned to START | No symptom |
| P, N position switch — starter | Starter does not operate | | |

Throttle Position Sensor

| Circuit | Condition | | |
|--|--|--|--|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 3A terminal — throttle position sensor | Code P0120 output Shift point incorrect and shift shock strong Torque converter clutch operation will be inhibited | Code P0120 output Shift point incorrect and shift shock strong Torque converter clutch operation will be inhibited | Line pressure will be abnormal and clutches may slip if powertrain control module does not judge malfunction Vehicle may jolt |
| Powertrain control module 3B terminal — throttle position sensor | | | |

Closed Throttle Position Switch

| Circuit | Condition | | |
|---|--|---------------------------------|------------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 3X terminal — closed throttle position switch | Vehicle jolts when accelerator pedal depressed or released | Clutches may slip when shifting | Vehicle may jolt |

Input/Turbine Speed Sensor

| Circuit | Condition | | |
|--|---|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2P terminal — input/turbine speed sensor | Code P0715 output Shifting does not match shift diagram and fourth gear is cancelled | Code P0715 output Shifting does not match shift diagram and fourth gear is cancelled | NA |
| Input/turbine speed sensor — ground | | NA | |

Vehicle Speedometer Sensor

| Circuit | Condition | | |
|--|-------------------|-------------------|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 1C terminal — vehicle speedometer sensor | Code P0500 output | Code P0500 output | NA |
| | | NA | |

Brake Switch

| Circuit | Condition | | |
|--|---|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 1O terminal — brake switch | Torque converter clutch operation will not be inhibited | Torque converter clutch operation will be inhibited | NA |

Transaxle Fluid Temperature Sensor

| Circuit | Condition | | |
|--|---|--|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2O terminal — transaxle fluid temperature sensor | Code P0710 output Shift shock will be strong | No Code P0710 output Shift shock will be strong | NA |
| Transaxle fluid temperature sensor — ground | | NA | |

Fourth Gear Inhibit Signal (ASC Signal)

| Circuit | Condition | | |
|---|--|-------------------------------|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 4V terminal — cruise control unit | Fourth gear not inhibited when fourth gear inhibitor signal ON | Does not shift to fourth gear | NA |

NA: Not applicable

Barometric Pressure Sensor

| Circuit | Condition | | |
|--|---|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 3F terminal — barometric pressure sensor | Shift shock will be strong at high altitude | Shift shock will be strong at high altitude | NA |

Shift Solenoid A

| Circuit | Condition | | |
|--|---|---|--|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2A terminal — shift solenoid A | Code P0750 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Code P0750 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Shifting may be abnormal if powertrain control module does not judge malfunction |
| Shift solenoid A — ground | | No symptom | |

Shift Solenoid B

| Circuit | Condition | | |
|--|---|---|--|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2B terminal — shift solenoid B | Code P0755 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Code P0755 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Shifting may be abnormal if powertrain control module does not judge malfunction |
| Shift solenoid B — ground | | No symptom | |

Shift Solenoid C

| Circuit | Condition | | |
|--|---|---|--|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2F terminal — shift solenoid C | Code P0760 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Code P0760 output Shifting will be performed by remaining normal solenoid valve(s), but does not match shift diagram and torque converter clutch operation is canceled | Shifting may be abnormal if powertrain control module does not judge malfunction |
| Shift solenoid C — ground | | No symptom | |

Torque Converter Clutch Control Solenoid Valve

| Circuit | Condition | | |
|--|---|---|---|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2C terminal — torque converter clutch control solenoid valve | Code P1743 output Torque converter clutch will not operate | Code P1743 output Torque converter clutch will not operate | Torque converter clutch may not be operated in torque converter clutch operation zone |
| Torque converter clutch control solenoid valve — ground | | No symptom | |

3-2 Timing Solenoid Valve

| Circuit | Condition | | |
|---|---|---|--------------------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2G terminal — 3-2 timing solenoid valve | Code P1765 output Shift shock may be strong Torque converter clutch operation is canceled | Code P1765 output Shift shock may be strong Torque converter clutch operation is canceled | Shifting may be abnormal |
| 3-2 timing solenoid valve — ground | | No symptom | |

NA: Not applicable

Torque Converter Clutch Solenoid Valve

| Circuit | Condition | | |
|--|---|---|---|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2D terminal — torque converter clutch solenoid valve | Code P1744 output Torque converter clutch will not operate | Code P1744 output Torque converter clutch will not operate | Torque converter clutch may not operate in torque converter clutch operation zone |
| Torque converter clutch solenoid valve — ground | | No symptom | |

Pressure Control Solenoid

| Circuit | Condition | | |
|---|--|--|---|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2H terminal — Pressure control solenoid | Code P0745 output Shift shock and select shock will be strong | Code P0745 output Shift shock and select shock will be strong | Shifting may be abnormal if transaxle control module does not judge malfunction |
| Pressure control solenoid — ground | | No symptom | |

O/D OFF Indicator Light

| Circuit | Condition | | |
|---|---|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2E terminal — O/D OFF indicator light | O/D OFF indicator light will not illuminate | O/D OFF indicator light will be illuminated | NA |

Battery Power (Backup)

| Circuit | Condition | | |
|---|--|-------------------------|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 4B terminal — battery | Memory functions that rely on self-diagnosis, such as diagnostic trouble code memory, do not operate | ROOM 15A fuse burns out | NA |

Battery Power


| Circuit | Condition | | |
|---|---|---|-------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 4A terminal — battery | No symptom | Meter 15A fuse burns out when ignition switch is ON | NA |
| Powertrain control module 4C terminal — battery | No symptom Powertrain control module D, 2 range: Third gear fixed 1 range: First gear fixed | Meter 15A fuse burns out when ignition switch is ON | NA |

Ground

| Circuit | Condition | | |
|--|--|---------------|--------------------------|
| | Open circuit | Short circuit | Poor ground |
| Powertrain control module 2P terminal — ground | Powertrain control module does not function D, 2 range: Third gear fixed 1 range: First gear fixed | No symptom | Shifting may be abnormal |

NA: Not applicable

HYDRAULIC CIRCUIT




Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

AUTOMATIC TRANSAXLE (LA4A-EL)

| | | | |
|-------------------------------------|-------|--|--------|
| INDEX | K2- 2 | SHIFT MECHANISM | K2- 65 |
| OUTLINE | K2- 3 | SELECTOR LEVER | K2- 65 |
| SPECIFICATIONS | K2- 3 | TROUBLESHOOTING GUIDE | K2- 67 |
| CROSS-SECTIONAL VIEW | K2- 4 | GENERAL NOTES | K2- 67 |
| POWER FLOW DIAGRAM | K2- 5 | QUICK DIAGNOSIS CHART | K2- 68 |
| OPERATION OF COMPONENTS .. | K2- 6 | OUTLINE | K2- 68 |
| FLUID PASSAGE LOCATIONS | K2- 7 | QUICK DIAGNOSIS CHART (I) ... | K2- 68 |
| MECHANICAL SYSTEM TEST | K2-10 | QUICK DIAGNOSIS CHART (II) ... | K2- 70 |
| PREPARATION | K2-10 | SYMPTOM TROUBLESHOOTING .. | K2- 72 |
| LINE PRESSURE TEST | K2-10 | USING THIS SECTION | K2- 72 |
| STALL TEST | K2-12 | DIAGNOSTIC INDEX | K2- 74 |
| TIME LAG TEST | K2-14 | SYMPTOM TROUBLESHOOTING | |
| TORQUE CONVERTER CLUTCH | | CHART | K2- 75 |
| OPERATION TEST | K2-15 | ON-BOARD DIAGNOSTIC SYSTEM K2-117 | |
| ROAD TEST | K2-15 | DESCRIPTION | K2-117 |
| D RANGE TEST | K2-15 | PREPARATION | K2-118 |
| 2 RANGE TEST | K2-19 | ON-BOARD DIAGNOSTIC TEST . | K2-118 |
| 1 RANGE TEST | K2-20 | DIAGNOSTIC TROUBLE CODE .. | K2-123 |
| P POSITION TEST | K2-20 | SERVICE POINTS | K2-144 |
| AUTOMATIC TRANSAXLE FLUID | | OUTLINE | K2-144 |
| (ATF) | K2-22 | WIRING DIAGRAM | K2-145 |
| ATF | K2-22 | HYDRAULIC CIRCUIT | K2-149 |
| ELECTRICAL SYSTEM | | TRANSAXLE OVERHAUL | K2-150 |
| COMPONENTS | K2-24 | TRANSAXLE UNIT | |
| PREPARATION | K2-24 | (DISASSEMBLY) | K2-150 |
| TRANSAXLE TESTER | | TORQUE CONVERTER | K2-175 |
| INSTRUCTION | K2-25 | OIL PUMP | K2-176 |
| MLP TESTER INSTRUCTION | K2-34 | FORWARD ONE-WAY CLUTCH, | |
| TRANSAXLE | K2-39 | LOW-INTERMEDIATE SUN GEAR | |
| TRANSAXLE UNIT (REMOVAL) ... | K2-39 | ASSEMBLY, AND LOW-INTERMEDIATE | |
| 2/4 BAND SERVO (ON-VEHICLE | | CARRIER ASSEMBLY | K2-180 |
| REMOVAL / INSPECTION / | | FORWARD/COASTING/DIRECT CLUTCH | |
| INSTALLATION) | K2-44 | CYLINDER AND REVERSE CLUTCH | |
| CONTROL VALVE BODY AND | | DRUM | K2-184 |
| THERMOSTATIC OIL LEVEL CONTROL | | LOW ONE-WAY CLUTCH | K2-198 |
| VALVE (ON-VEHICLE REMOVAL / | | REVERSE/FOURTH GEAR RING GEAR, | |
| INSTALLATION) | K2-45 | REVERSE/FOURTH GEAR CARRIER | |
| DIFFERENTIAL OIL SEALS (ON-VEHICLE | | ASSEMBLY, AND CHAIN DRIVE . | K2-199 |
| REMOVAL / INSTALLATION) | K2-48 | CONTROL VALVE BODY | |
| ATF LEAK FROM OIL PUMP BODY | | (DISASSEMBLY / INSPECTION) . | K2-201 |
| SEAL | K2-49 | ACCUMULATOR BODY | K2-205 |
| TRANSAXLE UNIT | | VALVE BODY ASSEMBLY | K2-207 |
| (INSTALLATION) | K2-55 | CONTROL VALVE BODY | |
| OIL COOLER | K2-61 | (ASSEMBLY) | K2-209 |
| OIL COOLER | K2-61 | DIFFERENTIAL | K2-212 |
| DRIVE PLATE | K2-63 | TRANSAXLE UNIT (ASSEMBLY) . | K2-214 |
| PREPARATION | K2-63 | | |
| DRIVE PLATE | K2-63 | | |

INDEX



| | |
|---|--|
| 1. ATF Inspection page K2- 22 | 6. Control valve body Disassembly / Inspection page K2-201 |
| 2. TR switch MLP tester instruction page K2- 34 | Assembly page K2-209 |
| 3. Solenoid body Transaxle tester instruction .. page K2- 25 | On-vehicle removal / installation page K2- 45 |
| 4. TSS sensor Transaxle tester instruction .. page K2- 25 | 7. Oil cooler Removal / Inspection / Installation page K2- 61 |
| 5. Transaxle Removal page K2- 39 | 8. Drive plate Removal / Inspection / Installation page K2- 63 |
| Installation page K2- 55 | 9. Shift mechanism page K2- 65 |
| Overhall page K2-150 | |


OUTLINE

SPECIFICATIONS


K2

| Item | | Transaxle/Engine | LA4A-EL |
|-----------------------------------|----------------------------|------------------|------------------|
| | | | FS |
| Transaxle control | | | Floor shift |
| Torque converter clutch mechanism | | | Equipped |
| Gear ratio | First gear | | 2.889 |
| | Second gear | | 1.571 |
| | Third gear | | 1.000 |
| | Fourth gear | | 0.698 |
| | Reverse | | 2.310 |
| Final gear ratio | | | 3.770 |
| ATF | Type | | M-III or MERCON® |
| | Capacity L {US qt, Imp qt} | | 8.3 {8.8, 7.3} |
| Number of drive/driven plates | Forward clutch | | 2/3 |
| | Coasting clutch | | 2/2 |
| | Direct clutch | | 3/3 |
| | Reverse clutch | | 2/2 |
| | Low/rev clutch | | 3/3 |

CROSS-SECTIONAL VIEW




POWER FLOW DIAGRAM



- | | |
|-------------------------------|--|
| 1. Torque converter | 12. Low/intermediate planetary carrier |
| 2. Turbine shaft | 13. Low/intermediate ring gear |
| 3. Oil pump drive shaft | 14. Reverse/fourth gear sun gear |
| 4. Oil pump | 15. Low/reverse clutch |
| 5. Reverse clutch | 16. Low one-way clutch |
| 6. 2/4 band | 17. Reverse/fourth gear carrier |
| 7. Direct clutch | 18. Reverse/fourth gear ring gear (Drive sprocket) |
| 8. Coasting clutch | 19. Chain |
| 9. Forward clutch | 20. Driven sprocket |
| 10. Forward one-way clutch | 21. Differential |
| 11. Low/intermediate sun gear | |

K2




OPERATION OF COMPONENTS


| Position/ Range | Mode | Gear | Engine braking effect | 2/4 band | Reverse clutch | Direct clutch | Forward clutch | Forward one-way clutch | | Coasting clutch | Low/reverse clutch | Low one-way clutch | |
|--------------------|------------------------|--------------|--------------------------|----------|----------------|---------------|----------------|------------------------------|-------|-----------------|--------------------|--------------------------|----------|
| | | | | | | | | Drive | Coast | | | Drive | Coasting |
| P | — | — | — | | | | | | | | | | |
| R | — | Reverse gear | Yes | | ○ | | | | | | ○ | | |
| N | — | — | — | | | | | | | | | | |
| D | ☆ O/D OFF SW OFF | First gear | No | | | | ○ | ○ | ⊗ | | | ○ | ⊗ |
| | | Second gear | No | ○ | | | ○ | ○ | ⊗ | | | | |
| | | Third gear | No | | | ○ | ○ | ○ | ⊗ | | | | |
| | | Fourth gear | Yes | ○ | | ○ | ⊙ | ⊗ | | | | | |
| | ☆ O/D OFF SW ON | First gear | No | | | | ○ | ○ | — | ○ | | ○ | ⊗ |
| | | Second gear | Yes | ○ | | | ○ | ○ | — | ○ | | ⊗ | ⊗ |
| | | Third gear | Yes | | | ○ | ○ | ○ | — | ○ | | ⊗ | ⊗ |
| | | *Fourth gear | Yes | ○ | | ○ | ⊙ | ⊗ | ⊗ | | | ⊗ | ⊗ |
| 2 | — | Second gear | Yes | ○ | | | ○ | ○ | — | ○ | | ⊗ | ⊗ |
| | | *Third gear | Yes | | | ○ | ○ | ○ | — | — | | ⊗ | ⊗ |
| | | *Fourth gear | Yes | ○ | | ○ | ⊙ | ⊗ | ⊗ | | | ⊗ | ⊗ |
| 1 | — | First gear | Yes | | | | ○ | ○ | — | ○ | ○ | ○ | — |
| | | *Second gear | Yes | ○ | | | ○ | ○ | — | ○ | | ⊗ | ⊗ |

- Operating.
- ⊗ Operating but not contributing to transaxle output. (OVER RUNNING)
- ⊙ Power is not transmitted.
- * Engine overspeed protection.
- ☆ The powertrain control module switches automatically between power and normal modes corresponding to how rapidly the accelerator pedal is depressed.


FLUID PASSAGE LOCATIONS
Transaxle Case



K2




Converter Housing




Oil Pump

SEAL RINGS








BOTTOM VIEW



K2

MECHANICAL SYSTEM TEST

PREPARATION SST


| | | | |
|---|------------------------------|--|------------------------------|
| <p>49 UN01 128</p> <p>Adapter to mate hose</p>  | <p>For oil pressure test</p> | <p>49 0378 400A</p> <p>Gauge set, oil pressure</p>  | <p>For oil pressure test</p> |
| <p>49 B019 902</p> <p>Oil pressure gauge (Part of 49 0378 400A)</p>  | <p>For oil pressure test</p> | <p>49 B019 903</p> <p>Hose (Part of 49 0378 400A)</p>  | <p>For oil pressure test</p> |
| <p>49 B019 901</p> <p>Oil pressure gauge</p>  | <p>For oil pressure test</p> | <p>—</p> | <p>—</p> |

LINE PRESSURE TEST


This test measures line pressure as a means of checking the hydraulic components and inspecting for oil leakage.

Preparation


1. Engage the parking brake and use wheel chocks at the front and rear of the wheels.
2. Check, and correct as necessary, the engine coolant level.
3. Warm the engine thoroughly to raise the ATF temperature to operating level **66—77°C {150—170°C}**.
4. Check, and correct as necessary, the engine oil and ATF levels.
5. Check the idle speed and ignition timing in P position. (Service as section F3.)




ENGAGE PARKING BRAKE




WARM UP ENGINE




ENGINE COOLANT LEVEL



ENGINE OIL LEVEL



WHEEL CHOCK




DO NOT DRIVE MARK MIN. MAX.

FLUID LEVEL AT NORMAL OPERATING TEMPERATURE 66—77°C {150—170°F}

ATF LEVEL

Procedure

**Caution**

- Perform the **LINE PRESSURE TEST** prior to performing the **STALL TEST**. If line pressure is low at stall, do not perform the **STALL TEST** or further transaxle damage will occur. Do not keep the **WOT** in any gear range for more than 5 seconds.
- The transaxle tester must be removed from the transaxle and the vehicle harness reinstalled in order to verify the line pressure.

1. Connect the **SST** to the line pressure inspection port.
2. Start engine.
3. Shift the selector to **D** range and read the line pressure at idle.
4. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.
5. When the engine speed no longer increases, quickly read the line pressure and release the accelerator.
6. Shift the selector to **N** position and let the engine idle for 1 minute or more to cool the ATF.
7. Read the line pressure at idle and at the engine stall speed for each range in the same manner.

Specified line pressure

| LINE PRESSURE SPECIFICATIONS | | | | |
|------------------------------|---------|---------------------------------|-------------|---------------------------------|
| | IDLE | kPa {kgf-cm ² , psi} | STALL | kPa {kgf-cm ² , psi} |
| P, N | 441—524 | {4.50—5.34, 64—76} | — | — |
| R | 441—524 | {4.50—5.34, 64—76} | 1,786—2,027 | {18.21—20.66, 259—294} |
| D | 310—365 | {3.16—3.72, 45—53} | 1,158—1,269 | {11.80—12.93, 168—184} |
| 2 | 310—365 | {3.16—3.72, 45—53} | 1,158—1,269 | {11.80—12.93, 168—184} |
| 1 | 310—365 | {3.16—3.72, 45—53} | 1,158—1,269 | {11.80—12.93, 168—184} |

8. Install a new square head plug in the inspection port.

Evaluation of Line Pressure Test

| Line pressure | Possible cause |
|--------------------------------|---|
| Low pressure in every position | Fluid level low Restricted inlet filter Control valve body, solenoid body or accumulator body is loose Excessive leakage in pump, case, control bodies Sticking main regulator valve Damaged inlet tube seal or inlet filter Damaged gaskets, separator plate |
| Higher than specification | Problem with main regulator valve, solenoid body and wiring harness |


STALL TEST

This test is performed to determine if there is slippage of the friction elements or a malfunction of the hydraulic components.

Preparation

Perform the preparation procedure outlined in LINE PRESSURE TEST. (Refer to page K2-10.)

Procedure



Warning

- Apply the service and parking brakes firmly while performing each STALL TEST. Failure to set the brakes may result in death or bodily injury.

Caution

- Perform the LINE PRESSURE TEST prior to performing the STALL TEST. If line pressure is low at stall, do not perform the STALL TEST or further transaxle damage will occur. Do not keep the WOT in any gear range for more than 5 seconds.

1. Start the engine.
2. Shift the selector lever to R position.

Caution

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transaxle could be damaged. Therefore, do steps 4 and 5 within 5 seconds of each other.

3. Firmly depress the foot brake with the left foot, and gently depress the accelerator pedal with the right foot.
4. When the engine speed no longer increases, quickly read the engine speed and release the accelerator.
5. Shift the selector to N position and let the engine idle for 1 minute or more to cool the ATF.
6. Perform stall tests for the remaining ranges in the same manner.
 - (1) D range
 - (2) 2 range
 - (3) 1 range

Engine stall speed: 2,200—2,500 rpm

Evaluation of Stall Test

| Condition | | Possible cause |
|---------------------|---------------|--|
| Above specification | in D range | Forward clutch Forward one-way clutch Low one-way clutch |
| | In R position | Reverse clutch Low and reverse clutch |
| Below specification | | Engine Torque converter one-way clutch |


TIME LAG TEST

This test measures time lag as a means of checking the hydraulic components and the friction elements.

Preparation

Perform the preparation procedure outlined in LINE PRESSURE TEST. (Refer to page K2-10.)

Procedure



1. Start the engine.
2. Shift from N position to D range.
3. Use a stopwatch to measure the time it takes from shifting until shock is felt.
4. Shift the selector to N position and run the engine at idle speed for at least one (1) minute.
5. Do the time lag test for the following shifts in the same manner. Take three measurements for each test and average the results.
6. Perform the test for the following shifts in the same manner.
 - (1) N → D range
 - (2) N → R position

Time lag: N → D range ... below approx. 1.0 second
N → R position ... below approx. 1.0 second

Evaluation of Time Lag Test

| Condition | | Possible Cause |
|-------------|-------------------------|---|
| N → D shift | More than specification | Insufficient line pressure Forward clutch slipping Forward one-way clutch slipping Low one-way clutch slipping |
| | Less than specification | Forward accumulator not operating properly Excessive line pressure |
| N → R shift | More than specification | Insufficient line pressure Low/reverse clutch slipping Reverse clutch slipping |
| | Less than specification | Low/reverse accumulator not operating properly Excessive line pressure |

TORQUE CONVERTER CLUTCH OPERATION TEST

This test verifies that the torque converter clutch control system and the torque converter are operating properly.

Warning

- **Doing this test by yourself can be dangerous. You could have an accident if you are looking at the manual or devices while driving, which may result in death or injury. Always have another person in the vehicle with you to read the manual or devices while you drive.**

Note

- Perform the OBD Test. Check for a code P0741 or P0743. Refer to the appropriate pinpoint test or procedure for diagnosis.
1. Bring the engine to normal operating temperature by driving the vehicle at highway speeds for approximately 15 minutes in D range.
 2. After normal operating temperature is reached, maintain a constant vehicle speed of about 80 km/h (50 mph), and tap the brake pedal with the left foot.
 3. Engine rpm should increase when the brake pedal is tapped, and decrease about 5 seconds after the brake pedal is released. If this does not occur, refer to Torque Converter Operation Concern in SYMPTOM TROUBLESHOOTING.
 4. If the vehicle stalls in D range at idle with the vehicle at a stop, move the selector lever to 1 range. If the vehicle stalls, the cause may be the converter control valve in the oil pump. Service as required. If the vehicle does not stall in 1 range, refer to Pinpoint Test C1 in ON-BOARD DIAGNOSIS SYSTEM.

ROAD TEST


A road test is necessary to inspect for problems in the different gear ranges. If a range or function targeted by the road test is found to have any problem, refer to the ELECTRONIC SYSTEM COMPONENT segment or the TRANSAXLE, OIL COOLER, DRIVE PLATE, and SHIFT MECHANISM segments of this section.

Do the road test only when the ATF is 66—77°C {150—170°F}.


D RANGE TEST**D Range (Except O/D OFF Mode)****Note**

- The power mode and the normal mode are automatically selected by the Powertrain control module.
1. Shift the selector lever to D range.
 2. Accelerate the vehicle with half and wide open throttle.
 3. Verify that 1→2, 2→3, and 3→4 upshifts and downshifts are obtained. The shift points must be as shown in the D range shift diagram.
 4. Drive the vehicle in Fourth, Third, and Second gears and verify that kickdown occurs for 4→3, 4→2, 4→1, 3→2, 3→1, 2→1, and that the shift points are as shown in the D range shift diagram.
 5. Decelerate the vehicle and verify that engine braking effect is felt in Fourth and Third gears.
 6. Drive the vehicle and verify that torque converter clutch operation is obtained. (only for normal mode)

D range (POWER mode) shift diagram




D range (NORMAL mode) shift diagram




D Range (O/D OFF Mode)

1. Shift the selector lever to D range, and select the O/D OFF mode.
2. Accelerate the vehicle with half and wide open throttle.
3. Verify that 1-2 and 2-3 upshifts and downshifts are obtained. The shift points must be as shown in the D range O/D OFF shift diagram.
4. Drive the vehicle in Third and Second gears and verify that kickdown occurs for 3→2, 3→1, 2→1, and that the shift points are as shown in the D range O/D OFF shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in Third gear.
6. Drive the vehicle and verify that torque converter clutch operation is obtained. (only for normal mode)

D range (O/D OFF POWER mode) shift diagram




D range (O/D OFF NORMAL mode) shift diagram



2 RANGE TEST

1. Shift the selector lever to 2 range.
2. Accelerate the vehicle with half and wide open throttle, and verify that Second gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.


2 range shift diagram



1 RANGE TEST

1. Shift the selector lever to 1 range.
2. Accelerate the vehicle with half and wide open throttle, and verify that First gear is held.
3. Decelerate the vehicle and verify that engine braking effect is felt.

1 range shift diagram



P POSITION TEST





Shift into P position on a gentle slope, release the brake, and verify that the vehicle does not roll.

Vehicle Speed at Shiftpoint Table

| Range Mode | | Throttle condition (throttle position sensor voltage) | Shift | Vehicle speed km/h {mph} | |
|---|--------------------------------------|--|--------------------------------------|--------------------------------|--------------------------------|
| D | O/D OFF switch OFF | POWER | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 51—57 {32—35} |
| | | | | D ₂ →D ₃ | 101—109 {63—68} |
| | | | | D ₃ →D ₄ | 157—167 {97—104} |
| | | | Half throttle | D ₁ →D ₂ | 36—45 {22—28} |
| | | | | D ₂ →D ₃ | 74—92 {46—57} |
| | | | | D ₃ →D ₄ | 124—149 {77—92} |
| | | Closed throttle position (0.1—1.1 V) | D ₄ →D ₃ | 37—43 {23—27} | |
| | | | D ₃ →D ₁ | 8—14 {5—9} | |
| | | Kickdown | D ₄ →D ₃ | 148—158 {92—98} | |
| | | | D ₃ →D ₂ | 93—101 {58—63} | |
| | | | D ₂ →D ₁ | 37—43 {23—27} | |
| | | | NORMAL | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ |
| | D ₂ →D ₃ | | | | 101—109 {63—68} |
| | D ₃ →D ₄ | | | | 157—167 {97—104} |
| | TCC ON (D ₄) | 147—157 {91—97} | | | |
| | Half throttle | D ₁ →D ₂ | | 28—36 {17—22} | |
| | | D ₂ →D ₃ | | 61—77 {38—48} | |
| | | D ₃ →D ₄ | 105—132 {65—82} | | |
| | TCC ON (D ₄) | 118—145 {73—90} | | | |
| | Closed throttle position (0.1—1.1 V) | D ₄ →D ₃ | 37—43 {23—27} | | |
| | | D ₃ →D ₁ | 8—14 {5—9} | | |
| | Kickdown | D ₄ →D ₃ | 148—158 {92—98} | | |
| | | D ₃ →D ₂ | 93—101 {58—63} | | |
| | | D ₂ →D ₁ | 37—43 {23—27} | | |
| O/D OFF switch ON | | POWER | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 51—57 {32—35} |
| | | | | D ₂ →D ₃ | 101—109 {63—68} |
| | | | | D ₁ →D ₂ | 36—45 {22—28} |
| | Half throttle | | D ₂ →D ₃ | 75—91 {47—56} | |
| | | | Closed throttle position (0.1—1.1 V) | D ₃ →D ₁ | 8—14 {5—9} |
| | | | | D ₃ →D ₂ | 93—101 {58—63} |
| | Kickdown | D ₂ →D ₁ | 42—48 {26—30} | | |
| | | NORMAL | Wide open throttle (3.0—4.4 V) | D ₁ →D ₂ | 51—57 {32—35} |
| | | | | D ₂ →D ₃ | 101—109 {63—68} |
| | | | | TCC ON (D ₂) | 51—57 {32—35} |
| | | | TCC ON (D ₃) | 101—109 {63—68} | |
| | | | Half throttle | D ₁ →D ₂ | 28—37 {17—23} |
| D ₂ →D ₃ | 55—72 {34—45} | | | | |
| TCC ON (D ₃) | 55—72 {34—45} | | | | |
| Closed throttle position (0.1—1.1 V) | D ₃ →D ₁ | 8—14 {5—9} | | | |
| | D ₃ →D ₂ | 93—101 {58—63} | | | |
| Kickdown | D ₂ →D ₁ | 42—48 {26—28} | | | |
| | 2 | — | TCC ON (S ₃) | 104—114 {64—71} | |
| D ₄ (S ₄)→S ₃ | | | 162—168 {100—104} | | |
| S ₃ →S ₂ | | | 103—109 {64—68} | | |
| 1 | — | L ₂ →L ₁ | 43—49 {27—30} | | |

Input the voltages displayed on the engine signal monitor into the following formula to calculate the half throttle voltage.

$$\frac{\text{Wide open throttle voltage} - \text{Closed throttle position voltage}}{2} = \text{Half throttle voltage}$$



AUTOMATIC TRANSAXLE FLUID (ATF)

ATF Inspection Level

1. Park the vehicle on level ground.
2. Apply the parking brake and position wheel chocks securely to prevent the vehicle from rolling.
3. Warm up the engine until the ATF reaches **66—77°C {150—170°F}**.

Caution

- **Do not warm the transaxle by performing stalls. This will damage the torque converter.**

4. While depressing the brake pedal, shift the selector lever to each range (P—1), pausing momentarily in each range.
5. Shift back to P position.

6. Ensure that the ATF level is between max. and min.

ATF type: M-III or MERCON®

Total capacity: 8.3 L {8.8 US qt, 7.3 Imp qt}

Condition


Determine whether the automatic transaxle should be disassembled by noting:

1. If the ATF is muddy or varnished.
2. If the ATF smells strange or unusual.

Fluid Leaks













Check for ATF leaks of the transaxle at the points shown below and repair or replace as necessary.

- 1. Gaskets, O-rings, and plugs.
- 2. Oil hoses, oil pipes, and connections.
- 3. Oil cooler.



ELECTRICAL SYSTEM COMPONENTS

PREPARATION SST

| | | | |
|---|--|--|--|
| <p>49 UN01 086</p> <p>MLPS alignment tool</p>  | <p>For Alignment of TR switch</p> | <p>49 UN01 071</p> <p>Transaxle tester</p>  | <p>For check of electrical system components</p> |
| <p>49 UN01 089</p> <p>Transaxle diagnostic harness</p>  | <p>For check of electrical system components</p> | <p>49 UN01 090</p> <p>Transaxle overlay</p>  | <p>For check of electrical system components</p> |
| <p>49 UN01 091</p> <p>MLPS harness adapter</p>  | <p>For check of TR switch</p> | <p>49 UN01 092</p> <p>MLPS overlay</p>  | <p>For check of TR switch</p> |
| <p>49 UN01 128</p> <p>Adapter</p>  | <p>For oil pressure test</p> | <p>49 0378 400A</p> <p>Gauge set, oil pressure</p>  | <p>For oil pressure test</p> |
| <p>49 B019 901</p> <p>Oil pressure gauge</p>  | <p>For oil pressure test</p> | <p>49 B019 902</p> <p>Oil pressure gauge (Part of 49 0378 400A)</p>  | <p>For oil pressure test</p> |
| <p>49 B019 903</p> <p>Hose (Part of 49 0378 400A)</p>  | <p>For oil pressure test</p> | <p>49 UN01 056</p> <p>Super STAR II tester</p>  | <p>For diagnosis of malfunction</p> |

TRANSAXLE TESTER INSTRUCTION

The transaxle tester allows a technician to operate the electrical portion of the transaxle independent of the vehicle electronics. The transaxle tester usage is divided into five steps.

1. Preliminary testing and diagnosis.
2. Installing the transaxle tester.
3. Static testing-vehicle OFF.
4. Dynamic testing-vehicle running.
5. Removing the transaxle tester and clearing Diagnostic Trouble Codes (DTCs).

Preliminary Testing and Diagnosis

Before any diagnostic testing is done on a vehicle some preliminary checks must be performed, as outlined below. Be sure to write down your findings, especially any DTC, for future reference.

- Check ATF level and condition.
- Check for add-on items (phones, computers, CB radio etc).
- Visually inspect wiring harness and connectors.
- Check for vehicle modifications.
- Verify that the shift linkage is properly adjusted.
- Verify customer concern.
 - Upshift, Downshift, Coasting, Engagement, Noise/Vibration
- Vehicle must be at normal operating temperature.
- Perform vehicle On-Board Diagnostic Test. (Refer to page K2-118.)
- Record all DTCs.
- Repair all non-transaxle DTCs.

Installing The Transaxle Tester (Set Up Procedures)

Installing the transaxle tester at the solenoid body connector allows the separation of the vehicle electronics from the transaxle electronics. Disconnecting the normal vehicle electronics will in itself set additional DTCs and cause firm shifts. (Disconnecting the solenoid body connector defaults the transaxle to maximum line pressure).


Note

- During tester usage additional DTCs may be set.
- Therefore, it is important that all DTCs are erased after repairs have been made. To verify elimination of all DTCs, rerun the On-Board Diagnostic Test. (Refer to page K2-118.)

Caution

- Do not attempt to pry off connectors with a screwdriver. This will damage the connector and could result in a transaxle concern.

1. Disconnect the emission harness at the solenoid body connector and at the TSS connector on the oil pump body in the LH wheel arch.




2. Turn the tester solenoid select switch to the "OHMS CHECK" position.

Caution

- Route all cables away from heat sources.


3. Install the SST onto tester. Connect the SST to the transaxle tester and then to the appropriate solenoid body connector and TSS connector.




Caution


- Route all gauge lines away from heat sources.

4. Connect the SST to the line pressure inspection port.



5. Plug the transaxle tester power supply plug into the cigarette lighter receptacle. At this time, all LED's should illuminate for a short period and then turn off. This is the tester internal circuit check.





6. Set the Bench/Drive switch to "BENCH" mode.

Static Testing-Vehicle "OFF"


Static testing procedures allow for shop testing of the transaxle in the vehicle or on the bench. Completion of these tests prove out the transaxle electronically.

Caution

- For resistance checks, be sure that the tester solenoid select switch is set to the "OHMS CHECK" position or damage to the ohmmeter may result.

Resistance/Continuity Tests

- Refer to Pinpoint Test (Refer to page K2-124.) to be performed "On Board Diagnostics" based on the DTC displayed.
- Using a volt-ohmmeter and the transaxle tester, perform the Pinpoint Tests as indicated in "On Board Diagnostics" (Refer to page K2-124) based on the DTC which were displayed.
- Perform repairs as indicated by the Pinpoint Tests. (Refer to page K2-124.) Always retest and road test the vehicle after a repair. (Refer to page K2-15.)




Transaxle Solenoid and Sensors Resistance Tests Solenoids (EPC, SS1, SS2, TCC, 3-2T/CCS)

1. Set an ohmmeter to the 0—100 ohm range.
2. Connect the position lead of the ohmmeter to the appropriate VPWR jack for the solenoid being tested.
3. Connect the negative lead of the ohmmeter to the appropriate solenoid (EPC, SS1, SS2, TCC, 3-2T/CCS) jack.
4. Record the resistance.
5. Refer to the chart for the valves.

| SOLENOID | SOLENOID RESISTANCE (Ω) |
|----------|----------------------------------|
| SS1 | 12—22 |
| SS2 | 12—22 |
| TCC | 12.5—19.0 |
| EPC | 3.7—5.92 |
| 3-2T/CCS | 3.7—5.92 |

6. If out of range refer to the following pinpoint tests.
 - Pinpoint test E (EPC) (Refer to page K2-133.)
 - Pinpoint test A (SS1, SS2) (Refer to page K2-124.)
 - Pinpoint test C (TCC) (Refer to page K2-128.)
 - Pinpoint test G (3-2T/CCS) (Refer to page K2-137.)




Transaxle Fluid Temperature (TFT)

1. Set an ohmmeter to the 1,000 ohm range.
2. Connect the positive lead to the + TFT jack.
3. Connect the negative lead to the - TFT jack.

4. Record the resistance. Resistance will vary with temperature.
5. Refer to the chart for the valves.



| Temperature °C {°F} | Resistance kΩ |
|---------------------|---------------|
| -40—-20 {-40—-4} | 967—284 |
| -19—-1 {-3—31} | 284—100 |
| 0—20 {32—58} | 100—37 |
| 21—40 {59—104} | 37—16 |
| 41—70 {105—158} | 16—5 |
| 71—90 {159—194} | 5—2.7 |
| 91—110 {195—230} | 2.7—1.5 |
| 111—130 {231—266} | 1.5—0.8 |
| 131—150 {267—302} | 0.8—0.54 |

6. If out of range, refer to Pinpoint test B. (Refer to page K2-126.)



Turbine Shaft Speed (TSS) Sensor

1. Set an ohmmeter to the 1,000 ohm range.
2. Connect the positive lead to the +TSS jack.
3. Connect the negative lead to the -TSS jack.
4. Record the resistance.
5. TSS should be **140—290 ohm**.
6. If out of range, refer to Pinpoint test F. (Refer to page K2-135.)



Short to Ground and Solenoid Voltage Tests


Note

- LED will turn "GREEN" when solenoid activates and turn "OFF" when deactivated. LED will turn "RED" if an activated solenoid/harness is shorted to BAT+. LED will remain "OFF" if an activated solenoid/harness is shorted to ground or no continuity.

1. Tester Bench/Drive switch set to "BENCH" mode.
2. Set an voltmeter to the 20 volt D.C. range.
3. Connect the voltmeter positive lead to the appropriate solenoid VPWR.
4. Connect voltmeter negative lead to the appropriate solenoid.
5. Using the voltmeter, check for voltage across each solenoid by activating the solenoid switch. Select the appropriate solenoid with the rotary switch and depress the corresponding solenoid switch. The "LED" should illuminate, the voltage should change, and an audible click may be heard. If "LED" does not illuminate, a short to ground condition exists.
6. Observe and record the values.


Dynamic Testing-Vehicle Running

Dynamic testing is the final step in the transaxle tester usage. It allows the transaxle to be proven out electronically and hydraulically.



Transaxle Solenoid Cycling and Drive Test Procedures Preliminary Set Up

1. Set the Bench/Drive switch to DRIVE mode.
2. Rotate the gear select switch on tester to the GEAR SELECT "1" position.
3. Set the vehicle in PARK.
4. Start the vehicle.





EPC Solenoid

Caution

- Do not attempt to keep the EPC switch depressed (minimum line pressure) and stall the transaxle (holding the vehicle with the brake while depressing the throttle with the transaxle in gear). Transaxle damage will result.

5. Observe the line pressure. Record the value. Line pressure should go to maximum. If not, refer to SYMPTOM TROUBLESHOOTING (refer to page K2-72) or Pinpoint test "E" concerning the EPC solenoid. (refer to page K2-133.)
6. Depress the EPC switch. Line pressure should drop to a minimum value. Record the value. If not, refer to SYMPTOM TROUBLESHOOTING (refer to page K2-72.) or Pinpoint Test "E". (refer to page K2-133.)



Engagement

Note

- For reverse operation, the gear select switch must be in "3/R".

7. Set the Bench/Drive switch to the "DRIVE" mode.
8. Rotate the gear select switch to GEAR SELECT "1".
9. Start the vehicle, rotate the gear select switch to GEAR SELECT "3/R". Line pressure should drop to idle pressure. While holding the EPC switch down, shift the vehicle from PARK to REVERSE.

- Does the vehicle shift into REVERSE?

Note

- Engagement will be harsh and line pressure will be at maximum regardless of the EPC switch during reverse check.

Shift the vehicle from REVERSE to PARK.

10. Rotate the gear select switch to GEAR SELECT "1". Depress the EPC switch. Line pressure should drop to idle pressure. While holding the EPC switch down, shift the vehicle from PARK to DRIVE.

- Does the vehicle shift into DRIVE?
- Was the engagement smooth?

Shift the vehicle from DRIVE to PARK.

Release the EPC switch. Line pressure should return to maximum. Repeat steps 9 and 10 for engagements. With the EPC switch released, engagements should be firm.


Upshift/Downshift

Note

- GEAR SELECT SWITCH must be in GEAR SELECT “3/R” to get REVERSE gear.
- Upshifts and downshifts will be FIRM during this procedure.
- Pressure gauges may be removed from the vehicle during these tests.
- These tests should be performed on the road. If they are performed on the hoist, the technician may not feel all of the shifts when they are engaged.
- LED’s will turn “green” when solenoids are activated and turn “off” when deactivated. Refer to the appropriate overlay for the proper status/shift sequence of the shift solenoids during upshift and downshift.

Caution

- **Selector lever must be in the D range position or internal damage could result. Do not shift to 2 or 1 range position.**



11. Verify that the gear select switch is in 1st gear position. Move the selector lever into the D range. Depress the 3–2 T/CCS button and accelerate the vehicle. If there is no vehicle movement, inspect the forward one-way clutch. If movement occurs, proceed to step 12 and continue diagnosis.
12. Verify that the gear select switch is in the “1” position. Move the selector shift lever into D range and accelerate to **5 km/h {15 mph}**. Select second gear by rotating the gear selector to “2” position.

- Did the vehicle upshift to second gear?
- Did the appropriate shift solenoids activate/deactivate?

13. Accelerate to **40 km/h {25 mph}** and select “3” position.
 - Did the vehicle upshift to third gear?
 - Did the appropriate shift solenoids activate/deactivate?
14. Accelerate to **56—72 km/h {35—45 mph}** and select “4” position.
 - Did the vehicle upshift to fourth gear?
 - Did the appropriate shift solenoids activate/deactivate?


Caution

- **The vehicle must below 56 km/h {35 mph} before selecting gear select “1” position, or the trans-axle could overrun.**

15. Reverse the order to downshift.

Note

- 4–3 downshift will be harsh when using the transaxle tester.
- Does the vehicle down shift from fourth gear to third gear, third gear to second gear, and second gear to 1st gear?.
- Did the appropriate shift solenoids activate/deactivate?



Torque Converter Clutch (TCC) Engagement

Note


- This test should be performed on the road. If it is performed on a hoist, the technician may not feel the torque converter clutch engage.

Caution

- **Do not depress the TCC switch with the transaxle in gear and the vehicle at a stop. Damage to converter clutch may result.**

16. Accelerate and shift the vehicle up into third gear. Hold the speed steady and depress the TCC switch.

- Does the converter engage?
- Does the engine rpm drop?
- Did the TCC solenoid activate?



3-2 Timing/Coasting Clutch (3-2T/CCS) Engagement

Note

- This test should be performed on the road. If it is performed on the hoist, the technician may not feel the 3-2 timing/coasting clutching disengage.

17. Accelerate and upshift the vehicle into 2nd gear. Go to closed throttle. Depress the 3-2T/CCS switch.

- Does the 3-2 timing/coasting clutch disengage?
- Did the 3-2T/CCS solenoid deactivate (light on)?

18. Remain at closed throttle, then release the 3-2T/CCS switch.

Note

- Coast clutch engagement at closed throttle will be harsh.

- Does the 3-2 timing/coasting clutch engage?
- Did the 3-2 T/CCS solenoid activate (light off)?
- Did engine braking occur when the throttle was released?



Turbine Shaft Speed Sensor Function Check.

Note

- This test may be performed on the hoist or on the road.

19. Set a voltmeter to 20 volt A.C.
Connect the positive lead to the (+) TSS jack.
Connect the negative lead to the (-) TSS jack.
Slowly accelerate the vehicle and monitor voltmeter.

- Does the voltage increase with vehicle speed?



Removing the Transaxle Tester and Clearing DTC

Caution

- Do not attempt to pry off connectors with a screwdriver. This will cause damage to connector and could result in a transaxle concern.

1. Disconnect the transaxle tester from the solenoid body connector and TSS connector.
2. Reinstall the emission harnesses. Verify the connections by pulling up on the harness.
3. Disconnect the transaxle tester power lead from the vehicle.
4. Erase all DTCs from the continuous test.
(Refer to page K2-118.)
5. Rerun the On-Board Diagnostic Test.
(Refer to page K2-118.)
6. Based on the transaxle tester testing results, proceed to the appropriate segment of this section for transaxle or electrical/wiring service.
7. Confirm the servicing by repeating transaxle tester test.

MLP TESTER INSTRUCTION

The transaxle tester allows the technician to operate the electrical portion of the TR switch. The MLP tester usage is divided into five steps.

1. Preliminary testing and diagnosis.
2. Installing the transaxle tester.
3. Testing the TR switch.
4. Testing the Park/Neutral and backup circuits.
5. Removing the transaxle tester and clearing DTCs.

Preliminary Testing and Diagnosis

Before any diagnostic testing is done on a vehicle, some preliminary checks must be performed, as outlined below. Be sure to write down your findings, especially any DTCs found, for future reference.

- Check ATF level and condition.
- Check for add-on items (phones, computers, CB radio etc).
- Visually inspect wiring harness and connector.
- Check for vehicle modifications.
- Verify that the shift linkage is properly adjusted in "OVERDRIVE".
- Verify that TR switch is properly adjusted in "NEUTRAL".
- Verify customer concern.
 - Upshift, Downshift, Coasting, Engagement, Noise/Vibration
- Vehicle must be at normal operating temperature.
- Perform vehicle On-Board Diagnostic Test. (Refer to page K2-118.)
- Record all DTCs.
- Repair all non-transaxle DTCs.

Installing the Transaxle Tester (Set Up Procedures)

Installing the transaxle tester at the TR switch connector allows the separation of the vehicle electronics from the TR switch electronics.


Note

- During tester usage, additional DTCs may be set. Therefore, it is important that all DTCs are erased after repairs have been made. To verify the elimination of all DTCs, rerun the On-Board Diagnostic Test.

Caution

- Do not attempt to pry off connectors with a screwdriver. This will damage the connector and could result in a transaxle concern.

1. Disconnect the emission harness at transaxle TR switch connector.


**Note**

- For in vehicle testing, use the SST.


Caution

- Route all cables away from heat sources.

2. Set the Bench/Drive switch to "DRIVE" mode. Install the SST onto the tester. Connect the interface cable (cable I.D. "D") to the transaxle tester and then to the TR switch connector.



3. Turn the test select switch to the "MLP SENSOR TEST" position.



4. Plug the transaxle tester power supply plug into the cigarette lighter receptacle. At this time, all LED's should illuminate for a short period and then turn off. This is the tester internal circuit check.

Testing the TR Switch

Static testing procedures allow for shop testing of the transaxle in the vehicle or on the bench. Completion of these tests prove out the TR switch electronically.

Caution

- For resistance checks, be sure that the tester select switch is set to the “MLP SENSOR TEST” position or damage to the ohmmeter may result.



Resistance/Continuity Tests

- Using a digital volt-ohmmeter and the transaxle tester, perform the pinpoint test “D” as indicated on page K2-126 based on the DTCs which were displayed.
- Perform repairs as indicated by the pinpoint test. Always retest and road test the vehicle after a repair.

TR Switch resistance tests

- TR Switch – Set the ohmmeter to the 1,000 ohm range.
- Connect the positive lead of the ohmmeter to the MLP jack.
 - Connect the negative lead of the ohmmeter to the SIGRTN jack.
 - Move the selector lever into each range position.
 - Record the resistance at each position.
 - Refer to the chart for values.
 - If out of range, refer to the pinpoint test “D” on page K2-130.

| Selector lever position | Resistance (ohms) | |
|-------------------------|-------------------|---------|
| | Minimum | Maximum |
| P | 3,770 | 4,607 |
| R | 1,304 | 1,593 |
| N | 660 | 807 |
| D | 361 | 442 |
| 2 | 190 | 232 |
| 1 | 78 | 95 |





Park/Neutral backup light and optional circuit voltage tests

Note

- LED will turn "RED" when the circuit is closed and turn "OFF" when the circuit is open.

1. Set the tester select switch to the "MLP SENSOR TEST" position.
2. Press and hold each button while moving the selector lever through each range position.
3. Monitor each "LED".

4. The status "LED" should indicate "RED" only in the indicated position. Refer to the overlay.
5. If the LED does not indicate "RED" in the desired position, or indicated "RED" in another position, first verify the TR switch alignment and then retest. If the switch fails, then replace.




Removing the transaxle tester and clearing DTC


Caution

- Do not attempt to pry off connectors with a screwdriver. This will damage the connector and could result in a transaxle concern.

1. Disconnect the transaxle tester from the TR switch connector.
2. Reinstall the emission harness. Verify the connection by pulling up on the harness.
3. Disconnect the transaxle tester power lead from vehicle.
4. Erase all DTCs by using the procedures in Section F3. (Unlatch the center button of the star tester while the codes are being displayed on a KOEO on-board diagnostic test)
5. Return to the on-board diagnostic test.
6. Verify that the customer concern has been eliminated.

**Transaxle range switch replacement**

1. Disconnect the negative battery cable.
2. Remove the resonance chamber, fresh air duct, and air cleaner assembly.
3. Disconnect the TR switch connector.
4. Remove the TR switch.



5. Shift the transaxle into N position.
6. Install the TR switch on the manual lever shaft.
7. Handly tighten the two mounting bolts.
8. Use the **SST** to align the switch on the shaft and case.
9. Tighten the two mounting bolts.








Tightening torque: 9.8 N·m {100 kgf·cm, 86.8 in·lbf}

TRANSAXLE

TRANSAXLE UNIT (REMOVAL)


Preparation


SST

| | | | |
|---|---|---|---|
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 T028 3A0</p> <p>Puller, ball joint</p>  | <p>For removal of tie rod end</p> | <p>49 T028 303</p> <p>Body (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> |
| <p>49 T028 304</p> <p>Attachment (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> | <p>—</p> | <p>—</p> |


Removal

1. Disconnect the negative battery cable.
2. Raise the vehicle on a vehicle hoist.
3. Drain the ATF into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.






- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Battery 2. Battery carrier 3. Resonance chamber 4. Fresh air duct 5. Air cleaner assembly 6. Ground and bracket 7. Solenoid body connector 8. Transaxle range switch connector 9. Vehicle speedometer sensor connector 10. Oil filler tube 11. Ignition coil 12. Ignition coil bracket 13. Fuel filter mounting nut 14. Emission harness protector nuts 15. No.1 engine mount nut 16. No.1 engine mount rubber 17. No.1 engine mount bracket 18. No.4 engine mount Removal Note page K2-42 19. Shift control cable 20. Wheel and tire | <ul style="list-style-type: none"> 21. Splash shield 22. Turbine speed sensor connector 23. Transverse member 24. Engine mounting member 25. Tie rod end Removal Note page K2-42 26. Stabilizer control link Removal Note page K2-42 27. Lower arm Removal Note page K2-42 28. Drive shaft 29. Joint shaft 30. Intake manifold bracket 31. Starter 32. Torque converter nut 33. No.5 engine mount 34. No.2 engine mount 35. Oil hose 36. Transaxle Removal Note page K2-43 |
|---|--|


**Removal Note****No.4 engine mount**

1. Support the engine by using the **SST** before removing the engine mounting member.
2. Remove the No.4 engine mount.


**Tie rod end****Caution**

- The sharp edges of the **SST** can slice the tie rod end dust boot. Install the **SST** so that the sharp edges are between the dust boot and the tie rod.

1. Remove the cotter pin and nut.
2. Disconnect the tie rod end from the knuckle by using the **SST**.


**Lower arm**

1. Remove the clinch bolt from the lower arm ball joint.


**Caution**

- Wrap a rag around the ball joint dust seal to protect it from damage.


2. Wrap a rag around the ball joint dust boot.
3. Pry the lower arm out of the knuckle.

**Drive shaft**

1. Remove the clip.
2. Remove the ABS wheel speed sensor harness mounting nuts.



3. Separate the drive shaft (right side) from the joint shaft by using a brass bar and a hammer.




Caution

- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when removing the drive shaft from the transaxle.

Note


- Do not pry on the seal surface.

4. Separate the left side drive shaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle, as shown in the figure.
5. Suspend the drive shaft with a rope.



Transaxle

1. Loosen the **SST** (engine support) and lean the engine toward the transaxle.



2. Support the transaxle on a jack.
3. Remove the transaxle mounting bolts.
4. Remove the transaxle.

2/4 BAND SERVO (ON-VEHICLE REMOVAL / INSPECTION / INSTALLATION)**Preparation
SST**

| | | | | | |
|--|--|--|---|--|--|
| 49 UN01 104 Servo cover remover/ replacer | | For installation of 2/4 servo piston | 49 UN01 105 Servo piston rod selector | | For installation of 2/4 servo piston |
|--|--|--|---|--|--|

Caution


- Servicing the 2/4 band servo in the vehicle is only recommended in the event of a leak. If servicing is required due to a servo problem, it is necessary to remove and disassemble the transaxle to inspect the 2/4 band assembly and direct clutch for damage.

On-vehicle Removal


1. Raise and support the vehicle.
2. Remove the splash shield.

Warning

- The servo cover is under high spring pressure.



3. Install a nut with an integral washer onto the forcing bolt of the servo cover remover/replacer tool with a permanent thread sealer. This nut and washer will aid in the installation of the cover.



4. Install the **SST** and compress the servo cover assembly.
5. Remove the servo cover retaining ring and release the tension on the servo cover assembly slowly.
6. After releasing all of the tension on the servo cover assembly, remove the **SST**.
7. Remove the servo cover assembly, 2/4 servo piston and return spring.

Inspection

Inspect the 2/4 servo piston and servo cover assembly for nicks or cuts and replace if necessary.

On-vehicle Installation

1. Lubricate the 2/4 servo piston, servo cover, servo cover seal, and servo case bore using ATF or petroleum jelly to aid in the installation and prevent cutting of the seal.
2. Install the 2/4 servo piston and return spring into the transaxle case.

3. Install the **SST**.
4. Tighten the center screw to compress the 2/4 servo into the bore.

Note


- If the cover will not seat deep enough in the bore to install the servo cover retaining ring, a blunt punch may be used with a small hammer. Gently tap the cover around the outer edge with the punch until the snap ring groove is fully exposed.

5. Install the servo cover retaining ring into transaxle case.
6. Remove the **SST**.
7. Lower the vehicle. Check the fluid level prior to road testing.



CONTROL VALVE BODY AND THERMOSTATIC OIL LEVEL CONTROL VALVE (ON-VEHICLE REMOVAL / INSTALLATION)

Preparation

SST



On-vehicle Removal



Caution


- Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents before removal.

1. Remove the following items. (Refer to page K2-39.)
 - Battery
 - Battery carrier
 - Fresh air duct
 - Resonance chamber
2. Disconnect the TR switch connector.
3. Disconnect the solenoid body connector.
4. Drain the ATF.
5. Remove the splash shield.
6. Remove the oil cooler hose.
7. Remove the control valve body cover.
8. Remove the control valve body mounting bolts.

Caution

- Do not pull on the connector wires or use a hammer on the connector.

9. Remove the control valve body assembly.



- If the thermostatic oil level control valve must be removed, remove the bolt and the bracket. Pull the thermostatic oil level control valve straight out of the transaxle case.

On-vehicle Installation

- If the thermostatic oil level control valve was removed, insert it into the transaxle case and install the bracket and bolt.

Tightening torque:

11—13 N·m {112—133 kgf·cm, 96—117 in·lbf}

- Install a new O-ring on the solenoid electrical connector and lightly coat the O-ring with petroleum jelly.


Caution

- Do not pull wires or damage connector body.



- Place the control valve body slightly away from the transaxle case and push the solenoid body connector into its bore.
- Align the Z-link in the manual valve.
- Install the 12 mounting bolts. Tighten the mounting bolts in the sequence shown.

Tightening torque:


9—11 N·m {92—112 kgf·cm, 80—97 in·lbf}




- Loosen the nut on the ball stud for the manual valve detent actuating rod.
- Remove the manual lever control shaft outer lever.
- Use the **SST** to move the shaft to the D range position and install the pin to hold the tool in position.



- Move the manual valve detent lever to the D range position.



10. Loosen the nut on the ball stud for the manual valve detent lever actuating rod assembly.
11. Initially tighten the nut on the ball. Remove the shifter pin.



12. Rotate the **SST** until the socket can be installed on the nut. Tighten the manual valve detent lever ball stud nut.

Tightening torque:


11—13 N·m {112—133 kgf·cm, 96—117 in·lbf}

13. Remove the pin and **SST**.
14. Install the manual control lever assembly and bolt.

Tightening torque:

24—30 N·m {2.4—3.1 kgf·m, 18—22 ft·lbf}

15. Install the control valve body cover gasket on the case. Attach the cover to the case.
16. Install the fourteen mounting bolts in the sequence shown.



Tightening torque:

14—18 N·m {143—184 kgf·cm, 127—138 in·lbf}

Caution





- If reusing the hose clamp, position it in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a tight fit.

17. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated.
18. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
19. Verify that the hose clamp does not interfere with any other parts.
20. Slide the radiator hose onto the radiator pipe until it is fully seated.
21. Install the hose clamp on the hose.
22. Squeeze it lightly with large pliers to ensure a good fit.
23. Connect the TR switch connector.
24. Connect the solenoid body connector.
25. Install the following items. (Refer to page K2-55.)
 - Battery
 - Battery carrier
 - Fresh air duct
 - Resonance chamber
26. Fill the transaxle with the specified ATF. (Refer to page K2-22.)
27. Check for leakage of ATF from the oil pan or the oil hose connecting points. (Refer to page K2-22.)
28. Carry out the mechanical system test. (Refer to page K2-10.)
29. Carry out the road test. (Refer to page K2-15.)

DIFFERENTIAL OIL SEALS (ON-VEHICLE REMOVAL / INSTALLATION)



Preparation

SST

| | | | |
|--|----------------------------|---|---------------------------------|
| <p>49 UN01 087</p> <p>Converter seal remover</p>  | <p>For removal of seal</p> | <p>49 0223 630B</p> <p>Axle shaft puller</p>  | <p>For removal of seal</p> |
| <p>49 UN11 101</p> <p>Threaded adapter</p>  | <p>For removal of seal</p> | <p>49 UN01 129</p> <p>Seal replacer</p>  | <p>For installation of seal</p> |

On-vehicle Removal

1. Raise and support the vehicle on safety stands.
2. Remove the front wheels.
3. Drain the ATF.
4. Remove the drive shaft and joint shaft.
(Refer to section M.)
5. Remove the differential seals using the **SSTs** or equivalent.







On-vehicle installation

1. Apply a thin coat of petroleum jelly on the outer diameter and the lip of the new differential seals.
2. Use the **SST** to tap in the differential seals.
3. Install the drive shaft and joint shaft.
(Refer to section M.)
4. Install the front wheels.
5. Refill the ATF.

ATF LEAK FROM OIL PUMP BODY SEAL

Preparation

SST

| | | | |
|--|--------------------------------|--|--------------------------------|
| <p>49 UN01 100</p>  <p>Oil pump removal bolts</p> | <p>For removal of oil pump</p> | <p>49 UN11 101</p> <p>Threaded adapter</p>  | <p>For removal of oil pump</p> |
| <p>49 0223 630B</p>  <p>Axle shaft puller</p> | <p>For removal of oil pump</p> | <p>49 8501 631A</p> <p>Adapter</p>  | <p>For removal of oil pump</p> |

Issue


Some vehicles may leak fluid from the pump-to-case interface area of the transaxle. This may be caused by the pump body seal being rolled or pinched during installation.

Action

If a fluid leak is detected in the pump-to-case interface area, refer to the following service procedure to replace the pump body seal.


Caution

- **This procedure does not require complete teardown of the transaxle and should only be used for leak concerns. If replacement of the pump body or pump support is required, the transaxle must be disassembled and reassembled. The components will be misaligned if this repair is performed while the transaxle is still in the vehicle.**




Procedure


1. Remove the transaxle from the vehicle.
(Refer to page K2-39.)
2. Remove the torque converter from the transaxle and drain.
3. Remove the transaxle drain plug from the transaxle case. Allow the transaxle to drain completely.




4. Remove the pump drive shaft.




5. Position the transaxle with the pump facing up and remove the TSS sensor mounting bolt.




6. Separate the TSS sensor from the pump.




7. Remove the nine (9) pump mounting bolts.




8. Install the **SSTs** on the pump.




9. Install a large screwdriver through the TSS sensor hole. Do not locate the screwdriver on the reverse clutch hub tabs.
10. Remove the pump while holding the components into the case with the screwdriver. Remove the #1 thrust bearing. This bearing may be attached to the pump support or on the reverse clutch hub.




11. Remove the pump support mounting bolts.




12. Remove the pump support.




13. Remove the pump-to-case gasket and separator plate and discard the gasket.




14. Remove the pump seal and discard.




15. Install the **SST** in the holes. Use the bolt hole next to the TSS sensor hole and the bolt hole opposite it for the **SST**.



16. Install the separator plate and new gasket.




17. Install the pump support.




18. Install four (4) mounting bolts and tighten the bolts to 13 N·m (10 lb·ft).

19. Remove the **SST** and install and torque the remaining two (2) bolts to 13 N·m (10 lb·ft).




20. Install the new pump seal. Ensure that the white stripe is visible all around the pump.


21. Visually inspect the case flange for damage or burrs.




22. Lubricate the #1 thrust bearing with petroleum jelly and install on the pump support.




- 23. Lubricate the pump support seals and the pump bore in the case.
- 24. Lower the pump assembly into the case.



- 25. Install the nine (9) pump mounting bolts and torque to 13 N·m (10 lb·ft).



- 26. Install the TSS sensor and mounting bolt and tighten to 14 N·m (10 lb·ft).







- 27. Install the pump drive shaft.
- 28. Install the torque converter into the transaxle.
- 29. Reinstall the transaxle into the vehicle.
(Refer to page K2-55.)

MEMO


TRANSAXLE UNIT (INSTALLATION)


**Preparation
SST**

| | | | |
|---|----------------------------------|---|----------------------------------|
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |


Installation

1. Install in the order shown in the figure, referring to **Installation Note**.
2. Fill the transaxle with the specified ATF after installation. (Refer to page K2-22.)
3. Check for leakage of ATF from all connecting points. (Refer to page K2-22.)
4. Carry out the mechanical system test. (Refer to page K2-10.)
5. Carry out the road test. (Refer to page K2-15.)





- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Transaxle Installation Note page K2-58 2. No.2 engine mount 3. Torque converter nut 4. Starter 5. Intake manifold bracket 6. No.1 engine mount bracket 7. No.1 engine mount rubber 8. No.1 engine mount nut 9. Emission harness protector nuts 10. Shift control cable 11. No.4 engine mount 12. Drive shaft Service section M 13. Joint shaft Service section M 14. Lower arm Installation Note page K2-58 15. Stabilizer control link 16. Tie rod end Installation Note page K2-59 17. No.5 engine mount | <ul style="list-style-type: none"> 18. Vehicle speedometer sensor connector 19. Engine mounting member Installation Note page K2-59 20. Transverse member 21. Turbine speed sensor connector 22. Splash shield 23. Oil hose Installation Note page K2-60 24. Wheel and tire 25. Oil filler tube 26. Ground and bracket 27. Fuel filter mounting nut 28. Ignition coil bracket 29. Ignition coil 30. Transaxle range switch connector 31. Solenoid body connector 32. Air cleaner 33. Fresh air duct 34. Resonance chamber 35. Battery carrier 36. Battery |
|---|--|



Installation Note Transaxle

Warning

- Do not allow the transaxle to fall from the jack.

1. Set the transaxle on a jack and lift it into place.

2. Install the transaxle mounting bolts.

Tightening torque

Ⓐ: 90—116 N·m {9.1—11.9 kgf·m, 66—86 ft·lbf}

Ⓑ: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



Ⓒ: 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}

3. Install the torque converter nuts.

Tightening torque:

28—46 N·m {2.8—4.7 kgf·m, 21—33 ft·lbf}

4. Handly tighten the No.4 engine mount nuts.



Lower arm

1. Connect the lower arm to the knuckle and tighten the clinch bolt.

Tightening torque:


37—53 N·m {3.7—5.5 kgf·m, 27—39 ft·lbf}


2. Install the ABS wheel speed sensor harness mounting nuts.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 69.5—95.4 in·lbf}

3. Install the clip.






Tie rod end

1. Install the locknut.

Tightening torque:

32—44 N·m {3.2—4.5 kgf·m, 24—32 ft·lbf}

2. Secure the locknut by using a new cotter pin.



Engine mounting member

Note


- Verify that the engine mount rubbers are installed as shown.
- Put the No.2 engine mount stud bolts in the installing holes when installing the engine mounting member.

1. Install the bolts and nuts (A) as shown.

Tightening torque

A: 67—93 N·m {6.8—9.5 kgf·m, 50—68 ft·lbf}

2. Handly tighten the nuts (B) and (C) as shown.




3. Tighten the No.4 engine mount nuts and bolts.

Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}

4. Remove the SST (engine support).





5. Tighten the nuts (B) and (C) as shown.

Tightening torque

B: 75—104 N·m {7.6—10.7 kgf·m, 55.0—77.3 ft·lbf}

C: 44—60 N·m {4.4—6.2 kgf·m, 32—44 ft·lbf}






Oil hose

Caution

- If reusing the hose clamp, position it in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a tight fit.




1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.

OIL COOLER

OIL COOLER

Removal / Inspection / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add ATF to the specified level.
5. Connect the negative battery cable.
6. Inspect for oil leakage from the oil pipes and oil hoses.
7. Inspect the ATF level and condition. (Refer to page K2-22.)



1. Connector bolts

2. Washers


3. Oil hose

Installation Note page K2-62

4. Oil pipe

5. Radiator


Service section E1



Installation Note Oil hose

Caution





- If reusing the hose clamp, position it in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a tight fit.



1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.


DRIVE PLATE

PREPARATION
SST


| | | | |
|---|--------------------------------|--|--------------------------------|
| <p>49 E011 1A0 Brake set, ring gear</p>  | <p>For holding drive plate</p> | <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For holding drive plate</p> |

DRIVE PLATE
Removal / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



- | | | |
|-------------------------------|------------|------------------|
| 1. Drive plate mounting bolts | | 2. Backing plate |
| Removal Note | page K2-64 | 3. Drive plate |
| Installation Note | page K2-64 | 4. Adapter |

**Removal Note****Drive plate mounting bolts**

1. Set the **SST** or equivalent against the drive plate.
2. Remove the bolts and the drive plate.

**Installation Note****Drive plate mounting bolts**

1. Remove any old locking compound from the bolt threads and bolt holes, and apply new locking compound to the bolt threads.
2. Set the **SST** or equivalent against the drive plate.
3. Tighten the drive plate mounting bolts in two or three steps in the order shown.

Tightening torque:


97—102 N·m {9.8—10.5 kgf·m, 70.9—75.9 ft·lbf}

SHIFT MECHANISM

SELECTOR LEVER



Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the shift-lock, emergency override button, and key interlock operations.



1. Steering column cover
2. Front console
3. Side wall
4. Indicator panel
Service section K1
5. Clip

6. Selector lever
Installation Note page K2-66
7. Insulator
8. Clip
9. Selector cable
10. Interlock cable

**Installation Note****Selector lever**

1. Install the selector lever.

Tightening torque:

16—22 N·m {1.6—2.3 kgf·m, 12—16 ft·lbf}

2. Verify the transaxle is in D range.
3. Install the selector cable to the selector lever.
4. Push the selector lever into the D range.
5. Connect the set button.
6. Slide the lock cover and lock the set button.
7. Install the interlock cable to the selector lever.

Tightening torque:

9.8—14.7 N·m {100—150 kgf·cm, 87—130 in·lbf}

TROUBLESHOOTING GUIDE

GENERAL NOTES

A problem with the EC-AT may be caused by the engine, the EC-AT powertrain, the hydraulic control system, or the electronic control system; therefore, when troubleshooting begin with those points which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.

Caution


- Be aware that this section deals with the engine control module. It is interconnected for the FS engine.

Preliminary Inspection

- Know and understand the customer's concern.
- Verify the concern by operating the vehicle.
- Check the ATF level and condition.
- Check for NON-factory add-on items.
- Check shift linkages for proper adjustment.
- Check the Service Bulletins for the concern.


Step 1: On-Boad Diagnostic System Inspection

Check for diagnostic trouble code(s) memorized in the powertrain control module with the New Generation Star (NGS) Tester. (Refer to page K2-117.)



Step 3: Mechanical System Test

Check the engine stall speed and line pressure. (Refer to page K2-10.)



Step 4: Road Test

Check the shift point, shift schedule, and shift shock. (Refer to page K2-15.)

QUICK DIAGNOSIS CHART

OUTLINE

The QUICK DIAGNOSIS CHART shows various problems and the various components that might be the cause of the problem.

1. Components indicated in the "On-board diagnostic" line of the QUICK DIAGNOSIS CHART (I) are diagnosed by the powertrain control module on-board diagnostic function. NGS can be used for easy retrieval of the diagnostic trouble code numbers.
2. Components indicated in the "Adjustment" line of the QUICK DIAGNOSIS CHART (I) indicate that there is a possibility that the problem may be the result of an incorrect adjustment. Check the adjustment of each component, and readjust if necessary.
3. Input and output signals of the powertrain control module for the components indicated in the NGS line of the QUICK DIAGNOSIS CHART (I) can be easily checked by using the NGS.
4. Components indicated in the "Line Pressure Test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the line pressure test.
5. Components indicated in the "Stall Test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the stall test.
6. Components indicated in the "Road Test" line of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the road test.
7. QUICK DIAGNOSIS CHART (II) shows the relationship between the troubleshooting item and inspection point.

QUICK DIAGNOSIS CHART (I)

| Possible parts and reference page | Preliminary | | | | Emission control system | | | | | | | EC-AT control system | | | | | | | Hydraulic control system | | | | | | | | | | | | |
|-----------------------------------|-------------------------|----------------|------------|--------------------|-------------------------|---------------------------|----------------------------|----------------------|--------------------------|-----------------------------------|-----------------|------------------------------------|------------------------|--------------|----------------------------|----------------------------|----------------|------------------|--------------------------|--------------------------------------|----------------------------------|-------------------------------------|----------|--------------------|--------------------------------------|------------------|---------------------|------------|-----------|--|--|
| | ATF level and condition | Selector lever | Stall test | Line pressure test | Road test | Powertrain control module | Electronic ignition system | Mass air flow sensor | Throttle position sensor | Engine coolant temperature sensor | Magnetic clutch | Transaxle fluid temperature sensor | Transaxle range switch | Brake switch | Vehicle speedometer sensor | Turbine shaft speed sensor | O/D OFF switch | Shift solenoid 1 | Shift solenoid 2 | Electronic pressure control solenoid | Torque converter clutch solenoid | 3-2 timing/coasting clutch solenoid | Oil pump | Control valve body | Thermostatic oil level control valve | Torque converter | Oil filter and seal | Oil cooler | Chain pan | | |
| Item | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| On-Board Diagnostic | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Adjustment | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Testers | NGS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Transaxle tester | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Breakout box | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Stall test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Line pressure test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Road test | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

QUICK DIAGNOSIS CHART (I)

| Powertrain | | | | | | | | | | Exteria | Other | Possible parts and reference page | | | | | | | | | | | | |
|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|---|-----------------------|----------------------------|------------------------|-----------------------|-----------------------------------|--------------------------|--------------------------|-----------------------------------|-----------------------|-----------------------|------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|---------------------|
| Forward clutch | Coasting clutch | Direct clutch | Reverse clutch | 2/4 band and servo | Low/reverse clutch | Chain and sprocket | Forward/coasting/direct clutch cylinder | REV/4GR carrier | REV/4GR sun gear and shell | Forward one-way clutch | Low one-way clutch | | Converter one-way clutch | Low-intermediate carrier | Planetary gearsets (Differential) | Parking mechanism | Turbine shaft | Final drive and differential | Transaxle case | Converter housing | Joint shaft | Engine mount | Drive plate | Tire size |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | On-Board Diagnostic |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Adjustment |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | NGS |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Transaxle tester |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Breakout box |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Stall test |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Line pressure test |
| <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Road test |

QUICK DIAGNOSIS CHART (II)

| Item | Possible parts and reference page | Preliminary | | | | Emission control system | | | Electronic system | | | | | | | Hydraulic control system | | | | | | | | | | | | | | | | |
|------|---|---|-----------------------|-----------------------|-----------------------|-------------------------|---------------------------|----------------------------|----------------------|--------------------------|-----------------------------------|------------------------------------|------------------------|--------------|----------------------------|----------------------------|----------------|-----------------------|------------------|--------------------------------------|----------------------------------|-------------------------------------|----------|--------------------|--------------------------------------|------------------|---------------------|------------|-----------|--|--|--|
| | | ATF level and condition | Selector lever | Stall test | Line pressure test | Road test | Powertrain control module | Electronic ignition system | Mass air flow sensor | Throttle position sensor | Engine coolant temperature sensor | Transaxle fluid temperature sensor | Transaxle range switch | Brake switch | Vehicle speedometer sensor | Turbine shaft speed sensor | O/D OFF switch | Shift solenoid 1 | Shift solenoid 2 | Electronic pressure control solenoid | Torque converter clutch solenoid | 3-2 timing/coasting clutch solenoid | Oil pump | Control valve body | Thermostatic oil level control valve | Torque converter | Oil filter and seal | Oil cooler | Chain pan | | | |
| 1 | No forward engagement only | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | No reverse engagement only | | <input type="radio"/> | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | | | |
| 3 | Harsh engagement | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | <input type="radio"/> | | | | | | | | <input type="radio"/> | | | | | | | | | | | | |
| 4 | Delayed/soft engagement | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | No forward and no reverse engagements | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Some or all shift missing | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Shift concern | Timing-early/late | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | | Erratic | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | | Feel-soft/slipping | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | | Feel harsh | | <input type="radio"/> | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | | No first gear engages in higher gear ("D" range) | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | | No first gear in "1" range (First gear in "D" range O.K.) | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | | No 1-2 shift | | | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | | No 2-3 shift | | | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | | No 3-4 shift | | | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | | Soft/slipping 1-2 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | | Soft/slipping 2-3 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 18 | | Soft/slipping 3-4 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 19 | | Soft/slipping 4-3 shift (Automatic) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20 | | Soft/slipping 3-2 shift (Automatic) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 21 | | Soft/slipping 2-1 shift (Automatic or kickdown) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 22 | | Harsh 1-2 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 23 | | Harsh 2-3 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 24 | | Harsh 3-4 shift | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | | Harsh 4-3 shift (Automatic) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 26 | | Harsh 3-2 shift (Automatic) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 27 | Torque converter clutch | No apply | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 28 | | Always applied/may stall engine | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 29 | Poor vehicle acceleration/performance | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | Engine will not crank | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | No "P" position | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 32 | Transaxle overheating | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 33 | No engine braking in first gear ("1" range) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 34 | No engine braking in "D" range (O/D OFF sw ON) | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35 | Vehicle movement with gear selector in the "N" position | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 36 | Shift efforts high | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 37 | External leaks | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 38 | Noise/vibration—forward/reverse | | <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

QUICK DIAGNOSIS CHART (II)

| Powertrain | | | | | | | | | | Exteria | Other | Possible parts and reference page | | | | | | | | | | | | | | | |
|-----------------------|-----------------------|-----------------------|-----------------------|--------------------|-----------------------|-----------------------|---|--------------------------|----------------------------|------------------------|-----------------------|-----------------------------------|-----------------------------------|---------------------------------|-----------------------|-----------------------|------------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|---|---|----|
| Forward clutch | Coasting clutch | Direct clutch | Reverse clutch | 2/4 band and servo | Low/reverse clutch | Chain and sprocket | Forward/coasting/direct clutch cylinder | REV/4GR carrier assembly | REV/4GR sun gear and shell | Forward one-way clutch | Low one-way clutch | Converter one-way clutch | Low-intermediate carrier assembly | Planetary gearsets differential | Parking mechanism | Turbine shaft | Final drive and differential | Transaxle case | Converter housing | Joint shaft | Engine mount | Drive plate | Tire size | | | | |
| <input type="radio"/> | <input type="radio"/> | | | | | | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | | | | | <input type="radio"/> | | | <input type="radio"/> | <input type="radio"/> | | | No forward engagement only | 1 | |
| | | | <input type="radio"/> | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | No reverse engagement | 2 | |
| <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | | <input type="radio"/> | | | | | | | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | Harsh engagement | 3 | |
| <input type="radio"/> | | | <input type="radio"/> | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | Delayed/soft engagement | 4 | |
| | | | | | | <input type="radio"/> | | | | | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | | | | <input type="radio"/> | | | | | No forward and no reverse engagements | 5 | |
| | | | | | | | | | | | | | | | | | | | | | | | | | Some or all shift missing | 6 | |
| | | | | | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | Shift concern | Timing-early/late | 7 |
| | | | | | | | | | | | | | | | | | | | | | | | | | | Erratic | 8 |
| | | | | | | | | | | | | | | | | | | | | | | | | | | Feel-soft/slipping | 9 |
| | | | | | | | | | | | | | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | Feel harsh | 10 |
| | | | <input type="radio"/> | | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | No first gear engages in higher gear ("D" range) | 11 |
| | | | | | | | | | | | | | | | | | | | | | | | | | | No first gear in "1" range (First gear in "D" range O.K.) | 12 |
| | | | | | | | | <input type="radio"/> | | <input type="radio"/> | | | | | | | | <input type="radio"/> | | | | | | | | No 1-2 shift | 13 |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | No 2-3 shift | 14 |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | No 3-4 shift | 15 |
| <input type="radio"/> | | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 1-2 shift | 16 |
| | | | | | | | | | | <input type="radio"/> | | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 2-3 shift | 17 |
| | | | | | | | | | | <input type="radio"/> | | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 3-4 shift | 18 |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 4-3 shift (Automatic) | 19 |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 3-2 shift (Automatic) | 20 |
| <input type="radio"/> | | | | | | | | | | | <input type="radio"/> | | | | | | | <input type="radio"/> | | | | | | | | Soft/slipping 2-1 shift (Automatic or kickdown) | 21 |
| <input type="radio"/> | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | Harsh 1-2 shift | 22 |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | Harsh 2-3 shift | 23 | |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | Harsh 3-4 shift | 24 | |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | Harsh 4-3 shift (Automatic) | 25 | |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | Harsh 3-2 shift (Automatic) | 26 | |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | Torque converter clutch | No apply | 27 |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | Always applied/may stall engine | 28 |
| | | | | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | | Poor vehicle acceleration/performance | 29 | |
| | | | | | | | | | | | | | | | | | | | | | | | | | Engine will not crank | 30 | |
| | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | | | | No "P" position | 31 | |
| | | | | | | | | | | | | | | | | | | <input type="radio"/> | <input type="radio"/> | | | | | | Transaxle overheating | 32 | |
| | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | No engine braking in first gear ("1" range) | 33 | |
| | <input type="radio"/> | | | | | | | | | <input type="radio"/> | | | | | | | | | | | | | | | No engine braking in "D" range (O/D OFF sw ON) | 34 | |
| <input type="radio"/> | <input type="radio"/> | | | | | | | | | | | | | | | | | | | | | | | | Vehicle movement with gear selector in the "N" position | 35 | |
| | | | | | | | | | | | | | | | <input type="radio"/> | | | | | | | | | | Shift efforts high | 36 | |
| | | | | | | | | | | | | | | | | | | | | | | | | | External leaks | 37 | |
| | | | | | | <input type="radio"/> | | <input type="radio"/> | | <input type="radio"/> | | | <input type="radio"/> | | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | Noise/vibration—forward/reverse | 38 | |


SYMPTOM TROUBLESHOOTING

USING THIS SECTION

Introduction

- Most of the automatic transaxle control system is electronically controlled, often making it difficult to diagnose problems in the system, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer is often a good source of information on such problems, especially intermittent ones. Through talks with the customer, one can find out what the symptoms are and under what conditions they occur.
- If the problem is related to any part of the automatic transaxle unit, repair or replace the automatic transaxle unit as necessary.

Work Flow



Diagnosis Index

No.:
Each troubleshooting item is assigned a number

Troubleshooting Item:
There are 38 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

| K2 SYMPTOM TROUBLESHOOTING | | |
|----------------------------|---|--------|
| DIAGNOSTIC INDEX | | |
| No. | TROUBLESHOOTING ITEM | PAGE |
| 1 | No forward engagement only | K2- 75 |
| 2 | No reverse engagement only (No movement) | K2- 75 |
| 3 | Hard engagement | K2- 74 |
| 4 | Delayed/lift engagement | K2- 74 |
| 5 | No forward and no reverse engagements (No vehicle movement) | K2- 76 |
| 6 | Clutch or all shift missing | K2- 79 |
| 7 | Timing-early/late | K2- 79 |
| 8 | Erratic | K2- 80 |
| 9 | Fast-slow/missing | K2- 81 |
| 10 | Feed-back | K2- 82 |
| 11 | No 1st gear engages in higher gear ("D" range) | K2- 84 |
| 12 | No 1st gear in "1" range (1st gear in "D" range O.K.) | K2- 85 |
| 13 | No 1-2 shift | K2- 86 |
| 14 | No 2-3 shift | K2- 87 |
| 15 | No 3-4 shift | K2- 88 |
| 16 | Shift concern | K2- 88 |
| 17 | Soft/Slipping 1-2 shift | K2- 89 |
| 18 | Soft/Slipping 2-3 shift | K2- 90 |
| 19 | Soft/Slipping 3-4 shift (Automatic) | K2- 91 |
| 20 | Soft/Slipping 3-2 shift (Automatic) | K2- 92 |
| 21 | Soft/Slipping 2-1 shift (Automatic or lockdown) | K2- 93 |
| 22 | Hard 1-2 shift | K2- 95 |
| 23 | Hard 2-3 shift | K2- 96 |
| 24 | Hard 3-4 shift | K2- 97 |
| 25 | Hard 4-3 shift (Automatic) | K2- 98 |
| 26 | Hard 3-2 shift (Automatic) | K2- 99 |
| 27 | Torque converter clutch | K2-100 |
| 28 | Always spinning/stall engine | K2-101 |
| 29 | Poor vehicle acceleration/performance | K2-102 |
| 30 | Engine will not crank | K2-103 |
| 31 | No "P" position | K2-104 |
| 32 | Transaxle overloading | K2-105 |
| 33 | No engine braking in 1st gear ("1" range) | K2-106 |
| 34 | No engine braking in "D" range (D OFF or ON) | K2-107 |
| 35 | Vehicle movement with gear selector in the "N" position | K2-108 |
| 36 | Shift effort high | K2-109 |
| 37 | External leaks | K2-110 |
| 38 | Noise/vibration-forward/reverse | K2-110 |

Page:
Shows the reference page

Troubleshooting chart

| | | | |
|---|--|-------------------------------------|---------------------|
| 1 | NO FORWARD ENGAGEMENT ONLY | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Internal or external shift linkages | | ⑤ Low one way clutch assembly | |
| ② Oil pump | | ⑥ Forward one way clutch assembly | |
| ③ Control valve body | | ⑦ Low intermediate carrier assembly | |
| ④ Forward clutch and coasting clutch assembly | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ⓘ page K2–58 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged or leaking • Pressure Tap Plate/Gasket leaking or damaged • Separator Plates damaged • Hydraulic Passages damaged • Main Regulator Valve stuck, damaged or misassembled • Forward Accumulator leaking | Yes | Service as required |
| | | No | Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to spec • Gaskets damaged or leaking • Porosity or leakage | Yes | Service as required |
| | | No | Go to next step |

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page shown by the “ⓘ” mark.


ACTION:

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page shown by ⓘ mark.

DIAGNOSTIC INDEX

| TROUBLESHOOTING ITEM | | PAGE | |
|----------------------|---|---|--------|
| No. | TROUBLE | | |
| 1 | No forward engagement only | K2- 75 | |
| 2 | No reverse engagement only (No movement) | K2- 76 | |
| 3 | Harsh engagement | K2- 78 | |
| 4 | Delayed/soft engagement | K2- 80 | |
| 5 | No forward and no reverse engagements (No vehicle movement) | K2- 82 | |
| 6 | Some or all shift missing | K2- 84 | |
| 7 | Shift concern | Timing-early/late | K2- 85 |
| 8 | | Erratic | K2- 86 |
| 9 | | Feel-soft/slipping | K2- 87 |
| 10 | | Feel harsh | K2- 88 |
| 11 | | No first gear engages in higher gear ("D" range) | K2- 90 |
| 12 | | No first gear in "1" range (First gear in "D" range O.K.) | K2- 91 |
| 13 | | No 1-2 shift | K2- 92 |
| 14 | | No 2-3 shift | K2- 93 |
| 15 | | No 3-4 shift | K2- 94 |
| 16 | | Soft/slipping 1-2 shift | K2- 95 |
| 17 | | Soft/slipping 2-3 shift | K2- 96 |
| 18 | | Soft/slipping 3-4 shift | K2- 97 |
| 19 | | Soft/slipping 4-3 shift (Automatic) | K2- 98 |
| 20 | | Soft/slipping 3-2 shift (Automatic) | K2- 99 |
| 21 | | Soft/slipping 2-1 shift (Automatic or kickdown) | K2-100 |
| 22 | | Harsh 1-2 shift | K2-101 |
| 23 | | Harsh 2-3 shift | K2-102 |
| 24 | | Harsh 3-4 shift | K2-103 |
| 25 | | Harsh 4-3 shift (Automatic) | K2-104 |
| 26 | | Harsh 3-2 shift (Automatic) | K2-105 |
| 27 | Torque converter clutch | No apply | K2-106 |
| 28 | | Always applied/may stall engine | K2-107 |
| 29 | Poor vehicle acceleration/performance | K2-108 | |
| 30 | Engine will not crank | K2-109 | |
| 31 | No "P" position | K2-110 | |
| 32 | Transaxle overheating | K2-111 | |
| 33 | No engine braking in first gear ("1" range) | K2-112 | |
| 34 | No engine braking in "D" range (O/D OFF sw ON) or "2" range | K2-113 | |
| 35 | Vehicle movement with gear selector in the "N" position | K2-114 | |
| 36 | Shift efforts high | K2-115 | |
| 37 | External leaks | K2-116 | |
| 38 | Noise/vibration—forward/reverse | K2-116 | |

SYMPTOM TROUBLESHOOTING CHART




| 1 | NO FORWARD ENGAGEMENT ONLY | | |
|--|--|--------|----------------------|
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Internal or external shift linkages ② Oil pump ③ Control valve body ④ Forward clutch and coasting clutch assembly</p> <p>⑤ Low one way clutch assembly ⑥ Forward one way clutch assembly ⑦ Low intermediate carrier assembly</p> | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Internal or External Shift Linkages – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Damaged • Misadjusted • Misassembled <p style="text-align: right;"> page K2–58</p> | Yes | Service as required |
| | | No | Go to next step |
| 2 | <p>Control Valve Body – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Bolts not torqued to specification • Gaskets damaged or leaking • Pressure Tap Plate/Gasket leaking or damaged • Separator Plates damaged • Hydraulic Passages damaged • Main Regulator Valve stuck, damaged, or misassembled • Forward Accumulator leaking | Yes | Service as required |
| | | No | Go to next step |
| 3 | <p>Oil Pump – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Bolts not torqued to spec • Gaskets damaged • Porosity/cross leaks and/or ball plug missing or leaking or a plugged hole • Pump support seal rings, #3 and #4 damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | <p>Forward Clutch and Coasting Clutch Assembly – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Seals or Pistons damaged • Return Spring damaged • Ball Check Valve damaged • Friction Elements severely damaged or worn • F/C/D Clutch Cylinder damaged, leaking, misassembled, or binding • Welding between Cylinder and Hub broken or Splines damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | <p>Low One Way Clutch Assembly – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Worn • Damaged • Misassembled | Yes | Service as required |
| | | No | Go to next step |
| 6 | <p>Forward One Way Clutch Assembly – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Worn • Damaged • Misassembled | Yes | Service as required |
| | | No | Go to next step |
| 7 | <p>Low Intermediate Carrier – Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Damaged • Misassembled | Yes | Service as required |
| | | No | The problem is fixed |

| 2 | NO REVERSE ENGAGEMENT (NO MOVEMENT) | | | | |
|---|---|-----|---|--|--|
| [TROUBLESHOOTING HINTS] | | | | | |
| <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> ① Powertrain control system ② Improper pressures ③ Internal or external shift linkages ④ Control valve body ⑤ Oil pump </td> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> ⑥ Reverse clutch assembly ⑦ Low/reverse clutch assembly ⑧ Forward/coasting/direct clutch cylinder assembly ⑨ Transaxle case ⑩ Reverse/fourth gear carrier assembly </td> </tr> </table> | | | | <ul style="list-style-type: none"> ① Powertrain control system ② Improper pressures ③ Internal or external shift linkages ④ Control valve body ⑤ Oil pump | <ul style="list-style-type: none"> ⑥ Reverse clutch assembly ⑦ Low/reverse clutch assembly ⑧ Forward/coasting/direct clutch cylinder assembly ⑨ Transaxle case ⑩ Reverse/fourth gear carrier assembly |
| <ul style="list-style-type: none"> ① Powertrain control system ② Improper pressures ③ Internal or external shift linkages ④ Control valve body ⑤ Oil pump | <ul style="list-style-type: none"> ⑥ Reverse clutch assembly ⑦ Low/reverse clutch assembly ⑧ Forward/coasting/direct clutch cylinder assembly ⑨ Transaxle case ⑩ Reverse/fourth gear carrier assembly | | | | |
| STEP | INSPECTION | | ACTION | | |
| 1 | Powertrain Control System – Are there any problems with the following? <ul style="list-style-type: none"> • Electrical Input/Output • Vehicle Wiring Harness • PCM • SS1 (ON) • TR Switch | Yes | Run OBD Tests Perform Pinpoint Tests “A and D” page K2–124, 130 | | |
| | | No | Go to next step | | |
| 2 | Improper Pressures – Is there low line pressure? page K2–10 | Yes | Check the following possible components Control Valve Body, Oil Pump, Reverse Clutch Assembly, Low/Reverse Clutch Assembly | | |
| | | No | Go to next step | | |
| 3 | Internal or External Shift Linkages – Do any of the following problems exist? <ul style="list-style-type: none"> • Damaged • Misadjusted page K2–65 | Yes | Service as required | | |
| | | No | Go to step 9 | | |
| 4 | Control Valve Body – Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Gasket damaged • 1–2 Shift Valve, SS1, Main Regulator Valve, Low/Reverse Modulator Valve, Low/Reverse Accumulator Piston, Pressure Tap Plate damaged, missing, stuck, misassembled • Separator Plates damaged • Hydraulic Passages damaged | Yes | Service as required | | |
| | | No | Go to next step | | |
| 5 | Oil Pump – Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Gasket damaged • Porosity/cross leaks/ball plug missing or leaking, plugged hole • Pump Support Seal Rings, #6 and #7, damaged | Yes | Service as required | | |
| | | No | Go to next step | | |
| 6 | Reverse Clutch Assembly – Do any of the following problems exist? <ul style="list-style-type: none"> • Seals-Piston damaged • Ball Check Valve damaged • Friction Elements worn, severely damaged, or misassembled • Piston Return Spring damaged • Reverse Clutch Hub to F/C/D clutch Hub Splines damaged | Yes | Service as required | | |
| | | No | Go to next step | | |
| 7 | Low/Reverse Clutch Assembly – Do any of the following problems exist? <ul style="list-style-type: none"> • Seals or Piston damaged • Friction Elements worn or severely damaged • Piston Return Spring damaged • Wave Spring missing • Piston Bore damaged | Yes | Service as required | | |
| | | No | Go to step 3 | | |
| 8 | Forward/Coasting/Direct Clutch Cylinder – Are any of the reverse seal rings damaged, missing, or misassembled? | Yes | Service as required | | |
| | | No | Go to next step | | |

| STEP | INSPECTION | | ACTION |
|-------------|---|-----|----------------------|
| 9 | Reverse/fourth Carrier Assembly – Is there any damage? | Yes | Service as required |
| | | No | Go to next step |
| 10 | Transaxle Case – Is there any severe cross leakage from the reverse clutch to low/reverse clutch feeds? | Yes | Service as required |
| | | No | The problem is fixed |


| 3 HARSH ENGAGEMENT | | | |
|--|--|--------|--|
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① ATF ② Powertrain control system ③ Improper pressure ④ Control valve body ⑤ Oil filter and seal ⑥ Internal and external linkages | <ul style="list-style-type: none"> ⑦ Joint shafts ⑧ Engine mounts ⑨ Forward clutch assembly (Forward only) ⑩ Reverse clutch assembly (Reverse only) ⑪ Low/reverse clutch assembly (Reverse only) ⑫ Direct clutch assembly (Reverse only) | | |
| STEP | INSPECTION | ACTION | |
| 1 | ATF – Are there any problems with the following? <ul style="list-style-type: none"> • Level • Condition 📖 page K2–22 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Powertrain Control System – Are there any problems with the following? <ul style="list-style-type: none"> • Electrical Input/Output • Vehicle Wiring Harness • PCM • EPC Solenoid • TFT Sensor • 3–2 T/CCS (Harsh forward only) 📖 page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “B and E” 📖 page K2–126, 133 |
| | | No | Go to next step |
| 3 | Improper Pressure – Is line pressure higher than normal? 📖 page K2–10 | Yes | Verify engagements at minimum EPC using the Transaxle Tester If line remains high, check the following components: Control valve body, Oil Filter and Seal assembly |
| | | No | Go to next step |
| 4 | Control Valve Body – Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Gaskets damaged • Low/Reverse Accumulator Piston and Spring (Reverse), Main Regulator Valve, Coast Clutch Valve (Forward) • Accumulator Piston and Spring misassembled, stuck or damaged • EPC Solenoid stuck or damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Oil Filter and Seal Assembly – Do any of the following problems exist? <ul style="list-style-type: none"> • Filter/Seal damaged, plugged • Recirculation Seal damaged, plugged, or out of position | Yes | Replace as required |
| | | No | Go to next step |
| 6 | Internal or External Shift Linkages – Do any of the following problems exist? <ul style="list-style-type: none"> • Damaged • Misadjusted 📖 page K2–65 | Yes | Service as required |
| | | No | Go to next step |
| 7 | Joint Shafts – Is there spline damage? 📖 page K2–39 | Yes | Service as required |
| | | No | Go to next step |
| 8 | Engine Mounts – Do any of the following problems exist? <ul style="list-style-type: none"> • Loose, broken, missing or misaligned • Powertrain contacting with other vehicle components 📖 page K2–39 | Yes | Service as required |
| | | No | Go to next step |

| STEP | INSPECTION | | ACTION |
|------|--|-----|----------------------|
| 9 | F/C/D Clutch Assembly (Forward Only) – Do any of the following problems exist? • F/C/D Clutch Cylinder damaged • Piston Bore damaged • Friction Elements damaged worn • Forward Clutch Return Spring damaged or missing • Ball Check damaged • Piston or Seals damaged | Yes | Service as required |
| | | No | Go to next step |
| 10 | Reverse Clutch Assembly (Reverse Only) – Do any of the following problems exist? • Seals or Piston damaged • Reverse Piston damaged • Friction Elements damaged, worn, misassembled • Return Spring Assembly damaged, worn • Ball Check damaged, missing | Yes | Service as required |
| | | No | Go to next step |
| 11 | Low/Reverse Clutch Assembly (Reverse Only) – Do any of the following problems exist? • Seals or Piston damaged • Wave Spring damaged • Friction Elements damaged, worn, misassembled • Return Spring Assembly damaged, worn, or misassembled • Piston Bore damaged | Yes | Service as required |
| | | No | Go to next step |
| 12 | Direct Clutch Assembly (Reverse Only) – Are any of the friction elements severely damaged? | Yes | Service as required |
| | | No | The problem is fixed |




| 4 DELAYED/SOFT ENGAGEMENT | | |
|--|---|---|
| [TROUBLESHOOTING HINTS] | | |
| ① ATF ② Improper pressure ③ Internal or external shift linkages ④ Control valve body ⑤ Oil filter and seal assembly ⑥ Oil pump ⑦ Forward clutch assembly ⑧ Reverse clutch assembly ⑨ Low/reverse clutch assembly ⑩ Forward/coasting/direct clutch cylinder assembly | | |
| STEP | INSPECTION | ACTION |
| 1 | ATF – Are there any problems with the following? • Level • Condition  page K2–22 | Yes Service as required |
| | | No Go to next step |
| 2 | Improper Pressure – Is line pressure lower than normal?  page K2–10 | Yes Check the following possible components; Control valve body, oil pump, oil filter and seal assembly, recirculating seal, clutch assemblies |
| | | No Go to next step |
| 3 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled  page K2–65 | Yes Service as required |
| | | No The problem is fixed |
| 4 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Manual Valve, Main Regulator Valve, Low/Reverse Modulator Regulator Valve stuck, damaged, or misassembled • Separator Plates damaged • Pressure Tap Plate/Gasket leaks, damaged, misassembled | Yes Service as required |
| | | No Go to next step |
| 5 | Oil Filter and Seal Assembly – Do any of the following problems exist? • Filter/Seal damaged, plugged • Recirculating Seal damaged or out of position | Yes Service as required |
| | | No Go to next step |
| 6 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Porosity/cross leaks/ball plug missing or leaking, or passage blockage • Pump Support Seal Rings, #3 and #4 (Forward), or #6 and #7 (Reverse), damaged • Pump Gear/Pocket damaged • Separator Plate damaged | Yes Service as required |
| | | No Go to next step |
| 7 | Forward Clutch Assembly (Forward Only) – Do any of the following problems exist? • Seals or Piston damaged • Ball Check damaged, missing, or not seating properly • Friction Elements damaged, worn, or excessive end clearance | Yes Service as required |
| | | No Go to next step |
| 8 | Reverse Clutch Assembly (Reverse Only) – Do any of the following problems exist? • Seals or Piston damaged • Check Ball damaged • Friction Elements damaged, worn • Return Spring worn, damaged • Piston Bore damaged • Excessive Clutch Pack End Clearance | Yes Service as required |
| | | No Go to next step |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---------------------|
| 9 | Low/Reverse Clutch Assembly (Reverse Only) – Do any of the following problems exist? • Piston or Seals damaged • Friction Elements damaged, worn • Return Spring damaged • Piston Bore damaged • Excessive Clutch Pack End Clearance | Yes | Service as required |
| | | No | Go to next step |
| 10 | Forward/Coasting/Direct Clutch Cylinder Assembly – Do any of the following problems exist? • Reverse Seal Ring damaged or missing • Cylinder damaged or leaking | Yes | Service as required |
| | | No | Go to step 3 |

| 5 NO FORWARD AND NO REVERSE ENGAGEMENTS (NO VEHICLE MOVEMENT) | | | |
|--|--|---|--|
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① ATF ② Improper pressure ③ Internal or external linkages ④ Control valve body ⑤ Oil filter and seal assembly ⑥ Oil pump ⑦ Drive plate | | <ul style="list-style-type: none"> ⑧ Turbine shaft to forward/coasting/direct clutch cylinder ⑨ Torque converter ⑩ Chain and sprocket assembly ⑪ Park mechanism ⑫ Joint shafts ⑬ Final drive and differential assembly ⑭ Planetary gearsets (Differential) | |
| STEP | INSPECTION | | ACTION |
| 1 | ATF – Are there any problems with the following? • Level • Condition 📖 page K2–22 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Improper Pressures – Do any of the following problems exist? • Low Line Pressure • No Line Pressure 📖 page K2–10 | Yes | If pressure is low, check the following possible components: Control Valve Body, Oil Filter and Seal Assembly, Oil Pump Go to step 4 If OK, proceed to Turbine Shaft Check Torque Converter Pump Shaft and Assembly Go to step 7 |
| | | No | Go to next step |
| 3 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled 📖 page K2–65 | Yes | Service as required |
| | | No | Go to step 10 |
| 4 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Pressure Plate/Gasket damaged or missing • Main Regulator Valve, Manual Valve stuck, damaged, plugged, missing, “Z” Link not connected | Yes | Service as required |
| | | No | Go to next step |
| 5 | Oil Filter and Seal Assembly – Do any of the following problems exist? • Filter/Seal damaged, plugged, or missing • Recirculating Seal damaged or out of position | Yes | Service as required |
| | | No | Go to next step |
| 6 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to spec • Gasket damaged, missing • Porosity/cross leaks or passage(s) blocked • Pump Support Seal Rings missing • Oil Pump Shaft broken, damaged | Yes | Service as required |
| | | No | Go to step 3 |
| 7 | Drive plate – Do any of the following problems exist? • Damaged • Broken 📖 page K2–63 | Yes | Service as required |
| | | No | Go to next step |
| 8 | Turbine Shaft to Forward/Coasting/Direct Clutch Cylinder Housing – Is there Splines damaged? | Yes | Service as required |
| | | No | Go to next step |
| 9 | Torque Converter Assembly – Do any of the following problems exist? • Oil Pump Shaft Insert damaged • Studs broken or damaged • Splines damaged • Internal Blades damaged, broken | Yes | Service as required |
| | | No | Go to step 3 |

| STEP | INSPECTION | | ACTION |
|------|--|-----|----------------------|
| 10 | Chain and Sprocket Assembly – Do any of the following problems exist? • Broken • Damaged | Yes | Service as required |
| | | No | Go to next step |
| 11 | Park Mechanism – Are any of the Parking Pawl Return Spring damaged, missing, or misassembled? | Yes | Service as required |
| | | No | Go to next step |
| 12 | Joint shaft – Do any of the following problems exist? • Broken • Splines damaged  page K2–39 | Yes | Service as required |
| | | No | Go to next step |
| 13 | Final Drive and Differential Assembly – Do any of the following problems exist? • Splines damaged • Gearset damaged | Yes | Service as required |
| | | No | Go to next step |
| 14 | Planetary Gearsets (Differential) – Are there any problems with the following? • Gear Teeth • Carriers • Splines | Yes | Service as required |
| | | No | The problem is fixed |

| 6 | SOME OR ALL SHIFTS MISSING | | | | | | | | |
|--------------------------------|---|--|---|--------|----------|-----|----|-----|----|
| [TROUBLESHOOTING HINTS] | | | | | | | | | |
| ① ATF | | ③ Internal and external shift linkages | | | | | | | |
| ② Powertrain control system | | ④ Speed input | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | |
| 1 | ATF – Is there improper level? ↳ page K2–22 | Yes | Adjust fluid to proper level | | | | | | |
| | | No | Go to next step | | | | | | |
| 2 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle Wiring Harness • PCM • Shift Solenoids • TR Switch • TP Sensor • Vehicle speedometer sensor • O/D OFF switch ↳ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “A and D” ↳ page K2–124, 130 | | | | | | |
| | | No | Go to next step | | | | | | |
| 3 | Internal and External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ↳ page K2–65 | Yes | Service as required | | | | | | |
| | | No | Go to next step | | | | | | |
| 4 | Speed Input – Is the vehicle speedometer sensor drive gear damaged? | Yes | Service as required | | | | | | |
| | | No | For further diagnosis, refer to the appropriate shift routine(s): <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center; border-bottom: 1px solid black;">Shifts</th> <th style="text-align: center; border-bottom: 1px solid black;">No Shift</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1–2</td> <td style="text-align: center;">13</td> </tr> <tr> <td style="text-align: center;">2–3</td> <td style="text-align: center;">14</td> </tr> <tr> <td style="text-align: center;">3–4</td> <td style="text-align: center;">15</td> </tr> </tbody> </table> | Shifts | No Shift | 1–2 | 13 | 2–3 | 14 |
| Shifts | No Shift | | | | | | | | |
| 1–2 | 13 | | | | | | | | |
| 2–3 | 14 | | | | | | | | |
| 3–4 | 15 | | | | | | | | |

| | | | |
|---|--|-----|--|
| 7 | SHIFT CONCERN: TIMING — EARLY/LATE | | |
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Tire size ③ Speed input | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle Wiring Harness • PCM • TP Sensor • Vehicle speedometer sensor • TFT Sensor  page K2–24 | Yes | Run OBD Tests Perform Pinpoint Test “B”  page K2–126 |
| | | No | Go to next step |
| 2 | Possible Components – Do any of the following problems exist? • Tire Size change  section Q • Vehicle speedometer sensor drive gear damaged | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 8 | | SHIFT CONCERN: ERRATIC | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|------------------------|--|--------|----------|-----------|-------|-----|----|----|----|-----|----|----|----|-----|----|----|----|-----|---|----|----|-----|---|----|----|-----|---|
| [TROUBLESHOOTING HINTS] ① ATF ② Powertrain control system ③ Vehicle speed input ④ Control valve body | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | ATF – Are there any problems with the followings? • Level • Condition ⓘ page K2–22 | Yes | Service as required | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Powertrain Control System – Are there any problems with the following? • Electrical Inputs/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch • Brake switch • TCC solenoid • Vehicle speedometer sensor • TP sensor • TSS • EPC solenoid • 3–2T/CCS ⓘ page K2–24 | Yes | Run OBD tests Perform Pinpoint Test “A, C, D, F and G” ⓘ page K2–124, 128, 130, 135, 137 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Vehicle Speed Input – Is the vehicle speedometer sensor drive gear damaged? | Yes | Service as required | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Control Valve Body – Do any of the following problems exist? • Bolts not torque to specification • Gaskets damaged • 3–2 timing valve, Pull in valve, 2–4 accumulator valve, Servo release shuttle valve, 3–2 control valve stuck, damaged, misassembled • Solenoid screen brocked • Separator plates damaged, blocked • Pressure tap plate/gasket damaged • SS1, SS2, 3–2T/CCS solenoid malfunction, stuck, damaged | Yes | Service as required | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Refer to the appropriate shift for further diagnosis <table border="1"> <thead> <tr> <th>Shifts</th> <th>No Shift</th> <th>Soft/Slip</th> <th>Harsh</th> </tr> </thead> <tbody> <tr> <td>1–2</td> <td>13</td> <td>16</td> <td>22</td> </tr> <tr> <td>2–3</td> <td>14</td> <td>17</td> <td>23</td> </tr> <tr> <td>3–4</td> <td>15</td> <td>18</td> <td>24</td> </tr> <tr> <td>4–3</td> <td>—</td> <td>19</td> <td>25</td> </tr> <tr> <td>3–2</td> <td>—</td> <td>20</td> <td>26</td> </tr> <tr> <td>2–1</td> <td>—</td> <td>21</td> <td>—</td> </tr> </tbody> </table> | Shifts | No Shift | Soft/Slip | Harsh | 1–2 | 13 | 16 | 22 | 2–3 | 14 | 17 | 23 | 3–4 | 15 | 18 | 24 | 4–3 | — | 19 | 25 | 3–2 | — | 20 | 26 | 2–1 | — |
| Shifts | No Shift | Soft/Slip | Harsh | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1–2 | 13 | 16 | 22 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2–3 | 14 | 17 | 23 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3–4 | 15 | 18 | 24 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4–3 | — | 19 | 25 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3–2 | — | 20 | 26 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2–1 | — | 21 | — | | | | | | | | | | | | | | | | | | | | | | | | | | |

| 9 | SHIFT CONCERN: FEEL — SOFT/SLIPPING | | | | | | | | | | | | | | | | |
|--|---|--|--|-------|-----------|-----|----|-----|----|-----|----|-----|----|-----|----|-----|----|
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | | | | | | | |
| ① ATF ② Powertrain control system ③ Internal or external shift linkages ④ Improper pressure | | ⑤ Control valve body ⑥ Oil pump ⑦ Oil filter and seal assembly | | | | | | | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | |
| 1 | ATF – Are there any problems with the following? • Level • Condition ⓘ page K2-22 | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 2 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor • TP sensor • MAF sensor ⓘ page K2-24 | Yes | Run OBD Tests, Perform Pinpoint Tests “B and E” ⓘ page K2-126, 133 | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 3 | Internal External Shift Linkage – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ⓘ page K2-65 | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 4 | Improper Pressure – Is there low line pressure? ⓘ page K2-10 | Yes | Check the line pressure If pressures are low or all shifts are soft/slipping, go to step 6 If pressures are OK and a specific shift is soft/slipping, refer to the following chart: <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="border-bottom: 1px solid black; padding: 2px;">Shift</th> <th style="border-bottom: 1px solid black; padding: 2px;">Soft/Slip</th> </tr> </thead> <tbody> <tr><td style="padding: 2px;">1-2</td><td style="padding: 2px;">16</td></tr> <tr><td style="padding: 2px;">2-3</td><td style="padding: 2px;">17</td></tr> <tr><td style="padding: 2px;">3-4</td><td style="padding: 2px;">18</td></tr> <tr><td style="padding: 2px;">4-3</td><td style="padding: 2px;">19</td></tr> <tr><td style="padding: 2px;">3-2</td><td style="padding: 2px;">20</td></tr> <tr><td style="padding: 2px;">2-1</td><td style="padding: 2px;">21</td></tr> </tbody> </table> | Shift | Soft/Slip | 1-2 | 16 | 2-3 | 17 | 3-4 | 18 | 4-3 | 19 | 3-2 | 20 | 2-1 | 21 |
| | | Shift | Soft/Slip | | | | | | | | | | | | | | |
| 1-2 | 16 | | | | | | | | | | | | | | | | |
| 2-3 | 17 | | | | | | | | | | | | | | | | |
| 3-4 | 18 | | | | | | | | | | | | | | | | |
| 4-3 | 19 | | | | | | | | | | | | | | | | |
| 3-2 | 20 | | | | | | | | | | | | | | | | |
| 2-1 | 21 | | | | | | | | | | | | | | | | |
| No | Go to next step | | | | | | | | | | | | | | | | |
| 5 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Main Regulator Valve, Line Modulator Valve stuck, damaged, or misassembled, or springs missing, tangled or damaged • EPC Solenoid stuck or damaged • Separator Plates damaged, blocked • Pressure Tap Plate/Gasket damaged or missing | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 6 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Porosity/cross leaks | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 7 | Oil Filter and Seal Assembly – Do any of the following problems exist? • Filter/Seal damaged, plugged, or missing • Recirculating Seal damaged or out of position | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | The problem is not in the automatic transaxle Go to section F3 | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | |
|--|---|--------|--|-------|-------|-----|----|-----|----|-----|----|-----|----|-----|----|-----|---|
| 10 SHIFT CONCERN: FEEL — HARSH [TROUBLESHOOTING HINTS] ① ATF ② Powertrain control system ③ Joint shafts ④ Engine mounts ⑤ Improper pressure ⑥ Control valve body ⑦ Torque converter assembly | | | | | | | | | | | | | | | | | |
| 1 | ATF – Are there any problems with the following? • Level • Condition ⓘ page K2–22 | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 2 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor • TSS • TP sensor • Vehicle speedometer sensor • MAF sensor • TCC solenoid • TR switch • 3–2T/CCS ⓘ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “B, C, D, E, F and G” ⓘ page K2–126, 128, 130, 133, 135, 137 | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 3 | Joint Shafts – Do any of the following problems exist? • Damaged • Loose • Splines damaged ⓘ page K2–39 | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 4 | Engine Mounts – Do any of the following problems exist? • Damaged • Loose • Missing ⓘ page K2–39 | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 5 | Improper Pressure – Is there high line pressure? ⓘ page K2–10 | Yes | Check the line pressure Service as required If pressures are OK and a specific shift is harsh, refer to the following chart: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Shift</th> <th>Harsh</th> </tr> </thead> <tbody> <tr><td>1–2</td><td>22</td></tr> <tr><td>2–3</td><td>23</td></tr> <tr><td>3–4</td><td>24</td></tr> <tr><td>4–3</td><td>25</td></tr> <tr><td>3–2</td><td>26</td></tr> <tr><td>2–1</td><td>—</td></tr> </tbody> </table> | Shift | Harsh | 1–2 | 22 | 2–3 | 23 | 3–4 | 24 | 4–3 | 25 | 3–2 | 26 | 2–1 | — |
| Shift | Harsh | | | | | | | | | | | | | | | | |
| 1–2 | 22 | | | | | | | | | | | | | | | | |
| 2–3 | 23 | | | | | | | | | | | | | | | | |
| 3–4 | 24 | | | | | | | | | | | | | | | | |
| 4–3 | 25 | | | | | | | | | | | | | | | | |
| 3–2 | 26 | | | | | | | | | | | | | | | | |
| 2–1 | — | | | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |
| 6 | Control Valve Bodys – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Main Regulator Valve, By-Pass Valve, Line Modulator Valve stuck, damaged, or misassembled • Springs tangled, missing, damaged • EPC solenoid stuck or damaged • Hydraulic Passages damaged • Separator plate damaged, blocked | Yes | Service as required | | | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION |
|------|--|---|
| 7 | Torque Converter Assembly Note <ul style="list-style-type: none"> • TCC applied during shifts – Do any of the following problems exist? <ul style="list-style-type: none"> • Piston damaged • Pump Support Seal #1 (CBY) leaking, missing or damaged • Case leakage • Converter Assembly damaged | Yes Service as required If heat stained, replace converter |
| | | No The problem is not in the automatic transaxle Go to section F3 |

| 11 | SHIFT CONCERNS: NO FIRST GEAR ENGAGES IN HIGHER GEAR ("D" RANGE) | | | | | | | | | | |
|---|--|--|--|-------|----------|-----|----|-----|----|-----|----|
| [TROUBLESHOOTING HINTS] | | | | | | | | | | | |
| ① Powertrain control system ② Internal or external shift linkage ③ Control valve body | | ④ Seals ⑤ Direct clutch ⑥ 2/4 band and servo | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | | | |
| 1 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch • O/D OFF switch ⓘ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests "A and D" ⓘ page K2–124, 130 | | | | | | | | |
| | | No | Go to next step | | | | | | | | |
| 2 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ⓘ page K2–65 | Yes | Service as required After servicing linkage, verify that the TR switch is properly adjusted ⓘ page K2–35 | | | | | | | | |
| | | No | Go to next step | | | | | | | | |
| 3 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Pull In Valve, Solenoid Regulator Valve, Shift Valves stuck, damaged, misassembled • Solenoid Filter Gasket damaged or misassembled • Hydraulic Passages damaged • SS1, SS2 Solenoid malfunction | Yes | Service as required | | | | | | | | |
| | | No | Go to next step | | | | | | | | |
| 4 | Mechanical – Do any of the following problems exist? • Seals, Clutches damaged, worn • Direct Clutch, 2/4 Band, 2/4 Servo damaged, stuck on | Yes | Service as required | | | | | | | | |
| | | No | Refer to the appropriate shift for further diagnosis <table border="1" data-bbox="850 1142 1073 1253"> <thead> <tr> <th>Shift</th> <th>No Shift</th> </tr> </thead> <tbody> <tr> <td>1–2</td> <td>13</td> </tr> <tr> <td>2–3</td> <td>14</td> </tr> <tr> <td>3–4</td> <td>15</td> </tr> </tbody> </table> | Shift | No Shift | 1–2 | 13 | 2–3 | 14 | 3–4 | 15 |
| Shift | No Shift | | | | | | | | | | |
| 1–2 | 13 | | | | | | | | | | |
| 2–3 | 14 | | | | | | | | | | |
| 3–4 | 15 | | | | | | | | | | |

| 12 | SHIFT CONCERNS: NO FIRST GEAR IN "1" RANGE (FIRST GEAR IN "D" RANGE O.K.) | | |
|--|--|-----|---|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Internal or external shift linkages ③ Control valve body | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch ↳ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests "A and D" ↳ page K2–124, 130 |
| | | No | Go to next step |
| 2 | Internal or External Shift Linkage – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ↳ page K2–65 | Yes | Service as required After servicing linkage, verify that the TR sensor is properly adjusted ↳ page K2–35 |
| | | No | Go to next step |
| 3 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Pull in Valve stuck, damaged • SS2 stuck "ON" • Hydraulic Passages damaged • Separator Plates damaged, blocked | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 13 | SHIFT CONCERNS: NO 1-2 SHIFT | | |
|---|---|-----|---|
| [TROUBLESHOOTING HINTS] | | | |
| <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <ul style="list-style-type: none"> ① Powertrain control system ② Improper pressure ③ Control valve body ④ 2/4 band and servo </div> <div style="width: 45%;"> <ul style="list-style-type: none"> ⑤ Low OWC assembly ⑥ Reverse/fourth gear sun gear and shell ⑦ Transaxle case </div> </div> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? <ul style="list-style-type: none"> • Electrical Input/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch • O/D OFF switch | Yes | Run OBD Tests Perform Pinpoint Tests “A and D” page K2-124, 130 |
| | | No | Go to next step |
| 2 | Improper Pressure – Do any of the following problems exist? <ul style="list-style-type: none"> • High line pressure • Low line pressure | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Control Valve Body – Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Gaskets damaged • 1-2 Shift Valve, 2-4 Accumulator, Main Regulator Valve stuck, damaged, or misassembled • SS1 malfunction • Pressure Tap Plate/Gasket damaged • Separator Plates damaged • Hydraulic Passages damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | 2/4 Band and Servo Assembly Note <ul style="list-style-type: none"> • Also no fourth gear – Do any of the following problems exist? <ul style="list-style-type: none"> • Seals damaged, missing • Piston damaged • Band damaged, worn • Springs damaged • Servo Rod or Rod Bore damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Low OWC Assembly – Is there damaged? | Yes | Service as required |
| | | No | Go to next step |
| 6 | Reverse/fourth gear Sun Gear and Shell – Do any of the following problems exist? <ul style="list-style-type: none"> • Damaged, weld broken • Lugs damaged | Yes | Service as required |
| | | No | Go to next step |
| 7 | Transaxle Case – Do any of the following problem exist? <ul style="list-style-type: none"> • Band anchor area damaged • Porosity/leakage in servo apply, servo release circuits | Yes | Service or replace case as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |



| 14 | SHIFT CONCERNS: NO 2-3 SHIFT | | |
|---|---|-----|--|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Improper pressure ③ Control valve body ④ Oil pump ⑤ Direct clutch assembly ⑥ 2/4 servo ⑦ Transaxle case | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch • O/D OFF switch ↳ page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “A and D” ↳ page K2-124, 130 |
| | | No | Go to next step |
| 2 | Improper Pressure – Do any of the following problems exist? • High line pressure • Low line pressure ↳ page K2-10 | Yes | Go to next step |
| | | No | Go to step 5 |
| 3 | Control Valve Body – Do any of the following problems exist? • Bolts not torque to specification • Gasket leaks • 2-3 Shift Valve (also No fourth), Main Regulator Valve stuck, damaged, misassembled • SS2 malfunction (also No fourth) • Separator Plates damaged • Pressure Tap Plate/Gasket leaks • Hydraulic Passages damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to spec • Gaskets damaged • Porosity/cross leaks • Pump Support Seal Rings, #4 and #5, damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Direct Clutch Assembly – Do any of the following problems exist? • Seals or Piston damaged • Piston Bore damaged • Friction severely damaged, worn • Ball Check not seating properly • Return Spring Assy. damaged • Cylinder Bore/Splines damaged • Shell/Hub damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | 2/4 Servo – Do any of the following problems exist? • Piston or Piston Bore damaged • Rod Bore or Rod damaged leaking | Yes | Service as required |
| | | No | Go to next step |
| 7 | Transaxle Case – Do any of the following problems exist? • Leakage in the Servo Apply, Servo Release or Direct Clutch Circuits | Yes | Service or replace case as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 15 | SHIFT CONCERNS: NO 3-4 SHIFT | | |
|--|---|-----|--|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Improper pressures ③ Control valve body ④ 2/4 band and servo assembly ⑤ Coasting clutch assembly ⑥ Forward OWC assembly ⑦ Transaxle case | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • SS1, SS2 • TR switch • O/D OFF switch ⓘ page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “A and D” ⓘ page K2-124, 130 |
| | | No | Go to next step |
| 2 | Improper Pressure – Do any of the following problems exist? • High line pressure • Low line pressure ⓘ page K2-10 | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • 3-4 Shift Valve, Main Regulator Valve stuck, damaged or misassembled • SS1 malfunction (Also No first gear) • Separator Plates damaged or Orifice blocked | Yes | Service as required |
| | | No | Go to next step |
| 4 | 2/4 Band and Servo Assembly Note • Also no second gear – Do any of the following problems exist? • 2/4 Band damaged, worn • Servo Rod or Rod Bore damaged • Servo Piston or Cover damaged or leaking • Springs damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Coasting Clutch Assembly – Do any of the following problems exist? • Seals damaged, missing • Piston damaged • Friction severely damaged, worn • Check Ball severely damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | Forward OWC Assembly – Is there damage? | Yes | Service as required |
| | | No | Go to next step |
| 7 | Transaxle Case Note • Also no second gear – Do any of the following problems exist? • Band Anchor damaged • Servo Apply and Servo Release circuits leaking | Yes | Service as required |
| | | No | Go to next step |

| 16 | SHIFT CONCERNS: SOFT/SLIPPING 1-2 SHIFT | | |
|--|--|-----|--|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ 2/4 Band and servo assembly ④ Forward OWC assembly ⑤ Forward clutch assembly ⑥ Low OWC assembly ⑦ Low/reverse clutch assembly ⑧ Transaxle case | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor ⓘ page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “B and E” ⓘ page K2-124, 130 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • 2-4 Accumulator Piston Plug and Seal (also soft 3-4 shift), Main Regulator Valve, Line Modulator Valve (also soft 3-4 shift) stuck, damaged, or misassembled • Hydraulic Passages damaged • Pressure Tap Plate/Gasket damaged • Separator Plates damaged | Yes | Service as required |
| | | No | Go to next step |
| 3 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • Piston, Seals or Piston Bore damaged, missing • Servo Rod or Rod Bore damaged • 2/4 Band and/or Reverse Clutch Drum Assembly worn, damaged, or misassembled • Springs damaged • Servo Cover and Seal damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Forward OWC Assembly (Slips in first gear) – Is the forward OWC assembly damaged or not holding? | Yes | Service as required |
| | | No | Go to next step |
| 5 | Forward Clutch Assembly (Slip in first gear) – Do any of the following problems exist? • Seals damaged • Return Spring damaged • Friction Elements damaged • Pump Support Seals #3, #4 damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | Low OWC Assembly – Is the low OWC assembly damaged or not over-running? | Yes | Service as required |
| | | No | Go to next step |
| 7 | Low/Reverse Clutch Assembly – Is there severe friction damage? | Yes | Service as required |
| | | No | Go to next step |
| 8 | Transaxle Case – Do any of the following problems exist? • Band Anchor damaged • Porosity/Leakage in servo Apply Servo Release circuits | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 17 SHIFT CONCERNS: SOFT/SLIPPING 2-3 SHIFT | | |
|--|--|---|
| [TROUBLESHOOTING HINTS] | | |
| ① Powertrain control system | ⑤ 2/4 servo | |
| ② Control valve body | ⑥ Forward OWC assembly | |
| ③ Oil pump | ⑦ Transaxle case | |
| ④ Direct clutch assembly | | |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor ⓘ page K2-24 | Yes Run OBD Tests Perform Pinpoint Tests “B and D” ⓘ page K2-124, 130 |
| | | No Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • Line Modulator Valve (also soft 1-2 and 3-4 shifts), Servo Release Shuttle Valve stuck, damaged or misassembled • Hydraulic Passages damaged • Separator Plates damaged • Pressure Tap Plate/Gasket leaks | Yes Service as required |
| | | No Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Pump Support Seals #4 and #5 damaged, missing | Yes Service as required |
| | | No Go to next step |
| 4 | Direct Clutch Assembly – Do any of the following problems exist? • Seals or Piston damaged • Piston Bore damaged • Friction damaged, worn, or excessive end clearance • Check Ball not seating properly • Return Spring Assembly damaged | Yes Service as required |
| | | No Go to next step |
| 5 | 2/4 Servo – Do any of the following problems exist? • Piston or Piston Bore damaged • Servo Rod or Rod Bore damaged | Yes Service as required |
| | | No Go to next step |
| 6 | Forward OWC Assembly – Is the forward OWC assembly damaged or not holding | Yes Service as required |
| | | No Go to next step |
| 7 | Transaxle Case – Do any of the following problems exist? • Leakage in the Servo Apply, Servo Release or Direct Clutch circuits | Yes Service as required |
| | | No The problem is not in the automatic transaxle Go to section F3 |

| 18 | SHIFT CONCERNS: SOFT/SLIPPING 3-4 SHIFT | | |
|--|---|--------|--|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ 2/4 band and servo assembly ④ Direct clutch assembly ⑤ Transaxle case | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor ↳ page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “B and E” ↳ page K2-124, 130 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • Line Modulator Valve, 2-4 Accumulator Valve Plug and Seal (also soft 1-2 shift), stuck, damaged, misassembled • Pressure Tap Plate/Gasket leaks • Hydraulic Passages damaged • Separator Plates damaged or Orifice blocked | Yes | Service as required |
| | | No | Go to next step |
| 3 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • 2/4 Band and/or Reverse Clutch Drum Assembly worn, damaged, or misassembled • Piston, Seals or Piston Bore damaged, missing • Servo Cover or Seal damaged • Servo Rod or Rod Bore damaged • Springs damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Direct Clutch Assembly Note • May also have third gear slip – Do any of the following problems exist? • Seals damaged, missing • Piston damaged • Check Ball damaged, missing, or leaking • Return Spring damaged • Friction Elements damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Transaxle Case – Do any of the following problems exist? • Band Anchor damaged • Servo Apply and Servo Release circuits leaking | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 19 | | SHIFT CONCERNS: SOFT/SLIPPING 4-3 SHIFT (AUTOMATIC) | |
|--------------------------------|---|---|---|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ④ Direct clutch assembly | |
| ② Control valve body | | ⑤ Forward/Coasting clutch assembly | |
| ③ 2/4 band and servo assembly | | ⑥ Transaxle case | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • Vehicle speedometer sensor • MAF • TP sensor  page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “E”  page K2-133 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • Servo Release Shuttle Valve, Main Regulator Valve stuck, damaged, or misassembled • Hydraulic Passages damaged • Pressure Tap Plate/Gasket leaks, or damaged • Separator Plates damaged, blocked | Yes | Service as required |
| | | No | Go to next step |
| 3 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • 2/4 Band and/or Reverse Clutch Drum Assembly damaged/worn/misassembled • Servo Return Spring broken • Servo Rod damaged • Piston Seal damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Direct Clutch Assembly – Do any of the following problems exist? • Seals damaged, missing • Piston damaged • Check Ball damaged, missing, or leaking • Return Spring damaged • Friction Elements damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Forward/Coasting Clutch Assembly – Do any of the following problems exist? • Seals damaged, missing • Piston damaged • Friction Elements worn, damaged • Check Ball not functioning • Forward Clutch, Piston and Return Spring damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | Transaxle Case – Do any of the following problems exist? • Proximity/cross leaks in Servo Apply, Servo Release, Direct Clutch circuits | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 20 | SHIFT CONCERNS: SOFT/SLIPPING 3-2 SHIFT (AUTOMATIC) | |
|--|--|---|
| [TROUBLESHOOTING HINTS] | | |
| ① Powertrain control system ② Control valve body ③ Oil pump ④ 2/4 band and servo assembly ⑤ Direct clutch assembly ⑥ Transaxle case | | |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TP sensor • Vehicle speedometer sensor • MAF • 3-2T/CCS ⓘ page K2-24 | Yes Run OBD Tests Perform Pinpoint Tests “E and G” ⓘ page K2-133, 137 |
| | | No Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket damaged • 3-2 Timing Valve, Solenoid Regulator Valve, 3-2 Control Valve Stuck, damaged or misassembled • 3-2T/CCS Solenoid malfunction • Pressure Tap Plate/Gasket leaks or damaged • Separator Plates damaged, blocked | Yes Service as required |
| | | No Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Porosity/Cross leaks • Pump Support Seal Rings #4, 5, 6 damaged or misassembled • Forward to Direct passage leaks | Yes Service as required |
| | | No Go to next step |
| 4 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • 2/4 Band and/or Reverse Clutch Drum Assembly damaged, worn, or misassembled • Servo Piston damaged • Servo Return and Cushion Springs damaged, misassembled • Springs damaged, misassembled • Servo Rod bent, damaged | Yes Service as required |
| | | No Go to next step |
| 5 | Direct Clutch Assembly – Do any of the following problems exist? • Return Spring damaged, broken • Friction Elements damaged, worn • Ball Check not releasing • Piston or Seal damaged | Yes Service as required |
| | | No Go to next step |
| 6 | Transaxle Case – Do any of the following problems exist? • Band Anchor damaged • Leakage in Servo Apply/Release circuits • Case Bore damaged (Servo Rod) | Yes Service as required |
| | | No The problem is not in the automatic transaxle Go to section F3 |

| 21 | SHIFT CONCERNS: SOFT/SLIPPING 2-1 SHIFT (AUTOMATIC OR KICKDOWN) | | |
|--------------------------------|--|---------------------------|---|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ④ Forward clutch assembly | |
| ② Oil pump | | ⑤ Low OWC assembly | |
| ③ 2/4 band and servo assembly | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor • TP sensor • MAF page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “B and E” page K2-126, 133 |
| | | No | Go to next step |
| 2 | Oil Pump – Do any of the following problems exist? • Gaskets damaged • Porosity/cross leaks • Pump Support Seals #3 and 4 leaking, misassembled, damaged | Yes | Service as required |
| | | No | Go to next step |
| 3 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • Piston damaged • Return Spring damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Forward Clutch Assembly – Do any of the following problems exist? • Piston or Seals damaged • Friction Elements damaged | Yes | Service as required |
| | | No | Go to next step |
| 5 | Low OWC Assembly – Is there the low OWC damaged or not holding? | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 22 | SHIFT CONCERNS: HARSH 1-2 SHIFT | | |
|--------------------------------|---|-------------------------------|--|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ④ 2/4 band and servo assembly | |
| ② Control valve body | | ⑤ Forward clutch assembly | |
| ③ Oil pump | | ⑥ Transaxle case | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TFT sensor • TSS • TP sensor • Vehicle speedometer sensor • MAF • TCC • TR switch ↗ page K2-24 | Yes | Run OBD Tests Perform Pinpoint Tests “B, C, D, E, and F” ↗ page K2-126, 128, 130, 133, 135 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • 2-4 Accumulator Valve, 3-2 Control Valve (also harsh 3-4 shift) stuck, damaged, or misassembled • Separator Plates damaged • Hydraulic Passages damaged | Yes | Service as required |
| | | No | Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gasket damaged • Pump Support Seal Rings #3 and #4 damaged • Porosity/cross leaks | Yes | Service as required |
| | | No | Go to next step |
| 4 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • Cushion Return Springs damaged • Band damaged, worn • 2/4 Band and/or Reverse Clutch Drum Assembly worn, damaged, or misassembled | Yes | Service as required |
| | | No | Go to next step |
| 5 | Forward Clutch Assembly – Do any of the following problems exist? • Seals damaged • Return Spring damaged • Friction Elements damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | Transaxle Case – Is there the band anchor area damaged? | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section F3 |

| 23 | SHIFT CONCERNS: HARSH 2-3 SHIFT | |
|--|---|---|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ Oil pump ④ Direct clutch assembly ⑤ 2/4 servo ⑥ Transaxle case | | |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TR switch • Vehicle speedometer sensor • TFT sensor • MAF • TCC solenoid • TSS ↳ page K2-24 | Yes Run OBD Tests Perform Pinpoint Tests “B, C, D, E, and F” ↳ page K2-126, 128, 130, 133, 135 |
| | | No Go to next step |
| 2 | Control Valve Body – Do any of following problems exist? • Bolts not torqued to specification • Gasket leaks • Line Modulator Valve (also 1-2 and 3-4 harsh shift), Servo Release Shuttle Valve stuck, damaged, misassembled • Separator Plates damaged • Hydraulic Passages damaged | Yes Service as required |
| | | No Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gasket damaged • Porosity/cross leaks • Pump Support Seal Rings #4 and #5 damaged | Yes Service as required |
| | | No Go to next step |
| 4 | Direct Clutch Assembly – Do any of the following problems exist? • Piston or Piston Bore damaged • Friction Elements damaged, worn • Ball Check not seating properly • Return Spring Assembly damaged • F/C/D Clutch Cylinder Splines damaged | Yes Service as required |
| | | No Go to next step |
| 5 | 2/4 Band Servo – Do any of the following problems exist? • Piston or Piston Bore damaged • Servo Rod damaged | Yes Service as required |
| | | No Go to next step |
| 6 | Transaxle Case – Do any of the following problems exist? • Leakage in the Servo Apply, Servo Release, or Direct Clutch circuits • Servo Rod Bore damaged | Yes Service as required |
| | | No The problem is not in the automatic transaxle Go to section F3 |

| 24 | SHIFT CONCERNS: HARSH 3-4 SHIFT | |
|--|---|---|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ Oil pump ④ 2/4 band and servo assembly ⑤ Coasting clutch assembly ⑥ Direct clutch assembly ⑦ Transaxle case | | |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TR switch • Vehicle speedometer sensor • 3-2T/CCS • TFT sensor • TSS • TP sensor • MAF • TCC solenoid ⓘ page K2-24 | Yes Run OBD Tests Perform Pinpoint Tests “B, C, D, E, F, and G” ⓘ page K2-126, 128, 130, 133, 135, 137 |
| | | No Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket leaks • Line Modulator Valve (also harsh 1-2 and 2-3 shifts), 3-2 Control Valve, 2-4 Accumulator Valve, Coasting Clutch Valve, stuck, damaged, or misassembled • Hydraulic Passaged damaged • Separator Plates damaged, blocked | Yes Service as required |
| | | No Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gasket damaged • Porosity/cross leaks • Coasting Clutch Teflon Seals damaged | Yes Service as required |
| | | No Go to next step |
| 4 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • 2/4 Band and/or Reverse Clutch Drum Assembly damaged/worn/misassembled • Servo Piston or Cover damaged or leaking • Springs damaged | Yes Service as required |
| | | No Go to next step |
| 5 | Coasting Clutch Assembly – Do any of the following problems exist? • Piston or Seals damaged, missing • Friction damaged, worn • Check Ball not functioning | Yes Service as required |
| | | No Go to next step |
| 6 | Direct Clutch Assembly – Do any of the following problems exist? • Piston or Seals damaged, missing • Check Ball damaged, missing, or leaking • Return Spring damaged • Friction Elements damaged • F/C/D Clutch Cylinder Splines damaged | Yes Service as required |
| | | No Go to next step |
| 7 | Transaxle Case – Is there the band anchor damaged? | Yes Service as required |
| | | No The problems is not in the automatic transaxle Go to section F3 |

| 25 | SHIFT CONCERNS: HARSH 4-3 SHIFT (AUTOMATIC) | | |
|-------------------------|---|--------|---|
| [TROUBLESHOOTING HINTS] | | | |
| ① | Powertrain control system | ④ | 2/4 band and servo assembly |
| ② | Control valve body | ⑤ | Coasting clutch assembly |
| ③ | Oil pump | ⑥ | Transaxle case |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System — Do any of the following problems exist? <ul style="list-style-type: none"> • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TR switch • Vehicle speedometer sensor • TP sensor • TFT sensor • MAF • TSS • 3-2T/CCS • TCC solenoid <p style="text-align: right;">🔍 page K2-24</p> | Yes | Run OBD Tests Perform Pinpoint Tests “B, C, D, E, F and G” 🔍 page K2-126, 128, 130, 133, 135, 137 |
| | | No | Go to next step |
| 2 | Control Valve Body — Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Gasket leaks • Servo Release Shuttle Valve, 3-2 Timing/Coast Clutch Valve stuck, damaged, misassembled • Hydraulic Passaged damaged • Separator Plates damaged, blocked | Yes | Service as required |
| | | No | Go to next step |
| 3 | Oil Pump — Do any of the following problems exist? <ul style="list-style-type: none"> • Bolts not torqued to specification • Porosity/cross leak, Seal Rings damaged, missing or leaking ball plug • Gasket damaged • Pump Support Seal Rings #2, 3, 4, and #5 (Coast and Direct circuits) damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | 2/4 Band and Servo Assembly — Do any of the following problems exist? <ul style="list-style-type: none"> • Servo Rod bent, damaged • Servo Return Spring broken | Yes | Service as required |
| | | No | Go to next step |
| 5 | Coasting Clutch Assembly — Do any of the following problems exist? <ul style="list-style-type: none"> • Seals damaged, mission • Piston damaged • Friction Elements worn, damaged • Check Ball not functioning • Forward Clutch Piston and Return spring damaged | Yes | Service as required |
| | | No | Go to next step |
| 6 | Transaxle Case — Do any of the following problems exist? <ul style="list-style-type: none"> • Porosity/cross leaks in Servo Apply, Servo Release, Direct Clutch, Coasting Clutch circuits | Yes | Service as required |
| | | No | The problems is not in the automatic transaxle Go to section F3 |

| 26 | SHIFT CONCERNS: HARSH 3-2 SHIFT (AUTOMATIC) | |
|--|--|---|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ Oil pump ④ Direct clutch assembly ⑤ 2/4 band and servo assembly ⑥ Transaxle case | | |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • EPC solenoid • TR switch • Vehicle speedometer sensor • 3-2T/CCS • TFT sensor • MAF • TP sensor • TSS • TCC solenoid 📖 page K2-24 | Yes Run OBD Tests Perform Pinpoint Tests “B, C, D, E, F, and G” 📖 page K2-126, 128, 130, 133, 135, 137 |
| | | No Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gasket damaged • 3-2 Timing Valve, Solenoid Regulator Valve, 3-2 Control Valve stuck, damaged, misassembled • Hydraulic Passages damaged • Separator Plates damaged, blocked • 3-2T/CCS Solenoid malfunction | Yes Service as required |
| | | No Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Porosity/Cross leaks • Pump Support Seal Rings damaged or misassembled | Yes Service as required |
| | | No Go to next step |
| 4 | Direct Clutch Assembly – Do any of the following problems exist? • Return Spring damaged, broken • Friction Elements damaged, worn • Check Ball not exhausting • Servo Rod bent or damaged | Yes Service as required |
| | | No Go to next step |
| 5 | 2/4 Band and Servo Assembly – Do any of the following problems exist? • 2/4 Band and/or Reverse Clutch Drum Assembly damaged, worn, or misassembled • Servo Piston damaged • Servo Return and Cushion Springs damaged, misassembled • Springs damaged, misassembled | Yes Service as required |
| | | No Go to next step |
| 6 | Transaxle Case – Do any of the following problems exist? • Band Anchor damaged • Leaks • Servo Rod Bore damaged | Yes Service as required |
| | | No The problem is not in the automatic transaxle Go to section F3 |

| 27 | TORQUE CONVERTER CLUTCH: NO APPLY | | |
|--------------------------------|--|-----------------------------|--|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ③ Torque converter assembly | |
| ② Control valve body | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • TFT sensor • TCC solenoid • Brake switch • TSS ↳ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “B, C, and F” ↳ page K2–126, 128, 135 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Caskets damaged • Solenoid Pressure Regulator Valve, Bypass Clutch Control Valve and Plunger, Converter Regulator Valve stuck, damaged, or misassembled • TCC Solenoid malfunction, stuck • Hydraulic Passages damaged • Separator Plates damaged, blocked | Yes | Service as required |
| | | No | Go to next step |
| 3 | Torque Converter Assembly – Do any of the following problems exist? • Leakage • Internal damage | Yes | Perform Torque converter test |
| | | No | Replace the torque converter assembly |

| 28 | TORQUE CONVERTER CLUTCH; ALWAYS APPLIED/MAY STALL ENGINE | | |
|--------------------------------|---|-----------------------------|--|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ④ Torque converter assembly | |
| ② Control valve body | | ⑤ Transaxle case | |
| ③ Oil pump | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Do any of the following problems exist? • Electrical Input/Output • Vehicle wiring harness • PCM • TFT sensor • TCC solenoid page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “B and C” page K2–126, 128 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Bypass Clutch Control Valve and Plunger (always applied), Converter Regulator Valve stuck, damaged, misassembled • Separator Plates damaged, blacked Note • Converter not applied in first gear or reverse gear • TCC Solenoid malfunction • Pressure Tap Plate/Gasket damaged • Hydraulic Passages damaged | Yes | Service as required |
| | | No | Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Pump Support #1, Seal Ring damaged, missing, misassembled | Yes | Service as required |
| | | No | Go to next step |
| 4 | Torque Converter Assembly – Do any of the following problems exist? • Internal Seals damaged • Piston Plate damage/stuck to Cover | Yes | Service as required |
| | | No | Go to next step |
| 5 | Transaxle Case – Do any of the following problems exist? • Porosity/cross leaks from the CBY circuit | Yes | Service as required |
| | | No | The problem is fixed |

| 29 OTHER: POOR VEHICLE ACCELERATION/PERFORMANCE | | |
|---|---|--|
| [TROUBLESHOOTING HINTS] | | |
| ① Powertrain control system | | ③ Torque converter clutch |
| ② Internal or external shift linkages | | ④ Converter OWC |
| STEP | INSPECTION | ACTION |
| 1 | Powertrain Control System – Are there any problems with the following? • Engine • Electrical Input/Output • Vehicle wiring harness • PCM • TFT sensor • TP sensor • O/D OFF switch ⓘ page K2–24 | Yes Run OBD Tests If the problem is engine related, go to Section F3 If the problem is not engine related, perform Pinpoint Tests “B, C and D” ⓘ page K2–126, 128, 130 |
| | | No Go to next step |
| 2 | Internal and External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ⓘ page K2–65 | Yes Service as required |
| | | No Go to next step |
| 3 | Torque Converter Clutch – Is the torque converter clutch always applied? ⓘ page K2–107 | Yes Perform Symptom Troubleshooting No.28 ⓘ page K2–107 |
| | | No Go to next step |
| 4 | Converter OWC – Is the converter OWC damaged? ⓘ page K2–15 | Yes Service as required |
| | | No Perform Road Test and verify proper shift schedule and engagements Service as required ⓘ page K2–15 |


| 30 | OTHER: ENGINE WILL NOT CRANK | | |
|---------------------------------------|--|---------------|--|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ③ TR switch | |
| ② Internal or external shift linkages | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Are there any problems with the following? • Engine • Electrical Input/Output • Vehicle wiring harness • PCM • TR switch ☞ page K2–24 | Yes | Run OBD Tests If the problem is engine related, go to Section F3 If the problem is not engine related, perform Pinpoint Tests “D” ☞ page K2–130 |
| | | No | Go to next step |
| 2 | Internal and External Shift Linkage or TR Switch – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ☞ page K2–65 ☞ page K2–35 | Yes | Service as required |
| | | No | Go to next step |
| 3 | Starter/Drive plate – Do any of the following problems exist? • Damaged • Misassembled ☞ section G ☞ page K2–63 | Yes | Service as required |
| | | No | The problem is fixed |



| 31 | OTHER: NO "P" POSITION | | |
|---------------------------------------|---|------------------|----------------------|
| [TROUBLESHOOTING HINTS] | | | |
| ① Internal or external shift linkages | | ② Park mechanism | |
| STEP | INSPECTION | ACTION | |
| 1 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged, misadjusted, or misassembled ↳ page K2–65 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Park Mechanism – Do any of following problems exist? • Park gear on driven sprocket assembly, Parking pawl return spring, Park pawl ratcheting springs, Park pawl shaft • Manual lever, Cam apply lever • Manual lever detent spring • TR switch, Parking pawl apply cam • Manual shaft nut damaged • Missing or misassembled | Yes | Service as required |
| | | No | The problem is fixed |

| 32 | OTHER: TRANSAXLE OVERHEATING | | |
|---|---|--------|--|
| <p>[TROUBLESHOOTING HINTS]</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>① ATF</p> <p>② Powertrain control system</p> <p>③ Oil cooler</p> <p>④ Control valve body</p> <p>⑤ Torque converter clutch</p> </div> <div style="width: 48%;"> <p>⑥ Oil pump</p> <p>⑦ Chain pan</p> <p>⑧ Thermostatic oil level control valve</p> <p>⑨ Transaxle case/converter housing/Starter support</p> </div> </div> | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>ATF</p> <p>– Are there any problems with the following?</p> <ul style="list-style-type: none"> • Level • Condition <p style="text-align: right;">📖 page K2–22</p> | Yes | Service as required |
| | | No | Go to next step |
| 2 | <p>Powertrain Control System</p> <p>– Are there any problems with the following?</p> <ul style="list-style-type: none"> • Electrical Input/Output • Vehicle wiring harness • PCM • TCC solenoid • TFT sensor • TSS <p style="text-align: right;">📖 page K2–24</p> | Yes | Run OBD Tests Perform Pinpoint Tests “B, C and F” 📖 page K2–126, 128, 135 |
| | | No | Go to next step |
| 3 | <p>Oil cooler</p> <p>– Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Damaged • Blocked • Reversed • Restricted • Leaking • Misassembled <p style="text-align: right;">📖 page K2–61</p> | Yes | Service as required |
| | | No | Go to next step |
| 4 | <p>Control Valve Body</p> <p>– Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Bolts not torqued to specification • Main Regulator Valve, Bypass Clutch Control Valve, Converter Regulator Valve stuck, damaged, misassembled • Hydraulic Passages damaged • Separator Plates/Gaskets damaged • TCC Solenoid malfunction (OFF) | Yes | Service as required |
| | | No | Go to next step |
| 5 | <p>Torque Converter Clutch</p> <p>– Does the torque converter clutch not apply?</p> | Yes | Perform Symptom Troubleshooting No.27 📖 page K2–106 |
| | | No | Go to next step |
| 6 | <p>Oil Pump</p> <p>– Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Gasket damaged • Rear Lube Passage blocked | Yes | Service as required |
| | | No | Go to next step |
| 7 | <p>Chain Pan</p> <p>– Is it missing?</p> | Yes | Install the chain pan |
| | | No | Go to next step |
| 8 | <p>Thermostatic Oil Level Control Valve</p> <p>– Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Stuck open or damaged • Gasket damaged or missing • Bolt or bracket damaged, missing, or improperly installed | Yes | Service as required |
| | | No | Go to next step |
| 9 | <p>Transaxle Case/Converter Housing/Stater Support</p> <p>– Do any of the following problems exist?</p> <ul style="list-style-type: none"> • Front Lube Passage blocked or restricted • TC, CI, CT Passages blocked or restricted | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section E |

| 33 | OTHER: NO ENGINE BRAKING IN FIRST GEAR (“1” RANGE) | | |
|--|---|--------|--|
| [TROUBLESHOOTING HINTS] ① Powertrain control system ② Control valve body ③ Oil pump ④ Coasting clutch assembly ⑤ Low/reverse clutch assembly | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Are there any problems with the following? • Electrical Input/Output • Vehicle wiring harness • PCM • 3–2T/CCS ⓘ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests “G” ⓘ page K2–137 |
| | | No | Go to next step |
| 2 | Control Valve Body – Do any of the following problems exist? • Bolts not torqued to specification • Gaskets damaged • Low/Reverse Modulator Valve, Coasting Clutch Valve stuck damaged or misassembled • 3–2T/CCS stuck or damaged • Hydraulic Passages damaged • Pressure Tap Plate/Gasket damaged • Separator Plate/Gasket damaged | Yes | Service as required |
| | | No | Go to next step |
| 3 | Oil Pump – Do any of the following problems exist? • Pump Support #2 and #3 Seal Rings for the Coast Clutch circuit damaged, missing | Yes | Service as required |
| | | No | Go to next step |
| 4 | Coasting Clutch Assembly – Do any of the following problems exist? • Assembly misassembled, damaged • Forward Clutch Hub Seal damaged • Piston or Seals damaged • Ball Check damaged, missing | Yes | Service as required |
| | | No | Go to next step |
| 5 | Low/Reverse Clutch Assembly – Do any of the following problems exist? • Misassembled • Damaged • Piston or seals damaged | Yes | Service as required |
| | | No | The problem is fixed |

| 34 | OTHER: NO ENGINE BRAKING IN "D" RANGE (O/D OFF SW ON) OR "2" RANGE | | |
|---------------------------------------|---|----------------------------|---|
| [TROUBLESHOOTING HINTS] | | | |
| ① Powertrain control system | | ④ Oil pump | |
| ② Internal or external shift linkages | | ⑤ Forward OWC assembly | |
| ③ Control valve body | | ⑥ Coasting clutch assembly | |
| STEP | INSPECTION | ACTION | |
| 1 | Powertrain Control System – Are there any problems with the following? • Electrical Inputs/Outputs • Vehicle wiring harnesses • PCM • 3–2T/CCS ⓘ page K2–24 | Yes | Run OBD Tests Perform Pinpoint Tests "G" ⓘ page K2–137 |
| | | No | Go to next step |
| 2 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled ⓘ page K2–65 | Yes | Service as required |
| | | No | Go to next step |
| 3 | Control Valve Body – Do any of the following problems exist? • 3–4 Shift Valve, 1–2 Shift Valve, Pull in Valve, Coasting Clutch Control Valve stuck, damaged • 3–2T/CCS stuck or damaged | Yes | Service as required |
| | | No | Go to next step |
| 4 | Oil Pump – Do any of the following problems exist? • Pump Support #2 and #3 Seal Rings for the Coasting Clutch circuit damaged, missing | Yes | Service as required |
| | | No | Go to next step |
| 5 | Forward OWC Assembly – Do any of the following problems exist? • Damaged • Misassembled | Yes | Service as required |
| | | No | Go to next step |
| 6 | Coasting Clutch Assembly – Do any of the following problems exist? • Assembly misassembled, damaged • Forward Clutch Hub Seal damaged • Piston or Seals damaged • Ball Check damaged, missing | Yes | Service as required |
| | | No | The problem is not in the automatic transaxle Go to section B1 or F3 |

| 35 | OTHER: VEHICLE MOVEMENT WITH GEAR SELECTOR IN "N" POSITION | | |
|---------------------------------------|---|------------------------------------|----------------------|
| [TROUBLESHOOTING HINTS] | | | |
| ① Internal or external shift linkages | | ③ Forward/coasting clutch assembly | |
| ② Oil pump | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled  page K2–65 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Oil Pump – Do any of the following problems exists? • Gaskets Severely damaged • Pump Support Seal Ring #2, leakage from Lube Circuit into FC Circuit | Yes | Service as required |
| | | No | Go to next step |
| 3 | Forward/Coasting Clutch Assembly – Do any of the following problems exist? • Friction plates severely damaged • Return Spring damaged • Ball Check damaged, missing | Yes | Service as required |
| | | No | The problem is fixed |

| 36 | OTHER: SHIFT EFFORTS HIGH | | |
|--------------------------------------|--|----------------------|----------------------|
| [TROUBLESHOOTING HINTS] | | | |
| ① Shift interlock | | ③ Transaxle case | |
| ② Internal or external shift linkage | | ④ Control valve body | |
| STEP | INSPECTION | ACTION | |
| 1 | Shift Interlock – Is there any problem?  page K2-65 | Yes | Service as required |
| | | No | Go to next step |
| 2 | Internal or External Shift Linkages – Do any of the following problems exist? • Damaged • Misadjusted • Misassembled  page K2-65 | Yes | Service as required |
| | | No | Go to next step |
| 3 | Transaxle Case – Do any of the following problems exist? • Manual lever damaged • Park mechanism damaged • Shaft bent • Detent lever shaft bore (in case) damaged • Detent spring bent/damaged • Nut loose | Yes | Service as required |
| | | No | Go to next step |
| 4 | Control Valve Body – Do any of the following problems exist? • Bolts are not torqued to specification • Manual valve stuck, damaged | Yes | Service as required |
| | | No | The problem is fixed |

| 37 | OTHER: EXTERNAL LEAKS | | |
|--------------------------------|---|-----|--|
| [TROUBLESHOOTING HINTS] | | | |
| ① ATF | | | |
| STEP | INSPECTION | | ACTION |
| 1 | ATF – Is ATF improper level? <div style="text-align: right;">👉 page K2–22</div> | Yes | Service as required |
| | | No | Go to next step |
| | SEALS/GASKETS Differential seal, speedometer seal, pump, main control cover, servo cover, split frange converter inpeller hub, manual shift seal OTHERS <ul style="list-style-type: none"> • Cooler fitting, pressure tap plug, line pressure plug, case porosity, case cracked • Vent blocked or damaged CONNECTORS/SENSORS <ul style="list-style-type: none"> • Transaxle connector, TR switch, TSS sensor seal | | Locate source of leak Service as required |

| 38 | OTHER: NOISE/VIBRATION — FORWARD/REVERSE | | |
|--|--|-----|----------------------|
| [TROUBLESHOOTING HINTS] | | | |
| ① For Noises/Vibrations that Change with Engine Speed ③ Other Noises/Vibrations | | | |
| ② For Noises/Vibrations that Change with Vehicle speed | | | |
| STEP | INSPECTION | | ACTION |
| 1 | For Noises/Vibrations that Change with Engine Speed – Are there any problems with the following? <ul style="list-style-type: none"> • Torque converter • ATF level (low) pump cavitation • Oil pump • Engine drive accessories • Cooler lines grounding out • Drive plate | Yes | Service as required |
| | | No | Go to next step |
| 2 | For Noises/Vibrations that Change with Vehicle Speed – Are there any problems with the following? <ul style="list-style-type: none"> • Engine mount • Tires • Drive shaft or joint shaft • Differential (final drive/chain) • Suspension • Planetary gear sets • Chain grounding to chain pan • Forward one-way clutch • Torque converter | Yes | Service as required |
| | | No | Go to next step |
| 3 | Other Noise/Vibrations – Are there any problems with the following? <ul style="list-style-type: none"> • Shift cable vibration grounding • Cooler lines grounding | Yes | Service as required |
| | | No | The problem is fixed |

ON-BOARD DIAGNOSTIC SYSTEM

DESCRIPTION

Quick Test Description

Quick Test is divided into three special tests: Key On Engine Off Self-Test, Key On Engine Running Self-Test and Continuous Memory DTC access. Quick Test also provides a quick check of the powertrain control system and is usually performed at the start of each diagnostic procedure and at the end of most pinpoint tests for verification of repair and to ensure no other faults exist.

Key On Engine Off Self-Test

Key On Engine Off is a functional test of the powertrain control system performed on demand. A fault has to be present at the time of testing for the Key On Engine Off Self-Test to detect the fault. When a fault is detected, a Diagnostic Trouble Code (DTC) will be output on the data link when requested by a scan tool.

Key On Engine Running Self-Test

Key On Engine Running is a functional test of the powertrain control system performed on demand with the engine running and vehicle stopped. A check of the inputs and outputs is made during operating conditions and at normal temperature. A fault has to be present at the time of testing. When a fault is detected, a Diagnostic Trouble Code (DTC) will be output on the data link when requested by a scan tool.

Continuous Memory DTC Access Self-Test

Continuous Memory DTC access is also a functional test of the powertrain control system. The Continuous Memory self-test is always active. The test consists of all the OBD II monitors and the comprehensive component monitor, and is designed to detect failures contributing to driveability and emission concerns. As part of Quick Test, the technician may perform a specific drive cycle before running Quick Test. This is necessary to detect certain faults not tested during other self-test operations. All self-tests are menu driven in the New Generation Star (NGS) scan tool.

Parameter Identification (PID) Access

The PID mode allows access to certain data values, analog and digital inputs and outputs, calculated values, and system status information.

Brake On/Off Test

On vehicles equipped with Brake On/Off (BOO) input, the brake pedal **MUST** be depressed and released after the Key On Engine Running self-test is initiated.

O/D OFF Switch Test


On vehicles equipped with an O/D OFF switch, the switch **MUST** be cycled after the Key On Engine Running self-test is initiated.





Wiggle/Tap Test

The wiggle/tap test is performed by the technician in an attempt to re-create an intermittent fault.

PREPARATION

SST

| | | |
|--------------------------------|---|---|
| <p>49 T088 0A0 NGS set</p> |  | <p>For inspection of PCM terminal voltage and input/output device</p> |
|--------------------------------|---|---|



ON-BOARD DIAGNOSTIC TEST New Generation Start (NGS) Hook-up Procedure

Note

- Make sure Key is Off.


1. Insert the vehicle interface module and program card into the **SST** (NGS) control unit.
2. Plug the NGS OBD II adapter into the interface module and the large 5 pin connector into the vehicle data link connector (DLC) located under the dash to left of the center console.
3. Plug the (NGS) tester power cable into the cigarette lighter or use a battery hook-up adapter.
4. Listen for a double beep. The **SST** (NGS) is now initialized. Begin the functional test of powertrain control system.

Key On Engine Off Quick-Test Procedure


Note

- Start the engine and bring up to operating temperature before running the Quick-Test.

1. Perform the necessary vehicle preparation and visual inspection (Refer to section F3). Hook-up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selections.
3. Select vehicle year and model.
4. Select diagnostic data link.
5. Select PCM.



6. Select diagnostic test mode.
7. Select key ON engine off on-demand self-test.
8. Turn the key ON. Press start and trigger. Follow the operating procedures from the menu.





Key On Engine Running Quick-Test Procedure

Note

- Start the engine and bring up to normal operating temperature before running the Quick-Test.

1. Perform the necessary vehicle preparation and visual inspection (Refer to section F3). Hook-up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.




6. Select diagnostic test mode.
7. Select key ON engine running on-demand self-test.
8. Start the vehicle. Press start and trigger.
9. Follow the operating instructions from the menu and perform BOO, and O/D OFF switch cycling, if equipped.


Accessing All Continuous Memory DTC's Procedure

Note

- Start the engine and bring up to operating temperature before running the Quick-Test.

1. Perform the necessary vehicle preparation and visual inspection (Refer to section F3). Hook the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection menu.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.






6. Select Diagnostic test mode.
7. Select Retrieve/Clear continuous DTC's.
8. Turn the key ON. Press start.
9. Follow the operating instruction from the menu.


Output Control Test Procedure

Note


- Start the engine and bring up to operating temperature before running the Output Control Test.




1. Perform the necessary vehicle preparation and visual inspection. (Refer to section F3). Hook up the **SST** (NGS) to the vehicle.
2. Select vehicle and engine selection.
3. Select vehicle year and model.



4. Select diagnostic data link.
5. Select PCM.



6. Select diagnostic test mode.
7. Select active tests.
8. Select output control.
9. Turn the key ON. Press start and trigger. Follow the operating instructions from the menu.



After Repair Procedure

1. Connect the **SST** (NGS) to the Data Link Connector.
2. Select Clear codes function and clear the DTC's.
3. Perform Quick-Test to ensure that the customer's concern has been resolved. If DTC P1000 is present, go to the DTC P1000 chart.

OBD II Drive Cycle

Note

- Only perform this procedure when instructed to do so.



1. Start the engine.
2. Drive the vehicle in any mode for 6 minutes.
3. Monitor the ECT PID drive vehicle until the ECT PID reaches 0.6 volts (180°F [82°C]) or greater.
4. Idle for 45 seconds.
5. Accelerate to 45 mph at 1/4 throttle.
6. Drive for 4 minutes in the range of 30 to 45 mph. If stop and go conditions occur, the accumulated time must be within the 20 to 45 mph range. No wide open throttle (WOT) conditions should occur.
7. Drive at a speed between 30 and 40 mph for 1 minute at steady throttle.
8. Decelerate and idle for 1 minute.
9. Accelerate to 55 mph at 1/2 throttle.
10. Cruise at a speed between 40 and 65 mph for 80 seconds at steady throttle.
11. Decelerate and idle.
12. With the ignition key ON, (vehicle at idle or engine off) check for Continuous Memory DTCs.


Accessing OBD II PID Mode Procedure

Note

- Start the engine and bring up to operating temperature before running the Quick-Test.

1. Hook-up the **SST** (NGS).
2. Select vehicle and engine selection menu.
3. Select vehicle year and model.
4. Select Diagnostic data link.
5. Select PCM.
6. Select PID/DATA monitor and Record.
7. Turn the key ON or start the engine.






8. Select the PID values to view and press the trigger.
9. Select start to begin.

Note

- Refer to the manufacturer provided instruction manual for other NGS diagnostic testing procedures.



| TIME | ECT | TP | MAF |
|------|-----|------|------|
| -0.8 | 182 | 55.3 | 10.8 |
| T0.0 | 183 | 99.3 | 11.3 |
| +0.2 | 184 | 65.4 | 11.5 |
| SEC | °F | % | G/S |

SUDDEN SPIKE — POSSIBLE FAULT

DIAGNOSTIC TROUBLE CODE

Note

- If the DTC that you want to find is not in the following chart, please refer to the “Diagnostic Trouble Code Number” chart in section F3.

| No. | Diagnosed Circuit | Condition | Page |
|-------|-----------------------------|--|--------|
| P0500 | Vehicle speedometer sensor | Insufficient vehicle speedometer sensor input | K2-141 |
| P0706 | TR switch | TR out of range Open circuit or sensor | K2-130 |
| P0707 | | TR out of range Shorted circuit or sensor | |
| P0712 | TFT sensor | 150°C (302°F) indicated TFT sensor circuit grounded | K2-126 |
| P0713 | | -40°C (-40°F) indicated TFT sensor circuit open | |
| P0715 | TSS sensor | Insufficient input from TSS sensor | K2-135 |
| P0731 | SS1, SS2, or internal parts | Incorrect gear ratio for 1GR | K2-124 |
| P0732 | | Incorrect gear ratio for 2GR | |
| P0733 | | Incorrect gear ratio for 3GR | |
| P0734 | | Incorrect gear ratio for 4GR | |
| P0741 | TCC solenoid | TCC control engagement error | K2-128 |
| P0743 | | TCC solenoid circuit failure during self-test | |
| P0750 | SS1 | SS1 circuit failure | K2-124 |
| P0755 | SS2 | SS2 circuit failure | |
| P1500 | Vehicle speedometer sensor | Insufficient vehicle speedometer sensor input | K2-141 |
| P1705 | TR switch | TR not in PARK | K2-130 |
| P1711 | TFT sensor | ATF is not at operating temperature during self-test | K2-126 |
| P1746 | EPC solenoid | Open PCM output driver | K2-133 |
| P1747 | | EPC solenoid circuit failure, shorted to ground or open | |
| P1780 | O/D OFF switch | O/D OFF switch not cycled during self-test | K2-139 |
| P1783 | TFT sensor | ATF temperature exceeded 132°C (270°F) | K2-126 |
| P1788 | 3-2T/CCS | Circuit shorted during self-test | K2-137 |
| P1789 | | Circuit open or PCM drive circuit failure during self-test | |

Caution

- **Do not disconnect the battery to clear diagnostic trouble codes. This will erase the keep alive memory information which may cause a driveability concern.**
- **After repairing a failure, perform the After Repair Procedure to verify the fault has been corrected.**

Pinpoint Test Pinpoint test A

| DIAGNOSTIC TROUBLE CODE NO.P0750, P0755, P0731, P0732, P0733, P0734 | | |
|---|--|--|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, SS1, SS2, VPWR • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] Engine: Performance, Cooling, Brakes Electrical: Battery, Input Sensors, Wiring Harnesses Transaxle: Internal Transaxle Components, Linkages, Cooling | | |
| STEP | INSPECTION | ACTION |
| A1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the solenoid body connector is fully seated, terminals are fully engaged in the connector and in good condition before proceeding. • Connect NGS tester. • Perform KOEO Test until Continuous Memory DTC have been displayed. • Perform the Drive Cycle Test mode. • Depress throttle to WOT and release. • Does vehicle enter Output State (DTM)? | Yes Remain in Output State (DTM). Go to A2 |
| | | No Depress throttle and release. If vehicle did not enter Output State (DTM), refer to section F3. |
| A2 | CHECK ELECTRICAL SIGNAL OPERATION Caution <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. <ul style="list-style-type: none"> • Disconnect solenoid body connector. • Using a mirror, inspect both ends of the connector for damaged or pushed out pins, corrosion, loose wires, and missing or damaged seals. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Connect VOM/DVOM positive test lead to VPWR circuit and negative test lead to the suspect solenoid circuit of the transaxle vehicle harness connector. • VOM/DVOM ON 20 Volt scale. • While observing DVOM, depress and release throttle to cycle solenoid output ON and OFF. • Does the suspected solenoid output voltage change at least 0.5 volt? | Yes Go to A5 |
| | | No Go to A3 |
| A3 | CHECK CONTINUITY OF SOLENOID SIGNAL AND VPWR HARNESS CIRCUITS <ul style="list-style-type: none"> • Key OFF. • Solenoid body connector disconnected. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as Reqd. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Measure resistance between PCM signal test pin (27 or 1) at the breakout box and signal pin at solenoid body connector. • Measure resistance between PCM Test Pin (71/97) at the breakout box and VPWR pin at solenoid body connector. • Is each resistance less than 5.0 ohms? | Yes Go to A4 |
| | | No Service open circuit(s). Remove breakout box. Reconnect all components. Rerun OBD Tests. |

| STEP | INSPECTION | | ACTION | | | | | | |
|------|--|----------|--|-----|----------|-----|----------|-----|--|
| A4 | CHECK SOLENOID HARNESS FOR SHORTS TO POWER AND GROUND <ul style="list-style-type: none"> Breakout box installed, PCM disconnected. Solenoid body connector disconnected. Refer to connector schematic and table of solenoid body. (Refer to page K2-143) Measure resistance between PCM signal test pin (27 or 1) and Test Pin (71/97) at the breakout box. Measure resistance between PCM signal test pin (27 or 1) and test pins (77/103) and (91) at breakout box and chassis ground. Is each resistance greater than 10,000 ohms? | Yes | Go to A5 | | | | | | |
| | | No | Service short circuit. Remove breakout box. Reconnect all components. Rerun OBD Tests. | | | | | | |
| A5 | SOLENOID FUNCTIONAL TEST <ul style="list-style-type: none"> Ensure that the harness is disconnected at the transaxle. Install Transaxle tester at the solenoid body connector. Using tests outlined under Tester Instructions, Perform the SOLENOID VOLTAGE test. Note <ul style="list-style-type: none"> LED will turn "GREEN" when solenoid activates and turn "OFF" when deactivated LED will turn "RED" if activated solenoid is shorted to BAT+. LED will remain "OFF" if an activated solenoid is shorted to ground or no continuity. <ul style="list-style-type: none"> Does the solenoids activate? (LED GREEN) | Yes | Go to A6 | | | | | | |
| | | No | Go to A7 | | | | | | |
| A6 | TRANSAXLE DRIVE TEST <ul style="list-style-type: none"> Perform the Drive test. (Refer to page K2-25.) Does the vehicle upshift when commanded by the tester? | Yes | Replace the PCM. Reconnect all components. Return OBD Tests. If symptom still are present, refer to SYMPTOM TROUBLESHOOTING for shift concern. | | | | | | |
| | | No | Go to A7 | | | | | | |
| A7 | CHECK RESISTANCE OF SOLENOID Note <ul style="list-style-type: none"> Refer to the Transaxle Tester for terminal location. <ul style="list-style-type: none"> Bench/Drive switch in BENCH mode. Rotate gear selector switch to OHMS position. Connect ohmmeter negative lead to the SS1 jack and the positive lead to VPWR jack on tester. This is to test SS1. Record resistance. Connect ohmmeter negative lead to the SS2 jack and the positive lead to VPWR jack on tester. This is to test SS2. Are all the shift solenoids resistance between 12 and 22 ohms? | Yes | Go to A8 | | | | | | |
| | | No | Replace Solenoid Body assembly. Record and erase codes. Rerun OBD Tests. | | | | | | |
| A8 | CHECK SOLENOID FOR SHORT TO GROUND <ul style="list-style-type: none"> Check for continuity between BAT- (engine ground) and appropriate jack by using an ohmmeter or other low current tester (less than 200 milliamps). <table border="1" data-bbox="277 1745 621 1833"> <tr> <td>Solenoid</td> <td>Tester Jack</td> </tr> <tr> <td>SS1</td> <td>SS1/VPWR</td> </tr> <tr> <td>SS2</td> <td>SS2/VPWR</td> </tr> </table> <ul style="list-style-type: none"> Connection should show infinite resistance (no continuity). Is there continuity? | Solenoid | Tester Jack | SS1 | SS1/VPWR | SS2 | SS2/VPWR | Yes | Replace Solenoid Body assembly. Record and erase codes. Rerun OBD Tests. |
| | | Solenoid | Tester Jack | | | | | | |
| SS1 | SS1/VPWR | | | | | | | | |
| SS2 | SS2/VPWR | | | | | | | | |
| No | Refer to SYMPTOM TROUBLESHOOTING. | | | | | | | | |

Pinpoint test B

| DIAGNOSTIC TROUBLE CODE NO.P1711, P0712, P0713, P1783 | | | |
|--|--|-----|--|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, TFT, SIGNAL RETURN • Powertrain Control Module (PCM) | | |
| [TROUBLESHOOTING HINTS] | | | |
| Engine: Cooling Electrical: Battery, Wiring Harness Transaxle: Internal Transaxle Components, Cooling, Fluid | | | |
| STEP | INSPECTION | | ACTION |
| B1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the solenoid body connector is fully seated, terminals are fully engaged in the connector and in good condition before proceeding. • Have the items been checked? | Yes | Go to B2 |
| | | No | Perform checks. Erase DTCs and rerun OBD Tests. |
| B2 | CHECK ELECTRICAL SIGNAL OPERATION <ul style="list-style-type: none"> • Key OFF. Caution <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. <ul style="list-style-type: none"> • Disconnect solenoid body connector. • Using a mirror, inspect both ends of the connector for damaged or pushed out pins, corrosion, loose wires, and missing or damaged seals. • Refer to connector schematic and table of solenoid body. (Refer to page K2–143) • Connect VOM/DVOM positive test lead to TFT circuit and negative test lead to SIG RTN circuit of the solenoid body connector. • VOM/DVOM ON 20 Volt scale. • Key ON. (engine OFF). • Is the voltage between 4.50 and 5.25 volts? | Yes | Go to B6 |
| | | No | Go to B3. |
| B3 | CHECK CONTINUITY OF TFT AND SIG RTN CIRCUITS <ul style="list-style-type: none"> • Key OFF. • Solenoid body connector disconnected. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as required. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2–143) • Measure resistance between PCM signal test pin (37) at the breakout box and signal pin at solenoid body connector. • Measure resistance between PCM signal test pin (91) at the breakout box and signal pin at solenoid body transaxle harness connector. • Are both resistances less than 5.0 ohms? | Yes | Go to B4 |
| | | No | Service open circuit(s). Remove breakout box. Reconnect all components. Erase DTCs and rerun OBD Tests. |
| B4 | CHECK TFT CIRCUIT FOR SHORT TO VPWR AND GROUND <ul style="list-style-type: none"> • Key OFF. • Solenoid body connector disconnected. • Disconnect PCM, inspect for damaged or pushed out pins, corrosion, loose wires, etc. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2–143) • Measure resistance between TFT test pin 37 and Pins 71/97 at breakout box. • Measure resistance between TFT test Pin 37 and Pins 77/103 and 91 at breakout box. • Is each resistance greater than 10,000 ohms? | Yes | Go to B5 |
| | | No | Service short circuit. Remove breakout box. Reconnect all components. Erase DTCs and rerun OBD Tests. |

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | | | | | | | | | |
|---------------------|--|---------------------|--|------------------|---------|----------------|---------|--------------|--------|----------------|-------|-----------------|------|-----------------|-------|------------------|---------|-------------------|---------|-------------------|----------|-----|----------|
| B5 | <p>CHECK RESISTANCE OF TFT SENSOR/HARNES</p> <p>Note</p> <ul style="list-style-type: none"> Refer to the Transaxle Tester for Terminal Locations. Ensure that the emission harness is disconnected. Install tester to solenoid body connector. Set Bench/Drive switch to BENCH mode. Rotate Gear selector switch to OHMS Check position. Connect ohmmeter negative lead to -TFT jack and positive lead to +TFT jack no tester. Perform Tests 1 and 2. <p>Note</p> <ul style="list-style-type: none"> While performing Tests 1 and 2 observe resistances. Code P0713 is set if resistance value exceeds 869K ohms (OPEN circuit). Code P0712 is set if resistance value falls below 597 ohms (Short circuit). <p>TEST 1</p> <ul style="list-style-type: none"> Record resistance. Resistance should be approximately in the following ranges: Transaxle Fluid Temperature <table border="1" data-bbox="269 953 781 1278"> <thead> <tr> <th>Temperature °C {°F}</th> <th>Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td>-40—-20 {-40—-4}</td> <td>967—284</td> </tr> <tr> <td>-19—-1 {-3—31}</td> <td>284—100</td> </tr> <tr> <td>0—20 {32—58}</td> <td>100—37</td> </tr> <tr> <td>21—40 {59—104}</td> <td>37—16</td> </tr> <tr> <td>41—70 {105—158}</td> <td>16—5</td> </tr> <tr> <td>71—90 {159—194}</td> <td>5—2.7</td> </tr> <tr> <td>91—110 {195—230}</td> <td>2.7—1.5</td> </tr> <tr> <td>111—130 {231—266}</td> <td>1.5—0.8</td> </tr> <tr> <td>131—150 {267—302}</td> <td>0.8—0.54</td> </tr> </tbody> </table> <p>TEST 2</p> <ul style="list-style-type: none"> Check for intermittent short or open. If resistance was between 0.8K and 100K ohms, perform the following test. If transaxle is cold, run transaxle to warm it up. If transaxle is warm, allow transaxle to cool. Check TFT sensor resistance again. Compare resistance with internal resistance. Resistance should decrease if transaxle was warmed and should increase if transaxle was allowed to cool. If correct change in resistance occurs, repeat OBD Tests. Is the resistance within range? | Temperature °C {°F} | Resistance kΩ | -40—-20 {-40—-4} | 967—284 | -19—-1 {-3—31} | 284—100 | 0—20 {32—58} | 100—37 | 21—40 {59—104} | 37—16 | 41—70 {105—158} | 16—5 | 71—90 {159—194} | 5—2.7 | 91—110 {195—230} | 2.7—1.5 | 111—130 {231—266} | 1.5—0.8 | 131—150 {267—302} | 0.8—0.54 | Yes | Go to B6 |
| Temperature °C {°F} | Resistance kΩ | | | | | | | | | | | | | | | | | | | | | | |
| -40—-20 {-40—-4} | 967—284 | | | | | | | | | | | | | | | | | | | | | | |
| -19—-1 {-3—31} | 284—100 | | | | | | | | | | | | | | | | | | | | | | |
| 0—20 {32—58} | 100—37 | | | | | | | | | | | | | | | | | | | | | | |
| 21—40 {59—104} | 37—16 | | | | | | | | | | | | | | | | | | | | | | |
| 41—70 {105—158} | 16—5 | | | | | | | | | | | | | | | | | | | | | | |
| 71—90 {159—194} | 5—2.7 | | | | | | | | | | | | | | | | | | | | | | |
| 91—110 {195—230} | 2.7—1.5 | | | | | | | | | | | | | | | | | | | | | | |
| 111—130 {231—266} | 1.5—0.8 | | | | | | | | | | | | | | | | | | | | | | |
| 131—150 {267—302} | 0.8—0.54 | | | | | | | | | | | | | | | | | | | | | | |
| | | No | Replace solenoid body assembly. Record and erase DTCs. Repeat OBD Tests. | | | | | | | | | | | | | | | | | | | | |
| B6 | <p>CHECK TFT SENSOR FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> Check for continuity between -BAT (engine ground) and appropriate jack (-TFT and +TFT) appropriate wire with ohmmeter or other low current tester (less than 200 milliamps). Connection should show infinite resistance (no continuity). Is there continuity? | Yes | Replace solenoid body assembly. Repeat OBD Test. | | | | | | | | | | | | | | | | | | | | |
| | | No | Replace PCM. Erase DTCs and perform Drive Cycle Test. Rerun OBD Tests. If DTC are present and overtemp condition existed determine. If fluid is burnt, teardown unit and repair as required. Rerun OBD Test. | | | | | | | | | | | | | | | | | | | | |

Pinpoint test C

| DIAGNOSTIC TROUBLE CODE NO.P0741, P0743 | | |
|--|--|---|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, TCC, VPWR • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] | | |
| Engine: Performance, Cooling Electrical: Battery, Input Sensors, Wiring Harnesses, Brake Switch Transaxle: Internal Transaxle Components, Linkage, Cooling | | |
| STEP | INSPECTION | ACTION |
| C1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the solenoid body connector is fully seated, terminals are fully engaged in the connector and in good condition before preceeding. • Connect NGS tester. • Perform KOEO Test until Continuous Memory DTC have been displayed. • Perform the Drive Cycle Test mode. • Depress throttle to WOT and release. • Does vehicle enter Output State (DTM)? | Yes Remain in Output State (DTM). Go to C2 |
| | | No Depress thottle and release. If vehicle did not enter Output State (DTM), refer to section F3. |
| C2 | CHECK ELECTRICAL SIGNAL OPERATION Caution <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. <ul style="list-style-type: none"> • Disconnect solenoid body connector. • Using a mirror, inspect both ends of the connector for damaged or pushed out pins, corrosion, loose wires, and missing or damaged seals. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Connect VOM/DVOM positive test lead to VPWR circuit and negative test lead to solenoid circuit of the solenoid body connector. • VOM/DVOM ON 20 Volt scale. • While observing DVOM, depress and release throttle to cycle solenoid output ON and OFF. • Does the suspected solenoid output voltage change at least 0.5 volt? | Yes Go to C5 |
| | | No Go to C3 |
| C3 | CHECK CONTINUITY OF SOLENOID SIGNAL AND VPWR HARNESS CIRCUITS <ul style="list-style-type: none"> • Key OFF. • Solenoid body connector disconnected. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as required. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Measure resistance between PCM signal pin (54) at the breakout box and signal test pin at solenoid body connector. • Measure resistance between PCM test pin (71/97) at the breakout box and VPWR pin at solenoid body connector. • Is each resistance less than 5.0 ohms? | Yes Go to C4 |
| | | No Service open circuit(s). Remove breakout box. Reconnect all components. Rerun OBD Tests. |

| STEP | INSPECTION | | ACTION | | | | |
|----------|--|----------|--|-----|-------------|-----|---------------------------------|
| C4 | <p>CHECK SOLENOID HARNESS FOR SHORTS TO POWER AND GROUND</p> <ul style="list-style-type: none"> • Key OFF. • Breakout box installed, PCM disconnected. • Solnoid body connector disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Measure resistance between PCM signal test pin (54) and Test Pin (71/97) at the breakout box. • Measure resistance between PCM signal test pin (54) and test pins (77/103) and (91) at breakout box and chassis ground. • Is each resistance greater than 10,000 ohms? | Yes | Go to C5 | | | | |
| | | No | Service short circuit. Remove breakout box. Reconnect all components. Rerun OBD Tests. | | | | |
| C5 | <p>SOLENOID FUNCTIONAL TEST</p> <ul style="list-style-type: none"> • Emission harness disconnected at transaxle. • Install Transaxle tester at the solenoid body connector. • Using tests outlined under Tester Instructions Perform the SOLENOID VOLTAGE test. <p>Note</p> <ul style="list-style-type: none"> • LED will turn "GREEN" when solenoid activates and turn "OFF" when deactivated. LED will turn "RED" if activated solenoid is shorted to BAT+. • LED will remain "OFF" if an activated solenoid is shorted to ground or no continuity. <ul style="list-style-type: none"> • Does the solenoid activate? (LED GREEN) | Yes | Go to C6 | | | | |
| | | No | Go to C7 | | | | |
| C6 | <p>TRANSAXLE DRIVE TEST</p> <ul style="list-style-type: none"> • Perform the Drive Cycle Test as outlined in Transaxle Tester manual. • Does the TCC active when commanded by the tester? • Does the engine RPM drop? | Yes | Replace PCM. Erase DTCs and perform Drive Cycle Test. Rerun OBD Tests. If symptom are still present, refer to SYMPTOM TROUBLE-SHOOTING for torque converter concern. | | | | |
| | | No | Go to C7 | | | | |
| C7 | <p>CHECK RESISTANCE OF SOLENOID</p> <p>Note</p> <ul style="list-style-type: none"> • Refer to the Transaxle Tester for terminal location. • Set Bench/Drive switch to Bench mode. • Rotate gear select switch to Ohms Check position. • Connect ohmmeter negative lead to TCC jack and positive lead to VPWR jack on tester. • Record resistance. • Is resistance between 12.5—19.0 ohms? | Yes | Go to C8 | | | | |
| | | No | Replace solenoid body assembly. | | | | |
| C8 | <p>CHECK SOLENOID FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> • Check for continuity between BAT- (engine ground) and appropriate jack with and ohmmeter or other low current tester (less than 200 milliamps). <table border="1" data-bbox="284 1627 792 1717"> <tr> <td>Solenoid</td> <td>Tester Jack</td> </tr> <tr> <td>TCC</td> <td>TCC VPWE</td> </tr> </table> <ul style="list-style-type: none"> • Connection should show infinite resistance (no continuity). • Is there continuity? | Solenoid | Tester Jack | TCC | TCC VPWE | Yes | Replace solenoid body assembly. |
| Solenoid | Tester Jack | | | | | | |
| TCC | TCC VPWE | | | | | | |
| | | No | Refer SYMPTOM TROUBLE SHOOTING to diagnose torque converter clutch diagnosis. | | | | |

Pinpoint test D

| DIAGNOSTIC TROUBLE CODE NO.P1705, P0707, P0708 | | |
|---|--|--|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, TR switch, Signal Return • Powertrain Control Module (PCM) • Starter Circuits, Backup Circuits | |
| [TROUBLESHOOTING HINTS] Engine: Starter, Starter Relay Electrical: Battery, Ignition Switch, Wiring Harness Transaxle: Internal Transaxle Components, Linkage | | |
| STEP | INSPECTION | ACTION |
| D1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the TR switch connector is fully seated, terminals are fully engaged in the connector and in good condition before preceeding. • Verify shift linkage adjustment in D range. • Key OFF. • Apply parking brake. • Place transaxle in N position. • Verify that TR Switch Alignment Tool or equivalent fits in the appropriate slots. • Is TR switch proper adjusted? | Yes Remove tools. Go to D2 |
| | | No Adjust TR switch as outlined under Transaxle assembly. After adjustments place selector lever in P position. Erase DTCs and rerun OBD Tests. |
| D2 | CHECK ELECTRICAL SIGNAL OPERATION <ul style="list-style-type: none"> • Key OFF. Caution <ul style="list-style-type: none"> • Do not attempt to pry on TR switch connector. Depress tab and pull up on wiring harness. <ul style="list-style-type: none"> • Disconnect TR switch connector. • Using a mirror, inspect both end of the connector for damaged or pushed out pins, corrosion, loose wires and missing or damaged seals. • Refer to connector schematic of TR switch. (Refer to page K2-143) • Connect a VOM/DVOM positive test lead to TR signal circuit and negative test lead to signal return (SIGRTN) circuit of TR switch connector. • Place VOM on 20 volt scale. • Key ON. (engine OFF). • Is voltage between 4.75 and 5.25 volts? | Yes Go to D5 |
| | | No Go to D3 |
| D3 | CHECK CONTINUITY OF TR SWITCH HANESS CIRCUITS <ul style="list-style-type: none"> • Key OFF. Caution <ul style="list-style-type: none"> • Do not attempt to pry on TR switch connector. Depress tab and pull up on wiring harness. <ul style="list-style-type: none"> • Disconnect TR switch connector. • Inspect for damaged or pushed out pins, corrosion, loose wires, etc. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as required. • Install breakout box, leave PCM disconnected. • Refer to connector of TR switch. (Refer to page K2-143) • Measure resistance between PCM test pin (91) at the breakout box and SIG RTN circuit at the TR switch connector • Measure resistance between PCM test pin (64) at the breakout box and TR signal circuit at the TR switch connector • Is each resistance less than 5.0 ohms? | Yes Go to D4 |
| | | No Service open circuit(s). Remove breakout box. Reconnect all components. Erase codes. Rerun OBD Tests. |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|-------------------------|-------------------|-------------|-------------------------|-----------------------------|-----------|-------|------------------|-----------|------------------------|-------|------------------|-----------|------------------------|-----|------------------------|-----------|------------------------|---|-----|-----------|---|-----|-----|-----------|---|----|----|-----------|--|
| D4 | <p>CHECK TR SWITCH CIRCUIT FOR SHORTS TO POWER AND GROUND</p> <ul style="list-style-type: none"> • Key OFF. • Breakout box installed, PCM disconnected. • TR switch connector disconnected. • Refer to connector of TR switch. (Refer to page K2-143) • Measure resistance between PCM test pin (64) and PCM test pin (71/97), (77/103), and (91) at the breakout box. • Measure resistance between PCM test pin (64) at the breakout box and chassis ground. • Is each resistance greater than 10,000 ohms? | Yes Go to D5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | No Service short circuit. Remove breakout box. Reconnect all components. Erase codes. Rerun OBD Tests. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D5 | <p>CHECK TR SWITCH RESISTANCE</p> <ul style="list-style-type: none"> • Disconnect TR switch connector. • Connect MLPS Harness Adapter to TR switch and Transaxle Tester. • Install MLPS Overlay onto Transaxle Tester. • Using procedure provide with tester, verify switch resistive functions in all positions. <table border="1" data-bbox="293 730 768 1010"> <thead> <tr> <th rowspan="2">Selector Lever Position</th> <th colspan="2">Resistance (ohms)</th> <th rowspan="2">Range Volts</th> </tr> <tr> <th>min</th> <th>max</th> </tr> </thead> <tbody> <tr> <td>P</td> <td>3,770</td> <td>4,607</td> <td>3.97—4.85</td> </tr> <tr> <td>R</td> <td>1,304</td> <td>1,593</td> <td>3.24—3.96</td> </tr> <tr> <td>N</td> <td>660</td> <td>807</td> <td>2.55—3.11</td> </tr> <tr> <td>D</td> <td>361</td> <td>442</td> <td>1.88—2.30</td> </tr> <tr> <td>2</td> <td>190</td> <td>232</td> <td>1.23—1.51</td> </tr> <tr> <td>1</td> <td>78</td> <td>95</td> <td>0.61—0.75</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Are the resistive value within specifications? | Selector Lever Position | Resistance (ohms) | | Range Volts | min | max | P | 3,770 | 4,607 | 3.97—4.85 | R | 1,304 | 1,593 | 3.24—3.96 | N | 660 | 807 | 2.55—3.11 | D | 361 | 442 | 1.88—2.30 | 2 | 190 | 232 | 1.23—1.51 | 1 | 78 | 95 | 0.61—0.75 | Yes If you are here as a result of No VREF (D2), replace PCM, then Go to D6 |
| | | | Selector Lever Position | Resistance (ohms) | | Range Volts | | | | | | | | | | | | | | | | | | | | | | | | | | |
| min | max | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P | 3,770 | 4,607 | 3.97—4.85 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | 1,304 | 1,593 | 3.24—3.96 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N | 660 | 807 | 2.55—3.11 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D | 361 | 442 | 1.88—2.30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 190 | 232 | 1.23—1.51 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 78 | 95 | 0.61—0.75 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No Replace TR swithc and adjust. Erase DTCs and rerun OBD Tests. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D6 | <p>CHECK PARK/NEUTRAL CIRCUITS OF TR SWITCH</p> <ul style="list-style-type: none"> • Using the procedures outlined in the tester manual check the Park/Neutral circuits of TR switch in all gear positions. • Monitor the status light on the tester for proper indications. <table border="1" data-bbox="293 1276 768 1587"> <thead> <tr> <th colspan="3">Park/Neutral Circuit</th> </tr> <tr> <th>Terminal</th> <th>Selector Lever Position</th> <th>A Good Switch Will Indicate</th> </tr> </thead> <tbody> <tr> <td rowspan="6">33 and 32</td> <td>P</td> <td>Less than 5 ohms</td> </tr> <tr> <td>R</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>N</td> <td>Less than 5 ohms</td> </tr> <tr> <td>D</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>2</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>1</td> <td>Greater than 100K ohms</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Do the Park/Neutral circuits operate properly and only in the proper gear position? | Park/Neutral Circuit | | | Terminal | Selector Lever Position | A Good Switch Will Indicate | 33 and 32 | P | Less than 5 ohms | R | Greater than 100K ohms | N | Less than 5 ohms | D | Greater than 100K ohms | 2 | Greater than 100K ohms | 1 | Greater than 100K ohms | Yes Service as required. Go to D7 | | | | | | | | | | | |
| | | Park/Neutral Circuit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminal | Selector Lever Position | A Good Switch Will Indicate | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 33 and 32 | P | Less than 5 ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | R | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | N | Less than 5 ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | D | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No Replace TR switch and adjust. Erase DTCs and rerun OBD Tests. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| STEP | INSPECTION | ACTION | | | | | | | | | | | | | | | | | | | |
|-------------------|---|-------------------------------|--|--|----------|-------------------------|-----------------------------|-------------------|---|------------------------|---|------------------|---|------------------------|---|------------------------|---|------------------------|---|------------------------|---|
| D7 | <p>CHECK REVERSE/BACK-UP LIGHT CIRCUIT OF TR SWITCH</p> <ul style="list-style-type: none"> Using the procedures outlined in the tester manual, check the Reverse/Back-up light circuits of TR switch in all gear positions. Monitor the status light on the tester for proper indications. <table border="1" data-bbox="224 380 699 688"> <thead> <tr> <th colspan="3">Reverse/Back-up Light Circuit</th> </tr> <tr> <th>Terminal</th> <th>Selector Lever Position</th> <th>A Good Switch Will Indicate</th> </tr> </thead> <tbody> <tr> <td rowspan="6">298 and 140</td> <td>P</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>R</td> <td>Less than 5 Ohms</td> </tr> <tr> <td>N</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>D</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>2</td> <td>Greater than 100K ohms</td> </tr> <tr> <td>1</td> <td>Greater than 100K ohms</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Do the Reverse/Back-up circuits operate properly and only in the proper gear positions? | Reverse/Back-up Light Circuit | | | Terminal | Selector Lever Position | A Good Switch Will Indicate | 298 and 140 | P | Greater than 100K ohms | R | Less than 5 Ohms | N | Greater than 100K ohms | D | Greater than 100K ohms | 2 | Greater than 100K ohms | 1 | Greater than 100K ohms | <p>Yes Service as required.</p> <hr/> <p>No Replace TR switch and adjust. Erase DTCs and rerun OBD Tests.</p> |
| | | Reverse/Back-up Light Circuit | | | | | | | | | | | | | | | | | | | |
| Terminal | Selector Lever Position | A Good Switch Will Indicate | | | | | | | | | | | | | | | | | | | |
| 298 and 140 | P | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | |
| | R | Less than 5 Ohms | | | | | | | | | | | | | | | | | | | |
| | N | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | |
| | D | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | |
| | 2 | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | |
| | 1 | Greater than 100K ohms | | | | | | | | | | | | | | | | | | | |

Pinpoint test E

| | | |
|--|--|---|
| DIAGNOSTIC TROUBLE CODE NO. P1747, P1746 | | |
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, EPC, EPCPWR • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] Engine: Performance Electrical: Battery, Input Sensors, Wiring Harness Transaxle: Internal Transaxle Components, Cooling | | |
| STEP | INSPECTION | ACTION |
| E1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the solenoid body connector is fully seated, terminals are fully engaged in the connector and in good condition before proceeding. • Connect NGS tester. • Perform KOEO Test until Continuous Memory DTC have been displayed. • Perform the Drive Cycle Test mode. • Depress throttle to WOT and release. • Does vehicle enter Output State (DTM)? | Yes Remain in Output State (DTM). Go to E2 |
| | | No Depress thottle and release. If vehicle did not enter Output State (DTM), refer to section F3. |
| E2 | CHECK ELECTRICAL SIGNAL OPERATION <p>Caution</p> <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. • Disconnect solenoid body connector. • Using a mirror, inspect both ends of the connector for damaged or pushed out pins, corrosion, loose wires, and missing or damaged seals. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Connect VOM/DVOM positive test lead to VPWR circuit and negative test lead to the suspect solenoid circuit of the transaxle vehicle harness connector. • VOM/DVOM ON 20 Volt scale. • While observing DVOM, depress and release throttle to cycle solenoid output ON and OFF. • Does the suspected solenoid output voltage change at least 0.5 volt? | Yes Go to E5 |
| | | No Go to E3 |
| E3 | CHECK CONTINUITY OF SOLENOID SIGNAL AND VPWR HARNESS CIRCUIT <ul style="list-style-type: none"> • Key OFF. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of the solenoid body. (Refer to page K2-143) • Measure resistance between PCM Test Pin (71/97) at breakout box and EPC PWR circuit at the solenoid body connector. • Measure resistance between PCM Test Pin (81) at the breakout box and EPC solenoid signal pin at the solenoid body connector. • Is each resistance less than 5.0 ohms? | Yes Go to E4 |
| | | No Service open circuit. Remove breakout box. Reconnect all components. Erase DTCs and rerun OBD Tests. |

| STEP | INSPECTION | | ACTION | | | | |
|----------|---|----------|--|-----|-------------|-----|---|
| E4 | CHECK HARNESS FOR SHORT TO POWER OR GROUND <ul style="list-style-type: none"> • Key OFF. • Breakout box installed, PCM disconnected. • Solenoid body connector disconnected. • Refer to connector schematic and table of the solenoid body. (Refer to page K2-143) • Measure resistance between EPC solenoid circuit test pin (81) and test pin (71/97) at the breakout box. • Measure resistance between EPC solenoid circuit test pin (81) and test pins (77/103), (91) at the breakout box. • Is each resistance greater than 10,000 ohms? | Yes | Go to E5 | | | | |
| | | No | Service short circuit. Remove breakout box. Reconnect all components. Erase DTCs and rerun OBD Tests. | | | | |
| E5 | TRANSAXLE FUNCTIONAL TEST <ul style="list-style-type: none"> • Solenoid body connector disconnected. • Install Transaxle Tester. • Set Bench/Drive switch to Drive mode. • Rotate Gear selector switch to 1st Gear position. • Using tests outlined in the manual perform the EPC function test. • Observe line pressure on the gauge while depressing the EPC switch. (VEHICLE MUST BE RUNNING) • Does the EPC (LED GREEN) activate and line pressure drop when the EPC switch is depressed? | Yes | Replace PCM. Rerun OBD Tests. | | | | |
| | | No | Go to E6 | | | | |
| E6 | CHECK RESISTANCE OF SOLENOID <p>Note</p> <ul style="list-style-type: none"> • Be sure that tester power is OFF or damage to ohmmeter may result. • Connect ohmmeter negative lead to VPWR jack and positive lead to EPC jack on tester. This is to test EPC solenoid. • Record resistance. • Is the resistance between 3.75—5.92 ohms? | Yes | Go to E7 | | | | |
| | | No | Replace solenoid body assembly. Record and erase DTCs. Rerun OBD tests. | | | | |
| E7 | CHECK SOLENOID FOR SHORT TO GROUND <ul style="list-style-type: none"> • Check for continuity between BAT- (engine ground) and appropriate jack with an ohmmeter or other low current tester (less than 200 milliamps). <table border="1" data-bbox="201 1310 542 1398"> <tr> <td>Solenoid</td> <td>Tester jack</td> </tr> <tr> <td>EPC</td> <td>EPC VPWR</td> </tr> </table> <ul style="list-style-type: none"> • Connection should show infinite resistance (no continuity). • Is there continuity? | Solenoid | Tester jack | EPC | EPC VPWR | Yes | Replace Solenoid Body Assembly. Record and erase DTCs. Rerun OBD Tests. |
| Solenoid | Tester jack | | | | | | |
| EPC | EPC VPWR | | | | | | |
| | | No | Refer to QUICK DIAGNOSIS CHART to diagnose EPC concerns under engagement and/or Shift diagnosis. | | | | |

Pinpoint test F

| DIAGNOSTIC TROUBLE CODE NO.P0715 | | |
|--|--|---|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: • Transaxle Wiring Harness, TSS, SIGNAL RETURN • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] | | |
| Electrical: Battery, Input Sensors, Wiring Harness Transaxle: Internal Transaxle Components | | |
| STEP | INSPECTION | ACTION |
| F1 | ELECTRONIC DIAGNOSTICS • Check the turbine shaft speed sensor (TSS) connector is fully seated, terminal are fully engaged in the connector and in good condition before proceeding. • Have the items above been checked? | Yes Go to F2 |
| | | No Perform the checks. Erase DTCs and rerun OBD Tests. |
| F2 | CHECK CONTINUITY OF TSS HARNESS CIRCUIT • Key OFF. Caution • Do not pry on connector. Pull up on harness. • Disconnect TSS connector. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. • Install breakout box, leave PCM disconnected. • Refer to connector schematic of TSS. (Refer to page K2-143) • Measure resistance between PCM test pin (84) at the breakout box and the TSS (+) circuit at the TSS connector. • Measure resistance between PCM test pin (91) at the breakout box and the TSS (-) circuit at the TSS connector and chassis/battery ground. • Is each resistance less than 5.0 ohms? | Yes Go to F3 |
| | | No Service open circuit. Remove breakout box. Reconnect all components. Rerun OBD Tests. |
| F3 | CHECK TSS CIRCUIT FOR SHORT TO POWER AND GROUND • Key OFF. • Disconnect TSS connector. • Breakout box installed, PCM disconnected. • Measure resistance between PCM test pins (84), (91) and test pins (71/97) at breakout box. • Measure resistance between PCM test pins (84), (91), (71/97) and test pins (77/103) at breakout box. • Is each resistance greater than 10,000 ohms? | Yes Go to F4 |
| | | No Service short circuit. Remove breakout box. Reconnect all components. Rerun OBD Tests. |
| F4 | TSS FUNCTIONAL TEST Caution • Do not pry on connector. Pull up on harness. • Disconnect vehicle harness at TSS. • Install transaxle tester on to TSS. • Connect voltmeter positive lead to (+) TSS and negative lead to (-) TSS jacks. Set voltmeter to 20 volts AC. • Perform drive cycle test. Monitor voltmeter. • Does the voltage increase with an increase in vehicle speed? | Yes Replace PCM. |
| | | No Go to F5 |

| STEP | INSPECTION | ACTION | | | | | | |
|------|--|--|-------------|-----|------|--|------|---|
| F5 | <p>CHECK RESISTANCE OF TSS</p> <p>Note</p> <ul style="list-style-type: none"> Refer to the LA4A-EL Transaxle Tester for Terminal Locations <ul style="list-style-type: none"> Connect ohmmeter negative lead to +TSS jack and positive lead to -TSS jack on tester. This is to test TSS. Record resistance. Is the resistance between 140—290 ohms? | Yes Go to F6 | | | | | | |
| | | No Replace TSS. Rerun TSS functional test. | | | | | | |
| F6 | <p>CHECK SENSOR FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> Check for continuity between BAT- (engine ground) and appropriate jack with an ohmmeter or other low current tester (less than 200 milliamps). <table border="1" data-bbox="196 583 537 674"> <tr> <td>Solenoid</td> <td>Tester jack</td> </tr> <tr> <td>TSS</td> <td>+TSS</td> </tr> <tr> <td></td> <td>-TSS</td> </tr> </table> <ul style="list-style-type: none"> Connection should show infinite resistance (no continuity). Is there continuity? | Solenoid | Tester jack | TSS | +TSS | | -TSS | Yes Replace TSS. Rerun function test. |
| | Solenoid | Tester jack | | | | | | |
| TSS | +TSS | | | | | | | |
| | -TSS | | | | | | | |
| | No Go to F7 | | | | | | | |
| F7 | <p>CHECK TSS MAGNETISM</p> <ul style="list-style-type: none"> Remove TSS from transaxle. Place TSS against a metal surface to which a magnet would stick. The TSS should be magnetized and stick to the metal surface. Does the TSS stick? | Yes Go to F8 | | | | | | |
| | | No Replace TSS. Rerun functional test. | | | | | | |
| F8 | <p>CHECK EXCITER WHEEL</p> <ul style="list-style-type: none"> Remove TSS. With a remote starter, start and stop until a tooth of the exciter wheel is visible through the TSS hole. Continue until all 4 teeth have been visibly inspected. Were all teeth present? | Yes Replace TSS. Rerun functional test. | | | | | | |
| | | No Service or replace as required. Then rerun function test. | | | | | | |

Pinpoint test G

| | | |
|---|---|---|
| DIAGNOSTIC TROUBLE CODE NO.P1788, P1789 | | |
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, 3-2T/CCS, VPWR • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] | | |
| Engine: Performance Electrical: Battery, Input Sensors, Wiring Harness Transaxle: Internal Transaxle Components | | |
| STEP | INSPECTION | ACTION |
| G1 | ELECTRONIC DIAGNOSTICS <ul style="list-style-type: none"> • Check the solenoid body connector is fully seated, terminals are fully engaged in the connector and in good condition before preceeding. • Connect NGS tester. • Perform KOEO Test until Continuous Memory DTC have been displayed. • Perform the Drive Cycle Test mode. • Depress throttle to WOT and release. • Does vehicle enter Output State (DTM)? | Yes Remain in Output State (DTM). Go to G2 |
| | | No Depress thottle and release. If vehicle did not enter Output State (DTM), refer to section F3. |
| G2 | CHECK ELECTRICAL SIGNAL OPERATION <p>Caution</p> <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. • Disconnect solenoid body connector. • Using a mirror, inspect both ends of the connector for damaged or pushed out pins, corrosion, loose wires, and missing or damaged seals. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Connect VOM/DVOM positive test lead to VPWR circuit and negative test lead to the suspect solenoid circuit of the transaxle vehicle harness connector. • VOM/DVOM ON 20 Volt scale. • While observing DVOM, depress and release throttle to cycle solenoid output ON and OFF. • Does the suspected solenoid output voltage change at least 0.5 volt? | Yes Go to G5 |
| | | No Go to G3 |
| G3 | CHECK CONTINUITY OF SOLENOID SIGNAL AND VPWR HARNESS CIRCUIT <ul style="list-style-type: none"> • Key OFF. • Disconnect Powertrain Control Module (PCM). Inspect for damaged or pushed out pins, corrosion, loose wires, etc. • Install breakout box, leave PCM disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Measure resistance between PCM Test Pin (71/97) at breakout box and SOL PWR circuit at the solenoid body connector. • Measure resistance between PCM Test Pin (102) at the breakout box and 3-2T/CCS solenoid signal pin at the solenoid body connector. • Is each resistance less than 5.0 ohms? | Yes Go to G4 |
| | | No Service open circuit. Remove breakout box. Reconnect all components. Erase DTCs and rerun OBD Tests. |

| STEP | INSPECTION | ACTION | | | | |
|---|--|--|-------------|----------|------------------|--|
| G4 | CHECK HARNESS FOR SHORT TO POWER OR GROUND <ul style="list-style-type: none"> • Key OFF. • Breakout box installed, PCM disconnected. <p>Caution</p> <ul style="list-style-type: none"> • Removing the solenoid body connector by prying with a screwdriver will damage the connector. Remove the solenoid body connector by pushing on the wire tab and pulling on the wiring harness. | Yes Go to G5 | | | | |
| | <ul style="list-style-type: none"> • Solenoid body connector disconnected. • Refer to connector schematic and table of solenoid body. (Refer to page K2-143) • Measure resistance between 3-2T/CCS solenoid circuit test pin (102) and test pin (71/97) at the breakout box. • Measure resistance between 3-2T/CCS solenoid circuit test pin (102) and test pins (77/103), (91) at the breakout box. • Is each resistance greater than 10,000 ohms? | No Service short circuit. Remove breakout box. Reconnect all componets. Rerun OBD Tests. | | | | |
| G5 | TRANSAXLE FUNCTIONAL TEST <ul style="list-style-type: none"> • Solenoid body connector disconnected. • Install Transaxle Tester. • Set Bench/Drive switch to Drive mode. • Rotate Gear selector switch to 1st Gear position. • Does the 3-2T/CCS (LED GREEN) deactivate when the 3-2T/CCS switch is depressed? • When the 3-2T/CCS switch is released does engine braking occur and the 3-2T/CCS engage (LED OFF)? | Yes Replace PCM. Inspect PCM power relay, service as required. Rerun OBD Tests. | | | | |
| | | No Go to G6 | | | | |
| G6 | CHECK RESISTANCE OF SOLENOID <p>Note</p> <ul style="list-style-type: none"> • Be sure that tester power is OFF or damage to ohmmeter may result. <ul style="list-style-type: none"> • Connect ohmmeter negative lead to VPWR jack and positive lead to 3-2T/CCS jack on tester. This is to test 3-2T/CCS solenoid. • Record resistance. • Is the resistance between 3.75—5.92 ohms? | Yes Go to G7 | | | | |
| | | No Replace solenoid body assembly. Record and erase DTCs. Rerun OBD Tests. | | | | |
| G7 | CHECK SOLENOID FOR SHORT TO GROUND <ul style="list-style-type: none"> • Check for continuity between BAT- (engine ground) and appropriate jack with and ohmmeter or other low current tester (less than 200milliamps). <table border="1" data-bbox="203 1444 545 1533"> <thead> <tr> <th>Solenoid</th> <th>Tester Jack</th> </tr> </thead> <tbody> <tr> <td>3-2T/CCS</td> <td>3-2T/CCS VPWR</td> </tr> </tbody> </table> | Solenoid | Tester Jack | 3-2T/CCS | 3-2T/CCS VPWR | Yes Replace solenoid body assembly. Record and erase DTCs. Rerun OBD Tests. |
| | Solenoid | Tester Jack | | | | |
| 3-2T/CCS | 3-2T/CCS VPWR | | | | | |
| <ul style="list-style-type: none"> • Connection should show infinite resistance (no continuity). • Is there continuity? | No Refer to QUICK DIAGNOSIS CHART to diagnose. 3-2T/CCS concerns under shift diagnosis. | | | | | |

Pinpoint test TB

| DIAGNOSTIC TROUBLE CODE NO.P1780 | | |
|---|--|--|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, O/D OFF switch, O/D OFF indicator light • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] | | |
| Electrical: Battery, Input Sensors, Wiring Harness Transaxle: Linkages | | |
| STEP | INSPECTION | ACTION |
| TB1 | DIAGNOSTIC TROUBLE CODE P1780 DTC P1780 indicates the O/D OFF switch was not cycled during Key On Engine Running (KOER) Self-Test. Possible Cause: <ul style="list-style-type: none"> – O/D OFF switch damaged or switch not cycled during self-test – Shorted harness – Damaged PCM – Open harness or fuse Did O/D OFF switch cycled during KOER Self-Test? | Yes Go to TB2 |
| | | No Return KOER Self-Test to cycle O/D OFF switch |
| TB2 | CHECK O/D OFF SWITCH CIRCUIT FOR VOLTAGE <ul style="list-style-type: none"> • Key OFF • Disconnect PCM Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary <ul style="list-style-type: none"> • Install breakout box, leave PCM disconnected • Key on, engine off • Measure voltage between test pin (29) and test pins (24/77) at the breakout box while cycling the O/D OFF switch several times Does the voltage cycle? | Yes Replace PCM Remove breakout box Return OBD Tests |
| | | No Go to TB3 |
| TB3 | CHECK HARNESS CIRCUIT(S) FOR SHORT TO GROUND <ul style="list-style-type: none"> • Key OFF • Breakout box installed, PCM disconnected • Disconnect O/D OFF switch Inspect both ends of the connector for damaged or pushed out pins, moisture, corrosion, loose wires, etc. Service as necessary <ul style="list-style-type: none"> • Measure resistance between test pin (29) and test pins (24/77) at the breakout box Is the resistance greater than 10,000 ohms? | Yes Go to TB4 |
| | | No Service short circuit Return KOER Self-Test |
| TB4 | CHECK CONTINUITY OF O/D OFF SWITCH HARNESS <ul style="list-style-type: none"> • Key OFF • Breakout box connected, PCM disconnected Measure the resistance between keypower at the fuse panel and power side of O/D OFF switch vehicle harness connector (ohmmeter negative probe) Is resistance less than 5.0 ohms? | Yes Go to TB5 |
| | | No Service open circuit Remove breakout box Reconnect all components Return OBD Tests |
| TB5 | CHECK HARNESS CIRCUIT FOR SHORT TO POWER <ul style="list-style-type: none"> • Key OFF • Breakout box installed, PCM disconnected Measure resistance between test pin (29) and test pins (71/97) at the breakout box Is each resistance greater than 10,000 ohms? | Yes Replace damaged switch Remove breakout box Reconnect all components Return OBD Tests |
| | | No Service short circuit Remove breakout box Reconnect all components Return OBD Tests |


| STEP | INSPECTION | ACTION | |
|------|---|--------|---|
| TB6 | O/D OFF INDICATOR LIGHT ALWAYS ON <ul style="list-style-type: none"> • Key ON, engine off • Cycle O/D OFF switch Does O/D OFF indicator light turn on and off? | Yes | Concern may be intermittent. Go to Pinpoint Test Step Z1 (Refer to section F3) |
| | | No | Go to TB7 |
| TB7 | CHECK FOR SHORT TO GROUND IN O/D OFF INDICATOR LIGHT CIRCUIT <ul style="list-style-type: none"> • Key OFF • Disconnect PCM Inspect both ends for damaged or pushed out pins, moisture, corrosion, loose wires, etc. Service as necessary <ul style="list-style-type: none"> • Key ON, engine off Does O/D OFF indicator light remain on? | Yes | Repair short to ground between bulb and test pin (79) Verify O/D OFF indicator light turns on and off |
| | | No | O/D OFF indicator light turns off when PCM is disconnected Replace PCM |
| TB8 | O/D OFF INDICATOR LIGHT NEVER ON <ul style="list-style-type: none"> • Run Key On Engine Running (KOER) Self-Test Is DTC P1780 present? | Yes | Service DTC P1780 Go to TB1 |
| | | No | Go to TB9 |
| TB9 | CHECK CONTINUITY OF O/D OFF INDICATOR LIGHT CIRCUIT <ul style="list-style-type: none"> • Key OFF • Breakout box installed • Key ON, engine off • Measure the voltage between test pin (79) and test pins (24/76) at the breakout box Is the voltage reading greater than 2.0 volts? | Yes | Replace PCM Cycle (O/D OFF switch) checking operation of O/D OFF indicator light |
| | | No | Check indicator bulb and fuse If OK, open is in the wiring between the ignition switch and test pin (79) at the harness connector Repair as necessary |

Pinpoint test DP

| DIAGNOSTIC TROUBLE CODE NO.P0500, P1500 | | |
|---|--|--|
| DESCRIPTION | This Pinpoint Test is intended to diagnose the following components: <ul style="list-style-type: none"> • Transaxle Wiring Harness, Vehicle Speedometer Sensor, VPWR • Powertrain Control Module (PCM) | |
| [TROUBLESHOOTING HINTS] | | |
| Electrical: Battery, Input Sensors, Wiring Harness Transaxle: Linkages | | |
| STEP | INSPECTION | ACTION |
| DP1 | DTC P0500: CHECK CONTINUITY OF VEHICLE SPEEDOMETER SENSOR HARNESS CIRCUIT DTC P0500 indicates the VSS input signal has been detected out of Self-Test range. Note <ul style="list-style-type: none"> • Delayed engagement or no vehicle movement may be caused by a transaxle concern. Harsh shifts and/or erratic speedometer may be caused by a failed speedometer or an open or intermittent ground within the instrument panel on vehicles with electronic readout. Possible causes: <ul style="list-style-type: none"> – Open in VSS (+)/VSS (-) harness circuit. – Short to GND or SIG RTN in VSS (+)/VSS (-) harness circuit – Short to PWR in VSS (+)/VSS (-) harness circuit – Damaged VSS – Damaged PCM • Key OFF. • Disconnect PCM. Inspect for damaged or pushed out pins, corrosion, loose wires, etc. Service as necessary. • Install breakout box, PCM disconnected. • Disconnect VSS. • Measure resistance between test pin 58 [VSS (+)] at the breakout box and VSS (+) circuit at the VSS vehicle harness connector. • Measure resistance between test pin 33 [VSS (-)] at the breakout box and VSS (-) circuit at the VSS vehicle harness connector. Is each resistance less than 5.0 ohms? | Yes Go to DP2 |
| | | No Service open in harness circuit Remove breakout box Reconnect all components Complete PCM Reset to clear DTCs Run VSS Drive Cycle in DP5 to verify repair |
| DP2 | CHECK VEHICLE SPEEDOMETER SENSOR HARNESS CIRCUITS FOR SHORTS TO GROUND, SIG RTN AND POWER <ul style="list-style-type: none"> • Key OFF • VSS disconnected. • Breakout box installed, PCM disconnected. • Measure resistance between test pin (58) [VSS (+)] and test pins (51), (103) (PWR GND), (33) [VSS (-)], (91) (SIG RTN) and (71) (VPWR) at the breakout box. • Measure resistance between test pins (33) [VSS (-)] and (71) (VPWR) at the breakout box. Is each resistance greater than 500 ohms? | Yes Go to DP3 |
| | | No Service short circuit Remove the breakout box Reconnect all components Complete PCM Reset to clear DTCs Run VSS Drive Cycle in DP5 to verify repair |
| DP3 | CHECK VEHICLE SPEEDOMETER SENSOR RESISTANCE <ul style="list-style-type: none"> • Key OFF. • VSS disconnected. • Measure the resistance of the VSS. Is resistance between 190 and 250 ohms? | Yes Remove breakout box Replace the PCM Reconnect the VSS Run VSS Drive Cycle in DP5 to verify repair |
| | | No Replace the VSS Remove breakout box Reconnect the PCM Run VSS Drive Cycle in DP5 to verify repair |

| STEP | INSPECTION | ACTION |
|------|---|---|
| DP4 | DTC P1500: VISUAL INSPECTION DTC P1500 indicates the VSS input signal was intermittent. Possible causes: <ul style="list-style-type: none"> - Intermittent VSS connections - Intermittent open in VSS harness circuit(s) - Intermittent short in VSS harness circuit(s) - Damaged VSS - Damaged PCM • Key OFF. • Visually inspect the VSS and VSS harness circuits for any potential failures. Use the following check list for reference: <ul style="list-style-type: none"> - Loose VSS connector - Pushed out VSS connector pins - Damaged VSS wiring harness insulation - Incorrect harness routing - Incorrect VSS mounting Did the visual inspection reveal a potential failure? | Yes Service fault as necessary Complete PCM Reset to clear DTCs Run VSS Drive Cycle in DP5 to verify repair |
| | | No Reconnect all components Unable to duplicate or identify fault at this time Go to Pinpoint Test Step Z1 in section F3 with the following data: the VSS PID, if available, the VSS check list and list of possible concern |
| DP5 | VEHICLE SPEEDOMETER SENSOR DRIVE CYCLE TEST <ul style="list-style-type: none"> • Warm engine to operating temperature. • Perform the VSS Drive Cycle at least three times as outlined below: AUTOMATIC TRANSAXLE: <ul style="list-style-type: none"> • Place gear selector in DRIVE range. • Obey all local traffic laws. • Accelerate heavily to 35 mph. • Coast down to an idle and stop the vehicle. • Shut the engine off. • After the drive cycle is completed, retrieve and record any Continuous Memory DTCs. Address the DTCs in Section 5, Powertrain Diagnostic Trouble Code Charts. • If no DTCs are generated, testing is complete. | |


Solenoid body



VEHICLE HARNESS CONNECTOR PIN LOCATIONS

| Pin | Description | PCM Test Pin |
|-----|-----------------|--------------|
| 1 | TCC Power | 71, 97 |
| 2 | Signal return | 91 |
| 3 | TFT Signal | 37 |
| 4 | SS1 Signal | 27 |
| 5 | Solenoid Power | 71, 97 |
| 6 | SS2 Signal | 1 |
| 7 | TCC Signal | 54 |
| 8 | EPC Signal | 81 |
| 9 | EPC Power | 71, 97 |
| 10 | 3-2T/CCS Signal | 102 |


TR switch



VEHICLE HARNESS CONNECTOR PIN LOCATIONS


| Pin | Circuit | Circuit Function |
|-----|-------------|-------------------------------|
| 1 | 66H (BK/BL) | Sensor Signal Return |
| 2 | 12X (BK/R) | Starter Motor Output |
| 3 | 108 (R/Y) | Backup Lamp Output |
| 4 | — | NOT USED |
| 5 | 41W (BK/Y) | Power |
| 6 | — | NOT USED |
| 7 | 817 (R/BK) | Transaxle Range Signal |
| 8 | 18X (GN) | Starter interrupt Relay Input |
| 9 | — | NOT USED |
| 10 | — | NOT USED |
| 11 | — | NOT USED |

SCHEMATICS



TR SWITCH

TSS sensor



SIG RTN Test Pin 91

TSS Test Pin 84

SERVICE POINTS

OUTLINE

Transaxle Range (TR) Switch

- If a malfunction occurs in the wiring of the TR or TR switch, the powertrain control module (PCM) cannot determine the range position, and shifting may be abnormal in D, 2, and 1 ranges. There may not be a shift to fourth gear, and all shifts will be firm.

Transaxle Fluid Temperature (TFT) Sensor

- If a malfunction occurs in the TFT sensor, the problem will be the torque converter clutch operation and EPC pressure control.

Brake Switch

- If the brake switch is always ON, the torque converter clutch will not engage at less than 1/3 throttle.
- If the brake switch is always OFF, the torque converter clutch will not disengage when the brake is applied.

Turbine Shaft Speed Sensor (TSS)

- If a malfunction occurs in the TSS, the torque converter clutch will not engage, and shifting may be harsh. There may not be a shift to fourth gear and engine braking may operate in second and third gear.

Vehicle Speedometer Sensor

- If a malfunction occurs in the vehicle speedometer sensor, shifting may be abnormal, the torque converter will not engage.
- There may not be all shift to fourth gear.

Electronic Pressure Control (EPC) Solenoid

- If the EPC is always ON, at maximum current line pressure will be at minimum.
- If the EPC is always OFF, the line pressure will be maximum and there will be harsh engagements or harsh shift.

Shift Solenoid No.1 and No.2 (SS1, SS2)

- If a malfunction occurs in the SS1 or SS2, shifting may be abnormal.

3–2 Timing/Coasting Clutch Solenoid (3–2T/CCS)

- If the 3–2T/CCS is always ON, the engine braking will not operate (except in fourth gear) and will delay 3–2, 4–2 downshifts.
- If the 3–2T/CCS is always OFF, the engine braking will operate in second/third gear (D range) and abnormal 3–2 downshifts and harsh 4–3 downshift.

Torque Converter Clutch (TCC) Solenoid

- If the TCC is always ON, the torque converter clutch will not disengage.
- If the TCC is always OFF, the torque converter clutch will not engage.

Engine Coolant Temperature (ECT) Sensor

- If a malfunction occurs in the ECT, the TCC will always be OFF.

Distributor Ignition (DI) System

- If a malfunction occurs in the DI, the torque converter clutch will not engage, and shifting may be abnormal.

Magnetic Clutch

- If the magnetic clutch is always ON, the line pressure will be slightly low with the A/C OFF.
- If the magnetic clutch is always OFF, the line pressure will be slightly high with the A/C ON.


Mass Air Flow Sensor (MAF)

- If a malfunction occurs in the MAF, shifting and torque converter clutch operation will be abnormal.


Throttle Position (TP) Sensor


- If a malfunction occurs in the TP, shifting and torque converter clutch operation will be abnormal.

B-1b FS ATX ■ EC-AT CONTROL SYSTEM (2/4)
■ ENGINE CONTROL SYSTEM (2/4)




| Terminal | Wire Color | Component / Description |
|----------|------------|-------------------------|
| 13 | * | L/B |
| 14 | * | L/B |
| 15 | * | L/B |
| 16 | * | L/B |
| 17 | * | L/B |
| 18 | * | L/B |
| 19 | * | L/B |
| 20 | * | L/B |
| 21 | * | L/B |
| 22 | * | L/B |
| 23 | * | L/B |
| 24 | * | L/B |
| 25 | * | L/B |
| 26 | * | L/B |
| 27 | * | L/B |
| 28 | * | L/B |
| 29 | * | L/B |
| 30 | * | L/B |
| 31 | * | L/B |
| 32 | * | L/B |
| 33 | * | L/B |
| 34 | * | L/B |
| 35 | * | L/B |
| 36 | * | L/B |
| 37 | * | L/B |
| 38 | * | L/B |
| 39 | * | L/B |
| 40 | * | L/B |
| 41 | * | L/B |
| 42 | * | L/B |
| 43 | * | L/B |
| 44 | * | L/B |
| 45 | * | L/B |
| 46 | * | L/B |
| 47 | * | L/B |
| 48 | * | L/B |
| 49 | * | L/B |
| 50 | * | L/B |
| 51 | * | L/B |
| 52 | * | L/B |
| 53 | * | L/B |
| 54 | * | L/B |
| 55 | * | L/B |
| 56 | * | L/B |
| 57 | * | L/B |
| 58 | * | L/B |
| 59 | * | L/B |
| 60 | * | L/B |
| 61 | * | L/B |
| 62 | * | L/B |
| 63 | * | L/B |
| 64 | * | L/B |
| 65 | * | L/B |
| 66 | * | L/B |
| 67 | * | L/B |
| 68 | * | L/B |
| 69 | * | L/B |
| 70 | * | L/B |
| 71 | * | L/B |
| 72 | * | L/B |
| 73 | * | L/B |
| 74 | * | L/B |
| 75 | * | L/B |
| 76 | * | L/B |
| 77 | * | L/B |
| 78 | * | L/B |
| 79 | * | L/B |
| 80 | * | L/B |
| 81 | * | L/B |
| 82 | * | L/B |
| 83 | * | L/B |
| 84 | * | L/B |
| 85 | * | L/B |
| 86 | * | L/B |
| 87 | * | L/B |
| 88 | * | L/B |
| 89 | * | L/B |
| 90 | * | L/B |
| 91 | * | L/B |
| 92 | * | L/B |
| 93 | * | L/B |
| 94 | * | L/B |
| 95 | * | L/B |
| 96 | * | L/B |
| 97 | * | L/B |
| 98 | * | L/B |
| 99 | * | L/B |
| 100 | * | L/B |
| 101 | * | L/B |
| 102 | * | L/B |
| 103 | * | L/B |
| 104 | * | L/B |
| 105 | * | L/B |
| 106 | * | L/B |
| 107 | * | L/B |
| 108 | * | L/B |
| 109 | * | L/B |
| 110 | * | L/B |
| 111 | * | L/B |
| 112 | * | L/B |
| 113 | * | L/B |
| 114 | * | L/B |
| 115 | * | L/B |
| 116 | * | L/B |
| 117 | * | L/B |
| 118 | * | L/B |
| 119 | * | L/B |
| 120 | * | L/B |
| 121 | * | L/B |
| 122 | * | L/B |
| 123 | * | L/B |
| 124 | * | L/B |
| 125 | * | L/B |
| 126 | * | L/B |
| 127 | * | L/B |
| 128 | * | L/B |
| 129 | * | L/B |
| 130 | * | L/B |
| 131 | * | L/B |
| 132 | * | L/B |
| 133 | * | L/B |
| 134 | * | L/B |
| 135 | * | L/B |
| 136 | * | L/B |
| 137 | * | L/B |
| 138 | * | L/B |
| 139 | * | L/B |
| 140 | * | L/B |
| 141 | * | L/B |
| 142 | * | L/B |
| 143 | * | L/B |
| 144 | * | L/B |
| 145 | * | L/B |
| 146 | * | L/B |
| 147 | * | L/B |
| 148 | * | L/B |
| 149 | * | L/B |
| 150 | * | L/B |
| 151 | * | L/B |
| 152 | * | L/B |
| 153 | * | L/B |
| 154 | * | L/B |
| 155 | * | L/B |
| 156 | * | L/B |
| 157 | * | L/B |
| 158 | * | L/B |
| 159 | * | L/B |
| 160 | * | L/B |
| 161 | * | L/B |
| 162 | * | L/B |
| 163 | * | L/B |
| 164 | * | L/B |
| 165 | * | L/B |
| 166 | * | L/B |
| 167 | * | L/B |
| 168 | * | L/B |
| 169 | * | L/B |
| 170 | * | L/B |
| 171 | * | L/B |
| 172 | * | L/B |
| 173 | * | L/B |
| 174 | * | L/B |
| 175 | * | L/B |
| 176 | * | L/B |
| 177 | * | L/B |
| 178 | * | L/B |
| 179 | * | L/B |
| 180 | * | L/B |
| 181 | * | L/B |
| 182 | * | L/B |
| 183 | * | L/B |
| 184 | * | L/B |
| 185 | * | L/B |
| 186 | * | L/B |
| 187 | * | L/B |
| 188 | * | L/B |
| 189 | * | L/B |
| 190 | * | L/B |
| 191 | * | L/B |
| 192 | * | L/B |
| 193 | * | L/B |
| 194 | * | L/B |
| 195 | * | L/B |
| 196 | * | L/B |
| 197 | * | L/B |
| 198 | * | L/B |
| 199 | * | L/B |
| 200 | * | L/B |




















HYDRAULIC CIRCUIT



TRANSAXLE OVERHAUL

TRANSAXLE UNIT (DISASSEMBLY)

Preparation SST

| | | | |
|--|---|--|---|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly of transaxle</p> | <p>49 G019 038 Hanger, transaxle</p>  | <p>For disassembly of transaxle</p> |
| <p>49 UN01 087 Converter seal remover</p>  | <p>For removal of converter seal</p> | <p>49 0223 630B Puller, axle shaft</p>  | <p>For removal of seal</p> |
| <p>49 UN11 101 Threaded adapter</p>  | <p>For removal of seal</p> | <p>49 UN01 101 Jet plug remover</p>  | <p>For removal of cap</p> |
| <p>49 UN01 104 Servo cover remover/replacer</p>  | <p>For removal of servo cover</p> | <p>49 UN01 117 Actuator pin</p>  | <p>For removal of oil filter recirculation seal</p> |
| <p>49 UN01 118 Collet</p>  | <p>For removal of oil filter recirculation seal</p> | <p>49 8501 631A Attachment</p>  | <p>For removal of oil pump</p> |
| <p>49 UN01 100 Oil pump removal bolts</p>  | <p>For removal of oil pump</p> | <p>49 UN01 119 Lube tube seal replacer</p>  | <p>For removal of lube tube seal</p> |
| <p>49 UN01 099 Servo plug replacer/needle replacer</p>  | <p>For removal of bearing</p> | <p>49 UN01 098 Needle bearing remover/replacer/receiver</p>  | <p>For removal of bearing</p> |
| <p>49 UN01 122 Threaded drawbar</p>  | <p>For removal of bearing</p> | <p>—</p> | <p>—</p> |


Precaution**General notes:**

1. Disassemble the transaxle in a clean area (dust proof work space) to prevent the entry of dust into the mechanism.
2. Inspect the individual transaxle components in accordance with the QUICK DIAGNOSIS CHART during disassembly. (Refer to page K2–68.)
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts look alike; organize them so they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when a clutch or brake band is burnt or when the ATF has degenerated.

Cleaning notes:

1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvents before disassembly.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and verify that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.


Components



- 1. Torque converter
Inspection page K2-175
- 2. ATF dipstick and oil filler tube
- 3. Vehicle speedometer sensor
Inspection section K1
- 4. Turbine shaft speed sensor
Inspection section K1

- 5. Control valve body cover
- 6. Control valve body
Disassembly / Inspection page K2-201
Assembly page K2-209
On-vehicle
removal / installation page K2- 45


Components



- 1. Converter housing
- 2. Final drive and differential
Disassembly / Inspection /
Assembly page K2-212
- 3. Chain cover pan
- 4. Drive chain


- 5. #13 driven sprocket thrust bearing
- 6. Driven sprocket
- 7. #12 driven sprocket bearing
- 8. #11 driven sprocket shim
- 9. #18 driven sprocket bearing

Components




- | | |
|--|--|
| 1. Reverse/fourth gear sun gear Disassembly / Inspection / Assembly page K2-199 | 7. Turbine shaft |
| 2. Reverse/fourth gear carrier assembly Disassembly / Inspection / Assembly page K2-199 | 8. Forward/coasting/direct clutch cylinder Disassembly / Inspection / Assembly page K2-184 |
| 3. Low-intermediate ring gear | 9. Thrust washer |
| 4. Low-intermediate carrier assembly | 10. Direct clutch shell assembly |
| 5. Reverse/fourth gear sun gear and low-intermediate carrier assembly Disassembly / Inspection / Assembly page K2-180 | 11. Reverse clutch drum Disassembly / Inspection / Assembly page K2-184 |
| 6. Forward one way clutch and low-intermediate sun gear Disassembly / Inspection / Assembly page K2-180 | 12. Retaining ring |
| | 13. Low one way clutch plate |
| | 14. Low one way clutch |
| | 15. Wave spring |
| | 16. Low/reverse clutch |
| | 17. Low/reverse clutch piston assembly |
| | 18. Low/reverse piston seal (Inner) |


Components




- | | |
|---|---|
| <ul style="list-style-type: none"> 1. Transaxle case 2. 2/4 band servo piston, rod, and spring 3. Oil pump and pump support Disassembly / Inspection / Assembly page K2-176 4. 2/4 band 5. Transaxle range switch Inspection page K2- 24 6. Manual valve detent lever assembly 7. Thermostatic oil level valve | <ul style="list-style-type: none"> 8. Thermal valve bracket 9. Manual control lever and shaft 10. Differential seal 11. Parking pawl acturing cam 12. Parking cam actuator lever 13. Parking pawl and shaft 14. Manual valve detent lever actuating rod 15. Oil filter and seal 16. Recirculating regulator exhaust seal |
|---|---|

**Disassembly Procedure**


1. Install the SSTs or equivalent on the transaxle case. Position a drain pan under the transaxle.




2. Remove the drain plug from the transaxle case. Allow the transaxle to drain completely.




3. Remove the torque converter from the transaxle. Drain the fluid from converter.




4. Remove the oil pump shaft by pulling it from the end of the turbine shaft.




5. Remove the turbine shaft speed sensor mounting bolt.




6. Pull the sensor from the bore.




7. Remove the O-ring seal. Discard the O-ring seal.




8. Remove the two transaxle range switch mounting bolts.



9. Pull the transaxle range switch from the shaft.




10. Use the **SSTs** or equivalent to remove the RH and LH differential seals. Check the seal contact surfaces on the LH joint shaft and the RH drive shaft for excessive wear.


**Note**

- Do not remove the stator support bolts behind the impeller hub seal.


11. Use the **SSTs** or equivalent to remove the torque converter impeller hub seal. Check the seal contact surface on the torque converter impeller hub for excessive wear.




12. Remove the oil filler tube mounting bolt.




13. Pull the tube from the bore.



14. Remove the tube seal grommet.




15. Remove the vehicle speedometer sensor bolt.




16. Remove the sensor from the bore.

17. Remove the O-ring seal from the sensor. Discard the O-ring seal.




18. Remove the fourteen control valve body cover-to-transaxle case bolts.

19. Pull the cover from the transaxle case.
 20. Separate the cover from the gasket. Discard the gasket.
 21. Inspect the vent and grommet.




22. Remove the twelve control valve body assembly mounting bolts shown.

**Caution**


- Do not allow the loose manual valve to become damaged.

23. Pull the control valve body slightly away from the transaxle case. Disconnect the Z-link from the manual valve.


**Caution**

- Do not pull on the connector wires or use a hammer on the connector.


24. Squeeze the retainer tabs of the solenoid body connector and remove the connector from the bore in the case.
25. If seepage is found around the solenoid body connector area, inspect the O-ring for damage and discard it.



26. Remove the control valve body from the transaxle and store it in a clean location.
27. Remove the thermostatic oil level valve bracket bolt. Remove the bracket. Remove the filter from the forward clutch circuit.
28. Pull the thermostatic oil level valve from the transaxle case.




29. If equipped, remove the cap from the 2/4 servo assembly by using the **SST**. Discard the cap.




30. Install a nut with an integral washer onto the forcing bolt of the servo cover remover/replacer tool with a permanent thread sealer. This nut and washer will aid in the installation of the cover.

Warning


- The servo cover is under high spring pressure.




31. Attach the **SST** or equivalent to the pump.




32. Screw in the bolt to compress the servo cover and remove the retaining ring.
 33. Remove the **SST**.




34. Remove the servo cover from the bore.




35. Remove the 2/4 servo assembly.




36. Position the transaxle so the converter housing faces up.
 37. Remove the twenty converter housing-to-transaxle case bolts.




38. Separate the converter housing from the transaxle case.
39. Remove the split flange gasket from the converter housing. Discard the split flange gasket.




40. Remove the #15 differential bearing.
41. Remove the #14 differential bearing shim (selective fit) from the differential case.
42. Remove the speedometer drive gear from the differential case.




43. Remove the final drive carrier/differential case.



44. Remove the front part of the chain cover by unsnapping it from the rear part.




45. Remove the #13 driven sprocket thrust bearing.



Note

- The thrust washer may be attached to the converter housing.


46. Remove the #10 drive sprocket thrust washer (selective fit) from the drive sprocket.




Warning

- Wear gloves as personal protection from the sharp chain and sprocket teeth.


47. Lift the drive chain and both sprockets together from the transaxle case.




48. Separate the drive chain from the sprockets.




49. Remove the rear part of the chain cover (with the magnet attached) from the transaxle case. Check the magnet for excessive metal particles.




50. Remove the #12 driven sprocket bearing and the #11 driven sprocket shim (selective fit) from the transaxle case.



51. Unsnap the socket end of the manual detent lever actuating rod from the parking cam actuator.




52. Unsnap the socket end of the manual detent lever actuating rod from the manual detent lever.




Note

- Thrust bearing may be attached to the drive sprocket.


53. Remove the #9 reverse/fourth gear ring gear thrust bearing.




54. Remove the reverse/fourth gear carrier (with captured #8 reverse/fourth gear carrier thrust bearing).



55. Remove the reverse/fourth gear sun gear and shell assembly.




56. Remove the #7 reverse/fourth gear sun gear thrust bearing.




57. Remove the low-intermediate ring gear.

Note


- Thrust bearing may be attached to the low-intermediate ring gear.




58. Remove the #6 low-intermediate carrier thrust bearing.




59. Remove the low-intermediate carrier.




60. Remove the #5 low-intermediate sun gear thrust bearing and the forward one-way clutch and low-intermediate sun gear assembly.




61. Remove the #4 turbine shaft thrust bearing.




62. Remove the turbine shaft.




63. Remove the assembly of the forward/coasting/direct cylinder and reverse clutch drum.




64. Remove the #1 pump support thrust bearing.




65. Use the **SSTs** or equivalent to remove the oil filter recirculation seal. Discard the recirculation seal.




66. Remove the oil filter and seal assembly and discard.




67. Remove the low one-way clutch retaining ring.




68. Remove the low one-way clutch thrust plate.




69. Remove the low one-way clutch assembly.




70. Remove the low/reverse wave spring.




71. Remove the low/reverse clutch plates.




72. Use a screwdriver to remove the return spring retaining ring.




73. Remove the return spring.




74. Pull the piston from the bore by using a rotating motion.




75. Remove the outer seal from the piston. Discard the outer seal.




76. Remove the inner seal from the piston. Discard the inner seal.



77. Position the transaxle with the oil pump facing up. Remove the nine oil pump assembly mounting bolts.




78. Install the **SSTs** or equivalent and remove the oil pump assembly from the transaxle case.




Note

- Use a piece of wire to secure the 2/4 band so that it is not damaged by being stretched.


79. Slide the 2/4 band from the case.




80. Remove the fluid cooler line fitting. Inspect the fluid cooler line fitting seal.




81. Remove the final drive ring gear retaining ring.




82. Lift the final drive ring gear from the housing. Inspect gear and housing lug teeth.




83. Remove the drive chain/differential lube tube mounting bolt.




84. Wiggle and pull the drive chain/differential lube tube from the housing and discard.




85. Use a screwdriver to remove the final drive lube tube from the case and discard.




86. Use the **SST** or equivalent to remove the final drive lube tube seal from the case.




87. Remove the parking pawl spring.




88. Remove the manual control outer lever bolt.
89. Remove the manual control outer lever.




90. Remove the manual control shaft nut.




91. Remove the parking lock cam, cam actuator, spacer, and manual control lever shaft.




92. Remove the parking pawl shaft retainer and bolt.



93. Use an O-ring pick or magnet to remove the parking pawl shaft.




94. Remove the parking pawl and return spring.




Caution

- Do not damage the case bore during seal removal.

95. Use a screwdriver to remove the manual control shaft seal.




96. Remove the manual valve actuator rod (Z-link).



Caution

- Do not damage the transaxle case sealing surface.


97. Protect the case and use a pair of side cutters to remove the manual valve detent lever roll pin. Discard the roll pin.




Caution

- Do not damage the transaxle case sealing surface.

98. Protect the case and use a pair of side cutters to remove the manual valve detent lever shaft roll pin. Discard the roll pin.




99. Remove the manual valve detent lever and shaft from the case.



Caution


- Do not damage the transaxle case during seal removal.

100. Use a screwdriver to remove the manual valve detent lever shaft seal from the case. Discard the seal.




101. Remove the line pressure port plug from the transaxle case.

102. Remove the fluid cooler line fitting. Inspect the fluid cooler line fitting seal.





103. If it is necessary to replace #18 driven sprocket bearing in the transaxle case, install the **SSTs**.




104. Remove the bearing by using the **SSTs**.

TORQUE CONVERTER

**Preparation
SST**

| | | | |
|--|---|---|---|
| <p>49 UN01 123</p> <p>End play checking tool</p>  | <p>For inspection of torque converter</p> | <p>49 UN01 120</p> <p>End play checking tool sleeve</p>  | <p>For inspection of torque converter</p> |
|--|---|---|---|


The torque converter is welded together and cannot be disassembled.



Inspection


Torque converter one-way clutch check

1. Place the torque converter on a workbench with the impeller hub facing up.
2. Place a pick in a slot on the bottom of the stator.
3. While holding the bottom of the stator, rotate the inner race of the one-way clutch.
4. If the inner race rotates in both directions during this check, the stator one-way clutch is slipping.




Torque converter pump insert check

1. Install the oil pump shaft into the torque converter.
2. Verify that the insert can hold 14 N·m {1.5 kgf·m, 10 ft·lbf} of torque.
3. If the insert cannot hold the specified torque, replace the torque converter.
4. Remove the oil pump shaft.



Turbine torque check



1. Install the **SSTs** into the turbine splines in the torque converter.
2. Attach a torque wrench and determine the torque required to turn the turbine.
3. If the torque exceeds 8 N·m {0.8 kgf·m, 6 ft·lbf}, replace the torque converter.



Torque converter end play check


1. Install the **SSTs** into the turbine splines in the torque converter.
2. Attach a dial indicator to the **SSTs**.
3. Zero the needle of the dial indicator.
4. Pull up on the **SSTs** and observe the dial indicator reading.
5. If the end play exceeds 1.27 mm {0.05 in}, replace the torque converter.

OIL PUMP Preparation SST

| | | | |
|---|-----------------------------------|--|---------------------------------|
| <p>49 UN01 108</p> <p>Gauge bar</p>  | <p>For inspection of oil pump</p> | <p>49 UN01 107</p> <p>Pump alignment pins</p>  | <p>For assembly of oil pump</p> |
|---|-----------------------------------|--|---------------------------------|


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




N·m {kgf·m, ft·lbf}

- | | |
|-----------------------|------------------------------|
| 1. Seal ring | |
| 2. Pump support | |
| 3. Gasket | |
| 4. Separator plate | |
| 5. Drive gear insert | |
| 6. Drive gear | Inspection page K2-177 |
| 7. Driven gear | Inspection page K2-177 |
| 8. Oil pump seal ring | |
| 9. Oil pump body | |




Inspection

1. Use the **SST** and a depth micrometer to measure the clearance between each gear and the pump body face.
2. The allowable clearance for each gear is **0.040—0.080 mm {0.0016—0.0031 in}**. If the clearance exceeds the specification, replace the oil pump assembly.
3. Check for oil blockage. (Refer to page K2–9.)




Assembly Procedure

1. Install the driven gear in the oil pump body with the identification dot facing down.




2. Install the drive gear and insert in the oil pump body.




Note

- Use the bolt hole next to TSS sensor hole and the bolt hole opposite it for alignment pins.


3. Install the **SST** or equivalent in the oil pump body, with the alignment pins in the holes as shown.




4. Install the separator plate and new gasket on the oil pump body.




5. Install the pump support on the oil pump body.



6. Install and tighten the four pump support-to-oil pump body bolts to **13 N·m {1.3 kgf·m, 10 ft·lbf}** and remove the **SST** (alignment pins). Install and tighten the two remaining mounting bolts to **13 N·m {1.3 kgf·m, 10 ft·lbf}**.




7. Install a new seal ring on the oil pump body. Ensure that the white stripe is visible all around the pump.




Note

- Ensure that the scarf cut seals are overlapped correctly.



8. Install seven new seal rings on the pump support.




9. Install the oil pump drive shaft.
10. Use a torque wrench to rotate the oil pump. The maximum rotating torque is **0.3 N·m {3.1 kgf·m, 2 in·lbf}**.

11. Remove the torque wrench and oil pump drive shaft.
12. If the rotating torque exceeds the specification, disassemble and inspect the oil pump for contamination or improper end clearance.

FORWARD ONE-WAY CLUTCH, LOW-INTERMEDIATE SUN GEAR ASSEMBLY, AND LOW-INTERMEDIATE CARRIER ASSEMBLY


Preparation

SST

| | | |
|----------------|---|------------------------------------|
| 49 UN01 102 |  | For installation of sprag assembly |
| Sprag replacer | | |

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




1. Retaining ring
2. Coasting clutch hub
3. One-way clutch outer race
4. Sprag assembly
5. End cap

6. Retaining washer
7. Retaining ring
8. Low-intermediate sun gear
9. Low-intermediate carrier

Disassembly note page K2-181

Inspection page K2-181




Disassembly Note
End cap

Note

- Note the position of the end caps. They are of different thicknesses and are not interchangeable.


Separate the sprag assembly and end caps from the outer race.



Inspection


Low-intermediate carrier assembly

Inspect the low-intermediate carrier assembly pinion gear end play. End play should be between 0.15—0.72 mm {0.006—0.028 in}.



Assembly procedure


1. Install the retaining ring.




Note

- The tabs on the retaining washer should be facing down.


2. Install the retaining washer.




3. Identify the thick and thin end caps.



4. Assemble the one-way clutch, sprag assembly and end caps.




5. Use the **SST** or equivalent to install the sprag assembly and end caps in the outer race.




Caution

- **Lube grooves face up (away from sun gear).**

6. Flip the outer race and sprag assembly over and install on the sun gear.




7. Install the coasting clutch hub.



Note

- The end of the retaining ring should point towards the coasting clutch hub.










8. Install the coasting clutch hub retaining ring.



9. Check the operation of the forward one-way clutch with the sun gear facing up. It should work as follows:
- When the sun gear is rotated in a clockwise direction, it should not rotate the outer race.
 - When the sun gear is rotated in a counterclockwise direction, it should rotate the outer race.


FORWARD/COASTING/DIRECT CLUTCH CYLINDER AND REVERSE CLUTCH DRUM

Preparation SST


| | | | |
|--|---|--|---|
| <p>49 G019 0A7A</p> <p>Compressor set, return spring</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> | <p>49 G019 025</p> <p>Body B (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch</p> |
| <p>49 G019 026</p> <p>Plate (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> | <p>49 G019 027</p> <p>Attachment A (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> |
| <p>49 G019 029</p> <p>Nut (Part of 49 G019 0A7A)</p>  | <p>For disassembly / assembly of coasting clutch and reverse clutch</p> | <p>49 UN01 095</p> <p>Coasting clutch piston seal protector</p>  | <p>For installation of forward clutch piston</p> |
| <p>49 UN01 096</p> <p>Seal sizer</p>  | <p>For installation of F/C/D clutch cylinder hub seal</p> | <p>49 UN01 094</p> <p>Reverse clutch piston seal protector</p>  | <p>For installation of reverse clutch piston</p> |
| <p>49 L019 001</p> <p>Bolt</p>  | <p>For removal / installation of snap ring</p> | <p>—</p> | <p>—</p> |

Disassembly / Inspection / Assembly

1. Disassemble as shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Retaining ring Disassembly note page K2-186 2. Reverse clutch hub 3. Reverse clutch drum 4. Direct clutch hub/shell 5. Forward/coasting/direct clutch cylinder 6. Reverse clutch seal rings 7. Direct clutch thrust washer 8. F/C/D clutch cylinder hub seal 9. Retaining ring 10. Pressure plate 11. Friction plates Inspect for wear and burning 12. Steel plates 13. Retaining ring Disassembly note page K2-186 14. Return spring assembly Inspection page K2-187 15. Reverse clutch piston 16. Retaining ring 17. Pressure plate 18. Friction plates Inspect for wear and burning 19. Steel plates | <ol style="list-style-type: none"> 20. Retaining ring Disassembly note page K2-186 21. Return spring assembly Inspection page K2-187 22. Direct clutch piston Disassembly note page K2-187 23. Direct clutch piston inner seal 24. Direct clutch piston outer seal 25. Retaining ring 26. Pressure plate 27. Friction plates Inspect for wear and burning 28. Steel plates 29. Pressure plate 30. Friction plates Inspect for wear and burning 31. Steel plates 32. Retaining ring Disassembly note page K2-187 33. Return spring assembly Inspection page K2-187 34. Forward clutch piston 35. Forward clutch piston outer seal 36. Forward clutch piston inner seal 37. Coasting clutch piston |
|--|--|



Disassembly Note


Retaining ring (Reverse clutch hub)

Support the forward/coasting/direct clutch cylinder on a block so that the reverse clutch hub is facing up and the direct clutch hub/shell is not touching the workbench.




Retaining ring (Reverse clutch)

1. Use the **SSTs** or equivalent to compress the return spring assembly.




2. Remove the retaining ring.




Retaining ring (Direct clutch)

1. Use the **SST** or equivalent to compress the return spring assembly.




2. Remove the retaining ring.




Direct clutch piston

Remove the direct clutch piston by using external snapping pliers as shown in the figure.



Retaining ring (Forward and coasting clutch)

1. Use the **SSTs** or equivalent to compress the return spring assembly.




2. Remove the retaining ring.

Inspection


Springs

- Springs must be the same length.
- Springs must not be twisted.
- Springs must not be damaged.




Assembly procedure

1. Install a new inner forward clutch piston seal in the forward/coasting/direct clutch cylinder.




2. Install a new outer seal on the forward clutch piston.


3. Install the forward clutch piston in the forward/coasting/direct clutch cylinder.




4. Lubricate and install the coasting clutch piston in the SST.




5. Use the **SST** or equivalent to install the coasting clutch piston into the forward clutch piston.




6. Install the return spring assembly.




7. Use the **SST** or equivalent to compress the return spring assembly.




8. Install the retaining ring.
9. Remove the **SST**.



10. Install the forward and coasting clutch plates.




11. Install the forward clutch plate retaining ring (selective fit).




12. Use a feeler gauge to measure the clearance between the clutch plates and the forward clutch plate retaining ring. Make a second measurement on the opposite side. Average the two measurements to get the clearance.
13. The standard clearance is **0.50—1.09 mm {0.02—0.04 in}**. If the clearance is not within the specification, select and install the proper thickness retaining plate to obtain the standard clearance.

Retaining ring sizes are as follows:


| Thickness mm {in} |
|-------------------------|
| 1.28—1.38 {0.050—0.054} |
| 1.39—1.49 {0.055—0.059} |
| 1.52—1.62 {0.060—0.064} |
| 1.65—1.75 {0.065—0.069} |




14. Install the forward/coasting/direct clutch cylinder hub seal ring on the forward/coasting/direct clutch cylinder.




15. Install a new outer seal on the direct clutch piston.




16. Install a new inner piston seal in the forward/coasting/direct clutch cylinder.




17. Lubricate the seals and install the direct piston in the forward/coasting/direct clutch cylinder.




18. Install the return spring assembly.




19. Use the **SSTs** or equivalent to compress the return spring assembly.




20. Use a pair of snap ring pliers to install the retaining ring.
21. Remove the **SST**.



22. Install the direct clutch plates.



23. Install the direct clutch plate retaining ring (selective fit)




24. Measure the direct clutch clearance as follows:


- Install a dial indicator on the side of the forward/coasting/direct clutch cylinder and zero the needle on the pressure plate.
 - Use two picks to pull the pressure plate upward. Observe the dial indicator reading.
 - Make a second measurement on the opposite side. Average the two measurements to get the clearance.
25. The standard clearance is **0.52—1.12 mm {0.02—0.04 in}**. If the clearance is not within the specification, select and install the proper thickness retaining ring to obtain the standard clearance.

Retaining ring sizes are as follows:


| Thickness mm {in} |
|-------------------------|
| 1.28—1.38 {0.050—0.054} |
| 1.39—1.49 {0.054—0.06} |
| 1.52—1.62 {0.060—0.063} |
| 1.65—1.75 {0.064—0.068} |




26. Lubricate and install the reverse clutch piston in the **SST** or equivalent.




27. Use the **SST** or equivalent to install the reverse clutch piston with integral seals.




28. Install the return spring assembly.




29. Use the **SSTs** or equivalent to compress the return spring assembly.




30. Use a pair of snap ring pliers to install the retaining ring.
31. Remove the **SSTs**.



32. Install the reverse clutch plates.




33. Install the reverse clutch plate retaining ring (selective fit).



34. Use a feeler gauge to measure the clearance between the clutch plates and the reverse clutch plate retaining ring. Make a second measurement on the opposite side. Average the two measurements to get the clearance.
35. The standard clearance is **0.33—0.89 mm {0.01—0.04 in}**. If the clearance is not within the specification, select and install the proper thickness retaining ring to obtain the standard clearance.

Retaining ring sizes are as follows:


| Thickness mm {in} |
|-------------------------|
| 1.39—1.49 {0.055—0.059} |
| 1.53—1.63 {0.060—0.064} |
| 1.68—1.78 {0.066—0.070} |



Caution

- Tabs on direct clutch thrust washers must be seated in return spring assembly.


36. Install the direct clutch thrust washer on the forward/coasting/direct clutch cylinder with the tabs facing down.




Note


- Ensure that the scarf cut seals are overlapped correctly.

37. Install the two reverse clutch seal rings.




38. Support the forward/coasting/direct clutch cylinder on a block so that the direct clutch faces upward.







39. Install the direct clutch hub/shell on the forward/coasting/direct clutch cylinder.




40. Install the reverse clutch drum.




41. Install the reverse clutch hub.



42. Install the reverse clutch hub retaining ring.



43. Flip the assembly over. Use the **SST** to size the forward/coasting/direct clutch cylinder hub seal. Leave the seal sizer on until the assembly is installed in the case.



44. Lubricate the pump seal rings (#1–#7) with ATF.
45. Install the thrust bearing on a pump support.
46. Lower the forward/coasting/direct clutch cylinder and reverse clutch drum assembly on the oil pump as shown in the figure.


Warning

- **Wear eye protection when using compressed air.**

47. Apply compressed air 275 kPa {2.8 kgf/cm², 40 psi} to each clutch passage and listen for a dull thud sound when the clutch applies.
48. If a hissing sound occurs during the check, disassemble and locate the source of the leakage.
49. Lift the cylinder and drum assembly from the oil pump.


LOW ONE-WAY CLUTCH**Disassembly / Inspection / Assembly**

1. Disassemble as shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




1. Low one-way clutch inner race
2. Roller assembly

3. Low one-way clutch outer race

**Assembly Procedure****Note**


- The outer tabs of the roller assembly must be facing up.

1. Install the roller assembly into the outer race.

**Caution**

- **Inner race groove must be face up.**





2. Install the inner race with the groove facing up, using clockwise rotating motion.



3. Check the operation of the low one-way clutch as follows:
 - When the inner race is rotated in a clockwise direction, it should move freely.
 - When the inner race is rotated in a counterclockwise direction, it should lock to the outer race.


REVERSE/FOURTH GEAR RING GEAR, REVERSE/FOURTH GEAR CARRIER ASSEMBLY, AND CHAIN DRIVE

**Preparation
SST**






| | | | |
|--|---|--|---|
| <p>49 0223 630B</p> <p>Puller, axle shaft</p>  | <p>For removal of drive sprocket bearing/stator support bearing</p> | <p>49 UN01 124</p> <p>Shaft bearing remover</p>  | <p>For removal of drive sprocket bearing</p> |
| <p>49 S231 660</p> <p>Puller, needle bearing</p>  | <p>For removal of stator support bearing</p> | <p>49 F027 003</p> <p>Handle (Part of 49 F028 2A0)</p>  | <p>For installation of drive sprocket bearing</p> |

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- | | |
|---|--|
| <p>1. Reverse/fourth gear carrier assembly Inspection page K2-200</p> | <p>3. Reverse/fourth gear ring gear Inspect for wear</p> |
| <p>2. Bearing Disassembly Note page K2-200</p> | <p>4. Chain drive Inspect for excessive stretching, wear, or tight link(s)</p> |



Disassembly Note Bearing

1. If necessary, use the **SSTs** or equivalent to remove the drive sprocket bearing.
2. If necessary, use the **SSTs** or equivalent to remove the stator support bearing.


Inspection

Reverse/fourth gear carrier assembly


Inspect the Reverse/fourth gear carrier assembly pinion gear end play. End play should be between **0.15—0.72 mm {0.006—0.028 in}**.

Assembly Procedure

1. If removed, install the drive sprocket bearing on the **SST**.
2. If removed, use the **SSTs** or equivalent to install the drive sprocket bearing.



3. If removed, install the stator support bearing on the SST.




4. If removed, use the **SSTs** or equivalent to install the stator support bearing.

CONTROL VALVE BODY (DISASSEMBLY / INSPECTION)
Disassembly / Inspection


Caution

- Be especially careful when handling the control valve because it consists of the most precise and delicate parts of the transaxle.
- Neatly organize the removed parts so that similar parts do not get mixed up.
- Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.
- Wear eye protection when using compressed air to clean components.

1. Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.
2. Inspect all parts and repair or replace as necessary.




- | | |
|---------------------------|-------------------------------|
| 1. Bolt | 9. Bolt |
| 2. Solenoid body assembly | 10. Accumulator body assembly |
| 3. Solenoid gasket | 11. Gaskets |
| 4. Bolt | 12. Separator plate |
| 5. Pressure tap plate | 13. Valve body assembly |
| 6. Pressure tap gasket | 14. Gaskets |
| 7. Bolt | 15. Separator plate |
| 8. Detent lever | 16. Transfer plate |




Disassembly Procedure


1. Remove manual control valve from the valve body. Remove the two solenoid body assembly bolts. Remove the solenoid body assembly.




2. Remove the solenoid gasket from the accumulator body. Discard the solenoid gasket.




3. Remove the three pressure tap plate bolts. Remove the pressure tap plate.




4. Remove the gasket from the accumulator body assembly. Discard the gasket.




5. Remove the three valve body-to-transfer plate bolts. Remove the detent lever.



6. Remove the three accumulator body assembly bolts.



7. Remove the accumulator body, separator plate, and gaskets from the valve body assembly. Discard the gaskets.



8. Remove the valve body, separator plate and gaskets from the transfer plate. Discard the gaskets.


ACCUMULATOR BODY

Disassembly / Inspection / Assembly


Caution

- Each valve should slide out/in under its own weight.
- When a valve will not slide out under its own weight, depending on the valve, push it out with a wire or place the valve body open-side down and lightly tap it with a plastic hammer. Never scratch or otherwise damage a valve surface or bore.
- Do not drop or lose the valves or internal parts.
- Before assembly, make sure all parts are thoroughly clean.
- Apply ATF to all parts and bores.
- Note the proper direction of the valve and internal parts.
- Do not reuse any part that has been dropped.
- Wrap a screwdriver or rod with tape before using it to insert a valve.


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.



- | | |
|------------------------------------|----------------------------------|
| 1. Retaining plate | 10. Forward accumulator spring |
| 2. Low/reverse accumulator springs | Inspection page K2-206 |
| Inspection page K2-206 | 11. Forward accumulator piston |
| 3. Low/reverse accumulator piston | 12. Spring retaining plate |
| 4. Retaining plate | 13. Pull-in control valve spring |
| 5. 2/4 accumulator plug | Inspection page K2-206 |
| Disassembly note page K2-206 | 14. Pull-in control valve |
| 6. 2/4 accumulator piston | 15. Valve plug retainer |
| 7. 2/4 accumulator spring | 16. Valve retainer plug |
| Inspection page K2-206 | 17. 3-2 timing valve spring |
| 8. 2/4 accumulator plug seal | Inspection page K2-206 |
| Assembly note page K2-206 | 18. 3-2 timing valve |
| 9. Retaining plate | 19. Accumulator body assembly |

**Disassembly note****2/4 accumulator plug**


1. Remove the 2/4 accumulator plug by using a bolt.



2. Remove the 2/4 accumulator plug seal. Discard the seal.

Inspection**Springs**


- Springs must not be twisted.
- Springs must not be damaged.

**Assembly note****2/4 accumulator plug seal**

1. Install a new seal on the 2/4 accumulator plug.
2. Lubricate the plug and install.

Caution

- Do not push the plug into the bore beyond flush or damage to the seal will occur.




3. Install the retaining plate by using needle-nosed pliers.

VALVE BODY ASSEMBLY

Disassembly / Inspection / Assembly

Caution

- Each valve should slide out/in under its own weight.
 - When a valve will not slide out under its own weight, depending on the valve, push it out with a wire or place the valve body open-side down and lightly tap it with a plastic hammer. Never scratch or otherwise damage a valve or bore.
 - Do not drop or lose the valves or internal parts.
 - Before assembly, make sure all parts are thoroughly clean.
 - Apply ATF to all parts and bores.
 - Note the proper direction of the valve and internal parts.
 - Do not reuse any part that has been dropped.
 - Wrap a screwdriver or rod with tape before using it to insert a valve.
1. Disassemble in the order shown in the figure.
 2. Inspect all parts and repair or replace as necessary.
 3. Assemble in the reverse order of disassembly.



- | | |
|--|--|
| 1. Manual control valve | 25. Spring retaining plate |
| 2. Spring retaining plate | 26. Coasting clutch shift valve spring Inspection page K2-209 |
| 3. Solenoid regulator valve spring Inspection page K2-209 | 27. Coasting clutch shift valve |
| 4. Solenoid regulator valve | 28. Valve plug retainer |
| 5. Valve plug retainer | 29. Valve retainer plug |
| 6. Valve retainer plug | 30. Low/reverse modulator spring Inspection page K2-209 |
| 7. Bypass clutch control valve spring Inspection page K2-209 | 31. Low/reverse modulator valve |
| 8. Bypass clutch control sleeve | 32. Valve plug retainer |
| 9. Clutch control valve plunger | 33. Valve retainer plug |
| 10. Bypass clutch control valve | 34. 1-2 shift valve spring Inspection page K2-209 |
| 11. Spring retaining plate | 35. 1-2 shift valve |
| 12. Converter regulator valve spring Inspection page K2-209 | 36. Valve plug retainer |
| 13. Converter regulator valve | 37. Valve retainer plug |
| 14. Valve plug retainer | 38. 3-2 control valve spring Inspection page K2-209 |
| 15. Valve retainer plug | 39. 3-2 control valve |
| 16. Line modulator spring Inspection page K2-209 | 40. Valve plug retainer |
| 17. Line modulator valve | 41. Valve retainer plug |
| 18. Valve plug retainer | 42. 2-3 shift valve spring Inspection page K2-209 |
| 19. Valve retainer plug | 43. 2-3 shift valve |
| 20. Main regulator valve spring Inspection page K2-209 | 44. Valve plug retainer |
| 21. Main regulator valve | 45. Valve retainer plug |
| 22. Spring retaining plate | 46. 3-4 shift valve spring Inspection page K2-209 |
| 23. Servo release shuttle valve spring Inspection page K2-209 | 47. 3-4 shift valve |
| 24. Servo release shuttle valve | |

Inspection


Springs

- Springs must not be twisted.
- Springs must not be damaged.

CONTROL VALVE BODY (ASSEMBLY)

Preparation


SST

| | | |
|----------------------|---|------------------------------------|
| 49 UN01 106 |  | For assemble of control valve body |
| Valve body guide pin | | |

Caution


- Before assembly, make sure all parts are perfectly clean.
- Apply ATF to all parts.
- Do not reuse the gaskets or O-rings.

Assemble as shown in the figure, referring to **Assembly Procedure**.




N·m {kgf·m, ft·lbf}


- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Transfer plate 2. Separator plate 3. Gaskets 4. Valve body assembly 5. Separator plate 6. Gaskets 7. Accumulator body assembly 8. Bolt | <ol style="list-style-type: none"> 9. Detent lever 10. Bolt 11. Pressure tap gasket 12. Pressure tap plate 13. Bolt 14. Solenoid gasket 15. Solenoid body assembly 16. Bolt |
|--|---|




1. Install the **SST** or equivalent in the valve body transfer plate.




2. Install the valve body separator plate and new gaskets on the transfer plate.




3. Install the valve body assembly on the transfer plate.



4. Install the accumulator body separator plate and new gaskets on the valve body assembly.




5. Install the accumulator body assembly on the valve body assembly.




6. Install and tighten the three accumulator body assembly-to-transfer plate bolts.

Tightening torque: 10 N·m {1.1 kgf·m, 7 ft·lbf}




7. Install the three valve body-to-transfer plate bolts and detent lever.

Tightening torque: 10 N·m {1.1 kgf·m, 7 ft·lbf}



8. Install the pressure tap plate, gasket, and three bolts on the accumulator body assembly.


Tightening torque: 8 N·m {0.8 kgf·m, 6 ft·lbf}



Note

- Match the solenoid body gasket to the passages.

9. Install the solenoid body and a new gasket on the accumulator body.



10. Install the two solenoid body-to-accumulator body bolts.


Tightening torque: 10 N·m {1.1 kgf·m, 7 ft·lbf}

11. Remove the valve body alignment pins.
12. Install the manual control valve.


DIFFERENTIAL

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- | | |
|------------------------------|----------------------|
| 1. Roll pin | 4. Thrust washer |
| Disassembly Note below | 5. Side gears |
| 2. Pinion shaft | 6. Thrust washer |
| 3. Pinion gears | 7. Differential case |



Disassembly Note


Roll pin

Use a punch to remove the pinion shaft roll pin.




Assembly Procedure


1. Install the side gears and thrust washers.



2. Install the pinion gears and thrust washers.



















3. Install the pinion shaft.












4. Install the pinion shaft roll pin.

TRANSAXLE UNIT (ASSEMBLY)

Preparation SST

| | | | |
|--|--|--|--|
| <p>49 UN01 098</p> <p>Needle bearing remover/ replacer/ receiver</p>  | <p>For installation of #18 bearing</p> | <p>49 UN01 099</p> <p>Servo plug replacer</p>  | <p>For installation of #18 bearing</p> |
| <p>49 UN01 024</p> <p>Throttle shaft seal replacer</p>  | <p>For installation of manual control shaft seal</p> | <p>49 UN01 119</p> <p>Lube tube seal replacer</p>  | <p>For installation of lube tube seal</p> |
| <p>49 UN01 116</p> <p>Lube tube replacer</p>  | <p>For installation of lube tube</p> | <p>49 UN01 115</p> <p>Lube tube replacer</p>  | <p>For installation of lube tube</p> |
| <p>49 UN01 093</p> <p>Low/reverse clutch piston seal protector</p>  | <p>For installation of low/reverse clutch piston</p> | <p>49 UN01 097</p> <p>Low/reverse clutch piston seal protector</p>  | <p>For installation of low/reverse clutch piston</p> |
| <p>49 UN01 109</p> <p>Preload tool</p>  | <p>For adjustment of preload</p> | <p>49 UN01 110</p> <p>Preload tool adaptor</p>  | <p>For adjustment of preload</p> |
| <p>49 UN01 111</p> <p>Preload tool aligner</p>  | <p>For adjustment of preload</p> | <p>49 UN01 108</p> <p>Gauge bar</p>  | <p>For adjustment of preload</p> |
| <p>49 UN01 112</p> <p>Preload tool aligner adaptor</p>  | <p>For adjustment of preload</p> | <p>49 UN01 106</p> <p>Valve body guide pins</p>  | <p>For installation of oil filter recirculation seal</p> |
| <p>49 UN01 126</p> <p>Filter replacer</p>  | <p>For installation of oil filter recirculation seal</p> | <p>49 UN01 114</p> <p>Gauge bar spacer set</p>  | <p>For adjustment of preload</p> |

| | | | |
|---|---|--|--|
| <p>49 UN01 104</p> <p>Servo cover remover/replacer</p>  | <p>For installation of 2/4 servo piston</p> | <p>49 UN01 105</p> <p>Servo piston rod selector</p>  | <p>For installation of 2/4 servo piston</p> |
| <p>49 UN01 113</p> <p>Transmission test plate with valve body</p>  | <p>For checking clutch hydraulic circuit</p> | <p>49 UN01 085</p> <p>Shifter shaft alignment tool</p>  | <p>For adjustment of shifter shaft</p> |
| <p>49 UN01 086</p> <p>MLPS alignment tool</p>  | <p>For adjustment of TR sensor</p> | <p>49 UN01 129</p> <p>Seal replacer</p>  | <p>For installation of differential seal</p> |
| <p>49 UN01 088</p> <p>Converter seal replacer</p>  | <p>For installation of torque converter impeller hub seal</p> | <p>49 G019 038</p> <p>Transaxle hanger</p>  | <p>For assembly of transaxle</p> |
| <p>49 0107 680A</p> <p>Engine stand</p>  | <p>For assembly of transaxle</p> | <p>—</p> | <p>—</p> |

Precaution


1. If the drive plates or 2/4 band are replaced with new ones, soak the new part in ATF for at least 15 minutes before installation.
2. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, and sliding parts.
3. All O-rings, seals, and gaskets must be replaced with the new ones included in the overhaul kit.
4. Use petroleum jelly, not grease, during reassembly.
5. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.


Bearing assembly location

Outer diameter of bearing assembly

| No. | Name | Outer diameter mm {in} |
|-----|----------------------------------|------------------------|
| #1 | Pump support thrust bearing | 75.09 {2.956} |
| #4 | Turbine shaft thrust bearing | 44.25 {1.742} |
| #5 | Low-int sun gear thrust bearing | 49.90 {1.965} |
| #6 | Low-int carrier thrust bearing | 66.41 {2.615} |
| #7 | Rev/4gr sun gear thrust bearing | 76.75 {3.022} |
| #8 | Rev/4gr carrier thrust bearing | 72.87 {2.869} |
| #9 | Rev/4gr ring gear thrust bearing | 99.70 {3.925} |
| #12 | Driven sprocket thrust bearing | 79.26 {3.120} |
| #13 | Driven sprocket thrust bearing | 79.95 {3.148} |
| #15 | Differential bearing | 58.44 {2.301} |


Bearing and race locations






- 1. Recirculating regulator exhaust seal
- 2. Oil filter and seal
- 3. Manual valve detent lever actuating rod
- 4. Parking pawl and shaft
- 5. Parking cam actuator lever
- 6. Parking pawl actuating cam
- 7. Differential seal
- 8. Manual control lever and shaft

- 9. Thermal valve bracket
- 10. Thermostatic oil level valve
- 11. Manual valve detent lever assembly
- 12. Transaxle range switch
- 13. 2/4 band
- 14. Oil pump and pump support
- 15. 2/4 band servo piston, rod, and spring
- 16. Transaxle case




- | | |
|---------------------------------------|--|
| 1. Low/reverse piston seal (Inner) | 11. Forward/coasting/direct clutch cylinder |
| 2. Low/reverse clutch piston assembly | 12. Turbine shaft |
| 3. Low/reverse clutch | 13. Forward one-way clutch and low-intermediate sun gear |
| 4. Wave spring | 14. Low-intermediate carrier assembly |
| 5. Low one-way clutch | 15. Low-intermediate ring gear |
| 6. Low one-way clutch plate | 16. Reverse/fourth gear sun gear and low-intermediate carrier assembly |
| 7. Retaining ring | 17. Reverse/fourth gear carrier assembly |
| 8. Reverse clutch drum | 18. Reverse/fourth gear sun gear |
| 9. Direct clutch shell assembly | |
| 10. Thrust washer | |




- 1. #18 driven sprocket bearing
- 2. #11 driven sprocket shim
- 3. #12 driven sprocket bearing
- 4. Driven sprocket
- 5. #13 driven sprocket thrust bearing

- 6. Drive chain
- 7. Chain cover pen
- 8. Final drive and differential
- 9. Converter housing




- 1. Control valve body
- 2. Control valve body cover
- 3. Turbine shaft speed sensor

- 4. Vehicle speedometer sensor
- 5. ATF dipstick and oil filler tube
- 6. Torque converter



Assembly Procedure

1. If necessary, use the **SSTs** or equivalent to install the #18 driven sprocket bearing in the transaxle case.




2. Apply thread sealant to the fitting. Install the fluid cooler line fitting on the transaxle case.


Tightening torque: 40 N·m {4.1 kgf·m, 30 ft·lbf}

3. Apply thread sealant to the port plug. Install the line pressure port plug on the transaxle case.


Tightening torque: 8 N·m {0.8 kgf·m, 6 ft·lbf}




4. Use a small rubber mallet to install the manual valve detent lever shaft seal in the case.



5. Install the manual valve detent lever and shaft into the case.




6. Use a hammer and a punch to install a new manual valve detent lever shaft roll pin.


**Caution**

- Do not allow the manual valve detent lever roll pin to make contact with the case.


7. Use a hammer and a punch to install a new manual valve detent lever roll pin.




8. Verify that the manual valve detent lever rotates freely. Install the manual valve actuator rod (Z-link).




9. Use the **SST** or equivalent to install the manual control shaft seal.



10. Install the parking pawl and return spring.




11. Install the parking pawl shaft.




12. Install the parking pawl shaft retainer and bolt.

Tightening torque: 8 N·m {0.8 kgf·m, 6 ft·lbf}




13. Assemble the parking lock cam, cam actuator, spring, and spacer on the manual lever control shaft.



Note


- Verify that the manual lever control shaft assembly can move freely.

14. Install the manual lever control shaft assembly into the case.




15. Install the manual control shaft nut.

Tightening torque: 74 N·m {7.5 kgf·m, 55 ft·lbf}




16. Install the parking pawl spring.


**Note**

- Bolt will be torqued after linkage adjustment.


17. Install the manual control outer lever and bolt by hand.




18. Use the **SST** or equivalent to install a new final drive lube tube seal into the case.




19. Lubricate the end of a new final drive lube tube and push it into the seal.




20. Push the final drive lube tube into the bearing of the case and seat it with the **SST**.



21. Push a new drive chain/differential lube tube into the housing.




22. Seat the end of the drive chain/differential lube tube with the SST.



23. Install the mounting bolt.


Tightening torque: 15 N·m {1.5 kgf·m, 11 ft·lbf}




Note

- The gear is installed with the lug end up away from the housing.

24. Lower the final drive ring gear into the housing.




25. Install the final drive gear retaining ring.




26. Install the fitting to the converter housing.


Tightening torque: 40 N·m {4.1 kgf·m, 30 ft·lbf}



27. Slide the 2/4 band into the case.




28. Lubricate the seal and bore in the case.
29. Lower the pump into the transaxle case.




30. Install the nine oil pump assembly-to-transaxle case bolts.


Tightening torque:
12—14 N·m {122—146 kgf·cm, 104—127 in·lbf}




31. Install a new outer seal on the low/reverse piston.




32. Install a new inner seal on the piston.




33. Install the low/reverse clutch piston into **SST** (49 UN01 093) and **SST** (49 UN01 097). Install the low/reverse clutch piston into the case. Remove the **SSTs**.



34. Install the return spring assembly.




35. Use a screwdriver to install the retaining ring. Verify that the ring is seated all around.








Caution

- The wave spring is installed in this position for measurement purposes only.

36. Install the low/reverse wave spring.



37. Install the low/reverse steel and friction plates, and the pressure plate.



Note

- The thrust plate is installed in this position for measurement purposes only.

- Install the low one-way clutch thrust plate.
- Use a feeler gauge to measure the clearance between the pressure plate and the thrust plate. Make a second measurement on the opposite side. Average the two measurements to obtain the clearance.
- The standard clearance is **0.54—1.17 mm {0.02—0.05 in}**. If the clearance is not within the specification, select the proper thickness pressure plate to obtain the standard clearance.


Pressure plate sizes are as follows:

| Thickness mm {in} | Number of notches |
|-------------------------|-------------------|
| 2.57—2.47 {0.1—0.097} | 1 |
| 2.36—2.26 {0.092—0.088} | 2 |
| 2.16—2.06 {0.085—0.081} | 3 |


- Remove the thrust plate, pressure plate, steel and friction plates, and the wave spring for installation later.
- Install the #1 pump support thrust bearing.

- Remove the **SST** (seal sizer) from the forward/coasting/direct clutch cylinder.
- Install the assembly of the forward/coasting/direct clutch cylinder and reverse drum assembly.

- Install the turbine shaft.




46. Install the #4 turbine shaft thrust bearing.




47. Install the forward one-way clutch/low-intermediate sun gear.


48. Be sure that the assembly is fully installed in all clutch plates and is resting on the #4 turbine shaft thrust bearing.




49. Install the #5 low-intermediate sun gear thrust bearing.




50. Install the low-intermediate carrier.




51. Install the #6 low-intermediate carrier thrust bearing.




52. Install the low-intermediate ring gear.




53. Install the #7 reverse/fourth gear sun gear thrust bearing.




54. Install the reverse/fourth gear sun gear/shell.




55. Install the reverse/fourth gear carrier with the captured #8 reverse/fourth gear carrier thrust bearing.




56. Install the low/reverse clutch plates.



57. Install the low/reverse pressure plate previously selected.




58. Install the low/reverse wave spring.



Note


- Be sure the grooves in the inner and outer races face up.

59. Install the low one-way clutch assembly with the I.D. groove on the inner ring facing up.




60. Install the low one-way clutch thrust plate.


61. Install the low one-way clutch retaining ring. Position the retaining ring ends in an area near the case lugs.



62. Snap the socket end of the manual valve detent lever actuating rod on the parking cam actuator.




63. Snap the opposite socket end of the manual valve detent lever actuating rod on the manual valve detent lever.




64. Install the **SSTs** on the reverse/fourth gear carrier.


Tightening torque: 13.5 N·m {1.4 kgf·m, 10 ft·lbf}



65. Install the **SST** across the case.




66. Use a depth micrometer to measure the distance from the top of the gauge bar to the bearing surface on the reverse/fourth gear carrier. Repeat this measurement on the other side of the turbine shaft. Average the two measurements. This is dimension A.




67. Measure the distance from the top of the **SST** to the #12 driven sprocket bearing surface area of the case. This is dimension B.
68. Subtract dimension A from dimension B to get dimension C.
69. Use dimension C to select the proper #11 driven sprocket shim from the following chart.

| Dimension C mm {in} | Shim Thickness mm {in} |
|---------------------------|-------------------------|
| 14.34—14.17 {0.565—0.558} | 2.20—2.10 {0.087—0.083} |
| 14.16—14.00 {0.557—0.551} | 2.02—1.92 {0.080—0.076} |
| 13.99—13.83 {0.550—0.544} | 1.85—1.75 {0.073—0.069} |
| 13.82—13.66 {0.543—0.538} | 1.67—1.57 {0.066—0.062} |
| 13.65—13.49 {0.537—0.531} | 1.50—1.40 {0.059—0.055} |
| 13.48—13.32 {0.530—0.524} | 1.32—1.22 {0.052—0.048} |


70. Remove the **SSTs**.




71. Lubricate the needles and seals of #18 bearing in the case.
72. Install the selected #11 driven sprocket shim on the case.
73. Install the #12 driven sprocket thrust bearing.



74. Install the #9 reverse/fourth gear thrust bearing.




75. Install the drive sprocket, for gauging only.




76. Install the **SSTs** on the drive sprocket.


Tightening torque: 13.5 N-m {1.4 kgf-m, 10 ft-lbf}



77. Install the **SST** on the case.



78. Use a depth micrometer to measure the distance from the top of the gauge bar to the face of the drive sprocket. Repeat on other side of the turbine shaft. Average these two numbers. This is dimension A.




79. Use the combined thickness 25.4 mm {1.00 in} of the gauge bar and short spacers as distance B.

80. Subtract dimension A from dimension B to get dimension C.


81. Use dimension C to select the proper #10 drive sprocket thrust washer from the following chart.

| Dimension C mm {in} | #10 Washer Thickness mm {in} |
|-------------------------|------------------------------|
| 1.12—0.86 {0.044—0.034} | 1.51—1.41 {0.059—0.056} |
| 0.85—0.60 {0.033—0.024} | 1.77—1.67 {0.070—0.066} |
| 0.59—0.34 {0.023—0.013} | 2.03—1.93 {0.080—0.076} |
| 0.33—0.08 {0.013—0.003} | 2.29—2.19 {0.090—0.086} |


82. Remove the drive sprocket.




83. Remove the gauge bar and preload tool. Apply petroleum jelly to the selected #10 drive sprocket thrust washer and install on the converter housing. Remove the drive sprocket.




84. Install the oil filter and seal assembly.




85. Temporarily install the **SST** or equivalent.



86. Use the **SST** to install a new oil filter recirculation seal and then remove the **SST** from the filter.




87. Install the rear part of the chain cover in the transaxle case.




Warning

- Wear gloves as personal protection from the sharp chain and sprocket teeth.


88. Lower the chain drive and its sprockets together in the transaxle case. Verify that both sprockets are seated.




89. Install the front part of the chain cover by snapping it into place.




90. Install the #13 driven sprocket thrust bearing.



91. Install the final drive carrier/differential case.




92. Install the **SSTs** on the case. Secure them with the two bolts.




93. Use a depth micrometer to measure the distance from the top of the gauge bar to the shim surface area of the final drive carrier and differential assembly. Make two measurements then average them. This is dimension A.
94. Use the combined thickness of the gauge bar with long spacers 177.8 mm {7.00 in} as distance B.
95. Subtract dimension A from dimension B to get dimension C.
96. Use dimension C to select the proper #14 differential bearing shim from the following chart.

| Dimension C | mm {in} | #14 Shim Thickness | mm {in} |
|---------------|---------------|--------------------|---------------|
| 130.76—130.46 | {5.148—5.136} | 1.08—0.98 | {0.043—0.039} |
| 130.45—130.16 | {5.136—5.124} | 1.38—1.28 | {0.054—0.050} |
| 130.15—129.87 | {5.123—5.113} | 1.67—1.57 | {0.066—0.062} |
| 129.86—129.57 | {5.113—5.101} | 1.97—1.87 | {0.078—0.074} |
| 129.56—129.27 | {5.100—5.089} | 2.27—2.17 | {0.089—0.085} |


97. Remove the gauge bar and long spacers.




98. Install a new speedometer drive gear.
99. Install the selected #14 differential bearing shim.
100. Install the #15 differential bearing.



101. Attach a new gasket to the transaxle case split flange.



102. Lower the converter housing onto the transaxle case.




103. Install the twenty converter housing-to-transaxle case bolts or replace bolts. Tighten the bolts in the sequence shown.

Tightening torque:


20—25 N·m {2.0—2.5 kgf·m, 15—18 ft·lbf}

Note

- Note the number of grooves on the piston rod.




104. Install the 2/4 servo piston and return spring assembly.




105. Install the **SST** on the piston.

Note

- Legs of the **SST** fit into the servo piston cover retaining ring groove.




106. Install the **SST** in the case bore. The **SST** bolts should be loosely assembled for easy installation.



107. Tighten the bolts on the **SST** as shown.


108. Tighten the screw.

Tightening torque: 4 N·m {40 kgf·m, 36 ft·lbf}




109. Install a depth micrometer on the head of the **SST**. Measure and record the distance from the depth micrometer to the bar of the **SST**. (distance A).
110. Unscrew until the servo piston movement stops. Measure and record the distance to the bar of the **SST**. (distance B).
111. Subtract A from B to obtain travel C.

| Number of Grooves | Travel Specification mm {in} | Rod Length mm {in} |
|-------------------|---------------------------------|-----------------------|
| 0 | 2.43—4.82 {0.096—0.190} | 108.1 {4.26} |
| 1 | | 107.1 {4.22} |
| 2 | | 105.7 {4.16} |



112. If the depth micrometer reading is not within the travel specification, replace the 2/4 servo piston rod and recheck.
113. Remove the **SST**.
114. Install a nut with an integral washer onto the forcing bolt of the servo cover remover/replacer tool with a permanent thread sealer. This nut and washer will aid in the installation of the cover.



115. Lubricate the 2/4 servo piston, servo cover, servo cover seal and servo case bore, using ATF or petroleum jelly to aid in the installation and prevent cutting of the seal.
116. Install the servo cover in the case.
117. Install the **SST**.


Warning

- Servo return spring force is very high.

118. Compress the servo cover and install the retaining ring.
119. Remove the **SST**.

Note

- If the cover will not seat deep enough in the bore to install the servo cover retaining ring, a blunt punch may be used with a small hammer. Gently tap the cover around the outer edge with the punch until the snap ring groove is fully exposed.




120. Install the servo cover cap by using the **SST**, if equipped originally.

Warning

- Use safety glasses when using compressed air.

Caution


- The coasting clutch circuit should not be applied. Failure to do so may result in the coasting clutch piston coming out of the forward clutch piston.



121. Install the **SST** by using six mounting bolts.
Use a rubber tipped blow gun and compressed air **275 kPa {2.8 kgf/cm², 40 psi}** to check the following clutch hydraulic circuits for function and leakage.
- REVERSE CLUTCH
 - FORWARD CLUTCH
 - DIRECT CLUTCH
 - LOW/REVERSE CLUTCH
 - SERVO RELEASE
 - SERVO APPLY

Warning

- **Wear eye protection when using compressed air.**
122. If leakage is heard in any circuit, the transaxle must be disassembled and the source of leakage corrected.
Remove the **SST**.



123. Install the filter in the forward clutch circuit. Place the thermostatic oil level control valve in the transaxle case.
124. Install the bracket and the bolt.

Tightening torque:


11—13 N·m {112—133 kgf·cm, 96—117 in·lbf}

125. If necessary, install the O-ring on the solenoid body connector.

Caution

- **Do not pull on the wires or damage the connector body.**


126. Place the control valve body slightly away from the transaxle case and push the solenoid body connector into its bore.
127. Align the Z-link in the manual valve.



128. Install the 12 mounting bolts. Tighten the mounting bolts in the sequence shown.


Tightening torque:

9—11 N·m {92—112 kgf·cm, 80—97 in·lbf}




129. Loosen the nut on the ball stud for the manual valve detent actuating rod.


130. Remove the manual lever control shaft outer lever.



131. Use the **SST** to move the shaft to the D range position and install the pin to hold the tool in position.




132. Move the manual valve detent lever to the D range position.



133. Loosen the nut on the ball stud for the manual valve detent lever actuating rod assembly.

134. Initially tighten the nut on the ball. Remove the shifter pin.



135. Rotate the **SST** until the socket can be installed on the nut. Tighten the manual valve detent lever ball stud nut.


Tightening torque:

11—13 N·m {112—133 kgf·cm, 96—117 in·lbf}


136. Remove the pin and **SST**.
137. Install the manual control lever assembly and bolt.

Tightening torque:

24—30 N·m {2.4—3.1 kgf·m, 18—22 ft·lbf}



138. Install the transaxle range switch on the manual lever shaft. Hand-tighten the two mounting bolts.




TRANSAXLE RANGE (TR) SWITCH

Note

- The outer lever must be in the N position.


139. Use the **SST** to align the switch on the shaft and case.



140. Tighten the transaxle range switch bolts. Remove the **SST**.


Tightening torque:

11—13 N·m {112—133 kgf·cm, 96—117 in·lbf}



141. Install the control valve body cover gasket on the case. Attach the cover to the case.


142. Install the fourteen mounting bolts in the sequence shown.



143. Install and tighten the control valve body cover-to-transaxle case bolts.

Tightening torque: 12 N·m {1.2 kgf·m, 9 ft·lbf}
(galvanized cover)

Tightening torque: 20 N·m {2.0 kgf·m, 15 ft·lbf}
(black cover)



144. Install the O-ring seal on the vehicle speedometer sensor.


145. Push the vehicle speedometer sensor into the bore.

146. Install the bolt.


147. Tighten the bolt.

Tightening torque:

5—6 N·m {50—61 kgf·cm, 44—53 in·lbf}



148. Install the oil filler tube seal grommet into the case.



149. Install the oil filler tube.

150. Install the mounting bolt. Tighten the mounting bolt.

Tightening torque:

7—9 N·m {71—92 kgf·cm, 62—80 in·lbf}

151. Install the oil level indicator in the tube.

152. Install the turbine shaft speed sensor O-ring seal.


153. Push the turbine shaft speed sensor into the bore.

154. Install the mounting bolt.


155. Tighten the bolt.

Tightening torque:


12—14 N·m {120—146 kgf·cm, 104—127 in·lbf}



156. Use the **SST** or equivalent and a hammer to install the RH and LH differential seals.




157. Use the **SST** or equivalent and a hammer to install the torque converter impeller hub seal spring, then verify that the seal spring has not been dislodged.




158. Apply sealant to the drain plug. Install the drain plug. Tighten the drain plug.

Tightening torque:


15—35 N·m {1.5—3.6 kgf·m, 11—26 ft·lbf}



159. Install the oil pump drive shaft into the end of the turbine shaft.



160. Install the torque converter in the transaxle.



161. Remove the transaxle from the **SST**.

162. Dry the transaxle exterior and prepare it for installation.


Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

FRONT AND REAR AXLES

| | |
|------------------------------------|------|
| INDEX | M- 2 |
| OUTLINE | M- 3 |
| SPECIFICATIONS | M- 3 |
| TROUBLESHOOTING GUIDE | M- 3 |
| FRONT AXLE | M- 4 |
| PREPARATION | M- 4 |
| WHEEL HUB, STEERING KNUCKLE | M- 5 |
| REAR AXLE | M-11 |
| PREPARATION | M-11 |
| DRUM BRAKE TYPE | M-12 |
| DISC BRAKE TYPE | M-15 |
| DRIVE SHAFT | M-18 |
| PREPARATION | M-18 |
| JOINT SHAFT | M-19 |
| DRIVE SHAFT | M-23 |
| DOUBLE OFFSET TYPE (MTX) | M-28 |
| TRIPOD TYPE (ATX) | M-33 |


INDEX

FRONT AXLE




REAR AXLE

(DRUM BRAKE TYPE)



(DISC BRAKE TYPE)



| | | |
|------------------------------|-----------|------------------------------|
| 1. Front axle | | |
| Wheel hub, steering knuckle | | |
| Preinspection | page M- 5 | |
| Removal / Installation | page M- 5 | |
| Disassembly / Inspection / | | |
| Assembly | page M- 7 | |
| 2. Rear axle | | |
| (Drum brake type) | | |
| Preinspection | page M-12 | |
| Removal / Inspection / | | |
| Installation | page M-12 | |
| Disassembly / Assembly | page M-14 | |
| | | (Disc brake type) |
| | | Preinspection |
| | | page M-15 |
| | | Removal / Inspection / |
| | | Installation |
| | | page M-15 |
| | | Disassembly / Assembly |
| | | page M-16 |
| 3. Joint shaft | | |
| Preinspection | page M-19 | |
| Removal / Installation | page M-19 | |
| Overhaul | page M-22 | |
| 4. Drive shaft | | |
| Preinspection | page M-23 | |
| Removal / Installation | page M-24 | |
| Overhaul | | |
| (Double offset type) | page M-28 | |
| (Tripod type) | page M-33 | |

OUTLINE

SPECIFICATIONS

| Item | Engine | FS | | KL | |
|---|-------------------|---------------------|---------------|---------------|---------------|
| | Transaxle | MTX | ATX | MTX | ATX |
| Front axle | | | | | |
| Maximum wheel bearing play | mm {in} | 0.05 {0.002} | | | |
| Rear axle | | | | | |
| Maximum wheel bearing play | mm {in} | 0.05 {0.002} | | | |
| Drive shaft | | | | | |
| Joint type | Wheel side | Birfield joint (BJ) | | | |
| | Differential side | DOJ* | TJ* | DOJ | TJ |
| Length of joint (between center of joint) mm {in} | Right side | 387.0 {15.24} | 380.0 {14.96} | 382.0 {15.04} | 380.0 {14.96} |
| | Left side | 387.0 {15.24} | 357 {14.06} | 382.0 {15.04} | 380.0 {14.96} |
| Shaft diameter | Right side | 24.0 {0.94} | 24.3 {0.96} | 26.0 {1.02} | 26.3 {1.03} |
| | Left side | 24.0 {0.94} | 24.3 {0.96} | 26.0 {1.02} | 26.3 {1.03} |
| Length of joint shaft | mm {in} | 376.0 {14.80} | | | |
| Joint shaft diameter | mm {in} | 26.0 {1.02} | | | |

* TJ: Tripod joint
DOJ: Double offset joint

TROUBLESHOOTING GUIDE



Front Axle













| Problem | Possible Cause | Remedy | Page |
|--|---|----------------------|----------|
| Steering wheel vibration | Excessive wheel bearing play | Tighten or replace | M- 5 |
| | Worn or damaged wheel bearing | Replace | M- 7 |
| Steering wheel pulls or one-sided braking | Excessive wheel bearing play | Tighten or replace | M- 5 |
| | Worn or damaged wheel bearing | Replace | M- 7 |
| Excessive steering wheel play | Excessive wheel bearing play | Tighten or replace | M- 5 |
| Abnormal noise | Worn or damaged wheel bearing | Replace | M- 7 |
| | Insufficient grease in joint or splines of joint shaft | Add or replace | M-19 |
| | Bent drive shaft or joint shaft | Replace | M-19, 23 |
| | Worn drive shaft or joint shaft splines | Replace | M-19, 23 |
| | Insufficient grease in joint or on splines of drive shaft | Replenish or replace | M-23, 28 |
| | Worn drive shaft | Replace | M-24 |
| Grease leakage from boot | Damaged or broken boot | Replace | M-28, 33 |
| | Faulty boot band | Replace | M-28, 33 |
| | Excessive grease | Repair | M-28, 33 |


Rear Axle

| Problem | Possible Cause | Remedy | Page |
|--|-------------------------------|--------------------|----------|
| Steering wheel vibration | Worn or damaged wheel bearing | Replace | M-12, 15 |
| | Excessive wheel bearing play | Tighten or replace | M-12, 15 |
| Steering wheel pulls or one-sided braking | Worn or damaged wheel bearing | Replace | M-12, 15 |
| | Excessive wheel bearing play | Tighten or replace | M-12, 15 |
| Excessive steering wheel play | Excessive wheel bearing play | Tighten or replace | M-12, 15 |
| Abnormal noise | Worn or damaged wheel bearing | Replace | M-12, 15 |

FRONT AXLE

PREPARATION
SST

| | | | |
|---|--|---|--|
| <p>49 G030 797 Handle (Part of 49 G030 795)</p>  | <p>For installation of wheel bearing</p> | <p>49 G033 1A1 Puller, wheel hub</p>  | <p>For disassembly and assembly of wheel hub</p> |
| <p>49 F026 103 Puller, wheel hub</p>  | <p>For disassembly of wheel bearing</p> | <p>49 G033 105 Attachment (Part of 49 G033 1A1)</p>  | <p>For installation of front wheel hub</p> |
| <p>49 G033 102 Handle (Part of 49 G033 1A1)</p>  | <p>For removal of front wheel hub</p> | <p>49 F027 0A1 Installer set, bearing</p>  | <p>For installation of bearing</p> |
| <p>49 G033 107 Installer, dust cover</p>  | <p>For installation of dust cover</p> | <p>49 F027 004 Attachment 80 (Part of 49 F027 0A1)</p>  | <p>For removal of wheel bearing</p> |
| <p>49 V001 795 Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1)</p>  | <p>For instalation of dust cover</p> |
| <p>49 G033 106 Attachment (Part of 49 G033 1A1)</p>  | <p>For removal of front wheel hub</p> | <p>49 G030 795 Installer, oil seal</p>  | <p>For installation of wheel bearing</p> |



WHEEL HUB, STEERING KNUCKLE

Preinspection


Wheel bearing play

1. Remove the wheel and tire.
2. Remove the brake caliper assembly and disc plate.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds the specification, check and adjust the locknut torque or replace the wheel bearing if necessary.


Maximum wheel bearing play: 0.05 mm {0.002 in}

Removal / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Tighten the stabilizer and shock absorber bolts and nuts to just under the specified torque. Lower the vehicle and tighten all bolts and nuts to the specified torque with the vehicle unladen.
5. After installation, check the wheel alignment. (Refer to section R.)



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Wheel nut 2. Wheel and tire 3. Locknut Removal Note page M-6 Installation Note page M-6 4. Brake caliper assembly Service section P 5. Disc plate Service section P 6. ABS wheel-speed sensor Service section P | <ol style="list-style-type: none"> 7. Tie-rod end Service section N 8. Stabilizer control link 9. Lower arm ball joint 10. Steering knuckle, wheel hub and dust cover Inspect dust cover for damage and distortion Disassembly / Inspection / Assembly page M-7 |
|---|---|

**Removal Note****Locknut**

1. Knock the crimped portion of the locknut outward by using a small chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.

**Installation Note****Locknut**


Install a new locknut and stake it as shown.

Tightening torque: 236—318 N·m

{24.0—32.5 kgf·m, 173.6—235.0 ft·lbf}


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | | | |
|-----------------------------|------------------|-------|-----------|
| 1. Oil seal | Assembly Note | | page M-10 |
| 2. Front wheel hub assembly | Disassembly Note | | below |
| | Assembly Note | | page M- 9 |
| 3. Retaining ring | | | |
| 4. Wheel bearing | Disassembly Note | | page M- 8 |
| | Assembly Note | | page M- 9 |

- | | | | |
|---------------------|------------------|-------|----------|
| 5. Dust cover | Disassembly Note | | page M-8 |
| | Assembly Note | | page M-9 |
| 6. Steering knuckle | | | |
| 7. Hub bolt | Disassembly Note | | page M-8 |
| | Assembly Note | | page M-9 |




Disassembly Note
Front wheel hub assembly

1. Remove the front wheel hub assembly by using the SSTs.




- If the bearing inner race remains on the front wheel hub assembly, grind a section of the bearing inner race until approx. 0.5 mm {0.020 in} remains. Then remove it with a chisel.



Wheel bearing

Using the SSTs, remove the wheel bearing.




Dust cover


Note

- The dust cover does not need to be removed unless you are replacing it.

- Mark the dust cover and steering knuckle for proper reassembly.



- Remove the dust cover by using a chisel.




Hub bolt


Note

- The hub bolts do not need to be removed unless you are replacing them.


Remove the hub bolts by using a press.



Assembly Note
Hub bolt
 Press in new hub bolts.




Dust cover
 1. Mark the new dust cover as the one removed.




2. Align the marks of the new dust cover and the steering knuckle.
 3. Using a steel plate and the **SSTs**, install the dust cover.


M



Wheel bearing
 Using the **SSTs**, install the new wheel bearing.




Front wheel hub assembly
 Using the **SSTs**, install the front wheel hub assembly.


**Oil seal**

1. Using the **SST** and a hammer, tap a new oil seal in evenly until the **SST** contacts the steering knuckle.
2. Coat the lip of the oil seal with grease.

REAR AXLE

**PREPARATION
SST**

| | | |
|-----------------------------------|---|---|
| <p>49 H028 204 Attachment</p> |  | <p>For installation of sensor rotor</p> |
|-----------------------------------|---|---|




DRUM BRAKE TYPE
Wheel Hub, Hub Spindle
Preinspection
Wheel bearing play

1. Remove the wheel and tire.
2. Position a dial indicator against the brake drum. Push and pull the rear brake assembly by hand in the axial direction and measure the wheel bearing play.
3. If the bearing play exceeds specification, check and adjust the locknut torque or replace the hub bearing assembly if necessary.


Maximum wheel bearing play: 0.05 mm {0.002 in}

Removal / Inspection / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Tighten the lateral link, trailing link and shock absorber bolts and nuts to just under the specified torque. Lower the vehicle and tighten all bolts and nuts to the specified torques with the vehicle unladen.
5. After installation, check the rear wheel alignment. (Refer to section R.)



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Hub cap 3. Locknut Removal Note page M-13 Installation Note page M-13 4. Brake drum 5. Hub bearing assembly Inspect for cracks and damage Disassembly / Assembly page M-14 | <ol style="list-style-type: none"> 6. Parking brake cable bracket 7. Clip 8. Rear brake assembly Service section P 9. Rear hub spindle Inspect for cracks and damage |
|---|--|

**Removal Note****Locknut**

1. Raise the staked portion of the locknut using a small cape chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.

**Installation Note****Locknut**

Install a new locknut and stake it as shown.


Tightening torque: 177—235 N·m
{18.0—24.0 kgf·m, 130.1—173.6 ft·lbf}

Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.

Caution


- The wheel hub and bearing are one assembly and do not need to be disassembled.



1. Hub bolt

Disassembly Note page M-14
 Assembly Note page M-14

2. Hub bearing assembly




Disassembly Note Hub bolt

Note

- The hub bolts do not need to be removed unless you are replacing them.


Remove the hub bolts with a press.



Assembly Note

Hub bolt

Press in new hub bolts.



**DISC BRAKE TYPE
Wheel Hub, Hub Spindle
Preinspection**


Wheel bearing play

1. Remove the wheel and tire.
2. Remove the brake caliper assembly.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds the specification, check and adjust the locknut torque or replace the hub bearing assembly if necessary.


Maximum wheel bearing play: 0.05 mm {0.002 in}

Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Tighten the lateral link, trailing link and shock absorber bolts and nuts to just under the specified torque.
Lower the vehicle and tighten all bolts and nuts to the specified torques with the vehicle unladen.
5. After installation, check the rear wheel alignment. (Refer to section R.)




- | | |
|-----------------------------------|--|
| 1. Wheel and tire | 6. Hub bearing assembly |
| 2. Hub cap | Inspect for cracks and damage |
| 3. Locknut | Disassembly / Assembly page M-16 |
| Removal Note page M-16 | 7. Allen bolt or flange bolt |
| Installation Note page M-16 | 8. Dust cover |
| 4. Brake caliper assembly | Inspect for damage and distortion |
| Service section P | 9. ABS wheel-speed sensor |
| 5. Disc plate | 10. Hub spindle |
| Inspection section P | Inspect for cracks and damage |



Removal Note

Locknut

1. Knock the crimped portion of the locknut outward by using a small chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.



Installation Note

Locknut

Install a new locknut and stake it as shown.

Tightening torque: 177—235 N·m


{18.0—24.0 kgf·m, 130.1—173.6 ft·lbf}

Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.


Caution

- The wheel hub and bearing are one assembly and do not need to be disassembled.



- | | |
|---------------------|-----------------|
| 1. ABS sensor rotor | |
| Disassembly Note | page M-17 |
| Assembly Note | page M-17 |

- | | |
|-------------------------|-----------------|
| 2. Hub bolt | |
| Disassembly Note | page M-17 |
| Assembly Note | page M-17 |
| 3. Hub bearing assembly | |




Disassembly Note
ABS sensor rotor

Note

- The ABS sensor rotor does not have to be removed unless you are replacing it.

Remove the ABS sensor rotor by using a chisel.




Hub bolt

Note


- The wheel hub and bearing are one assembly and do not to be disassembled.

Remove the hub bolts by using a press.



Assembly Note
Hub bolt

Press in new hub bolts.



ABS sensor rotor
















1. Install a new rear ABS sensor rotor on to the wheel hub.
2. Using a steel plate and the **SST**, press the rotor until it is flush with the wheel hub.


Note

- The ABS sensor rotor can be installed in either direction.

DRIVE SHAFT

PREPARATION SST

| | | | |
|--|---|--|---|
| <p>49 H034 2A0</p> <p>Lower arm bushing puller & installer</p>  | <p>For support of bracket</p> | <p>49 H034 201</p> <p>Support block (Part of 49 H034 2A0)</p>  | <p>For support of bracket</p> |
| <p>49 F026 102</p> <p>Installer, bearing</p>  | <p>For removal of bearing and left side dust seal</p> | <p>49 G030 795</p> <p>Installer, oil seal</p>  | <p>For installation of right side dust seal and bearing</p> |
| <p>49 H027 002</p> <p>Remover, bearing</p>  | <p>For removal of dust cover</p> | <p>49 B025 005</p> <p>Installer, dust cover</p>  | <p>For installation of dust cover</p> |
| <p>49 W027 003</p> <p>Installer, oil seal</p>  | <p>For installation of left side dust seal</p> | <p>49 G025 001</p> <p>Installer, sensor rotor</p>  | <p>For installation of sensor rotor</p> |
| <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> |
| <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p>  | <p>For installation of right side dust seal and bearing</p> | <p>49 G030 796</p> <p>Body (Part of 49 G030 795)</p>  | <p>For installation of right side dust seal and bearing</p> |
| <p>49 G030 455</p> <p>Holder, diff. side gear</p>  | <p>For holding side gears</p> | <p>—</p> | <p>—</p> |




**JOINT SHAFT
Preinspection
Joint shaft**

1. Verify that the joint shaft is not twisted or cracked. Replace it if necessary.
2. Turn the joint shaft by hand and verify that the bearing rotates smoothly and freely. Replace it if necessary.


Removal / Installation

1. Drain the transaxle oil.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, fill the transaxle with the specified amount of the specified transaxle oil or ATF and inspect for oil leakage.




1. Wheel and tire
2. Drain plug
3. Stabilizer control link
4. Tie-rod end
Service section N
5. Lower arm ball joint


6. Right drive shaft and axle
Removal Note page M-20
Installation Note page M-21
7. Joint shaft
Removal Note page M-20
Installation Note page M-20
Overhaul page M-21

**Removal Note****Right drive shaft and axle**


1. Remove the clinch bolt and nut.




2. Wrap a rag around the ball joint dust boot.
3. Pry the lower arm out of the knuckle.



4. As shown in the figure, insert a pry bar between the right drive shaft and the joint shaft and tap on the bar to uncouple them.

**Joint shaft**


Pull the joint shaft straight out.

**Installation Note****Joint shaft**

1. Install the joint shaft with the end-gap of a new clip facing upward.
2. Tighten the bolts in the order shown.


Tightening torque:

43—61 N·m {4.3—6.3 kgf·m, 32—45 ft·lbf}



Right drive shaft and axle

1. Push the drive shaft into the joint shaft.
2. After installation, pull the front hub outward to verify that the drive shaft is securely held by the clip.




3. Install the lower arm ball joint to the knuckle and tighten the through bolt.

Tightening torque:


35—56 N·m {3.5—5.8 kgf·m, 26—41 ft·lbf}

Overhaul


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|-------------------------------------|-----------|
| 1. Clip | |
| 2. Dust cover (KL engine) | |
| Disassembly Note | page M-22 |
| Assembly Note | page M-23 |
| 3. Joint shaft | |
| Inspect splines for damage and wear | |
| Disassembly Note | page M-22 |
| Assembly Note | page M-23 |
| 4. Dust cover (KL engine) | |
| 5. Dust seal (left) | |
| Disassembly Note | page M-22 |
| Assembly Note | page M-23 |
| 6. Bearing | |
| Disassembly Note | page M-22 |
| Assembly Note | page M-22 |
| 7. Dust seal (right) | |
| Assembly Note | page M-22 |
| 8. Bracket | |

**Disassembly Note****Dust cover (KL engine)**


While holding the joint shaft, press out the dust cover by using the SST.

**Joint shaft**


Remove the joint shaft by using the SST.

**Dust seal (left)/Bearing**


Remove the left side dust seal and bearing by using the SSTs.

**Assembly Note****Dust seal (right)**

Using the SST, install the new right side dust seal.


**Bearing**

Using the SSTs, install the new bearing.




Dust seal (left)

Using a steel plate and the **SSTs**, install the new left side dust seal.



Joint shaft


Using a press and the **SST**, install the joint shaft.



Dust cover (KL engine)


1. Mark the shaft as shown in the figure.

Length L: 89.0 ± 0.5 mm {3.50 ± 0.02 in}



2. Press in the dust cover to the marked position by using a steel plate and the **SST**.

3. Verify that length L is within specification.



DRIVE SHAFT


Preinspection

Drive shaft

1. Check the dust boot on the drive shaft for cracks, damage, leaking grease, and a loose boot band.
2. Check the drive shaft for bending, cracks, and wear of joints or splines.
3. Repair or replace the drive shaft if necessary.


Removal / Installation

1. Drain the transaxle oil.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, fill the transaxle with the specified amount of the specified transaxle oil or ATF and inspect for oil leakage.
5. Check the front wheel alignment. (Refer to section R.)




N-m {kgf-m, ft-lbf}


- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Splash shield 3. Drain plug 4. Locknut Removal Note page M-25 Installation Note page M-27 5. Stabilizer and control link 6. Tie-rod end Service section N 7. Transverse member | <ol style="list-style-type: none"> 8. Lower arm ball joint Removal Note page M-25 9. Engine mount member (Only for ATX at left side drive shaft) Removal Note page M-25 10. Drive shaft Removal Note page M-25 Installation Note page M-26 Overhaul pages M-28, 33 |
|---|---|

**Removal Note****Locknut**


1. Knock the crimped portion of the locknut outward by using a chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.

**Lower arm ball joint**


1. Remove the clinch bolt and nut.



2. Wrap a rag around the ball joint dust boot.
3. Pry the lower arm out of the knuckle.


**Engine mount member**

Suspend the engine by using the **SST** and remove the engine mount member.


**Drive shaft****Caution**

- The sharp edges of the drive shaft can slice or puncture the oil seal. Be careful when removing the drive shaft from the transaxle.


1. Separate the left-side drive shaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle, as shown in the figure.



2. Separate the right-side drive shaft from the joint shaft by hammering on a bar inserted between them.




3. Install the **SST** into the transaxle to hold the side gears.



Note

- If the drive shaft will not come out of the front wheel hub easily, install an already discarded nut onto the drive shaft so that the nut is flush with the end of the drive shaft. Tap the nut with a copper hammer to loosen the drive shaft from the front wheel hub.



Installation Note Drive shaft

Caution

- The sharp edges of the drive shaft can slice or puncture the oil seal. Be careful when installing the drive shaft to the transaxle.


1. Turn the clip with the opening facing upward.


2. Apply grease to the ends of the drive shafts.

Caution


- The oil seals are damaged easily if this procedure is not done correctly.

3. Push the drive shaft into the transaxle (left side) or joint shaft (right side).






4. After installation, pull the front hub outward to confirm that the drive shaft is securely held by the clip.



5. Install the lower arm ball joint to the knuckle and tighten the through bolt.

Tightening torque:

35—56 N·m {3.5—5.8 kgf·m, 26—41 ft·lbf}

**Locknut**

Install a new locknut and stake it as shown.


Tightening torque: 236—318 N·m

{24.0—32.5 kgf·m, 173.6—235.0 ft·lbf}


DOUBLE OFFSET TYPE (MTX)

Overhaul


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Verify that all parts are free of dust, dirt and other foreign material immediately before reassembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|--|
| <p>1. Boot band Disassembly Note page M-29 Assembly Note page M-32</p> <p>2. Clip Disassembly Note page M-29 Assembly Note page M-31</p> <p>3. Outer ring Inspect inside bore for wear, corrosion, and scoring Assembly Note page M-31</p> <p>4. Snap ring Disassembly Note page M-29 Assembly Note page M-31</p> <p>5. Balls Disassembly Note page M-29 Assembly Note page M-31</p> <p>6. Inner ring Disassembly Note page M-29 Assembly Note page M-31</p> | <p>7. Cage Disassembly Note page M-29 Assembly Note page M-31</p> <p>8. Boot (transaxle side) Disassembly Note page M-30 Inspect for cracks and damage Assembly Note pages M-30, 31</p> <p>9. Boot (wheel side) Disassembly page M-30 Inspect for cracks and damage Assembly Note page M-31</p> <p>10. ABS sensor rotor Disassembly Note page M-30 Assembly Note page M-30</p> <p>11. Shaft and ball joint assembly Inspect splines for damage and wear Inspect wheel side joint for excessive play and rough rotation</p> <p>12. Clip</p> |
|--|--|

**Disassembly Note**


Rotate the joint by hands as shown. If the joint does not move smoothly or if a problem is found, repair the necessary parts or replace the drive shaft.

**Boot band**


1. Pry up the locking clips by using a screwdriver.
2. Pull back the end of the band.

**Clip**


1. Use paint to mark the drive shaft and outer ring for proper reassembly.
2. Remove the clip.

**Snap ring**

1. Use paint to mark the drive shaft and inner ring for proper reassembly.
2. Remove the snap ring by using snap ring pliers.


**Cage, inner ring, and balls**

1. Use paint to mark the inner ring and cage for proper reassembly.
2. Turn the cage approximately 30 degrees and pull the cage and balls away from the inner ring.



Boot

1. Wrap the shaft splines with tape to protect the boot.
2. Remove the boot.




ABS sensor rotor

Note

- The sensor rotor does not need to be removed unless you are replacing it.


Tap the ABS sensor rotor off the drive shaft with a chisel.



Assembly Note


ABS sensor rotor

Set a new ABS sensor rotor on the drive shaft in the direction as shown, and press it onto the shaft assembly by using the SST.




Boot

1. Wrap the shaft splines with tape.



2. Install the wheel-side and transaxle-side boots, noting the shape and size of each one in the figure.



Boot (wheel side)


1. Fill the boot with the grease supplied in the boot kit.

Grease amount

FS engine: 90—110 g {3.18—3.88 oz}


KL engine: 130—150 g {4.59—5.29 oz}

2. Slide the boot onto the shaft.



Cage, inner ring and balls/Snap ring

1. Align the marks and install the balls and cage to the inner ring in the direction shown in the figure.
2. Install a new snap ring.




Boot (differential side), outer ring, clip

1. Fill the boot and outer ring with the grease supplied in the boot kit and joint kit.


Grease amount

FS engine: 120—140 g {4.24—4.94 oz}

KL engine: 140—160 g {4.94—5.64 oz}



2. Align the marks, and install the outer ring onto the shaft.
3. Install a new clip.
4. Install the boot.




5. Set the drive shaft to the standard length.


Standard length

mm {in}

| Engine | Left side | Right side |
|--------|------------------------------|------------------------------|
| FS | 649.2—659.2 {25.56—25.95} | 600.2—610.2 {23.63—24.02} |
| KL | 650.7—660.7 {25.62—26.01} | 600.7—610.7 {23.65—24.04} |



6. Release trapped air from inside the boot (differential side) by using a screwdriver covered with a rag.
7. Verify the drive shaft length.
8. If not within specification, return to Step 5.


**Boot band**

1. Fold the band back in the direction opposite the forward revolving direction of the drive shaft and use pliers to pull it tight.
2. Lock the end of the band by bending the locking clips.


TRIPOD TYPE (ATX)

Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Verify that all parts are free of dust, dirt, and other foreign material immediately before reassembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | |
|---|--|
| <p>1. Boot band Disassembly Note page M-34 Assembly Note page M-36</p> <p>2. Clip</p> <p>3. Outer ring Disassembly Note page M-34 Inspect inside bore for wear, corrosion, and scoring Assembly Note page M-35</p> <p>4. Snap ring Disassembly Note page M-34 Assembly Note page M-35</p> <p>5. Tripod joint Disassembly Note page M-34 Inspect for damage and wear Assembly Note page M-35</p> | <p>6. Boot Inspect for damage Assembly Note page M-35</p> <p>7. ABS sensor rotor Disassembly Note page M-34 Assembly Note page M-35</p> <p>8. Shaft and ball joint assembly Inspect splines for damage and wear Inspect wheel-side joint for excessive play and rough rotation</p> |
|---|--|




Disassembly Note Boot band

Note


- The boot band does not need to be removed unless you are replacing it.

Remove the boot clamp with end clamp pliers as shown and discard the clamp.




Outer ring

Mark the outer ring and the shaft for proper reassembly.



Snap ring/tripod joint


1. Mark the shaft and tripod joint for proper reassembly.
2. Remove the snap ring with snap ring pliers.
3. Remove the tripod joint from the shaft with a bar and a hammer.



Note

- The wheel-side boot does not need to be removed unless you are replacing it.

Wrap the splines of the shaft with tape to prevent damaging the boot.




ABS sensor rotor

Note

- The sensor rotor does not need to be removed unless you are replacing it.

Tap the ABS sensor rotor off the drive shaft by using a chisel.




Assembly Note ABS sensor rotor

Caution


- Verify the direction of the sensor rotor.

Set a new ABS sensor rotor on the drive shaft in the direction shown, and press it onto the shaft assembly by using the SST.




Boot

1. Wrap the splines of the transaxle side shaft, and install the wheel-side and transaxle side boots, noting the shape and size of each one in the figure.




2. Fill the wheel side boot with the grease supplied in the boot kit.

Grease amount: 125—145 g {4.41—5.11 oz}



Snap ring/tripod joint





1. Align the marks and install the tripod joint.
2. Install the new snap ring with snap-ring pliers.



Outer ring

Fill the outer ring and transaxle-side boot with the grease supplied in the boot kit.

Grease amount: 185—215 g {6.52—7.58 oz}



Boot band

1. Verify that the boots are not dented or twisted.

2. Set the drive shaft to the standard length.

Standard length

| | mm {in} | |
|------------|------------------------------|------------------------------|
| | FS engine | KL engine |
| Left side | 695.5—705.5 {27.39—27.77} | 653.6—663.6 {25.74—26.12} |
| Right side | 603.1—613.1 {23.75—24.13} | 603.1—613.1 {23.75—24.13} |

3. Release any trapped air from inside the boot by using a rag-covered screwdriver.
4. Verify that the drive shaft length is within the standard.
5. If the drive shaft length is not within the standard, return to step 1.
6. Install a new boot band on the boot so that the end of the boot band with solts is pointing opposite the forward revolving direction of the drive shaft.
7. Slide the hook into the end slot, and fit the tabs into the remaining two slots.

8. Crimp the clamp securely by using clamp pliers.

Caution

- Do not overcrimp the boot band clamp. Overcrimping could damage the clamp bridge.

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

STEERING SYSTEM

| | |
|--|------|
| INDEX | N- 2 |
| OUTLINE | N- 3 |
| SPECIFICATIONS | N- 3 |
| ENGINE SPEED SENSING POWER STEERING .. | N- 3 |
| PREPARATION | N- 3 |
| TROUBLESHOOTING GUIDE | N- 4 |
| AIR BLEEDING | N- 5 |
| POWER STEERING FLUID | N- 6 |
| STEERING WHEEL AND COLUMN | N- 9 |
| STEERING GEAR AND LINKAGE | N-14 |
| POWER STEERING OIL PUMP | N-18 |
| DRIVE BELT | N-22 |


INDEX

ENGINE SPEED SENSING POWER STEERING (ESPS)

FS ENGINE

POWER STEERING FLUID
SPECIFICATION:
ATF Dexron®II or M-III

STEERING WHEEL
FREE PLAY:
0—30 mm {0—1.18 in}




DRIVE BELT DEFLECTION
AT 98 N {10 kgf, 22 lbf}
NEW: 7.5—9.0 mm {0.30—0.35 in}
USED: 8.0—9.5 mm {0.32—0.37 in}
LIMIT: 11.0 mm {0.43 in}

KL ENGINE

POWER STEERING FLUID
SPECIFICATION:
ATF Dexron®II or M-III

STEERING WHEEL
FREE PLAY:
0—30 mm {0—1.18 in}



DRIVE BELT DEFLECTION
AT 98 N {10 kgf, 22 lbf}
NEW: 6.0—7.0 mm {0.24—0.27 in}
USED: 7.0—8.0 mm {0.28—0.31 in}
LIMIT: 9.0 mm {0.35 in}

- | | |
|--|---|
| <p>1. Steering wheel and column On-vehicle inspection page N- 9 Removal / Installation page N-10 Disassembly / Inspection / Assembly page N-12</p> <p>2. Steering gear and linkage Removal / Installation page N-14 Disassembly / Inspection / Assembly page N-16 Air bleeding page N- 5</p> | <p>3. Power steering oil pump Removal / Installation page N-18 Disassembly / Inspection / Assembly page N-20 Air bleeding page N- 5 Power steering fluid page N- 6</p> <p>4. Drive belt Inspection page N-22 Adjustment page N-23 Replacement page N-23</p> |
|--|---|











OUTLINE

SPECIFICATIONS







| Item | | Specifications |
|---------------------------|----------------------------|------------------------|
| Steering wheel | Outer diameter mm {in} | 380 {15.0} |
| | Lock-to-lock turns | 3.1 |
| Steering gear | Type | Rack-and-pinion |
| | Total gear ratio | 17.0 |
| | Rack stroke mm {in} | 137 {5.39} |
| Steering column and shaft | Shaft type | Collapsible |
| Power assist system | | Engine speed sensing |
| Power steering fluid | Type | ATF Dexron®II or M-III |
| | Capacity L {US qt, Imp qt} | 1.25 {1.32, 1.10} |

ENGINE SPEED SENSING POWER STEERING

PREPARATION
SST

| | | | |
|--|--|---|--|
| <p>49 T028 3A0</p> <p>Puller set, ball joint</p>  | <p>For removal of tie-rod end ball joint</p> | <p>49 0180 510B</p> <p>Attachment, preload</p>  | <p>For inspection of pinion preload</p> |
| <p>49 1232 670A</p> <p>Gauge set, power steering</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 1232 672</p> <p>Gauge (Part of 49 1232 670A)</p>  | <p>For inspection of power steering fluid pressure</p> |
| <p>49 1232 673</p> <p>Body, valve (Part of 49 1232 670A)</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 H002 671</p> <p>Adapter, power steering gauge</p>  | <p>For inspection of power steering fluid pressure</p> |
| <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> | <p>49 9200 020</p> <p>Tension gauge, V-ribbed belt</p>  | <p>For inspection of drive belt tension</p> |
| <p>49 H032 321A</p> <p>Wrench, hexagon</p>  | <p>For removal / installation of adjusting cover</p> | <p>49 D032 316</p> <p>Protractor</p>  | <p>For installation of adjusting cover</p> |

N


| | | | |
|---|--|---|--|
| <p>49 G032 3A4</p> <p>Adapter, power steering gauge</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 G032 351</p> <p>Adapter (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering pressure</p> |
| <p>49 G032 352</p> <p>Adapter (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 G032 353</p> <p>Bolt (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering fluid pressure</p> |
| <p>49 F032 301</p> <p>Hanger, power steering pump</p>  | <p>For disassembly / assembly of power steering oil pump</p> | <p>49 F032 320</p> <p>Installer A</p>  | <p>For assembly of power steering oil pump</p> |

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page/Section |
|--|--|--|--|
| Steering feels heavy | Poor lubrication or abnormal wear of steering assembly ball joint Stuck or damaged lower arm ball joints Improper steering pinion preload Damaged steering gear Malfunctioning steering shaft joint Improperly adjusted wheel alignment Incorrect tire pressure Loose or damaged oil pump drive belt Low fluid level or air in fluid Leakage of fluid Insufficient P/S oil pump pressure | Replace Replace Adjust Replace gear Replace Adjust Adjust Adjust or replace Add fluid or bleed air Repair or replace Replace | N-16 section R N-17 N-14 N-10 section R section Q N-23 N-5, 6 — N-18 |
| Steering wheel pulls to one side | Incorrect tire pressure Unevenly worn tires Weak front spring Worn or damaged stabilizer and/or lower arm bushing Dragging brake Loose lower arm Improperly adjusted wheel alignment | Adjust Replace Replace Replace Repair Tighten or replace Adjust | section Q section Q section R section R section P section R section R |
| General instability while driving | Incorrect tire pressure Damaged or unbalanced wheel Worn or damaged steering shaft joint(s) Improper steering pinion preload Weak front coil spring Worn or damaged stabilizer and/or lower arm bushing Damaged shock absorber Improperly adjusted wheel alignment | Adjust Adjust or replace Replace Adjust Replace Replace Replace Adjust | section Q section Q N-10 N-17 section R section R section R section R |
| Shake (steering wheel vibrates up/down) | Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel(s) Cracked or worn engine mount rubber Cracked or worn transaxle mount rubber | Replace Tighten Adjust or replace Replace Replace | section Q section Q section Q sections B1, B2 sections J, K1, K2 |


| Problem | Possible Cause | Action | Page/Section |
|---|--|--------------------|--------------|
| Shimmy (steering wheel vibrates circumferentially) | Cracked or worn steering gear mount rubber | Replace | N-16 |
| | Loose steering gear mounting bolts | Tighten | N-14 |
| | Stuck or damaged steering ball joint | Replace | N-16 |
| | Excessive tire and/or wheel runout | Replace | section Q |
| | Loose lug nuts | Tighten | section Q |
| | Unbalanced wheel(s) | Adjust or replace | section Q |
| | Incorrect tire pressure | Adjust | section Q |
| | Unevenly worn tires | Replace | section Q |
| | Damaged shock absorber | Replace | section R |
| | Loose shock absorber mounting bolts | Tighten | section R |
| | Stuck or damaged lower arm ball joint | Replace | section R |
| | Cracked or worn suspension bushing | Replace | section R |
| | Damaged or worn front wheel bearing | Replace | section M |
| | Improperly adjusted front wheel alignment | Adjust | section R |
| Excessive steering wheel play | Worn steering gear | Replace gear | N-14 |
| | Worn or damaged steering shaft joints | Replace | N-10 |
| | Worn or damaged lower arm bushing | Replace | section R |
| | Loose steering gear mounting bolts | Tighten | N-14 |
| | Worn linkage or tie rod ball joint | Replace | N-16 |
| Poor steering wheel return | Incorrect tire pressure | Adjust | section Q |
| | Stuck or damaged steering shaft joints | Replace | N-10 |
| | Improperly adjusted front wheel alignment | Adjust | section R |
| | Improperly adjusted steering pinion preload | Adjust | N-17 |
| | Ball joint sticking | Replace | N-16 |
| | Obstruction near steering shaft | Repair | N-10 |
| Abnormal noise from steering system | Loose P/S oil pump or bracket | Tighten | N-18 |
| | Loose steering gear | Tighten | N-14 |
| | Drive belt too loose/tight | Adjust | N-23 |
| | Air in system | Bleed air | N- 5 |
| | Malfunctioning steering gear | Replace gear | N-14 |
| | Malfunctioning P/S oil pump | Replace | N-18 |
| | Obstruction near steering shaft or pressure pipe | Repair or replace | N-10 |
| | Loose steering linkage | Tighten or replace | N-14 |
| | Worn steering shaft joints | Replace | N-10 |

N




AIR BLEEDING

1. Check the fluid level. (Refer to page N-6.)
2. Turn the steering wheel fully left and right several times with the engine not running.
3. Recheck the fluid level. If it has dropped, add fluid.
4. Repeat steps 2 and 3 until the fluid level stabilizes.
5. Start the engine and let it idle.
6. Turn the steering wheel fully left and right several times.



7. Verify that the fluid is not foamy and that the fluid level has not dropped.
8. Add fluid if necessary and repeat steps 6 and 7.



POWER STEERING FLUID

Inspection

Fluid level

Check the power steering fluid level. Add the specified power steering fluid if necessary.

Fluid specification:


ATF Dexron®II or M-III


Fluid leakage

Caution

- Never hold the steering wheel to the extreme left or right for more than five seconds with the engine running. This could damage the power steering pump.

Start the engine and let it idle. Turn the steering wheel fully left and right to apply fluid pressure. Inspect the points shown in the figure for fluid leakage.






Fluid pressure


1. Assemble the **SST** as shown in the figure. Remove the transverse member. (KL engine) (Refer to section R.)

Tightening torque:

40—49 N·m {4.0—5.0 kgf·m, 29—36 ft·lbf}



2. Mark both hose connections to ensure that the hose is reinstalled in its original position.
3. Disconnect the pressure hose from the oil pump. Attach the **SST** (adapters).
4. Connect the **SST** (gauge set) to the **SST** (adapters).
5. Bleed the air from the system. (Refer to page N-5.)




6. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to 50—60°C {122—140°F}.

Caution


- Do not let the valve stay closed for more than five seconds. The increase in fluid temperature will damage the oil pump.

N




7. Close the gauge valve completely. Increase the engine speed to 1,000—1,500 rpm and measure the fluid pressure generated by the oil pump. If the pressure is not within specification, replace the oil pump assembly. (Refer to page N-18.)

Oil pump fluid pressure: 8,340—8,820 kPa {85.0—90.0 kgf/cm², 1,210—1,270 psi}



8. Open the gauge valve fully and increase the engine speed to 1,000—1,500 rpm.

**Caution**

- Do not let the valve stay closed for more than five seconds. The increase in fluid temperature will damage the oil pump.

9. Turn the steering wheel fully left and right and measure the fluid pressure generated within the gear housing. If the pressure is not within specification, repair or replace the steering gear assembly.


**Gear housing fluid pressure: 8,340—8,820 kPa
{85.0—90.0 kgf/cm², 1,210—1,270 psi}**

10. Remove the gauge set. Install and tighten the pressure hose to the specified torque.

Tightening torque:

24—35 N·m {2.4—3.6 kgf·m, 18—26 ft·lbf}


11. Install the transverse member. (Refer to section R.)
12. Bleed the air from the system. (Refer to page N-5.)

**STEERING WHEEL AND COLUMN****On-vehicle Inspection****Steering wheel play**


With the wheels in the straight-ahead position, gently turn the steering wheel left and right and verify that the play is within specification.

Play: 0—30 mm {0—1.18 in}


If the play exceeds specification, either the steering joints are worn or the backlash of the steering gear is excessive.

**Looseness or play of steering wheel**

Move the steering wheel in the directions shown to check for column bearing and bushing wear, steering shaft joint play, steering wheel looseness, and column looseness.

**Steering wheel effort**

1. With the vehicle on a hard, level surface, put the wheels in the straight-ahead position.
2. Start the engine and warm the power steering fluid to 50—60°C {122—140°F}.



3. With the engine running at idle, attach a pull scale to the outermost point of the steering wheel spoke. Then, starting with the wheels in the straight-ahead position, measure the effort required to turn the steering wheel to the left and to the right.

Steering wheel effort:

28—29 N {2.8—3.0 kgf, 6.2—6.6 lbf}

[during one turn of the steering wheel]


4. If not within specification, check the following: fluid level, air in system, fluid leakage at hose or connections, function of oil pump and steering gear, and tire pressure.

Removal / Installation


Warning

- Refer to the 1996 626/MX-6 Body Electrical Troubleshooting Manual for removal and installation of the air bag module.

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Tighten all necessary nuts and bolts to the specified torque.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Air bag module Service ... 1996 626/MX-6 Body Electrical Troubleshooting Manual 2. Locknut 3. Steering wheel Removal Note page N-11 Installation Note page N-11 4. Column cover 5. Combination switch Service ... 1996 626/MX-6 Body Electrical Troubleshooting Manual 6. Lower panel 7. Key interlock cable (ATX) 8. Steering shaft assembly Installation Note page N-11 Disassembly / Inspection / Assembly page N-12 | <ol style="list-style-type: none"> 9. Dynamic damper (FS engine MX-6 with ATX) 10. Intermediate shaft Installation Note page N-11 Inspect for damage Inspect universal joint for looseness, abnormal noise, and sticking 11. Shaft seal Inspect for damage and cracks 12. Set plate 13. Dust cover 14. Bolt (intermediate shaft) Installation Note page N-15 15. Universal joint Inspect for looseness, abnormal noise, and sticking |
|---|---|




Removal note

Steering wheel

Caution

- Do not try to remove the steering wheel by hitting the shaft with a hammer. The column will collapse.

Remove the steering wheel by using a suitable puller.



Installation note

Intermediate shaft and steering shaft assembly


1. Tighten bolt A after tightening bolt B.
2. Tighten bolt C with the steering shaft at its uppermost tilt position.
3. After installation, lightly tap the lower bracket at the point shown by using a hammer to verify correct installation.

Caution

- Do not apply the shock in the axial direction of the shaft.

Note

- If the tilt lever does not move easily, loosen nuts D, tap the lower bracket at the point shown and retighten.




Steering wheel

Set the wheels in the straight-ahead position, and install the steering wheel.


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Steering lock mounting bolts and bracket
 Disassembly Note below
 Assembly Note page N-13
2. Steering lock assembly
 Inspection page N-13


3. Steering shaft assembly
 Inspection page N-13




Disassembly note

Steering lock mounting bolts and bracket

1. Use a chisel and a hammer to make a groove in the heads of the steering lock mounting bolts.
2. Remove the bolts by using a screwdriver.
3. Remove the steering lock assembly.

**Inspection****Steering lock assembly (Automatic transaxle only)**

Verify that the cable connector does not move when the key is in the LOCK position and that it moves freely with the key in other positions.


**Steering shaft assembly**

Check for the following and replace the steering shaft assembly if necessary.

1. Column bushing damage
2. Column bearing damage



3. Steering shaft length

Length: 567.6—569.6 mm {22.35—22.42 in}



4. Tilt operation

- (1) Verify that the adjusting lever moves smoothly from unlock position to lock position.
- (2) Verify that the steering shaft is fixed firmly when the adjusting lever is locked.

**Assembly note****Steering lock mounting bolts and bracket**

1. Install the steering lock assembly on the jacket.
2. Verify that the lock operates correctly.
3. Install new steering lock mounting bolts.
4. Tighten the bolts until the heads break off.

STEERING GEAR AND LINKAGE


Removal / Installation

1. Remove the wheels.
2. Jack up the front of the vehicle and support it on safety stands.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheels.


Tightening torque: 89—117 N·m {9—12 kgf·m, 65—86 ft·lbf}

6. After Installation:

- (1) Check for fluid leakage. (Refer to page N-6.)
- (2) Bleed air from the system. (Refer to page N-5.)
- (3) Check the steering gear and toe-in, and adjust if necessary. (Refer to section R.)




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Cotter pin 2. Nut 3. Tie-rod end ball joint Removal Note page N-15 4. Transverse member (KL engine) Service section R 5. Front exhaust pipe and catalytic converter (KL engine) Service section F2 6. Engine mount Removal Note page N-15 | <ol style="list-style-type: none"> 7. Pressure pipe Installation Note page N-15 8. Return hose and clamp 9. Bolt (Intermediate shaft) Installation Note page N-15 10. Mounting bracket nut and bolt Installation Note page N-15 11. Steering gear and linkage Removal Note page N-15 Disassembly / Inspection / Assembly page N-16 |
|---|---|



Removal note Tie-rod end ball joint

1. Remove the tie rod nut.
2. Separate the tie-rod end from the steering knuckle by using the SST.




Engine mount

1. Use the SST as shown.
2. Remove the engine mount.

Steering gear and linkage

Pull the steering gear from the right side to remove it.




Installation note

Mounting bracket nut and bolt

1. Loosely tighten nuts 4 and 3.
2. Tighten the mounting bracket nuts and bolts to the specified torque in the order shown.


Tightening torque:

38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



Pressure pipe

1. Hand-tighten the pressure pipe fitting to the gear housing, being careful not to damage the O-ring.
2. Hand-tighten bolt A.
3. Tighten bolt B to the specified torque.
4. Tighten bolt A and the pressure pipe fitting to the specified torque.



Bolt (intermediate shaft)


1. Align the marks as shown.
2. Install the intermediate shaft so that the universal joint gap is aligned with the marks.
3. Tighten the bolt.

Tightening torque:


18—26 N·m {1.8—2.7 kgf·m, 13—20 ft·lbf}

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Oil pipe and pipe clip 2. Mounting bracket 3. Heat insulator (KL engine) 4. Mounting rubber 5. Tie-rod end Inspection page N-17 6. Locknut (tie-rod end) 7. Clamp 8. Boot wire 9. Boot 10. Tie rod Inspection page N-17 | <ol style="list-style-type: none"> 11. Locknut (adjusting cover) 12. Adjusting cover Assembly Note page N-17 13. Spring Inspect for damage 14. Pressure pad Inspect for damage 15. Steering gear assembly Inspect for damage and poor operation (Not repairable; replace steering gear assembly) |
|---|---|

**Inspection****Tie-rod end**


1. Inspect the tie-rod end for damage and boot cracks. Replace it as necessary.
2. Inspect the ball joint for looseness. Replace the tie-rod end as necessary.
3. Rotate the ball joint five times.
4. Measure the rotation torque of the ball joint by using the **SST** and a pull scale.

Rotation torque:

0.3—2.9 N·m {3—30 kgf·cm, 2.6—26 in-lbf}

Pull scale reading: 3—29 N {0.3—3 kgf, 0.7—6.6 lbf}

5. If not within specification, replace the tie-rod end.

**Tie rod**

1. Inspect the tie rod for bending and damage. Replace it if necessary.
2. Inspect the ball joint for looseness. Replace the tie rod as necessary.
3. Swing the tie rod five times.
4. Measure the swinging torque by using a pull scale.


Swinging torque:

0.1—3.4 N·m {1—35 kgf·cm, 0.9—30 in-lbf}

Pull scale reading:

0.7—21 N {0.07—2.2 kgf, 0.16—4.8 lbf}

5. If not within specification, replace the tie rod.

**Assembly note****Adjusting cover**

1. Set the rack in the center position.
2. Tighten the adjusting cover to **9.8 N·m {100 kgf·cm, 87 in-lbf}**, then loosen it.
3. Tighten again to **4.4—5.4 N·m {45—55 kgf·cm, 39—48 in-lbf}**, and then return it **20 degrees**.
4. Apply thread-locking compound to the exposed threads of the adjusting cover.
5. Attach the **SST** and a pull scale to the pinion shaft.
6. Measure the pinion preload.

Rack position: Center $\pm 90^\circ$

Pinion preload:

1.2—1.5 N·m {12—16 kgf·cm, 11—13 in-lbf}


Pull scale reading:

12—15 N {1.2—1.6 kgf, 2.8—3.3 lbf}

7. If not within specification, repeat steps 2—6.
8. Tighten the locknut while holding the adjusting cover by using the **SST**.

Tightening torque:


49—58 N·m {5.0—6.0 kgf·m, 37—43 ft-lbf}



POWER STEERING OIL PUMP


Removal / Installation

1. Remove the transverse member. (Refer to section R.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the transverse member. (Refer to section R.)
6. After installation:
 - (1) Adjust the belt deflection. (Refer to page N-23.)
 - (2) Bleed air from the system. (Refer to page N-5.)
 - (3) Check all connections for fluid leakage. (Refer to page N-6.)




- | | |
|--|-----------------------------|
| 1. Locknut | 6. Pulley |
| 2. Idler pulley and bearing | 7. Hose bracket |
| 3. Adjusting bolt | 8. Pump bracket |
| 4. Drive belt | 9. PSP switch connector |
| Inspection page N-22 | 10. Pressure pipe |
| Adjustment page N-23 | 11. Return hose |
| Replacement page N-23 | 12. Power steering oil pump |
| 5. Nut | Disassembly / Inspection / |
| Removal / Installation Note page N-19 | Assembly page N-20 |

FS ENGINE



N-m {kgf-m, ft-lbf}

- | | |
|---|---|
| 1. Lock bolt | 5. Pulley |
| 2. Adjusting bolt | 6. PSP switch connector |
| 3. Drive belt | 7. Pressure pipe |
| Inspection page N-22 | 8. Return hose |
| Adjustment page N-23 | 9. Pulley cover |
| Replacement page N-23 | 10. Power steering oil pump and bracket |
| 4. Nut | Disassembly / Inspection / |
| Removal / Installation Note below | Assembly page N-20 |




Removal / Installation note
Nut


Insert a screwdriver through a hole of the pulley, and while holding the pulley, loosen/tighten the nut.

Disassembly / Inspection / Assembly

1. The following procedure is for replacement of the O-rings, the shaft, and the pump body (front) only. Replace the oil pump assembly if other repairs are necessary.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Bracket (FS engine) 2. Bracket 3. Suction pipe 4. O-ring 5. PSP switch assembly 6. O-ring 7. Connector 8. O-ring 9. Control valve Inspect for clogging, cracks, and damage 10. Spring Inspect for weakness 11. Pump body (Rear) Assembly Note page N-22 Inspect for cracks, wear, and damage 12. Gasket 13. Pin | <ol style="list-style-type: none"> 14. Cam ring Assembly Note page N-22 Inspect for wear and damage 15. Rotor Inspect for wear and damage 16. Blade Assembly Note page N-22 Inspect for wear and damage 17. Side plate Inspect for wear and damage 18. O-ring 19. Pump body (Front) Inspect for cracks, wear, and damage 20. Snap ring 21. Shaft and bearing Disassembly Note page N-21 Assembly Note page N-21 22. Oil seal Assembly Note page N-21 |
|--|---|



Disassembly note


Oil pump

Install the pump to the **SST** and hold the pump and **SST** in a vise.



Shaft and bearing


Remove the shaft and bearing by using a press.



Assembly note


Oil seal

Tap the oil seal into the pump body (front) by using the **SST**.




Shaft and bearing

Press the shaft and bearing into the pump body (front) by using the **SST**.



Cam ring

Install the cam ring in the pump body (front) with the mark facing upward.




Blade

Place the blades in the rotor with the rounded edges contacting the cam.

Pump body (Rear)


After installing the pump body (rear), manually turn the shaft to verify that it rotates smoothly.




DRIVE BELT

Inspection

1. Check the drive belt for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belt is correctly mounted on the pulleys.



3. Check the belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure **98 N {10 kgf, 22 lbf}** midway between the specified pulleys.




Deflection

| | mm {in} | | |
|-----------|------------------------|------------------------|-------------|
| | New* | Used | Limit |
| KL engine | 6.0—7.0 {0.24—0.27} | 7.0—8.0 {0.28—0.31} | 9.0 {0.35} |
| FS engine | 7.5—9.0 {0.30—0.35} | 8.0—9.5 {0.32—0.37} | 11.0 {0.43} |

* A belt that has been on a running engine for less than five minutes.

4. If the deflection is not within specification, adjust it.



Drive belt tension check


Belt tension can be checked in place of belt deflection. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the **SST**, check the belt tension between any two pulleys.

Tension

N {kgf, lbf}

| | New* | Used | Limit |
|-----------|-----------------------------|-----------------------------|--------------|
| KL engine | 540—680 {55—70, 130—150} | 400—530 {40—55, 10—150} | 340 {35, 77} |
| FS engine | 590—780 {60—80, 140—170} | 500—680 {50—70, 110—150} | 390 {40, 88} |

* A belt that has been on a running engine for less than five minutes.




Adjustment

Loosen idler pulley locknut (bolt) A, and adjust the belt deflection by turning adjusting bolt B.

Tightening torque

A: 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}



Replacement


1. Remove the alternator A/C drive belt. (KL engine) (Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual.)
2. Loosen locknut (bolt) A and adjusting bolt B.
3. Remove and replace the drive belt.
4. Adjust the deflection (tension). (Refer to above.)
5. Install the alternator A/C drive belt. (KL engine) (Refer to 1996 626/MX-6 Body Electrical Troubleshooting Manual.)

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

BRAKING SYSTEM


| | | | |
|--------------------------------------|------|---------------------------------------|------|
| INDEX | P- 2 | PARKING BRAKE SYSTEM | P-36 |
| OUTLINE | P- 4 | TROUBLESHOOTING GUIDE | P-36 |
| SPECIFICATIONS | P- 4 | PARKING BRAKE SHOE | P-36 |
| CONVENTIONAL BRAKE SYSTEM ... | P- 5 | PARKING BRAKE (LEVER TYPE) . | P-36 |
| PREPARATION | P- 5 | PARKING BRAKE CABLE | P-37 |
| TROUBLESHOOTING GUIDE | P- 6 | PARKING BRAKE LEVER | P-38 |
| AIR BLEEDING | P- 7 | ANTILOCK BRAKE SYSTEM (ABS) .. | P-38 |
| BRAKE HYDRAULIC LINE | P- 7 | PREPARATION | P-38 |
| BRAKE FLUID | P- 9 | TROUBLESHOOTING GUIDE | P-39 |
| VACUUM LINE | P- 9 | WIRING DIAGRAM | P-40 |
| BRAKE PEDAL | P-10 | RELATIONSHIP CHART | P-41 |
| MASTER CYLINDER | P-12 | QUICK DIAGNOSIS CHART | P-41 |
| POWER BRAKE UNIT | P-18 | DIAGNOSTIC INDEX | P-41 |
| DUAL PROPORTIONING VALVE ... | P-22 | SYMPTOM TROUBLESHOOTING .. | P-42 |
| FRONT BRAKE (DISC) | P-24 | ON-BOARD DIAGNOSTIC SYSTEM | P-45 |
| DISC PAD | P-25 | ABS HYDRAULIC UNIT | P-60 |
| DISC PLATE | P-26 | ABS CONTROL MODULE | P-63 |
| CALIPER | P-26 | ABS RELAY | P-64 |
| REAR BRAKE (DISC) | P-28 | ABS WHEEL-SPEED SENSOR | |
| DISC PAD | P-29 | (FRONT) | P-66 |
| DISC PLATE | P-30 | ABS SENSOR ROTOR (FRONT) ... | P-67 |
| CALIPER | P-31 | ABS WHEEL-SPEED SENSOR | |
| REAR BRAKE (DRUM) | P-33 | (REAR) | P-69 |
| WHEEL CYLINDER | P-35 | ABS SENSOR ROTOR (REAR) | P-70 |

INDEX



| | | | |
|---|-----------|---|-----------|
| 1. Brake hydraulic line Inspection / Removal / Installation | page P- 8 | 11. Caliper Disassembly / Inspection / Assembly | page P-26 |
| 2. Brake fluid Inspection | page P- 9 | 12. Rear brake (disc) Inspection (on-vehicle) | page P-28 |
| Replacement | page P- 9 | Removal / Inspection / Installation | page P-28 |
| 3. Vacuum line Inspection | page P- 9 | 13. Disc pad Replacement | page P-29 |
| 4. Brake pedal Inspection (on-vehicle) | page P-10 | 14. Disc plate Inspection | page P-30 |
| Removal / Inspection / Installation | page P-11 | 15. Caliper Disassembly / Inspection / Assembly | page P-31 |
| 5. Master cylinder Removal / Installation | page P-12 | 16. Rear brake (drum) Inspection (on-vehicle) | page P-33 |
| Disassembly / Inspection / Assembly | page P-16 | Removal / Inspection / Installation | page P-33 |
| 6. Power brake unit Inspection (on-vehicle) | page P-18 | 17. Wheel cylinder Disassembly / Inspection / Assembly | page P-35 |
| Removal / Installation | page P-20 | 18. Parking brake (lever type) Inspection (on-vehicle) | page P-36 |
| 7. Dual proportioning valve Inspection | page P-22 | Adjustment | page P-36 |
| Replacement | page P-22 | 19. Parking brake cable Removal / Inspection / Installation | page P-37 |
| 8. Front brake (disc) Inspection (on-vehicle) | page P-24 | 20. Parking brake lever Removal / Inspection / Installation | page P-38 |
| Removal / Inspection / Installation | page P-24 | | |
| 9. Disc pad Replacement | page P-25 | | |
| 10. Disc plate Inspection | page P-26 | | |

ANTILOCK BRAKE SYSTEM (ABS)



- | | |
|--|---|
| <p>21. ABS hydraulic unit Inspection page P-60 Removal / Installation page P-61</p> <p>22. ABS control module Removal / Installation page P-63</p> <p>23. ABS relay Removal / Inspection / Installation page P-64</p> <p>24. ABS wheel-speed sensor (front) Removal / Inspection / Installation page P-66</p> | <p>25. ABS sensor rotor (front) Removal / Inspection page P-67 Installation page P-68</p> <p>26. ABS wheel-speed sensor (rear) Removal / Inspection / Installation page P-69</p> <p>27. ABS sensor rotor (rear) Removal / Installation page P-70</p> |
|--|---|












OUTLINE

SPECIFICATIONS

| Item | | Engine | FS | | KL | |
|------------------------------|---|---------|--|--------------------------|-------------------|-----------|
| | | | non ABS | ABS | non ABS | ABS |
| Brake pedal | Type | | Suspended | | | |
| | Pedal lever ratio | | 4.1 | | | |
| | Max. stroke | mm {in} | 125 {4.92} | | | |
| Master cylinder | Type | | Tandem (with level sensor) | | | |
| | | | Conventional | Port-less | Conventional | Port-less |
| | Cylinder inner diameter | mm {in} | 23.81 {0.937} | | | |
| Front disc brake | Type | | Ventilated disc | | | |
| | Cylinder bore | mm {in} | 57.15 {2.250} | | | |
| | Pad dimensions (area × thickness) mm ² {in ² } × mm {in} | | 4800 {7.44} × 10 {0.39} | | | |
| | Disc plate dimensions (outer diameter × thickness) | mm {in} | 258 × 24 {10.16 × 0.94} | | | |
| Rear disc brake | Type | | — | Solid disc | | |
| | Cylinder bore | mm {in} | — | 30.16 {1.187} | | |
| | Pad dimensions (area × thickness) mm ² {in ² } × mm {in} | | — | 2900 × 8.0 {4.49 × 0.31} | | |
| | Disc plate dimensions (outer diameter × thickness) | mm {in} | — | 261 × 10.0 {9.88 × 0.39} | | |
| Rear drum brake | Type | | Leading-trailing | — | | |
| | Wheel cylinder inner diameter | mm {in} | 17.46 {0.687} | — | | |
| | Lining dimensions (width × length × thickness) | mm {in} | 30 × 219.3 × 4.5 {1.18 × 8.63 × 0.18} | — | | |
| | Drum inner diameter | mm {in} | 228.6 {9.000} | — | | |
| | Shoe clearance adjustment | | Automatic adjuster | — | | |
| Power brake unit | Type | | Vacuum multiplier | | | |
| | | | Single diaphragm | | Tandem diaphragm | |
| | Diameter | mm {in} | 239 {9.4} | | 188+215 {7.4+8.5} | |
| Braking force control device | Type | | Dual proportioning valve | | | |
| Brake fluid | | | FMVSS116, DOT-3 | | | |
| Parking brake | Type | | Mechanical two-rear-wheel control | | | |
| | Operation system | | Center lever | | | |

CONVENTIONAL BRAKE SYSTEM


PREPARATION
SST

| | | | |
|---|---|---|--|
| <p>49 0259 770B</p> <p>Wrench, flare nut</p>  | <p>For removal of brake pipe</p> | <p>49 F043 001</p> <p>Adjust gauge</p>  | <p>For adjustment of push rod clearance</p> |
| <p>49 0208 701A</p> <p>Air-out tool, boot</p>  | <p>For removal of piston seal</p> | <p>49 0221 600C</p> <p>Expand tool, disc brake</p>  | <p>For installation of brake pads (Front disc brake)</p> |
| <p>49 B043 001</p> <p>Adjust gauge</p>  | <p>For adjustment of push rod clearance</p> | <p>49 E043 003A</p> <p>Lock tool, turning</p>  | <p>For adjustment of push rod clearance</p> |
| <p>49 B043 004</p> <p>Socket wrench</p>  | <p>For adjustment of push rod clearance</p> | <p>49 U043 0A0</p> <p>Gauge set, oil pressure</p>  | <p>For inspection of brake fluid pressure</p> |
| <p>49 U043 004</p> <p>Gauge, oil pressure (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> | <p>49 U043 005</p> <p>Joint (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> |
| <p>49 U043 006</p> <p>Hose (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> | <p>—</p> | <p>—</p> |

P

TROUBLESHOOTING GUIDE



| Problem | Possible cause | Action | Page |
|--|---|-------------------------|--------------|
| Poor braking | Leakage of brake fluid | Repair | — |
| | Air in system | Bleed air | P- 7 |
| | Worn disc pad or brake shoe | Replace | P-25, 29, 33 |
| | Brake fluid, grease, oil or water on disc pad or brake shoe | Clean or replace | P-25, 29, 33 |
| | Hardening of disc pad or brake shoe surface or poor contact | Grind or replace | P-25, 29, 33 |
| | Malfunction of caliper piston or wheel cylinder | Replace | P-26, 31, 33 |
| | Malfunction of master cylinder or wheel cylinder | Repair or replace | P-12, 16, 33 |
| | Malfunction of power brake unit | Replace | P-20 |
| | Malfunction of check valve (vacuum hose) | Replace | P- 9 |
| | Damaged vacuum hose | Replace | P- 9 |
| | Deterioration of flexible hose | Replace | P- 8 |
| Malfunction of dual proportioning valve | Replace | P-22 | |
| Brakes pull to one side | Worn disc pad or brake shoe | Replace | P-25, 29, 33 |
| | Brake fluid, grease, oil or water on disc pad or brake shoe | Clean or replace | P-25, 29, 33 |
| | Hardening of disc pad brake shoe surface or poor contract | Grind or replace | P-25, 29, 33 |
| | Abnormal wear, distortion of disc plate or drum | Repair or replace | P-24, 28, 33 |
| | Malfunction of automatic adjuster | Repair or replace | P-31, 33 |
| | Loose or damaged dust cover/backing plate mounting bolt | Tighten or replace | section M |
| | Malfunction of caliper piston or wheel cylinder | Replace | P-26, 31, 33 |
| | Worn or improperly adjusted wheel bearing preload | Adjust or replace | section M |
| Improper adjustment of wheel alignment | Adjust | section R | |
| Unequal tire air pressure | Adjust | section Q | |
| Brakes do not release | No brake pedal play | Adjust | P-10 |
| | Improper adjustment of push rod clearance | Adjust | P-13 |
| | Clogged master cylinder return port | Clean | — |
| | Brake pad not returning properly | Repair | — |
| | Improper return or malfunction of caliper piston or wheel cylinder piston | Repair or replace | P-26, 31, 35 |
| | Excessive runout of disc plate | Repair or replace | P-24, 28 |
| Improper adjustment of wheel bearing preload | Adjust or replace | section M | |
| Pedal goes too far (Excessive pedal stroke) | Air in system, insufficient brake fluid | Add fluid and bleed air | P-7, 9 |
| | Improper adjustment of pedal play | Adjust | P-10 |
| | Worn disc pad or brake shoe | Replace | P-25, 29, 33 |
| Abnormal noise or vibration during braking | Worn disc pad or brake shoe | Replace | P-25, 29, 33 |
| | Damaged pad or brake shoe | Grind or replace | P-25, 29, 33 |
| | Brakes do not release | Repair | — |
| | Foreign material or scratches on disc plate or drum contact surface | Clean | — |
| | Loose backing plate/dust cover or caliper mounting bolt | Tighten | P-24, 28, 33 |
| | Damaged disc plate or drum contact surface | Replace | P-24, 28, 33 |
| | Poor contact of pad or brake shoe | Repair or replace | P-25, 29, 33 |
| | Insufficient grease on sliding parts | Apply grease | — |



AIR BLEEDING

Note

- The brakes should be bled whenever a brake line is disconnected. If a hydraulic line is disconnected at the master cylinder, start at the slave cylinder farthest from the brake master cylinder, and move to the next closest slave cylinder until all four cylinders have been bled. If the disconnection point is anywhere except the master cylinder, start at the point closest to the disconnection, and move to the next farthest slave cylinder until all four cylinders have been bled.




1. Jack up the vehicle and support it with safety stands.
2. Remove the bleeder cap and attach a vinyl hose to the bleeder plug.
3. Place the other end of the vinyl tube in a clear container.
4. One person should depress the brake pedal a few times, and then hold it in the depressed position.
5. A second person should loosen the bleeder screw, drain out the fluid, and retighten the screw by using the **SST**.
6. Repeat steps 4 and 5 until no air bubbles are seen. The reservoir should be kept about 3/4 full during bleeding to prevent air from reentering the lines.
7. Check for correct brake operation.
8. Verify that there is no fluid leakage. Wipe off any spilled fluid immediately.
9. After bleeding the air, add brake fluid to the reservoir up to the specified level.

Tightening torque

Front: 7—9 N·m {72—91 kgf·cm, 63—78 in·lbf}


Rear: 5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}

BRAKE HYDRAULIC LINE




1. Brake pipe
Inspection / Removal /
Installation page P-8


2. Flexible hose
Inspection / Removal /
Installation page P-8

**Inspection (on-vehicle)****Brake pipe**


Check for cracks, damage, and corrosion of the brake pipe. Replace the pipe or flare nut(s) if necessary.

**Flexible hose**


Check for scars, cracks, and swelling of the flexible hose. Replace the hose if necessary.

**Removal**

1. Remove the brake pipe by using the **SST**.
2. Disconnect the clip and remove the flexible hose from the bracket.

**Installation**


1. Secure the flexible hose in the bracket and connect the clip to it.



2. Connect the flexible hose to the brake pipe. Verify that the hose is not twisted.
3. Tighten the flare nut by using the **SST**. Verify that the hose can not come in contact with any other parts of vehicle.

Tightening torque:

12.9—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}



BRAKE FLUID


Inspection

1. Depress the brake pedal several times, and inspect for leakage of the brake line system.



2. Verify that the fluid level in the reservoir is between the MAX and MIN lines on the reservoir.
3. If the fluid level is extremely low, check the brake system for leakage.

Fluid specification: FMVSS116, DOT-3




Replacement

Caution

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.


1. Remove the brake fluid from the reservoir by using a suction pump.
2. Fill the reservoir with clean brake fluid.
3. Attach a vinyl tube to the farthest bleeder screw and place the other end of the tube in a clear container.
4. Remove all old brake fluid from the brake lines by loosening the bleeder screw and pumping the brake pedal until only clean fluid is seen. The reservoir should be kept about 3/4 full during bleeding to prevent air from re-entering the lines.
5. Perform the above for all bleeder screws.
6. Fill the reservoir to the specified levels.




VACUUM LINE

Inspection

1. Remove the clamps and the hose.
2. Apply both suction and pressure to the engine-side of the hose, and verify that air flows only toward that side. If air flows in both directions or not at all, replace the vacuum hose.



P

**BRAKE PEDAL****Inspection (on-vehicle)****Brake pedal height****Inspection**

Verify that the distance from the center on the pedal pad to the carpet is as specified.

Specification: 191.5—196.5 mm {7.54—7.74 in}

Adjustment

1. Loosen locknut (B) and turn bolt (A) until it does not contact the pedal.
2. Loosen locknut (D) and turn rod (C) to adjust the height.
3. Adjust the pedal free play and tighten locknut (D).
4. Turn bolt (A) until it contacts the pedal; then turn an additional 1/2 turn.
5. Tighten locknut (B).

Tightening torque:

9.81—14.7 N·m {100—150 kgf·cm, 86.9—130 in·lbf}

Pedal Play**Inspection**

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Remove the snap pin, verify that the holes in the fork and in the pedal are aligned, then reinstall the pin.
3. Gently depress the pedal by hand and check the free play (until resistance is felt).

Pedal play: 4—12 mm {0.16—0.47 in}

Adjustment

1. Remove the spring pin and the clevis pin.
2. Loosen locknut (D) and turn rod (C) to align the holes in the fork and in the pedal.
3. Install the clevis pin and a new spring pin.
4. Verify the pedal height and the brake light operation.

Tightening torque:

24—34 N·m {2.4—3.5 kgf·m, 17—25 ft·lbf}




Pedal-To-Floor Clearance**Inspection**

Verify that the distance from the floor panel to the pedal pad center is as specified when the pedal is depressed with a force of 589 N {60 kgf, 132 lbf}.

Pedal-to-floor clearance: 85 mm {3.35 in} min.


If the distance is less than specified, check for the following problems:

1. Air in brake system
2. Malfunction of automatic adjuster
3. Worn pads




Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.
4. After installation, check and if necessary adjust the pedal height and free play.



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Brake switch connector 2. Spring pin 3. Clevis pin 4. Steering shaft Service section N 5. Brake switch Inspection below | <ol style="list-style-type: none"> 6. Pedal pad Inspect for wear and damage 7. Brake pedal Inspect for bending and damage |
|--|---|




Inspection
Brake switch


1. Disconnect the brake switch connector.
2. Connect an ohmmeter between the terminals of the brake switch.
3. Confirm continuity between the terminals when the brake pedal is depressed.

**MASTER CYLINDER
Removal / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.



- | | |
|---------------------------------------|------------------------------------|
| 1. Brake fluid level sensor connector | 5. Bracket |
| 2. Brake pipe | 6. Master cylinder |
| Removal Note below | Disassembly / Inspection / |
| Installation Note page P-15 | Assembly page P-16 |
| 3. Hose (MTX) | Installation Note page P-13 |
| 4. Nut | 7. O-ring (Except MTX without ABS) |








**Removal note
Brake pipe**

Caution

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.

Disconnect the brake pipe from the master cylinder by using the SST.



Installation note
Master cylinder (MTX without ABS)
Piston to push rod clearance

1. Place the **SST** atop the master cylinder. Turn the adjusting bolt until it touches the bottom of the push rod hole in the piston.
2. Apply **66.7 kPa {500 mmHg, 19 inHg}** vacuum to the power brake unit by using a vacuum pump.
3. Invert the adjustment gauge used in step 1 and place it on the power brake unit.
4. Measure the clearance between the end of the **SST** and the push rod of the power brake unit. If it is not **0 mm {0 in}**, loosen the push rod locknut and turn the push rod to make the adjustment by using the **SSTs**.

Note

- This adjustment produces the following clearance.

| Vacuum applied to unit | Push rod to piston clearance |
|--|------------------------------|
| Approx. 66.7 kPa {500 mmHg, 19.7 inHg} | 0.1—0.4 mm {0.004—0.016 in} |


Master cylinder (except MTX without ABS)
Piston to push rod clearance

1. Turn the nut of the **SST** clockwise to fully retract the **SST** gauge rod. Attach the **SST** to the power brake unit.

Tightening torque:


9.81—15.6 N·m {100—160 kgf·cm, 87—138 in·lbf}

2. Apply **66.7 kPa {500 mmHg, 19.7 inHg}** vacuum to the power brake unit by using a vacuum pump.
3. Turn the adjusting nut of the **SST** counterclockwise until the gauge rod just contacts the push rod end of the power brake unit. Push lightly on the end of the gauge rod to be sure it is seated. Verify that there is no gap between the adjusting nut and **SST** body.



4. Remove the **SST** from the power brake unit without disturbing the adjusting nut. Set the **SST** onto the master cylinder as shown in the figure.
5. Push lightly on the end of the **SST** gauge rod to be sure it is bottomed in the master cylinder piston, but do not push so hard that the piston moves. Note any clearance between the **SST** body and the adjusting nut (clearance B) or between the body and the master cylinder (clearance C). Adjust the push rod as necessary as outlined in "Adjustment" below.

| Measurement | Push rod |
|----------------------------|-----------|
| Clearance at (B) | Too short |
| Clearance at (C) | Too long |
| No clearance at (B) or (C) | OK |




Adjustment

The threads of the push rod are specially designed so that the bolt becomes harder to turn past a certain point. This is to prevent the bolt from coming loose. Turn the bolt only within this range when adjusting.


Clearance at (B)


1. Push lightly on the end of the **SST** gauge rod, and measure the clearance between the adjusting nut and the **SST** body.
2. Using the **SSTs**, turn the nut to lengthen the power brake unit push rod to an amount equal to the clearance measured at (B).




Clearance at (C)

1. Measure and record height (D1) of the gauge rod.






2. Turn the adjusting nut until the **SST** body sets squarely on the master cylinder. (Turn only enough for the body to touch.)
3. Measure and record height D2 of the gauge rod.




4. Subtract D1 from D2 and using the **SSTs**, turn the nut to shorten the power brake unit push rod an amount equal to the sum.



Note

- This adjustment produces the following clearance.

| Vacuum applied to unit | Push rod to piston clearance |
|---|------------------------------|
| Approx. 66.7 kPa {500 mmHg, 19.7 inHg} | 0.1—0.4 mm {0.004—0.016 in} |



Brake pipe

Tighten the brake pipe flare nut by using the **SST**.

Tightening torque:


12.9—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}

Disassembly / Inspection / Assembly

1. After removing the brake fluid, disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary. If the master cylinder body is damaged, replace the unit as an assembly.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.


Caution

- The brake master cylinder is made of aluminum, and can be easily damaged by tightening in a vise. When securing the master cylinder in a vise, tighten only the flange of the master cylinder.



- | | |
|------------------------------------|-----------|
| 1. Brake fluid level sensor | |
| Inspection | page P-17 |
| 2. Cap set | |
| 3. Filter | |
| 4. Screw | |
| 5. Reservoir | |
| Inspect for damage and deformation | |
| 6. Bushings | |
| 7. Snap ring | |
| 8. Spacer | |
| 9. Piston guide | |
| 10. O-ring | |


- | | |
|---|-----------|
| 11. Cup | |
| 12. Stopper | |
| 13. Primary piston assembly | |
| Inspect for abnormal wear, rust, and damage | |
| 14. Stop screw and O-ring (Non-ABS model) | |
| Assembly Note | page P-17 |
| 15. Stop pin and O-ring (ABS model) | |
| Assembly Note | page P-17 |
| 16. Secondary piston assembly | |
| Inspect for abnormal wear, rust, and damage | |
| 17. Master cylinder body | |
| Inspect inside of body for corrosion | |



Assembly note


Stop screw and O-ring (non-ABS model)

1. Push the secondary piston assembly in fully.
2. Install and tighten a new O-ring and stop screw.
3. Push and release the piston to verify that it is held by the stop screw.



Stop pin and O-ring (ABS model)


1. Install the secondary piston assembly with the piston hole facing the stop pin.
2. Install and tighten the new O-ring and stop pin.
3. Push and release the piston to verify that it is held by the stop pin.



Inspection

Fluid level sensor


1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above the MIN mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the MIN mark.
5. Replace the sensor if necessary.



POWER BRAKE UNIT
Quick Inspection (on-vehicle)
Power brake unit function check
(Simple method)


Step 1

1. With the engine stopped, depress the pedal a few times.
2. With the pedal depressed, start the engine.
3. If the pedal moves down slightly immediately after the engine starts, the unit is operating.



Step 2


1. Start the engine.
2. Stop the engine after it has run for **1 or 2 minutes**.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect the check valve and vacuum hose for damage and examine the installation. Repair if necessary, and inspect it again.



Step 3


1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, check the check valve and vacuum hose for damage, and check the connection. Repair if necessary and check again.

If the nature of the problem is still not clear after the 3 steps above, follow the more detailed check described in "Inspection using gauges" below.




(Inspection using gauges)

Connect the **SSTs** gauges, vacuum gauge (A), and pedal depression force gauge (B) as shown. Bleed the air from the **SSTs** gauges before performing the following tests.




a) Checking for vacuum loss
Unloaded condition

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa {475—500 mmHg, 18.7—19.7 inHg}**, the unit is operating.



Loaded condition


1. Start the engine.
2. Depress the brake pedal with a force of **196 N {20 kgf, 44 lbf}**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa {475—500 mmHg, 18.7—19.7 inHg}**, the unit is operating.



b) Checking for hydraulic pressure

1. If the fluid pressure is within the specification when the engine is stopped (vacuum **0 kPa {0 mmHg, 0 inHg}**), the unit is operating.

| Pedal force | N {kgf, lbf} | Fluid pressure kPa {kgf/cm ² , psi} |
|-------------|--------------|--|
| | 196 {20, 44} | 883 {9, 128} min. |




2. Start the engine. Depress the brake pedal when the vacuum reaches **66.7 kPa {500 mmHg, 19.7 inHg}**. If the fluid pressure is within the specification, the unit is operating.


| Pedal force | N {kgf, lbf} | Fluid pressure kPa {kgf/cm ² , psi} |
|-------------|--------------|--|
| | 196 {20, 44} | MTX: 7061 {72, 1024} min. |
| | | ATX: 8826 {90, 1280} min. |

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, perform the following.
 - (1) Add fluid and bleed the air. (Refer to page P-7.)
 - (2) Check and adjust the brake pedal height. (Refer to page P-10.)
 - (3) Check for fluid leakage. (Refer to page P-9.)



- | | |
|---|------------------------------------|
| 1. Brake fluid level sensor connector | 7. O-ring (Except MTX without ABS) |
| 2. Hose (MTX) | 8. Vacuum hose |
| 3. Brake pipe | 9. Spring pin |
| Removal / Installation Note page P-21 | 10. Clevis pin |
| 4. Nut | 11. Nut |
| 5. Bracket | 12. Fork |
| 6. Master cylinder | 13. Nut |
| Removal / Installation page P-12 | 14. Power brake unit |
| Disassembly / Inspection / | 15. Gasket |
| Assembly page P-16 | |




Removal / Installation note
Brake pipes

Caution

- Brake fluid will damage painted surfaces. If it does get on a painted surface, wipe it off immediately.

Loosen and tighten the brake pipes by using the SST.



DUAL PROPORTIONING VALVE

Inspection


1. Connect the SSTs to the brake pipes with adapters as shown in the figure.

Adapter and flare nut tightening torque:

12.9—21.5 N·m {130—220 kgf·m, 113—190 ft·lbf}

Note

- Connect the brake pipes by using the SST (49 0259 770B).



2. Bleed the air from the brake system. (Refer to page P-7.)
3. Depress the brake pedal until the master cylinder pressure equals A; then record rear brake pressure A'.
4. Depress the brake pedal again, apply additional pressure until the pressure equals B; then record pressure B'.


Fluid pressure

kPa {kgf/cm², psi}

| | A | A' | B | B' |
|---------------|---------------|----------------------------|---------------|------------------------------|
| Non-ABS MODEL | 3400 {35,500} | 3400 {35,500} ± 200 {2,30} | 5880 {60,850} | 4170 {42,5,600} ± 294 {3,43} |
| ABS MODEL | 3400 {35,500} | 3400 {35,500} ± 200 {2,30} | 5880 {60,850} | 4410 {45,640} ± 294 {3,43} |


Replacement

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.



1. Brake pipe
Removal / Installation Note page P-23
2. Bolts

3. Dual proportioning valve
Installation Note page P-23




Removal / Installation note

Brake pipe

Loosen and tighten the brake pipe by using the SST.

Tightening torque:


12.9—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}



Installation note

Dual proportioning valve

Install the dual proportioning valve with the R marks facing the right side.



**FRONT BRAKE (DISC)
Inspection (on-vehicle)
Disc pad**


1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels and tires.
3. Look through the caliper inspection hole and inspect the remaining thickness of the pads.

Thickness: 2.0 mm {0.08 in} min.


4. Replace the pads as a set (right and left wheels) if either is at or less than the minimum thickness.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, perform the following.
 - (1) Add fluid and bleed the air. (Refer to page P-7.)
 - (2) Check for fluid leakage. (Refer to page P-9.)
 - (3) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Flexible hose 2. Bolt 3. Caliper Disassembly / Inspection / Assembly page P-26 4. V-spring 5. Disc pad Inspection above Installation Note page P-25 | <ol style="list-style-type: none"> 6. Outer shim 7. Inner shim 8. Guide plate 9. Mounting support 10. Disc plate Inspection page P-26 |
|--|--|




Installation note

Disc pad

Before installing the disc pads, push the piston fully inward by using the **SST**.



DISC PAD Replacement

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|-------------|----------------|
| 1. Bolt | 5. Outer shim |
| 2. Caliper | 6. Inner shim |
| 3. V-spring | 7. Guide plate |
| 4. Disc pad | |

Installation Note above



DISC PLATE

Inspection

Disc plate thickness

1. Measure the thickness of the disc plate.

Caution

- When it is necessary to machine the disc plate, if the disc plate is removed from the vehicle then machined, excessive runout may result. Machine the disc plate with it installed on the vehicle.

Standard: 24 mm {0.94 in}

Minimum: 22 mm {0.87 in}

Minimum thickness after machining by using a brake lathe on-vehicle: 22.8 mm {0.90 in}

2. If the thickness is not within the specifications, replace the disc plate.

Disc plate runout

1. Verify that there is no wheel bearing looseness.
2. Measure the runout at the outer edge of the contact surface of the disc pad.


Runout: 0.05 mm {0.002 in} max.

3. If the runout is not within the specification, repair or replace the disc plate.


CALIPER

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Dust seal Inspect for damage and poor sealing 2. Piston Disassembly Note page P-27 Inspect for wear and rust 3. Piston seal Disassembly Note page P-27 | <ul style="list-style-type: none"> 4. Bleeder cap, bleeder screw Disassembly Note page P-27 Assembly Note page P-27 5. Caliper body Inspect for damage, wear and rust 6. Boot |
|---|--|



Disassembly note

Piston


- 1. Place a piece of wood in the caliper.
- 2. Gently blow compressed air through the pipe hole to force the piston out of the caliper.



49 0208 701A

Piston seal


Remove the piston seal from the caliper by using the SST.



49 0259 770B

Bleeder screw

Loosen the bleeder screw by using the SST.



49 0259 770B


Assembly note

Bleeder screw

Tighten the bleeder screw by using the SST.

Tightening torque:

7—9 N·m {72—91 kgf·cm, 63—78 in·lbf}




**REAR BRAKE (DISC)
Inspection (on-vehicle)
Disc pad**

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels and tires.
3. Verify the remaining thickness of the pads.


Thickness: 1.0 mm {0.04 in} min.

Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the following.
 - (1) Add fluid and bleed the air. (Refer to page P-7.)
 - (2) Check for fluid leakage. (Refer to page P-9.)
 - (3) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.




- | | |
|---|--|
| <p>1. Parking brake cable, clip Removal / Inspection / Installation page P-37</p> <p>2. Connecting bolt</p> <p>3. Brake hose</p> <p>4. Screw plug</p> <p>5. Manual adjustment gear Removal Note page P-29 Installation Note page P-29</p> <p>6. Lock bolt</p> <p>7. Caliper Disassembly / Inspection / Assembly page P-31</p> | <p>8. M-spring</p> <p>9. Disc pad Inspection above</p> <p>10. Outer shim</p> <p>11. Inner shim</p> <p>12. Guide plate</p> <p>13. Bolt</p> <p>14. Mounting support</p> <p>15. Disc plate Inspection page P-30</p> |
|---|--|



Removal note

Manual adjustment gear

Turn the manual adjustment gear counterclockwise with an Allen wrench to pull the brake caliper piston inward. (Turn until it stops.)



Installation note


Manual adjustment gear

1. Turn the manual adjustment gear clockwise until the brake pads just touch the disc plate.
2. Return the manual adjustment gear 1/3-turn.


DISC PAD

Replacement

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|------------------------------|----------------|
| 1. Parking brake cable, clip | 5. M-spring |
| 2. Screw plug | 6. Disc pad |
| 3. Manual adjustment gear | 7. Outer shim |
| Removal Note | 8. Inner shim |
| Installation Note | 9. Guide plate |
| 4. Lock bolt | |

**DISC PLATE****Inspection****Disc plate thickness**

1. Measure the thickness of the disc plate.

Caution


- When it is necessary to machine the disc plate, if the disc plate is removed from the vehicle then machined, excessive runout may result. Machine the disc plate with it installed on the vehicle.

Standard: 10 mm {0.39 in}

Minimum: 8 mm {0.31 in}

**Minimum thickness after machining by using a
brake lathe: 8.8 mm {0.35 in}**

2. If the thickness is not within the specifications, replace the disc plate.

**Disc plate runout**

1. Verify that there is no looseness in the wheel bearing.
2. Measure the runout at the outer edge of the contact surface of the disc pad.


Runout: 0.05 mm {0.002 in} max.

3. If the runout is not within the specification, repair or replace the disc plate.


CALIPER

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Dust seal 2. Piston Disassembly Note below Assembly Note page P-32 Inspect for wear and rust 3. Manual adjustment gear 4. Snap ring 5. Adjusting bolt 6. O-ring 7. Connecting link 8. Piston seal Disassembly Note page P-32 | <ol style="list-style-type: none"> 9. Spring 10. Operating lever 11. Sleeve 12. Boot 13. Bleeder cap and bleeder screw Disassembly Note page P-32 Assembly Note page P-32 14. Boot 15. Boot 16. Caliper body Inspect for damage and cracks |
|--|--|




Disassembly note

Piston


Turn the adjustment gear clockwise with an Allen wrench to remove the piston from the adjustment gear.
(Turn the adjustment gear until it becomes easy to turn.)

**Piston seal**


Remove the piston seal from the caliper by using the SST.

**Bleeder screw**


Loosen the bleeder screw by using the SST.

**Assembly note****Bleeder screw**

Tighten the bleeder screw by using the SST.

**Piston**

Insert the piston into the caliper and turn the adjustment gear counterclockwise with an Allen wrench to pull the piston inward. (Turn until it stops.)




REAR BRAKE (DRUM)
Inspection (on-vehicle)
Brake shoe (lining)

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels and tires.
3. Remove the brake drum. (See below)
4. Verify the remaining thickness of the lining.


Thickness: 1.0 mm {0.04 in} min.

Removal / Inspection / Installation

1. Remove the lining in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the following.
 - (1) Add fluid and bleed the air. (Refer to page P-7.)
 - (2) Check for fluid leakage. (Refer to page P-9.)
 - (3) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Screw 2. Brake drum Inspection page P-34 Installation Note page P-34 3. Hub cap 4. Locknut 5. Wheel hub assembly 6. Return spring (upper) 7. Return spring (lower) 8. Hold pin and spring 9. Anti-rattle spring 10. Brake shoe (leading side) Inspection above 11. Brake shoe (trailing side) Inspection above | <ol style="list-style-type: none"> 12. Operating lever 13. Quadrant 14. Quadrant spring 15. Parking brake cable 16. Brake pipe Removal Note page P-34 17. Bolt 18. Wheel cylinder Disassembly / Inspection / Assembly page P-35 19. Wheel cylinder gasket 20. Insulator 21. Bolt 22. Backing plate Inspect for damage and cracks |
|---|---|

**Removal note****Brake pipe**

Disconnect or connect the brake pipe from/to the wheel cylinder with the SST.

Tightening torque:

16—21 N·m {1.6—2.2 kgf·m, 12—15 ft·lbf}

**Inspection**


Check for the following and repair or replace the parts as necessary.

Brake drum


1. Measure the inner diameter of the drum.

Standard diameter: 228.6 mm {9.000 in}


Diameter limit: 230.1 mm {9.059 in}




2. Check for scratches, and uneven or abnormal wear inside the drum.

**Grease points**

- (1) Shoe and cylinder contact points
- (2) Shoe anchor points
- (3) Projections of backing plate

**Installation note****Brake drum**

1. Before installing the brake drum, depress the brake pedal to verify operation of the automatic adjuster.




2. After installation:
 - (1) Add fluid and bleed the air. (Refer to page P-7.)
 - (2) Check for fluid leakage. (Refer to page P-8.)
 - (3) Depress the brake pedal a few times and check that the rear brakes do not drag while rotating the wheel.
 - (4) Check the parking brake lever stroke. (Refer to page P-36.)

WHEEL CYLINDER

Disassembly / Inspection / Assembly

1. Disassemble the wheel cylinder in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary. If any of the metal parts are damaged, replace the wheel cylinder as an assembly.
3. Assemble in the reverse order of disassembly.



N-m {kgf-cm, in-lbf}

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Dust boot 2. Piston Inspect for corrosion and damage 3. Piston cup | <ol style="list-style-type: none"> 4. Spring 5. Bleeder cap and bleeder screw 6. Wheel cylinder body Inspect for corrosion and damage |
|---|--|

PARKING BRAKE SYSTEM

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|----------------------------------|---|-------------------|----------|
| Brakes do not release | Improper return of parking brake cable or improper adjustment | Repair or adjust | P-36, 37 |
| Parking brake does not hold well | Excessive lever stroke | Adjust | P-36 |
| | Brake cable stuck or damaged | Repair or replace | P-37 |
| | Brake fluid or oil on pad or brake shoe | Clean or replace | — |
| | Hardening of pad or brake shoe surface or poor contact | Grind or replace | P-29, 33 |


PARKING BRAKE SHOE

Removal / Inspection / Installation

Drum brake

Removal and Installation. (Refer to page P-33.)

Inspection. (Refer to page P-33.)




PARKING BRAKE (LEVER TYPE)

Inspection (on-vehicle)

Verify whether or not the stroke is within the specification when the parking brake lever is pulled with a force of **98 N {10 kgf, 22 lbf}**.

Stroke: 5—7 notches




Adjustment

1. Before adjustment, start the engine and depress the brake pedal several times.
2. Stop the engine.
3. Remove the parking brake lever cover.
4. Turn the adjusting nut at the front of the parking cable.
5. After adjustment, check the following points:
 - (1) Turn the ignition switch ON, pull the parking brake lever one notch, and check that the parking brake warning light illuminates.
 - (2) Verify that the rear brakes do not drag.

PARKING BRAKE CABLE

Removal / Inspection / Installation

1. Remove the cable in the order shown in the figure.
2. Visually check each part, and replace it if necessary.
3. Install in the reverse order of removal.
4. Depress the brake pedal a few times and check that the rear brakes do not drag while rotating the wheels.
5. Adjust the parking brake lever stroke.




- | | |
|---|-----------------------|
| 1. Rear console Removal / Installation section S | 5. Nut |
| 2. Adjusting nut | 6. Clip |
| 3. Return spring | 7. Screw |
| 4. Front parking cable Inspect for damage and wear | 8. Brake drum |
| | 9. Rear parking cable |

PARKING BRAKE LEVER

Removal / Inspection / Installation

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove in the order shown in the figure.
4. Inspect all components and parts. Replace any parts if necessary.
5. Install in the reverse order of removal. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
6. Adjust the parking lever stroke. (Refer to page P-37.)
7. Turn the ignition switch to ON, and verify that the parking brake warning light comes on when the lever is pulled up one notch.







- 1. Rear console
Removal / Installation section S
- 2. Adjusting nut
- 3. Bolt








- 4. Parking brake lever assembly
Inspect for damage and wear
- 5. Parking brake switch
Inspection section T

ANTILOCK BRAKE SYSTEM (ABS)

PREPARATION

SST

| | | | |
|---|---|--|---|
| <p>49 G025 001 Sensor rotor installer</p>  | <p>For installation of sensor rotor (Front)</p> | <p>49 0259 770B Wrench, flare nut</p>  | <p>For removal and installation of brake pipe</p> |
| <p>49 H028 204 Attachment</p>  | <p>For installation of sensor rotor (Rear)</p> | <p>49 T088 0A0 NGS set</p>  | <p>For diagnosis</p> |

| | | | |
|---|--------------------------|---|--------------------------|
| <p>49 T088 001 Control Unit (Part of 49 T088 0A0)</p>  | <p>For diagnosis</p> | <p>49 T088 002 Vehicle Interface Module (Part of 49 T088 0A0)</p>  | <p>For diagnosis</p> |
| <p>49 T088 003 Super MECS Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis</p> | <p>49 T088 005 STAR/DCL Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis</p> |
| <p>49 T088 006 Battery Hookup Adapter (Part of 49 T088 0A0)</p>  | <p>For diagnosis</p> | <p>49 T088 008A Instruction Manual</p>  | <p>For diagnosis</p> |
| <p>49 T088 010B Program Card</p>  | <p>For diagnosis</p> | <p>—</p> | <p>—</p> |

TROUBLESHOOTING GUIDE

Precaution

Conditions that are not malfunctions

1. Vibration can sometimes be felt in the steering wheel, body, and/or brake pedal when the ABS is functioning; such vibration is simply an indication that the system is functioning.
2. The ABS warning light may illuminate under any of the following conditions:
 - When the vehicle is travelling on snow or ice with the parking brake activated or a brake dragging at one wheel.
 - When different size tires are used.
 - When tires of different gripping performance are used.
 - When (while the vehicle is jacked up or stuck) the front wheels only are spun for 20 seconds or more.
 - When there is insufficient battery voltage.

Note

- Under the above conditions, the warning light will not illuminate a second time when the ignition is switched OFF then back ON, and there will be no problem entry made to the control module memory.



Troubleshooting notes

The ABS is composed of electrical components, mechanical components (ABS hydraulic unit), and the components of the standard brake system.

Fundamentally, malfunctions of the ABS electrical or mechanical components are judged by the on-board diagnosis function within the ABS control module. The malfunctions are indicated by the warning light in the instrument panel. The location of a malfunction is indicated by the technician switching the system to the diagnostic test mode.

The on-board diagnostic system must be used when diagnosing malfunctions of the ABS.

WIRING DIAGRAM



RELATIONSHIP CHART

| Input | Output | ABS hydraulic unit | | ABS warning light | Data link connector |
|------------------------|--------|--------------------|-----------|-------------------|---------------------|
| | | Solenoid valve | ABS motor | | |
| ABS wheel-speed sensor | | ○ | ○ | ○ | ○ |
| Brake switch | | ○ | ○ | | |
| Fail-safe relay | | ○ | | ○ | ○ |
| Motor relay | | | ○ | ○ | ○ |






QUICK DIAGNOSIS CHART


| Symptom | Cause | Input | | | | Output | | | | ABS control module |
|---------|--|------------------------|--------------|-----------------|-------------|--------------------|-----------|-------------------|---------------------|--------------------|
| | | ABS wheel-speed sensor | Brake switch | ABS relay | | ABS hydraulic unit | | ABS warning light | Data link connector | |
| | | | | Fail-safe relay | Motor relay | Solenoid valve | ABS motor | | | |
| 1 | ABS warning light not illuminated when ignition switch turned ON | | | | | | | ○ | | |
| 2 | ABS warning light remains ON | ○ | ○ | | ○ | ○ | ○ | ○ | | ○ |
| 3 | ABS warning light flashes | | | | | | | | ○ | |


DIAGNOSTIC INDEX

| No. | Troubleshooting Items | Remarks | Page |
|-----|--|---|------|
| 1 | ABS warning light not illuminated when ignition switch turned ON | — | P-42 |
| 2 | Warning light remains ON | Warning light remains ON and ABS does not operate | P-43 |
| 3 | ABS warning light flashes | — | P-44 |

SYMPTOM TROUBLESHOOTING

| 1 | WARNING LIGHT NOT ILLUMINATED WHEN IGNITION SWITCH TURNED ON | | |
|---|---|--------|---|
| DETAILED DESCRIPTION | | | |
| <p>Possible cause:</p> <ul style="list-style-type: none"> • If other warning indicators do not illuminate, METER 15 A fuse may be burnt. • Failed indicator light or open in related wiring harness. | | | |
| Step | Inspection | Action | |
| 1 | <p>Is METER 15 A fuse OK?  page P-54</p>  | Yes | Go to next step |
| | | No | Repair METER 15 A fuse |
| 2 | <p>Is harness of ABS warning light normal?  page P-51</p>  | Yes | Inspect ABS warning light  page P-51 |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ABS relay • Inspect harness between instrument panel and ABS CM • Inspect harness between instrument panel and ABS relay • Inspect ABS warning light bulb |

| 2 | WARNING LIGHT REMAINS ON | | |
|---|--|--------|---|
| DETAILED DESCRIPTION Warning light remains ON and ABS does not operate | | | |
| Possible cause: <ul style="list-style-type: none"> • If ABS warning light only illuminates, activate diagnostic mode and check for diagnostic trouble code • Malfunction of battery • Malfunction of ABS warning light harness (fail-safe relay) • Malfunction of ABS CM | | | |
| Step | Inspection | Action | |
| 1 | With the SSTs (self diagnosis checker, system selector), verify that diagnostic trouble code is indicated. (Connect the SSTs to the data link connector) page P-45 | Yes | Read diagnostic trouble code ⇔ Inspect as indicated page P-47 |
| | | No | Go to next step |
| 2 | Is battery voltage OK? page P-51 | Yes | Go to next step |
| | | No | Charge or replace battery |
| 3 | Is ABS warning light harness normal? page P-51  | Yes | Go to next step |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ABS relay • Inspect harness between instrument panel and ABS CM • Inspect harness between instrument panel and ABS relay |
| 4 | Connect terminal 2J of ABS CM connector (18 pin) to a ground and check the following points (IG ON) <ul style="list-style-type: none"> • Operation sound of relay is heard • ABS warning light is not illuminated • 1D terminal of ABS CM connector indicates 12V | Yes | Go to next step |
| | | No | <ul style="list-style-type: none"> • Inspect ABS relay (fail-safe relay) • Inspect harness between ABS relay (fail-safe relay) and ABS CM, battery • Inspect harness between ABS relay (fail-safe relay) and ABS hydraulic unit |
| 5 | Is voltage at terminals 1E, 1F and 1H of ABS CM connector (12 pin) and terminals 2B and 2L of ABS CM connector (18 pin) as specified? page P-56 | Yes | Replace ABS CM |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ground • Inspect harness between ignition switch and ABS CM • Inspect harness between data link connector and ABS CM • Inspect harness between ABS warning light and ABS CM |

| 3 | ABS WARNING LIGHT FLASHES | | |
|--|--|-----|--|
| DETAILED DESCRIPTION — | | | |
| Possible cause: <ul style="list-style-type: none"> Data link connector terminal TBS grounded | | | |
| Step | Inspection | | Action |
| 1 | Verify that there is no continuity between terminal TBS and GND  | Yes | Inspect ABS CM |
| | | No | Repair short between terminal TBS and ground |



ON-BOARD DIAGNOSTIC SYSTEM

Inspection by diagnostic test mode


Outline

- The ABS control module contains an on-board diagnostic and memory functions to detect and indicate present and past failures.
Read and note the diagnostic indications by using the **SST**, and take action according to the Diagnostic Trouble Code Table. (Refer to page P-47.)
- The ABS CM has a nonvolatile memory. Diagnostic trouble codes are not erased if the battery is disconnected. The memory should be cleared when servicing is finished. (Refer to page P-47.)


Inspection using NGS




1. Connect the **SST** (NGS) to the data link connector and battery.
2. Set the **SST** (Super MECS Adapter) to ABS.



3. Select "VEHICLE & ENGINE SELECTION" on the **SST** (Control Unit) display, and then select the vehicle model, engine type, and model year.



4. Select “DIAGNOSTIC DATA LINK” on the **SST**, (Control Unit) display.
5. Select “ANTI LOCK BRAKE MODULE” on the **SST** (Control Unit) display.



6. Select “DIAGNOSTIC TEST MODE” on the **SST** (Control Unit) display.
7. (1) If a trouble code is displayed, refer to the Diagnostic trouble code table (Refer to page P-47.) and inspect the appropriate system area.
(2) If “No codes received” is displayed, the system areas shown in the Diagnostic trouble code table are okay. Inspect another system area.

Memory Cancel

Diagnostic trouble codes memorized in the ABS control module are canceled by performing the following steps.

1. Connect the TBS terminal to GND at the data link connector.
2. Turn the ignition switch ON.
3. Output all memorized codes.
4. After verifying that the first code is repeated, depress the brake pedal 10 times at intervals of less than one second (1 sec.).

Note

Diagnostic trouble codes will not be canceled if:

- Intervals of depressing the brake pedal exceed one second (1 sec.).
- Brake switch has failed.
- While performing the memory cancel operation, the ABS warning light will not illuminate.
- When the memory cancel operation is completed, the ABS warning light comes on for 2—3 seconds, then goes off.
- After the memory is canceled, the ABS control module performs on-board diagnosis.

Diagnostic Trouble Code Table

Note

- If the ignition switch is turned OFF and ON again, and the vehicle is then accelerated to higher than 10 km/h {6.2 MPH}, diagnostic trouble code 15 will be replaced by a code from 11 through 14.

| DTC | Display on the NGS | Possible cause | Diagnosis chart No. |
|-----|---|--|---------------------|
| 11 | WSS, SR (RH-FFRONT) — OPEN OR SHORT, DEFECT | Right front wheel-speed sensor Right front sensor rotor | ABS-1 |
| 12 | WSS, SR (LH-FRONT) — OPEN OR SHORT, DEFECT | Left front wheel-speed sensor Left front sensor rotor | |
| 13 | WSS, SR (RH-REAR) — OPEN OR SHORT, DEFECT | Right rear wheel-speed sensor Right rear sensor rotor | |
| 14 | WSS, SR (LH-REAR) — OPEN OR SHORT, DEFECT | Left rear wheel-speed sensor Left rear sensor rotor | |
| 15 | WSS — OPEN OR SHORT | ABS wheel-speed sensor | ABS-2 |
| 22 | SOLV (RH-FRONT) — OPEN OR SHORT | Right front solenoid valve | ABS-3 |
| 24 | SOLV (LH-FRONT) — OPEN OR SHORT | Left front solenoid valve | ABS-3 |
| 26 | SOLV (RH-REAR) — OPEN OR SHORT | Right rear solenoid valve | |
| 28 | SOLV (LH-REAR) — OPEN OR SHORT | Left rear solenoid valve | |
| 51 | FAIL-SAFE RELAY — OPEN OR SHORT, DEFECT | Fail-safe relay | ABS-4 |
| 53 | MOTOR, MOTOR RELAY, OPEN OR SHORT, DEFECT | ABS motor Motor relay | ABS-5 |
| 61 | ABS CONTROL UNIT — DEFECT | ABS control module | ABS-6 |

Diagnosis Chart

| ABS-1 | | Diagnostic trouble code: 11—14 | |
|--|--|--|----------|
| Possible failure: ABS wheel-speed sensor, harness, ABS sensor rotor, hydraulic pressure | | | |
| 11: Right front 12: Left front 13: Right rear 14: Left rear | | | |
| Step | Check item | Remark | Refer to |
| 1 | Check control module connector | Check for poor connection | — |
| 2 | Check wiring harness between control module and ABS wheel-speed sensor | Check for open or short to ground | — |
| 3 | Check ABS wheel-speed sensor | — | P-59 |
| 4 | Check ABS sensor rotor | — | P-59 |
| 5 | Check brake switch | — | P-52 |
| 6 | Check hydraulic system | If a problem is found, replace ABS hydraulic unit or repair hydraulic system piping as necessary | P-60 |
| 7 | If all above are OK after diagnostic trouble code(s) is erased, recheck for diagnostic trouble code after driving from when vehicle is stopped to over 10 km/h {6 mph} | If code of 11—14 is obtained, replace ABS control module | P-63 |
| 8 | If all above are OK, there was temporarily poor contact in wiring and now ABS system is functioning | | |


| ABS-2 | | Diagnostic trouble code: 15 | |
|--|--|---|----------|
| Possible failure: ABS wheel-speed sensor, harness | | | |
| Step | Check item | Remark | Refer to |
| 1 | If all the malfunctions are OK after diagnostic trouble code is erased, recheck for diagnostic trouble code after driving from when vehicle is stopped to over 10 km/h {6 mph} | If code of 11—14 is obtained, go to ABS-1 | Above |
| | | If code 15 is obtained, replace ABS control module | P-63 |
| | | If nothing is displayed, there was temporarily poor contact in wiring and now ABS is OK | — |

| ABS-3 | | Diagnostic trouble code: 22—28 | |
|---|--|---|----------|
| Possible failure: Solenoid valve, harness 22: Right front, 24: Left front, 26: Right rear, 28: Left rear | | | |
| Step | Check item | Remark | Refer to |
| 1 | Check control module connector | Check for poor connection | — |
| 2 | Check wiring harness between ABS hydraulic unit and control module | Check for open or short to ground | — |
| 3 | Check ABS hydraulic unit solenoid valve | Check for open circuit | P-54 |
| 4 | Check ABS warning light operation | If warning light remains illuminated after turning ignition switch ON, replace ABS control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was temporarily poor contact in wiring and now ABS system is functioning | |

| ABS-4 | | Diagnostic trouble code: 51 | |
|--|---|---|----------|
| Possible failure: Fail-safe relay | | | |
| Step | Check item | Remark | Refer to |
| 1 | Check pump fuse | Check pump fuse condition | P-54 |
| | | Check short to ground | — |
| 2 | Check ABS relay | Check for open circuit | P-64 |
| 3 | Check wiring harness between ABS relay and ABS hydraulic unit or ABS control module | Check for open or short to ground | — |
| 4 | Check ABS warning light operation | If warning light remains illuminated after turning ignition switch ON, replace ABS control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was temporarily poor contact in wiring and now ABS system is functioning | |

| ABS-5 | | Diagnostic trouble code: 53 | |
|---|--|---|-----------------|
| Possible failure: ABS motor, motor relay | | | |
| Step | Check item | Remark | Refer to |
| 1 | Check motor relay | If pump motor continues operating after turning ignition switch OFF, motor relay may be faulty | P-65 |
| 2 | Check ABS pump fuse | Check ABS pump fuse condition | P-54 |
| | | Check short to ground | — |
| 3 | Check wiring harness between ABS relay and ABS hydraulic unit and ABS control module | Check for open or short to ground | — |
| 4 | Check voltage at ABS control module terminal | Turn ignition switch ON and check motor relay terminal voltage | P-56 |
| 5 | Check ABS motor | Check for open circuit | P-53 |
| 6 | Check wiring harness between ABS motor and ground | Check for open circuit | — |
| 7 | Check wiring harness between ABS motor and ABS control module | Check for open or short to ground | — |
| 8 | Check ABS warning light operation | If warning light remains illuminated after turning ignition switch ON, replace ABS control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was temporarily poor contact in wiring and now ABS system is functioning | |

| ABS-6 | | Diagnostic trouble code: 61 | |
|---|-------------------|------------------------------------|-----------------|
| Possible failure: ABS control module | | | |
| Step | Check item | Remark | Refer to |
| 1 | — | Replace ABS control module | P-63 |



Inspection of ABS system
Check battery


Note

- If the battery voltage is low, the ABS warning light may illuminate.

1. Start the engine.
2. Check the voltage at the battery and at the ABS control module terminal 1H.


Voltage: 10 V min.

3. If the battery voltage is below the specification, charge or replace the battery as necessary.
4. If the battery voltage is within the specification and terminal 1H voltage is below the specification, check the wiring harness between the battery and the ABS control module terminal 1H.




Check ABS warning light harness

1. Turn the ignition switch OFF, and disconnect the ABS control module connector (18 pin).
2. Turn the ignition switch ON. If the warning light is ON, go to the next step. If the warning light is OFF, check the ABS relay and the harness. (Warning light — ABS relay, ABS relay — Ground)



3. Disconnect the ABS relay connector.
4. If the warning light remains illuminated, check the warning light harness for a short to ground.




Check ABS warning light bulb


1. Remove the meter assembly.
2. Remove the warning light bulb from the rear of the cluster.
3. Check the condition of the bulb.
4. Replace the bulb if necessary.


Check brake switch

1. Depress the brake pedal.
2. Verify that the brake lights illuminate.
3. If they do not illuminate, check the following:
 - Brake light bulb
 - Brake light fuse
 - Brake switch
 - Brake light harness
4. Repair or replace any parts as necessary.

**Check brake switch harness at ABS control module**

1. Turn the ignition switch OFF.
2. Disconnect the ABS control module connector (12 pins).
3. Turn the ignition switch ON.
4. Check for voltage between terminal 1M at the vehicle side harness and ground. (Refer to page P-55.)
5. If not as specified, check the wiring harness between the brake switch and the ABS control module.







Check motor harness at ABS control module

1. Turn the ignition switch OFF, and disconnect the ABS control module connector (12 pin).
2. Measure the resistance between 1L terminal of the control module connector and ground.

Resistance: 1 Ω max.

3. If not as specified, check the wiring harness between the ABS motor and the control module and check the ABS motor.




Check ABS motor at ABS hydraulic unit

1. Turn the ignition switch OFF.
2. Disconnect the ABS hydraulic unit connector (2 pin).
3. Measure the resistance between the connector terminals.

Resistance: 1 Ω max.

Warning

- **Allowing the ABS motor to operate for more than two seconds will cause it to overheat and become damaged. When checking the ABS motor and its related equipment, do not allow the ABS motor to operate for more than two seconds.**




4. Verify that the ABS motor operates when applying 12 V to the connector (2 pin).
5. If not as specified, replace the ABS hydraulic unit.

Check solenoid valve harness of ABS control module


1. Turn the ignition switch OFF.
2. Measure the resistance between a ground and the following terminals at the ABS control module connector (12 pin).

- Terminal: 1A, Right rear
- 1B, Left front
- 1C, Right front
- 1D, Left rear

Resistance: Approx. 3 Ω



3. If not as specified, check the wiring harness between the ABS hydraulic unit connector (8 pin) and the ABS control module.



Check solenoid valve at ABS hydraulic unit

1. Disconnect the ABS hydraulic unit connector (8 pin).
2. Measure the resistance between the following terminals.

| Terminal |
|----------|
| A—H |
| B—G |
| C—F |
| D—E |


Resistance: approx. 3 Ω

3. If not as specified, check the ABS hydraulic unit wiring harness or replace the ABS hydraulic unit if necessary.


Check fuse

Check the fuses according to the following table. If a fuse is burnt, replace it.

| Fuse name | Rating (Amp) | Location | Failure condition | Refer to |
|-----------|--------------|-------------------------------|---|----------|
| ABS | 60 | Main fuse block | <ul style="list-style-type: none"> • ABS warning light illuminates (Malfunction code 51 or 53) • ABS motor and solenoid valves do not operate | P-49, 50 |
| MAIN | 100 | | <ul style="list-style-type: none"> • Engine does not start | — |
| ENGINE | 15 | Fuse block (at driver's side) | <ul style="list-style-type: none"> • ABS warning light illuminates after engine started • ABS control module not activated | — |
| STOP | 20 | | <ul style="list-style-type: none"> • Brake light does not illuminate | — |
| METER | 15 | | <ul style="list-style-type: none"> • No ABS warning lights in instrument cluster illuminate | — |



Check ABS control module






B+: Battery positive voltage

| Connector | Terminal | Connected to | Condition | Voltage | Remark |
|-----------|--------------|----------------------------|---------------------|---------|--|
| 12 pin | 1A | Right rear wheel solenoid | Solenoid ON* | 0—2 | * Solenoid is ON only when ABS system is functioning. Voltage when solenoid is ON can be measured following "Hydraulic System Test" (Refer to P-60.) |
| | | | Ignition switch ON | B+ | |
| | 1B | Left front wheel solenoid | Solenoid ON* | 0—2 | |
| | | | Ignition switch ON | B+ | |
| | 1C | Right front wheel solenoid | Solenoid ON* | 0—2 | |
| | | | Ignition switch ON | B+ | |
| | 1D | Left rear wheel solenoid | Solenoid ON* | 0—2 | |
| | | | Ignition switch ON | B+ | |
| | 1E | Ground | Constant | 0 | |
| | 1F | Ground | Constant | 0 | |
| | 1H | Battery | Ignition switch ON | B+ | |
| | | | Ignition switch OFF | 0 | |
| | 1J | Not used | — | — | |
| 1K | Not used | — | — | | |
| 1L | ABS motor | Motor running | B+ | | |
| | | Motor stopped | 0—1 | | |
| 1M | Brake switch | Brake pedal depressed | B+ | | |
| | | Brake pedal released | 0—2 | | |
| 1N | Not used | — | — | | |

B+: Battery positive voltage

| Connector | Terminal | Connected to | Condition | Voltage | Remark | |
|-----------|------------|------------------------|--------------------------------------|--------------------------------------|----------|--|
| 18 pin | 2A | FBS check terminal | Ignition switch ON | 0 | | |
| | 2B | TBS check terminal | Normal mode | B+ | | |
| | | | Diagnostic test mode | 0 | | |
| | 2C | Not used | — | — | | |
| | 2D | Not used | — | — | | |
| | 2E | Not used | — | — | | |
| | 2F | Not used | — | — | | |
| | 2G | Not used | — | — | | |
| | 2H | Motor relay | Motor relay ON | 0—2 | | |
| | | | Motor relay OFF | B+ | | |
| | 2J | Fail-safe relay | Normal | 0—2 | | |
| | | | If malfunction present | B+ | | |
| | 2L | Warning light | Illuminated | 0—3 | | |
| | | | Not illuminated | B+ | | |
| | 2M | ABS wheel-speed sensor | Right front | Vehicle stopped | 0 | <ul style="list-style-type: none"> • Turn wheel at specified speed to prevent incorrect diagnosis • Check following terminals of ABS wheel-speed sensor in AC range: 2N—2M (right front) 2O—2P (left front) 2R—2Q (left rear) 2S—2T (right rear) • In DC range, ABS wheel-speed sensor voltage will be approx. 1.0V (with ignition switch ON) |
| | 2N | | | Wheel turned 1 revolution per second | 0.25—3.0 | |
| | 2O | | Left front | Vehicle stopped | 0 | |
| | 2P | | | Wheel turned 1 revolution per second | 0.25—3.0 | |
| 2Q | Left rear | | Vehicle stopped | 0 | | |
| 2R | | | Wheel turned 1 revolution per second | 0.25—3.0 | | |
| 2S | Right rear | | Vehicle stopped | 0 | | |
| 2T | | | Wheel turned 1 revolution per second | 0.25—3.0 | | |



Check ABS relay harness (fail-safe relay)

1. Turn the ignition switch OFF and disconnect the ABS control module connector (18 pin).
2. Turn the ignition switch ON.
3. Connect terminal 2J of the control module connector (18 pin) to a ground.
4. Check the following points.

| Condition | Action |
|---|---|
| Fail-safe relay in ABS relay does not click when 2J terminal grounded | <ul style="list-style-type: none"> • Check fail-safe relay • Check harness between fail safe relay and ABS control module |
| Warning light illuminates after grounding 2J terminal | <ul style="list-style-type: none"> • Check fail-safe relay |
| 1D terminal of ABS control module connector does not indicate 12V | <ul style="list-style-type: none"> • Check fail-safe relay • Check harness between fail safe relay and ABS hydraulic unit |

Check ABS relay (fail-safe relay)

1. Measure the resistance between terminals c and d of the ABS relay connector.


Resistance: 60—100 Ω

2. Check for continuity between terminals a and e and between b and e.

| Terminal | Continuity |
|----------|------------|
| a—e | Yes |
| b—e | No |


3. Apply 12 V between terminals d and c. Check for continuity between terminals a and e and between b and e.

| Terminal | Continuity |
|----------|------------|
| b—e | Yes |
| a—e | No |



Check ABS relay harness (motor relay)

1. Inspect the fail-safe relay.
2. Turn the ignition switch OFF and disconnect the ABS control module connector (18 pin).
3. Turn the ignition switch ON.
4. Connect terminal 2J to a ground.
5. Connect terminal 2H to a ground.
6. Check the following points.




Caution

- **Allowing the ABS motor to operate for more than two seconds will cause it to overheat and become damaged. When checking the ABS motor and its related equipment, do not allow the ABS motor to operate for more than two seconds.**

| Condition | Action |
|---|--|
| Motor relay in ABS relay does not click when terminals are grounded | <ul style="list-style-type: none"> • Check harness between motor relay and ABS control module • Check motor relay |
| ABS motor does not operate | <ul style="list-style-type: none"> • Check motor relay • Check harness between motor relay and ABS motor • Check fuse |

7. If not as specified, replace the ABS relay.



Check ABS relay (motor relay)

1. Measure the resistance between terminals e and h, or between a and h of ABS relay connector.

Resistance: 50—90 Ω




2. Check for continuity between terminals b and f.

| Terminal | Continuity |
|----------|------------|
| b—f | No |

3. Apply 12 V to terminals g (+) and h (-). Check for continuity between terminals b and f.

| Terminal | Continuity |
|----------|------------|
| b—f | Yes |

4. If not as specified, replace the ABS relay.



Check ABS wheel-speed sensor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the wheel and tire assembly.
3. Check for looseness and damage.

4. Check the clearance between the ABS wheel-speed sensor and the ABS sensor rotor at each wheel.

Clearance: 0.3—1.1 mm {0.012—0.043 in}

5. If not as specified, replace the ABS wheel-speed sensor or ABS sensor rotor as necessary.

Check resistance of ABS wheel-speed sensor

1. Disconnect the ABS wheel-speed sensor connector.
2. Check the resistance at the ABS wheel-speed sensor.


Resistance: 1.6—2.0 kΩ

Check voltage of ABS wheel-speed sensor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Disconnect the ABS wheel-speed sensor connector.
3. Check each wheel by rotating it at one revolution per second.

Voltage: 0.25—3.0 V (AC)

4. If not as specified, replace the ABS wheel-speed sensor or ABS sensor rotor as necessary.
5. Cancel the ABS control module memory.







Check ABS sensor rotor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the wheel and tire assembly.
3. Inspect the rotor for missing and damaged teeth.
4. Replace the ABS sensor rotor as necessary.

ABS HYDRAULIC UNIT

The ABS control module contains an on-board diagnostic function to check the hydraulic system operation. During the diagnostic test mode, the ABS control module activates the ABS hydraulic unit to reduce the hydraulic pressure of the right front, left front, right rear, left rear in sequence for 0.5 second each at intervals of 1.5 seconds.




Inspection

1. Verify that the battery is fully charged.
Verify that the ABS warning light goes out after the engine is started.
2. If the light stays ON after the engine has started, the ABS control module detects a failure and will not activate the ABS hydraulic unit.
3. Turn off the engine.
4. On level ground, jack up the vehicle and support it evenly on safety stands. Shift the transaxle to neutral or N range.
5. Release the parking brake.
6. Rotate the wheels by hand, and inspect for brake drag.
7. Using a jumper wire, connect the TBS and GND terminals of the data link connector.
8. Depress the brake pedal, and have an assistant verify that the right front wheel will not turn.
9. With the brake pedal still depressed, turn the ignition switch ON and verify that the brake is released momentarily (approx. **0.5 sec.**) and that the wheel turns when pressure reduction operates.
10. Check operation of the remaining wheels in order: left front, right rear, left rear.
11. If steps 9 and 10 show correct operation, the following systems are OK:
 - Brake piping to the ABS hydraulic unit
 - Braking system, including the ABS hydraulic unit
 - Electrical system in the ABS hydraulic unit (solenoid, ABS motor, etc.)
 - ABS control module, its output system (solenoid, relay, etc.) and harness
 The following are not checked with the above steps.
 - Input system and harness of the ABS control module
 - Intermittent failure
 - Fluid leakage
12. Replace the ABS hydraulic unit if necessary.

Removal / Installation

1. Remove the nuts mounting the fuel filter and igniter to the bracket, and move them toward the engine.
2. Remove the ABS hydraulic unit in the order shown in the figure, referring to **Removal Note**.
3. The ABS hydraulic unit is not serviceable. If there is a malfunction, replace the ABS hydraulic unit assembly. Install in the reverse order of removal, referring to **Installation Note**.
4. Add brake fluid, bleed the air, and check for fluid leakage.
5. Verify that the diagnostic trouble codes have been canceled. (Refer to page P-47.)




- | | |
|-----------------------------------|-----------------------------------|
| 1. Charcoal canister | 7. ABS hydraulic unit |
| 2. Cruise control actuator | Installation Note page P-62 |
| 3. Brake pipe | 8. Casing |
| Removal Note below | 9. Mount rubber |
| Installation Note page P-62 | 10. Hex stud |
| 4. Band | 11. Connector bolt |
| 5. Connector | 12. Connector |
| 6. Nut and washer | 13. Spacer |


Removal note
Brake pipe

Caution

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.

Loosen the brake pipes by using the SST.




**Installation note****Brake pipe**

Tighten the brake pipe by using the **SST**.

Tightening torque:

12.9—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}


**ABS hydraulic unit**

1. Fix the ABS motor-harness to the clip as shown in (A).
2. Tie the solenoid harness and the ABS motor-harness together by using a band as shown in (B).
3. Fix the connector to the bracket.
4. Cut off 1—10 mm {0.04—0.39 in} of the band from the tied part.

ABS CONTROL MODULE

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Connect the negative battery cable and verify that the diagnostic trouble codes have been canceled.
(Refer to page P-47.)



N-m {kgf-cm, in-lbf}


1. Connector
2. Nut

3. ABS control module


ABS RELAY

Removal / Inspection / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Connect the negative battery cable and verify that the diagnostic trouble codes have been canceled. (Refer to page P-47.)



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Fuse block cover 2. Data link connector 3. Fuse block | <ol style="list-style-type: none"> 4. ABS relay Inspection below 5. Connector |
|--|---|



Inspection

ABS relay (fail-safe relay)

1. Measure resistance between terminals e and d of the ABS relay box connector.


Resistance: 60—100 Ω

2. Check for continuity between terminals a and e and between b and e.

| Terminal | Continuity |
|----------|------------|
| a—e | Yes |
| b—e | No |

3. Apply 12 V between terminals d and c. Check for continuity between terminals b and e and between a and e.

| Terminal | Continuity |
|----------|------------|
| b—e | Yes |
| a—e | No |



4. If not as specified, replace the ABS relay.

ABS relay (motor relay)

1. Measure the resistance between terminals e and h or between a and h of the ABS relay connector.

Resistance: 50—90 Ω

2. Check for continuity between terminals b and f.

| Terminal | Continuity |
|----------|------------|
| b—f | No |

3. Apply 12 V to terminals g (+) and h (-). Check for continuity between terminals b and f.


| Terminal | Continuity |
|----------|------------|
| b—f | Yes |

4. If not as specified, replace the ABS relay.

ABS WHEEL-SPEED SENSOR (FRONT)


Removal / Inspection / Installation

1. Jack up the vehicle and support it on safety stands.
2. Remove the wheel and tire assembly.
3. Remove in the order shown in the figure.
4. Install in the reverse order of the removal.
5. Install the wheel and tire assembly.
6. Verify that the diagnostic trouble codes have been cancelled. (Refer to page P-47.)



1. Connector
2. Nut
3. Bolt

4. Bolt
 5. ABS wheel-speed sensor
- Inspection below



Inspection

1. Check the resistance at the ABS wheel-speed sensor terminals.


Resistance: 1.6—2.0 kΩ

2. If not as specified, replace the ABS wheel-speed sensor.


ABS SENSOR ROTOR (FRONT)

Removal / Inspection

1. Inspect the ABS sensor rotor for missing and damaged teeth.
2. Remove the drive shaft assembly from the vehicle. (Refer to section M.)
3. Remove in the order shown in the figure, referring to **Removal Note**.



- | | |
|-----------------------|-----------------|
| 1. ABS sensor rotor | 3. Drive shaft |
| Removal Note | Removal |
| 2. Boot band and boot | below section M |




Removal note

ABS sensor rotor


Tap the ABS sensor rotor off the drive shaft by using a chisel.

Installation

1. Install in the order shown in the figure, referring to **Installation Note**.
2. Install the drive shaft assembly onto the vehicle. (Refer to section M.)



- | | | | | | |
|-----------------------|-------------------|-------------|----------------|--------------|-----------------|
| 1. ABS sensor rotor | Installation Note | below | 3. Drive shaft | Installation | section M |
| 2. Boot and boot band | | | | | |




Installation note
ABS sensor rotor

Set a new ABS sensor rotor on the drive shaft in the direction shown and press it onto the shaft assembly by using the SST.

ABS WHEEL-SPEED SENSOR (REAR)


Removal / Inspection / Installation

1. Jack up the vehicle and support it on safety stands.
2. Remove the wheel and tire assembly.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Install the wheel and tire assembly.
6. Verify that the diagnostic trouble codes have been canceled. (Refer to page P-47.)



1. Connector
2. Bolt
3. Bolt

4. Bolt
 5. ABS wheel-speed sensor
- Inspection below



Inspection

1. Check resistance at the ABS wheel-speed sensor terminals.


Resistance: 1.6—2.0 Ω

2. If not as specified, replace the ABS wheel-speed sensor.

ABS SENSOR ROTOR (REAR)

Removal / Installation

1. Remove the rear wheel hub assembly from the vehicle. (Refer to section M.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the order shown in the figure, referring to **Installation Note**.
4. Install the rear wheel hub assembly onto the vehicle. (Refer to section M.)




1. ABS sensor rotor

Removal Note below

Installation Note below


2. Wheel hub



Removal note

ABS sensor rotor

Tap the ABS sensor rotor off the wheel hub by using a chisel.



Installation note

ABS sensor rotor

1. Install a new rear ABS sensor rotor onto the wheel hub.
2. Using a steel plate and the **SST**, press the rotor until it is flush with the wheel hub.

Note

- The ABS sensor rotor can be installed in either direction.

WHEELS AND TIRES

| | |
|---|-----|
| OUTLINE | Q-2 |
| SPECIFICATIONS | Q-2 |
| TROUBLESHOOTING GUIDE | Q-3 |
| WHEELS AND TIRES | Q-4 |
| SPECIAL NOTES ABOUT WHEELS AND TIRES | Q-4 |
| NOTES REGARDING TIRE REPLACEMENT | Q-4 |
| INSPECTION / ADJUSTMENT | Q-4 |
| REMOVAL / INSTALLATION | Q-6 |
| TIRE ROTATION | Q-6 |
| WHEEL BALANCE ADJUSTMENT | Q-6 |

OUTLINE

SPECIFICATIONS

Standard Tires

| Item | | Engine/Model | FS | | | KL | |
|--------|---|--------------|----------------|---------------|----------------|----------------|--|
| | | | 626 | MX-6 | MX-6 | 626 | |
| Wheels | Size | | 14 × 6-JJ | 14 × 5 1/2-JJ | 15 × 6 1/2-JJ | 15 × 6-JJ | |
| | Offset | mm {in} | 45 {1.77} | | | | |
| | Pitch circle diameter | mm {in} | 114.3 {4.50} | | | | |
| | Material | | Aluminum alloy | Steel | Aluminum alloy | | |
| Tires | Size | | P195/65R14 88S | | P205/55R15 87V | P205/55R15 87H | |
| | Air pressure kPa {kgf/cm ² , psi} | Front | 220 {2.2, 32} | | | | |
| | | Rear | 180 {1.8, 26} | | | | |

Temporary spare tire

| Item | | Specifications |
|-------|-----------------------|---|
| Wheel | Size | 15 × 4T |
| | Offset | mm {in} 45 {1.77} |
| | Pitch circle diameter | mm {in} 114.3 {4.50} |
| | Material | Steel |
| | Size | T125/70D15 |
| Tire | Air pressure | kPa {kgf/cm ² , psi} 415 {4.2, 60} |

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|--|--|---|--|
| Excessive or irregular tire wear | Refer to page Q-5 for details. | | |
| Premature tire wear | Incorrect tire pressure | Adjust | Q-2 |
| Tire squeal | Incorrect tire pressure Tire deterioration | Adjust Replace | Q-2 — |
| Road noise or body vibration | Insufficient tire pressure Unbalanced wheel Deformed wheel or tire Irregular tire wear | Adjust Adjust Repair or replace — | Q-2 Q-6 — Q-5 |
| “Shake” occurs (steering wheel vibrates up/down) | Excessive tire and wheel runout Loose lug nuts Unbalanced wheel Cracked or worn engine mount rubber Cracked or worn transaxle mount rubber | Replace Tighten Adjust Replace Replace | — Q-5 Q-6 sections B1, B2 sections J, K1, K2 |
| “Shimmy” occurs (steering wheel vibrates circumferentially) | Excessive tire and wheel runout Loose lug nuts Unbalanced wheel Irregular tire wear Insufficient tire pressure Damaged or worn front wheel bearing Malfunction of steering system Malfunction of suspension | Replace Tighten Adjust Adjust Replace — — | — Q-5 Q-6 Q-5 Q-2 section M section N section R |
| Steering wheel pulls to one side | Incorrect tire pressure Excessive or irregular tire wear Malfunction of steering system Malfunction of braking system Malfunction of suspension | Adjust — — — — | Q-2 Q-5 section N section P section R |
| General driving instability | Unequal tire air pressures Deformed wheel or tire Loose lug nuts Malfunction of steering system Malfunction of suspension | Adjust Repair or replace Tighten — — | Q-2 — Q-5 section N section R |
| Uneven (one-sided) braking | Unequal tire air pressures Malfunction of braking system | Adjust — | Q-2 section P |
| Heavy handling | Insufficient tire pressure Malfunction of steering system Malfunction of suspension | Adjust — — | Q-2 section N section R |
| Steering wheel doesn't return properly | Insufficient tire pressure Malfunction of steering system Malfunction of suspension | Adjust — — | Q-2 section N section R |

WHEELS AND TIRES


SPECIAL NOTES ABOUT WHEELS AND TIRES

1. Do not use wheels or tires other than the specified types.
2. Aluminum wheels are easily scratched. When washing them, use a soft cloth, never a wire brush. If the vehicle is steam cleaned, do not allow boiling water to contact the wheels.
3. If alkaline compounds (such as salt water or road salts) get on aluminum wheels, wash them as soon as possible to prevent damage. Use only a neutral detergent.

NOTES REGARDING TIRE REPLACEMENT

Note the following points when tires are to be removed from or mounted onto the wheels.

1. Be careful not to damage the tire bead, the rim bead, or the edge of the rim:
2. Use a wire brush, sandpaper, or cloth to clean and remove all rust and dirt from the rim edge and the rim bead.
3. When cleaning aluminum wheels, use a soft cloth, never a wire brush or sandpaper.
4. Remove pebbles, glass, nails, and other foreign items embedded in the tire tread.
5. Be sure the air valve is installed correctly.
6. Apply a soapy solution to the tire bead and the edge of the rim before mounting.
7. After mounting a tire onto a wheel, inflate the tire to **250—300 kPa {2.55—3.06 kgf/cm², 36—42 psi}**. Verify that the bead is seated correctly onto the rim and that there are no air leaks. Then reduce the pressure to the specified level.
8. If a tire iron is used to change a tire on an aluminum wheel, be sure to use a piece of rubber between the iron lever and the wheel to avoid damage to the wheel. Work should be done on a rubber mat, not on a hard or rough surface.




INSPECTION / ADJUSTMENT

Visual Inspection

Inspection (Tire and Wheel)

A wheel or tire should be replaced if any cracks, damages, deformation, or other problems are found.



Tire Wear


1. Check the remaining tread.

Remaining tread

Standard tires: 1.6 mm {0.063 in} min.

Snow tires: 50% of tread


2. A tire should be replaced if the wear indicators are exposed.



Abnormal tire wear

Abnormal tire wear patterns shown in the illustration can occur. Refer to the chart for the possible causes and actions.


| | Possible cause | Action |
|-----|--|--|
| (a) | <ul style="list-style-type: none"> Underinflation (both sides worn) Incorrect camber (one side worn) Hard cornering Lack of rotation | <ul style="list-style-type: none"> Measure and adjust pressure Repair or replace suspension parts Reduce speed Rotate tires |
| (b) | <ul style="list-style-type: none"> Overinflation Lack of rotation | <ul style="list-style-type: none"> Measure and adjust pressure Rotate tires |
| (c) | <ul style="list-style-type: none"> Incorrect toe-in | <ul style="list-style-type: none"> Adjust toe-in |
| (d) | <ul style="list-style-type: none"> Incorrect camber or caster Malfunctioning suspension Unbalanced wheel Out-of-round brake drum or disc Other mechanical problem Lack of rotation | <ul style="list-style-type: none"> Repair or replace axle and suspension parts Repair or replace Balance or replace Correct or replace Correct or replace Rotate tires |



Air Pressure


Check the air pressure of all tires, including the spare tire, with an air pressure gauge. If necessary, adjust the air pressure.

Air pressure: Refer to page Q-2



Air Leakage

Verify that there is no air leakage from the air valve.




Loose Lug Nuts

Verify that the lug nuts are tightened to the specified torque.

Tightening torque:

89—117 N·m {9—12 kgf·m, 65—86 ft·lbf}




Wheel and Tire Runout

1. Jack up the vehicle and support it on safety stands.
2. Set the probe of a dial indicator against the wheel, and measure the runout through one full revolution.

Runout limit

| | mm {in} | |
|-------------------|------------|----------|
| Radial direction | 1.5 {0.06} | |
| Lateral direction | 2.5 {0.10} | Steel |
| | 2.0 {0.08} | Aluminum |

3. Replace the wheel if necessary.



REMOVAL / INSTALLATION

Installation


1. The wheel-to-hub contact surfaces must be clean.
2. Tighten the lug nuts to the specified torque.

Tightening torque:

89—117 N·m {9—12 kgf·m, 65—86 ft·lbf}

Caution

- Retighten the lug nuts to the specified torque after about 1000 km {620 miles} of driving.




TIRE ROTATION

To prolong tire life and assure uniform tire wear, rotate the tires as specified below. After rotating the tires, adjust each tire to the specified air pressure. (Refer to page Q-2.)

U.S.A. : Every 6000 km {3750 miles}

Canada : Every 24000 km {15000 miles} or 15 months (whichever comes first)



WHEEL BALANCE ADJUSTMENT

If a wheel becomes unbalanced or if a tire is replaced or repaired, the wheel must be rebalanced to within the specification.


Maximum unbalance (at rim edge)

14-inch wheel: 10 g {0.35 oz}

15-inch wheel: 9 g {0.32 oz}

Caution

- Do not use more than two balance weights on the inner or outer side of the wheel.
- One balance weight; max. 60 g {2.1 oz}.
- If the total weight exceeds 100 g {3.5 oz} on one side, rebalance after moving the tire around on the rim.
- Attach the balance weights tightly to the wheel.
- Select suitable balance weights for steel or aluminum alloy wheels.
- Do not use an on-car balancer on automatic trans-axle models; it may cause transaxle damage.




Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.

SUSPENSION

| | |
|---------------------------------------|------|
| INDEX | R- 2 |
| OUTLINE | R- 4 |
| SPECIFICATIONS | R- 4 |
| TROUBLESHOOTING GUIDE | R- 6 |
| WHEEL ALIGNMENT | R- 7 |
| PREINSPECTION | R- 7 |
| FRONT WHEEL ALIGNMENT | R- 7 |
| REAR WHEEL ALIGNMENT | R- 9 |
| FRONT SUSPENSION (STRUT) | R-11 |
| PREPARATION | R-11 |
| FRONT SHOCK ABSORBER AND SPRING | R-13 |
| LOWER ARM | R-22 |
| FRONT STABILIZER | R-24 |
| STABILIZER CONTROL LINK | R-26 |
| TRANSVERSE MEMBER | R-27 |
| FRONT CROSSMEMBER | R-28 |
| REAR SUSPENSION (STRUT) | R-30 |
| PREPARATION | R-30 |
| REAR SHOCK ABSORBER AND SPRING | R-31 |
| REAR STABILIZER | R-38 |
| STABILIZER CONTROL LINK | R-39 |
| LATERAL LINK AND TRAILING LINK | R-40 |
| REAR CROSSMEMBER | R-42 |

INDEX


FRONT SUSPENSION




- | | |
|---|---|
| <p>1. Front shock absorber and spring Removal / Installation page R-13 Disassembly / Inspection page R-15 Assembly When using SST 49 T034 1A0 page R-15 49 G034 1A0 page R-19</p> | <p>4. Stabilizer control link Removal / Inspection / Installation page R-26</p> |
| <p>2. Lower arm Removal / Inspection / Installation page R-22</p> | <p>5. Transverse member Removal / Inspection / Installation page R-27</p> |
| <p>3. Front stabilizer Removal / Inspection / Installation page R-24</p> | <p>6. Front crossmember Removal / Inspection / Installation page R-28</p> |

REAR SUSPENSION

DISC BRAKE TYPE



DRUM BRAKE TYPE



R

- | | |
|--|--|
| <p>1. Rear shock absorber and spring Removal / Installation page R-31 Disassembly / Inspection page R-32 Assembly When using SST 49 T034 1A0 page R-32 49 G034 1A0 page R-36</p> | <p>3. Stabilizer control link Removal / Inspection / Installation page R-39</p> |
| <p>2. Rear stabilizer Removal / Inspection / Installation page R-38</p> | <p>4. Lateral link and trailing link Removal / Inspection / Installation page R-40</p> |
| | <p>5. Rear crossmember Removal / Inspection / Installation page R-42</p> |

OUTLINE

SPECIFICATIONS

| Item | | Model | MX-6 | 626 |
|-----------------------------|--|---------|--|--|
| Suspension type | | | Strut | |
| Shock absorber type | | Front | Cylindrical, double-acting (oil-filled) | Cylindrical, double-acting, low-pressure gas charged |
| | | Rear | Cylindrical, double-acting, low-pressure gas charged | |
| Coil spring | Type | Front | Straight wound | |
| | | Rear | Taper wound | |
| Dimension | | | See coil spring specification | |
| Stabilizer | Type | | Torsion bar | |
| | Diameter mm {in} | Front | 25.4 {1.00} | |
| | | Rear | 12 {0.47} | |
| Wheel alignment (Unladen)*1 | | | | |
| Front | Maximum steering angle | Inner | 37° ± 2° | |
| | | Outer | 32° ± 2° | |
| | Total toe-in | mm {in} | 3 ± 4 {0.12 ± 0.16} | 3 ± 4 {0.12 ± 0.16} |
| | | Degree | 0°17' ± 0°23' | 0°17' ± 0°23' |
| | Camber angle (Difference between left and right) | Degree | -0°43' ± 1° (1°30' max) | -0°36' ± 1° (1°30' max) |
| | Caster angle (Difference between left and right) | Degree | 3°01' ± 1° (1°30' max) | 2°37' ± 1° (1°30' max) |
| SAI*2 | Degree | 15°25' | 15°04' | |
| Rear | Total toe-in | mm {in} | 3 ± 4 {0.12 ± 0.16} | 3 ± 4 {0.12 ± 0.16} |
| | | Degree | 0°17' ± 0°23' | 0°17' ± 0°23' |
| | Camber angle (Difference between left and right) | Degree | -0°54' ± 1° (1°30' max) | -0°09' ± 1° (1°30' max) |
| | Thrust angle | Degree | 0° ± 0°48' | 0° ± 0°48' |

*1 • Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position
• Adjust to the median when carrying out wheel alignment

*2 SAI: Steering Axis Inclination

Coil Spring Specifications

| Item | Identification mark color | | Wire diameter mm {in} | Coil outer diameter mm {in} | Free length mm {in} | No. of active coil |
|-------|---------------------------|-------------|--------------------------|--------------------------------|------------------------|-----------------------|
| | M*1 | A*2 | | | | |
| Front | A | Purple | — | 175 {6.9} | 293 {11.5} | 2.74 |
| | B | Light blue | — | | 301 {11.8} | 2.94 |
| | C | Orange | — | | 309 {12.2} | 3.11 |
| | D | Purple | White | | 345 {13.6} | 3.52 |
| | E | Light green | White | | 353 {13.9} | 3.62 |
| | F | Orange | White | | 355 {14.0} | 3.69 |
| | G | Yellow | White | | 349 {13.7} | 3.63 |
| | H | Pink | — | | 317 {12.5} | 3.20 |
| Rear | I | Blue | — | 122—152 {4.8—6.0} | 332 {13.1} | 4.92 |
| | J | Red | — | | 338 {13.3} | 5.24 |
| | K | Yellow | — | | 275 {10.8} | 3.94 |
| | L | Pink | — | | 279 {11.0} | 4.08 |

*1 Main identification mark color: lower side paint


*2 Auxiliary identification mark color: upper side paint

Coil Spring Applications

| Model | Engine | Transaxle | Front | Rear right | Rear left |
|-------|--------|-----------|-------|------------|-----------|
| 626 | FS | MTX | D | I | J |
| | FS | ATX | E | I | J |
| | KL | MTX | F | I | J |
| | KL | ATX | G | I | J |
| MX-6 | FS | MTX | A | K | L |
| | FS | ATX | B | K | L |
| | KL | MTX | C | K | L |
| | KL | ATX | H | K | L |

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Remedy | Page |
|--|--|----------------------|-----------|
| Body “rolls” | Weak stabilizer | Replace | R-24 |
| | Damaged or worn stabilizer bushing or control link | Replace | R-24, 26 |
| | Worn or deteriorated lower arm bushing | Replace | R-21 |
| | Malfunction of shock absorber | Replace | R-13, 31 |
| Poor riding comfort | Weakened coil spring | Replace | R-15, 32 |
| | Malfunction of shock absorber | Replace | R-13, 31 |
| Body leans | Weakened coil spring | Replace | R-15, 32 |
| | Damaged or worn stabilizer bushing or control link | Replace | R-24, 26 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| Abnormal noise from suspension system | Poor lubrication or wear of thrust bearing | Replace | R-13 |
| | Poor lubrication or wear of lower arm ball joint | Lubricate or replace | R-21 |
| | Looseness of peripheral connections | Tighten | — |
| | Malfunction of shock absorber | Replace | R-13, 31 |
| | Damaged or worn stabilizer, control link or stabilizer bracket | Replace | R-24, 26 |
| | Worn or deteriorated lower arm bushing | Replace | R-21 |
| General driving instability | Weakened coil spring | Replace | R-15, 32 |
| | Malfunction of shock absorber | Replace | R-13, 31 |
| | Worn or deteriorated lower arm bushing | Replace | R-21 |
| | Damaged or worn stabilizer bushing or control link | Replace | R-24, 26 |
| | Improperly adjusted wheel alignment | Adjust | R- 7 |
| | Damaged lower arm ball joint | Replace | R-21 |
| | Malfunction of steering system | — | section N |
| Damaged or unbalanced wheel(s) | — | section Q | |
| Heavy steering | Poor lubrication or wear of lower arm ball joint | Lubricate or replace | R-21 |
| | Improperly adjusted wheel alignment | Adjust | R- 7 |
| | Malfunction of steering system | — | section N |
| | Damaged or unbalanced wheel(s) | — | section Q |
| Steering wheel pulls to one side | Weakened coil spring | Replace | R-15, 32 |
| | Damaged or worn stabilizer bushing or control link | Replace | R-24, 26 |
| | Worn or deteriorated lower arm bushing | Replace | R-21 |
| | Damaged lower arm ball joint | Replace | R-21 |
| | Improperly adjusted wheel alignment | Adjust | R- 7 |
| | Malfunction of steering system | — | section N |
| | Malfunction of braking system | — | section P |
| Damaged or unbalanced wheel(s) | — | section Q | |
| “Shimmy” occurs (steering wheel vibrates circumferentially) | Damaged lower arm ball joint | Replace | R-21 |
| | Malfunction of shock absorber | Replace | R-13, 31 |
| | Loose shock absorber mounting | Tighten | R-13, 31 |
| | Worn or deteriorated lower arm bushing | Replace | R-21 |
| | Damaged or worn stabilizer bushing or control link | Replace | R-24, 26 |
| | Damaged or leaking lower arm bushing (rear) | Replace | R-21 |
| | Improperly adjusted wheel alignment | Adjust | R- 7 |
| | Damaged or worn wheel bearing | Replace | section M |
| | Malfunction of steering system | — | section N |
| | Damaged or unbalanced wheel(s) | — | section Q |
| Steering wheel doesn’t return properly | Stuck or damaged lower arm ball joint | Replace | R-21 |
| | Improperly adjusted wheel alignment | Adjust | R- 7 |
| | Malfunction of steering system | — | section N |
| | Damaged or unbalanced wheel(s) | — | section Q |



WHEEL ALIGNMENT

PREINSPECTION

1. Check the tire inflations and set to the recommended pressure if necessary.
2. Inspect the front wheel bearing play. Replace the bearing if necessary.
3. Inspect the wheel and tire runout.
4. Inspect the ball joints and steering linkage for excessive looseness.
5. Position the vehicle on level ground and with no luggage or passenger load.
6. The difference in height between the left and right sides from the center of the wheel to the fender brim must not exceed 10 mm {0.39 in}.
7. Shake the vehicle to check operation of the shock absorbers.

FRONT WHEEL ALIGNMENT

Specifications (Unladen)*¹

626

| Fuel gauge indication | | Empty | 1/4 | 1/2 | 3/4 | Full |
|----------------------------|---------|----------------------------------|----------------------------------|----------------------------------|---------------------|------------|
| Maximum steering angle | Inner | 37° ± 2° | | | | |
| | Outer | 32° ± 2° | | | | |
| Total toe-in | mm {in} | 4 ± 4 {0.16 ± 0.16} | | | 3 ± 4 {0.12 ± 0.16} | |
| | Degree | 0°23' ± 0°23' | | | 0°17' ± 0°23' | |
| Camber angle* ² | | -0°35' ± 1° | | | -0°36' ± 1° | |
| Caster angle* ² | | FS: 2°25' ± 1° KL: 2°26' ± 1° | FS: 2°27' ± 1° KL: 2°28' ± 1° | FS: 2°31' ± 1° KL: 2°32' ± 1° | 2°34' ± 1° | 2°37' ± 1° |
| SAI* ³ | | 15°04' | | | | |

MX-6


| Fuel gauge indication | | Empty | 1/4 | 1/2 | 3/4 | Full |
|----------------------------|---------|---------------------|------------|------------|---------------------|------------|
| Maximum steering angle | Inner | 37° ± 2° | | | | |
| | Outer | 32° ± 2° | | | | |
| Total toe-in | mm {in} | 4 ± 4 {0.16 ± 0.16} | | | 3 ± 4 {0.12 ± 0.16} | |
| | Degree | 0°23' ± 0°23' | | | 0°17' ± 0°23' | |
| Camber angle* ² | | -0°42' ± 1° | | | -0°43' ± 1° | |
| Caster angle | | 2°52' ± 1° | 2°54' ± 1° | 2°56' ± 1° | 2°59' ± 1° | 3°01' ± 1° |
| SAI* ³ | | 15°25' | | | | |

*¹ Radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

Adjust to the median when carrying out wheel alignment.

*² Difference between left and right must not exceed 1.5°.

*³ SAI: Steering axis inclination




Adjustment

Total toe-in

1. Remove the steering gear boot clamps.
2. Loosen the left and right tie rod locknuts, and turn the tie rods equally. Both tie rods are right threaded, so turning the right tie rod toward the front of the vehicle and the left toward the rear increases toe-in.

Note

- Turning both tie rods one complete turn changes toe-in by about 6 mm {0.24 in}.




3. Tighten the tie rod locknuts.

Tightening torque:

69—98 N·m {7.0—10.0 kgf·m, 51—72.3 ft·lbf}


4. Verify that the boots are not twisted and install the boot clamps.



Maximum steering angle

1. Remove the steering gear boot clamps.
2. Loosen the left and right tie rod locknuts, and turn the tie rods equally to provide the correct maximum steering angle.

Maximum left/right difference: 3 mm {0.12 in}




3. Tighten the tie rod locknuts.

Tightening torque:


69—98 N·m {7.0—10.0 kgf·m, 51—72.3 ft·lbf}

4. Verify that the boots are not twisted and install the boot clamps.
5. Inspect and adjust the toe-in after adjusting the turning angle.




Camber and caster

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the mounting block nuts.
3. Push the mounting block downward, and turn it to the desired position.



| Mark | Difference from standard position | |
|------|-----------------------------------|--------------|
| | Camber angle | Caster angle |
| A | 0° | +30° |
| B | +30° | +30° |
| C | +30° | 0° |



4. Install and tighten the mounting nuts to the specified torque.

Tightening torque:

47—62 N·m {4.7—6.4 kgf·m, 33—46 ft·lbf}

REAR WHEEL ALIGNMENT Specifications (Unladen)*1
626


| Fuel gauge indication | | Empty | 1/4 | 1/2 | 3/4 | Full |
|-----------------------|---------|---------------------|-------------|---------------------|-------------|-------------|
| Total toe-in | mm {in} | 2 ± 4 {0.08 ± 0.16} | | 3 ± 4 {0.12 ± 0.16} | | |
| | Degree | 0°12' ± 0°23' | | 0°17' ± 0°23' | | |
| Camber angle*2 | | -0°02' ± 1° | -0°04' ± 1° | -0°06' ± 1° | -0°07' ± 1° | -0°09' ± 1° |
| Thrust angle | | 0° ± 0°48' | | | | |

MX-6

| Fuel gauge indication | | Empty | 1/4 | 1/2 | 3/4 | Full |
|-----------------------|---------|---------------------|---------------------|-------------|-----|-------------|
| Total toe-in | mm {in} | 2 ± 4 {0.08 ± 0.16} | 3 ± 4 {0.12 ± 0.16} | | | |
| | Degree | 0°12' ± 0°23' | 0°17' ± 0°23' | | | |
| Camber angle*2 | | -0°51' ± 1° | | -0°53' ± 1° | | -0°54' ± 1° |
| Thrust angle | | 0° ± 0°48' | | | | |

*1 Radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions. Adjust to the median when carrying out wheel alignment.

*2 Difference between left and right must not exceed 1.5°.




Adjustment


Total toe-in

The thrust angle can only be measured with 4-wheel alignment tester. If the thrust angle is not within specification, check the body dimensions. (Refer to the 626/MX-6 Bodyshop Manual)

Thrust angle: 0° ± 0°48'



1. Remove the access hole caps.



2. Loosen the cam nut on the lateral link.
3. Turn the adjusting cam bolt as indicated to adjust the toe-in.

| | Left wheel | Right wheel |
|-------------------|------------------|------------------|
| Toe-out direction | Counterclockwise | Clockwise |
| Toe-in direction | Clockwise | Counterclockwise |

Note


- Turning the adjusting cam bolt one graduation changes the toe-in about 3.2 mm {0.13 in} (0°18').

4. Tighten the cam nut.

Tightening torque:

















79—116 N·m {8.0—11.9 kgf·m, 58—86.0 ft·lbf}










5. Install the caps.



FRONT SUSPENSION (STRUT)

PREPARATION
SST

| | | | |
|--|--|---|--|
| <p>49 B034 2A0A Replacer, rubber bushing</p>  | <p>For removal / installation of lower arm bushing</p> | <p>49 B034 202 Support block (Part of 49 B034 2A0A)</p>  | <p>For removal of lower arm bushing</p> |
| <p>49 B034 203 Guide (Part of 49 B034 2A0A)</p>  | <p>For installation of lower arm bushing</p> | <p>49 B034 204A Attachment (Part of 49 B034 2A0A)</p>  | <p>For removal / installation of lower arm bushing</p> |
| <p>49 B034 205A Replacer (Part of 49 B034 2A0A)</p>  | <p>For installation of lower arm bushing</p> | <p>49 B034 206 Shaft (Part of 49 B034 2A0A)</p>  | <p>For removal / installation of lower arm bushing</p> |
| <p>49 G034 205 Bearing (Part of 49 B034 2A0A)</p>  | <p>For removal / installation of lower arm</p> | <p>49 W038 002 Nut (Part of 49 B034 2A0A)</p>  | <p>For removal / installation of lower arm</p> |
| <p>49 T034 1A0 Coil spring compressor set</p>  | <p>For removal / installation of coil spring</p> | <p>49 0180 510B Attachment, steering worm bearing preload measuring</p>  | <p>For measurement of ball joint preload</p> |
| <p>49 T034 101 Spring compressor (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 T034 103 Hook (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 T034 102 Stand (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 T034 104 Support (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 T034 105 Attachment (with engine stand)</p>  | <p>For removal / installation of coil spring</p> | <p>49 0107 680A Engine stand</p>  | <p>For removal / installation of coil spring</p> |

| | | | |
|---|--|---|--|
| <p>49 G034 1A0</p> <p>Coil spring compressor</p>  | <p>For removal / installation of coil spring</p> | <p>49 G034 101</p> <p>Body (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 G034 102</p> <p>Screw (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 G034 103</p> <p>Arm (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 8038 785</p> <p>Installer, boot</p>  | <p>For installation of ball joint dust boot</p> | <p>49 G017 5A0</p> <p>Support, engine</p>  | <p>For support of engine</p> |
| <p>49 G017 502</p> <p>Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 501</p> <p>Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 503</p> <p>Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>—</p> | <p>—</p> |


FRONT SHOCK ABSORBER AND SPRING

Removal / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Tighten all nuts and bolts to the specified torques, referring to the figure.
7. Install the wheels.


Tightening torque: 89—117 N·m {9.0—12.0 kgf·m, 66—86.7 ft·lbf}

8. Adjust the front wheel alignment. (Refer to page R-7.)




1. Hose clip and flexible hose
2. ABS wheel-speed sensor harness
Installation Note page R-14
3. Shock absorber bolt
4. Nut

5. Sheet
6. Front shock absorber and spring
Installation Note page R-14
Disassembly / Inspection page R-15
Assembly page R-16 or R-19

**Installation note****Front shock absorber and spring**


Face the mounting block direction indicator toward the rear outboard position, and install the shock absorber.

**ABS wheel-speed sensor harness**

Install the sensor harness bracket in the direction shown.

Disassembly / Inspection

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.



- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Cap 2. Piston rod nut Disassembly Note When using SST 49 T034 1A0 below 49 G034 1A0 page R-19 3. Mounting rubber Inspect for damage, deterioration, and weakness 4. Thrust bearing Inspect for damage, wear, and poor lubrication 5. Upper spring seat 6. Upper rubber spring seat Inspect for damage and deterioration | <ol style="list-style-type: none"> 7. Dust cover Inspect for damage and deterioration 8. Bound stopper Inspect for damage and cracks 9. Coil spring Inspect for damage, deterioration, and weakness 10. Lower rubber spring seat Inspect for damage and cracks 11. Shock absorber Inspection page R-16 |
|---|---|


When using SST 49 T034 1A0
Disassembly note
Piston rod nut

Warning


- Removing the piston rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston rod nut.

Caution


- To prevent damage to the mounting rubber, use protective plates in the vise jaws.



1. Secure the mounting rubber in a vise.
2. Loosen the nut several turns, but do not remove it.



3. Assemble the **SST**.
4. Secure the shock absorber in the **SST**.
5. Compress the coil spring by using the **SST** and remove the nut.




Inspection

Shock absorber

Check the following and replace if necessary.

1. Inspect for damage and oil leakage.
2. Secure a handle to the piston rod, and compress and expand the shock piston at least three times. Verify that the operational force does not change and that there is no unusual noise.



Disposal of shock absorber (626)


Warning

- The gas in the shock absorber is pressurized, and could spray metal chips into the eyes and face when drilling. Whenever drilling into a shock absorber, wear protective eye wear.

1. Clamp a shock absorber flat or with the piston downwards.
2. Drill the 2—3 mm {0.08—0.12 in} hole at a point of 20—30 mm {0.08—0.12 in} from the bottom of the tube, so that the gas can escape.
3. Turn the hole downwards.
4. The oil can be collected by moving the piston rod several times up and down and cutting the tube at the end.
5. Dispose of waste oil according to the waste disposal law.


Note

- Shock absorber gas is nitrogen gas.
- Shock absorber oil is mineral oil.




Assembly


1. Temporarily assemble the upper rubber spring seat, the upper spring seat and coil spring to the shock absorber, as shown.
2. Mark the upper rubber spring seat, the upper spring seat and coil spring for proper reassembly.




3. Align the marks of the upper spring seat and coil spring. Protect the upper spring seat and the coil spring with a piece of cloth; then assemble the **SST**.
4. Use the **SST** to compress the spring.




5. Install the bound stopper.
6. Install the dust cover.
7. Install the lower rubber spring seat.



8. Install the shock absorber, fitting the end of the coil into the step of the lower seat.



9. Install the thrust bearing.
10. Install the mounting rubber, facing the direction indicator as shown.
11. Tighten the nut several turns.
12. Remove the **SST**.
13. Verify that the lower coil of the spring is seated on the step of the lower seat.



Caution


- To prevent damage to the mounting rubber, use protective plates in the jaws of the vise.

14. Secure the mounting rubber in a vise.
15. Tighten the nut.

Tightening torque:

90—116 N·m {9.1—11.9 kgf·m, 66—86.0 ft·lbf}

16. Install the cap.



When using SST 49 G034 1A0

Disassembly note

Piston rod nut

Warning


- Removing the piston rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death.

Secure the shock absorber in the SST before removing the piston rod nut.

Caution


- Do not remove the nut.
- To prevent damage to the mounting rubber, use protective plates in the vise jaws.

1. Secure the mounting rubber in a vise.
2. Loosen the nut several turns, but do not remove it.
3. Assemble the SST.
4. Secure the shock absorber in the SST.
5. Compress the coil spring by using the SST and remove the nut.





Assembly

1. Assemble the SST, and secure the SST in a vise.
2. Install the lower rubber spring seat.




3. Install the coil spring, fitting the end of the coil into the step of the lower seat.







4. Compress the coil spring by using the **SST**.
5. Install the spring so that the lower coil is seated on the step of the lower seat.



6. Install the bound stopper.
7. Install the dust cover.
8. Install the upper rubber spring seat.
9. Install the upper spring seat, facing the direction indicator as shown.



10. Install the thrust bearing.
11. Install the mounting rubber, facing the direction indicator as shown.
12. Tighten the nut several turns.
13. Remove the **SST**.
14. Verify that the lower coil of the spring is seated on the step of the lower seat.

**Caution**

- To prevent damage to the mounting rubber, use protective plates in the jaws of the vise.

15. Secure the mounting rubber in a vise.
16. Tighten the nut.

Tightening torque:


90—116 N·m {9.1—11.9 kgf·m, 66—86.0 ft·lbf}

17. Install the cap.


LOWER ARM

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten the lower arm bolts to just under the specified torque. Tighten all other nuts and bolts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unloaded, tighten the lower arm bolts.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Bolt (Lower arm ball joint) 2. Nut (Stabilizer control link) 3. Bolt, and dynamic damper 4. Lower arm assembly Inspection page R-23 5. Dust boot Removal Note below Installation Note page R-23 | <ol style="list-style-type: none"> 6. Lower arm bushing (front) Removal Note page R-23 Installation Note page R-23 7. Stopper Inspect for damage and deterioration 8. Lower arm bushing (rear) Inspect for damage, oil leakage, and deterioration 9. Lower arm |
|--|--|



Removal note


Dust boot

Carefully remove the dust boot with a chisel.



Lower arm bushing (front)

1. Cut away the projecting rubber of the lower arm bushing.
2. Set the **SST** onto the lower arm, and remove the bushing.




Inspection

Lower arm assembly

Inspect all parts and repair or replace as necessary.

1. Lower arm for damage and cracks
2. Bushings for deterioration and wear
3. Dust boot for damage
4. Ball joint for looseness and damage
If the ball joint needs to be replaced, replace the lower arm.



5. Ball joint preload


Move the ball joint back and forth 5 or 6 times, then attach the **SST** to the ball stud, and measure the preload with a pull scale.

Ball joint preload:

1.0—4.9 N·m {10—50 kgf·cm, 8.6—43 in·lbf}

Pull scale reading:


9.8—49 N {1.0—5.0 kgf, 2.2—11.0 lbf}



Installation note

Lower arm bushing (front)

Install the new bushing, and pull it into the lower arm by using the **SST**.




Dust boot

1. Wipe the grease off the ball stud.
2. Fill the inside of the new dust boot with grease.
3. Press the boot onto the ball joint by using the **SST**.
4. Wipe away the excess grease.


FRONT STABILIZER

Removal / Inspection / Installation


1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten the stabilizer bracket bolts to just under the specified torque. Tighten all other nuts and bolts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unloaded, tighten the stabilizer bracket bolts.
8. Adjust the front wheel alignment. (Refer to page R-7.)
9. Bleed the air from the power steering system. (Refer to section N.)




FS ENGINE



KL ENGINE




- 1. Transverse member
Removal / Inspection /
Installation page R-27
- 2. Engine mount member
Removal Note below
- 3. Front exhaust pipe
Removal / Installation sections F1, F2
- 4. No.1 engine mount
- 5. Tie-rod end ball joint
Removal / Installation section N
- 6. Pressure pipe
Service section N
- 7. Return hose
- 8. Bolt (intermediate shaft)
- 9. Bolt (lower arm ball joint)
- 10. Steering gear and linkage
- 11. Nut and bolt
- 12. Crossmember and lower arm
- 13. Stabilizer control link
- 14. Stabilizer bracket
Installation Note below
- 15. Stabilizer bushing
Inspect to damage and weakness
Installation Note below
- 16. Front stabilizer bar
Removal Note below



Removal note


Engine mount member

- 1. Support the engine by using the **SST**.
- 2. Remove the engine mount member.



Front stabilizer bar


- 1. Support the crossmember by using a jack, and remove the bolts and nuts.
- 2. Remove the stabilizer bracket.
- 3. Lower the crossmember slowly and remove the stabilizer bar from the crossmember.



Installation note

Stabilizer bushing and bracket

- 1. Apply rubber grease to the inside surface of the stabilizer bushing.
- 2. Align the bushing with the installation mark on the stabilizer bar.




- 3. Install the stabilizer bracket in the direction shown.

STABILIZER CONTROL LINK

Removal / Inspection / Installation


1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels.
3. Remove in the order as shown in the figure.
4. Inspect all parts and replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheels.

Tightening torque: 89—117 N·m {9—12 kgf·m, 66—86.7 ft·lbf}



1. Nuts

2. Stabilizer control link
Inspection below



Inspection

Check the following and replace if necessary.

Stabilizer control link

1. Inspect for bending and damage.
2. Measure the ball joint starting torque.(a) Rock the ball joint stud side to side 10 times.(b) Rotate the ball joint stud 10 times.(c) Measure the starting torque by using a suitable Allen socket and a torque wrench.


Starting torque:

0.2—1.5 N·m {2.0—15.0 kgf·cm, 1.7—13 in·lbf}

TRANSVERSE MEMBER

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the undercover.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal.




1. Bolt

2. Transverse member
Inspect for cracks and damage


FRONT CROSSMEMBER

Removal / Inspection / Installation


1. Jack up the front of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten the lower arm and the stabilizer bracket bolts to just under the specified torque. Tighten all other nuts and bolts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unloaded, tighten the lower arm and stabilizer bracket bolts.
8. Adjust the front wheel alignment. (Refer to page R-7.)
9. Bleed the air from the power steering system. (Refer to section N.)




FS ENGINE



KL ENGINE




- 1. Transverse member
- 2. Engine mount member
Removal Note below
- 3. Front exhaust pipe
Removal / Installation sections F1, F2
- 4. Engine mount No.1
- 5. Tie rod end ball joint
Removal / Installation section N
- 6. Pressure pipe
Service section N
- 7. Return hose
- 8. Bolts (intermediate shaft)
- 9. Bolt (lower arm ball joint)
- 10. Steering gear and linkage
- 11. Nut and bolt
- 12. Lower arm
- 13. Front crossmember and stabilizer
Removal Note below
- 14. Stabilizer bracket
Installation Note below
- 15. Stabilizer bushing
Installation Note below
- 16. Front stabilizer
- 17. Front crossmember



Removal note


Engine mount member

- 1. Support the engine by using the SST.
- 2. Remove the engine mount member nuts.



Front crossmember and stabilizer


- 1. Support the crossmember by using a jack and remove the bolts and nuts.
- 2. Remove the crossmember and steering assembly.



Installation note

Stabilizer bushing and bracket

- 1. Apply rubber grease to the inside surface of the stabilizer bushing.
- 2. Align the bushing with the installation mark on the stabilizer bar.














- 3. Install the stabilizer bracket in the direction shown.

REAR SUSPENSION (STRUT)

PREPARATION

SST

| | | | |
|---|--|--|--|
| <p>49 T034 1A0</p> <p>Coil spring compressor set</p>  | <p>For removal / installation of coil spring</p> | <p>49 T034 102</p> <p>Stand (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 T034 101</p> <p>Spring compressor (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 T034 103</p> <p>Hook (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 T034 104</p> <p>Support (Part of 49 T034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 0107 680A</p> <p>Engine stand</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 T034 105</p> <p>Attachment (with engine stand)</p>  | <p>For removal / installation of coil spring</p> | <p>49 G034 1A0</p> <p>Coil spring compressor</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 G034 101</p> <p>Body (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>49 G034 102</p> <p>Screw (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> |
| <p>49 G034 103</p> <p>Arm (Part of 49 G034 1A0)</p>  | <p>For removal / installation of coil spring</p> | <p>—</p> | <p>—</p> |


REAR SHOCK ABSORBER AND SPRING

Removal / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheels.
3. Remove the trunk side trim. (Refer to section S.)
4. Remove in the order as shown in the figure.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the trunk side trim. (Refer to section S.)
7. Install the wheels.


Tightening torque: 89—117 N·m {9—12 kgf·m, 66—86.7 ft·lbf}

8. After installation, measure the rear wheel alignment and adjust it if necessary. (Refer to page R-9.)



1. Hose clip and flexible hose
2. ABS wheel-speed sensor harness
Installation Note below
3. Shock absorber bolt
4. Nut

5. Sheet
6. Rear shock absorber and spring
Disassembly / Inspection page R-32
Assembly page R-34 or 36




Installation note

ABS wheel-speed sensor harness

Install the sensor harness bracket in the direction shown.

Disassembly / Inspection

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.



1. Nut

Disassembly Note

When using SST

49 T034 1A0 below

49 G034 1A0 page R-36

2. Mounting rubber

Inspect for damage and weakness

3. Upper spring seat

Inspect for damage and cracks

4. Dust cover

Inspect for damage and deterioration

5. Bound stopper

Inspect for damage and cracks

6. Coil spring

Inspect for damage and weakness

7. Lower spring seat

Inspect for damage and cracks

8. Shock absorber

Inspection page R-33

When using SST 49 T034 1A0

Disassembly note


Nut

Warning


- Removing the piston rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston rod nut.

Caution


- To prevent damage to the mounting rubber, use protective plates in the vise jaws.



1. Secure the mounting rubber in a vise.
2. Loosen the nut several turns, but do not remove it.



3. Assemble the **SST**.
4. Secure the shock absorber in the **SST**.
5. Compress the coil spring by using the **SST** and remove the nut.




Inspection

Shock absorber

Check for the following and replace the shock absorber, if necessary.

1. Inspect for damage and oil leakage.
2. Secure a handle to the piston rod, and compress and expand the shock piston at least three times. Verify that the operational force does not change and that there is no unusual noise.



Disposal of shock absorber


Warning

- The gas in the shock absorber is pressurized, and could spray metal chips into the eyes and face when drilling. Whenever drilling into a shock absorber, wear protective eye wear.


1. Clamp a shock absorber flat or with the piston downwards.
2. Drill the 2—3 mm {0.08—0.12 in} hole at a point of 20—30 mm {0.08—0.12 in} from the bottom of the tube, so that the gas can escape.
3. Turn the hole downwards.
4. The oil can be collected by moving the piston rod several times up and down and cutting the tube at the end.
5. Dispose of waste oil according to the waste disposal law.

Note


- Shock absorber gas is nitrogen gas.
- Shock absorber oil is mineral oil.

**Assembly**


1. Temporarily assemble the upper spring seat, the mounting rubber and coil spring to the shock absorber, as shown.
2. Mark the upper spring seat and coil spring for proper reassembly.




3. Align the marks of the upper spring seat and coil spring. Protect the upper spring seat and the coil spring with a piece of cloth, then assemble the **SST**.
4. Use the **SST** to compress the spring.



5. Install the lower spring seat.
6. Install the bound stopper.
7. Install the dust cover.
8. Install the shock absorber, fitting the end of the coil into the step of the lower seat.



9. Tighten the nut several turns.
10. Remove the **SST**.
11. Verify that the lower coil of the spring is properly seated on the step of the lower seat.




Caution

- Use protective plates in the jaws of the vise.

12. Secure the mounting rubber in a vise.
13. Tighten the nut.

Tightening torque:

90—116 N·m {9.1—11.9 kgf·m, 66—86.0 ft·lbf}



When using SST 49 G034 1A0

Disassembly note


Nut

Warning


- Removing the piston rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston rod nut.

Caution

- To prevent damage to the mounting rubber, use protective plates in the vise jaws.




1. Secure the mounting rubber in a vise.
2. Loosen the nut several turns, but do not remove it.
3. Assemble the SST.
4. Secure the shock absorber in the SST.
5. Compress the coil spring by using the SST and remove the nut.




Assembly


1. Assemble the SST, and secure the SST in a vise.




2. Install the lower rubber spring seat.
3. Install the coil spring, fitting the end of the coil into the step of the lower seat.



4. Compress the coil spring by using the SST.



5. Install the stopper.
6. Install the dust cover.
7. Install the upper spring seat.
8. Install the mounting rubber, facing the direction indicator as shown in the figure.
9. Tighten the nut several turns.
10. Remove the **SST**.
11. Verify that the lower coil of the spring is properly seated on the step of the lower seat.



Caution

- Use protective plates in the jaws of the vise.

12. Secure the mounting rubber in a vise.
13. Tighten the nut.


Tightening torque:

90—116 N·m {9.1—11.9 kgf·m, 66—86.0 ft·lbf}


REAR STABILIZER

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten the stabilizer bracket bolts to just under the specified torque. Tighten all other nuts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unloaded, tighten the stabilizer bracket bolts.



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Nut 2. Set washer 3. Protector 4. Bolt 5. Nut 6. Stabilizer bracket Installation Note below | <ol style="list-style-type: none"> 7. Stabilizer bushing Inspect for damage and weakness Installation Note below 8. Rear stabilizer bar Inspect for damage and deformation |
|---|--|



Installation note

Stabilizer bushing and bracket


1. Apply rubber grease to the inside surface of the stabilizer bushing.
2. Align the bushing with the installation mark on the stabilizer bar.

STABILIZER CONTROL LINK

Removal / Inspection / Installation


1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheels.

Tightening torque: 89—117 N·m {9—12 kgf·m, 66—86.7 ft·lbf}



1. Nuts
2. Set washer
3. Protector

4. Stabilizer control link
Inspection below



Inspection

Check the following and replace if necessary

Stabilizer control link

1. Inspect for bending and damage.
2. Measure the ball joint starting torque.
 - (1) Rock the ball joint stud side to side 10 times.
 - (2) Rotate the ball joint stud 10 times.
 - (3) Measure the starting torque by using a suitable Allen socket and a torque wrench.


Starting torque:

0.2—1.5 N·m {2.0—15.0 kgf·cm, 1.7—13 in·lbf}

LATERAL LINK AND TRAILING LINK


Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove in the order as shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Tighten the lateral link and trailing link mounting bolts and nuts to just under the specified torque. Tighten brake cable nuts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unloaded, tighten the lateral link and the trailing link mounting bolts.
8. After installation, measure the rear wheel alignment and adjust it if necessary. (Refer to page R-9.)



N-m {kgf-m, ft-lbf}


- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Cap 2. Stabilizer control link 3. Bolt, washers and nut 4. Nut, cam plate, and adjusting cam bolt Removal Note page R-41 Installation Note page R-41 5. Lateral link (rear) Inspect for deformation Inspect bushing for damage 6. Bolt (Crossmember) Removal Note page R-41 | <ol style="list-style-type: none"> 7. Bolt, washer, and nut 8. Lateral link (front) Inspect for deformation Inspect bushing for damage 9. Brake cable bracket 10. Trailing link Inspect for deformation Inspect bushing for damage |
|---|--|



Removal note


Nut, cam plate, and adjusting cam bolt

Before loosening the nut, make a mark on the cam plate and the crossmember for reference during installation.



Bolt (Crossmember)

Support the crossmember by using a jack and remove the bolts.



Installation Note

Nut, cam plate, and adjusting cam bolt

1. Install the cam plate so that the notch faces the same direction as the adjusting cam bolt.
2. Align to the mark made before removing the adjusting cam bolt. Tighten the nut.


Tightening torque:

79—116 N·m {8.0—11.9 kgf·m, 58—86.0 ft·lbf}

REAR CROSSMEMBER

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove in the order shown in the figure.
3. Inspect all parts and replace as necessary.
4. Install in the reverse order of removal.
5. Tighten the stabilizer bracket, lateral link and trailing link mounting bolts to just under the specified torque. Tighten all other bolts and nuts to the specified torque.
6. Lower the vehicle.
7. With the vehicle unladen, tighten the stabilizer bracket lateral link and trailing link mounting bolts.
8. After installation, measure the rear wheel alignment and adjust it if necessary. (Refer to page R-9.)




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Rear stabilizer Removal / Inspection / Installation page R-38 2. Lateral link (rear) Removal / Inspection / Installation page R-40 3. Bolts | <ol style="list-style-type: none"> 4. Rear crossmember and lateral link 5. Lateral link (front) Removal / Inspection / Installation page R-40 6. Rear crossmember Inspect for damage and cracks |
|--|--|

Before beginning any service procedure, refer to section S of the 1996 626/MX-6 Body Electrical Troubleshooting Manual for air bag system service warnings.


BODY

| | | | |
|---------------------------------------|-------|------------------------------------|-------|
| INDEX | S- 2 | MOLDING | S- 44 |
| HOOD | S- 5 | PREPARATION | S- 44 |
| COMPONENTS | S- 5 | COMPONENTS | S- 44 |
| FRONT DOOR | S- 7 | COWL GRILLE | S- 52 |
| PREPARATION | S- 7 | COMPONENTS | S- 52 |
| COMPONENTS | S- 8 | OUTSIDE MIRROR | S- 53 |
| FRONT WINDOW REGULATOR, | | COMPONENTS | S- 53 |
| GLASS AND GUIDE | S- 10 | REARVIEW MIRROR | S- 56 |
| COMPONENTS | S- 10 | COMPONENTS | S- 56 |
| FRONT DOOR GLASS | S- 17 | WINDSHIELD WIPER AND | |
| FRONT DOOR LOCK AND OPENER | S- 18 | WASHER | S- 57 |
| COMPONENTS | S- 18 | COMPONENTS | S- 57 |
| REAR DOOR | S- 20 | WINDSHIELD WIPER MOTOR | S- 59 |
| COMPONENTS | S- 20 | WINDSHIELD | S- 60 |
| REAR WINDOW REGULATOR, | | PREPARATION | S- 60 |
| GLASS AND GUIDE | S- 22 | COMPONENTS | S- 60 |
| COMPONENTS | S- 22 | REAR WINDOW GLASS | S- 65 |
| REAR DOOR LOCK AND OPENER .. | S- 24 | PREPARATION | S- 65 |
| COMPONENTS | S- 24 | COMPONENTS | S- 65 |
| WINDOW FRAME WEATHERSTRIP .. | S- 25 | QUARTER WINDOW GLASS | S- 70 |
| COMPONENTS | S- 25 | PREPARATION | S- 70 |
| TRUNK LID | S- 26 | COMPONENTS | S- 70 |
| COMPONENTS | S- 26 | INNER SLIDING SUNROOF | S- 73 |
| TRUNK LID LOCK AND OPENER ... | S- 29 | PREPARATION | S- 73 |
| COMPONENTS | S- 29 | COMPONENTS | S- 73 |
| FUEL-FILLER LID AND OPENER ... | S- 31 | OUTER SLIDING SUNROOF | S- 78 |
| COMPONENTS | S- 31 | COMPONENTS | S- 78 |
| FRONT BUMPER | S- 32 | SUNROOF DRIVE UNIT | S- 82 |
| COMPONENTS | S- 32 | DASHBOARD AND CONSOLE | S- 84 |
| REAR BUMPER | S- 36 | DASHBOARD AND CONSOLE | S- 84 |
| COMPONENTS | S- 36 | TRIM | S- 91 |
| RADIATOR GRILLE | S- 40 | COMPONENTS | S- 91 |
| COMPONENTS | S- 40 | FLOOR COVERING | S- 99 |
| REAR FINISHER | S- 41 | COMPONENTS | S- 99 |
| COMPONENTS | S- 41 | HEADLINER | S-100 |
| REAR SPOILER | S- 42 | COMPONENTS | S-100 |
| COMPONENTS | S- 42 | SEAT BELT | S-103 |
| EXTRACTOR CHAMBER | S- 43 | COMPONENTS | S-103 |
| COMPONENTS | S- 43 | SEAT | S-106 |
| | | COMPONENTS | S-106 |


INDEX



- | | |
|--|---|
| 1. Hood | 8. Radiator grille |
| Removal / Installation page S- 5 | Removal / Installation page S-40 |
| Adjustment page S- 6 | 9. Molding |
| 2. Front door | Removal / Installation page S-44 |
| Removal / Installation page S- 8 | 10. Cowl grille |
| Adjustment page S- 9 | Removal / Installation page S-52 |
| 3. Front window regulator, glass and guide | 11. Outside mirror |
| Removal / Installation page S-10 | Removal / Installation page S-53 |
| Adjustment page S-13 | Replacement of mirror glass ... page S-55 |
| Disassembly / Assembly page S-17 | 12. Rearview mirror |
| 4. Front door lock and opener | Removal / Installation page S-56 |
| Removal / Installation page S-18 | 13. Windshield wiper and washer |
| 5. Window frame weatherstrip | Removal / Installation page S-57 |
| Removal / Installation page S-25 | Adjustment page S-58 |
| 6. Fuel-filler lid and opener | Disassembly / Assembly page S-59 |
| Removal / Installation page S-31 | 14. Windshield |
| 7. Front bumper | Removal / Installation page S-60 |
| Removal / Installation page S-32 | |
| Disassembly / Assembly page S-34 | |



- | | |
|--|---|
| <ul style="list-style-type: none"> 1. Rear door Removal / Installation page S-20 Adjustment page S-21 2. Rear window regulator, glass and guide Removal / Installation page S-22 3. Rear door lock and opener Removal / Installation page S-24 4. Trunk lid Removal / Installation page S-26 Adjustment page S-28 5. Trunk lid lock and opener Removal / Installation page S-29 Adjustment page S-30 6. Rear bumper Removal / Installation page S-36 Disassembly / Assembly page S-38 7. Rear finisher Removal / Installation page S-41 8. Rear spoiler Removal / Installation page S-42 | <ul style="list-style-type: none"> 9. Extractor chamber Removal / Installation page S-43 10. Molding Removal / Installation page S-44 11. Rear window glass Removal / Installation page S-65 12. Quarter window glass Removal / Installation page S-70 13. Inner sliding sunroof Removal / Inspection page S-73 Adjustment page S-77 Inspection page S-77 14. Outer sliding sunroof Removal / Installation page S-78 Disassembly / Assembly page S-82 Adjustment page S-83 Inspection page S-83 |
|--|---|




- | | |
|--|---|
| 1. Trunk lid lock and opener Removal / Installation page S- 29 Adjustment page S- 30 | 6. Headliner Removal / Installation page S-100 |
| 2. Fuel-filler lid and opener Removal / Installation page S- 31 | 7. Seat belt Removal / Installation page S-103 Inspection page S-105 |
| 3. Dashboard and console Removal / Installation page S- 84 | 8. Seat Removal / Installation page S-106 Disassembly / Assembly page S-109 |
| 4. Trim Removal / Installation page S- 91 | |
| 5. Floor covering Removal / Installation page S- 99 | |

HOOD

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Windshield washer pipe
2. Hood insulator
3. Parting seal weatherstrip
4. Surround seal weatherstrip
5. Hood

Adjustment page S-6

6. Hood hinge
7. Hood lock
8. Hood release cable

Adjustment page S-6

N·m {kgf·m, ft·lbf}



Adjustment

Hood


1. Verify that the hood can be closed easily and that there is no looseness.

Clearance ①: 4.0 ± 1.0 mm { 0.16 ± 0.04 in}

2. If not as specified, loosen the hood-to-hinge mounting bolts and reposition the hood.

Tightening torque:

$19\text{--}25$ N·m { $1.9\text{--}2.6$ kgf·m, $14\text{--}18$ ft·lbf}



Hood lock

1. Adjust the hood lock after the hood has been aligned.
2. Loosen the hood lock mounting bolts and nut and align the lock with the striker on the hood.

Tightening torque

Bolts:

$7.9\text{--}10.7$ N·m { $80\text{--}110$ kgf·cm, $70\text{--}95.4$ in·lbf}

Nut:

$7.9\text{--}10.7$ N·m { $80\text{--}110$ kgf·cm, $70\text{--}95.4$ in·lbf}


FRONT DOOR

PREPARATION


| | |
|-----------------|---|
| TORX tool (T40) | For installation / removal of door lock striker |
|-----------------|---|

TORX TOOL (T40)

1. ILLUSTRATION



2. USAGE



TORX SCREW

DOOR LOCK STRIKER

TORX TOOL (T40)


6.6 mm

S

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the door trim and door screen.
(Refer to page S-10 or S-12.)
3. Install in the reverse order of removal.



1. Harness connector

2. Checker pin

3. Front door


Adjustment page S-9

4. Door hinge

5. Checker

6. Door lock striker

Adjustment page S-9

**Adjustment****Front door**

1. Verify that the front door can be closed easily and that there is no looseness or excessive clearance.


Clearance

- ①: 4.0 ± 1.0 mm { 0.16 ± 0.04 in}
- ②: $4.0^{+1.0}_{-0.5}$ mm { $0.16^{+0.04}_{-0.02}$ in}
- ③: 4.0 ± 1.0 mm { 0.16 ± 0.04 in}

2. If not as specified, loosen the door-hinge-to-body mounting bolts and reposition the front door.

Tightening torque:

22—30 N·m {2.2—3.1 kgf·m, 16—22 ft·lbf}

**Door lock striker**

1. Verify that the door can be closed easily and that there is no looseness.
2. If not correct, loosen the striker mounting screws and move the striker horizontally or vertically.

Tightening torque:

18—26 N·m {1.8—2.7 kgf·m, 14—19 ft·lbf}

FRONT WINDOW REGULATOR, GLASS AND GUIDE

COMPONENTS


Removal / Installation

1. Raise the rear of the front door glass about 80 mm {3.2 in} from the fully lowered position.
2. Disconnect the negative battery cable.


Note

- Remove the door screen carefully so that it may be reused.


3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal, referring to **Installation note**.



- | | |
|--|----------------------------|
| 1. Recess cover | 5. Bracket |
| 2. Regulator handle | 6. Sealing pad |
| Removal note page S-11 | 7. Door screen |
| Installation note page S-11 | 8. Front door glass |
| 3. Inner handle | 9. Manual window regulator |
| 4. Front door trim | 10. Power window regulator |
| Removal / Installation page S-91 | 11. Glass run channel |

**Removal note**
Regulator handle

Remove the regulator handle clip by using a rag as shown.

**Installation note**
Regulator handle

1. Raise the door glass fully.
2. Install the clip in the handle and push the regulator handle into position as shown.


Removal / Installation

1. Raise the rear of the front door glass about 100 mm {3.9 in} from the fully lowered position.
2. Disconnect the negative battery cable.

Note

- Remove the door screen carefully so that it may be reused.
- Mark around the upper glass stopper mounting bolts with paint before removing them.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Recess cover
2. Inner handle cover
3. Door trim
4. Bracket
5. Sealing pad


6. Door screen
7. Upper glass stopper
8. Door glass
9. Power window regulator
10. Glass guide

Removal / Installation page S-93

Adjustment page S-13

**Adjustment
Door glass (MX-6)**

Adjust the door glass on the MX-6 as follows.




Inward/outward adjustment of door glass

Note

- The door glass moves outward about **1.5 mm {0.06 in}** with one clockwise turn of the adjusting bolt.
1. Loosen the front and rear bracket installation nuts.
 2. Move the adjusting bolts inward or outward by using a screwdriver until the upper and side edges of the door glass are in the correct positions.
 3. Tighten the installation nuts while holding the adjusting bolt with a screwdriver.


Tightening torque: 5.9—8.8 N·m {60—90 kgf·cm, 53—78 in·lbf}



Vertical adjustment of door glass



1. Loosen the upper glass stopper installation bolts.
2. Lower the door glass slightly.
3. Move the upper glass stoppers up or down so that the upper edge of the door glass is in the correct position.
4. Tighten the installation bolts.

Tightening torque: 6.9—11.7 N·m {70—120 kgf·cm, 61—104 in·lbf}




After completion of adjustment


1. Verify the following with the weatherstrip and drip molding removed:
 - (1) The door glass is in the correct position when fully closed.
 - (2) When the door glass is raised, the lower glass stoppers contact the upper glass stoppers at the same time.
2. Verify the following with the weatherstrip installed:
 - (1) The weatherstrip mounting is correct.
 - (2) The door glass raises and lowers smoothly with the door closed.




SECTION (A)




SECTION (B)



SECTION (C)



SECTION (D)




SECTION (E)

mm {in}

FRONT DOOR GLASS
Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Front bracket
 2. Rear bracket

3. Lower glass stopper

FRONT DOOR LOCK AND OPENER

COMPONENTS


Removal / Installation

1. Raise the front door glass fully.
2. Disconnect the negative battery cable.

Note


- Remove the door screen carefully so that it may reused.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



- | | |
|--|---------------------------|
| 1. Recess cover | 6. Door screen |
| 2. Inner handle | 7. Front door lock |
| 3. Front door trim | 8. Outer handle |
| Removal / Installation page S-91 | 9. Lock cylinder retainer |
| 4. Bracket | 10. Lock cylinder |
| 5. Sealing pad | |

MX-6




- | | |
|--|---------------------------|
| 1. Recess cover | 6. Door screen |
| 2. Inner handle cover | 7. Door lock |
| 3. Door trim | 8. Outer handle |
| Removal / Installation page S-93 | 9. Lock cylinder retainer |
| 4. Inner handle | 10. Lock cylinder |
| 5. Sealing pad | |

REAR DOOR

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the door trim and door screen. (Refer to page S-22 or S-24.)
3. Install in the reverse order of removal.



1. Harness connector
2. Checker pin
3. Door hinge
4. Rear door

5. Checker
 6. Door lock striker
- Adjustment page S-21

Adjustment page S-21



Adjustment

Rear door

1. Verify that the rear door can be closed easily and that there is no looseness or excessive clearance.


Clearance ①: $4.0^{+1.0}_{-0.5}$ mm { $0.16^{+0.04}_{-0.02}$ in}

②: 4.0 ± 1.0 mm { 0.16 ± 0.04 in}

2. If not as specified, loosen the door-hinge-to-body mounting bolts and reposition the door.

Tightening torque:

$22\text{--}30$ N·m { $2.2\text{--}3.1$ kgf·m, $16\text{--}22$ ft·lbf}



Door lock striker

1. Verify that the door can be closed easily and that there is no looseness.
2. If necessary, loosen the striker mounting screws and move the striker horizontally or vertically.

Tightening torque:

$18\text{--}26$ N·m { $1.8\text{--}2.7$ kgf·m, $14\text{--}19$ ft·lbf}

REAR WINDOW REGULATOR, GLASS AND GUIDE

COMPONENTS


Removal / Installation

1. Raise the front of the rear door glass about 50 mm {2.0 in} from the fully lowered position.
2. Disconnect the negative battery cable.


Note

- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal, referring to **Installation note**.




- | | |
|--|-----------------------------|
| 1. Regulator handle Removal note page S-23 Installation note page S-23 | 6. Bracket |
| 2. Inner handle | 7. Sealing pad |
| 3. Rear door trim Removal / Installation page S-91 | 8. Door screen |
| 4. Inner garnish | 9. Rear door glass |
| 5. Outer garnish | 10. Manual window regulator |
| | 11. Power window regulator |
| | 12. Glass run channel |
| | 13. Glass guide |



Removal note
Regulator handle

Remove the regulator handle clip by using a rag as shown.



Installation note
Regulator handle

1. Raise the door glass fully.
2. Install the clip in the handle and push the regulator handle into position as shown.

REAR DOOR LOCK AND OPENER

COMPONENTS


Removal / Installation

1. Raise the rear door glass fully.
2. Disconnect the negative battery cable.

Note

- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Inner handle
2. Rear door trim
3. Sealing pad

4. Door screen
5. Rear door lock
6. Outer handle

Removal / Installation page S-91



WINDOW FRAME WEATHERSTRIP

COMPONENTS


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.

MX-6



A-PILLAR, ROOF



B-PILLAR


1. Window frame weatherstrip

TRUNK LID

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the trunk lid trim. (Refer to page S-91.)
3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal.



1. Harness
2. Trunk lid
Adjustment page S-28

3. Balance spring
Removal note page S-28
Adjustment page S-28
4. Trunk lid hinge


MX-6



N-m {kgf-m, ft-lbf}

1. Trunk lid
Adjustment page S-28

2. Stay damper
3. Trunk lid hinge



Removal note
Balance spring

Warning

- Removing the balance spring without securing the trunk lid can be dangerous. The trunk lid may fall and injure you. Open the trunk lid fully and secure it before removing the balance spring.

1. Lift the balance spring by using a screwdriver which has been wrapped in tape.
2. Remove the balance spring.

Adjustment

Trunk lid




1. Verify that the trunk lid can be closed easily and that there is no looseness or excessive clearance.

Clearance ①: 4.0 ± 0.8 mm {0.16 ± 0.03 in}

2. If not as specified, loosen the trunk-lid-to-hinge mounting nuts and reposition the trunk lid.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



Balance spring

Slide the balance spring to the desired position by using a screwdriver which has been wrapped in tape.

| Tension | Set position | | |
|----------|--------------|---|---|
| | Hook bracket | a | b |
| Standard | Left side | | ○ |
| | Right side | ○ | |
| Increase | Left side | | ○ |
| | Right side | | ○ |
| Decrease | Left side | ○ | |
| | Right side | ○ | |


○: Position

TRUNK LID LOCK AND OPENER

COMPONENTS

Removal / Installation


1. Remove the trunk lid trim. (Refer to page S-91.)
2. Disconnect the negative battery cable.
3. Remove in the order shown in the figure. To remove the trunk lid striker, remove the trunk end trim. (Refer to page S-91.)
4. Install in the reverse order of removal.




Without keyless entry system

1. Trunk lid lock
2. Inboard combination light
3. Rear finisher
Removal / Installation page S-41
4. Lock cylinder
5. Trunk lid striker
Adjustment page S-30
6. Trunk lid opener cover

7. Front scuff plate
Removal / Installation page S-91
 8. Trunk lid opener lever
 9. Trunk lid opener cable
- With keyless entry system**
1. Trunk lid lock
 2. Trunk lid striker
Adjustment page S-30
 3. Trunk lid actuator



- 1. Trunk lid lock
 - 2. Lock cylinder retainer
 - 3. Lock cylinder
 - 4. Trunk end trim
 - 5. Trunk lid striker
 - 6. Trunk lid opener cover
 - 7. Scuff plate
 - 8. Trunk lid opener lever
 - 9. Trunk lid opener cable
- Removal / Installation page S-93
- Adjustment below



Adjustment

Trunk lid striker

Loosen the trunk lid striker mounting bolts and align the striker with the lock assembly.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

FUEL-FILLER LID AND OPENER

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure. To remove the fuel-filler lid opener, remove the trunk side trim. (Refer to page S-91 or S-93.)
2. Install in the reverse order of removal.



1. Fuel-filler lid
2. Lift spring
3. Fuel-filler lid opener
4. Opener cover


5. Front scuff plate
Removal / Installation page S-91
6. Opener lever
7. Opener cable

FRONT BUMPER

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove the radiator grille. (Refer to page S-40.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Headlight
2. Front flap
3. Mud guard

4. Front bumper
Disassembly / Assembly page S-34

MX-6




- 1. Mud guard
- 2. Front combination light
- 3. Headlight

- 4. Front bumper
- Disassembly / Assembly page S-35

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.


626



N-m {kgf-cm, in-lbf}

- | | |
|-------------------------------|------------------------|
| 1. Front bumper reinforcement | 5. Front side bracket |
| 2. Set plate | 6. Side marker |
| 3. Junction plate | 7. Front air dam |
| 4. Front bumper retainer | 8. Front bumper fascia |

MX-6



- 1. Fog light
- 2. Set plate
- 3. Bracket
- 4. Stay


- 5. Front bumper reinforcement
- 6. Front bumper retainer
- 7. Front bumper fascia

REAR BUMPER

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the rear bumper, remove the trunk end trim and trunk side trim. (Refer to page S-91 or S-93.)
3. Install in the reverse order of removal.



1. Rear combination light

2. Rear bumper
Disassembly / Assembly page S-38

MX-6




- 1. Rear combination light
- 2. License plate light

- 3. Rear bumper
Disassembly / Assembly page S-39

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.


626



1. Set plate
2. Rear bumper reinforcement
3. Energy-absorbing foam

4. Rear bumper retainer
5. Rear side marker
6. Rear bumper fascia

MX-6




- 1. Rear bumper reinforcement
- 2. Energy-absorbing foam
- 3. Rear bumper retainer

- 4. Rear side marker
- 5. Rear bumper fascia

RADIATOR GRILLE**COMPONENTS****Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Radiator grille

2. Hood molding

REAR FINISHER**COMPONENTS****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

626




1. Inboard combination light

2. Rear finisher

REAR SPOILER**COMPONENTS****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



MX-6



1. Rear spoiler

MOLDING


PREPARATION SST

| | | | | | |
|-------------------------------------|---|---|------------------------------------|--|------------------------------|
| 49 0305 870A Tool set, window |  | For installation of windshield molding | 49 G050 1A0 Remover, sealant |  | For removal of sealant |
|-------------------------------------|---|---|------------------------------------|--|------------------------------|


COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal note**.
2. Install in the reverse order of removal, referring to **Installation note**.



| | |
|--|--|
| 1. Windshield molding Removal note page S-45 Installation note page S-48 | 7. Lower molding No.2 (626) Removal note page S-46 Installation note page S-51 |
| 2. Front beltline molding Removal note page S-45 | 8. Lower molding No.3 (626) Removal note page S-46 Installation note page S-51 |
| 3. Rear beltline molding (626) Removal note page S-45 | 9. Lower molding No.4 (626) Removal note page S-47 |
| 4. Front sash molding (626) Removal note page S-46 Installation note page S-51 | 10. Roof molding Removal note page S-47 Installation Note page S-51 |
| 5. Rear sash molding (626) Removal note page S-46 Installation note page S-51 | 11. Drip molding (MX-6) Removal note page S-47 |
| 6. Lower molding No.1 (626) Removal note page S-46 | 12. Rear window molding Removal note page S-48 Installation note page S-50 |




**Removal note
Windshield molding**

1. Remove the cowl grille. (Refer to page S-52.)
2. Pull the molding from one end to separate it. Do not reuse the windshield molding.



Front and rear beltline moldings

1. Open the door glass fully.
2. Remove the outside mirror (Front beltline molding). (Refer to pages S-53, 54.)
3. Remove the beltline molding mounting screw (626) or fastener (MX-6).
4. Pull the beltline molding upward to disengage the clips from the body.




Front and rear sash moldings

1. Peel the top of the sash molding forward to disengage it from the sash.
2. Remove the sash molding from the door garnish.




Lower molding No.1

Pull the lower molding No.1 forward to disengage the clips from the body.




Lower molding No.2

Pull the lower molding No.2 downward to disengage the clips from the body.




Lower molding No.3

Pull the lower molding No.3 downward to disengage the clips from the body.

**Lower molding No.4**


1. Remove the lower molding mounting fastener.
2. Pull the lower molding forward to disengage the pin from the body.

**Roof molding**

Pull the rear edge of the roof molding upward to disengage the molding clips from the body clips.




Drip molding (MX-6)

1. Remove the window frame weatherstrip. (Refer to page S-25.)
2. Remove the molding mounting rivet, fastener, and screw.
3. Remove the drip molding from the quarter window molding.



Rear window molding


1. Remove the molding mounting screws from the lower section.
2. Remove the molding mounting clips by using a molding remover and remove the side and upper sections of the molding.




Installation note
Windshield molding

1. Apply protective tape along the edge of the body to protect it from damage.
2. Cut the sealant by using a razor knife as shown.


3. Cut the sealant near the body by using the SST as shown.




4. Cut the sealant under the glass by using the **SST** as shown.




5. Cut the sealant near the glass by using the **SST** as shown.
 6. Remove as much sealant as possible from between the body and the glass.
 7. Carefully clean around the edge of the glass and the adhesion surface on the body.




8. If the protector is damaged, replace it with a new one.




9. Apply primer onto the bonding area of the glass, body, and new windshield molding by using a brush. Use only glass primer on the glass and body primer on the body and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.



10. Apply a **3 mm {0.12 in}** bead of repair sealant between the glass and the body.



11. Reshape the repair sealant as shown if necessary.




12. Install the molding before the sealant has hardened.

- ① Align the marks on the molding with the roof inner line.
- ② Push on the upper portion of the molding.
- ③ Push on the corner portion of the molding.
- ④ Push on the side portion of the molding, starting from the bottom and then toward the top.

Hardening time of repair sealant


| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

13. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation procedure with a new windshield molding.



Rear window molding

1. If one of the protectors is damaged, replace it with a new one.





2. Install the molding.


- ① Align the mark on the right molding with the roof outer line.
- ② Push on the upper and side portions of the right molding.
- ③ Insert the left molding into the joint.
- ④ Align the upper portion of the left molding with the body and push on the upper and side portions of the molding.
- ⑤ Fasten the lower portion with the screws, working from outside to inside.

Front and rear sash moldings

1. If the sash molding is being reused,
 - a) Clean and degrease the bonding area of the sash corner and sash molding.
 - b) Apply primer by using a brush to the bonding area of the sash molding and allow it to dry for approximately **30 minutes**.
 - c) Attach double-sided adhesive tape to the sash molding.
2. Insert one end of the sash molding into the door garnish.
3. Remove the wax paper from the double-sided adhesive tape and fit the sash molding onto the door sash.
4. Press the adhesive tape firmly to fix the sash molding.

**Lower moldings No.2 and No.3**

Apply plain or soapy water to the lower molding installation part of the door. Then fit the lower molding onto the door.

**Roof molding**


1. If the clips are damaged, replace them.
2. Install the molding.
 - ① Align the rear end of the molding with the body.
 - ② Press the molding down firmly.

COWL GRILLE

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Windshield wiper arm and blade
Adjustment page S-58


2. Cowl cap
3. Cowl grille

OUTSIDE MIRROR

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable if a power outside mirror is installed.
2. Remove in the order shown in the figure. To remove the power outside mirror and rear window defroster switches, remove the switch panel. (Refer to page S-84 or S-86.)
3. Install in the reverse order of removal.




- | | |
|---|--|
| 1. Inner garnish | 4. Door screen |
| 2. Remote control mirror Replacement of mirror glass ... page S-55 | 5. Power outside mirror Replacement of mirror glass ... page S-55 |
| 3. Front door trim Removal / Installation page S-91 | 6. Power outside mirror switch |
| | 7. Rear window defroster switch |

MX-6




- 1. Inner garnish
- 2. Power outside mirror
Replacement of mirror glass ... page S-55
- 3. Inner handle cover

- 4. Door trim
Removal / Installation page S-93
- 5. Power outside mirror switch
- 6. Rear window defroster switch




**Replacement of Mirror Glass
(Except heated outside mirror)**


1. Warm the frame and the mirror glass by using a hot-air blower.



2. Insert a scraper between the mirror glass and the frame, and pry the glass loose.
3. Remove the remaining adhesive.




4. Warm the adhesive surface of the frame and the mirror by using a hot-air blower.



5. Install the glass in the mirror frame and gently press on the glass to secure it.

REARVIEW MIRROR**COMPONENTS****Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Rearview mirror

WINDSHIELD WIPER AND WASHER


COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation note**.




- | | |
|--|-----------------------------|
| 1. Windshield wiper arm cover | 5. Windshield wiper link |
| 2. Windshield wiper arm and blade | 6. Windshield washer tank |
| Installation note page S-58 | 7. Windshield washer motor |
| Adjustment page S-58 | 8. Windshield washer pipe |
| 3. Cowl grille | 9. Windshield washer nozzle |
| 4. Windshield wiper motor | Adjustment page S-58 |
| Assembly / Disassembly page S-59 | |



Installation note

Windshield wiper arm and blade

Clean the windshield wiper arm connector shafts with a wire brush before installing the windshield wiper arms.




Adjustment

Windshield wiper arm and blade

1. Operate the wipers once to set them in the park position.
2. Set the height of the windshield wiper arms as shown.

Tightening torque:

16—19 N·m {1.6—2.0 kgf·m, 12—14 ft·lbf}



Adjustment


Windshield washer nozzle

Insert a needle or similar object into the nozzle hole and move the nozzle to adjust the spray direction.

626

mm {in}

| Clearance | |
|--------------|--------------|
| ① 350 {13.8} | ⑤ 350 {13.8} |
| ② 100 { 3.9} | ⑥ 300 {11.8} |
| ③ 100 { 3.9} | ⑦ 400 {15.7} |
| ④ 400 {15.7} | ⑧ 200 { 7.9} |



MX-6


mm {in}

| Clearance | |
|--------------|--------------|
| ① 350 {13.8} | ⑤ 350 {13.8} |
| ② 100 { 3.9} | ⑥ 300 {11.8} |
| ③ 150 { 5.9} | ⑦ 400 {15.7} |
| ④ 400 {15.7} | ⑧ 200 { 7.9} |

WINDSHIELD WIPER MOTOR

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Screw
2. Brush plate holder

3. Motor gear assembly

WINDSHIELD

PREPARATION


SST

| | | |
|------------------|--|-------------------------------------|
| 49 0305 870A | | For removal / installation of glass |
| Tool set, window | | |

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.



- 1. Overhead console
Removal / Installation .. pages S-100, 101
- 2. Sunvisor and adaptor
- 3. A-pillar trim
Removal / Installation .. pages S- 91, 93
- 4. Rearview mirror
Removal / Installation .. page S- 56
- 5. Windshield molding
Removal / Installation .. page S- 44
- 6. Wiper arm and blade
Adjustment page S- 58


- 7. Cowl grille
Removal / Installation page S-52
- 8. Windshield
Removal note page S-61
Installation note page S-61
- 9. Dam
- 10. Spacer
- 11. Protector



Removal note Windshield


If the glass will not be reused

1. Use a tool like that shown in the figure and insert the blade into the sealant.
2. Pull through the sealant around the edge of the glass.
3. If the protector is damaged, remove it.
4. Remove the glass.




If the glass will be reused


1. Apply protective tape along the front edge of the headliner to protect it from damage.



2. Apply protective tape along the edge of the body to protect it from damage.
3. Make a hole through the sealant from the inside of the vehicle by using an awl.
4. Pass piano wire through the hole.




5. Wind each end of the wire around a bar.
6. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking. Make sure the wire does not rub on the body or the dashboard.
7. Remove the glass.




Installation note Windshield


1. Cut away the old sealant by using a razor knife so that **1 to 2 mm {0.04 to 0.08 in}** of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then apply new sealant to create a **2 mm {0.08 in}** layer.
2. Carefully clean an area **50 mm {2.0 in}** wide around the circumference of the glass and clean the bonding area on the body.




3. Mark the outer edge of the glass with a marking pen to ensure proper reinstallation.




4. Securely bond a new dam along the top and sides **8 mm {0.31 in}** from the edge of the glass as shown. Allow it to dry completely.




5. Align the spacers with the markers and bond the spacers to the glass as shown.




6. Apply primer to the bonding area of the glass, new windshield molding, and body by using a brush. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately **30 minutes**.




7. Install the spacers onto the body as shown. If a spacer is damaged, replace it.
8. Set the glass onto the body and adjust the clearance between the top of the glass and the body to **8 mm {0.31 in}** by moving the spacers up or down.
9. Remove the glass from the body.




10. After the primer has dried, apply an **11 mm {0.43 in}** high bead of repair sealant around the entire circumference of the glass as shown. Keep the bead of sealant smooth and even, reshaping it with a spatula where necessary. If the windshield is being reused, apply new repair sealant over the original.




11. If the protector was removed, securely bond a new protector onto the body as shown. Allow it to dry completely.



12. Align the glass marks with the notches in the spacers and install the glass onto the body.
13. Press firmly on the glass to compress the sealant. Verify that the clearance between the top and sides of the glass and the body is **8 mm {0.31 in}**.



14. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Reshape the repair sealant on the upper and side areas as shown, if necessary.



15. Install the windshield molding before the sealant has hardened.
- (1) Align the marks on the molding with the roof inner line.
 - (2) Install the upper part of the molding.
 - (3) Install the corner part of the molding.
 - (4) Install the side parts of the molding, starting from the bottom and then toward the top.

16. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

17. Check for water leaks. If a leak is found, wipe the water off well and reinstall the windshield.

REAR WINDOW GLASS


PREPARATION
SST

| | | |
|------------------|--|-------------------------------------|
| 49 0305 870A | | For removal / installation of glass |
| Tool set, window | | |

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.




- | | |
|--|---|
| 1. C-pillar trim Removal / Installation page S-91 | 4. Rear window glass Removal note page S-67 Installation note page S-68 |
| 2. Rear package trim Removal / Installation page S-91 | 5. Dam |
| 3. Rear window molding Removal / Installation page S-44 | 6. Spacer 7. Protector |

MX-6



- 1. Rear window molding
Removal / Installation page S-44
- 2. Rear window glass
Removal note page S-67
Installation note page S-68


- 3. Dam
- 4. Spacer
- 5. Protector



Removal note
Rear window glass


If the glass will not be reused

1. Use a tool like that shown in the figure and insert the blade into the sealant.
2. Pull through the sealant around the edge of the glass.
3. If a protector is damaged, remove it.
4. Remove the glass.




If the glass will be reused






1. Apply protective tape along the rear edge of the headliner to protect it from damage.



2. Apply protective tape along the edge of the body to protect it from damage.
3. Make a hole through the sealant from the inside of the vehicle by using an awl.
4. Pass piano wire through the hole.








5. Wind each end of the wire around a bar.
6. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking. Make sure the wire does not rub on the body.
7. Remove the glass.



Installation note Rear window glass

1. Cut away the old sealant by using a razor knife so that **1 to 2 mm {0.04 to 0.08 in}** of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2 mm {0.08 in}** layer.
2. Carefully clean an area **50 mm {2.0 in}** wide around the circumference of the glass and clean the bonding area on the body.
3. Mark the outer edge of the glass with a marking pen to ensure proper reinstallation.
4. Securely bond a new dam along the circumference of the glass **8 mm {0.31 in}** from the edge. Allow it to dry completely.
5. Apply primer to the bonding area of the glass and body by using a brush. Use only glass primer on the glass and body primer on the body. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately **30 minutes**.
6. Install the spacers onto the body.



7. If the protectors are removed, securely bond new protectors onto the body as shown. Allow them to dry completely.

8. Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V notch from which the sealant can flow. Once the primer is dry, apply repair sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant 11 mm {0.43 in} high. Keep the bead of sealant smooth and even, reshaping it with a spatula where necessary.

9. Align the glass marks with the V notches in the spacers and install the glass to the body.

10. Press firmly on the glass to compress the sealant.

11. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

12. Check for water leaks. If a leak is found, wipe the water off well and add sealant where needed.


13. Install the rear window molding.

- ① Align the mark on the right molding with the roof outer line.
- ② Push on the upper and side portions of the right molding.
- ③ Insert the left molding into the joint molding.
- ④ Align the upper portion of the left molding with the body and push on the upper and side portions of the molding.
- ⑤ Fasten the lower portion with screws, working from outside to inside.

QUARTER WINDOW GLASS

PREPARATION


SST

| | | |
|------------------|---|-------------------------------------|
| 49 0305 870A |  | For removal / installation of glass |
| Tool set, window | | |

COMPONENTS





Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.



1. C-pillar trim
Removal / Installation page S-93

2. Quarter window glass
Removal note page S-71
Installation note page S-72







Removal note
Quarter window glass

1. Apply protective tape along the edge of the body to protect it from damage.
2. Cut the quarter window molding as shown by using a razor knife.
3. Using an awl, make a hole through the sealant from the inside of the vehicle.
4. Pass piano wire through the hole.
5. Wind each end of the wire around a bar.
6. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking. Make sure the wire does not rub on the body.
7. Remove the glass.

Note

- The quarter window glass has locating clips as shown. If it is difficult to cut the sealant with the piano wire, cut it by using a razor knife.



Installation note Quarter window glass

1. Cut away the old sealant by using a razor knife so that **1 to 2 mm {0.04 to 0.08 in}** of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it **30 minutes** to dry. Then put on new sealant to create a **2 mm {0.08 in}** layer.
2. Carefully clean an area **50 mm {2.0 in}** wide around the circumference of the glass and clean the bonding area on the body.
3. Apply primer to the bonding area of the glass and body by using a brush. Use only glass primer on the glass and body primer on the body. Keep the area free of dirt and grease. Do not touch the surface. Allow it to dry for approximately **30 minutes**.
4. Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Once the primer is dry, apply repair sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant **11 mm {0.43 in}** high. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.
5. Align the glass via the stud pins and install it onto the body.
6. Press firmly on the glass to compress the sealant.
7. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

8. Check for water leaks. If a leak is found, wipe the water off well and remove the quarter window glass. Install a new quarter window glass.

INNER SLIDING SUNROOF


PREPARATION

| | |
|-----------------|---|
| TORX tool (T25) | For installation / removal of glass panel |
|-----------------|---|


COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal note**. Disconnect the negative battery cable before removing the headliner.
2. Install in the reverse order of removal, referring to **Installation note**.




- | | |
|---|---|
| 1. Deflector Removal note below | 11. Sunshade Removal note page S-75 |
| 2. Glass panel Removal note below Adjustment page S- 77 | 12. Sunroof motor Installation note page S-76 Inspection page S-77 |
| 3. Headliner Removal note page S-102 | 13. Guide rail cover |
| 4. Sunroof relay | 14. Front guide Removal note page S-75 Installation note page S-75 |
| 5. Motor bracket | 15. Rear guide Removal note page S-75 Installation note page S-75 |
| 6. Drain hose | 16. Position plate Removal note page S-75 Installation note page S-75 |
| 7. Frame | |
| 8. Set bracket | |
| 9. Relay bracket | |
| 10. Drip rail Removal note page S- 75 | |



Removal note


Deflector

1. Operate the switch to fully open the panel.
2. Remove the link from the link connector by using a screwdriver.
3. Remove the mounting screws and remove the deflector from the frame.




Glass panel

1. Firmly push the sunshade to slide it to the rear.
2. Remove the link cover.




3. Tilt the glass panel up by using the tilt switch.
4. Remove the panel mounting screws by using a TORX tool (T25) and remove the glass panel from the position plate.




Drip rail

1. Remove the drip rail mounting screws.
2. Pull the drip rail to remove it from the position plate.




Sunshade

Free the guides from the frame groove by using a screwdriver, and remove the sunshade.




Front and rear guides, position plate

1. Remove the motor bracket mounting bolts and remove the bracket from the frame.
2. Remove the motor mounting screws and remove the motor from the frame.
3. Remove the guide rail cover from the rear end of the frame.








4. Push the front of the retaining hook to disengage it from the frame. Pull the position plate to remove the front guide, rear guide, and position plate from the guide rail.



Installation note

Front and rear guides, position plate



1. Grease the contact surfaces of the cable and rear guide position plate.
2. Insert the rear guide cable into the channel of the guide rail.



3. Insert the front guide, rear guide, and position plate into the guide rail.
4. Tilt the position plate upward. Verify that the spring hooks onto the retaining hook when the position plate is inserted into the guide rail.
5. Push the rear guide forward until the retaining hook engages with the notch of the guide rail.

Sunroof motor

1. Install the motor to the frame. Close the panel by turning the mechanism with a screwdriver.
2. Install the frame to the body.
3. Remove the motor from the frame and install the harness connector to the overhead console.
4. Set the limit switches.
 - (1) Press the back of either the TILT switch or SLIDE switch and operate the motor until it stops.
 - (2) Press the front of the same switch until the motor stops.
5. Install the motor to the frame.
6. After installing the motor, use the sliding sunroof switches to verify that the panel operates normally.



Adjustment

Glass panel

Gap

1. Open the glass panel about **100 mm {3.9 in}** from the fully closed position.
2. Pull up on the weatherstrip surrounding the section which is to be measured.
3. Fully close the glass panel.
4. Remove the link cover.
5. Loosen the panel mounting screws by using a TORX tool (T25) to adjust the gap vertically, horizontally, inward, or outward.

Clearance

mm {in}

| | Glass panel | |
|---|--|--|
| | Straight | Corner |
| ① | 6.92 ± 0.22 {0.272 ± 0.09} | 6.92 ± 0.25 {0.272 ± 0.1} |
| ② | 0 ^{+0.5} _{-1.5} {0 ^{+0.02} _{-0.06} } | 0 ^{+0.5} _{-1.5} {0 ^{+0.02} _{-0.06} } |

6. Tighten the panel mounting screws.
7. Open the glass panel and install the weatherstrip.

Tightening torque:

2.5—3.5 N·m {25—36 kgf·cm, 22—31 in·lbf}

Inspection

Sunroof motor

1. Measure the operation time of the slide panel from fully opened to fully closed and vice versa.

Specified time: 4—7 sec.


2. If not as specified, replace the sunroof motor.

OUTER SLIDING SUNROOF

COMPONENTS


Removal / Installation

1. Open the slide panel 100 mm {3.9 in} from the fully closed position.
2. Disconnect the negative battery cable.
3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal, referring to **Installation note**.



- | | |
|-------------------|------------------|
| 1. Sunroof trim | |
| Removal note | page S- 79 |
| Installation note | page S- 81 |
| 2. Slide panel | |
| Removal note | page S- 79 |
| Adjustment | page S- 83 |
| 3. Sunroof shim | |
| 4. Headliner | |
| Removal note | page S-102 |


- | | |
|------------------------|-----------------|
| 5. Sunroof motor | |
| Removal note | page S-79 |
| Installation note | page S-80 |
| 6. Drain hose | |
| Installation note | page S-81 |
| 7. Sunroof drive unit | |
| Removal note | page S-79 |
| Installation note | page S-79 |
| Disassembly / Assembly | page S-82 |



Removal note


Sunroof trim

1. Tilt up the slide panel.
2. Remove the fasteners on the front side of the sunroof trim.
3. Pull down the trim and remove it from the sunroof panel.
4. Pull out the sunroof trim from between the slide panel and the roof.




Slide panel

1. Fully close the slide panel by using an allen wrench.
2. Remove the slide panel mounting nuts.
3. Push up the slide panel from inside and remove it from the lower panel.




Sunroof motor

1. Tilt up the lower panel **80 mm {3.1 in}** from the fully closed position by using an allen wrench.
2. Remove the screws and remove the sliding sunroof motor from the sunroof frame.
3. Disconnect the motor harness connector.



Sunroof drive unit


1. Remove bolts C.
2. Loosen nuts B.
3. Loosen height adjusting nuts A and remove the sunroof drive unit from the body.




Installation note

Sunroof drive unit

1. Set the sunroof drive unit into the roof panel and align the locator pins.




- Loosely install the sunroof drive unit to the roof panel by using the height adjusting nuts.



- Loosen the set bracket attaching nuts. Position the set bracket so that it touches the roof panel fixing bracket. Tighten the bolts, and then tighten the nuts.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}



- Affix the rear of the sunroof frame to the roof panel.

Tightening torque:

7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}




- Install the slide panel to the lower panel.

Tightening torque:


7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf}

- If the height difference between the slide panel and the roof panel is greater than **2 mm {0.08 in}**, loosen the slide panel attaching nuts and insert shims between the panels.



Sunroof motor

- Move the lower panel fully forward by hand.
- Turn the limit switch off by using an allen wrench.
- Turn the limit switch on by using an allen wrench.
- Set gear B inside the guide plate.
- Install the motor to the sunroof frame with screws.
- Connect the motor harness connector.



Drain hose

Note


- Apply soapy water to the drain hoses and insert them fully into the sunroof frame.

(front)

Insert one end of the hose into the sunroof frame, affix the hose along the A-pillar, and insert the other end into the cowl side panel.


(rear)

Insert one end of the hose into the sunroof frame, affix the hose along the B-pillar, and insert the other end into the rear fender panel hole via the hole in the upper part of the B-pillar.




Sunroof trim

1. Tilt up the slide panel. Insert the sunroof trim between the slide panel and the roof panel from the rear of the vehicle.
2. Match the sunroof trim guide pin with the notch in the slide panel trim bracket to locate the trim.
3. Install the sunroof trim fasteners to the slide panel.






SUNROOF DRIVE UNIT
Disassembly / Assembly

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|----------------------------|-------------------|
| 1. Sunroof motor | 6. Position plate |
| Inspection page S-83 | 7. Guide assembly |
| 2. Sunroof relay | 8. Wind deflector |
| 3. Closing guide plate | 9. Guide rail |
| 4. Closing assembly | 10. Sunroof frame |
| 5. Drive unit | |



Adjustment
Slide panel
Height

1. Remove the headliner. (Refer to page S-101.)
2. Loosen the set bracket mounting nuts.
3. Turn the height adjusting nuts to adjust the sunroof frame height.

Clearance (1): 0 ± 0.05 mm { 0 ± 0.002 in }

4. After adjustment, securely install the sunroof to the roof panel.

Gap

1. Loosen the slide panel mounting nuts and move the panel to adjust the clearance between the slide panel and roof panel.

Clearance (2): 7.05 ± 0.35 mm { 0.28 ± 0.014 in }

2. If the above adjustment is not enough, loosen the attaching screws and bolts of the sunroof frame and set bracket and adjust again. (Refer to Installation note for the sunroof drive unit, page S-79.)

Inspection

Sunroof motor

1. Measure the operation time of the slide panel from fully open to fully closed and vice versa.

Specified time: 4—6 sec.

2. If not as specified, adjust it by increasing or decreasing the sliding sunroof driving torque.

- (1) Remove the housing cover attaching screws, E-ring, and gear. Remove the housing cover from the motor.
- (2) Unfold the locking washers.
- (3) Hold the motor shaft with an allen wrench and turn the locknut to adjust the torque.
- (4) Fold the locking washer against the locknut.

DASHBOARD AND CONSOLE

DASHBOARD AND CONSOLE


Removal / Installation

1. Disconnect the negative battery cable.

Warning


- Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read **SERVICE WARNINGS**, section T, before handling the air bag module.

2. Remove the A-pillar trim. (Refer to page S-91.)
3. Remove the front side trim. (Refer to page S-91.)
4. Remove in the order shown in the figure, referring to **Removal note**.
5. Install in the reverse order of removal.




1. Driver-side air bag module
1996 626/MX-6 Body Electrical Trouble-
shooting Manual section S
2. Steering wheel
Removal / Installation section N
3. Column cover
Removal note page S-87
4. Combination switch
5. Steering shaft
6. Side panel
Removal note page S-87
7. Hood release knob
8. Lower panel
Removal note page S-89
9. Front console
Removal note page S-89
10. Rear console
Removal note page S-89
11. Side wall
Removal note page S-88
12. Undercover
Removal note page S-88
13. Glove compartment
Removal note page S-88
14. Switch panel
Removal note page S-89
15. Passenger-side air bag module
1996 626/MX-6 Body Electrical Trouble-
shooting Manual section S
16. Meter hood
Removal note page S-90
17. Upper garnish
Removal note page S-90
18. Instrument cluster
19. Dashboard

MX-6




N·m {kgf·m, ft·lbf}

- | | |
|--|--|
| 1. Driver-side air bag module 1996 626/MX-6 Body Electrical Troubleshooting Manual, section S | 10. Rear console Removal note page S-89 |
| 2. Steering wheel Removal / Installation section N | 11. Side wall Removal note page S-88 |
| 3. Column cover Removal note below | 12. Meter hood Removal note page S-90 |
| 4. Combination switch | 13. Glove compartment Removal note page S-89 |
| 5. Side panel Removal note below | 14. Passenger-side air bag module 1996 626/MX-6 Body Electrical Troubleshooting Manual, section S |
| 6. Hood release knob | 15. Instrument cluster |
| 7. Lower panel Removal note page S-89 | 16. Upper garnish Removal note page S-90 |
| 8. Undercover Removal note page S-88 | 17. Dashboard |
| 9. Front console Removal note page S-89 | |




**Removal note
Column cover**

Remove the column cover mounting screws and bolt.




Side panel

Pull the side panel forward to disengage the clips.




Side wall

Remove the side wall mounting screws and fasteners.




Undercover

Remove the undercover mounting fasteners.




Glove compartment

Remove the glove compartment mounting screws.




Lower panel

1. Pull the lap duct from the rear of the lower panel.
2. Remove the mounting screws from the lower panel.
3. Pull the lower panel to disengage the clips.




Switch panel

1. Remove the switch panel mounting screws.
2. Pull the switch panel forward to disengage the clips.




Front console

Pull the front console forward to disengage the clips.




Rear console


Remove the rear console mounting screws.

**Meter hood (626)**


1. Remove the meter hood mounting screws.
2. Pull the meter hood forward to disengage the clips.

**Upper garnish (626)**

Pull the upper garnish upward to disengage the clips.

**Upper garnish (MX-6)**

1. Remove the upper garnish mounting screw.
2. Pull the upper garnish upward to disengage the clips.




TRIM

COMPONENTS


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal note**.
2. Install in the reverse order of removal.




- | | | | |
|--|-----------|--|-----------|
| 1. A-pillar trim Removal note | page S-94 | 8. Rear package trim Removal note | page S-95 |
| 2. Front scuff plate Removal note | page S-94 | 9. C-pillar trim Removal note | page S-96 |
| 3. Front side trim | | 10. Trunk end trim Removal note | page S-96 |
| 4. Rear scuff plate Removal note | page S-94 | 11. Trunk side trim | |
| 5. B-pillar lower trim Removal note | page S-95 | 12. Front door trim Removal note | page S-97 |
| 6. B-pillar upper trim Removal note | page S-95 | 13. Rear door trim Removal note | page S-97 |
| 7. Tire house trim Removal note | page S-95 | 14. Trunk lid trim | |

MX-6




- 1. A-pillar trim
Removal note page S-94
- 2. Scuff plate
Removal note page S-94
- 3. Front side trim
- 4. Quarter trim
Removal note page S-95
- 5. C-pillar trim
Removal note page S-96

- 6. Rear package trim
Removal note page S-95
- 7. Trunk end trim
Removal note page S-96
- 8. Trunk side trim
- 9. Door trim
Removal note page S-97




Removal note A-pillar trim

1. Pull the A-pillar trim forward to disengage the clips from the body.
2. Pull the A-pillar trim upward to disengage the hook from the body.




Front scuff plate (626)

Pull the front scuff plate upward to disengage the clips from the body.




Scuff plate (MX-6)

Pull the scuff plate upward to disengage the clips from the body.




Rear scuff plate (626)


Pull the rear scuff plate upward to disengage the clips from the body.

**B-pillar lower trim (626)**


1. Remove the front and rear scuff plates.
(Refer to page S-94.)
2. Slide the B-pillar lower trim upward, and then pull the trim forward as shown to disengage it from the body.

**B-pillar upper trim (626)**


1. Remove the front seat belt shoulder anchor.
(Refer to page S-103.)
2. Pull the B-pillar upper trim to disengage the clips from the body.

**Quarter trim (MX-6)**


1. Remove the rear seat cushion and rear seat back. (Refer to page S-108.)
2. Remove the scuff plate. (Refer to page S-94.)
3. Remove the quarter trim mounting fasteners.
4. Pull the quarter trim forward to disengage the clips from the body.

**Tire house trim (626)**

1. Remove the rear seat cushion, rear seat sides, and rear seat back. (Refer to page S-107.)
2. Remove the rear scuff plate. (Refer to page S-94.)
3. Remove the tire house trim mounting fasteners and screws.
4. Pull the tire house trim forward to disengage the clips from the body.


**Rear package trim (626)**

1. Remove the rear seat cushion, rear seat sides, and rear seat back. (Refer to page S-107.)
2. Remove the tire house trim. (Refer above.)
3. Remove the rear package trim mounting fasteners.
4. Pull the rear package trim upward to disengage clips B from the body.
5. Pull the rear package trim forward to disengage clips A from the body.



(MX-6)


1. Remove the rear seat cushion and rear seat back. (Refer to page S-108.)
2. Remove the C-pillar trim. (Refer below.)
3. Remove the rear package trim mounting screws.
4. Pull the rear package trim upward to disengage the clips from the body.



C-pillar trim


(626)

1. Remove the tire house trim. (Refer to page S-95.)
2. Remove the rear package trim. (Refer to page S-95.)
3. Pull the C-pillar trim forward to disengage the clips from the body.
4. Pull the C-pillar trim upward to disengage the hook from the body.




(MX-6)

1. Remove the quarter trim. (Refer to page S-95.)
2. Remove the C-pillar trim mounting screws.
3. Pull the C-pillar trim forward to disengage the clips from the body.




Trunk end trim


1. Remove the trunk end trim mounting fasteners.
2. Pull the trunk end trim upward to disengage the clips from the body.

**Front door trim (626)**


1. Disconnect the negative battery cable.
2. Remove the recess cover and the mounting screw.
3. Remove the inner handle mounting screw and remove the inner handle.
4. Remove the door trim mounting screws.




5. Pull the front door trim to disengage the clips from the body.
6. Lift the front door trim to remove the pins from the body.
7. Disconnect the harness connectors.

**Door trim (MX-6)**


1. Disconnect the negative battery cable.
2. Remove the recess cover and the mounting screw.
3. Remove the inner handle mounting screw and remove the inner handle.
4. Remove the door trim mounting screws and fastener.



5. Pull the door trim to disengage the clips from the body.
6. Lift the door trim to remove the pin from the body.
7. Disconnect the harness connectors.

**Rear door trim (626)**


1. Disconnect the negative battery cable.
2. Remove the inner handle mounting screw and remove the inner handle.



3. Pull the rear door trim to disengage the clips from the body.
4. Lift the rear door trim to remove the pins from the body.
5. Disconnect the harness connectors.

FLOOR COVERING**COMPONENTS****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the following:
 - a. Front seats (Refer to page S-106.)
 - b. Rear seat cushion (Refer to pages S-107, 108.)
 - c. Dashboard and console (Refer to pages S-84, 86.)
 - d. Front side trim, scuff plates, B-pillar lower trim, and tire house trim (Refer to pages S-91, 93.)
 - e. Front seat belt lower anchor (Refer to page S-103.) or slide bar (Refer to page S-104.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Cabin carpet


HEADLINER

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal.

626




1. Overhead console
2. Sunvisor and adapter
3. Assist handle
4. Interior lamp

5. Seaming welt (with sunroof)
6. Headliner

Removal note page S-102


MX-6



- 1. Sunvisor and adapter
- 2. Overhead console
- 3. Assist handle

- 4. Seaming welt (with sunroof)
- 5. Headliner


Removal note page S-102



Removal note

Headliner

1. Remove the A-pillar trim, C-pillar trim, and either the B-pillar trim (626) or the quarter trim (MX-6). (Refer to page S-91 or S-93.)
2. Remove the mounting clips.
3. Remove the sides of the headliner from the weatherstrip.
4. Slide the headliner forward to remove it.



SEAT BELT


COMPONENTS

Removal / Installation

Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the buckle or retractor assembly.


1. Remove in the order shown in the figure. To remove the front seat belt on the 626, remove the B-pillar lower trim. (Refer to page S-91.) To remove the rear seat belts, remove the C-pillar trim (Refer to page S-91 or S-93.) and the rear seat cushion. (Refer to page S-107 or S-108)
2. Install in the reverse order of removal.



1. Front seat belt
Inspection page S-105
a) Upper anchor
b) Lower anchor
2. Anchor adjuster

3. Front buckle
Inspection (driver) ... 1996 Body Electrical
Troubleshooting Manual, section C2
4. Rear seat belt
Inspection page S-105
5. Rear buckle





MX-6



N-m {kgf-m, ft-lbf}

- 1. Front seat belt
Inspection page S-105
- 2. Front buckle
Inspection (driver) ... 1996 Body Electrical
Troubleshooting
Manual, section C2

- 3. Rear seat belt
Inspection page S-105
- 4. Rear buckle



Inspection

Front and rear seat belts

Webbing and fittings

1. Inspect the webbing for scars, tears, and wear.
2. Inspect the fittings for deformation and damage.
3. If any problem is found, replace the seat belt.

Emergency locking retractor (ELR)

1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.


3. Remove the retractor.
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at approximately 30° inclination.
7. If not as specified, replace the seat belt.

SEAT

COMPONENTS

Removal / Installation


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Cover

2. Front seat
Disassembly / Assembly page S-109

REAR SEAT (626)




N-m {kgf-m, ft-lbf}

- 1. Rear seat cushion
- 2. Rear seat side
- 3. Rear seat back hinge
- 4. Rear seat back

- 5. Trunk carpet
- 6. Rear package trim
Removal / Installation page S-91
- 7. Seat back striker

REAR SEAT (MX-6)




N-m (kgf-m, ft-lbf)

- 1. Rear seat cushion
- 2. Rear seat back hinge

- 3. Rear seat back
- 4. Trunk carpet

Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.

MANUAL SEAT (DRIVER)

1. Headrest
2. Recliner lever
3. Cap
4. Side cover
5. Tilt knob
6. Seat back cover

7. Seat back
8. Pole guide
9. Seat cushion
10. Slide adjuster
11. Buckle
12. Cover


MANUAL SEAT (PASSENGER)



- 1. Headrest
- 2. Recliner lever
- 3. Cap
- 4. Side cover
- 5. Seat back cover
- 6. Seat back


- 7. Pole guide
- 8. Seat cushion
- 9. Slide adjuster
- 10. Buckle
- 11. Cover

POWER SEAT (DRIVER)




- | | |
|---------------------------|-----------------------|
| 1. Headrest | 10. Seat cushion |
| 2. Power seat switch knob | 11. Slide adjuster |
| 3. Recliner lever | 12. Buckle |
| 4. Cap | 13. Cover |
| 5. Knuckle cover | 14. Front-lift motor |
| 6. Front cover | 15. Rear-lift motor |
| 7. Seat back cover | 16. Slide motor |
| 8. Seat back | 17. Power seat switch |
| 9. Pole guide | |

REAR SEAT (626)



1. Rear seat catch knob

REAR SEAT (MX-6)



- 1. Seat back striker
- 2. Rear package trim

- 3. Rear seat catch lock

Removal / Installation page S-93